



1.10	
A16	ABS control module
K143	AC compressor clutch relay
B161	AC refrigerant pressure sensor
B138	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN	Controller area network (data bus)
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
K46	Engine control (EC) relay
A35	Engine control module (ECM)
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
K12-III	Engine coolant blower motor relay 3
B24	Engine coolant temperature (ECT) sensor
B86	Engine oil level sensor
S389	Engine oil pressure switch
Y28	Exhaust gas recirculation (EGR) solenoid
R64	Fuel filter heater
K138	Fuel heater relay
M12	Fuel pump
K20	Fuel pump relay
Y170	Fuel rail pressure (FRP) control valve
B186	Fuel rail pressure (FRP) sensor
B31	Fuel temperature sensor
B82	Fuel/water separator sensor
F	Fuse
X28	Fuse box/relay plate
A104	Glow plug control module
R5	Glow plugs
K79	Ignition main circuits relay
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
B30	Mass air flow (MAF) sensor
A11	Multifunction control module
A81	Power steering control module
VAN	Vehicle area network (data bus)
A123	Vehicle speed sensor (VSS) signal amplifier
B19	Wheel speed sensor, left front