Aruba and HP switches debug and diagnostics commands cheat sheet

Author: Yuri Slobodyanyuk, https://www.linkedin.com/in/yurislobodyanyuk/

| Command | Description |
|---|--|
| show logging -r | Show system logs and events in reverse chronological order, i.e. newest logs first. |
| clear log | Delete all logs on the switch. |
| debug destination buffer | Direct debug output to the log buffer, to be read later on CLI. |
| debug <daemon name=""></daemon> | Start runnig debug,e.g. to debug SNMP daemon: debug snmp pdu |
| show debug buffer | Show log buffer with the collected debug output. |
| show debug | Show what debug is currently active. |
| show mac-address | Show table of MAC addresses. |
| show interface status | Show list of all interfaces with info for each: state (Up/Down), Actual Speed, Tagged or not, VLANs configured for the interface (single VLAN for Untagged, multiple for Tagged). NOTE: In Cisco world Tagged interface is called trunk . |
| display interface | Show detailed information of an interface: MAC address, state, speed, VLAN id if any. |
| show interface transceiver | Info on installed optical transceivers: Port number where installed, Type/Speed, Serial Number. |
| show ip | Show all configured IP addresses on a switch. |
| show trunk | Show trunk interfaces with their state and type. NOTE: In HP/Aruba world trunk means aggregated interfaces (LACP), what in Cisco world is called port/ether-channel. |
| show trunk-statistics <trunk name=""></trunk> | Show cumulative statistics for the trunk interface: packets passed, bytes received, drops if any. |
| show lacp | Show LACP state on the trunking interfaces. |
| display stp root | Show root switch for Spanning Tree Protocol. |
| display stp brief | Short information on STP state for VLANs. |
| display lldp neighbor list | Display LLDP neighbors. |
| | |

| Command | Description |
|---|---|
| show ip ospf neighbor [detail] | Display OSPF neighbors |
| show ip route | Show routing table for Layer 3 switch. |
| show ip | Show IP routing state: disabled/enabled. It is disabled by default, to enable: (config)# ip routing on platforms that support Layer 3 routing. |
| display boot-loader | Show what image will be loaded on the next boot. |
| show time | Show switch time and date, for log correlation. |
| show power-over-ethernet brief/ethernet | Show state of PoE-enabled interfaces, including information on drawn/available power. |