This document describes the format of the SubClass element in Garmin GPX files. It is only valid for the subclass in Route points. (Excluding the end point) In the XML this is element <RtePt>.

Terminology:

BaseCamp	GPX file (XML Format)	Zumo XT		
Route	<rte></rte>	Trip		
Via Point	<rtept></rtept>			
Via Points, or <rtept> can be either:</rtept>				
 Via point (Alert on 	<trp:viapoint< li=""></trp:viapoint<>	Will alert, don't skip, can be chosen		
arrival)		as destination when starting trip.		
Via point (Don't	 <trp:shapingpoint< li=""> </trp:shapingpoint<>	Will not alert, can be skipped, can		
alert on arrival)		not be chosen when starting trip.		
Ghost Points				
• N/A	• <gpxx:rpt< td=""><td>N/A</td></gpxx:rpt<>	N/A		
		Are added by BaseCamp/MapSource		
		when a route is calculated. Points		
		are located on a Road, and have		
		road information. Can be used as a		
		basis for creating track.		

Objective:

- o Some problems found with the Zumo XT are, or at least seem to be, related to the SubClass.
 - Shaping points get renamed when importing.
 - The routing works different for Shaping points and Via. It should be the same.
 - CEP. (Closest Entry Point). When starting a route with CEP, sometimes Shaping points are ignored. Via Points seem to work more predictable.
- o Knowing what info this SubClass contains, might help resolve them.

Notes:

- This info was collected by 'reverse engineering'. It is not 100% complete, and may not be correct in all cases. Sources of info, tools used:
 - GPSBabel
 - GPSMapedit
 - JaVaWa GMTK
 - TypViewer
 - https://www.memotech.franken.de/FileFormats/Garmin_GPI_Format.pdf (Lat/Lon conversion)
- The Subclass is assigned when adding (inserting) a Via Point in Basecamp. Once assigned it is not always changed, even when it would be expected. (See Additional tests performed)

Additional tests performed:

- Create a route with start, end, and 1 shaping point. Export gpx.
 Move the 2nd shaping point. Export gpx
 Compare shows the same subclass!
- Change Map product from City Navigator to Open Street Map or vice versa. Recalculate route.
 Subclass changes. Sometimes to 'Empty'.
- Change an initial Shaping point to Via. Subclass remains the same.
- o Change an initial Via point to Shaping. Subclass changes!
- o Moving a Shaping point to another location, Subclass remains the same.
- Moving an initial Via point. Subclass remains the same. Then change to shaping, subclass changes.
- When importing a GPX file without SubClasses in Basecamp, and subsequently exporting it then
 the SubClass is reset to 'Empty'. An example of this is MyRoute App. MyRoute App has no
 knowledge of subclass. When importing a route exported from MRA all the subclasses are reset
 to 'Empty'.

The results from these tests show that Basecamp does not always update the Subclass, although it would be expected. Furthermore the 'Empty' value gets assigned in some scenario's, and does not seem to have a negative effect. Not in Basecamp nor in the XT.

Layout:

Because no documentation is available containing the layout, and I lack inspiration, I named the fields 1 to 9.

Field 1	2 Bytes	Can refer to a 'line/road', or a 'point'. See the road and point types. Screen shot from GPSMAPEDIT.	
Field 2	4 Bytes	An integer specifying the map segment nbr.	
Field 3	4 Bytes	This field is most likely a unique id of the road segment. Placing points along	
		the same road this nbr. remains the same. But when passing a junction for	
		example this nbr. changes.	
		There are clues that the last 2 bytes are flags. See RoadId Flags	
Field 4	1 Byte Looks like a type field. Values found:		
		OF = Begin	
		OD = Shaping point	
		01 = Via Point	
Following fields are only valid for Shaping Points. See the explanation in the sample.			
Field 5	1 Byte	Lat Byte 0	
Field 6	1 Byte	Lon Byte 0	
Field 7	1 Byte	Reserved = 00	
Field 8	2 Bytes	Lat Bytes 1 & 2	
Field 9	2 Bytes	Lon Bytes 1 & 2	
For Via Points			
Field 5-9	7 Bytes	To be determined.	
For Ghost	For Ghost Points <gpxx:rpt< td=""></gpxx:rpt<>		
Field 4	1 Byte	Looks like a type field. Values found:	
		21 = Begin, or End of a segment. (Segment from Route point to route point)	
		1F = Intermediate	
Field 5	1 Byte	Direction indicator. See Direction values	
Field 7-9	5 Bytes	To be determined.	

Integers have to read 'backwards'. Little Endian.

Sample RtePt:

```
<rtept lat="51.600542971864343" lon="5.660406164824963">
      <time>2022-10-09T17:45:21Z</time>
      <name>Erpseweg1</name>
      <sym>Waypoint</sym>
      <extensions>
        <trp:ShapingPoint />
        <qpxx:RoutePointExtension>
          <gpxx:Subclass>040089969800050026010D24040097B17206/gpxx:Subclass>
<!-- Note that the empty Subclass does not conflict with the fields found! -->
                <gpxx:Subclass>0400 89969800 05002601 0D 24040097B17206/gpxx:Subclass>
< ! -
Field 1 (Little Endian)
00 04
           = Road type, or Point Type. 'polyline arterial road' (See Road types)
Field 2 (Little Endian)
00 98 96 89 = 10000009 = Map Segment. (Sample is not City Navigator, but Open Street Map)
Field 3 (Little or Big Endian?)
05002601 = Unknown, probably road id for shaping point
            The values remain the same for each road segment. (Between junctions)
Field 4
0D
          = RtePt OF = Begin, OD = Shaping point, O1 = Via Point
Only valid for Shaping points. These bytes contain (part of) the Lat/Lon values of the next <qpxx:rpt
node, not the Lat/Lon values of the <rtept node.
Fields 5 to 9
        = Lat Byte 0
24
        = Lon Byte 0
        = Unknown, probably reserved for RtePt
97B1
        = Lat Bytes 1, 2
        = Lon Bytes 1, 2
24(1) 04(2) xx 97(3) B1(4) 72(5) 06(6)
First the 'real/decimal' values have to be converted to 'integer' (4 bytes). Multiply by 2^32 and
divide by 360
```

E.g.: 51,600542971864343 * 2^32 = 221622644520 / 360 = 615618457 = 24B19799 (hex) Bytes 1,2 and 3 are used like this.


```
24(1) B1(4) 97(3) 99(.) = 615618457 * 360 = 221622644520 / 2^32 = 51,600542971864343
```


$$04(2)$$
 $06(6)$ $72(5)$ $07(.) = 67531271 * 360 = 24311257560 / 2^32 = 5,660405745729804$


(.) Not used....

-->

```
<gpxx:Subclass>040089969800BC3D0000211600009A000E00/gpxx:Subclass>
</gpxx:rpt>
```







RoadId flags

Part of source code of MkgMap.

https://www.mkgmap.org.uk/download/mkgmap-r4923-src.zip mkgmap-r4923\src\uk\me\parabola\imgfmt\app\net\RoadDef.java

```
public class RoadDef {
       private static final Logger log = Logger.getLogger(RoadDef.class);
       public static final int MAX_NUMBER_NODES = 0x3ff;
        public static final int MAX_NUMBER_POLYLINES = 0x7f;
        public static final int NET_FLAG_NODINFO = 0x40;
       public static final int NET_FLAG_ADDRINFO = 0x10;
       private static final int NET_FLAG_UNK1 = 0x04; // lock on road?
       private static final int NET_FLAG_ONEWAY = 0x02;
       private static final int NOD2_FLAG_UNK
//
       private static final int NOD2_FLAG_EXTRA_DATA = 0x80; just documentation
       // first byte of Table A info in NOD 1
       private static final int TABA_FLAG_TOLL = 0x80;
        private static final int TABA_MASK_CLASS = 0x70; just documentation
//
        private static final int TABA_FLAG_ONEWAY = 0x08;
       private static final int TABA_MASK_SPEED = 0x07; just documentation
//
       private static final int TABAACCESS_FLAG_CARPOOL = 0x0008;
       private static final int TABAACCESS_FLAG_NOTHROUGHROUTE = 0x0080;
        // second byte: access flags, bits 0x08, 0x80 are set separately
        private static final int TABAACCESS_FLAG_NO_EMERGENCY = 0x8000;
        private static final int TABAACCESS_FLAG_NO_DELIVERY = 0x4000;
        private static final int TABAACCESS_FLAG_NO_CAR = 0x0001;
        private static final int TABAACCESS_FLAG_NO_BUS
        private static final int TABAACCESS_FLAG_NO_TAXI
                                                          = 0x0004;
       private static final int TABAACCESS_FLAG_NO_FOOT = 0x0010;
       private static final int TABAACCESS_FLAG_NO_BIKE = 0x0020;
        private static final int TABAACCESS_FLAG_NO_TRUCK = 0x0040;
```

Direction values

This table is taken initially from:

https://www.memotech.franken.de/FileFormats/Garmin MPS GDB and GFI Format.pdf (Look for Direction icon:)

	1
Direction indicator	Description
(Decimal)	·
	Cantinus
0	Continue
2, 15, 18	Right
3	Sharp Right
4	U-Turn
5	Sharp Left
6, 16, 19	Left
8, 11, 13, 17, 20, 21	Ahead
10	Turn Right
12	Ferry
14	Roundabout
22	Leave route point
23	Approach route point
24	Turn Left
25	Turn Right
29, 34, 35, 36	Route point
79	Exit Roundabout