

# **RISC-V**

Reference Data v1.8

BANIEBA CONIC	ED 47	- 81 8 8 4 5	DESCRIPTION (in Marile a)	Nata	CVAITAV	ODCODE	FUNCT		Data VI.O
MNEMONIC	FIVI		DESCRIPTION (in Verilog)		SYNTAX	OPCODE		FUNCT7 RS2	HEX
lb		Load Byte	$R[rd]={24'bM[](7),M[R[rs1]+imm](7:0)}$	4)	lb rd,imm(rs1)	0000011	000		03/0
lh		Load Halfword	R[rd]={16'bM[](15),M[R[rs1]+ imm](15:0)}	4)	lh rd,imm(rs1)	0000011	001		03/1
lw	1	Load Word	R[rd]=M[R[rs1]+imm]		lw rd,imm(rs1)	0000011	010		03/2
lbu	1	Load Byte Unsigned	R[rd]={24'b0,M[R[rs1]+imm](7:0)}		lbu rd,imm(rs1)	0000011	100		03/4
lhu	!	Load Halfword Unsigned	R[rd]={16'b0,M[R[rs1]+ imm](15:0)}		lhu rd,imm(rs1)	0000011	101		03/5
addi	!	Add Immediate	R[rd]=R[rs1]+imm		addi rd,rs1,imm	0010011	000	0000000	13/0
slli	1	Shift Left Logical Imm	R[rd]=R[rs1]< <imm< td=""><td></td><td>slli rd,rs1,imm</td><td>0010011</td><td>001</td><td>0000000</td><td>13/1/00</td></imm<>		slli rd,rs1,imm	0010011	001	0000000	13/1/00
	1	Set Less Than Immediate	R[rd]=(R[rs1] <imm)?1:0< td=""><td>٥١</td><td>slti rd,rs1,imm</td><td>0010011</td><td>010</td><td></td><td>13/2</td></imm)?1:0<>	٥١	slti rd,rs1,imm	0010011	010		13/2
sltiu	1	Set Less Than Imm Unsig	R[rd]=(R[rs1] <imm)?1:0< td=""><td>2)</td><td>sltiu rd,rs1,imm</td><td>0010011</td><td>011</td><td></td><td>13/3</td></imm)?1:0<>	2)	sltiu rd,rs1,imm	0010011	011		13/3
xori	1	XOR Immediate	R[rd]=R[rs1]^imm		xori rd,rs1,imm	0010011	100		13/4
srli	1	Shift Right Logical Imm	R[rd]=R[rs1]>>imm	_,	srli rd,rs1,imm	0010011	101	0000000	13/5/00
srai	1	Shift Right Arith Imm	R[rd]=R[rs1]>>>imm	5)	srai rd,rs1,imm	0010011	101	0100000	13/5/20
ori	1	OR Immediate	R[rd]=R[rs1] imm		ori rd,rs1,imm	0010011	110		13/6
andi	1	AND Immediate	R[rd]=R[rs1] & imm		andi rd,rs1,imm	0010011	111		13/7
auipc		Add Upper Immediate to PC			auipc rd,imm	0010111			17
sb	S	Store Byte	M[R[rs1]+imm](7:0)=R[rs2](7:0)		sb rs2,imm(rs1)	0100011	000		23/0
sh	S	Store Halfword	M[R[rs1]+imm](15:0)=R[rs2](15:0)		sh rs2,imm(rs1)	0100011	001		23/1
SW	S	Store Word	M[R[rs1]+imm]=R[rs2]		sw rs2,imm(rs1)	0100011	010		23/2
add	R	Add	R[rd]=R[rs1]+R[rs2]		add rd,rs1,rs2	0110011	000	0000000	33/0/00
sub	R	Subtract	R[rd]=R[rs1]-R[rs2]		sub rd,rs1,rs2	0110011	000	0100000	33/0/20
sll	R	Shift Left Logical	R[rd]=R[rs1]<< R[rs2]		sll rd,rs1,rs2	0110011	001	0000000	33/1/00
slt	R	Set Less Than	R[rd]=(R[rs1] <r[rs2])?1:0< td=""><td></td><td>slt rd,rs1,rs2</td><td>0110011</td><td>010</td><td>0000000</td><td>33/2/00</td></r[rs2])?1:0<>		slt rd,rs1,rs2	0110011	010	0000000	33/2/00
sltu	R	Set Less Than Unsigned	R[rd]=(R[rs1] <r[rs2])?1:0< td=""><td>2)</td><td>sltu rd,rs1,rs2</td><td>0110011</td><td>011</td><td>0000000</td><td>33/3/00</td></r[rs2])?1:0<>	2)	sltu rd,rs1,rs2	0110011	011	0000000	33/3/00
xor	R	XOR	R[rd]=R[rs1]^R[rs2]		xor rd,rs1,rs2	0110011	100	0000000	33/4/00
srl	R	Shift Right Logical	R[rd]=R[rs1]>>R[rs2]		srl rd,rs1,rs2	0110011	101	0000000	33/5/00
sra	R	Shift Right Arithmetic	R[rd]=R[rs1]>>>R[rs2]	5)	sra rd,rs1,rs2	0110011	101	0100000	33/5/20
or	R	OR	R[rd]=R[rs1] R[rs2]		or rd,rs1,rs2	0110011	110	0000000	33/6/00
and	R	AND	R[rd]=R[rs1] & R[rs2]		and rd,rs1,rs2	0110011	111	0000000	33/7/00
lui	U	Load Upper Immediate	R[rd]={imm,12'b0}		lui rd,imm	0110111			37
beq	SB	Branch if Equal	if(R[rs1]=R[rs2]) PC=PC+{imm,1'b0}		beq rs1,rs2,imm	1100011	000		63/0
bne	SB	Branch if Not Equal	if(R[rs1]!=R[rs2]) PC=PC+{imm,1'b0}		bne rs1,rs2,imm	1100011	001		63/1
blt	SB	Branch if Less Than	if(R[rs1] <r[rs2]) pc="PC+{imm,1'b0}&lt;/td"><td></td><td>blt rs1,rs2,imm</td><td>1100011</td><td>100</td><td></td><td>63/4</td></r[rs2])>		blt rs1,rs2,imm	1100011	100		63/4
bge	SB	Branch Greater or Equal	if(R[rs1]>=R[rs2]) PC=PC+{imm,1'b0}		bge rs1,rs2,imm	1100011	101		63/5
bltu	SB	Branch Less Than Unsign	if(R[rs1] <r[rs2]) pc="PC+{imm,1'b0}&lt;/td"><td>2)</td><td>bltu rs1,rs2,imm</td><td>1100011</td><td>110</td><td></td><td>63/6</td></r[rs2])>	2)	bltu rs1,rs2,imm	1100011	110		63/6
bgeu	SB	Branch Great or Eq Unsign	if(R[rs1]>=R[rs2]) PC=PC+{imm,1'b0}	2)	bgeu rs1,rs2,imm	1100011	111		63/7
jalr	T	Jump & Link Register	R[rd]=PC+4; PC=(R[rs1]+imm)&(!1)	3)	jalr rd,rs1,imm	1100111	000		67/0
jal	UJ	Jump & Link	R[rd]=PC+4; PC=PC+{imm,1'b0}	,	jal rd,imm	1101111			6F
ecall	T	Environment CALL	Transfer control to environment system		ecall	1110011	000	0000000 00000	73/0/000
csrrw	1	CSR Read & Write	R[rd]=CSR; CSR=R[rs1]		csrrw rd,rs1	1110011	001		73/1
csrrs	T	CSR Read & Set	R[rd]=CSR; CSR=CSR R[rs1]		csrrs rd,rs1	1110011	010		73/2
csrrc	1	CSR Read & Clear	R[rd]=CSR; CSR=CSR&!R[rs1]		csrrc rd,rs1	1110011	011		73/3
csrrwi	Т	CSR Read & Write Imm	R[rd]=CSR; CSR=imm		csrrwi rd,imm	1110011	101		73/5
csrrsi	1	CSR Read & Set Imm	R[rd]=CSR; CSR=CSR imm		csrrsi rd,imm	1110011	110		73/6
csrrci	T	CSR Read & Clear Imm	R[rd]=CSR; CSR=CSR&!imm		csrrci rd,imm	1110011	111		73/7
mul	R	Multiply	R[rd]=R[rs1]*R[rs2](31:0)		mul rd,rs1,rs2	0110011	000	0000001	33/0/01
mulh	R	Multiply upper Half	R[rd]=R[rs1]*R[rs2](63:32)		mulh rd,rs1,rs2	0110011	001	0000001	33/1/01
mulhsu	R	Mult upper Half Sign/Uns	R[rd]=R[rs1]*R[rs2](63:32)	6)	mulhsu rd,rs1,rs2		010	0000001	33/2/01
mulhu	R	Mult upper Half Unsig	R[rd]=R[rs1]*R[rs2](63:32)	2)	mulhu rd,rs1,rs2	0110011	011	0000001	33/3/01
div	R	Divide	R[rd]=(R[rs1]/R[rs2])	_,	div rd,rs1,rs2	0110011	100	0000001	33/4/01
divu	R	Divide Unsigned	R[rd]=(R[rs1]/R[rs2])	2)	divu rd,rs1,rs2	0110011	101	0000001	33/5/01
rem	R	Remainder	R[rd]=(R[rs1]%R[rs2])	-,	rem rd,rs1,rs2	0110011	110	0000001	33/6/01
remu	R	Remainder Unsigned	R[rd]=(R[rs1]%R[rs2])	2)	remu rd,rs1,rs2	0110011	111	0000001	33/7/01
fadd.s	R	Float Point Add	F[rd]=F[rs1]+F[rs2]	-1	fadd.s rd,rs1,rs2	1010011	rm	0000001	53/7/01 53/rm/00
fclass.s	R	Classify type	R[rd]=class(F[rs1])	8)	fclass.s rd,rs1	1010011	001	1110000	53/11/E0
fcvt.s.w	R	Convert from Integer	F[rd]=float(R[rs1])	٥)	fcvt.s.w rd,rs1	1010011	rm	1101000	
fcvt.s.wu		Convert Horri Integer	F[rd]=float(R[rs1])	2)	fcvt.s.wu rd,rs1	1010011	rm	1101000 00000	53/rm/D01
fcvt.w.s	R	Convert to Integer	R[rd]=integer(F[rs1])	۷)	fcvt.w.s rd,rs1	1010011	rm	1101000 00001	
fcvt.wu.s		Convert to Integer  Convert to Unsign Integer	R[rd]=integer(F[rs1]) R[rd]=integer(F[rs1])	2)	fcvt.w.s rd,rs1	1010011		1100000 00000	
fdiv.s	R	Float Point Divide	F[rd]=F(rs1]/F[rs2]	۷)	fdiv.s rd,rs1,rs2		rm		
feq.s						1010011 1010011	rm 010	0001100 1010000	53/rm/0C
fle.s	R	Compare Float Loss or Equal	R[rd]=(F[rs1]==F[rs2])?1:0		feq.s rd,rs1,rs2		010		53/2/50
	R	Comp Float Less or Equal	R[rd]=(F[rs1]<=F[rs2])?1:0		fle.s rd,rs1,rs2	1010011	000	1010000	53/0/50
flt.s	R	Compare Float Less Than	R[rd]=(F[rs1] <f[rs2])?1:0< td=""><td></td><td>flt.s rd,rs1,rs2</td><td>1010011</td><td>001</td><td>1010000</td><td>53/1/50</td></f[rs2])?1:0<>		flt.s rd,rs1,rs2	1010011	001	1010000	53/1/50
flw	L	Float Point Load	F[rd]=M[R[rs1]+imm]		flw rd,imm(rs1)	0000111	010	0010100	07/2
fmax.s	R	FP Maximum	F[rd]=(F[rs1]>F[rs2])?F[rs1]: F[rs2]		fmax.s rd,rs1,rs2	1010011	001	0010100	53/1/14
fmin.s	R	FP Minimum	F[rd]=(F[rs1] <f[rs2])?f[rs1]: f[rs2]<="" td=""><td></td><td>fmin.s rd,rs1,rs2</td><td>1010011</td><td>000</td><td>0010100</td><td>53/0/14</td></f[rs2])?f[rs1]:>		fmin.s rd,rs1,rs2	1010011	000	0010100	53/0/14
fmul.s	R	Float Point Multiply	F[rd]=F[rs1]*F[rs2]		fmul.s rd,rs1,rs2	1010011	rm	0001000	53/rm/08
fmv.s.x	R	Move from Integer	F[rd]=R[rs1]		fmv.s.x rd,rs1	1010011	000	1111000 00000	53/0/F00
fmv.x.s	R	Move to Integer	R[rd]=F[rs1]		fmv.x.s rd,rs1	1010011	000	1110000 00000	53/0/E00
fsgnj.s	R	Sign source	F[rd]={F[rs2](31),F[rs1](30:0)}		fsgnj.s rd,rs1,rs2	1010011	000	0010000	53/0/10
fsgnjn.s	R	Negative Sign source	F[rd]={!F[rs2](31),F[rs1](30:0)}		fsgnjn.s rd,rs1,rs2		001	0010000	53/1/10
fsgnjx.s		XOR Sign source	F[rd]={F[rs2](31)^F[rs1](31), F[rs1](30:0)}		fsgnjx.s rd,rs1,rs2		010	0010000	53/2/10
fsqrt.s	R	FP Square Root	F[rd]=sqrt(F[rs1])		fsqrt.s rd,rs1	1010011	rm	0101100 00000	53/rm/580
fsub.s	R	Float Point Subtract	F[rd]=F[rs1]-F[rs2]		fsub.s rd,rs1,rs2	1010011	rm	0000100	53/rm/04
fsw	S	Float Point Store	M[R[rs1]+imm]=F[rs2]		fsw rs2,imm(rs1)	0100111	010		27/2
uret	R	User Return	PC=CSR[UEPC] and other settings		uret	1110011	000	0010000 00000	73/0/200

	NOTES
2)	Operation assumes unsigned integers (instead 2's complement)
3)	The least significant bit of the branch address in jalr is set to 0
4)	(signed) Load instructions extend the sign bit of data
5)	Replicates the sign bit to fill in the leftmost bits of the result during right shift
6)	Multiply with one operand signed and one unsigned
8)	Classify writes a 10-bit mask to show which properties are true
	(e.g. −inf, -0, +0, +inf, denorm)
	The immediate field is sign-extended in RISC-V

## CORE INSTRUCTION FORMATS

	31 25	24 20	19	15 1	L4 12	11 7	6	0
R	funct7	rs2	rs1		funct3	Rd	opcode	
1	imm[1	1:0]	rs1		funct3	Rd	opcode	
S	imm[11:5]	rs2	rs1		funct3	imm[4:0]	opcode	
SB	imm[12 10:5]	rs2	rs1		funct3	imm[4:1 11]	opcode	
U		imm[31:1	.2]			Rd	opcode	
UJ	im	m[20 10:1 1	1 19:12]			Rd	opcode	

PSEUDO INS	TRUCTIONS	*non-exhaustive list
MNEMONIC	NAME	DESCRIPTION
beqz	Branch == Zero	If(R[rs1]==0) PC=PC+{imm,1'b0}
bnez	Branch != Zero	If(R[rs1]!=0) PC=PC+{imm,1'b0}
fabs.s	Absolut Value	F[rd]=(F[rs1]<0)?-F[rs1]:F[rs1]
fmv.s	FP move	F[rd]=F[rs1]
fneg.s	FP negate	F[rd]=-F[rs1]
j	Jump	PC={imm,1'b0}
jr	Jump Register	PC=R[rs1]
la	Load Address	R[rd]=address
li	Load Immediate	R[rd]=immediate
mv	Move	R[rd]=R[rs1]
neg	Negate	R[rd]=-R[rs1]
nop	No Operation	R[zero]=R[zero]+zero
not	Not	R[rd]=!R[rs1]
ret	Return	PC=R[ra]
seqz	Set if == Zero	R[rd]=(R[rs1]==0)?1:0
snez	Set if != Zero	R[rd]=(R[rs1]!=0)?1:0

	Decim	Binary P	refix		
mili(m)	10 <sup>-3</sup>	kilo(k)	10 <sup>3</sup>	kibi(ki)	2 <sup>10</sup>
micro(μ)	10 <sup>-6</sup>	Mega(M)	10 <sup>6</sup>	Mebi(Mi)	2 <sup>20</sup>
nano(n)	10 <sup>-9</sup>	Giga(G)	10 <sup>9</sup>	Gibi(Gi)	2 <sup>30</sup>
pico(p)	10 <sup>-12</sup>	Tera(T)	10 <sup>12</sup>	Tebi(Ti)	2 <sup>40</sup>
femto(f)	10 <sup>-15</sup>	Peta(P)	10 <sup>15</sup>	Pebi(Pi)	2 <sup>50</sup>
atto(a)	10 <sup>-18</sup>	Exa(E)	10 <sup>18</sup>	Exbi(Ei)	2 <sup>60</sup>
zepto(z)	10 <sup>-21</sup>	Zetta(Z)	10 <sup>21</sup>	Zebi(Zi)	2 <sup>70</sup>
yocto(y)	10 <sup>-24</sup>	Yotta(Y)	10 <sup>24</sup>	Yobi(Yi)	2 <sup>80</sup>

## IEEE 754 FLOATING-POINT STANDARD

 $(-1)^S \times (1 + Fraction) \times 2^{(Expoent-Bias)}$ 

Half-precision Bias = 15 Single-Precision Bias = 127 Double-Precision Bias = 1023 Quad-Precision Bias = 16383

## IEEE Half, Single, Double, and Quad-Precision Formats:

S	Exponent		Fraction			
15	14:10		9:0		_	
S	Exponent		Fraction			
31	30:23		22:0			
S	Exponent		Fraction			
63	62:52		51:0			
S	Exponent		Fraction			
127	126:112			111	1:0	

FCSR (Float-point Control and Status Register)

	resk (rioat-point control and status kegister)									
31	***	8	7	6	5	4	3	2	1	0
Reserved			Round Mode			NV	DZ	OF	UF	NX

## Round Mode(rm)

000	to even
001	to zero
010	to -∞
011	to +∞
100	to max mag
111	N.A. (Rars)

## Flags

NV	Invalid Operation
DZ	Divide by Zero
OF	Overflow
UF	Underflow
NX	Inexact

### **REGISTER NAME, USE, CALLING CONVENTION**

REGISTER NAME			CAVEDO
REGISTER	NAME	USE	SAVED?
x0	zero	The constant value 0	N.A.
x1	ra	Return Address	No
x2	sp	Stack Pointer	Yes
x3	gp	Global Pointer	
x4	tp	Thread Pointer	
x5-x7	t0-t2	Temporaries	No
x8	s0/fp	Saved Register/Frame Pointer	Yes
х9	s1	Saved Register	Yes
x10-x11	a0-a1	Function Arguments/Return Values	No
x12-x17	a2-a7	Function Arguments	No
x18-x27	s2-s11	Saved Registers	Yes
x28-x31	t3-t6	Temporaries	No
f0-f7	ft0-ft7	FP Temporaries	No
f8-f9	fs0-fs1	FP Saved Registers	Yes
f10-f11	fa0-fa1	FP Function Arguments/Return Values	No
f12-f17	fa2-fa7	FP Function Arguments	No
f18-f27	fs2-fs11	Saved Registers	Yes
f28-f31	ft8-ft11	Temporaries	No

Service	a7	Input	Output
Print Integer	1	a0=integer	Print an Integer on console
Print Float	2	fa0=float	Print a Float on console
Print String	4	a0=address of the string	Print a null-terminated string
Read Integer	5		Return in a0 the integer read from console
Read Float	6		Return in fa0 the float read from console
Read String	8	a0=buffer address,	Return in a0 address the string read from
Read String	0	a1=max num characters	console
Print Char	11	a0=char (ASCII)	Print a char a0 (ASCII)
Exit	10		Return to operational system
Read Char	12		Return in a0 the ASCII code of a pressed key
Time	30		Return in {a1,a0} the system time
Sleep	32	a0=time(ms)	Sleep for a0 milliseconds
Print Int Hex	34	a0=integer	Print an integer a0 in hexadecimal
Rand	41		Return a random number in a0