pi_ager install on Raspberry Pi 3/Pi 4/ Pi zero w under Pi OS (32-bit) with desktop and recommended software or Pi OS Lite

- For Pi 4/3: Download and install Raspberry Pi OS with desktop and recommended software from https://www.raspberrypi.org/software/operating-systems/
- <u>For Pi zero:</u> Download and install Raspberry Pi OS Lite from https://www.raspberrypi.org/software/operating-systems/
- Enable SSH for remote access sudo touch /boot/ssh
- Setup WLAN configuration
 Generate file wpa supplicant.conf in /boot:

```
country=DE
ctrl_interface=DIR=/var/run/wpa_supplicant GROUP=netdev
update_config=1
network={
    ssid="WLAN SSID"
    psk="WLAN PASSWORT"
}
```

• Edit config.txt in /boot to support I2C and SPI devices:

```
# Additional overlays and parameters are documented /boot/overlays/README # Use Pi-Ager Pins 11/13 GPIO 17/27 for I2C dtoverlay=i2c-gpio,bus=3,i2c_gpio_sda=17,i2c_gpio_scl=27 # Use Pi-Ager Pin 16 for MCP3204 dtoverlay=spi1-1cs,cs0_pin=16
```

- Add in /boot/cmdline.txt at the end of line this to enable USB camera with fswebcam: dwc_otg.fiq_fsm_mask=0x3
- Reboot system
- Edit /etc/modules to load i2c-dev at boot, add this line :
 i2c-dev
- Add file: sudo touch /etc/modprob.d/raspi-blacklist.conf
- Get a copy from Pi-Ager repository to your local system: git clone –b entwicklung https://github.com/Tronje-the-Falconer/Pi-Ager All project file are now in the folder ./Pi-Ager/
- Copy setup.txt from local repository to /boot/ and edit it as needed.
- Copy /etc/modprobe.d/Pi-Ager_i2c_off.conf.on from local repository to /etc/modprobe.d/

Reboot system

```
Install lighttpd:
  sudo apt-get update
  sudo apt-get upgrade
  sudo apt-get install lighttpd
  sudo systemctl status lighttpd
  sudo nano /etc/lighttpd/lighttpd.conf
  and change Parameter
  server.document-root = "/var/www/html"
  server.document-root = "/var/www"
  sudo usermod -G www-data -a pi
  sudo chown -R www-data:www-data/var/www
  sudo chmod -R 755 /var/www
Reboot system
  For testing the web server, generate html-page:
  sudo nano /var/www/test.html
  with content:
  <html>
  <head><title>Test-Seite</title></head>
  <body>
  <h1>Das ist eine Test-Seite.</h1>
  </body>
  </html>
  Enter your IP Address (or localhost) into the browser followed by /test.html
  In addition we need .htcredentials to contain user and password.
  Fort that we use the Online-Tool https://websistent.com/tools/htdigest-generator-tool/
  Username: pi-ager
  REALM: Pi-Ager
  Password: raspberry
  Caution! All entries are case sensitive!
  Open this file now
  sudo nano /var/.htcredentials
  and fill in the string output from the generator tool.
```

Now we have to setup the password authentification in lighttpd:

Save file with "STRG+o", "RETURN" and close with "STRG+x"

```
The following lines are added under server.modules += ("mod_auth"):
        auth.backend
                                = "htdigest"
        auth.backend.htdigest.userfile = "/var/.htcredentials"
                               = ( "/settings.php" =>
        auth.require
                           "method" => "digest",
                           "realm" => "Pi-Ager",
                           "require" => "user=pi-ager"
                           "/admin.php" =>
                           "method" => "digest",
                           "realm" => "Pi-Ager",
                           "require" => "valid-user"
                           "/webcam.php" =>
                           "method" => "digest",
                           "realm" => "Pi-Ager",
                           "require" => "valid-user"
                           "/notification.php" =>
                           "method" => "digest",
                           "realm" => "Pi-Ager",
                           "require" => "valid-user"
        Then we activate this modul:
        sudo lighty-enable-mod auth
In addition we have to edit:
sudo nano /etc/lighttpd/conf-available/15-fastcgi-php.conf
add at the end of the line
"broken-scriptfilename" => "enable"
a "," and in a new line
"allow-x-send-file" => "enable"
Save end exit nano.
Now enable these modules:
sudo lighty-enable-mod fastcgi
sudo lighty-enable-mod fastcgi-php
```

Now reload the the webserver: sudo service lighttpd force-reload

sudo nano /etc/lighttpd/conf-available/05-auth.conf

Now continue to install additional modules:

- Install Git sudo apt install git
- Install smbus sudo apt-get install python3-smbus
- Install sqlite3: sudo apt install sqlite3
- Install DHT sensor support sudo pip3 install Adafruit-DHT
- Install SHT1x sensors sudo pip3 install pi-sht1x
- Install libgd-dev (needed for new version of fswebcam) sudo apt install libgd-dev
- Install fswebcam: sudo apt install fswebcam
- Install influxdb sudo pip3 install influxdb
- Install php 7.3 sudo apt install php7.3-common php7.3-cgi php7.3 php7.3-sqlite3
- Install additional modules for php7.3:
 sudo apt install php7.3-apcu php7.3-fpm php7.3-mbstring php7.3-phpdebug
- Install wiringpi: sudo apt install wiringpi
- Install wiringpi new version with Pi4 support :
 cd /tmp

wget https://project-downloads.drogon.net/wiringpi-latest.deb sudo dpkg -i wiringpi-latest.deb

- Copy gpio to /usr/local/bin sudo cp /usr/bin/gpio /usr/local/bin sudo chmod 4755 /usr/local/bin/gpio
- Install PiShrink

wget https://raw.githubusercontent.com/Drewsif/PiShrink/master/pishrink.sh chmod +x pishrink.sh sudo mv pishrink.sh /usr/local/bin

 Nextion serial client (HMI Dislplay support) sudo pip3 install nextion php zip support:
 sudo apt update
 sudo apt install php-zip

 Install Isof command: sudo apt update sudo apt install Isof

- Install Locale en-GB and de-DE UTF-8 using sudo raspi-config
- Enable Serial Interface, disable login, needed for HMI Nextion Display sudo raspi-config
- Install zip and unzip: sudo apt install zip unzip
- Workaround for Adafruit_DHT for Pi4: In "/usr/local/lib/python3.7/dist-packages/Adafruit_DHT/platform_detect.py", you can add the followings at line #112 in the elif ladder, so it should workaround the issue.

```
elif match.group(1) == 'BCM2711': return 3
```

 Unblock wifi for Pi4, add rfkill unblock wifi and disable power management for wlan0: cd /etc
 sudo nano rc.local

```
GNU nano 3.2
                                                 /etc/rc.local
!/bin/sh -e
 This script is executed at the end of each multiuser runlevel.
 Make sure that the script will "exit 0" on success or any other
 value on error.
 In order to enable or disable this script just change the execution
 bits.
 By default this script does nothing.
Print the IP address
IP=$(hostname -I) || true
f [ "$ IP" ]; then
 printf "My IP address is %s\n" "$ IP"
rfkill unblock wifi
disable pwr mgmt for wlan0 to increase wlan reliability
iwconfig wlan0 power off
```

Generate/edit crontab to prepare for automatic enable pi-ager_backup.sh

Use visudo to edit /etc/sudoers, so that the www-data User (User of Website) can execute /var/sudowebscript.sh:

```
sudo visudo
and then in sudoers following
...
#User privilege specification
root ALL=(ALL:ALL) ALL
...
adding:
```

www-data ALL=NOPASSWD:/var/sudowebscript.sh

Save and exit.

- Now copy all files and folders from your local git repository /var/www to /var/www/
- from local repository /opt/pi-ager/ to /opt/pi-ager/
- from local repository /var/sudowebscript.sh to /var/
- sudo chown –R www-data:www-data /var/www
- sudo chown root:root /var/www/

- sudo usermod –G gpio –a www-data
- sudo chmod 666 /var/www/logs/logfile.txt
- sudo chown –R root:root /var/www/logs
- sudo chmod 755 /var/www/logs/
- sudo chmod 664 /var/www/config/pi-ager.sqlite3
- sudo chown -R www-data:www-data/var/www/config/
- sudo chmod 555 /var/sudowebscript.sh
- from local repository /usr/local/bin/*.sh copy all to /usr/local/bin/
 (pi-ager_backup.sh, pi-ager_image.sh,setup_pi-ager.sh)
 Set +x mode to the scripts:
 sudo chmod +x /usr/local/bin/*.sh
- from local repository /lib/systemd/system copy the following files to /lib/systemd/system/: pi-ager_main.service setup_pi-ager.service
- from local repository /usr/bin copy the following file to /usr/bin/. This is a newer version of fswebcam with re-get frame on error.

fswebcam
Set +x mode to fswebcam:
sudo chmod +x /usr/bin/fswebcam

- from local repository /usr/share/man/man1/fswebcam.1.gz copy the following file to /usr/share/man/man1/
 fswebcam.1.gz
- Enable setup_pi-ager.service to initialize system with data from /boot/setup.txt after next reboot:

sudo systemctl enable setup_pi-ager sudo reboot