

PROTOCOL DOCUMENT	P-27
Manage Raster	28/06/2021

## **GOALS**

Information on how Giswater handles rasters, as well as how they can be loaded on both a LINUX server and a Windows server

#### DESCRIPTION

#### 1 - SYSTEM TABLES, VARIABLES AND FUNCTIONS

The two tables that act on the system are:

ext\_raster\_dem ext\_cat\_raster

They are already created but the ext\_raster\_dem comes without *constraints*. In the case of existing **utils** schema, they are stored there, but have the different names:

raster\_dem cat raster

The raster\_dem table is filled from the outside according to the process explained in step 2.

In case of being in a utils corporate schema, the catalog table is filled automatically with an *AFTER INSERT* trigger in the raster taking:

file name (rastercat\_id)

cur\_user tstamp

On the other hand, in order to use this functionality, there are two variables:

```
SYSTEM: admin_raster_dem (must be TRUE)

USER: edit_insert_elevation_from_dem (must be TRUE)

edit_update_elevation_from_dem (must be TRUE)
```

The *node / connec triggers functions* in both *Insert* and *Update* capture automatic dimension value. On the other hand, the *toolbox's* **gw\_fct\_update\_elevation\_from\_dem** function automatically triggers the capture of all dimensions for the selected layer.

#### 2 - LOAD RASTER IN DB

The clear concepts to take into account are:

#### File name:

It is recommended that the name should include as much information as possible about the raster since it will give information in the meta table of ext\_cat\_raster about the type that it is:

```
dg_dem_2019_u48 (provider, raster type, data year, map sheet)
```

In this way, when the raster is inserted, the raster catalog is also filled and it carries detailed information about it.

## File typology:

If all DEM rasters are inserted into the same table, they must all be the same in terms of format so that the table column *constraints* does not break.

In this sense, when loading the first raster, the *constraints* must be created as defined in the point two of this document.



PROTOCOL DOCUMENT	P-27
Manage Raster	28/06/2021

#### Raster stored inside or outside of ddbb

Since there are two O/S environments for the machine where PostgreSQL is hosted, this process is detailed for each of the two environments.

Very interesting option for not loading the database and *reload* files automatically (you just have to change the file)

#### **WINDOWS ENVIRONMENT**

- 1. Check that there is a raster2pgsql executable in the PostgreSQL bin folder.
- 2. Open command prompt (cmd), go to the PostgreSQL bin folder (cd C:\Program Files\PostgreSQL\ 11\ bin\).
- 3. Execute the process as in the example, putting the SRID, the path to the file, the size of the *tile*, the name of the table to which the raster is imported and the connection to the database:

raster2pgsql.exe -R -s 25831 -C -x raster.txt -t 1500x1500 -a utils.raster\_dem -F -n rastercat\_id | psql -d giswater -U postgres -p 5432

#### LINUX ENVIRONMENT

It will depend on the distribution, but as a general rule it should be such that:

Since PostgreSQL normally installs on path, the command line can be totally straightforward:

raster2pgsql -s 25831 -C -x raster.txt -t 1500x1500 -a utils.raster\_dem -F -n rastercat\_id | psql -d giswater -U postgres -p 5432

If for whatever reason the environment variables are disabled, they should be enabled:

**OPTION A**: environment file (with a service postgresql reload)

POSTGIS\_ENABLE\_OUTDB\_RASTERS=1
POSTGIS\_GDAL\_ENABLED\_DRIVERS=ENABLE\_ALL

## **OPTION B**: through console (much easier)

SET postgis.enable\_outdb\_rasters TO True; SET postgis.enabled drivers TO enable all;

## **USER WARNING:**

If it is done with a PostgreSQL user, this must have read permissions for the file. If it is done with another user (*root* type) this must be registered in pg\_hba.conf and in SGDB.

## **SENTENCE NOTATIONS:**

[-R] -s 25831 -C -x raster.txt -t 1500x1500 -a utils.raster\_dem -F -n rastercat\_id | psql -d giswater -U postgres -p 5432

[-R] (OPTIONAL) raster is stored outside the database. Failing that, it is stored inside.

WARNING: Problem is that it is not easy to work with. May be system user and postgres user must be the same and with permissions to read/write on files



PROTOCOL DOCUMENT	P-27
Manage Raster	28/06/2021

Optional and essential depending on the chosen storage strategy.

NOTE: FOR THIS OPTION YOU MUST HAVE THE VARIABLES:

POSTGIS\_ENABLE\_OUTDB\_RASTERS POSTGIS\_GDAL\_ENABLED\_DRIVERS=ENABLE\_ALL

[-s 25831] SRID, mandatory

[-C] add constraints

# Required only on loading the first raster. The constraints are:

raster height (number of rows in table), enforce\_height\_rast raster width (number of columns in the raster): enforce\_width\_rast value for no data: enforce\_nodata\_values\_rast number of bands (for dem 1) enforce\_num\_bands\_rast pixel type (1bit, 2bit, 4bit....) enforce\_pixel\_types\_rast set the scale for x: enforce\_scalex\_rast set the scale for y: enforce\_scaley\_rast set SRID: enforce\_srid\_rast out\_db (info maintenance outside database) extension (enforce\_max\_extent\_rast)

[-x] excludes the *constraint* from the spatial dimension. Mandatory to use if the purpose is to put more than one raster in the same table (which will be usual) extension (enforce max extent rast)

#### [raster.txt]

File name

Without spacing, but with metadata.

## [-t 1500x1500]

Ddbb cell size.

Has limits - 5000x5000 - *Error out of memory. Failed on request of size*. Recommended size should not exceed 2000x2000 per row.

A new table will be created in the database (*updates* are not allowed) with the defined structure. The process divides the raster into parts (based on the defined size), each *row* in the table is a part of the raster.

The key point is that the size of the input 1500x1500 is a divisor of the raster size. Ideal divisor 1 to 1 but if the raster exceeds 2000x2000 it should be divided (always with dividers...). Examples:

```
for raster of 1000x1000 \rightarrow t\ 1001x1001 (will be in 1 rows) for raster of 1000x1000 \rightarrow t\ 1000x1000 (will be in 4 rows) for raster of 2000x2000 \rightarrow t\ 2001x2001 (will be in 1 rows) for raster of 2200x2200 \rightarrow t\ 1100x1100 (will be in 4 rows) for raster of 5555x5555 \rightarrow t\ 1111x1111 (will be in 16 rows)
```

[-a utils.raster\_dem] adds raster to the table, **mandatory** since otherwise it would create a new one with the conflict that this means.



PROTOCOL DOCUMENT	P-27
Manage Raster	28/06/2021

[-F] adds file name, **mandatory** and important to know file name.

[-n rastercat id] for the name of the column where to insert the file name. Mandatory

# [] -d giswater -U postgres -p 5432]

Connection parameters: if done with a PostgreSQL user, it is direct. If it is done with another user, it will ask for the password which can also obviously be done...

#### FOR MASSIVE LOADING PROCESSES

#### **NOTES**

- Watch out for the constraints
HINT: LOAD THE CONSTRAINT THEME FIRST AND THEN THE OTHERS

#### O/S

#### **WINDOWS**

for /r %%i in (\*) do "%PG\_PATH%/raster2pgsql.exe" -R -s 25830 -x %%i -t 1500x1500 -a utils.raster\_dem -F -n rastercat id | "%PG\_PATH%/psql" -h 192.168.99.124 -d gis -U bgeoadmin

(Attach a bat file)

# **LINUX**

# Hint:

The user (\$userSystem) must be the same as the one that is connected to the machine, otherwise the password issue is necessary and it becomes complicated (peer method, modify pg\_hba...)

Watch out with the path (files & raster2pgsql)

## Sentence

TEST:

for f in \*.txt; do echo "Test \$f"; done

# **EXECUTION:**

for f in \*.txt; do /raster2pgsql -R -s 25831 -C -x \$f -t 1500x1500 -a utils.raster\_dem -F -n rastercat\_id | psql -d giswater -U \$userSystem -p 5432

## REFERENCES

Documentation: <a href="https://postgis.net/docs/using\_raster\_dataman.html">https://postgis.net/docs/using\_raster\_dataman.html</a>



PROTOCOL DOCUMENT	P-27
Manage Raster	28/06/2021

# **REVIEWS**

Action	User	Date
Created	Barbara Rzepka	21/11/2019
Modified	Xavier Torret	16/04/2020
Modified	Xavier Torret	29/07/2020
Modified	Xavier Torret	12/03/2021
Modified	Xavier Torret	28/06/2021