Introduction to MicroPython for Raspberry Pi Pico Part 2 - Software

Hamilton Python Users Group 12 Dec 2022 Ian Stewart


What is MicroPython?


- Full implementation of the Python 3 programming language that runs directly on embedded hardware like Raspberry Pi Pico.
- Interactive prompt (the REPL) to execute commands immediately via USB Serial port, and a built-in filesystem.
- The Pico port of MicroPython includes modules for accessing low-level chip-specific hardware.
- Documentation:
 - https://www.raspberrypi.com/documentation/microcontrollers/micropython.html
 - Demo of how to install to Pico module
- Website:
 - https://micropython.org
- Download Micropython for Pico:
 - https://micropython.org/download/rp2-pico/

What is Thonny?

- Python IDE for Beginners.
- Written in Tkinter
- Website:
 - https://github.com/thonny/thonny/wiki/Linux
- Installation:
 - sudo apt install python3-tk thonny
 - pip install thonny

Plug in USB cable and release button





Thonny

Select connection to Raspberry Pi Pico

Thonny not connecting to Pico via USB?

Error message:

```
Unable to connect to /dev/ttyACM0: [Errno 13] could not open port /dev/ttyACM0: [Errno 13] Permission denied: '/dev/ttyACM0'


Try adding yourself to the 'dialout' group: > sudo usermod -a -G dialout <username> (NB! You may need to reboot your system after this!)

Process ended with exit code 1.
```

Allow Account to have Dialout:

- ian@dell:~\$ sudo usermod -a -G dialout ian
- [sudo] password for ian:
- ian@dell:~\$ reboot

MicroPython REPL >>> on Pico



MicroPython >>> help() 1/3

Welcome to MicroPython!

For online help please visit https://micropython.org/help/.

For access to the hardware use the 'machine' module. RP2 specific commands are in the 'rp2' module.

```
Quick overview of some objects:
machine.Pin(pin) -- get a pin, eg machine.Pin(0)
machine.Pin(pin, m, [p]) -- get a pin and configure it for IO mode m, pull mode p
methods: init(..), value([v]), high(), low(), irq(handler)
machine.ADC(pin) -- make an analog object from a pin
methods: read u16()
```

MicroPython >>> help() 2/3

```
machine.PWM(pin) -- make a PWM object from a pin methods: deinit(), freq([f]), duty_u16([d]), duty_ns([d])
```

```
machine.I2C(id) -- create an I2C object (id=0,1)
methods: readfrom(addr, buf, stop=True), writeto(addr, buf, stop=True)
readfrom_mem(addr, memaddr, arg), writeto_mem(addr, memaddr, arg)
```

```
machine.SPI(id, baudrate=1000000) -- create an SPI object (id=0,1) methods: read(nbytes, write=0x00), write(buf), write_readinto(wr_buf, rd_buf)
```

machine.Timer(freq, callback) -- create a software timer object eg: machine.Timer(freq=1, callback=lambda t:print(t))

MicroPython >>> help() 3/3

Pins are numbered 0-29, and 26-29 have ADC capabilities Pin IO modes are: Pin.IN, Pin.OUT, Pin.ALT Pin pull modes are: Pin.PULL_UP, Pin.PULL_DOWN

Useful control commands:

CTRL-C -- interrupt a running program

CTRL-D -- on a blank line, do a soft reset of the board

CTRL-E -- on a blank line, enter paste mode

For further help on a specific object, type help(obj) For a list of available modules, type help('modules')

MicroPython >>> help("modules")

```
>>> help(modules")
  main
                   framebuf
                                      uasyncio/funcs
                                                         ujson
boot
                                      uasyncio/lock
                                                         umachine
                   qc
boot fat
                                      uasyncio/stream
                   math
                                                         uos
onewire
                   micropython
                                      ubinascii
                                                         urandom
rp2
                   neopixel
                                      ucollections
                                                         ure
thread
                                      ucryptolib
                   onewire
                                                         uselect
uasyncio
                                      uctypes
                   rp2
                                                         ustruct
builtins
                                      uerrno
                   uarray
                                                         usys
                   uasyncio/ init uhashlib
cmath
                                                         utime
                   uasyncio/core
                                                         uzlib
                                      uheapq
dht
                   uasyncio/event
ds18x20
                                      uio
Plus any modules on the filesystem
>>>
```

```
>>> dir()
>>> dir()
['machine', ' thonny helper', 'usys', ' name ', 'rp2']
>>> dir(machine)
[' class__', '__name__', '__dict__', 'ADC', 'I2C', 'I2S',
'PWM', 'PWRON RESET', 'Pin', 'RTC', 'SPI', 'Signal',
'SoftI2C', 'SoftSPI', 'Timer', 'UART', 'WDT', 'WDT RESET',
'bitstream', 'bootloader', 'deepsleep', 'dht readinto',
'disable irq', 'enable irq', 'freq', 'idle', 'lightsleep',
'mem16', 'mem32', 'mem8', 'reset', 'reset cause',
'soft reset', 'time pulse us', 'unique id']
>>> dir(rp2)
[' class ', ' name ', 'const', '__dict__', '__file__',
'Flash', 'PIO', 'StateMachine', 'asm pio encode',
'PIOASMError', 'PIOASMEmit', 'asm pio', ' pio funcs']
```

```
>>> dir()
```

```
>>> import usys
>>> import sys
>>> dir(usys)
['__class__', '__name__', '__dict__', 'argv', 'byteorder',
'exit', 'implementation', 'maxsize', 'modules', 'path',
'platform', 'print exception', 'ps1', 'ps2', 'stderr',
'stdin', 'stdout', 'version', 'version info']
>>> dir(sys)
['__class__', '__name__', '__dict__', 'argv', 'byteorder',
'exit', 'implementation', 'maxsize', 'modules', 'path',
'platform', 'print exception', 'ps1', 'ps2', 'stderr',
'stdin', 'stdout', 'version', 'version info']
```

```
>>> sys.
>>> sys.version info
(3, 4, 0)
>>> sys.version
'3.4.0; MicroPython v1.19.1-721-gd5181034f on 2022-11-28'
>>> sys.platform
'rp2'
```

```
>>> os.
```

>>> import os >>> dir(os) [' class ', ' name ', 'remove', ' dict ', 'VfsFat', 'VfsLfs2', 'chdir', 'getcwd', 'ilistdir', 'listdir', 'mkdir', 'mount', 'rename', 'rmdir', 'stat', 'statvfs', 'umount', 'uname', 'unlink', 'urandom'] >>> os.uname() (sysname='rp2', nodename='rp2', release='1.19.1', version='v1.19.1-721-gd5181034f on 2022-11-28 (GNU 12.1.0

MinSizeRel)', machine='Raspberry Pi Pico with RP2040')

```
>>> OS.
>>> os.getcwd()
>>> os.listdir()
['adc temp.py', 'blink.py', 'get info.py',
'pin16 blink.py', 'pwm pin16.py', 'pwm pin25.py',
'pwm pin25 dimmer.py', 'rtc time.py', 'switch.py',
'switch interupt.py', 'switch interupt routine.py']
>>>
```

Python programs written by me and saved on the Pico's 2MB of flash RAM

```
Pin25 is for the LED on-board the
>>> led = Pin(25, Pin.OUT)
                                         Pico module
>>> led.on()
>>> led.off()
>>> from machine import Pin, Timer
>>> led = Pin(25, Pin.OUT)
>>> tim = Timer()
>>> def tick(timer):
    global led
    led.toggle()
>>> tim .init(freq=2.5, mode=Timer.PERIODIC, callback=tick)
```


First Programs...

>>> print ("hello world")


>>> from machine import Pin


hello world

Saving program to Pico flash




Saving program to Pico flash. Start / Stop





GPIO Pin OUT on Pico Module

from machine import Pin
led = Pin(25, Pin.OUT)





GPIO Pin OUT on Pico Module.

GPIO Pin OUT External

from machine import Pin
led = Pin(25, Pin.OUT)
led = Pin(16, Pin.OUT)


GPIO Pin IN Pull-Up / Pull-Down






Pin.PULL UP)

switch 2 = Pin(15, Pin.IN,





MicroPython

Demos:

- RTC
- Switches
- LEDs
- PWM
- Timer
- Debouncing
- Review MicroPython 1.19 source code