

```
PORT      STATE SERVICE VERSION
22/tcp    open  ssh      OpenSSH 6.0p1 Debian 3 (protocol 2.0)
Service Info: OS: Linux
```

2. Now use `ssh` to connect to the Raspberry Pi using the obtained IP address on the default port 22:

```
#ssh pi@192.168.1.xxx
```

You may receive a message like the one shown below:

```
The authenticity of host '192.168.1.xxx' can't be established.  
RSA key fingerprint is xx:xx:xx:xx:xx:xx:xx:xx:xx:xx:xx:xx:xx:xx:xx:  
:xx:xx:xx.  
Are you sure you want to continue connecting (yes/no)?
```

Type 'Yes'. When further prompted, enter the default password *raspberrypi* for the user Pi. You should get the terminal for Pi:

```
pi@raspberrypi:~$
```

3. Now every time you boot, you may get the same IP address from your LAN. But it is a good idea to assign a static IP address to Pi. To do this, edit the file `/etc/network/interfaces`

For an eth0 connection, change from *'dhcp'* to *'static'* and address it as follows:

```
iface eth0 inet static
```

Following this line, add the static IP address, gateway and netmask information, as shown below:

```
address: 192.168.1.yyy
netmask: 255.255.255.0
gateway: 192.168.1.1
```



Note: Use an IP address, a gateway that is related to your network and ensure that no other machine in your network has the same IP.

4. Once you have saved the changes, reboot the Pi, as follows:

```
pi@raspberrypi:~$ sudo reboot
```

5. After reboot, connect to Pi from your host machine with the new IP address:

```
#ssh pi@192.168.1.yyy
```

If you get any warning message due to the change in remote host identification, add the correct host key using

the 'ssh-keygen' command. The instruction will be shown on the warning screen itself, e.g.,:

```
ssh-keygen -f "/home/username/.ssh/known_hosts" -R
192.168.1.yyy
```

Again try to connect to the Pi using ssh and the static IP address that you have assigned to it.

6. Once you get the terminal prompt, install the VNC server on Pi, by using the following command:

```
pi@raspberrypi:~$ sudo apt-get install tightvncserver
```

7. Run *vncserver*:

```
pi@raspberrypi:~$ sudo systemctl start svcserver
You will get the following message:
You will require a password to access your desktops.
Password:
```

In the password field, enter a password that you will use to connect to Raspberry Pi's desktop from your host machine. When further prompted, verify the password.

When asked, 'Would you like to enter a view-only password (y/n)?' press 'n' which will result in the following message on the Pi terminal:

```
New 'X' desktop is raspberrypi:1
Creating default startup script /home/pi/.vnc/xstartup
Starting applications specified in /home/pi/.vnc/xstartup
Log file is /home/pi/.vnc/raspberrypi:1.log
```

- Verify if VNC server is running by executing the following code:

```
pi@raspberrypi:~$ ps aux | grep vnc
```

- To allow the VNC server desktop to run during the boot process, place a start-up script in the `/etc/init.d/vncserver` file:

```
pi@raspberrypi-$ sudo touch /etc/init.d/vncserver
```

Edit the above file with the following content:

```
#!/bin/sh
# /etc/init.d/vncserver
#
#Start or stop vncserver as asked
case "$1" in
start)
    su pi -c '/usr/bin/vncserver'
    echo "Starting VNC server "
    ;;
stop)
```