# Comments on Exercise 1 in TIHSC - Xilinx

René Nilsson

April 11, 2014

## 1 Introduction

This document describes all problems encountered in the execution of the TIHSC1\_Exercise1\_Xilinx.pdf exercise. The document is devided into chapters and sections according to the exercise descriptions.

The source code for the full solution can be found on GitHUb: https://github.com/HrNilsson/Xilinx. Note, that the first part of the exercise is not present here. Only the finished Lab1, Lab3/4, and the Multyplier project is present.

The folder structure is as shown in Figure 1.1. The folders Lab1, Lab3, project\_multiply includes all Vivado files. The corresponding folders ending with \_SDK includes the corresponding SDK projects.

The folders led\_ip and matrix\_ip includes the custom IP packages.




Figure 1.1: Directory structure

René Nilsson 10783

## 2 Installation

I am running Windows 8, 64 bit, and using Xilinx software version 2013.4, which is the newest at the moment. The following experiments are defined in: Setting Up a Development Platform for Zynq 2013\_3\_02.pdf

### 2.1 Experiment 1

• Install 7-zip - No comments.

### 2.2 Experiment 2

- Register account on Xilinx.com
- Download Vivado design suite appr. 7 Gb
- Check it with FastSum, to make sure the MD5 checksum is correct.
- Insall Vivado system edition + sdk. Note, the license installion fails, because Windows 8 is not supported. This does not matter.

### 2.3 Experiment 3

#### 2.3.1 Install license

Xilinx license manager does not work in 64 bit mode. Use 32 bit instead! It is located C:/Xilinx/Vivado/2013.4/ids\_lite/ISE/bin/nt/xlcm.exe

#### 2.3.2 Running the Vivado suite

Vivado GUI is not supported in windows 8! Instead, run the Vivado in Windows 7 compatible mode:

- Open C:/Xilinx/Vivado/2013.4/bin/vivado.bat and insert:
- set \_\_COMPAT\_LAYER=WIN7RTM, so the last 3 lines are:

```
set RDLPATASK=yes
set _COMPAT_LAYER=WIN7RTM
call "%RDLBINROOT%/loader.bat" -exec %RDLPROG% %*
```

Aparrently, this is not enough. Java throws an exception. Instead create a new shortcut to the 32 bit program:

- Open the folder: C:/Xilinx/Vivado/2013.4/bin/unwrapped/win32.o
- Create a shortcut for vivado.exe.
- Open the properties for the shortcut.
- Change the following:

```
Target: = "C:/Xilinx/Vivado/2013.4/bin/unwrapped/win32.o/vvgl.exe C:/Xilinx/Vivado/2013.4/./bin/vivado.bat" Start in: = "%APPDATA%/Xilinx/Vivado"
```

René Nilsson 10783

## 2.4 Experiment 4

Install USB-UART serial driver

## 2.5 Experiment 5

Install Tera Term

## 2.6 Experiment 7

Configure Tera Term - Note, the virtual comport lost connection: solution = restart PC.

## 2.7 Experiment 8

Windows firewall

## 2.8 Summary

Full installation took a couple of hours!

This would not be the case on a windows 7 machine.

René Nilsson 10783 3 of 10

# 3 Vivado

The following steps are defined in: lab1(2)-EmbeddedSystem.

### 3.1 Hardware Generation

#### Step 2-6-4:

The GPIO  $_{-}0$  has disappered. - run step 2-2 and 2-3 again.

If it complains about wrong license, with no bitstream generation, just add the right license, WITH bitstream generation.

#### Step 3-1-1:

lab1.xdc, added in step  $2.8~\rm does$  not work correctly.

It seems it is case-sensitive. Correct the lines to:

```
set_property PACKAGE.PIN R18 [get_ports btnr_tri_io] set_property IOSTANDARD LVCMOS25 [get_ports btnr_tri_io]
```

René Nilsson 10783 4 of 10

## 4 Xilinx SDK

#### 4.1 Software Platform

#### Step 5.1:

Building the software platform throws an include error.

Reason:

- There must be NO parentheses or spaces in project path.
- The PATH environment variable should be set up properly, by running setting 32. This did not work. Instead write the following in the top of the makefile (in one line):

PATH=C:/Xilinx/SDK/2013.4/bin/nt;

C:/Xilinx/SDK/2013.4/bin;

C:/Xilinx/SDK/2013.4/gnu/microblaze/nt/bin;

C:/Xilinx/SDK/2013.4/gnu/powerpc-eabi/nt/bin;

C:/Xilinx/SDK/2013.4/gnuwin/bin;

C:/Xilinx/SDK/2013.4/gnu/arm/nt/bin;

C:/Xilinx/SDK/2013.4/gnu/microblaze/linux\_toolchain/nt\_be/bin;

C:/Xilinx/SDK/2013.4/gnu/microblaze/linux\_toolchain/nt\_le/bin;%PATH%

## 4.2 C application

Step 5.2:

Building the C application:

Building error:

"make: Interrupt/Exception caught (code = 0xc00000fd, addr = 0x4227d3)"

This error is caused because of my PATH environment settings. It turns out that the ARM gcc compiler uses a file called sh.exe, which is also used/part of the program Github. A possible solution is to remove Github from your PATH environment. Or renaming the sh.exe file in github (Then Github might not work!!): C:/Program Files (x86)/Git/bin/sh.exe

You might need to restart your PC after changing your PATH variable.

René Nilsson 10783 5 of 10

# 5 Configure Peripherals

The following exercises and steps are defined in: lab3-ZynqHW.pdf.

## 5.1 Clocks

Experiment 2, Step 8: Do not turn of FCLK\_CLK0! It is already in use by the ZYng processor!

René Nilsson 10783 6 of 10

## 6 Create Custom IP

The following steps are defined in: lab3\_EmbeddedSystem.pdf.

### 6.1 Block design

Step 4-1-7:

Note, the diagrams are not alike, since I did not make Lab2, which is used in the toturial. There is no BTNR and no leds\_8bits, instead there is btns\_5bits in lab3. In my design, there is both leds\_8bits and LED[7:0]! The leds\_8bits and BTNR should be removed, and the btns\_5bits should be added!! Otherwise the following lab exercises cannot be completed!

This is done by:

- Double clicking leds\_8bits and change the board interface to btns\_5bits. Additional the block and external connection should be renamed.
- Open the ZYNQ, under MIO Configurations, remove EMIO GPIO.
- Delete the BTNR connection from the block design.
- Remove the lab1 constraint (and the System\_wrapper constraint), since we deleted BTNR.

René Nilsson 10783 7 of 10

# 7 Writing basic software application

The following steps are defined in: lab4\_EmbeddedSystem.pdf. Note I did not rename my Vivado project, since there is no need to do that!

Step 2-2: The hw\_platform and bsp will not rebuild automaticly, since the Vivado project has been renamed to lab3, instead of lab1. Therefore the new hw\_platform must be imported, and the bsp created.

Step 2-2-15: Note that the LEDs will not light up yet!

Step 2-4-5: In my case, the correct name is:

LED\_IP\_mWriteReg(XPAR\_LED\_IP\_S\_AXI\_BASEADDR, 0, dip\_check);

Step 4-2-2: I do not get any error, because the text area already is in the DDR, and not the BRAM.

René Nilsson 10783 8 of 10

# 8 Console application

The following steps are defined in: TIHSC1\_Exercise1\_Xilinx.pdf part 3. In the source code given, the defined value for one second should be changed to:

#define ONE\_SECOND 1333000

René Nilsson 10783 9 of 10

# 9 Hardware IP Acceleration

## 9.1 Creating matrix\_ip

Step 1-2-27 in lab3\_EmbeddedSystem: There is no guide help, thus no "Merge changes....." - I try without...

Note, that the drivers for matrix\_ip will be located in labs/matrix\_ip/matrix\_ip\_1.0/drivers/matrix\_ip\_v1\_00\_a/src. For some reason it is not part of the exported hardware platform.

René Nilsson 10783 10 of 10