Write Code and connections in wokwi for ultrasonic sensor. whatever distance is less than 100 cms send "Alert" to ibm cloud aand display in device recent events.

```
Code
```

```
//Pins
const int TRIG_PIN = 7; const
int ECHO PIN = 8;
//Anything over 400 cm (23200 us pulse) is "out of range" const
unsigned int MAX DIST = 23200;
void setup() {
// The Trigger pin will tell the sensor to range find
Pin Mode(TRIG PIN, OUTPUT); digital
Write(TRIG_PIN, LOW);
//Set Echo pin as input to measure the duration of
//pulses coming back from the distance sensor
pinMode(ECHO_PIN, INPUT );
// We'll use the serial monitor to view the sensor output
Serial.begin(9600);
}
void loop() { unsigned
long t1; unsigned
```

```
long t2; unsigned
long pulse_width;
float cm; float
inches;
// Hold the trigger pin high for at least 10 us
digitalWrite(TRIG PIN, HIGH);
delayMicroseconds(10);
digitalWrite(TRIG PIN, LOW);
// Wait for pulse on echo pin while
(digitalRead( ECHO_PIN )==0 );
// Measure how long the echo pin was held high (pulse width)
// Note: the micros() counter will overflow after-70 min t1=
micros ();
 while (digitalRead(ECHO PIN) == 1);
t2= micros (); pulse_width = t2-t1;
// Calculate distance in centimeters and inches. The constants
//are found in the datasheet, and calculated from the assumed speed
// of sound in air at sea level (- 340m/s)
cm=pulse Width / 58; inches =
pulse_width/148.0;
//
     Print out
                  results
                            if
(pulse width >MAX DIST){
```

## **Output:**

1.If the distance is less than 100 centimeters, it alerts.

```
WOKWI B SAVE - SHARE
  hc-sr04.ino diagram json ● Library Manager ▼
                                                                                                                                                                                  000:00.466 (758%
           const int TRIG_PIN = 7;
          const int ECHO_PIN = 8;
          // Anything over 400 cm (23200 us pulse) is "out of range"
const unsigned int MAX_DIST = 23200;
            // The Trigger pin will tell the sensor to range find
pinMode(TRIG_PIN, OUTPUT);
digitalWrite(TRIG_PIN, (OM);
                                                                                                                                   OO UNO
           //Set Echo pin as input to measure the duration of
//pulses coming back from the distance sensor
pinMode(ECHO_PIN, IMPUT);
             // We'll use the serial monitor to view the sensor output
           Serial.begin(9600);
                                                                                                                                   DEC 2885 RECETS
          void loop() {
            unsigned long t1;
unsigned long t2;
unsigned long pulse_width;
float cm;
float inches;
                                                                                                    .........
                                                                                                    The Measured Distance in cm : 84.14
                                                                                                    Alert!!
                                                                                                    // Hold the trigger pin high for at least 10 us
```

2.If the distance is more than 100 centimeters, it won't alert

```
WOKWI TO SAVE
                                                                                                                                                                     Docs
                                                                                            Simulation
 hc-sr04.ino
             diagram json ● Library Manager ▼
                                                                                                                                                               O00:00.599 (62%
         const int TRIG_PIN = 7;
         const int ECHO_PIN = 8;
        // Anything over 400 cm (23200 us pulse) is "out of range"
        const unsigned int MAX_DIST = 23200;
          // The Trigger pin will tell the sensor to range find
                                                                                                                 SECURITY PROTECTION (NO. 5) P.
           pinMode(TRIG_PIN, OUTPUT);
                                                                                                                     OO UNO
   12
           digitalWrite(TRIG_PIN, LOW);
   13
           //Set Echo pin as input to measure the duration of 
//pulses coming back from the distance sensor
   15
           pinMode(ECHO_PIN, INPUT);
   17
18
           // We'll use the serial monitor to view the sensor output
           Serial.begin(9600);
   20
21
                                                                                                                     POWER ANALOG IN
        void loop() {
           unsigned long t1;
           unsigned long t2;
unsigned long pulse_width;
   25
26
                                                                                         The Measured Distance in cm : 227.10
                                                                                         ************************
                                                                                                                                            Activate Windows
           float inches:
                                                                                                                                            Go to Settings to activate Windows.
```

3. Simulation and Code execution







