TEAM ID:PNT2022TMID31318

pinMode(ECHO_PIN, INPUT);

1.Write Code and connections in wokwi for ultrasonic sensor. whatever distance is less than 100 cms send "Alert" to ibm cloud aand display in device recent events.

Solution: //Pins const int TRIG_PIN = 7; const int ECHO_PIN = 8; //Anything over 400 cm (23200 us pulse) is "out of range" const unsigned int MAX DIST = 23200; void setup() { // The Trigger pin will tell the sensor to range findPin Mode(TRIG_PIN, OUTPUT); digital Write(TRIG_PIN, LOW); //Set Echo pin as input to measure the duration of //pulses coming back from the distance sensor

```
// We'll use the serial monitor to view the sensor output
Serial.begin(9600);
}
void loop() {
unsigned long t1;
unsigned long t2;
unsigned long pulse_width;
float cm;
float inches;
// Hold the trigger pin high for at least 10 us
digitalWrite(TRIG_PIN, HIGH);
delayMicroseconds(10); digitalWrite(TRIG PIN,
LOW);
// Wait for pulse on echo pin
while (digitalRead( ECHO PIN )==0 );
// Measure how long the echo pin was held high (pulse width)
// Note: the micros() counter will overflow after-70 min
t1= micros ();
 while (digitalRead(ECHO_PIN) == 1);
 t2= micros ();
 pulse_width = t2-t1;
```

```
// Calculate distance in centimeters and inches. The constants
//are found in the datasheet, and calculated from the assumed speed
// of sound in air at sea level (- 340m/s)
cm=pulse_Width / 58;
inches = pulse_width/148.0;
// Print out results
if (pulse width >MAX DIST){
Serial.println("Out of range");
Serial.print("The Measured Distance in cm: ");
Serial.println(cm);
if( cm < 100 ){
  //while(true){
   Serial.println("Alert!!");
   //}
}
}
//wait at least 1000ms before next measurement
Delay(1000);
}
```

Output:

• If the distance is less than 100 cms, it alerts.

```
WOKWI B SAVE
   hc-sr04.ino diagram json ● Library Manager ▼
            // Pins
const int TRIG_PIN = 7;
                                                                                                                                                                                                      ₫00:00.466 (%58%
            const int ECHO_PIN = 8;
            // Anything over 400 cm (23200 us pulse) is "out of range const unsigned int MAX_DIST = 23200;
            void setup() {
              // The Trigger pin will tell the sensor to range find
pinMode(TRIG_PIN, OUTPUT);
digitalWrite(TRIG_PIN, LOW);
                                                                                                                                            UNO UNO
              //Set Echo pin as input to measure the duration of
//pulses coming back from the distance sensor
pinNode(ECHO_PIN, INPUT);
              // We'll use the serial monitor to view the sensor output
Serial.begin(9600);
                                                                                                                                                 10 20 5 112212
            void loop() {
              unsigned long t1;
unsigned long t2;
unsigned long pulse_width;
float cm;
float inches;
                                                                                                               The Measured Distance in cm : 84.14
                                                                                                               M II I
               // Hold the trigger pin high for at least 10 us
```

• If the distance is more than 100 cms, it won't alert

```
WOKWI T SAVE
                                                                                                                                                         Docs
 hc-sr04.ino diagram_json ● Library Manager ▼
                                                                                     Simulation
                                                                                                                                                    ₫00:00.599 (%62%
        const int TRIG PIN = 7:
        const int ECHO_PIN = 8;
        // Anything over 400 cm (23200 us pulse) is "out of range"
        const unsigned int MAX_DIST = 23200;
          // The Trigger pin will tell the sensor to range find
                                                                                                         SETTION DISTAL (PM -) E
    11
          pinMode(TRIG_PIN, OUTPUT);
         digitalWrite(TRIG_PIN, LOW);
    12
                                                                                                             OO UNO
         //Set Echo pin as input to measure the duration of
    15
          //pulses coming back from the distance sensor
         pinMode(ECHO_PIN, INPUT);
          // We'll use the serial monitor to view the sensor output
Serial.begin(9600);
    18
    19
    20
                                                                                                            MANAGES STREET
    21
        void loop() {
   22
    23
           unsigned long t1;
           unsigned long t2;
                                                                                   The Measured Distance in cm : 227.10
    26
           unsigned long pulse_width;
                                                                                   *********************
                                                                                                                                  Activate Windows
           float inches:
                                                                                                                                  Go to Settings to activate Windows.
```

Simulation and code execution

