## **ASSIGNMENT-4**

NAME:MAHESWARI J

REG NO:710719104057

**MAXIMUM MARKS: 2 MARKS** 

## **QUESTION**

Write code and connections in wokwi for ultrasonic sensor. Whenever distance is less than 100cms send "alert" to ibm cloud and display in device recent events

## **PROGRAM:**

```
const int TRIG PIN = 7;
const int ECHO_PIN = 8;
// Anything over 400 cm (23200 us pulse) is "out of range"
const unsigned int max_dist = 23200;
void setup() {
// The Trigger pin will tell the sensor to range find
pinMode(TRIG PIN, OUTPUT);
digitalWrite(TRIG_PIN, LOW);
//Set Echo pin as input to measure the time duration of pulse returning back
from the distance sensor
pinMode(ECHO_PIN, INPUT);
// We'll use the serial monitor to view the sensor output
Serial.begin(9600);
void loop() {
unsigned long t1;
unsigned long t2;
unsigned long pulse_width;
float cm;
float inches:
// Hold the trigger pin high for at least 10 us
digitalWrite(TRIG_PIN, HIGH);
delayMicroseconds(10);
digitalWrite(TRIG PIN, LOW);
// Wait for pulse on echo pin
while (digitalRead(ECHO_PIN) == 0);
```

```
// Measure how long the echo pin was held high (pulse width)
// Note: the micros() counter will overflow after ~70 min
t1 = micros():
while ( digitalRead(ECHO_PIN) == 1);
t2 = micros();
pulse\_width = t2 - t1;
// Calculate distance in centimeters and inches. The constants
// are found in the datasheet, and calculated from the assumed speed
//of sound in air at sea level (~340 m/s).
cm = pulse\_width / 58.0;
inches = pulse_width / 148.0;
// Print out results
if ( pulse_width > max_dist ) {
Serial.println("Out of range");
} else
; Serial.print("Distance Measured in cm:");
Serial.println(cm);
if(cm < 100){
// while(true){
Serial.println("Alert !!");
// }
// Wait at least 1000ms before next measurement
delay(1000);
OUTPUT:
Distance Measured (cm): 2.07
Alert!!!
Distance Measured (cm):2.00
Alert!!!
```

## **SCREENSORT:**

