## **Assignment-4**

**Team ID:** PNT2022TMID52039

Name: RAMJITH B G

1. Write Code and connections in wokwi for ultrasonic sensor. whatever distance is less than 100 cm send "Alert" to IBM cloud and display in device recent events.

## **Solution:**

```
//Pins
const int TRIG_PIN = 7;
const int ECHO_PIN = 8;

//Anything over 400 cm (23200 us pulse) is "out of range"
const unsigned int MAX_DIST = 23200;

void setup() {

// The Trigger pin will tell the sensor to range find
Pin Mode(TRIG_PIN, OUTPUT);
digital Write(TRIG_PIN, LOW);


//Set Echo pin as input to measure the duration of
```

```
//pulses coming back from the distance sensor
pinMode(ECHO PIN, INPUT);
// We'll use the serial monitor to view the sensor output
 Serial.begin(9600);
}
void loop() {
unsigned long t1
unsigned long t2;
 unsigned long pulse width;
 float cm;
 float inches;
// Hold the trigger pin high for at least 10 us
digitalWrite(TRIG_PIN, HIGH);
delayMicroseconds(10);
digitalWrite(TRIG PIN, LOW);
// Wait for pulse on echo pin
while (digitalRead( ECHO PIN )==0 );
// Measure how long the echo pin was held high (pulse width)
 // Note: the micros() counter will overflow after-70 min
 t1= micros ();
 while (digitalRead(ECHO_PIN) == 1);
  t2= micros ();
  pulse_width = t2-t1;
 // Calculate distance in centimeters and inches. The constants
```

```
//are found in the datasheet, and calculated from the assumed speed
 // of sound in air at sea level (- 340m/s)
 cm=pulse_Width / 58;
 inches = pulse_width/148.0;
 // Print out results
 if (pulse_width >MAX _ DIST ){
 Serial.println("Out of range");
 } else {
 Serial.println("********************************);
 Serial.print("The Measured Distance in cm: ");
 Serial.println(cm);
if( cm < 100){
    //while(true){
    Serial.println("Alert!!");
    //}
 }
Serial.print("********************************);
 }
//wait at least 1000ms before next measurement
 Delay(1000);
 }
```

## **Output:**

1. If the distance is less than 100 cm, it alerts.



2. If the distance is more than 100 cm, it won't alert

```
WOKWI TO SAVE
                                                                                                                                                                              Docs
hc-sr04.ino diagram.json ● Library Manager ▼
                                                                                                                                                                        ₫00:00.599 @62%
           const int TRIG_PIN = 7;
          const int ECHO PIN = 8;
          // Anything over 400 cm (23200 us pulse) is "out of range"
           const unsigned int MAX_DIST = 23200;
            // The Trigger pin will tell the sensor to range find
pinMode(TRIG_PIN, OUTPUT);
     11
            digitalWrite(TRIG_PIN, LOW);
                                                                                                                            OO UNO
     14
15
            //Set Echo pin as input to measure the duration of 
//pulses coming back from the distance sensor
            pinMode(ECHO_PIN, INPUT);
    18
19
20
21
22
23
             // We'll use the serial monitor to view the sensor output
            Serial.begin(9600);
                                                                                                                           MAN POWER ANALOG IN
          void loop() {
     24
25
            unsigned long t2;
unsigned long pulse_width;
                                                                                              The Measured Distance in cm : 227.10
     26
27
                                                                                              ********************
                                                                                                                                                    Activate Windows
             float cm;
             float inches;
                                                                                                                                                    Go to Settings to activate Windows
```

## 3. Simulation and code execution

