```
Assignment--4
```


```
Date: November 3, 2022
Team ID PNT2022TMID34745
Project Name Industry-Specific Intelligent fire
management system
Maximum Marks 2 Marks
Question:
Write code and connections in wokwi for the ultrasonic sensor. Whenever the
distance is less than 100 cms send an "alert" to the IBM cloud and display in
the device recent events.
Wokwi link:
https://wokwi.com/projects/347294151283311187
Code:
const int TRIG_PIN = 7;
const int ECHO_PIN = 8;
//anything over 400cm(23200 us pulse)is "out of range"
const unsigned int MAX_DIST = 23200;
void setup() {
//The Trigger pin will tell the sensor to range find
```

```
pinMode(TRIG_PIN, OUTPUT);
digitalWrite(TRIG_PIN, LOW);
//Set Echo pin as input to measure the duration of pulse coming back from the
//distance sensor
pinMode(ECHO_PIN, INPUT);
//We'll use the serial monitor to view the sensor output
Serial.begin(9600);
}
void loop() {
unsigned long t1;
unsigned long t2;
unsigned long pulse_width;
float cm;
float inches;
//Hold the trigger pin high for at least 10us
digitalWrite(TRIG_PIN, HIGH);
delayMicroseconds(10);
digitalWrite(TRIG_PIN, LOW);
//wait for pulse on echo pin
while (digitalRead(ECHO_PIN) == 0);
//Measure how long the echo pin was held high (pulse width)
//note the micros()counter will overflow after -70min
t1 = micros();
while (digitalRead(ECHO_PIN) == 1);
t2 = micros();
```


```
pulse_width = t2 -t1;
//calculate distance in centimeters and inches. The constants are found in
//datasheet,and calculated from the assumed speed of sound in air at
sealevel(-340m/s)
cm = pulse_width / 58;
inches = pulse_width / 148.0;
//print out results
if (pulse_width > MAX_DIST) { > MAX_DIST) {
Serial.println("Out of range");
}
else
Serial.println("*******");
Serial. println("The Measured Distance in cm:");
Serial.println(cm);
if (cm < 100)
{
//while (true)
{
Serial.println("Alert!");
}
}
Serial.println("*******");
}
//wait at least 1000ms before next measurement
```

```
delay(1000);
}
```

Case 1: If the Distance less than 100 cms it will Alertase 1: If the Distance less than 100 cms it will Alert.



Case 2: If the Distance greater than 100 cms it wont Alert.



Case 3: If the distance is beyond the limit it will display Out Of Rangease 3: If the distance is beyond the limit it will display Out Of Range.

