Assignment date	07 November 2022
Student Name	Ms.M.Deepika
Student Roll Number	821719106009
Maximum Marks	2 Marks

Question-4

Write code and connections in wokwi for the ultrasonic sensor

Code

```
Ultrasonic Simple
  Prints the distance read by an ultrasonic sensor in
  centimeters. They are supported to four pins ultrasound
  sensors (liek HC-SC04) and three pins (like PING)))
  and Seeed Studio sensors).
  The circuit:
 * * Module HR-SC04 (four pins) or PING))) (and other with
    three pins), attached to digital pins as follows:
  | HC-SC04 | Arduino | | 3 pins | Arduino |
    Vcc | 5V | | Vcc | 5V |
Trig | 12 | OR | SIG | 13 |
     Echo | 13 | | Gnd | GND
     Gnd | GND |
  Note: You do not obligatorily need to use the pins defined above
  By default, the distance returned by the read()
  method is in centimeters. To get the distance in inches,
  pass INC as a parameter.
  Example: ultrasonic.read(INC)
  created 3 Apr 2014
  by Erick Simões (github: @ErickSimoes | twitter: @AloErickSimoes)
  modified 23 Jan 2017
  by Erick Simões (github: @ErickSimoes | twitter: @AloErickSimoes)
  modified 03 Mar 2017
  by Erick Simões (github: @ErickSimoes | twitter: @AloErickSimoes)
  modified 11 Jun 2018
  by Erick Simões (github: @ErickSimoes | twitter: @AloErickSimoes)
  This example code is released into the MIT License.
#include "Ultrasonic.h"
  Pass as a parameter the trigger and echo pin, respectively,
  or only the signal pin (for sensors 3 pins), like:
  Ultrasonic ultrasonic (13);
Ultrasonic ultrasonic(12, 13);
int distance;
```

```
void setup() {
    Serial.begin(9600);
}

void loop() {
    // Pass INC as a parameter to get the distance in inches

distance = ultrasonic.read(CM);

Serial.print("Distance in CM: ");
Serial.println(distance);

distance = ultrasonic.read(INC);

Serial.print("Distance in Inches: ");
Serial.println(distance);

delay(1000);
}
```

Output

