



LSN50 LoRa Sensor Node User Manual

Document Version: 1.2.3

Image Version: v1.4

Version	Description	Date
1.0	Release	2018-Dec-4
1.1	Add steps of install STM320x; Add ST-Link Upload firmware method	2018-Dec-27
1.2	Add trouble shooting for UART upload, Add changelog for firmware v1.4	2019-Jan-23
1.2.1	More detail description for 8 channel mode and trouble shooting for using in US915/AU915	2019-Feb-21
1.2.2	Modify trouble shooting for upload via Flashloader	2019-Mar-13
1.2.3	Add ISP Mode / Flash mode different/ Add working flow diagram (Chapter 2.1 how it works) Add FAQ for how to configure the Keys	2019-Apr-1

1. Introduction	4
1.1 What is LSN50 LoRa Sensor Node	4
1.2 Specifications	5
1.3 Features	6
1.4 Applications	6
1.5 Pin Definition	7
1.6 Hardware Change log	8
1.7 Hole Option	9
2. Use LSN50 with stock LoRaWAN firmware	10
2.1 How it works?	10
2.2 Quick guide to connect to LoRaWAN server (OTAA)	10
2.3 Uplink Payload	14
2.3.1 Payload explain	14
2.3.2 Decode payload in The Things Network	15
2.4 Payload explain and sensor interface	16
2.4.1 Battery Info	16
2.4.2 Temperature (DS18B20)	16
2.4.3 Digital Input	17
2.4.4 ADC	17
2.4.5 Digital Interrupt	18
2.4.6 I2C Interface (SHT20)	20
2.4.7 +5V output	21
2.5 Downlink Payload	21
2.6 Firmware Change Log	21
2.7 Battery Analyze	22
2.7.1 Battery Type	22
2.7.2 Power consumption Analyze	23
2.7.3 Battery notice	24
2.7.4 Replace the battery	24
3. Use AT Command	25
3.1 Access AT Command	25
3.2 Common AT Command Sequence	27
3.2.1 Multi-channel ABP mode (Use with SX1301/LG308)	27

3.2.2 Single-channel ABP mode (Use with LG01/LG02)	27
4. Upload Firmware	29
4.1 Upload Firmware via Serial Port.....	29
4.2 Upload Firmware via ST-Link V2.....	32
5. Developer Guide	34
5.1 Source Code	34
5.2 Compile Source Code.....	34
5.2.1 Set up Keil compile environment.....	34
5.2.2 Install STM32L0 Series Device.....	37
5.2.3 Compile Source Code.....	38
6. FAQ.....	40
6.1 Why there is 433/868/915 version?	40
6.2 What is the frequency range of LT LoRa part?	40
6.3 How to change the LoRa Frequency Bands/Region?.....	41
6.4 Can I use Private LoRa protocol?	41
6.5 How to set up LSN50 to work in 8 channel mode in US915, AU915, CN470 bands?	42
6.6 How to set up LSN50 to work with Single Channel Gateway such as LG01/LG02?.....	44
6.7 How to configure the EUI keys in LSN50?.....	45
7. Trouble Shooting.....	46
7.1 Connection problem while using USB <----> TTL to upload firmware.....	46
7.2 Why I can't join TTN in US915 /AU915 bands?.....	46
8. Order Info	47
9. Packing Info	47
10. Support.....	47
11. Reference.....	48

1. Introduction

1.1 What is LSN50 LoRa Sensor Node


LSN50 is a Long Range LoRaWAN Sensor Node. It is designed for **outdoor data logging** and powered by **Li/SOCl₂ battery** for long term use and secure data transmission. It is designed to facilitate developers to quickly deploy industrial level LoRa and IoT solutions. It helps users to turn the idea into a practical application and make the Internet of Things a reality. It is easy to program, create and connect your things everywhere.

It is based on SX1276/SX1278 allows the user to send data and reach extremely long ranges at low data-rates. It provides ultra-long range spread spectrum communication and high interference immunity whilst minimizing current consumption. It targets professional wireless sensor network applications such as irrigation systems, smart metering, smart cities, smartphone detection, building automation, and so on.

LSN50 uses STM32L0x chip from ST, STM32L0x is the **ultra-low-power** STM32L072xx microcontrollers incorporate the connectivity power of the universal serial bus (USB 2.0 crystal-less) with the high-performance ARM® Cortex®-M0+ 32-bit RISC core operating at a 32 MHz frequency, a memory protection unit (MPU), high-speed embedded memories (192 Kbytes of Flash program memory, 6 Kbytes of data EEPROM and 20 Kbytes of RAM) plus an extensive range of enhanced I/Os and peripherals.

LSN50 is an **open source product**, it is based on the STM32Cube HAL drivers and lots of libraries can be found in ST site for rapid development.

LSN50 Network Structure



1.2 Specifications

Micro Controller:

- STM32L072CZT6 MCU
- MCU: STM32L072CZT6
- Flash:192KB
- RAM:20KB
- EEPROM: 6KB
- Clock Speed: 32Mhz

Common DC Characteristics:

- Supply Voltage: 2.1v ~ 3.6v
- Operating Temperature: -40 ~ 85°C
- I/O pins: Refer to STM32L072 datasheet

LoRa Spec:

- Frequency Range,
 - ✓ Band 1 (HF): 862 ~ 1020 Mhz
 - or
 - ✓ Band 2 (LF): 410 ~ 528 Mhz
- 168 dB maximum link budget.
- +20 dBm - 100 mW constant RF output vs.
- +14 dBm high efficiency PA.
- Programmable bit rate up to 300 kbps.
- High sensitivity: down to -148 dBm.
- Bullet-proof front end: IIP3 = -12.5 dBm.
- Excellent blocking immunity.
- Low RX current of 10.3 mA, 200 nA register retention.
- Fully integrated synthesizer with a resolution of 61 Hz.
- FSK, GFSK, MSK, GMSK, LoRaTM and OOK modulation.
- Built-in bit synchronizer for clock recovery.
- Preamble detection.
- 127 dB Dynamic Range RSSI.
- Automatic RF Sense and CAD with ultra-fast AFC.
- Packet engine up to 256 bytes with CRC.
- LoRaWAN 1.0.2 Specification

Battery:

- Li/SOCl2 un-chargeable battery
- Capacity: 4000mAh
- Self Discharge: <1% / Year @ 25°C
- Max continuously current: 130mA

-
- Max boost current: 2A, 1 second

Power Consumption

- STOP Mode: 2.7uA @ 3.3v
- LoRa Transmit Mode: 125mA @ 20dBm 44mA @ 14dBm


1.3 Features

- ✓ LoRaWAN 1.0.2 Class A,Class C
- ✓ STM32L072CZT6 MCU
- ✓ SX1276/78 Wireless Chip
- ✓ Pre-load bootloader on USART1/USART2
- ✓ MDK-ARM Version 5.24a IDE
- ✓ I2C,LPUSART1,USB,SPI2
- ✓ 3x12bit ADC, 1x12bit DAC
- ✓ 20xDigital I/Os
- ✓ LoRa™ Modem
- ✓ Preamble detection
- ✓ Baud rate configurable
- ✓ CN470/EU433/KR920/US915/IN865
- ✓ EU868/AS923/AU915
- ✓ Open source hardware / software
- ✓ Available Band:433/868/915/920 Mhz
- ✓ IP66 Waterproof Enclosure
- ✓ Ultra Low Power consumption
- ✓ AT Commands to change parameters
- ✓ 4000mAh Battery for long term use

1.4 Applications

- ✓ Smart Buildings & Home Automation
- ✓ Logistics and Supply Chain Management
- ✓ Smart Metering
- ✓ Smart Agriculture
- ✓ Smart Cities
- ✓ Smart Factory

1.5 Pin Definition



Pin No.	Signal	Direction	Function	Remark
1	VCC(2.9V)	OUTPUT	VCC	Directly connect to main power for board
2	PA0	In/Out	Directly from STM32 chip	Used as ADC in LSN50 image
3	PA1	In/Out	Directly from STM32 chip	
4	PA2	In/Out	Directly from STM32 chip, 10k pull up to VCC	Used as UART_TXD in LSN50 image
5	PA3	In/Out	Directly from STM32 chip, 10k pull up to VCC	Used as UART_RXD in LSN50 image
6	PB6	In/Out	Directly from STM32 chip, 10k pull up to VCC	
7	PB7	In/Out	Directly from STM32 chip, 10k pull up to VCC	
8	PB3	In/Out	Directly from STM32 chip, 10k pull up to VCC	
9	PB4	In/Out	Directly from STM32 chip	
10	PA9	In/Out	Directly from STM32 chip, 10k pull up to VCC	
11	PA10	In/Out	Directly from STM32 chip, 10k pull up to VCC	

			up to VCC	
12	GND		Ground	
13	VCC(2.9V)	OUTPUT	VCC	Directly connect to main power for board
14	Jumper		Power on/off jumper	
15	PA4	In/Out	Directly from STM32 chip	
16	NRST	In	Reset MCU	
17	PA12	In/Out	Directly from STM32 chip	
18	PA11	In/Out	Directly from STM32 chip	
19	PA14	In/Out	Directly from STM32 chip	
20	PB13	In/Out	Directly from STM32 chip	
21	PB12	In/Out	Directly from STM32 chip	
22	PB15	In/Out	Directly from STM32 chip	
23	PB14	In/Out	Directly from STM32 chip	
24	PA13	In/Out	Directly from STM32 chip	
25	PA8	In/Out	Directly from STM32 chip	Default use to turn on/off LED1 in LSN50 image
26	GND		Ground	
27	+5V	Out	5v output power	Controlled by PB5(Low to Enable, High to Disable)
28	LED1		Controlled by PA8	Blink on transmit
29	BOOT MODE		Configure device in working mode or ISP program mode	Flash: Normal Working mode and send AT Commands ISP: UART Program Mode
30	NRST	In	Reset MCU	

1.6 Hardware Change log

LSN50 v1.2:

- ✓ Add LED. Turn on for every LoRa transmit
- ✓ Add pin PA4, PB13, NRST
- ✓ Add 5V Output, on/off control by PB5(Low to Enable, High to Disable)

LSN50 v1.3:

- ✓ Add P-MOS to control 5V output

1.7 Hole Option

The LSN50 provide different hole size option for different size sensor case. the option now provided is M12/M16 and M20. The definition is as below:



多项国际质量认证





品质保证放心使用



产品结构

Structure




MODEL	H1	H2	M	M1	D	D1	A	B
M12*1.5	8	28.3	12.0	12.0	10.4	8.5 ± 0.2	16 ± 0.2	18 ± 0.2
M16*1.5	8	30.7	15.1	16.0	13.5	10.9 ± 0.2	18.8 ± 0.2	20.6 ± 0.2
M20*1.5	9	34.0	20.2	20.0	18.7	16.2 ± 0.2	22.8 ± 0.2	25.2 ± 0.2

2. Use LSN50 with stock LoRaWAN firmware

2.1 How it works?

The LSN50 is pre-loaded with a firmware and is configured as LoRaWAN Class A mode by default. It has OTAA keys to join LoRaWAN network. To connect a local LoRaWAN network, user just need to input the OTAA keys in the LoRaWAN IoT server and power on the LSN50. It will auto join the network via OTAA.

Below shows the working flow for the device.



In case user can't set the OTAA keys in the LoRaWAN OTAA server and has to use the keys from the server. User can [use AT Command](#) to set the keys in LSN50.

2.2 Quick guide to connect to LoRaWAN server (OTAA)

Here is an example for how to join the [TTN LoRaWAN Network](#). Below is the network structure, we use [LG308](#) as LoRaWAN gateway in this example.

LSN50 in a LoRaWAN Network



The LG308 is already set to connect to [TTN network](#). So what we need to now is only configure the TTN:


Step 1: Create a device in TTN with the OTAA keys from LSN50.

Each LSN50 is shipped with a sticker with the default device EUI as below:




User can enter this key in their LoRaWAN Server portal. Below is TTN screen shot:

Add APP EUI in the application



The screenshot shows the 'dragino_test_application1' application details on the TTN console. In the 'APPLICATION EUIS' section, two EUIs are listed: '70 B3 D5 7E F0 00 46 18' and '3F 77 AD E3 6B CA AB 65'. The second EUI is highlighted with a red border.

Add APP KEY and DEV EUI




The screenshot shows the 'REGISTER DEVICE' page for the 'dragino_test_application1' application. It includes fields for 'Device ID' (set to 'B0'), 'Device EUI' (set to 'A8 40 41 00 01 81 85 48'), 'App Key' (set to '57 4E 37 E6 8A EC FC CD B3 B9 3D 87 A9 3B 4B 2C'), and 'App EUI' (set to '3F 77 AD E3 6B CA AB 65'). The 'Device EUI' and 'App Key' fields are highlighted with red borders.

Step 2: Power on LSN50

Put a Jumper on JP2 to power on the device.




Step 3: and it will auto join to the TTN network. After join success, it will start to upload message to TTN and user can see in the panel.


 A screenshot of the THE THINGS NETWORK CONSOLE interface. At the top, there's a navigation bar with 'THE THINGS NETWORK' logo, 'CONSOLE', 'COMMUNITY EDITION', 'Applications', 'Gateways', and 'Support'. Below that is a secondary navigation bar with 'Applications > engineer-lin > Data'. The main area is titled 'APPLICATION DATA' and shows a table of received messages. The table has columns for 'time', 'counter', 'port', 'Battery Info', 'Temperature (DS18B20)', 'ADC', 'Digital Input and Digital Interrupt', and 'Temperature (SHT20 or SHT31)' and 'Humidity (SHT20 or SHT31)'. Red arrows point from the 'Battery Info' column to the first message in the table, and from the other sensor columns to the subsequent messages. The table contains the following data:

time	counter	port	Battery Info	Temperature (DS18B20)	ADC	Digital Input and Digital Interrupt	Temperature (SHT20 or SHT31)	Humidity (SHT20 or SHT31)
▲ 13:46:38	4	2	dev id: Jsn50	payload: 0B 54 00 00 00 00 00 FC 02 05				
▲ 13:46:26	3	2	dev id: Jsn50	payload: 0B 54 00 00 00 02 00 00 FF 01 FE				
▲ 13:46:14	2	2	dev id: Jsn50	payload: 0B 54 00 00 00 0C 00 01 03 01 F4				
▲ 13:46:02	1	2	dev id: Jsn50	payload: 0B 58 00 00 00 02 00 01 08 01 E9				
▲ 13:45:50	0	2	dev id: Jsn50	payload: 0B 58 00 00 00 00 00 01 0D 01 E1				

2.3 Uplink Payload

The uplink payload is totally 11 bytes as shown below:



time	counter	port		Battery Info	Temperature (DS18B20)	ADC	Digital Input and Digital Interrupt	Temperature (SHT20 or SHT31)	Humidity (SHT20 or SHT31)
▲ 13:46:38	4	2		dev id: Jsn50	payload: 0B 54 00 00 00 00 00 00 FC 02 05				
▲ 13:46:26	3	2		dev id: Jsn50	payload: 0B 54 00 00 00 02 00 00 FF 01 FE				
▲ 13:46:14	2	2		dev id: Jsn50	payload: 0B 54 00 00 00 0C 00 01 03 01 F4				
▲ 13:46:02	1	2		dev id: Jsn50	payload: 0B 58 00 00 00 02 00 01 08 01 E9				
▲ 13:45:50	0	2		dev id: Jsn50	payload: 0B 58 00 00 00 00 00 01 0D 01 E1				


2.3.1 Payload explain

The uplink payload includes totally 12 bytes. Uplink packets use FPORT=2 and every 10 minutes send one uplink by default.

Size(bytes)	2	2	1	2	2	2
Value	BAT	Temperature (DS18B20)	Digital in & Digital Interrupt	ADC	Temperature (SHT20 or SHT31)	Humidity (SHT20)

2.3.2 Decode payload in The Things Network

While using TTN network, user can add the payload format to decode the payload.



```

function Decoder(bytes, port) {
    // Decode an uplink message from a buffer
    // (array) of bytes to an object of fields.
    var value=bytes[0]<<8 | bytes[1];
    var batV=value/1000;//Battery,units:V
    value=bytes[2]<<8 | bytes[3];
    if(bytes[2] & 0xFC)
        {value |= 0xFFFF0000;}
    var tempc=(value/10).toFixed(2);//DS18B20,PB3,units:°C
    var adc_ch0=(bytes[4]<<8 | bytes[5])/1000;//PA0,ADC Channel 0,units:V
    var digital_IS=(bytes[6] & 0x02)? "H":"L";//PA12, Digital Input Status
    var exti_trigger=(bytes[6] & 0x01)? "TRUE":"FALSE";//PB14,GPIO_MODE_IT_FALLING
    value=bytes[7]<<8 | bytes[8];
    if(bytes[7] & 0xFC)
        {value |= 0xFFFF0000;}
    var temp_SHT=(value/10).toFixed(2);//SHT20,temperature,units:°C
    value=bytes[9]<<8 | bytes[10];
    var hum_SHT=(value/10).toFixed(1);//SHT20,Humidity,units:%
}
return {
    BatV:batV,
    TempC:tempc,
    ADC_CH0:adc_ch0,
    Digital_IS:digital_IS,
    EXTI_Trigger:exti_trigger,
    //TempC_SHT:temp_SHT,
    //Hum_SHT:hum_SHT
};
}

```

The function is :

```

function Decoder(bytes, port) {
    // Decode an uplink message from a buffer
    // (array) of bytes to an object of fields.
    var value=bytes[0]<<8 | bytes[1];
    var batV=value/1000;//Battery,units:V
    value=bytes[2]<<8 | bytes[3];
    if(bytes[2] & 0xFC)
        {value |= 0xFFFF0000;}
    var tempc=(value/10).toFixed(2);//DS18B20,PB3,units:°C
    var adc_ch0=(bytes[4]<<8 | bytes[5])/1000;//PA0,ADC Channel 0,units:V
    var digital_IS=(bytes[6] & 0x02)? "H":"L";//PA12, Digital Input Status
    var exti_trigger=(bytes[6] & 0x01)? "TRUE":"FALSE";//PB14,GPIO_MODE_IT_FALLING
    value=bytes[7]<<8 | bytes[8];
    if(bytes[7] & 0xFC)
        {value |= 0xFFFF0000;}
    var temp_SHT=(value/10).toFixed(2);//SHT20,temperature,units:°C
    value=bytes[9]<<8 | bytes[10];
    var hum_SHT=(value/10).toFixed(1);//SHT20,Humidity,units:%
}
return {
    BatV:batV,
    TempC:tempc,
    ADC_CH0:adc_ch0,
    Digital_IS:digital_IS,
    EXTI_Trigger:exti_trigger,
    //TempC_SHT:temp_SHT,
    //Hum_SHT:hum_SHT
};
}

```

And the uplink payload will show as below:

The screenshot shows the THE THINGS NETWORK CONSOLE interface. At the top, there are links for Applications, Gateways, and Support, along with a user profile for 'linsongxiong'. Below this, a navigation bar shows 'Applications > engineer-lin > Devices > LSN50 > Data'. The main area is titled 'APPLICATION DATA' and contains a table of received data. The table has columns for time, counter, port, payload, ADC_CH0V, BatV, and Digital_IStatus. One row in the table is highlighted with a red box, corresponding to the payload shown in the screenshot.

2.4 Payload explain and sensor interface

2.4.1 Battery Info

Check the battery voltage for LSN50.


Ex1: 0xB45 = 2885mV

Ex2: 0xB49 = 2889mV

2.4.2 Temperature (DS18B20)

If there is a DS18B20 connected to PB3 pin. The temperature will be uploaded in the payload.

Connection:



Example:

If read: 0105H: if (0105 & FC00 == 0), temp = 0105H /10 = 26.1 degree

If read: FF3FH : if (FF3F & FC00 == 1) ,temp = (FF3FH - 65536)/10 = -19.3 degrees.

2.4.3 Digital Input

The digital input for pin PA12,


- ✓ When PA12 is high, the bit2 of payload byte 6 is 1.
- ✓ When PA12 is low, the bit2 of payload byte 6 is 0.

2.4.4 ADC

Monitor the voltage in PA0, in mv.

Ex: 0x021F = 543mv,


Example1: Reading an Oil Sensor (Read a resistance value):



In the LSN50, we can use PB4 and PA0 pin to calculate the resistance for the oil sensor. Steps:

1. Solder a 10K resistor between PA0 and VCC.
2. Screw oil sensor's two pins to PA0 and PB4.

The equip circuit is as below:



According to above photo:

$$(VCC - V_{PA0})/10k = V_{PA0}/R_{oil_sensor}$$

So

$$R_{oil_sensor} = V_{PA0} \times 10K / (VCC - V_{PA0})$$

V_{PA0} is the reading of ADC. So if ADC=0x05DC=0.9 v and VCC (BAT) is 2.9v

The $R_{oil_sensor} = 0.9 \times \frac{10K}{2.9-0.9} = 4.5K$ ohm

Since the Bouy is linear resistance from 10 ~ 70cm.


The position of Bouy is $\frac{4.5K}{10K} \times (70cm - 10cm) + 10cm = 37cm$, from the bottom of Bouy

2.4.5 Digital Interrupt

Digital Interrupt refer to the pin PB14, it is trailing edge trigger. When there is a trigger, the LSN50 will send a packet to the server.

Example to use approximate switch with Digital Interrupt

The Hall element is a magnetic sensing element. A switch made of a Hall element is called a Hall switch. When the magnetic object moves closer to the Hall switch, the Hall element on the switch detection surface changes the internal circuit state of the switch due to the Hall effect, thereby identifying the presence of a magnetic object nearby, thereby controlling the on or off of the switch. The detection object of such a proximity switch must be a magnetic object.




2.4.6 I2C Interface (SHT20)

PB6(SDA) and PB7(SCK) are I2C interface. User can use it to connect to I2C device and get the sensor data.


We have made an example to show how to use the I2C interface to connect to SHT20

Temperature and Humidity Sensor. This is support in the stock firmware since v1.4.

Below is the connection to SHT20.



The device will be able to get the I2C sensor data now and upload to IoT Server.



time	counter	port	payload	Type
▲ 14:37:16	26	2	0B 21 00 00 00 00 00 00 01 16 02 47	Temperature
▲ 14:37:06	25	2	0B 21 00 00 00 00 00 00 01 16 02 48	Humidity
▲ 14:36:56	24	2	0B 21 00 00 00 00 00 00 01 16 02 48	
▲ 14:36:46	23	2	0B 22 00 00 00 00 00 00 01 17 02 49	
▲ 14:36:36	22	2	0B 21 00 00 00 00 00 00 01 17 02 49	
▲ 14:36:25	21	2	0B 21 00 00 00 00 00 00 01 17 02 4A	
▲ 14:36:15	20	2	0B 22 00 00 00 00 00 00 01 17 02 4A	

Convert the read byte to decimal and divide it by ten.

EX:

Temperature: Read:0116(H) = 278(D) Value: 278 /10=27.8°C;

Humidity: Read:0248(H)=584(D) Value: 584 / 10=58.4, So 58.4%

If user wants to use other I2C device, he can refer the SHT20 part source code as reference.

2.4.7 +5V output

Since v1.2 hardware version, a +5v output is added in the hardware. The +5V output will be valid for every sampling.

2.5 Downlink Payload

By default, LSn50 will print the downlink payload to console port. It won't do any action on that.

2.6 Firmware Change Log

V1.4 Firmware:

- ✓ Adjust payload, the default firmware include SHT20 and SHT31, If there is no SHT20, SHT31, the related filed will show FF FF FF FF
- ✓ Adjust 868 & 915 payload into 11 bytes, now 868 & 915 has same payload
- ✓ Fix the 85 degree bug for DS18B20
- ✓ Add new AT command which can adjust RX window time for LG01/LG02

- ✓ Add AT command to print all parameters.
- ✓ Any FPORT can accept downlink message and print.

V1.3 Firmware:

- ✓ Add new AT Commands: AT+CHS & AT+CHE
- ✓ Change AT+FDR command. This command will reset to factory except the keys
- ✓ +5v power will only enable when read sensor data
- ✓ Optimize OTAA join procedure. The first 50 joins will act as per LoRaWAN request(request join every few seconds), if devices have not joined in network, the Join Interval will extend to 30 minutes. If devices still not join at 200 tries, it will restart and start to Join again.
- ✓ Now print Device Model/Frequency bands/ Image Version/Dev EUI at start.

V1.2 Firmware:

- ✓ Support Class C
- ✓ After the configuration key can be stored in. No need to configure again even after power off.
- ✓ Add auto send feature after power on
- ✓ Solve negative temperature issue.
- ✓ Support Cayenne_LPP payload, user need to recompile firmware again. see this link [this link](#)

V1.1 Firmware:

- ✓ Support Battery Voltage(mV) ,The data of Oil Sensor ,The data of DS18B20, Digital I/O,ADC_IN1(PA1),
- ✓ Proximity switch, I2C Device Example

V1.0 Firmware:

Support ADC monitoring (See how to in the case study of Oil Sensor) and DS18B20 (See how to in the case study of DS18B20)

2.7 Battery Analyze

2.7.1 Battery Type

LSN50 Battery is composed by a 4000mAh Li/SOCl₂ Battery and Super Capacitor. The battery is un-rechargeable one time battery with low discharge rate (<2% per year). This type of battery is commonly used in IoT target for long term running, such as water meter.

The battery is design to last for more than 5 years for LSN50.

The battery related documents as below:


- ✓ [Battery Dimension](#),
- ✓ [Lithium-Thionyl Chloride Battery datasheet](#), [Tech Spec](#)
- ✓ [Lithium-ion Battery-Capacitor datasheet](#), [Tech Spec](#)

2.7.2 Power consumption Analyze

In a minimum system with DS18B20 and Oil Sensor and default firmware, the power consumption includes:

1. Deep Sleep (Stop mode) for STM32. ~ 5uA
2. Sampling current while reading DS18B20 and Oil Sensor
 - ✓ Oil Sensor sampling time: 200us, current: 0.3mA
 - ✓ DS18B20 sampling time: 750ms, current: 0.64mA
 - ✓ Above power should add 8mA CPU power in working mode.
3. LoRaWAN transmit and receive time consumption. The LoRa TX / RX time and power can be found in the [LoRa calculator tool](#).

In a typical LoRaWAN data transmit. The energy profile is as below:



In LoRaWAN protocol, the device will transfer in different LoRa Radio, and have different energy profile in LoRa part. We can calculate the battery life in two cases:

- 1) Lower power LoRa radio. Device has a good signal to gateway
- 2) Higher power LoRa radio. Device has a poor signal to gateway

Lower Power Case:

- ✓ Radio Parameter: SF7, 125kHz, 20dbm
- ✓ Transmit interval: 15 minutes.
- ✓ Payload: 8 Bytes.

High Power Case:

- ✓ Radio Parameter: SF10, 125kHz, 20dbm
- ✓ Transmit interval: 15 minutes.
- ✓ Payload: 8 Bytes.

To simplify the calculation, we can:

- ✓ Combine oil sensor and ds18b20 sampling energy together to **751ms@8.64ma**
- ✓ Combine two RX windows together.

There is a [power consumption tool](#) for easy analyze. And below is the analyze result.

Scenarios	A	B	C	D	E	F	
Time	Units	Scenario_A	Scenario_B	Scenario_C	Scenario_D	Scenario_E	Scenario_F
Sleep	min	15	15	15			
Sampling	ms	751	751	5000			
Transmit	ms	100	274.4	34.3			
Receive	ms	72	491.4	82			
Radio type		SF7_125K_20dB	SF10_125K_20dB	SF7_125K_14dB			
# of bytes transmitted		8	8	8			

Total System Current	mA	0.005	0.005	0.005			
Sleep	mA	0.64	0.64	0.64			
Sampling	mA	133	133	52			
Transmit	mA	18.8	18.8	18.8			
Receive	mA						

Micro-Controller Active power (mA): 8							
Legend: Red > 100%, Green <= 100%							
Power usage comparison	%	22.92%	8.87%	40.82%	0.00%	0.00%	0.00%
Sleep	%	2.45%	0.95%	29.02%	0.00%	0.00%	0.00%
Sampling	%	67.74%	71.96%	16.18%	0.00%	0.00%	0.00%
Transmit	%	6.89%	18.22%	13.98%	0.00%	0.00%	0.00%
Receive	%						
Average current	mA	0.021793472	0.056254259	0.012180976	0	0	0

Design Goals	System efficiency	90%	90%	90%	90%	90%	90%
System efficiency							
Target battery life	yr	2	2	2	2	2	2
Required battery capac	mAh	424.54	1095.83	237.29	0.00	0.00	0.00
or							
Given battery capacity	mAh	4000	4000	4000	4000	4000	4000
Estimated battery life	yr	18.84	7.30	33.71	0.00	0.00	0.00

Ignore the 18 year, because the battery has a max 2% discharge per year.

2.7.3 Battery notice

The Li-SICO battery is designed for small current / long period application. It is not good to use high current, short period transmit. The recommend min period for use this battery is 5 minutes. If user uses a shorter period time to transmit LoRa. The battery life may be decreased.

2.7.4 Replace the battery

User can replace the battery to other battery for LSN50. In the mother board, there is a diode (D1) between the battery and the main circuit. If user needs to use a battery with less than 3.3v, please remove the D1 and shortcut the two pads of it. So there won't be voltage drop between battery and main board.


3. Use AT Command

3.1 Access AT Command

LSN50 supports AT Command set in stock firmware. User can use a USB to TTL adapter to connect to LSN50 for using AT command, as below.



In PC, User needs to set serial tool baud rate to **9600** to access serial console for LSN50. LSN50 will output system info once power on and access to:



Below are the available commands, a more detail AT Command manual can be found at [AT Command Manual](#)

AT+<CMD>? : Help on <CMD>

AT+<CMD> : Run <CMD>

AT+<CMD>=<value> : Set the value

AT+<CMD>=? : Get the value

General Command

AT: Attention

AT?: Short Help

ATZ: MCU Reset

AT+TDC: Application Data Transmission Interval

Keys,IDs and EUIs management

AT+APPEUI: Application EUI

AT+APPKEY: Application Key

AT+APPSKEY: Application Session Key

AT+DADDR: Device Address

AT+DEUI: Device EUI

AT+NWKID: Network ID(You can enter this command change only after successful network connection)

AT+NWKSKEY: Network Session Key

Joining and sending date on LoRa? network

AT+CFM: Confirm Mode

AT+CFS: Confirm Status

AT+JOIN: Join LoRa? Network

AT+NJM: LoRa? Network Join Mode

AT+NJS: LoRa? Network Join Status

AT+RECV: Print Last Received Data in Raw Format

AT+RECVB: Print Last Received Data in Binary Format

AT+SEND: Send Text Data

AT+SENB: Send Hexadecimal Data

LoRa network management

AT+ADR: Adaptive Rate

AT+CLASS: LoRa Class(Currently only support class A)

AT+DCS: Duty Cycle Setting

AT+DR: Data Rate (Can Only be Modified after ADR=0)

AT+FCD: Frame Counter Downlink

AT+FCU: Frame Counter Uplink

AT+JN1DL: Join Accept Delay1

AT+JN2DL: Join Accept Delay2
AT+PNM: Public Network Mode
AT+RX1DL: Receive Delay1
AT+RX2DL: Receive Delay2
AT+RX2DR: Rx2 Window Data Rate
AT+RX2FQ: Rx2 Window Frequency
AT+TXP: Transmit Power

Information

AT+RSSI: RSSI of the Last Received Packet
AT+SNR: SNR of the Last Received Packet
AT+VER: Image Version and Frequency Band
AT+FDR: Factory Data Reset
AT+PORT: Application Port
AT+CHS: Get or Set Frequency (Unit: Hz) for Single Channel Mode
AT+CHE: Get or Set eight channels mode, Only for US915, AU915, CN470

3.2 Common AT Command Sequence

3.2.1 Multi-channel ABP mode (Use with SX1301/LG308)

If device has not joined network via OTAA:

AT+FDR
AT+NJM=0
ATZ

If device already joined network:

AT+NJM=0
ATZ

3.2.2 Single-channel ABP mode (Use with LG01/LG02)

These settings require user to set the device in ABP mode in LoRaWAN server.

AT+FDR Reset Parameters to Factory Default, Keys Reserve
AT+NJM=0 Set to ABP mode
AT+ADR=0 Set the Adaptive Data Rate Off
AT+DR=5 Set Data Rate
AT+TDC=300000 Set transmit interval to 5 minutes
AT+CHS=868400000 Set transmit frequency to 868.4Mhz (same as RX frequency in LG01/LG02)
AT+DADDR=26 01 1A F1 Set Device Address to 26 01 1A F1
ATZ Reset MCU

4. Upload Firmware

Notice:

- Since image v1.3, the firmware will show version info during boot. If your device doesn't show version info, you may have a very old image version.
- Always run AT+FDR to reset parameters to factory default after update image, if update from image >= v1.3 to another image version >=v1.3. The keys will keep after running AT+FDR. Otherwise (such as from v1.2 to v1.3), AT+FDR may erase the keys.

4.1 Upload Firmware via Serial Port


The LSN50's AT Command port can be used for firmware upgrade. The hardware connection for upgrade firmware is as below:




Step1: Download [flash loader](#).

Step2: Download the [LSN50 Image files](#).

Step3: Open flashloader; choose the correct COM port to update






Step4: Switch SW1 back to flash state and push RESET button. The LSN50 will run the new firmware now.

4.2 Upload Firmware via ST-Link V2

User can use ST-LINK to upgrade firmware into LSN50. The hardware connection for upgrade firmware is as below:



Connection:


- ✓ ST-LINK v2 GND <-> LSN50 GND
- ✓ ST-LINK v2 SWCLK <-> LSN50 PA14
- ✓ ST-LINK v2 SWDIO <-> LSN50 PA13
- ✓ ST-LINK v2 RST <-> LSN50 NRST.

Step1: Install [ST-LINK driver](#) first and then install [ST-LINK Utility](#)

Step2: Download the [LSN50 Image files](#).


Step3: Open ST-LINK utility, [file --> open file](#) to select the image to be upgraded.

Step4: Click the “Program Verify” button on ST-LINK.



Step5: The led on the ST-LINK adapter will now blinking, and the ST-Link utility will pop up a download window. Click the start button to download the image to LSN50.

(NOTE: If this step fail, ST-LINK can't establish connection to LSN50, please try to swap SWDIO & SWCLK pin. We see some ST-LINK v2 has wrong mark for them)



5. Developer Guide

5.1 Source Code

[Software Source Code Download Link.](#)

[Hardware Source Code Download Link](#)


5.2 Compile Source Code

5.2.1 Set up Keil compile environment

Assume you already have [Keil uVision5](#) installed. Below step shows how to install MDK support and get license.

1: Open the web: <http://www2.keil.com/stmicroelectronics-stm32/mdk>


2: Download the keil:



3: Login with an account that has administration rights.

4: Right-click the µVision icon and select **Run as Administrator...** from the context menu.

5: Open the dialog **File — License Management...** and select the **Single-User License tab**.



6: Click the button **Get LIC via Internet...**, then click the button **OK** to register the product. This action opens the License Management page on the Keil web site.

[License Management page on the Keil web site.](#)


License Management

Single-User License | Floating License | Floating License Administrator | FlexLM License |

Customer Information		Computer ID
Name:	<input type="text"/>	CID: C7H4Y-I
Company:	Arm	Get LIC via Internet...
Email:	<input type="text"/>	
Product	License ID Code (LIC)/Product variant	Support Period
MDK-ARM Cortex-M0/M0+ 256K for ST	9DAUH-WU4S4-E89XN-BH47D-62JWP-CILZ6	Expires: Jan 2020


7: Enter the **Product Serial Number 4PPFW-QBEHZ-M0D5M** along with your contact information and click the button **Submit**. An e-mail is sent back with the **License ID Code (LIC)** within a few minutes.

(1)



The screenshot shows the "Single-User License" form on the arm KEIL website. The "Product Serial # (PSN)" field contains the value "4PPFW-QBEHZ-M0D5M", which is highlighted with a yellow background and a red arrow pointing to it. Other fields include "Computer ID (CID): CWS1R-RXZE" and "PC Description: [empty input field]". The "Important Information" sidebar at the bottom left states: "This site uses cookies to store information on your computer. By continuing to use our site, you consent to our cookies." A "Don't show this message again" button is also present.

(2)



The screenshot shows the "Thanks for Licensing Your Product" confirmation page. It states: "We have sent your product registration information including the License ID Code (LIC) via e-mail to [redacted]@qq.com. Your email". The "Important Information" sidebar at the bottom left is identical to the one in step 1. The right sidebar contains sections for "Quick Links" (with a link to "Licensing User's Guide") and "Knowledgebase" (with links to "LTOOLS - Unable to Start or Stop FlexLM Server", "L6050U: The code size of this image exceeds the maximum ...", and "Issues with Licensing Product Serial Number (PSN)").

(3)

Thank you for licensing your Keil product. Your License ID Code (LIC) is printed below. Print a copy of this e-mail to keep for your records.

MDK-ARM Cortex-M0/M0+ 256K
For ST Only
Support Ends 31 Jan 2020

PC Description : 111
Computer ID (CID): CWS1R-RLXZE


License ID Code (LIC): WZLTG-VNA70-2CV1I-6MCRS-21WVS-ZDPY5

To activate your Keil product, copy the License ID Code (LIC) and paste it into the New License ID Code input field on the Single-User License Tab in the uVision4 License Manager Dialog (available from the File menu).


*** DO NOT REPLY TO THIS EMAIL: For licensing problems or questions, please contact Keil Technical Support.

Thank You,
Technical Support

8:To activate the Software Product, enter the LIC in the field **New License ID Code (LIC)** of the dialog **License Management...** and click **Add LIC**.




9:Finish





5.2.2 Install STM32L0 Series Device

1:Open the web:<http://www.keil.com/dd2/pack/eula-container>;


2:Find the STMicroelectronics STM32L0 Series Device and download it;




3:Find the Software Pack and installs it;



4:Add the Device ,then you can rebuild the project.




Notice: If without add the Device, the keil would report this error.




5.2.3 Compile Source Code


1. Download the source code from [Software Source Code Download Link](#).
2. Use Keil to open the project file:
STM32CubeExpansion_LRWAN/Projects/Multi/Applications/LoRa/DRAGINO-LRWAN(AT)/MDK-ARM/STM32L072CZ-Nucleo/Lora.uvprojx
3. In Keil, you can see what frequency band the code support.



4. If you want to change frequency, modify the Preprocessor Symbols. For example, change EU868 to US915



5. Compile and build



6. FAQ

6.1 Why there is 433/868/915 version?

Different country has different rules for the ISM band for using the LoRa. Although the LoRa chip can support a wide range of Frequency, we provide different version for best tune in the LoRa part. That is why we provide different version of LoRa.

6.2 What is the frequency range of LT LoRa part?

Different LT version supports different frequency range, below is the table for the working frequency and recommend bands for each model :

Version	LoRa IC	Working Frequency	Best Tune Frequency	Recommend Bands
433	SX1278	Band2(LF): 410 ~525 Mhz	433Mhz	CN470/EU433
868	SX1276	Band1(HF):862~1020 Mhz	868Mhz	EU868
915	SX1276	Band1(HF):862 ~1020 Mhz	915Mhz	AS923/AU915/ KR920/US915

6.3 How to change the LoRa Frequency Bands/Region?

User can follow the introduction for [how to upgrade image](#). When download the images, choose the required image file for download.

6.4 Can I use Private LoRa protocol?

The stock firmware is based on LoRaWAN protocol. User can use a private LoRa protocol in LSN50, this section describe an example for base LoRa transfer. It is a reference/demo and we didn't provide further software develop support on this topic.

In this demo, we will show the communication between LoRa Shield and LSN50, both of them use the basic LoRa library. LSN50 will send a message to LoRa Shield and LoRa Shield will print it to the console.

LoRa Shield + UNO:


Use the <[LoRa Library](#)> and upload the [LoRa_Receive](#) Sketch to Arduino. Open the serial monitor to Arduino, it acts as a LoRa Receiver and listen on the frequency: 868.3Mhz

LSN50:

Use the <[LoRa RAW code](#)> . The project file is in: MDK-ARM\STM32L072CZ-Nucleo\Lora.uvprojx

Compile it and Upload it to LSN50, the LSN50 will transfer on the frequency 868.3Mhz.

In Arduino Console, it will see:



LoRa Receiver
Received packet 'Hello,LoRa shield' with RSSI -32
Received packet 'Hello,LoRa shield' with RSSI -33
Received packet 'Hello,LoRa shield' with RSSI -33
Received packet 'Hello,LoRa shield' with RSSI -32
Received packet 'Hello,LoRa shield' with RSSI -33
Received packet 'Hello,LoRa shield' with RSSI -33
Received packet 'Hello,LoRa shield' with RSSI -33
Received packet 'Hello,LoRa shield' with RSSI -34
Received packet 'Hello,LoRa shield' with RSSI -33
Received packet 'Hello,LoRa shield' with RSSI -33

Autoscroll No line ending 9600 baud

6.5 How to set up LSN50 to work in 8 channel mode in US915, AU915, CN470 bands?

By default, the frequency bands US915, AU915, CN470 works in 72 frequencies. Many gateways are 8 channel gateways, in such case, the OTAA joined time and uplink schedule is **long and unpredictable** while the end node hopping in 72 frequencies.

User can configure the end node to work in 8 channel models by using the AT+CHE command, the 500kHz channels are always includes for OTAA.

For example, in US915 band, the frequency table is as below. By default, end node will use all channels (0~71) for OTAA Join process. After OTAA JOINED, end node will use these all channels (0~71) to send uplink packets.

CHE	US915 Uplink Channels(125KHz,4/5,Unit:MHz,CHS=0)								
0	ENABLE Channel 0-63								
1	902.3	902.5	902.7	902.9	903.1	903.3	903.5	903.7	Channel 0-7
2	903.9	904.1	904.3	904.5	904.7	904.9	905.1	905.3	Channel 8-15
3	905.5	905.7	905.9	906.1	906.3	906.5	906.7	906.9	Channel 16-23
4	907.1	907.3	907.5	907.7	907.9	908.1	908.3	908.5	Channel 24-31
5	908.7	908.9	909.1	909.3	909.5	909.7	909.9	910.1	Channel 32-39
6	910.3	910.5	910.7	910.9	911.1	911.3	911.5	911.7	Channel 40-47
7	911.9	912.1	912.3	912.5	912.7	912.9	913.1	913.3	Channel 48-55
8	913.5	913.7	913.9	914.1	914.3	914.5	914.7	914.9	Channel 56-63
Channels(500KHz,4/5,Unit:MHz,CHS=0)									
	903	904.6	906.2	907.8	909.4	911	912.6	914.2	Channel 64-71

When user uses the TTN network, the US915 frequency bands use are:

- ✓ 903.9 - SF7BW125 to SF10BW125
- ✓ 904.1 - SF7BW125 to SF10BW125
- ✓ 904.3 - SF7BW125 to SF10BW125
- ✓ 904.5 - SF7BW125 to SF10BW125
- ✓ 904.7 - SF7BW125 to SF10BW125
- ✓ 904.9 - SF7BW125 to SF10BW125
- ✓ 905.1 - SF7BW125 to SF10BW125
- ✓ 905.3 - SF7BW125 to SF10BW125
- ✓ 904.6 - SF8BW500

Because the end node is now hopping in 72 frequency, it makes the devices hard to Join the TTN network and uplink data. To solve this issue, user can access the device via AT Command and run:

AT+CHE=2

ATZ

to set the end node to work in 8 channel mode. The device will work in Channel 8-15 & 64-71 for OTAA, and channel 8-15 for Uplink.

AU915 is similar. Below is the AU915 Uplink Channels.


CHE	AU915 Uplink Channels(125KHz,4/5,Unit:MHz,CHS=0)									
0	ENABLE Channel 0-63									
1	915.2	915.4	915.6	915.8	916	916.2	916.4	916.6	Channel 0-7	
2	916.8	917	917.2	917.4	917.6	917.8	918	918.2	Channel 8-15	
3	918.4	918.6	918.8	919	919.2	919.4	919.6	919.8	Channel 16-23	
4	920	920.2	920.4	920.6	920.8	921	921.2	921.4	Channel 24-31	
5	921.6	921.8	922	922.2	922.4	922.6	922.8	923	Channel 32-39	
6	923.2	923.4	923.6	923.8	924	924.2	924.4	924.6	Channel 40-47	
7	924.8	925	925.2	925.4	925.6	925.8	926	926.2	Channel 48-55	
8	926.4	926.6	926.8	927	927.2	927.4	927.6	927.8	Channel 56-63	
Channels(500KHz,4/5,Unit:MHz,CHS=0)										
	915.9	917.5	919.1	920.7	922.3	923.9	925.5	927.1	Channel 64-71	

6.6 How to set up LSN50 to work with Single Channel Gateway such as LG01/LG02?

In this case, users need to set LSN50 to work in ABP mode & transmit in only one frequency.

Assume we have a LG02 working in the frequency 868400000 now, below is the steps.

Step1: Log in TTN, Create an ABP device in the application and input the network session key (NETSKEY), app session key (APPSKEY) from the device.



CONSOLE
COMMUNITY EDITION

Applications > dragino_test_application1 > Devices > 23232

Application ID: dragino_test_application1

Device ID: 23232

Description: LT-33222-L-5645

Activation Method: ABP

Device EUI: 00 B9 14 BE 07 0A 90 34

Application EUI: 70 B3 D5 7E F0 00 46 18

Device Address: 26 01 1A F1

Network Session Key: DD 86 97 F6 BD 8E 7F 43 CE 69 44 4F 26 64 16 41

App Session Key: 78 48 B2 5C D6 BE 8B 2F 8B C8 47 B8 13 21 FE 14

Status: 4 minutes ago

In ABP mode, The device Address, Network Session Key, App Session Key must match between the End Node and LoRaWAN server

Note: user just need to make sure above three keys match, User can change either in TTN or Device to make them match. In TTN, NETSKEY and APPSKEY can be configured by user in setting page, but Device Addr is generated by TTN. User can also change the Device ADDR in TTN by using the [The Things Network CLI](#).


Step2: Run AT Command to make LSN50 work in Single frequency & ABP mode. Below is the AT commands:

```

AT+FDR      Reset Parameters to Factory Default, Keys Reserve
AT+NJM=0    Set to ABP mode
AT+ADR=0    Set the Adaptive Data Rate Off
AT+DR=5     Set Data Rate (Set AT+DR=3 for 915 band)
AT+TDC=300000 Set transmit interval to 5 minutes
AT+CHS=868400000 Set transmit frequency to 868.4Mhz
AT+DADDR=26 01 1A F1 Set Device Address to 26 01 1A F1
ATZ          Reset MCU

```

As shown in below:



```
LSN50 Device
Image Version: v1.3
Frequency Band: AU915
DevEui= A8 40 41 00 01 81 89 98
Please set the parameters or reset Device to apply change

OK
OK
OK
OK
OK
OK

LSN50 Device
Image Version: v1.3
Frequency Band: AU915
DevEui= A8 40 41 00 01 81 89 98
JOINED

***** UpLinkCounter= 0 *****
TX on freq 868400000 Hz at DR 5
txDone
rxTimeOut
rxTimeOut
```

6.7 How to configure the EUI keys in LSN50?

The early version of LSN50 doesn't have pre-configured keys, and have old image version. It is recommended that the user first update the image to the latest version before configure the keys.

Refer [upgrade image](#) to update the firmware to latest one.

And run AT Commands to set the keys to desired keys, refer [AT Command manual](#).


7. Trouble Shooting

7.1 Connection problem while using USB <----> TTL to upload firmware.

Issue: While using USB to TTL to upload firmware via UART interface. It works for several times but most of times it fails.

Checklist:

1. Double check if follow up exactly the steps as manual.
2. Check if hardware works fine: a) check if AT command works, b) check if ISP / flash switch works: PA12 will have different output level while set the ISP/Flash Switch in different position. c) check if reset button works.
3. If you use Windows10 system. Please change the flash loader to run in Windows7 compatibility mode.



4. We see a case the FT232 USB TTL adapter has reliability issue with the PC USB chipset(Intel). In this case, even point 1 & 2 work, it still has serious reliability issue for uploading. If this happen, change a PC or change a USB to TTL adapter will solve.

7.2 Why I can't join TTN in US915 /AU915 bands?

It is about the channels mapping. Please see [this link](#) for detail.

8. Order Info

Part Number: **LSN50-XX-YY**

XX: The default frequency band

- ✓ **AS923:** LoRaWAN AS923 band
- ✓ **AU915:** LoRaWAN AU915 band
- ✓ **EU433:** LoRaWAN EU433 band
- ✓ **EU868:** LoRaWAN EU868 band
- ✓ **KR920:** LoRaWAN KR920 band
- ✓ **US915:** LoRaWAN US915 band
- ✓ **IN865:** LoRaWAN IN865 band
- ✓ **CN470:** LoRaWAN CN470 band

YY:

- ✓ **12:** With M12 waterproof cable hole
- ✓ **16:** With M16 waterproof cable hole
- ✓ **20:** With M20 waterproof cable hole
- ✓ **NH:** No Hole

9. Packing Info

Package Includes:

- ✓ LSN50 LoRa Sensor Node x 1

Dimension and weight:

- ✓ Device Size: 8 x 6.5 x 5 cm
- ✓ Device Weight: 137g
- ✓ Package Size / pcs : 9 x 7 x 6cm
- ✓ Weight / pcs : 160g

10. Support

- Support is provided Monday to Friday, from 09:00 to 18:00 GMT+8. Due to different timezones we cannot offer live support. However, your questions will be answered as soon as possible in the before-mentioned schedule.
- Provide as much information as possible regarding your enquiry (product models, accurately describe your problem and steps to replicate it etc) and send a mail to

support@dragino.com

11. Reference

✧ [Product Page](#) , [DataSheet](#)

✧ [Image Download](#)

✧ [AT Command Manual](#)