ICE Telescope

A ROS package

Biel Artigues Aguilo

February 22, 2016 Version 0.1.3

Abstract

ice_telescope is a ROS package to operate and remote control the telescope system at the ICE building in the UAB Campus. The full system is composed of a Meade LX200GPS telescope, a SBIG ST-7 CCD camera, a Baader Planetarium dome, an APC Switched PDU and a Vaisala weather station..

1 Synopsis

ROS

roscore

Server

rosrun ice_telescope ice_tel_server

Client

rosrun ice_telescope ice_telescope_node action [params]

2 Description

ice_telescope is composed of several nodes -ice_telescope_node- that allow the control of the telescope system. In addition to the server to control all devices ice_tel_server, each of the system components (telescope, dome, ccd, pdu, weather station) has a client node following the naming convention brand_client:

Full-Serverice_tel_server.Telescopemeade_client.CCDsbig_client.Domebaader_client.PDUapc_client.WSvaisala_client.

The server node runs continuously waiting for petitions from the client nodes. When a client node's petition is received by the server node, the server processes the petition, sends a response back to the client and returns to the waiting mode. The client waits for the server response and finishes the execution.

Client node

The **action** parameter issues the desired order to the server.

[params] will depend on the system component and the selected action.

Note: roscore must be running at all times for node communication and interoperation.

3 Servers

The server for all the system elements is executed without additional parameters and it must be running to listen to the clients commands.

Full-Server

rosrun ice_telescope ice_tel_server

4 Telescope client

The telescope client issues the user's desired actions to perform with the Meade LX200GPS Telescope.

rosrun ice_telescope meade_client action [params]

Note: To run more than one *meade_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [__name:=DesiredName]

4.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

goto Point the telescope to the specified coordinates.

rosrun ice_telescope meade_client goto ra dec

- ra Right ascension as a double value.
- dec Declination as a double value.

messier Point the telescope to the selected catalog object.

star rosrun ice_telescope meade_client messier objectNum

deepsky rosrun ice_telescope meade_client star objectNum

rosrun ice_telescope meade_client deepsky objectNum

• **objectNum** The catalog number for the desired object.

gps Update the system's gps. Note: The dome must be open for the gps sync.

rosrun ice_telescope meade_client gps

getobjradec Get the coordinates of the currently selected object.

rosrun ice_telescope meade_client getobjradec

gettelradec Get the telescope's current pointing coordinates.

 $rosrun\ ice_telescope\ meade_client\ gettelradec$

getdatetime Get the telescope's current date and time.

 $rosrun\ ice_telescope\ meade_client\ getdatetime$

Version: 0.1.3, February 22, 2016

setdatetime Set the telescope's date and time to the current ones.

 $rosrun\ ice_telescope\ meade_client\ set date time$

getlatlon Get the telescope's latitude and longitude.

 $rosrun\ ice_telescope\ meade_client\ getlatlon$

setlation Set the telescope's latitude and longitude.

rosrun ice_telescope meade_client setlatlon lat lon

- lat The current latitude as a double value.
- lon The current longitude as a double value.

focus Move the telescope's focus (in/out). WORK IN PROGRESS.

reconnect Re-establish telescope connection.

 $rosrun\ ice_telescope\ meade_client\ reconnect$

5 CCD client

The CCD client issues the user's desired actions to perform with the SBIG ST-7 CCD.

 $rosrun\ ice_telescope\ sbig_client\ action\ [{f params}]$

Note: To run more than one *sbig_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [__name:=DesiredName]

5.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

capture

Start an exposure and save the result to file.

 $rosrun\ ice_telescope\ sbig_client\ capture\ filePath\ fileType\ imgCount\ imgType\ exp-Time\ readoutMode\ top\ left\ width\ height\ fastReadout\ dualReadoutChannel$

- ullet filePath: The path for the saved image files.
- fileType: FITS or SBIG file formats.
- imgCount: Number of exposures to take.
- imgType: LF (light frame) or DF (dark frame).
- expTime: Number of seconds (or fraction of second) of exposure.
- readoutMode: Binning. Options: 1x1, 2x2, 3x3.
- top: Starting position in the 'Y' axis.
- left: Starting position in the 'X' axis.
- width: Image width in pixels.
- height: Image height in pixels.

Note: If all params (top, left, width and height) are zero, the full size of the CCD image is used.

• fastReadout: 1 for fast readout and 0 for normal readout.

• dualReadoutChannel: 1 for dual channel readout an 0 for single channel readout.

settemp Enable or disable the cooler to achieve the desired temperature for the CCD.

 $rosrun\ ice_telescope\ sbig_client\ settemp\ enable\ temperature$

• enable: 1 to enable and 0 to disable.

• temperature: double value with the desired temperature

gettemp Query the CCD temperature. The server returns the temperature, the power

applied to the CCD as a percentage (0-1) and the cooler status (enabled/disabled).

rosrun ice_telescope sbig_client gettemp

getcapstatus Query the CCD capture status. The server returns the exposure progress percent-

age or the IDLE status.

rosrun ice_telescope sbig_client getcapstatus

reconnect Re-establish CCD connection.

rosrun ice_telescope sbig_client reconnect

6 Dome client

The dome client issues the user's desired actions to perform with the Baader Planetarium Dome.

rosrun ice_telescope baader_client action

Note: To run more than one *baader_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [__name:=DesiredName]

6.1 Options

The *action* parameter is the command to be sent to the server. The *action* can be one of the following:

open Open the dome.

rosrun ice_telescope baader_client open

close Close the dome.

 $rosrun\ ice_telescope\ baader_client\ close$

status Query the dome status. The possible states for the dome are: open, closed, moving

and unknown.

 $rosrun\ ice_telescope\ baader_client\ status$

reconnect Re-establish dome connection.

rosrun ice_telescope baader_client reconnect

7 PDU client

The PDU client issues the user's desired actions to perform with the APC Switched PDU.

rosrun ice_telescope apc_client action device

Note: To run more than one *apc_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [__name:=DesiredName]

7.1 Options 9 EXAMPLE

7.1 Options

The *action* parameter is the command to be sent to the server and the *device* parameter specifies on which system element the action has to be performed. The *device* parameter can be one of the following:

telescope The specified action will be performed on the telescope.

 $rosrun\ ice_telescope\ apc_client\ action\ telescope$

ccd The specified *action* will be performed on the CCD.

 $rosrun\ ice_telescope\ apc_client\ action\ ccd$

weather_station The specified action will be performed on the weather station.

 $rosrun\ ice_telescope\ apc_client\ action\ weather_station$

light The specified action will be performed on the light inside the dome.

rosrun ice_telescope apc_client action light

The action can be one of the following:

power_on Power on the specified device by switching on the corresponding outlet of the PDU.

rosrun ice_telescope apc_client power_on device

power_off Power off the specified device by switching off the corresponding outlet of the

PDU.

rosrun ice_telescope apc_client power_off device

power_status Check the corresponding PDU's outlet status.

rosrun ice_telescope apc_client power_status device

8 Weather Station client

The weather station client issues the user's desired actions to perform with the Vaisala weather station. The only action for the weather station is *getinfo*.

 $rosrun\ ice_telescope\ vaisala_client\ getinfo$

Note: To run more than one *vaisala_client* node at the same time it is necessary to specify a name for the node in the above commands as follows [__name:=DesiredName]

9 Example

```
$ roscore &

$ rosrun ice_telescope ice_tel_server &

$ rosrun ice_telescope baader_client open
$ rosrun ice_telescope sbig_client settemp 1 10.0
$ rosrun ice_telescope meade_client gps
$ rosrun ice_telescope meade_client setdatetime
$ rosrun ice_telescope meade_client messier 31
$ rosrun ice_telescope sbig_client capture /img/ FITS 10 LF 30.0 1x1 0 0 0 0 1 1
$ rosrun ice_telescope baader_client close
```

10 See Also

ROS, rosrun, roscd, rosls, catkin_make.

11 Requirements

ROS Environment ice_telescope requires ROS version >= 1.11.16 (>= Indigo distribution).

ROS Workspace If you want to compile or install the distributed system, you need a *catkin* workspace.

Libraries:

- libusb-1.0.
- cfitsio.
- libsnmp-dev.
- libsbigudry. This library can be downloaded from http://archive.sbig.com/sbwhtmls/devswframe.htm.

12 Changes

Please check the file CHANGELOG for the list of changes and acknowledgment to people contributing bugfixes or enhancements.

13 Version

Version: 0.1.3 of February 22, 2016.

14 License and Copyright

Copyright © 2015, Biel Artigues Aguilo, ICE Building, Campus UAB, Bellaterra, Catalunya artigues@ice.cat

License This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

15 Author

Biel Artigues Aguilo

Email: artigues@ice.cat

Web: http://www.ice.csic.es/.