


Raspberry PI Global Shutter Camera Support Hardware Trigger And Strobe Support PI4/PI3+/PI3/PI2 libcamera

## CAM-MIPI296RAW User Manual



## **SONY IMX296LLR-C**

Global Shutter CMOS Sensor

1456\*1088 / 60fps

Normally We will update our development Mannual here <a href="https://github.com/INNO-MAKER/cam-imx296raw-trigger/">https://github.com/INNO-MAKER/cam-imx296raw-trigger/</a>
<a href="https://www.inno-maker.com/product/cam-mipi296raw-trigger/">https://www.inno-maker.com/product/cam-mipi296raw-trigger/</a>

Date	Revision	Change Details
2023/04/04	V1.0	First Released
2023/05/30	V1.1	Chapter 4.2.1,Preview command change
2023/6/9	V1.2	Chapter3.3,3.4,3.5,3.6 Add python code
2023/06/13	V1.3	Delete 3.6 innocam description

Support: support@inno-maker.com
Bulk Price: sales@inno-maker.com

Wiki: wiki.inno-maker.com Github: https://github.com/INNO-MAKER



Raspberry PI Global Shutter Camera Support Hardware Trigger And Strobe Support PI4/PI3+/PI3/PI2 libcamera

2023/01/15	V1.4	Chapter 2.4, 2.5 Update Trigger/Strobe
2024/3/18	V1.5	

# Www.inno-maker.com

#### **CAM-MIPI296RAW**

Raspberry PI Global Shutter Camera Support Hardware Trigger And Strobe Support PI4/PI3+/PI3/PI2 libcamera

## **Chapter 1 Description**

CAM-MIPI296RAW is a Global Shutter Camera with IMX296LLR-C CMOS Sensor Module support up to 60fps at 1456×1088 Pixels operate with shorter exposure times down to 30µs, given enough light than a rolling shutter camera, which makes it useful for high-speed photography.

- Support Raspberry Pi OS Build In Drivers totally compatible raspberry pi official gs camera module with libcamera tools for all pi boards
- Support Innomaker driver with isolated hardware External Trigger And isolated Strobe function, control by v4l2-ctl -l tools.(InnoMaker Driver did not support libcamera and only support specify system version)

#### **Module Features:**

- Support up to 60fps at 1456×1088 Pixels, Compatible with rasberry pi GS camera;
- Comes with 1x M12 Len-seat and 1xCS Len-Seat, 1x M12 wide angle Len;
- Support Pi 4B/Pi 3B+/Pi 3B/Pi 3A+/CM4/CM3+/CM3 Directly with libcamera tools;
- Output format Y10 with Resolution 1456\*1088 up to 60fps (InnoMaker Driver);
- Output format YUV with Resolution 1456\*1088 up to 60fps;(Raspberry PI OS Driver);

#### **Sensor Features:**

This chip operates with analog 3.3V, digital 1.2V, and interface 1.8V triple power supply:

- low power consumption.
- High sensitivity, low dark current and low PLS characteristics are achieved.
   (Applications: Sensing)

Sony IMX296LLR Sensor		
FPS (Sensors):	60.3 fps	
Pixel Size (Sensors):	3.4µm x 3.4µm	
Resolution (Sensors):	1.58M	
Scan/Series:	Pregius	
Shutter (Sensors):	Global	
Signal (Sensors):	Monochrome	
Sensor Size	1 / 2.9	




Wiki: wiki.inno-maker.com

Raspberry PI Global Shutter Camera Support Hardware Trigger And Strobe Support PI4/PI3+/PI3/PI2 libcamera

# **Chapter 2 Hardware**

## 2.1 Module Size





Raspberry PI Global Shutter Camera Support Hardware Trigger And Strobe Support PI4/PI3+/PI3/PI2 libcamera

## 2.2 LEN Seat And LEN

## M12 LEN Seat







Raspberry PI Global Shutter Camera Support Hardware Trigger And Strobe Support PI4/PI3+/PI3/PI2 libcamera

## M12-CS Len Seat






M12 LEN



Raspberry PI Global Shutter Camera Support Hardware Trigger And Strobe Support PI4/PI3+/PI3/PI2 libcamera




- Interface: M12
- Field of view Fov(D) = wide angle
- Focal Length 2.8 mm
- Focal Distance Adjustable
- TV DISTORTION <-17%
- F(N) /Aperture 2.2

Support: support@inno-maker.com Bulk Price: sales@inno-maker.com Wiki: wiki.inno-maker.com Github: https://github.com/INNO-MAKER




Raspberry PI Global Shutter Camera Support Hardware Trigger And Strobe Support PI4/PI3+/PI3/PI2 libcamera

## 2.3 PIN Out Connector J1





## 2.4 STROB Connector J2




ISO FLASH



J2 PIN	Symbol Symbol	
1	STROB+	
2	STROB-	Π

## 2.4.1 Reference Circuit



On-board TLP281 optocoupler isolation, Notice the max collector current is 50mA.

**Output Specifications** 

Sart Charles	100 to 10			Value	E	J
S. No	Parameter	<b>Test Condition</b>	Min	Тур	Max	Unit
1	Driver Voltage (VCC)			12	24	V
2	Drive current (Icc)			10	50	mA
3	Collector Emitter Breakdown Voltage				80	٧
4	Collector Emitter Saturation Voltage	Icc = 1 mA		0.1	0.2	٧
5	Power Dissipation				150	mW

1	- K				
Collector-Emitter Saturation Voltage	$V_{\text{CE(sat)}}$	$I_F = 10mA, I_C = 1mA$	0.1	0.2	V

So If the current required to drive the Flash LED is no more than 50mA

The value of series resistor: R1 = ( VCC- Vf - VCE ) / If

VCC: system Voltage


Vf: Forward voltage of Flash LED for current Icc


VCE: Collection Emitter voltage, typical:0.1V

If the current required to drive the flash exceeds 50mA, then it is required to drive it with the help of LED driver circuit, and LED driver circuit can be controlled by using the strobe output pin.

Support: support@inno-maker.com Wiki: wiki.inno-maker.com Bulk Price: sales@inno-maker.com Github: https://github.com/INNO-MAKER

## 2.5 EXT TRIG Connector J3






J3 PIN	PIN Symbol Description	
1	TRIG+	3. 3V-5. OV External Trigger Input
2	TRIG-	External GND

## 2.5.1 Reference Circuit

Support: support@inno-maker.com Bulk Price: sales@inno-maker.com





For example, VCC = 12V, Vf = 1.25V

The calculations done here are based on 12VDC. Please do follow these calculations for other voltages like 24VDC.

Let's take the current through IR LED  $I_f$  = 20mA. Voltage drop across the IR LED = 1.25V

The value of Resistor R<sub>1</sub> =  $(V_{cc}-V_f)/I_f = (12 - 1.25)/0.02 = 537.5 \Omega$ 

Wattage of resistor  $R_1 > I_1^2 \times R_1 = 0.02^2 \times 537.5 = 0.215W$ 

Wattage of the resistor R<sub>1</sub> selected should be greater than 0.215W.

And there is a resistor on board(R4 =  $200\Omega$ ), So the R<sub>add</sub> = R1 - R4 =  $537.5 - 200 = 337.5\Omega$ 

Wiki: wiki.inno-maker.com

Github: https://github.com/INNO-MAKER

# Chapter 3 PI OS Driver Usage

Only Need below setting to enable Raspberry Pi Os BuildIn Driver, No need to follow Chapter 3

## 3.1 Simple Setup of config.txt

Update system to latest version

\$sudo apt-get update

\$sudo apt-get dist-upgrade

Edit /boot/config.txt

Support: support@inno-maker.com
Bulk Price: sales@inno-maker.com



#### \$sudo nano /boot/config.txt

Add below content to the last line and reboot

dtoverlay=imx296

edit /boot/cmdline.txt

cma=128M

Reboot

\$sudo reboot

Check camera module status after reboot

\$ls /dev/video\*

```
pi@raspberrypi:~ $ ls /dev/video*
/dev/video0 /dev/video11 /dev/video13 /dev/video
/dev/video10 /dev/video12 /dev/video14 /dev/video
pi@raspberrypi:~ $
```

#### 3.2 Libcamera

#### 3.2.1Preview

\$libcamera-vid --width 1456 --height 1088 -t 0

## More about libcamera and libcamera-apps Please Refer:

https://www.raspberrypi.com/documentation/computers/camera\_software.html#libcamera-and-libcamera-apps

Wiki: wiki.inno-maker.com

Github: https://github.com/INNO-MAKER

Support: support@inno-maker.com
Bulk Price: sales@inno-maker.com