Video Standards

Video devices typically support one or more different video standards or variations of standards. Each video input and output may support another set of standards. This set is reported by the std field of struct :c:type:\v412_input\` and struct :c:type:\v412_input\` and struct :c:type:\v412_output\` returned by the :ref:\v1DIOC ENUMINPUT\` and :ref:\v1DIOC ENUMOUTPUT\` ioctls, respectively.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 9); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 9); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 9); backlink

Unknown interpreted text role 'ref'.

 $System \, Message: ERROR/3 \, (\mbox{D:\nonlinear-resources}) a matter \mbox{Documentation} userspace-api\mbox{media} v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 9); backlink$

Unknown interpreted text role 'ref'.

V4L2 defines one bit for each analog video standard currently in use worldwide, and sets aside bits for driver defined standards, e. g. hybrid standards to watch NTSC video tapes on PAL TVs and vice versa. Applications can use the predefined bits to select a particular standard, although presenting the user a menu of supported standards is preferred. To enumerate and query the attributes of the supported standards applications use the ref. VIDIOC ENUMSTD ioctl.

 $System\ Message: ERROR/3\ (\mbox{D:\noboarding-resources}\scample-onboarding-resources\linux-master)\ [Documentation]\ [userspace-api]\ [media]\ [v41]\ standard.rst,\ line\ 17); \ backlink$

Unknown interpreted text role 'ref'.

Many of the defined standards are actually just variations of a few major standards. The hardware may in fact not distinguish between them, or do so internal and switch automatically. Therefore enumerated standards also contain sets of one or more standard bits.

Assume a hypothetic tuner capable of demodulating B/PAL, G/PAL and I/PAL signals. The first enumerated standard is a set of B and G/PAL, switched automatically depending on the selected radio frequency in UHF or VHF band. Enumeration gives a "PAL-B/G" or "PAL-I" choice. Similar a Composite input may collapse standards, enumerating "PAL-B/G/H/I", "NTSC-M" and "SECAM-D/K". [1]

To query and select the standard used by the current video input or output applications call the ref" VIDIOC_G_STD \rightarrow and ref" VIDIOC_S_STD \rightarrow video input or output applications call the ref" VIDIOC_G_STD \rightarrow inctl, respectively. The received standard can be sensed with the <a href">ref" VIDIOC QUERYSTD inctl.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 38); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 38); backlink

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 38); backlink

Unknown interpreted text role 'ref'.

Note

The parameter of all these loctls is a pointer to a ref. v412_std_id <v412-std-id>` type (a standard set), not an index into the standard enumeration. Drivers must implement all video standard loctls when the device has one or more video inputs or outputs.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 46); backlink
Unknown interpreted text role "ref".

Special rules apply to devices such as USB cameras where the notion of video standards makes little sense. More generally for any capture or output device which is:

- incapable of capturing fields or frames at the nominal rate of the video standard, or
- that does not support the video standard formats at all.

Here the driver shall set the std field of struct :c:type:`v412_input` and struct :c:type:`v412_output` to zero and the ref:`VIDIOC_G_STD < VIDIOC_G_STD >`, ref:`VIDIOC_G_STD >`, ref:`VIDIOC_G_STD >`, ref:`VIDIOC_ENUMSTD` ioctls shall return the ENOTTY error code or the EINVAL error code.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 60); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 60); backlink

Unknown interpreted text role "c:type".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 60); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 60); backlink

Unknown interpreted text role 'ref'.

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 60); backlink

Unknown interpreted text role "ref".

System Message: ERROR/3 (D:\onboarding-resources\sample-onboarding-resources\linux-master\Documentation\userspace-api\media\v41\[linux-master] [Documentation] [userspace-api] [media] [v41] standard.rst, line 60); backlink

Unknown interpreted text role 'ref'.

```
System\ Message: ERROR/3\ (\ D:\ onboarding-resources\ sample-onboarding-resources\ linux-master\ Documentation\ userspace-api\ media\ v41\ [linux-master]\ [Documentation]\ [userspace-api]\ [media]\ [v41]\ standard.rst,\ line\ 66);\ backlink
```

Unknown interpreted text role 'ref'.

```
System\ Message: ERROR/3\ (\mbox{D:\noboarding-resources}\scample-onboarding-resources\linux-master)\ [Documentation]\ [userspace-api]\ [media]\ [v41]\ standard.rst,\ line\ 66);\ backlink
```

Unknown interpreted text role "ref".

Example: Information about the current video standard

```
v412 std id std id;
struct v412 standard standard;
if (-1 == ioctl(fd, VIDIOC G STD, &std id)) {
    /* Note when VIDIOC ENUMSTD always returns ENOTTY this
      is no video device or it falls under the USB exception,
       and VIDIOC_G_STD returning ENOTTY is no error. */
    perror ("VIDIOC G STD");
    exit (EXIT FAILURE);
memset(&standard, 0, sizeof(standard));
standard.index = 0;
while (0 == ioctl(fd, VIDIOC_ENUMSTD, &standard)) {
   if (standard.id & std id) {
           printf("Current video standard: %s\\n", standard.name);
           exit(EXIT SUCCESS);
    standard.index++;
/\star EINVAL indicates the end of the enumeration, which cannot be
  empty unless this device falls under the USB exception. */
if (errno == EINVAL || standard.index == 0) {
    perror("VIDIOC ENUMSTD");
    exit(EXIT FAILURE);
```

Example: Listing the video standards supported by the current input

```
struct v412_input input;
struct v412 standard standard;
memset(&input, 0, sizeof(input));
if (-1 == ioctl(fd, VIDIOC G INPUT, &input.index)) {
   perror ("VIDIOC G INPUT");
    exit(EXIT_FAILURE);
if (-1 == ioctl(fd, VIDIOC ENUMINPUT, &input)) {
   perror("VIDIOC ENUM INPUT");
    exit(EXIT FAILURE);
printf("Current input %s supports:\\n", input.name);
memset(&standard, 0, sizeof(standard));
standard.index = 0;
while (0 == ioctl(fd, VIDIOC ENUMSTD, &standard)) {
   if (standard.id & input.std)
       printf("%s\\n", standard.name);
    standard.index++;
```

```
/* EINVAL indicates the end of the enumeration, which cannot be
   empty unless this device falls under the USB exception. */

if (errno != EINVAL || standard.index == 0) {
    perror("VIDIOC_ENUMSTD");
    exit(EXIT_FAILURE);
}
```

Example: Selecting a new video standard

```
struct v412 input input;
v412 std id std id;
memset(&input, 0, sizeof(input));
if (-1 == ioctl(fd, VIDIOC_G_INPUT, &input.index)) {
   perror("VIDIOC G INPUT");
    exit(EXIT FAILURE);
if (-1 == ioctl(fd, VIDIOC_ENUMINPUT, &input)) {
   perror("VIDIOC ENUM INPUT");
   exit(EXIT_FAILURE);
if (0 == (input.std & V4L2_STD_PAL_BG)) {
   fprintf(stderr, "Oops. B/G PAL is not supported.\\n");
    exit(EXIT FAILURE);
/* Note this is also supposed to work when only B
   or G/PAL is supported. */
std_id = V4L2_STD_PAL_BG;
if (-1 == ioctl(fd, VIDIOC S STD, &std id)) {
   perror("VIDIOC S STD");
   exit(EXIT FAILURE);
```

[1] Some users are already confused by technical terms PAL, NTSC and SECAM. There is no point asking them to distinguish between B, G, D, or K when the software or hardware can do that automatically.