# **IOB-UART**, a RISC-V UART

Software User Guide, V0.1, Build 40142f6



May 24, 2022



1 File Index	1
1.1 File List	. 1
2 File Documentation	3
2.1 iob-uart.h File Reference	. 3
2.1.1 Detailed Description	. 4
2.1.2 Macro Definition Documentation	. 4
2.1.2.1 ACK	. 4
2.1.2.2 ENQ	. 4
2.1.2.3 EOT	. 4
2.1.2.4 ETX	. 5
2.1.2.5 FRX	. 5
2.1.2.6 FTX	. 5
2.1.2.7 STX	. 5
2.1.2.8 UART_PROGNAME	. 5
2.1.3 Function Documentation	. 5
2.1.3.1 uart_finish()	. 5
2.1.3.2 uart_getc()	. 6
2.1.3.3 uart_init()	
2.1.3.4 uart_putc()	
2.1.3.5 uart puts()	
2.1.3.6 uart recyfile()	
2.1.3.7 uart_rxwait()	
2.1.3.8 uart_sendfile()	
2.1.3.9 uart_txwait()	
=:::=:= =::: -::: -::: -::: -::: -::: -	



## File Index

## 1.1 File List

Here	is a	list of	all	documented	files with	brief	descriptions:
11010	is a	iiot Oi	an	accumented	IIICS WILLI	וטווטו	acscriptions.

iob-uart.h											
IOb-Uart software drivers	 	 	 	 	 						3





## Chapter 2

## **File Documentation**

## 2.1 iob-uart.h File Reference

IOb-Uart software drivers.

```
#include <stdlib.h>
#include <stdarg.h>
#include <stdint.h>
#include "iob_uart_swreg.h"
```

## **Macros**

- #define UART\_PROGNAME "IOb-UART"
- #define STX 2
- #define ETX 3
- #define EOT 4
- #define ENQ 5
- #define ACK 6
- #define FTX 7
- #define FRX 8

## **Functions**

```
    void uart_init (int base_address, uint16_t div)
        Initialize UART.
    void uart_finish ()
        Close transmission.
    void uart_txwait ()
        Wait for TX.
```



• void uart\_putc (char c)

Print char.

void uart\_puts (const char \*s)

Print string.

• void uart\_sendfile (char \*file\_name, int file\_size, char \*mem)

Send file.

void uart\_rxwait ()

Wait for RX Data.

• char uart\_getc ()

Get char.

• int uart\_recvfile (char \*file\_name, char \*\*mem)

Receive file.

## 2.1.1 Detailed Description

IOb-Uart software drivers.

Public driver functions for the IOb-Uart peripheral.

### 2.1.2 Macro Definition Documentation

#### 2.1.2.1 ACK

#define ACK 6

Acknowledge. Signal reception of incomming message.

#### 2.1.2.2 ENQ

#define ENQ 5

Enquiry. Signal start of UART connection.

#### 2.1.2.3 EOT

#define EOT 4

End of transmission. Signal end of UART connection.



### 2.1.2.4 ETX

#define ETX 3

End text. Signal end of data sequence to be printed.

## 2.1.2.5 FRX

#define FRX 8

File reception. Signal file reception request.

#### 2.1.2.6 FTX

#define FTX 7

File transfer. Signal file transfer request.

#### 2.1.2.7 STX

#define STX 2

Start text. Signal start of data sequence to be printed.

## 2.1.2.8 UART\_PROGNAME

```
#define UART_PROGNAME "IOb-UART"
```

Prefix to IOb-Uart specific prints.

### 2.1.3 Function Documentation

## 2.1.3.1 uart\_finish()

```
void uart_finish ( )
```

Close transmission.

Send end of transmission (EOT) command via UART. Active wait until TX transfer is complete. Use this function to close console program.

Returns

void.



#### 2.1.3.2 uart\_getc()

```
char uart_getc ( )
```

Get char.

Active wait and receive char/byte from UART.

### Returns

received byte from UART.

## 2.1.3.3 uart\_init()

Initialize UART.

Reset UART, set IOb-Uart base address and set the division factor. The division factor is the number of clock cycles per simbol transfered.

For example, for a case with fclk = 100 Mhz for a baudrate of 115200 we should have  $div = (100*10^6/115200)$  = (868).

#### **Parameters**

base_address	IOb-Uart instance base address in the system.					
div	Equal to round (fclk/baudrate).					

#### Returns

void.

## 2.1.3.4 uart\_putc()

```
void uart_putc ( {\tt char} \ c \ )
```

Print char.

Send character via UART to be printed by in console program.



#### **Parameters**

Character to print.

#### Returns

void.

## 2.1.3.5 uart\_puts()

```
void uart_puts (
           const char *s)
```

Print string.

Send string via UART to be printed by in console program.

#### **Parameters**

Pointer to char array to be printed.

#### Returns

void.

## 2.1.3.6 uart\_recvfile()

```
int uart_recvfile (
           char * file_name,
            char ** mem )
```

Receive file.

Request variable size file via UART. Order of commands:

- 1. Send file receive (FRX) command.
- 2. Send file\_name.
- 3. Receive file\_size (in little endian format).
- 4. Send ACK command.
- 5. Receive file.

If memory pointer is not inicialized, allocates memory for incomming file.



#### **Parameters**

file_name	Pointer to file name string.
mem	Pointer in memory to store incomming file.

#### **Returns**

Size of received file.

## 2.1.3.7 uart\_rxwait()

```
void uart_rxwait ( )
```

Wait for RX Data.

Active wait for RX incomming data.

### Returns

void.

## 2.1.3.8 uart\_sendfile()

Send file.

Send variable size file via UART. Order of commands:

- 1. Send file transmit (FTX) comnand.
- 2. Send file\_name.
- 3. Send file\_size (in little endian format).
- 4. Send file.



### **Parameters**

file_name	Pointer to file name string					
file_size	Size of file to be sent.					
mem	Pointer to file.					

## Returns

void.

## 2.1.3.9 uart\_txwait()

```
void uart_txwait ( )
```

Wait for TX.

Active wait until TX is ready to process new byte to send.

## Returns

void.