

HeliOS

Kernel 0.3.5

HeliOS Developer's Guide

1 Data Structure Index 1

1 Data Structure Index	1
1.1 Data Structures	1
2 File Index	2
2.1 File List	2
3 Data Structure Documentation	2
3.1 MemoryRegionStats_s Struct Reference	2
3.1.1 Detailed Description	3
3.1.2 Field Documentation	3
3.2 QueueMessage_s Struct Reference	4
3.2.1 Detailed Description	4
3.2.2 Field Documentation	4
3.3 SystemInfo_s Struct Reference	5
3.3.1 Detailed Description	5
3.3.2 Field Documentation	5
3.4 TaskInfo_s Struct Reference	6
3.4.1 Detailed Description	6
3.4.2 Field Documentation	7
3.5 TaskNotification_s Struct Reference	7
3.5.1 Detailed Description	8
3.5.2 Field Documentation	8
3.6 TaskRunTimeStats_s Struct Reference	8
3.6.1 Detailed Description	9
3.6.2 Field Documentation	9
4 File Documentation	10
4.1 config.h File Reference	10
4.1.1 Detailed Description	10
4.1.2 Macro Definition Documentation	11
4.2 HeliOS.h File Reference	13
4.2.1 Detailed Description	19
4.2.2 Typedef Documentation	19
4.2.3 Enumeration Type Documentation	31
4.2.4 Function Documentation	32
Index	63

## 1 Data Structure Index

## 1.1 Data Structures

Here are the data structures with brief descriptions:

MemoryRegionStats_s	
Data structure for memory region statistics	2
QueueMessage_s	
Data structure for a queue message	4
SystemInfo_s	
Data structure for information about the HeliOS system	5
TaskInfo_s	
Data structure for information about a task	6
TaskNotification_s	
Data structure for a direct to task notification	7
TaskRunTimeStats_s	
Data structure for task runtime statistics	8

## 2 File Index

## 2.1 File List

Here is a list of all documented files with brief descriptions:

config.h
Kernel header file for user definable settings

10

HeliOS.h
Header file for end-user application code

13

## 3 Data Structure Documentation

## 3.1 MemoryRegionStats\_s Struct Reference

Data structure for memory region statistics.

## **Data Fields**

- Word\_t largestFreeEntryInBytes
- Word\_t smallestFreeEntryInBytes
- Word\_t numberOfFreeBlocks
- Word\_t availableSpaceInBytes
- Word\_t successfulAllocations
- Word\_t successfulFrees
- Word\_t minimumEverFreeBytesRemaining

## 3.1.1 Detailed Description

The MemoryRegionStats\_t data structure is used by xMemGetHeapStats() and xMemGetKernelStats() to obtain statistics about either memory region. The MemoryRegionStats\_t type should be declared as xMemoryRegion← Stats.

#### See also

```
xMemoryRegionStats
xMemGetHeapStats()
xMemGetKernelStats()
```

#### Attention

The memory allocated for the data structure must be freed by calling xMemFree().

#### See also

xMemFree()

## 3.1.2 Field Documentation

## **3.1.2.1 availableSpaceInBytes** Word\_t MemoryRegionStats\_s::availableSpaceInBytes

The amount of free memory in bytes (i.e., numberOfFreeBlocks \* CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE).

## **3.1.2.2 largestFreeEntryInBytes** Word\_t MemoryRegionStats\_s::largestFreeEntryInBytes

The largest free entry in bytes.

# **3.1.2.3 minimumEverFreeBytesRemaining** Word\_t MemoryRegionStats\_s::minimumEverFreeBytes↔ Remaining

Lowest water lever since system initialization of free bytes of memory.

## **3.1.2.4 numberOfFreeBlocks** Word\_t MemoryRegionStats\_s::numberOfFreeBlocks

The number of free blocks - see CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE for block size in bytes.

## **3.1.2.5 smallestFreeEntryInBytes** Word\_t MemoryRegionStats\_s::smallestFreeEntryInBytes

The smallest free entry in bytes.

## 3.1.2.6 successfulAllocations Word\_t MemoryRegionStats\_s::successfulAllocations

Number of successful memory allocations.

## 3.1.2.7 successfulFrees Word\_t MemoryRegionStats\_s::successfulFrees

Number of successful memory "frees".

The documentation for this struct was generated from the following file:

· HeliOS.h

## 3.2 QueueMessage\_s Struct Reference

Data structure for a queue message.

#### **Data Fields**

- · Base\_t messageBytes
- Char\_t messageValue [CONFIG\_MESSAGE\_VALUE\_BYTES]

## 3.2.1 Detailed Description

The QueueMessage\_t stucture is used to store a queue message and is returned by xQueueReceive() and xQueuePeek(). The QueueMessage\_t stucture should be declared as xQueueMessage.

## See also

```
xQueueMessage
xQueueReceive()
xQueuePeek()
CONFIG_MESSAGE_VALUE_BYTES
xMemFree()
```

## Attention

The memory allocated for the data structure must be freed by calling xMemFree().

The message value is *NOT* null terminated and thus Standard C Library string functions such as strcmp(), strcpy() and strlen(), which expect a null terminated char array, must not be used to manipulate the message value.

## 3.2.2 Field Documentation

#### **3.2.2.1 messageBytes** Base\_t QueueMessage\_s::messageBytes

The number of bytes contained in the message value which cannot exceed CONFIG\_MESSAGE\_VALUE\_BYTES.

## **3.2.2.2** messageValue Char\_t QueueMessage\_s::messageValue[CONFIG\_MESSAGE\_VALUE\_BYTES]

The ASCII queue message value - this is NOT a null terminated character array.

The documentation for this struct was generated from the following file:

• HeliOS.h

## 3.3 SystemInfo\_s Struct Reference

Data structure for information about the HeliOS system.

## **Data Fields**

- Char\_t productName [OS\_PRODUCT\_NAME\_SIZE]
- · Base t majorVersion
- · Base\_t minorVersion
- · Base t patchVersion
- Base\_t numberOfTasks

## 3.3.1 Detailed Description

The SystemInfo\_t data structure is used to store information about the HeliOS system and is returned by xSystemGetSystemInfo(). The SystemInfo\_t structure should be declared as xSystemInfo.

#### See also

```
xSystemInfo
xSystemGetSystemInfo()
OS_PRODUCT_NAME_SIZE
xMemFree()
```

## Attention

The memory allocated for the data structure must be freed by calling xMemFree().

The product name is *NOT* null terminated and thus Standard C Library string functions such as strcmp(), strcpy() and strlen(), which expect a null terminated char array, must not be used to manipulate the product name.

## 3.3.2 Field Documentation

```
3.3.2.1 majorVersion Base_t SystemInfo_s::majorVersion
```

The SemVer major version number of HeliOS.

```
3.3.2.2 minorVersion Base_t SystemInfo_s::minorVersion
```

The SemVer minor version number of HeliOS.

```
3.3.2.3 numberOfTasks Base_t SystemInfo_s::numberOfTasks
```

The number of tasks regardless of their state.

```
3.3.2.4 patchVersion Base_t SystemInfo_s::patchVersion
```

The SemVer patch version number of HeliOS.

```
3.3.2.5 productName Char_t SystemInfo_s::productName[OS_PRODUCT_NAME_SIZE]
```

The ASCII product name of the operating system (always "HeliOS").

The documentation for this struct was generated from the following file:

· HeliOS.h

## 3.4 TaskInfo\_s Struct Reference

Data structure for information about a task.

## **Data Fields**

- · Base tid
- Char\_t name [CONFIG\_TASK\_NAME\_BYTES]
- · TaskState t state
- Ticks\_t lastRunTime
- Ticks\_t totalRunTime

## 3.4.1 Detailed Description

The TaskInfo\_t structure is similar to xTaskRuntimeStats\_t in that it contains runtime statistics for a task. However, TaskInfo\_t also contains additional details about a task such as its ASCII name and state. The TaskInfo\_t structure is returned by xTaskGetTaskInfo() and xTaskGetAllTaskInfo(). If only runtime statistics are needed, then Task RunTimeStats\_t should be used because of its smaller memory footprint. The TaskInfo\_t should be declared as xTaskInfo

## See also

```
xTaskInfo
xTaskGetTaskInfo()
xTaskGetAllTaskInfo()
CONFIG_TASK_NAME_BYTES
xMemFree()
```

## Attention

The memory allocated for the data structure must be freed by calling xMemFree().

The task name is *NOT* null terminated and thus Standard C Library string functions such as strcmp(), strcpy() and strlen(), which expect a null terminated char array, must not be used to manipulate the task name.

#### 3.4.2 Field Documentation

## 3.4.2.1 id Base\_t TaskInfo\_s::id

The task identifier which is used by xTaskGetHandleById() to return the task handle.

## **3.4.2.2 lastRunTime** Ticks\_t TaskInfo\_s::lastRunTime

The duration in ticks of the task's last runtime.

```
3.4.2.3 name Char_t TaskInfo_s::name[CONFIG_TASK_NAME_BYTES]
```

The ASCII name of the task which is used by xTaskGetHandleByName() to return the task handle - this is NOT a null terminated char array.

```
3.4.2.4 state TaskState_t TaskInfo_s::state
```

The state the task is in which is one of four states specified in the TaskState t enumerated data type.

## 3.4.2.5 totalRunTime Ticks\_t TaskInfo\_s::totalRunTime

The duration in ticks of the task's total runtime.

The documentation for this struct was generated from the following file:

· HeliOS.h

## 3.5 TaskNotification\_s Struct Reference

Data structure for a direct to task notification.

## **Data Fields**

- · Base t notificationBytes
- Char\_t notificationValue [CONFIG\_NOTIFICATION\_VALUE\_BYTES]

## 3.5.1 Detailed Description

The TaskNotification\_t data structure is used by xTaskNotifyGive() and xTaskNotifyTake() to send and receive direct to task notifications. Direct to task notifications are part of the event-driven multitasking model. A direct to task notification may be received by event-driven and co-operative tasks alike. However, the benefit of direct to task notifications may only be realized by tasks scheduled as event-driven. In order to wait for a direct to task notification, the task must be in a "waiting" state which is set by xTaskWait(). The TaskNotification\_t type should be declared as xTaskNotification.

#### See also

xTaskNotification

#### Attention

The memory allocated for the data struture must be freed by calling xMemFree().

#### See also

```
xMemFree()
xTaskNotifyGive()
xTaskNotifyTake()
xTaskWait()
```

## Attention

The notification value is *NOT* null terminated and thus Standard C Library string functions such as strcmp(), strcpy() and strlen(), which expect a null terminated char array, must not be used to manipulate the notification value.

#### 3.5.2 Field Documentation

## **3.5.2.1 notificationBytes** Base\_t TaskNotification\_s::notificationBytes

The length in bytes of the notification value which cannot exceed CONFIG\_NOTIFICATION\_VALUE\_BYTES.

```
3.5.2.2 notificationValue Char_t TaskNotification_s::notificationValue[CONFIG_NOTIFICATION_VALUE_BYTES]
```

The notification value whose length is specified by the notification bytes member.

The documentation for this struct was generated from the following file:

• HeliOS.h

## 3.6 TaskRunTimeStats\_s Struct Reference

Data structure for task runtime statistics.

#### **Data Fields**

- · Base\_t id
- Ticks\_t lastRunTime
- · Ticks t totalRunTime

## 3.6.1 Detailed Description

The TaskRunTimeStats\_t data structure is used by xTaskGetTaskRunTimeStats() and xTaskGetAllRuntimeStats() to obtain runtime statistics about a task. The TaskRunTimeStats\_t type should be declared as xTaskRunTimeStats.

#### See also

```
xTaskRunTimeStats
xTaskGetTaskRunTimeStats()
xTaskGetAllRunTimeStats()
```

#### Attention

The memory allocated for the data struture must be freed by calling xMemFree().

## See also

xMemFree()

## 3.6.2 Field Documentation

```
3.6.2.1 id Base_t TaskRunTimeStats_s::id
```

The ID of the task referenced by the task handle.

```
3.6.2.2 lastRunTime Ticks_t TaskRunTimeStats_s::lastRunTime
```

The duration in ticks of the task's last runtime.

```
3.6.2.3 totalRunTime Ticks_t TaskRunTimeStats_s::totalRunTime
```

The duration in ticks of the task's total runtime.

The documentation for this struct was generated from the following file:

• HeliOS.h

## 4 File Documentation

## 4.1 config.h File Reference

Kernel header file for user definable settings.

#### **Macros**

• #define CONFIG MESSAGE VALUE BYTES 0x8u /\* 8 \*/

Define to enable the Arduino API C++ interface.

#define CONFIG\_NOTIFICATION\_VALUE\_BYTES 0x8u /\* 8 \*/

Define the size in bytes of the direct to task notification value.

• #define CONFIG TASK NAME BYTES 0x8u /\* 8 \*/

Define the size in bytes of the ASCII task name.

#define CONFIG\_MEMORY\_REGION\_SIZE\_IN\_BLOCKS 0x18u /\* 24 \*/

Define the number of memory blocks available in all memory regions.

• #define CONFIG MEMORY REGION BLOCK SIZE 0x20u /\* 32 \*/

Define the memory block size in bytes for all memory regions.

• #define CONFIG\_QUEUE\_MINIMUM\_LIMIT 0x5u /\* 5 \*/

Define the minimum value for a message queue limit.

• #define CONFIG\_STREAM\_BUFFER\_BYTES 0x20u /\* 32 \*/

Define the length of the stream buffer.

• #define CONFIG\_TASK\_WD\_TIMER\_ENABLE

Enable task watchdog timers.

#define CONFIG DEVICE NAME BYTES 0x8u /\* 8 \*/

## 4.1.1 Detailed Description

**Author** 

Manny Peterson ( mannymsp@gmail.com)

Version

0.3.5

Date

2022-01-31

Copyright

HeliOS Embedded Operating System Copyright (C) 2020-2022 Manny Peterson mannymsp@gmail.com

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see https←://www.gnu.org/licenses/.

#### 4.1.2 Macro Definition Documentation

# **4.1.2.1 CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE** #define CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE 0x20u /\* 32 \*/

Setting CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE allows the end-user to define the size of a memory region block in bytes. The memory region block size should be set to achieve the best possible utilization of the available memory. The CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE setting effects both the heap and kernel memory regions. The default value is 32 bytes. The literal must be appended with a "u" to maintain MISRA C:2012 compliance.

#### See also

```
xMemAlloc()
xMemFree()
CONFIG MEMORY REGION SIZE IN BLOCKS
```

# **4.1.2.2 CONFIG\_MEMORY\_REGION\_SIZE\_IN\_BLOCKS** #define CONFIG\_MEMORY\_REGION\_SIZE\_IN\_← BLOCKS 0x18u /\* 24 \*/

The heap memory region is used by tasks. Whereas the kernel memory region is used solely by the kernel for kernel objects. The CONFIG\_MEMORY\_REGION\_SIZE\_IN\_BLOCKS setting allows the end-user to define the size, in blocks, of all memory regions thus effecting both the heap and kernel memory regions. The size of a memory block is defined by the CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE setting. The size of all memory regions needs to be adjusted to fit the memory requirements of the end-user's application. By default the CONFIG\_MEMORY\_\top REGION\_SIZE\_IN\_BLOCKS is defined on a per platform and/or tool-chain basis therefor it is not defined here by default. The literal must be appended with a "u" to maintain MISRA C:2012 compliance.

## 4.1.2.3 CONFIG\_MESSAGE\_VALUE\_BYTES #define CONFIG\_MESSAGE\_VALUE\_BYTES 0x8u /\* 8 \*/

Because HeliOS kernel is written in C, the Arduino API cannot be called directly from the kernel. For example, assertions are unable to be written to the serial bus in applications using the Arduino platform/tool-chain. The CONFIG\_ENABLE\_ARDUINO\_CPP\_INTERFACE builds the included arduino.cpp file to allow the kernel to call the Arduino API through wrapper functions such as **ArduinoAssert**(). The arduino.cpp file can be found in the /extras directory. It must be copied into the /src directory to be built.

#### Note

On some MCU's like the 8-bit AVRs, it is necessary to undefine the DISABLE\_INTERRUPTS() macro because interrupts must be enabled to write to the serial bus.

Define to enable system assertions.

The CONFIG\_ENABLE\_SYSTEM\_ASSERT setting allows the end-user to enable system assertions in HeliOS. Once enabled, the end-user must define CONFIG\_SYSTEM\_ASSERT\_BEHAVIOR for there to be an effect. By default the CONFIG\_ENABLE\_SYSTEM\_ASSERT setting is not defined.

See also

CONFIG\_SYSTEM\_ASSERT\_BEHAVIOR

Define the system assertion behavior.

The CONFIG\_SYSTEM\_ASSERT\_BEHAVIOR setting allows the end-user to specify the behavior (code) of the assertion which is called when CONFIG\_ENABLE\_SYSTEM\_ASSERT is defined. Typically some sort of output is generated over a serial or other interface. By default the CONFIG\_SYSTEM\_ASSERT\_BEHAVIOR is not defined.

Note

In order to use the **ArduinoAssert**() functionality, the CONFIG\_ENABLE\_ARDUINO\_CPP\_INTERFACE setting must be enabled.

See also

```
CONFIG_ENABLE_SYSTEM_ASSERT
CONFIG_ENABLE_ARDUINO_CPP_INTERFACE
```

```
#define CONFIG_SYSTEM_ASSERT_BEHAVIOR(f, 1) __ArduinoAssert__( f , 1 )
```

Define the size in bytes of the message queue message value.

Setting the CONFIG\_MESSAGE\_VALUE\_BYTES allows the end-user to define the size of the message queue message value. The larger the size of the message value, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xQueueMessage

```
4.1.2.4 CONFIG_NOTIFICATION_VALUE_BYTES #define CONFIG_NOTIFICATION_VALUE_BYTES 0x8u /* 8 */
```

Setting the CONFIG\_NOTIFICATION\_VALUE\_BYTES allows the end-user to define the size of the direct to task notification value. The larger the size of the notification value, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xTaskNotification

## 4.1.2.5 CONFIG\_QUEUE\_MINIMUM\_LIMIT #define CONFIG\_QUEUE\_MINIMUM\_LIMIT 0x5u /\* 5 \*/

Setting the CONFIG\_QUEUE\_MINIMUM\_LIMIT allows the end-user to define the MINIMUM length limit a message queue can be created with xQueueCreate(). When a message queue length equals its limit, the message queue will be considered full and return true when xQueueIsQueueFull() is called. A full queue will also not accept messages from xQueueSend(). The default value is 5. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xQueuelsQueueFull()

xQueueSend()

xQueueCreate()

## 4.1.2.6 CONFIG\_STREAM\_BUFFER\_BYTES #define CONFIG\_STREAM\_BUFFER\_BYTES 0x20u /\* 32 \*/

Setting CONFIG\_STREAM\_BUFFER\_BYTES will define the length of stream buffers created by xStreamCreate(). When the length of the stream buffer reaches this value, it is considered full and can no longer be written to by calling xStreamSend(). The default value is 32. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

```
4.1.2.7 CONFIG_TASK_NAME_BYTES #define CONFIG_TASK_NAME_BYTES 0x8u /* 8 */
```

Setting the CONFIG\_TASK\_NAME\_BYTES allows the end-user to define the size of the ASCII task name. The larger the size of the task name, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xTaskInfo

## 4.1.2.8 CONFIG\_TASK\_WD\_TIMER\_ENABLE #define CONFIG\_TASK\_WD\_TIMER\_ENABLE

Defining CONFIG\_TASK\_WD\_TIMER\_ENABLE will enable the task wathdog timer feature. The default is enabled.

## 4.2 HeliOS.h File Reference

Header file for end-user application code.

#### **Data Structures**

struct TaskNotification\_s

Data structure for a direct to task notification.

struct TaskRunTimeStats s

Data structure for task runtime statistics.

• struct MemoryRegionStats\_s

Data structure for memory region statistics.

struct TaskInfo\_s

Data structure for information about a task.

• struct QueueMessage\_s

Data structure for a queue message.

struct SystemInfo\_s

Data structure for information about the HeliOS system.

## **Typedefs**

typedef TaskState\_t xTaskState

Enumerated data type for task states.

typedef SchedulerState\_t xSchedulerState

Enumerated data type for the scheduler state.

typedef VOID\_TYPE TaskParm\_t

Data type for the task paramater.

typedef TaskParm\_t \* xTaskParm

Data type for the task paramater.

• typedef UINT8\_TYPE Base\_t

Data type for the base type.

typedef Base\_t xBase

Data type for the base type.

• typedef UINT8\_TYPE Byte\_t

Data type for an 8-bit wide byte.

typedef Byte\_t xByte

Data type for an 8-bit wide byte.

• typedef VOID\_TYPE Addr\_t

Data type for a pointer to an address.

typedef Addr\_t \* xAddr

Data type for a pointer to an address.

• typedef SIZE\_TYPE Size\_t

Data type for the storage requirements of an object in memory.

• typedef Size t xSize

Data type for the storage requirements of an object in memory.

typedef UINT16\_TYPE HalfWord\_t

Data type for a 16-bit half word.

typedef HalfWord t xHalfWord

Data type for a 16-bit half word.

typedef UINT32\_TYPE Word\_t

Data type for a 32-bit word.

typedef Word t xWord

Data type for a 32-bit word.

typedef UINT32\_TYPE Ticks\_t

Data type for system ticks. typedef Ticks\_t xTicks Data type for system ticks. typedef UCHAR TYPE Char t Data type for a character. typedef Char\_t xChar Data type for a character. typedef VOID TYPE Device t Data type for a device handle. typedef Device\_t \* xDevice Data type for a device handle. typedef VOID\_TYPE Task\_t Data type for a task handle. typedef Task\_t \* xTask Data type for a task handle. typedef VOID TYPE StreamBuffer t Data type for a stream buffer handle. typedef StreamBuffer\_t \* xStreamBuffer Data type for a stream buffer handle. typedef VOID TYPE Queue t Data type for a queue handle. typedef Queue\_t \* xQueue Data type for a queue handle. typedef VOID\_TYPE Timer\_t Data type for a timer handle. typedef Timer\_t \* xTimer Data type for a timer handle. typedef struct TaskNotification\_s TaskNotification\_t Data structure for a direct to task notification. typedef TaskNotification t \* xTaskNotification Data structure for a direct to task notification. typedef struct TaskRunTimeStats s TaskRunTimeStats t Data structure for task runtime statistics. typedef TaskRunTimeStats\_t \* xTaskRunTimeStats Data structure for task runtime statistics. typedef struct MemoryRegionStats\_s MemoryRegionStats\_t Data structure for memory region statistics. typedef MemoryRegionStats\_t \* xMemoryRegionStats Data structure for memory region statistics. typedef struct TaskInfo\_s TaskInfo\_t Data structure for information about a task. typedef TaskInfo t \* xTaskInfo Data structure for information about a task. typedef struct QueueMessage\_s QueueMessage\_t Data structure for a queue message. typedef QueueMessage\_t \* xQueueMessage

(C)Copyright 2022 Manny Peterson

Data structure for a queue message.

• typedef struct SystemInfo\_s SystemInfo\_t

typedef SystemInfo\_t \* xSystemInfo

Data structure for information about the HeliOS system.

Data structure for information about the HeliOS system.

#### **Enumerations**

- enum TaskState\_t { TaskStateError , TaskStateSuspended , TaskStateRunning , TaskStateWaiting }
   Enumerated data type for task states.
- enum SchedulerState\_t { SchedulerStateError , SchedulerStateSuspended , SchedulerStateRunning } Enumerated data type for scheduler state.

#### **Functions**

xBase xDeviceRegisterDevice (xBase(\*device self register )())

System call to register a device driver.

xBase xDeviceIsAvailable (const xHalfWord uid\_)

System call to check if a device is available.

xBase xDeviceSimpleWrite (const xHalfWord uid\_, xWord \*data\_)

System call to write fixed length data to a device.

xBase xDeviceWrite (const xHalfWord uid\_, xSize \*size\_, xAddr data\_)

System call to write variable length data to a device.

• xBase xDeviceSimpleRead (const xHalfWord uid\_, xWord \*data\_)

System call to read fixed length data from a device.

xBase xDeviceRead (const xHalfWord uid\_, xSize \*size\_, xAddr data\_)

System call to read variable length data from a device.

xBase xDeviceInitDevice (const xHalfWord uid\_)

System call to initialize a device driver and its device.

xBase xDeviceConfigDevice (const xHalfWord uid\_, xSize \*size\_, xAddr config\_)

System call to configure a device driver and its device.

xAddr xMemAlloc (const xSize size\_)

System call to allocate memory from the heap.

void xMemFree (const volatile xAddr addr\_)

System call to free memory allocated from the heap.

xSize xMemGetUsed (void)

System call to return the amount of allocated heap memory.

xSize xMemGetSize (const volatile xAddr addr\_)

System call to return the amount of heap memory allcoated for a given address.

xMemoryRegionStats xMemGetHeapStats (void)

System call to obtain statistics on the heap.

xMemoryRegionStats xMemGetKernelStats (void)

System call to obtain statistics on the kernel memory region.

xQueue xQueueCreate (const xBase limit\_)

System call to create a new message queue.

void xQueueDelete (xQueue queue\_)

System call to delete a message queue.

• xBase xQueueGetLength (const xQueue queue )

System call to get the length of the message queue.

xBase xQueuelsQueueEmpty (const xQueue queue )

System call to check if the message queue is empty.

xBase xQueuelsQueueFull (const xQueue queue\_)

System call to check if the message queue is full.

xBase xQueueMessagesWaiting (const xQueue queue )

System call to check if there are message queue messages waiting.

• xBase xQueueSend (xQueue queue\_, const xBase messageBytes\_, const xChar \*messageValue\_)

System call to send a message using a message queue.

xQueueMessage xQueuePeek (const xQueue queue\_)

System call to peek at the next message in a message queue.

void xQueueDropMessage (xQueue queue )

System call to drop the next message in a message queue.

xQueueMessage xQueueReceive (xQueue queue\_)

System call to receive the next message in the message queue.

void xQueueLockQueue (xQueue queue )

System call to LOCK the message queue.

void xQueueUnLockQueue (xQueue queue\_)

System call to UNLOCk the message queue.

xStreamBuffer xStreamCreate (void)

The xStreamCreate() system call will create a new stream buffer.

void xStreamDelete (const xStreamBuffer stream\_)

The xStreamDelete() system call will delete a stream buffer.

xBase xStreamSend (xStreamBuffer stream\_, const xByte byte\_)

The xStreamSend() system call will write one byte to the stream buffer.

xByte \* xStreamReceive (const xStreamBuffer stream\_, xHalfWord \*bytes\_)

The xStreamReceive() system call will return the contents of the stream buffer.

xHalfWord xStreamBytesAvailable (const xStreamBuffer stream\_)

The xStreamBytesAvailable() system call returns the length of the stream buffer.

void xStreamReset (const xStreamBuffer stream )

The xStreamReset() system call will reset a stream buffer.

xBase xStreamIsEmpty (const xStreamBuffer stream\_)

The xStreamlsEmpty() system call returns true if the stream buffer is empty.

xBase xStreamIsFull (const xStreamBuffer steam\_)

The xStreamIsFull() system call returns true if the stream buffer is full.

void xSystemInit (void)

System call to initialize the system.

void xSystemHalt (void)

The xSystemHalt() system call will halt HeliOS.

xSystemInfo xSystemGetSystemInfo (void)

The xSystemGetSystemInfo() system call will return information about the running system.

xTask xTaskCreate (const xChar \*name\_, void(\*callback\_)(xTask task\_, xTaskParm parm\_), xTaskParm taskParameter )

System call to create a new task.

void xTaskDelete (const xTask task\_)

System call to delete a task.

xTask xTaskGetHandleByName (const xChar \*name\_)

System call to get a task's handle by its ASCII name.

xTask xTaskGetHandleByld (const xBase id )

System call to get a task's handle by its task identifier.

xTaskRunTimeStats xTaskGetAllRunTimeStats (xBase \*tasks\_)

System call to return task runtime statistics for all tasks.

xTaskRunTimeStats xTaskGetTaskRunTimeStats (const xTask task )

System call to return task runtime statistics for the specified task.

xBase xTaskGetNumberOfTasks (void)

System call to return the number of tasks regardless of their state.

xTaskInfo xTaskGetTaskInfo (const xTask task )

System call to return the details of a task.

xTaskInfo xTaskGetAllTaskInfo (xBase \*tasks\_)

System call to return the details of all tasks.

xTaskState xTaskGetTaskState (const xTask task\_)

System call to return the state of a task.

xChar \* xTaskGetName (const xTask task )

System call to return the ASCII name of a task.

xBase xTaskGetId (const xTask task )

System call to return the task identifier for a task.

void xTaskNotifyStateClear (xTask task )

System call to clear a waiting direct to task notification.

xBase xTaskNotificationIsWaiting (const xTask task\_)

System call to check if a direct to task notification is waiting.

xBase xTaskNotifyGive (xTask task\_, const xBase notificationBytes\_, const xChar \*notificationValue\_)

System call to give another task a direct to task notification.

xTaskNotification xTaskNotifyTake (xTask task\_)

System call to take a direct to task notification from another task.

void xTaskResume (xTask task )

System call to resume a task.

void xTaskSuspend (xTask task\_)

System call to suspend a task.

void xTaskWait (xTask task )

System call to place a task in a waiting state.

void xTaskChangePeriod (xTask task\_, const xTicks timerPeriod\_)

System call to set the task timer period.

xTicks xTaskGetPeriod (const xTask task\_)

System call to get the task timer period.

void xTaskResetTimer (xTask task\_)

System call to reset the task timer.

void xTaskStartScheduler (void)

System call to pass control to the HeliOS scheduler.

void xTaskResumeAll (void)

System call to set scheduler state to running.

void xTaskSuspendAll (void)

System call to set the scheduler state to suspended.

xSchedulerState xTaskGetSchedulerState (void)

System call to get the state of the scheduler.

void xTaskChangeWDPeriod (xTask task\_, const xTicks wdTimerPeriod\_)

The xTaskChangeWDPeriod() will change the period on the task watchdog timer.

xTicks xTaskGetWDPeriod (const xTask task\_)

The xTaskGetWDPeriod() return the current task watchdog timer.

xTimer xTimerCreate (const xTicks timerPeriod )

System call to create a new timer.

void xTimerDelete (const xTimer timer )

System call will delete a timer.

void xTimerChangePeriod (xTimer timer\_, const xTicks timerPeriod\_)

System call to change the period of a timer.

xTicks xTimerGetPeriod (const xTimer timer\_)

System call to get the period of a timer.

xBase xTimerIsTimerActive (const xTimer timer\_)

System call to check if a timer is active.

xBase xTimerHasTimerExpired (const xTimer timer\_)

System call to check if a timer has expired.

```
    void xTimerReset (xTimer timer_)
```

System call to reset a timer.

void xTimerStart (xTimer timer\_)

System call to start a timer.

void xTimerStop (xTimer timer\_)

The xTimerStop() system call will place the timer in the stopped state. Neither xTimerStart() nor xTimerStop() will reset the timer. Timers can only be reset with xTimerReset().

void <u>SystemAssert</u> (const char \*file , int line )

## 4.2.1 Detailed Description

**Author** 

Manny Peterson ( mannymsp@gmail.com)

Version

0.3.5

Date

2022-09-06

Copyright

HeliOS Embedded Operating System Copyright (C) 2020-2022 Manny Peterson mannymsp@gmail.com

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <a href="https://www.gnu.org/licenses/">https://www.gnu.org/licenses/</a>.

## 4.2.2 Typedef Documentation

## 4.2.2.1 Addr\_t typedef VOID\_TYPE Addr\_t

The Addr\_t type is a pointer of type void and is used to pass addresses between the end-user application and system calls. It is not necessary to use the Addr\_t ype within the end-user application as long as the type is not used to interact with the kernel through system calls. Addr\_t should be declared as xAddr.

See also

xAddr

```
4.2.2.2 Base_t typedef UINT8_TYPE Base_t
```

The Base\_t type is a simple data type often used as an argument or return type for system calls when the value is known not to exceed its 8-bit width and no data structure requirements exist. There are no guarantees the Base\_t will always be 8-bits wide. If an 8-bit data type is needed that is guaranteed to remain 8-bits wide, the Byte\_t data type should be used. Base\_t should be declared as xBase.

See also

xBase

Byte\_t

## 4.2.2.3 Byte\_t typedef UINT8\_TYPE Byte\_t

The Byte\_t type is an 8-bit wide data type and is guaranteed to always be 8-bits wide. Byte\_t should be declared as xByte.

See also

xByte

## 4.2.2.4 Char\_t typedef UCHAR\_TYPE Char\_t

The Char\_t data type is used to store an 8-bit char and is typically used for char arrays for ASCII names (e.g., task name). Char\_t should be declared as xChar.

See also

xChar

## $\textbf{4.2.2.5} \quad \textbf{Device\_t} \quad \texttt{typedef VOID\_TYPE Device\_t}$

The Device\_t data type is used as a device handle. The device handle is created when xDeviceRegisterDevice() is called. For more information about devices and device drivers, see xDeviceRegisterDevice() for more information. Device\_t should be declared as xDevice.

See also

**xDevice** 

xDeviceRegisterDevice()

```
4.2.2.6 HalfWord_t typedef UINT16_TYPE HalfWord_t
```

The HalfWord\_t type is a 16-bit wide data type and is guaranteed to always be 16-bits wide. HalfWord\_t should be declared as xHalfWord.

See also

xHalfWord

## **4.2.2.7 MemoryRegionStats\_t** typedef struct MemoryRegionStats\_s MemoryRegionStats\_t

The MemoryRegionStats\_t data structure is used by xMemGetHeapStats() and xMemGetKernelStats() to obtain statistics about either memory region. The MemoryRegionStats\_t type should be declared as xMemoryRegion← Stats.

## See also

```
xMemoryRegionStats
xMemGetHeapStats()
xMemGetKernelStats()
```

#### Attention

The memory allocated for the data structure must be freed by calling xMemFree().

#### See also

xMemFree()

## 4.2.2.8 Queue\_t typedef VOID\_TYPE Queue\_t

The Queue\_t data type is used as a queue handle. The queue handle is created when xQueueCreate() is called. For more information about queues, see xQueueCreate(). Queue\_t should be declared as xQueue.

See also

```
xQueue
xQueueCreate()
```

## Attention

The memory referenced by the queue handle must be freed by calling xQueueDelete().

#### See also

xQueueDelete()

## 4.2.2.9 QueueMessage\_t typedef struct QueueMessage\_s QueueMessage\_t

The QueueMessage\_t stucture is used to store a queue message and is returned by xQueueReceive() and xQueuePeek(). The QueueMessage\_t stucture should be declared as xQueueMessage.

## See also

```
xQueueMessage
xQueueReceive()
xQueuePeek()
CONFIG_MESSAGE_VALUE_BYTES
xMemFree()
```

## Attention

The memory allocated for the data structure must be freed by calling xMemFree().

The message value is *NOT* null terminated and thus Standard C Library string functions such as strcmp(), strcpy() and strlen(), which expect a null terminated char array, must not be used to manipulate the message value.

## 4.2.2.10 Size\_t typedef SIZE\_TYPE Size\_t

The Size\_t type is used for the storage requirements of an object in memory and is always represented in bytes. Size\_t should be declared as xSize.

See also

xSize

## 4.2.2.11 StreamBuffer\_t typedef VOID\_TYPE StreamBuffer\_t

The StreamBuffer\_t data type is used as a stream buffer handle. The stream buffer handle is created when xStreamCreate() is called. For more information about stream buffers, see xStreamCreate(). Stream\_t should be declared as xStream.

## See also

xStreamCreate()

## Attention

The memory referenced by the stream buffer handle must be freed by calling xStreamDelete().

#### See also

xStreamDelete()

#### 4.2.2.12 SystemInfo\_t typedef struct SystemInfo\_s SystemInfo\_t

The SystemInfo\_t data structure is used to store information about the HeliOS system and is returned by xSystemGetSystemInfo(). The SystemInfo\_t structure should be declared as xSystemInfo.

#### See also

```
xSystemInfo
xSystemGetSystemInfo()
OS_PRODUCT_NAME_SIZE
xMemFree()
```

#### Attention

The memory allocated for the data structure must be freed by calling xMemFree().

The product name is *NOT* null terminated and thus Standard C Library string functions such as strcmp(), strcpy() and strlen(), which expect a null terminated char array, must not be used to manipulate the product name.

## 4.2.2.13 Task\_t typedef VOID\_TYPE Task\_t

The Task\_t data type is used as a task handle. The task handle is created when xTaskCreate() is called. For more information about tasks, see xTaskCreate(). Task\_t should be declared as xTask.

## See also

xTask xTaskCreate()

## Attention

The memory referenced by the task handle must be freed by calling xTaskDelete().

#### See also

xTaskDelete()

#### 4.2.2.14 TaskInfo\_t typedef struct TaskInfo\_s TaskInfo\_t

The TaskInfo\_t structure is similar to xTaskRuntimeStats\_t in that it contains runtime statistics for a task. However, TaskInfo\_t also contains additional details about a task such as its ASCII name and state. The TaskInfo\_t structure is returned by xTaskGetTaskInfo() and xTaskGetAllTaskInfo(). If only runtime statistics are needed, then Task RunTimeStats\_t should be used because of its smaller memory footprint. The TaskInfo\_t should be declared as xTaskInfo

#### See also

```
xTaskInfo
xTaskGetTaskInfo()
xTaskGetAllTaskInfo()
CONFIG_TASK_NAME_BYTES
xMemFree()
```

#### Attention

The memory allocated for the data structure must be freed by calling xMemFree().

The task name is *NOT* null terminated and thus Standard C Library string functions such as strcmp(), strcpy() and strlen(), which expect a null terminated char array, must not be used to manipulate the task name.

## $\textbf{4.2.2.15} \quad \textbf{TaskNotification\_t} \quad \texttt{typedef struct TaskNotification\_s TaskNotification\_t}$

The TaskNotification\_t data structure is used by xTaskNotifyGive() and xTaskNotifyTake() to send and receive direct to task notifications. Direct to task notifications are part of the event-driven multitasking model. A direct to task notification may be received by event-driven and co-operative tasks alike. However, the benefit of direct to task notifications may only be realized by tasks scheduled as event-driven. In order to wait for a direct to task notification, the task must be in a "waiting" state which is set by xTaskWait(). The TaskNotification\_t type should be declared as xTaskNotification.

#### See also

xTaskNotification

#### Attention

The memory allocated for the data struture must be freed by calling xMemFree().

## See also

```
xMemFree()
xTaskNotifyGive()
xTaskNotifyTake()
xTaskWait()
```

#### Attention

The notification value is *NOT* null terminated and thus Standard C Library string functions such as strcmp(), strcpy() and strlen(), which expect a null terminated char array, must not be used to manipulate the notification value.

## 4.2.2.16 TaskParm\_t typedef VOID\_TYPE TaskParm\_t

The TaskParm\_t type is used to pass a paramater to a task at the time of task creation using xTaskCreate(). A task paramater is a pointer of type void and can point to any number of types, arrays and/or data structures that will be passed to the task. It is up to the end-user to manage, allocate and free the memory related to these objects using xMemAlloc() and xMemFree(). TaskParm\_t should be declared as xTaskParm.

#### See also

```
xTaskParm
xTaskCreate()
xMemAlloc()
xMemFree()
```

## $\textbf{4.2.2.17} \quad \textbf{TaskRunTimeStats\_t} \quad \texttt{typedef struct TaskRunTimeStats\_s TaskRunTimeStats\_t}$

The TaskRunTimeStats\_t data structure is used by xTaskGetTaskRunTimeStats() and xTaskGetAllRuntimeStats() to obtain runtime statistics about a task. The TaskRunTimeStats\_t type should be declared as xTaskRunTimeStats.

#### See also

```
xTaskRunTimeStats
xTaskGetTaskRunTimeStats()
xTaskGetAllRunTimeStats()
```

## Attention

The memory allocated for the data struture must be freed by calling xMemFree().

#### See also

xMemFree()

## 4.2.2.18 Ticks\_t typedef UINT32\_TYPE Ticks\_t

The Ticks\_t type is used to store ticks from the system clock. Ticks is not bound to any one unit of measure for time though most systems are configured for millisecond resolution, milliseconds is not guaranteed and is dependent on the system clock frequency and prescaler. Ticks\_t should be declared as xTicks.

## See also

**xTicks** 

```
4.2.2.19 Timer_t typedef VOID_TYPE Timer_t
```

The Timer\_t data type is used as a timer handle. The timer handle is created when xTimerCreate() is called. For more information about timers, see xTimerCreate(). Timer\_t should be declared as xTimer.

```
See also
```

```
xTimer
xTimerCreate()
```

## Attention

The memory referenced by the timer handle must be freed by calling xTimerDelete().

#### See also

xTimerDelete()

```
4.2.2.20 Word_t typedef UINT32_TYPE Word_t
```

The Word\_t type is a 32-bit wide data type and is guaranteed to always be 32-bits wide. Word\_t should be declared as xWord.

See also

xWord

```
4.2.2.21 xAddr typedef Addr_t* xAddr
```

See also

Addr t

```
4.2.2.22 xBase typedef Base_t xBase
```

See also

Base\_t

```
4.2.2.23 xByte typedef Byte_t xByte
See also
     Byte_t
4.2.2.24 xChar typedef Char_t xChar
See also
     Data t
4.2.2.25 xDevice typedef Device_t* xDevice
See also
     Device_t
4.2.2.26 xHalfWord typedef HalfWord_t xHalfWord
See also
     HalfWord_t
4.2.2.27 xMemoryRegionStats typedef MemoryRegionStats_t* xMemoryRegionStats
See also
     MemoryRegionStats_t
Attention
     The memory allocated for the data struture must be freed by calling xMemFree().
See also
     xMemFree()
```

```
4.2.2.28 xQueue typedef Queue_t* xQueue
See also
     Queue_t
Attention
     The memory referenced by the queue handle must be freed by calling xQueueDelete().
See also
     xQueueDelete()
4.2.2.29 xQueueMessage typedef QueueMessage_t* xQueueMessage
See also
     QueueMessage_t
Attention
     The memory allocated for the data structure must be freed by calling xMemFree().
See also
     xMemFree()
4.2.2.30 xSchedulerState typedef SchedulerState_t xSchedulerState
See also
     SchedulerState_t
4.2.2.31 xSize typedef Size_t xSize
See also
     Size_t
```

```
4.2.2.32 xStreamBuffer typedef StreamBuffer_t* xStreamBuffer
See also
     StreamBuffer_t
Attention
     The memory referenced by the stream buffer handle must be freed by calling xStreamDelete().
See also
     xStreamDelete()
4.2.2.33 xSystemInfo typedef SystemInfo_t* xSystemInfo
See also
     SystemInfo_t
Attention
     The memory allocated for the data structure must be freed by calling xMemFree().
See also
     xMemFree()
4.2.2.34 xTask typedef Task_t* xTask
See also
     Task_t
Attention
     The memory referenced by the task handle must be freed by calling xTaskDelete().
See also
     xTaskDelete()
```

```
4.2.2.35 xTaskInfo typedef TaskInfo_t* xTaskInfo
See also
     TaskInfo_t
Attention
     The memory allocated for the data struture must be freed by calling xMemFree().
See also
     xMemFree()
\textbf{4.2.2.36} \quad \textbf{xTaskNotification} \quad \texttt{typedef TaskNotification\_t* xTaskNotification}
See also
     TaskNotification_t
Attention
     The memory allocated for the data struture must be freed by calling xMemFree().
See also
     xMemFree()
4.2.2.37 xTaskParm typedef TaskParm_t* xTaskParm
See also
     TaskParm_t
4.2.2.38 xTaskRunTimeStats typedef TaskRunTimeStats_t* xTaskRunTimeStats
See also
     TaskRunTimeStats_t
Attention
     The memory allocated for the data struture must be freed by calling xMemFree().
See also
     xMemFree()
```

```
4.2.2.39 xTaskState typedef TaskState_t xTaskState
See also
     TaskState t
4.2.2.40 xTicks typedef Ticks_t xTicks
See also
     Ticks t
4.2.2.41 xTimer typedef Timer_t* xTimer
See also
     Timer t
Attention
     The memory referenced by the timer handle must be freed by calling xTimerDelete().
See also
     xTimerDelete()
4.2.2.42 xWord typedef Word_t xWord
See also
     Word_t
```

## 4.2.3 Enumeration Type Documentation

## $\textbf{4.2.3.1} \quad \textbf{SchedulerState\_t} \quad \texttt{enum SchedulerState\_t}$

The scheduler can be in one of three possible states as defined by the SchedulerState\_t enumerated data type. The state the scheduler is in is changed by calling xTaskSuspendAll() and xTaskResumeAll(). The state the scheduler is in can be obtained by calling xTaskGetSchedulerState(). SchedulerState\_t should be declared (i.e., used) as xSchedulerState.

```
See also
```

```
xSchedulerState
xTaskSuspendAll()
xTaskResumeAll()
xTaskGetSchedulerState()
xTaskStartScheduler()
```

#### Enumerator

SchedulerStateError	Not used - reserved for future use.
SchedulerStateSuspended	State the scheduler is in after calling xTaskSuspendAll() - xTaskStartScheduler() will stop scheduling tasks for execution and relinquish control when xTaskSuspendAll() is called.
SchedulerStateRunning	State the scheduler is in after calling xTaskResumeAll() - xTaskStartScheduler() will continue to schedule tasks for execution until xTaskSuspendAll() is called.

## 4.2.3.2 TaskState\_t enum TaskState\_t

A task can be in one of four possible states as defined by the TaskState\_t enumerated data type. The state a task is in is changed by calling xTaskResume(), xTaskSuspend() or xTaskWait(). The HeliOS scheduler will only schedule, for execution, tasks in either the TaskStateRunning or TaskStateWaiting state. TaskState\_t should be declared (i.e., used) as xTaskState.

#### See also

```
xTaskState
```

xTaskResume()

xTaskSuspend()

xTaskWait()

xTaskGetTaskState()

## **Enumerator**

TaskStateError	Returned by xTaskGetTaskState() when the task cannot be found.
TaskStateSuspended	State a task is in when it is first created OR after calling xTaskSuspend() - tasks in the TaskStateSuspended state will not be scheduled for execution.
TaskStateRunning	State a task is in after calling xTaskResume() - tasks in the TaskStateRunning state will be scheduled co-operatively.
TaskStateWaiting	State a task is in after calling xTaskWait() - tasks in the TaskStateWaiting state will be scheduled as event driven.

## 4.2.4 Function Documentation

The xDeviceConfigDevice() system call will configure the device driver and its device. Like most aspects of the HeliOS device driver model, the implementation of this feature is dependent on the author of the device driver. Some device drivers may not implement this feature of the device driver model at all. A device driver template and pre-packaged drivers can be found in /drivers.

#### **Parameters**

uid_	The unique identifier of the device driver.	
size⊷	The number of bytes (i.e., size) of the device configuration data structure.	
_		
config←	A pointer to the size_ bytes of memory occupied by the configuration data structure - the memory	
_	MUST be located in the heap memory region.	

#### Returns

xBase If configuration of the device driver was successful, RETURN\_SUCCESS is returned. Otherwise RETURN FAILURE is returned.

```
4.2.4.2 xDeviceInitDevice() xBase xDeviceInitDevice ( const xHalfWord uid_ )
```

The xDeviceInitDevice() system call will initialize the device driver and its device. Like most aspects of the HeliOS device driver model, the implementation of this feature is dependent on the author of the device driver. Some device drivers may not implement this feature of the device driver model at all. A device driver template and pre-packaged drivers can be found in /drivers.

#### **Parameters**

uid⊷	The unique identifier of the device driver.
_	

## Returns

xBase If the initialization of the device driver was successful, RETURN\_SUCCESS is returned. Otherwise RETURN\_FAILURE is returned.

```
4.2.4.3 xDevicelsAvailable() xBase xDeviceIsAvailable ( const xHalfWord uid_ )
```

The xDeviceIsAvailable() system call checks to see if a device driver is "available", generally for a read, write or read/write operation. What "available" means is up to the device driver author and may change based on what mode the device driver is in. For example, if the device driver is in read-only mode, then xDeviceIsAvailable() may return "true" if data is ready to be read from the device. A device driver template and pre-packaged device drivers can be found in /drivers.

## **Parameters**

uid←	The unique identifier of the device driver.

#### Returns

xBase If the device driver is "available", then "true" is returned. Otherwise "false" is returned.

The xDeviceRead() system call will read variable length data from a device driver. Whether the data is read is dependent on the device driver mode, state and implementation of these features by the device driver author. A device driver template and pre-packaged drivers can be found in /drivers.

#### **Parameters**

uid←	The unique identifier of the device driver.
_	
size←	The number of bytes read from the device.
_	
data←	A pointer to the data buffer to read the data into from the device - because xDeviceRead() uses
_	variable length data, the pointer must reference size_ bytes of memory and the memory MUST be
	located in the heap memory region.

#### Returns

xBase If the read operation was successful, RETURN\_SUCCESS is returned. Otherwise RETURN\_FAILURE is returned.

```
4.2.4.5 xDeviceRegisterDevice() xBase xDeviceRegisterDevice ( xBase(*)() device_self_register_)
```

The xDeviceRegisterDevice() system call, as part of the HeliOS device driver model, registers a device driver with the HeliOS kernel. This system call must be made before a device driver can be called by xDeviceRead(), xDeviceWrite(), etc. If the device driver is successfully registered with the kernel, xDeviceRegisterDevice() will return RETURN\_SUCCESS. Once a device is registered it cannot be un-registered - it can only be placed in a suspended state which is done by calling xDeviceConfigDevice(). However, as with most aspects of the device driver model in HeliOS, it is important to note that the implementation of the device state and mode is up to the device driver author. A quick word about device driver unique identifiers (uid). A device driver uid MUST be a globally unique identifier. No two device drivers in the same application can share the same uid. This is best achieved by ensuring the device driver author selects a uid for his device driver that is not in use by another device driver. A device driver template and pre-packaged device drivers can be found in /drivers.

## **Parameters**

device_self_←	A pointer to the self registration function for the device driver.
register_	

#### Returns

xBase If the device driver is successfully registered with the kernel, xDeviceRegisterDevice() returns RETURN\_SUCCESS. Otherwise RETURN\_FAILURE is returned..

```
4.2.4.6 xDeviceSimpleRead() xBase xDeviceSimpleRead ( const xHalfWord uid_{-}, xWord * data_{-})
```

The xDeviceSimpleRead() system call will read fixed length (one word) data from a device driver. Whether the data is read is dependent on the device driver mode, state and implementation of these features by the device driver author. A device driver template and pre-packaged device drivers can be found in /drivers.

#### **Parameters**

uid⊷	The unique identifier of the device driver.
_	
data⇔	A pointer to the data buffer to read the data into from the device - because xDeviceSimpleRead() uses
_	fixed length data, the pointer must reference a word of memory and the memory MUST be located in
	the heap memory region.

#### Returns

xBase If the read operation was successful, RETURN\_SUCCESS is returned. Otherwise RETURN\_FAILURE is returned.

```
4.2.4.7 xDeviceSimpleWrite() xBase xDeviceSimpleWrite ( const xHalfWord uid_, xWord * data_ )
```

The xDeviceSimpleWrite() system call will write fixed length (one word) data to a device driver. Whether the data is written is dependent on the device driver mode, state and implementation of these features by the device driver author. A device driver template and pre-packaged device drives can be found in /drivers.

#### **Parameters**

uid⊷	The unique identifier of the device driver
_	
data⇔	A pointer to the data to be written to the device - because xDeviceSimpleWrite() uses fixed length data,
_	the pointer must reference a word of memory and the memory <i>MUST</i> be located in the heap memory region.

## Returns

xBase If the write operation was successful, RETURN\_SUCCESS is returned. Otherwise RETURN\_FAILURE is returned.

The xDeviceWrite() system call will write variable length data to a device driver. Whether the data is written is dependent on the device driver mode, state and implementation of these features by the device driver author. A device driver template and pre-packaged drivers an be found in /drivers.

#### **Parameters**

uid←	The unique identifier of the device driver.
_	
size←	The length (i.e., size) of the data to be written to the device.
_	
data⇔	A pointer to the data to be written to the device - because xDeviceWrite uses variable length data, the
_	pointer must reference size_ bytes of memory and the memory MUST be located in the heap memory
	region.

#### Returns

xBase If the write operation was successful, RETURN\_SUCCESS is returned. Otherwise RETURN\_FAILURE is returned.

```
4.2.4.9 xMemAlloc() xAddr xMemAlloc ( const xSize size_)
```

The xMemAlloc() system call allocates memory from the heap for HeliOS system calls and end-user tasks. The size of the heap, in bytes, is dependent on the CONFIG\_MEMORY\_REGION\_SIZE\_IN\_BLOCKS and CONFIG\_← MEMORY\_REGION\_BLOCK\_SIZE settings. xMemAlloc() functions similarly to calloc() in that it clears the memory it allocates.

#### See also

```
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS
CONFIG_MEMORY_REGION_BLOCK_SIZE
xMemFree()
```

#### **Parameters**

size⊷	The amount (size) of the memory to be allocated from the heap in bytes.
_	

## Returns

xAddr If successful, xMemAlloc() returns the address of the newly allocated memory. If unsuccessful, the system call will return null.

Note

HeliOS technically does not allocate memory from what is traditionally heap memory. HeliOS uses a private "heap" which is actually static memory allocated at compile time. This is done to maintain MISRA C:2012 compliance since standard library functions like malloc(), calloc() and free() are not permitted.

```
4.2.4.10 xMemFree() void xMemFree (

const volatile xAddr addr_)
```

The xMemFree() system call will free heap memory allocated by xMemAlloc() and other HeliOS system calls such as xSystemGetSystemInfo().

See also

xMemAlloc()

## **Parameters**

addr⊷	The address of the allocated heap memory to be freed.
_	

## Warning

xMemFree() cannot be used to free memory allocated for kernel objects. Memory allocated by xTaskCreate(), xTimerCreate() or xQueueCreate() must be freed by their respective delete system calls (e.g., xTaskDelete()).

```
4.2.4.11 xMemGetHeapStats() xMemoryRegionStats xMemGetHeapStats ( void )
```

The xMemGetHeapStats() system call will return statistics about the heap so the end-user can better understand the state of the heap.

See also

xMemoryRegionStats

Returns

xMemoryRegionStats Returns the xMemoryRegionStats structure or null if unsuccessful.

Warning

The memory allocated by xMemGetHeapStats() must be freed by xMemFree().

```
4.2.4.12 xMemGetKernelStats() xMemoryRegionStats xMemGetKernelStats ( void )
```

The xMemGetKernelStats() system call will return statistics about the kernel memory region so the end-user can better understand the state of kernel memory.

See also

xMemoryRegionStats

#### Returns

xMemoryRegionStats Returns the xMemoryRegionStats structure or null if unsuccessful.

## Warning

The memory allocated by xMemGetKernelStats() must be freed by xMemFree().

```
4.2.4.13 xMemGetSize() xSize xMemGetSize ( const volatile xAddr addr_)
```

The xMemGetSize() system call returns the amount of heap memory in bytes that is currently allocated to a specific address. If the address is null or invalid, xMemGetSize() will return zero bytes.

## **Parameters**

 address of the allocated heap memory to obtain the size of the memory, in bytes, that is allocated.

## Returns

xSize The amount of memory currently allocated to the specific address in bytes. If the address is invalid or null, xMemGetSize() will return zero.

## Note

If the address addr\_points to a structure that, for example, is 48 bytes in size base on sizeof(), xMemGetSize() will return the number of bytes allocated by the block(s) that contain the structure. Assuming the default block size of 32, a 48 byte structure would require TWO blocks so xMemGetSize() would return 64 - not 48. xMemGetSize() also checks the health of the heap and will return zero if it detects a consistency issue with the heap. Thus, xMemGetSize() can be used to validate addresses before the objects they reference are accessed.

```
4.2.4.14 xMemGetUsed() xSize xMemGetUsed (void)
```

The xMemGetUsed() system call returns the amount of heap memory, in bytes, that is currently allocated. Calls to xMemAlloc() increases and xMemFree() decreases the amount of memory in use.

xSize The amount of memory currently allocated in bytes. If no heap memory is currently allocated, xMemGetUsed() will return zero.

#### Note

xMemGetUsed() returns the amount of heap memory that is currently allocated to end-user objects AND kernel objects. However, only end-user objects may be freed using xMemFree(). Kernel objects must be freed using their respective delete system call (e.g., xTaskDelete()).

```
4.2.4.15 xQueueCreate() xQueue xQueueCreate ( const xBase limit_ )
```

The xQueueCreate() system call creates a message queue for inter-task communication.

#### See also

xQueue

xQueueDelete()

CONFIG\_QUEUE\_MINIMUM\_LIMIT

#### **Parameters**

limit←	The message limit for the queue. When this number is reach, the queue is considered full and
_	xQueueSend() will fail. The minimum limit for queues is dependent on the setting
	CONFIG_QUEUE_MINIMUM_LIMIT.

## Returns

xQueue A queue is returned if successful, otherwise null is returned if unsuccessful.

#### Warning

The message queue memory can only be freed by xQueueDelete().

```
4.2.4.16 xQueueDelete() void xQueueDelete ( xQueue \ queue )
```

The xQueueDelete() system call will delete a message queue created by xQueueCreate(). xQueueDelete() will delete a queue regardless of how many messages the queue contains at the time xQueueDelete() is called. Any messages the message queue contains will be deleted in the process of deleting the message queue.

## See also

xQueueCreate()

queue⊷	The queue to be deleted.
_	

# **4.2.4.17 xQueueDropMessage()** void xQueueDropMessage ( $xQueue \ queue \_$ )

The xQueueDropMessage() system call will drop the next message from the message queue without returning the message.

#### **Parameters**

```
queue

The queue to drop the next message from.

_
```

# **4.2.4.18 xQueueGetLength() xBase xQueueGetLength** ( const **xQueue queue\_** )

The xQueueGetLength() system call returns the length of the queue (the number of messages the queue currently contains).

## **Parameters**

queue⊷	The queue to return the length of.

#### Returns

xBase The number of messages in the queue. If unsuccessful or if the queue is empty, xQueueGetLength() returns zero.

# **4.2.4.19 xQueuelsQueueEmpty()** xBase xQueueIsQueueEmpty ( const xQueue queue\_ )

The xQueuelsEmpty() system call will return a true or false dependent on whether the queue is empty (message queue length is zero) or contains one or more messages.

queue⊷	The queue to determine whether it is empty.
_	

xBase True if the queue is empty. False if the queue has one or more messages. xQueuelsQueueEmpty() will also return false if the queue parameter is invalid.

```
4.2.4.20 xQueuelsQueueFull() xBase xQueueIsQueueFull ( const xQueue queue_ )
```

The xQueuelsFull() system call will return a true or false dependent on whether the queue is full or contains zero messages. A queue is considered full if the number of messages in the queue is equal to the queue's length limit.

#### **Parameters**

queue⊷	The queue to determine whether it is full.

## Returns

xBase True if the queue is full. False if the queue has zero. xQueuelsQueueFull() will also return false if the queue parameter is invalid.

```
4.2.4.21 xQueueLockQueue() void xQueueLockQueue ( xQueue \ queue\_ )
```

The xQueueLockQueue() system call will lock the message queue. Locking a message queue will prevent xQueueSend() from sending messages to the queue.

## **Parameters**

queue⊷	The queue to lock.
_	

```
4.2.4.22 xQueueMessagesWaiting() xBase xQueueMessagesWaiting ( const xQueue queue_ )
```

The xQueueMessageWaiting() system call returns true or false dependent on whether there is at least one message waiting. The message queue does not have to be full to return true.

queue⊷	The queue to determine whether one or more messages are waiting.

xBase True if one or more messages are waiting. False if there are no messages waiting of the queue parameter is invalid.

```
4.2.4.23 xQueuePeek() xQueueMessage xQueuePeek ( const xQueue queue_ )
```

The xQueuePeek() system call will return the next message in the specified message queue without dropping the message.

## See also

xQueueMessage xMemFree()

## **Parameters**

queue⊷	The queue to return the next message from.

## Returns

xQueueMessage The next message in the queue. If the queue is empty or the queue parameter is invalid, xQueuePeek() will return null.

## Warning

The memory allocated by xQueuePeek() must be freed by xMemFree().

```
4.2.4.24 xQueueReceive() xQueueMessage xQueueReceive ( xQueue queue_ )
```

The xQueueReceive() system call will return the next message in the message queue and drop it from the message queue.

## See also

xQueueMessage xMemFree()

queue⊷	The queue to return the next message from.
_	

xQueueMessage The message returned from the queue. If the queue is empty of the queue parameter is invalid, xQueueReceive() will return null.

## Warning

The memory allocated by xQueueReceive() must be freed by xMemFree().

The xQueueSend() system call will send a message using the specified message queue. The size of the message value is passed in the message bytes parameter. The maximum message value size in bytes is dependent on the CONFIG MESSAGE VALUE BYTES setting.

#### See also

```
CONFIG_MESSAGE_VALUE_BYTES
xQueuePeek()
xQueueReceive()
```

#### **Parameters**

queue_	The queue to send the message to.
message <i>←</i> Bytes_	The number of bytes contained in the message value. The number of bytes must be greater than zero and less than or equal to the setting CONFIG_MESSAGE_VALUE_BYTES.
message⊷ Value_	The message value. If the message value is greater than defined in CONFIG_MESSAGE_VALUE_BYTES, only the number of bytes defined in CONFIG_MESSAGE_VALUE_BYTES will be copied into the message value. The message value is NOT a null terminated string.

#### Returns

xBase xQueueSend() returns RETURN\_SUCCESS if the message was sent to the queue successfully. Otherwise RETURN FAILURE if unsuccessful.

```
4.2.4.26 xQueueUnLockQueue() void xQueueUnLockQueue ( xQueue queue_ )
```

The xQueueUnLockQueue() system call will unlock the message queue. Unlocking a message queue will allow xQueueSend() to send messages to the queue.

queue⊷	The queue to unlock.
_	

# **4.2.4.27 xStreamBytesAvailable()** xHalfWord xStreamBytesAvailable ( const xStreamBuffer stream\_)

The xStreamBytesAvailable() system call will return the length of the stream buffer in bytes (i.e., bytes available to be received by xStreamReceive()).

#### **Parameters**

stream⇔	The stream to operate on.
_	

#### Returns

xHalfWord The length of the stream buffer in bytes.

## **4.2.4.28 xStreamCreate() xStreamBuffer xStreamCreate** ( void )

The xStreamCreate() system call will create a new stream buffer. The memory for a stream buffer is allocated from kernel memory and therefor cannot be freed by calling xMemFree().

## Returns

xStreamBuffer The newly created stream buffer.

## Warning

The stream buffer created by xStreamCreate() must be freed by calling xStreamDelete().

```
4.2.4.29 xStreamDelete() void xStreamDelete ( const xStreamBuffer stream_)
```

The xStreamDelete() system call will delete a stream buffer and free its memory. Once a stream buffer is deleted, it can not be written to or read from.

stream⊷	The stream buffer to operate on.

## **4.2.4.30 xStreamIsEmpty()** xBase xStreamIsEmpty ( const xStreamBuffer stream\_)

The xStreamIsEmpty() system call is used to determine if the stream buffer is empty. A stream buffer is considered empty when it's length is equal to zero. If the buffer is greater than zero in length, xStreamIsEmpty() will return false.

#### **Parameters**

steam←	The stream buffer to operate on.

#### Returns

xBase Returns true if the stream buffer length is equal to zero in length, otherwise xStreamIsEmpty() will return false.

# **4.2.4.31 xStreamIsFull()** xBase xStreamIsFull ( const xStreamBuffer steam\_ )

The xStreamIsFull() system call is used to determine if the stream buffer is full. A stream buffer is considered full when it's length is equal to CONFIG\_STREAM\_BUFFER\_BYTES. If the buffer is less than CONFIG\_STREAM\_ $\leftarrow$  BUFFER\_BYTES in length, xStreamIsFull() will return false.

#### **Parameters**

steam⇔	The stream buffer to operate on.
_	

#### Returns

xBase Returns true if the stream buffer is equal to CONFIG\_STREAM\_BUFFER\_BYTES in length, otherwise xStreamIsFull() will return false.

The xStreamReceive() system call will return the contents of the stream buffer. The contents are returned as a byte array whose length is known by the bytes\_paramater. Because the byte array is stored in the heap, it must be freed by calling xMemFree().

stream⇔	The stream to operate on.
_	
bytes⊷	The number of bytes returned (i.e., length of the byte array) by xStreamReceive().

#### Returns

xByte\* The byte array containing the contents of the stream buffer.

## Warning

The byte array returned by xStreamReceive() must be freed by calling xMemFree().

## 

The xStreamRest() system call will clear the contents of the stream buffer and reset its length to zero.

## **Parameters**

stream⊷	The stream buffer to operate on.
_	

```
4.2.4.34 xStreamSend() xBase xStreamSend ( xStreamBuffer stream_, const xByte byte_)
```

The xStreamSend() system call will write one byte to the stream buffer. If the stream buffer's length is equal to CONFIG\_STREAM\_BUFFER\_BYTES (i.e., full) then the byte will not be written to the stream buffer and xStreamSend() will return RETURN\_FAILURE.

#### **Parameters**

stream⇔	The stream buffer to operate on.
byte_	The byte to be sent to the stream buffer.

## Returns

xBase Returns RETURN\_SUCCESS if the byte was successfully written to the stream buffer. Otherwise, returns RETURN\_FAILURE.

```
4.2.4.35 xSystemGetSystemInfo() xSystemInfo xSystemGetSystemInfo ( void )
```

The xSystemGetSystemInfo() system call will return the type xSystemInfo containing information about the system including the OS (product) name, its version and how many tasks are currently in the running, suspended or waiting states.

## Returns

xSystemInfo The system info is returned if successful, otherwise null is returned if unsuccessful.

#### See also

xSystemInfo xMemFree()

#### Warning

The memory allocated by the xSystemGetSystemInfo() must be freed with xMemFree().

```
4.2.4.36 xSystemHalt() void xSystemHalt ( void )
```

The xSystemHalt() system call will halt HeliOS. Once xSystemHalt() is called, the system must be reset.

```
4.2.4.37 xSystemInit() void xSystemInit ( void )
```

The xSystemInit() system call initializes the required interrupt handlers and memory and must be called prior to calling any other system call.

The xTaskChangePeriod() system call will change the period (ticks) on the task timer for the specified task. The timer period must be greater than zero. To have any effect, the task must be in the waiting state set by calling xTaskWait() on the task. Once the timer period is set and the task is in the waiting state, the task will be executed every timerPeriod\_ ticks. Changing the period to zero will prevent the task from being executed even if it is in the waiting state unless it were to receive a direct to task notification.

## See also

```
xTaskWait()
xTaskGetPeriod()
xTaskResetTimer()
```

task_	The task to change the timer period for.
timer←	The timer period in ticks.
Period_	

```
4.2.4.39 xTaskChangeWDPeriod() void xTaskChangeWDPeriod ( xTask task_, const xTicks wdTimerPeriod_)
```

The xTaskChangeWDPeriod() system call will change the task watchdog timer period. The period, measured in ticks, must be greater than zero to have any effect. If the tasks last runtime exceeds the task watchdog timer period, the task will automatically be placed in a suspended state.

#### See also

xTaskGetWDPeriod()

#### **Parameters**

task_	The task to change the task watchdog timer for.
wdTimer⊷ Period_	The task watchdog timer period which is measured in ticks. If zero, the task watchdog timer will not have any effect.

The xTaskCreate() system call will create a new task. The task will be created with its state set to suspended. The xTaskCreate() and xTaskDelete() system calls cannot be called within a task. They MUST be called outside of the scope of the HeliOS scheduler.

## **Parameters**

name_	The ASCII name of the task which can be used by xTaskGetHandleByName() to obtain the
	task handle. The length of the name is depended on the CONFIG_TASK_NAME_BYTES.
	The task name is NOT a null terminated char string.
callback_	The address of the task main function. This is the function that will be invoked by the
	scheduler when a task is scheduled for execution.
task⊷	A pointer to any type or structure that the end-user wants to pass into the task as a
Parameter_	parameter. The task parameter is not required and may simply be set to null.

#### Returns

xTask A handle to the newly created task.

#### See also

```
xTask
xTaskParm
xTaskDelete()
xTaskState
CONFIG_TASK_NAME_BYTES
```

## Warning

xTaskCreate() MUST be called outside the scope of the HeliOS scheduler (i.e., not from a task's main). The task memory can only be freed by xTaskDelete().

```
4.2.4.41 xTaskDelete() void xTaskDelete ( const xTask task_)
```

The xTaskDelete() system call will delete a task. The xTaskCreate() and xTaskDelete() system calls cannot be called within a task. They MUST be called outside of the scope of the HeliOS scheduler.

## **Parameters**

task⊷	The handle of the task to be deleted.
_	

## Warning

xTaskDelete() MUST be called outside the scope of the HeliOS scheduler (i.e., not from a task's main).

```
4.2.4.42 xTaskGetAllRunTimeStats() xTaskRunTimeStats xTaskGetAllRunTimeStats ( xBase * tasks_ )
```

The xTaskGetAllRunTimeStats() system call will return the runtime statistics for all of the tasks regardless of their state. The xTaskGetAllRunTimeStats() system call returns the xTaskRunTimeStats type. An xBase variable must be passed by reference to xTaskGetAllRunTimeStats() which will be updated by xTaskGetAllRunTimeStats() to contain the number of tasks so the end-user can iterate through the tasks. The xTaskRunTimeStats memory must be freed by xMemFree() after it is no longer needed.

## See also

```
xTaskRunTimeStats
xMemFree()
```

tasks⊷	A variable of type xBase passed by reference which will contain the number of tasks upon return. If no
_	tasks currently exist, this variable will not be modified.

xTaskRunTimeStats The runtime stats returned by xTaskGetAllRunTimeStats(). If there are currently no tasks then this will be null. This memory must be freed by xMemFree().

## Warning

The memory allocated by xTaskGetAllRunTimeStats() must be freed by xMemFree().

```
4.2.4.43 xTaskGetAllTaskInfo() xTaskInfo xTaskGetAllTaskInfo ( xBase * tasks_ )
```

The xTaskGetAllTaskInfo() system call returns the xTaskInfo structure containing the details of ALL tasks including their identifier, name, state and runtime statistics.

#### See also

xTaskInfo

#### **Parameters**

tasks⊷	A variable of type xBase passed by reference which will contain the number of tasks upon return. If no
_	tasks currently exist, this variable will not be modified.

## Returns

xTaskInfo The xTaskInfo structure containing the tasks details. xTaskGetAllTaskInfo() returns null if there no tasks or if a consistency issue is detected.

## Warning

The memory allocated by xTaskGetAllTaskInfo() must be freed by xMemFree().

```
4.2.4.44 xTaskGetHandleById() xTask xTaskGetHandleById ( const xBase id_ )
```

The xTaskGetHandleById() system call will return the task handle of the task specified by identifier identifier.

## See also

xBase

id⊷	The identifier of the task to return the handle of.
_←	

## Returns

xTask The task handle. xTaskGetHandleByld() returns null if the the task identifier cannot be found.

```
4.2.4.45 xTaskGetHandleByName() xTask xTaskGetHandleByName ( const xChar * name_ )
```

The xTaskGetHandleByName() system call will return the task handle of the task specified by its ASCII name. The length of the task name is dependent on the CONFIG\_TASK\_NAME\_BYTES setting. The name is compared byte-for-byte so the name is case sensitive.

## See also

CONFIG\_TASK\_NAME\_BYTES

## **Parameters**

name	The ASCII name of the task to return the handle of. The task name is NOT a null terminated string.	
_		

#### Returns

xTask The task handle. xTaskGetHandleByName() returns null if the name cannot be found.

# **4.2.4.46 xTaskGetId()** xBase xTaskGetId ( const xTask task\_ )

The xTaskGetId() system call returns the task identifier for the task.

## **Parameters**

task⊷	The task to return the identifier of.

## Returns

xBase The identifier of the task. If the task cannot be found, xTaskGetId() returns zero (all tasks identifiers are 1 or greater).

```
4.2.4.47 xTaskGetName() xChar* xTaskGetName ( const xTask task_ )
```

The xTaskGetName() system call returns the ASCII name of the task. The size of the task is dependent on the setting CONFIG\_TASK\_NAME\_BYTES. The task name is NOT a null terminated char string. The memory allocated for the char array must be freed by xMemFree() when no longer needed.

## See also

```
CONFIG_TASK_NAME_BYTES xMemFree()
```

#### **Parameters**

task⊷	The task to return the name of.
_	

#### Returns

xChar\* A pointer to the char array containing the ASCII name of the task. The task name is NOT a null terminated char string. xTaskGetName() will return null if the task cannot be found.

## Warning

The memory allocated by xTaskGetName() must be free by xMemFree().

```
4.2.4.48 xTaskGetNumberOfTasks() xBase xTaskGetNumberOfTasks (
```

The xTaskGetNumberOfTasks() system call returns the current number of tasks regardless of their state.

## Returns

xBase The number of tasks.

```
4.2.4.49 xTaskGetPeriod() xTicks xTaskGetPeriod ( const xTask task_ )
```

The xTaskGetPeriod() will return the period for the timer for the specified task. See xTaskChangePeriod() for more information on how the task timer works.

## See also

```
xTaskWait()
xTaskChangePeriod()
xTaskResetTimer()
```

task⊷	The task to return the timer period for.
_	

#### Returns

xTicks The timer period in ticks. xTaskGetPeriod() will return zero if the timer period is zero or if the task could not be found.

```
      \textbf{4.2.4.50} \quad \textbf{xTaskGetSchedulerState()} \quad \textbf{xSchedulerState} \quad \textbf{xTaskGetSchedulerState()}
```

The xTaskGetSchedulerState() system call will return the state of the scheduler. The state of the scheduler can only be changed using xTaskSuspendAll() and xTaskResumeAll().

## See also

```
xSchedulerState
xTaskSuspendAll()
xTaskResumeAll()
```

#### Returns

xSchedulerState The state of the scheduler.

```
4.2.4.51 xTaskGetTaskInfo() xTaskInfo xTaskGetTaskInfo ( const xTask task_ )
```

The xTaskGetTaskInfo() system call returns the xTaskInfo structure containing the details of the task including its identifier, name, state and runtime statistics.

## See also

xTaskInfo

## **Parameters**

task⇔	The task to return the details of.
lasn←	The task to return the details of.

## Returns

xTaskInfo The xTaskInfo structure containing the task details. xTaskGetTaskInfo() returns null if the task cannot be found.

## Warning

The memory allocated by xTaskGetTaskInfo() must be freed by xMemFree().

```
4.2.4.52 xTaskGetTaskRunTimeStats() xTaskRunTimeStats xTaskGetTaskRunTimeStats ( const xTask task_{-})
```

The xTaskGetTaskRunTimeStats() system call returns the task runtime statistics for one task. The xTaskGetTaskRunTimeStats() system call returns the xTaskRunTimeStats type. The memory must be freed by calling xMemFree() after it is no longer needed.

#### See also

```
xTaskRunTimeStats
xMemFree()
```

#### **Parameters**

task⇔	The task to get the runtime statistics for.

## Returns

xTaskRunTimeStats The runtime stats returned by xTaskGetTaskRunTimeStats(). xTaskGetTaskRunTimeStats() will return null of the task cannot be found.

## Warning

The memory allocated by xTaskGetTaskRunTimeStats() must be freed by xMemFree().

```
4.2.4.53 xTaskGetTaskState() xTaskState xTaskGetTaskState( const xTask task_)
```

The xTaskGetTaskState() system call will return the state of the task.

#### See also

xTaskState

task⇔	The task to return the state of.

xTaskState The xTaskState of the task. If the task cannot be found, xTaskGetTaskState() will return null.

```
4.2.4.54 xTaskGetWDPeriod() xTicks xTaskGetWDPeriod ( const xTask task_ )
```

The xTaskGetWDPeriod() will return the current task watchdog timer for the task.

## See also

xTaskChangeWDPeriod()

#### **Parameters**

task⊷	The task to get the task watchdog timer period for.

## Returns

xTicks The task watchdog timer period which is measured in ticks.

# **4.2.4.55 xTaskNotificationIsWaiting()** xBase xTaskNotificationIsWaiting ( const xTask task\_ )

The xTaskNotificationIsWaiting() system call will return true or false depending on whether there is a direct to task notification waiting for the task.

## **Parameters**

```
task

The task to check for a waiting task notification.

—
```

## Returns

xBase Returns true if there is a task notification. False if there is no notification or if the task could not be found.

The xTaskNotifyGive() system call will give a direct to task notification to the specified task. The task notification bytes is the number of bytes contained in the notification value. The number of notification bytes must be between one and the CONFIG\_NOTIFICATION\_VALUE\_BYTES setting. The notification value must contain a pointer to a char array containing the notification value. If the task already has a waiting task notification, xTaskNotifyGive() will NOT overwrite the waiting task notification. xTaskNotifyGive() will return true if the direct to task notification was successfully given.

#### See also

```
CONFIG_NOTIFICATION_VALUE_BYTES xTaskNotifyTake()
```

#### **Parameters**

task_	The task to send the task notification to.
notification⊷ Bytes_	The number of bytes contained in the notification value. The number must be between one and the CONFIG_NOTIFICATION_VALUE_BYTES setting.
notification <i>⊷</i> Value_	A char array containing the notification value. The notification value is NOT a null terminated string.

#### Returns

xBase RETURN SUCCESS if the direct to task notification was successfully given, RETURN FAILURE if not.

The xTaskNotifyStateClear() system call will clear a waiting direct to task notification if one exists without returning the notification.

#### **Parameters**

task⊷	The task to clear the notification for.

```
4.2.4.58 xTaskNotifyTake() xTaskNotification xTaskNotifyTake ( xTask task_ )
```

The xTaskNotifyTake() system call will return the waiting direct to task notification if there is one. The xTaskNotifyTake() system call will return an xTaskNotification structure containing the notification bytes and its value. The memory allocated by xTaskNotifyTake() must be freed by xMemFree().

#### See also

```
xTaskNotification
xTaskNotifyGive()
xMemFree()
CONFIG_NOTIFICATION_VALUE_BYTES
```

task⇔	The task to return a waiting task notification.
_	

#### Returns

xTaskNotification The xTaskNotification structure containing the notification bytes and value. xTaskNotifyTake() will return null if no waiting task notification exists or if the task cannot be found.

## Warning

The memory allocated by xTaskNotifyTake() must be freed by xMemFree().

The xTaskResetTimer() system call will reset the task timer. xTaskResetTimer() does not change the timer period or the task state when called. See xTaskChangePeriod() for more details on task timers.

#### See also

```
xTaskWait()
xTaskChangePeriod()
xTaskGetPeriod()
```

#### **Parameters**

task⊷	The task to reset the task timer for.

```
4.2.4.60 xTaskResume() void xTaskResume ( xTask task_{-})
```

The xTaskResume() system call will resume a suspended task. Tasks are suspended on creation so either xTaskResume() or xTaskWait() must be called to place the task in a state that the scheduler will execute.

## See also

```
xTaskState
xTaskSuspend()
xTaskWait()
```

task⇔	The task to set its state to running.

```
4.2.4.61 xTaskResumeAll() void xTaskResumeAll ( void )
```

The xTaskResumeAll() system call will set the scheduler state to running so the next call to xTaskStartScheduler() will resume execute of all tasks. The state of each task is not altered by xTaskSuspendAll() or xTaskResumeAll().

#### See also

xTaskSuspendAll()

```
4.2.4.62 xTaskStartScheduler() void xTaskStartScheduler ( void )
```

The xTaskStartScheduler() system call passes control to the HeliOS scheduler. This system call will not return until xTaskSuspendAll() is called. If xTaskSuspendAll() is called, xTaskResumeAll() must be called before xTaskStartScheduler() can be called again to continue executing tasks.

The xTaskSuspend() system call will suspend a task. A task that has been suspended will not be executed by the scheduler until xTaskResume() or xTaskWait() is called.

#### See also

xTaskState xTaskResume() xTaskWait()

task⇔	The task to suspend.

```
4.2.4.64 xTaskSuspendAll() void xTaskSuspendAll ( void )
```

The xTaskSuspendAll() system call will set the scheduler state to suspended so the scheduler will stop and return. The state of each task is not altered by xTaskSuspendAll() or xTaskResumeAll().

#### See also

xTaskResumeAll()

```
4.2.4.65 xTaskWait() void xTaskWait ( xTask task_ )
```

The xTaskWait() system call will place a task in the waiting state. A task must be in the waiting state for event driven multitasking with either direct to task notifications OR setting the period on the task timer with xTaskChangePeriod(). A task in the waiting state will not be executed by the scheduler until an event has occurred.

#### See also

```
xTaskState
xTaskResume()
xTaskSuspend()
```

#### **Parameters**

task⇔	The task to place in the waiting state.
_	

The xTimerChangePeriod() system call will change the period of the specified timer. The timer period is measured in ticks. If the timer period is zero, the xTimerHasTimerExpired() system call will always return false.

## See also

```
xTimerHasTimerExpired()
```

## **Parameters**

timer_	The timer to change the period for.
timer←	The timer period in is ticks. Timer period must be zero or greater.
Period_	

## 4.2.4.67 xTimerCreate() xTimer xTimerCreate (

```
const xTicks timerPeriod_ )
```

The xTimerCreate() system call will create a new timer. Timers differ from task timers in that they do not create events that effect the scheduling of a task. Timers can be used by tasks to initiate various task activities based on a specified time period represented in ticks. The memory allocated by xTimerCreate() must be freed by xTimerDelete(). Unlike tasks, timers may be created and deleted within tasks.

## See also

xTimer

xTimerDelete()

#### **Parameters**

timer←	The number of ticks before the timer expires.
Period_	

#### Returns

xTimer The newly created timer. If the timer period parameter is less than zero or xTimerCreate() was unable to allocate the required memory, xTimerCreate() will return null.

## Warning

The timer memory can only be freed by xTimerDelete().

## 

The xTimerDelete() system call will delete a timer. For more information on timers see the xTaskTimerCreate() system call.

## See also

xTimerCreate()

## **Parameters**

timer←	The timer to be deleted.

```
4.2.4.69 xTimerGetPeriod() xTicks xTimerGetPeriod ( const xTimer timer_ )
```

The xTimerGetPeriod() system call will return the current timer period for the specified timer.

timer⊷	The timer to get the timer period for.

#### Returns

xTicks The timer period. If the timer cannot be found, xTimerGetPeriod() will return zero.

```
4.2.4.70 xTimerHasTimerExpired() xBase xTimerHasTimerExpired ( const xTimer timer_)
```

The xTimerHasTimerExpired() system call will return true or false dependent on whether the timer period for the specified timer has elapsed. xTimerHasTimerExpired() will NOT reset the timer. Timers will not automatically reset. Timers MUST be reset with xTimerReset().

## See also

xTimerReset()

#### **Parameters**

timer←	The timer to determine if the period has expired.

## Returns

xBase True if the timer has expired, false if the timer has not expired or could not be found.

## **4.2.4.71 xTimerlsTimerActive()** xBase xTimerIsTimerActive ( const xTimer timer\_ )

The xTimerlsTimerActive() system call will return true of the timer has been started with xTimerStart().

## See also

xTimerStart()

timer⇔	The timer to check if active.

xBase True if active, false if not active or if the timer could not be found.

The xTimerReset() system call will reset the start time of the timer to zero.

#### **Parameters**

timer←	The timer to be reset.
_	

```
4.2.4.73 xTimerStart() void xTimerStart ( xTimer timer_ )
```

The xTimerStart() system call will place the timer in the running (active) state. Neither xTimerStart() nor xTimerStop() will reset the timer. Timers can only be reset with xTimerReset().

## See also

```
xTimerStop()
xTimerReset()
```

#### **Parameters**

timer←	The timer to be started.

```
4.2.4.74 xTimerStop() void xTimerStop ( xTimer timer_ )
```

## See also

xTimerStart() xTimerReset()

timer←	The timer to be stopped.

## Index

Addr_t	SchedulerStateRunning, 32
HeliOS.h, 19	SchedulerStateSuspended, 32
availableSpaceInBytes	Size_t, 22
MemoryRegionStats_s, 3	StreamBuffer_t, 22
	SystemInfo_t, 22
Base_t	Task_t, 23
HeliOS.h, 19	TaskInfo_t, 23
Byte_t	TaskNotification t, 24
HeliOS.h, 20	TaskParm_t, 24
	TaskRunTimeStats_t, 25
Char_t	TaskState_t, 32
HeliOS.h, 20	TaskStateError, 32
config.h, 10	TaskStateRunning, 32
CONFIG_MEMORY_REGION_BLOCK_SIZE, 11	TaskStateSuspended, 32
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS,	TaskStateWaiting, 32
11	Ticks_t, 25
CONFIG_MESSAGE_VALUE_BYTES, 11	Timer_t, 25
CONFIG NOTIFICATION VALUE BYTES, 12	Word_t, 26
CONFIG_QUEUE_MINIMUM_LIMIT, 12	
CONFIG STREAM BUFFER BYTES, 13	xAddr, 26
CONFIG TASK NAME BYTES, 13	xBase, 26
CONFIG TASK WD TIMER ENABLE, 13	xByte, 26
CONFIG_MEMORY_REGION_BLOCK_SIZE	xChar, 27
config.h, 11	xDevice, 27
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS	xDeviceConfigDevice, 32
config.h, 11	xDeviceInitDevice, 33
CONFIG_MESSAGE_VALUE_BYTES	xDeviceIsAvailable, 33
config.h, 11	xDeviceRead, 34
CONFIG_NOTIFICATION_VALUE_BYTES	xDeviceRegisterDevice, 34
	xDeviceSimpleRead, 35
config.h, 12	xDeviceSimpleWrite, 35
CONFIG_QUEUE_MINIMUM_LIMIT	xDeviceWrite, 35
config.h, 12	xHalfWord, 27
CONFIG_STREAM_BUFFER_BYTES	xMemAlloc, 36
config.h, 13	xMemFree, 37
CONFIG_TASK_NAME_BYTES	xMemGetHeapStats, 37
config.h, 13	xMemGetKernelStats, 37
CONFIG_TASK_WD_TIMER_ENABLE	xMemGetSize, 38
config.h, 13	xMemGetUsed, 38
	xMemoryRegionStats, 27
Device_t	xQueue, 27
HeliOS.h, 20	xQueueCreate, 39
Llatina and A	xQueueDelete, 39
HalfWord_t	xQueueDropMessage, 40
HeliOS.h, 20	xQueueGetLength, 40
HeliOS.h, 13	xQueuelsQueueEmpty, 40
Addr_t, 19	xQueuelsQueueFull, 41
Base_t, 19	xQueueLockQueue, 41
Byte_t, 20	xQueueMessage, 28
Char_t, 20	<b>G</b> .
Device_t, 20	xQueueMessagesWaiting, 41
HalfWord_t, 20	xQueuePeek, 42
MemoryRegionStats_t, 21	xQueueReceive, 42
Queue_t, 21	xQueueSend, 43
QueueMessage_t, 21	xQueueUnLockQueue, 43
SchedulerState_t, 31	xSchedulerState, 28
SchedulerStateError 32	xSize, 28

xStreamBuffer, 28	xWord, 31
xStreamBytesAvailable, 44	
xStreamCreate, 44	id
xStreamDelete, 44	TaskInfo_s, 7
xStreamIsEmpty, 45	TaskRunTimeStats_s, 9
xStreamIsFull, 45	Jargoot Fron Entry In Pyton
xStreamReceive, 45	largestFreeEntryInBytes
xStreamReset, 46	MemoryRegionStats_s, 3 lastRunTime
xStreamSend, 46	
xSystemGetSystemInfo, 46	TaskInfo_s, 7
xSystemHalt, 47	TaskRunTimeStats_s, 9
xSystemInfo, 29	majorVersion
xSystemInit, 47	SystemInfo_s, 5
xTask, 29	MemoryRegionStats_s, 2
xTaskChangePeriod, 47	availableSpaceInBytes, 3
xTaskChangeWDPeriod, 48	largestFreeEntryInBytes, 3
xTaskCreate, 48	minimumEverFreeBytesRemaining, 3
xTaskDelete, 49	numberOfFreeBlocks, 3
xTaskGetAllRunTimeStats, 49	smallestFreeEntryInBytes, 3
xTaskGetAllTaskInfo, 50	• • •
xTaskGetHandleByld, 50	successfulAllocations, 3 successfulFrees, 4
xTaskGetHandleByName, 51	MemoryRegionStats t
xTaskGetId, 51	HeliOS.h, 21
xTaskGetName, 51	
xTaskGetNumberOfTasks, 52	messageBytes  QueueMessage_s, 4
xTaskGetPeriod, 52	
xTaskGetSchedulerState, 53	messageValue QueueMessage_s, 5
xTaskGetTaskInfo, 53	minimumEverFreeBytesRemaining
xTaskGetTaskRunTimeStats, 54	MemoryRegionStats_s, 3
xTaskGetTaskState, 54	minorVersion
xTaskGetWDPeriod, 55	SystemInfo_s, 6
xTaskInfo, 29	Gysteriiiio_s, o
xTaskNotification, 30	name
xTaskNotificationIsWaiting, 55	TaskInfo_s, 7
xTaskNotifyGive, 55	notificationBytes
xTaskNotifyStateClear, 56	TaskNotification s, 8
xTaskNotifyTake, 56	notificationValue
xTaskParm, 30	TaskNotification_s, 8
xTaskResetTimer, 57	numberOfFreeBlocks
xTaskResume, 57	MemoryRegionStats_s, 3
xTaskResumeAll, 58	numberOfTasks
xTaskRunTimeStats, 30	SystemInfo_s, 6
xTaskStartScheduler, 58	
xTaskState, 30	patchVersion
xTaskSuspend, 58	SystemInfo_s, 6
xTaskSuspendAll, 58	productName
xTaskWait, 59	SystemInfo_s, 6
xTicks, 31	Outside t
xTimer, 31	Queue_t
xTimerChangePeriod, 59	HeliOS.h, 21
xTimerCeate, 59	QueueMessage_s, 4 messageBytes, 4
xTimerDelete, 60	- ·
xTimerGetPeriod, 60	messageValue, 5 QueueMessage_t
xTimerHasTimerExpired, 61	HeliOS.h, 21
xTimerIsTimerActive, 61	1161103.11, 21
xTimerReset, 62 xTimerStart, 62	SchedulerState_t
xTimerStart, 62 xTimerStop, 62	HeliOS.h, 31
λ τιπισιοιορ, σε	SchedulerStateError

HeliOS.h, 32	Ticks_t
SchedulerStateRunning	HeliOS.h, 25
HeliOS.h, 32	Timer_t
SchedulerStateSuspended	HeliOS.h, 25
HeliOS.h, 32	totalRunTime
Size t	TaskInfo s, 7
HeliOS.h, 22	TaskRunTimeStats_s, 9
smallestFreeEntryInBytes	raski tarrimeotats_s, v
	Word t
MemoryRegionStats_s, 3	HeliOS.h, 26
state	1161100.11, 20
TaskInfo_s, 7	xAddr
StreamBuffer_t	HeliOS.h, 26
HeliOS.h, 22	xBase
successfulAllocations	
MemoryRegionStats_s, 3	HeliOS.h, 26
successfulFrees	xByte
MemoryRegionStats_s, 4	HeliOS.h, 26
SystemInfo s, 5	xChar
majorVersion, 5	HeliOS.h, 27
minorVersion, 6	xDevice
numberOfTasks, 6	HeliOS.h, 27
patchVersion, 6	xDeviceConfigDevice
productName, 6	HeliOS.h, 32
•	xDeviceInitDevice
SystemInfo_t	HeliOS.h, 33
HeliOS.h, 22	xDeviceIsAvailable
Task_t	HeliOS.h, 33
HeliOS.h, 23	xDeviceRead
	HeliOS.h, 34
TaskInfo_s, 6	
id, 7	xDeviceRegisterDevice
lastRunTime, 7	HeliOS.h, 34
name, 7	xDeviceSimpleRead
state, 7	HeliOS.h, 35
totalRunTime, 7	xDeviceSimpleWrite
TaskInfo_t	HeliOS.h, 35
HeliOS.h, 23	xDeviceWrite
TaskNotification_s, 7	HeliOS.h, 35
notificationBytes, 8	xHalfWord
notificationValue, 8	HeliOS.h, 27
TaskNotification t	xMemAlloc
HeliOS.h, 24	HeliOS.h, 36
TaskParm t	xMemFree
HeliOS.h, 24	HeliOS.h, 37
TaskRunTimeStats s, 8	xMemGetHeapStats
id, 9	HeliOS.h, 37
lastRunTime, 9	xMemGetKernelStats
totalRunTime, 9	HeliOS.h, 37
	xMemGetSize
TaskRunTimeStats_t	
HeliOS.h, 25	HeliOS.h, 38
TaskState_t	xMemGetUsed
HeliOS.h, 32	HeliOS.h, 38
TaskStateError	xMemoryRegionStats
HeliOS.h, 32	HeliOS.h, 27
TaskStateRunning	xQueue
HeliOS.h, 32	HeliOS.h, 27
TaskStateSuspended	xQueueCreate
HeliOS.h, 32	HeliOS.h, 39
TaskStateWaiting	xQueueDelete
HeliOS.h, 32	HeliOS.h, 39

xQueueDropMessage	xTaskCreate
HeliOS.h, 40	HeliOS.h, 48
xQueueGetLength	xTaskDelete
HeliOS.h, 40	HeliOS.h, 49
xQueuelsQueueEmpty	xTaskGetAllRunTimeStats
HeliOS.h, 40	HeliOS.h, 49
xQueuelsQueueFull	xTaskGetAllTaskInfo
HeliOS.h, 41	HeliOS.h, 50
xQueueLockQueue	xTaskGetHandleById
HeliOS.h, 41	HeliOS.h, 50
xQueueMessage	xTaskGetHandleByName
HeliOS.h, 28	HeliOS.h, 51
xQueueMessagesWaiting	xTaskGetId
HeliOS.h, 41	HeliOS.h, 51
xQueuePeek	xTaskGetName
HeliOS.h, 42	HeliOS.h, 51
xQueueReceive	xTaskGetNumberOfTasks
HeliOS.h, 42	HeliOS.h, 52
xQueueSend	xTaskGetPeriod
HeliOS.h, 43	HeliOS.h, 52
xQueueUnLockQueue	xTaskGetSchedulerState
HeliOS.h, 43	HeliOS.h, 53
xSchedulerState	xTaskGetTaskInfo
HeliOS.h, 28	HeliOS.h, 53
xSize	xTaskGetTaskRunTimeStats
HeliOS.h, 28	HeliOS.h, 54
xStreamBuffer	xTaskGetTaskState
HeliOS.h, 28	HeliOS.h, 54
xStreamBytesAvailable	xTaskGetWDPeriod
HeliOS.h, 44	HeliOS.h, 55
xStreamCreate	xTaskInfo
HeliOS.h, 44	HeliOS.h, 29
xStreamDelete	xTaskNotification
HeliOS.h, 44	HeliOS.h, 30
xStreamIsEmpty	xTaskNotificationIsWaiting
HeliOS.h, 45	HeliOS.h, 55
xStreamIsFull	xTaskNotifyGive
HeliOS.h, 45	HeliOS.h, 55
xStreamReceive	xTaskNotifyStateClear
HeliOS.h, 45	HeliOS.h, 56
xStreamReset	xTaskNotifyTake
HeliOS.h, 46	HeliOS.h, 56
xStreamSend	xTaskParm
HeliOS.h, 46	HeliOS.h, 30
xSystemGetSystemInfo	xTaskResetTimer
HeliOS.h, 46	HeliOS.h, 57
xSystemHalt	xTaskResume
HeliOS.h, 47	HeliOS.h, 57
xSystemInfo	xTaskResumeAll
HeliOS.h, 29	HeliOS.h, 58
xSystemInit	xTaskRunTimeStats
HeliOS.h, 47	HeliOS.h, 30
xTask	xTaskStartScheduler
HeliOS.h, 29	HeliOS.h, 58
xTaskChangePeriod	xTaskState
HeliOS.h, 47	HeliOS.h, 30
xTaskChangeWDPeriod	xTaskSuspend
HeliOS.h, 48	HeliOS.h, <mark>58</mark>
	,

xTaskSuspendAllHeliOS.h, 58 xTaskWait HeliOS.h, 59 xTicks HeliOS.h, 31 xTimer HeliOS.h, 31 xTimerChangePeriod HeliOS.h, 59 xTimerCreateHeliOS.h, 59 xTimerDelete HeliOS.h, 60 xTimerGetPeriod HeliOS.h, 60 xTimerHasTimerExpired HeliOS.h, 61 xTimerIsTimerActive HeliOS.h, 61 xTimerReset HeliOS.h, 62 xTimerStartHeliOS.h, 62 xTimerStop HeliOS.h, 62

xWord

HeliOS.h, 31