

HeliOS

Kernel 0.3.5

HeliOS Developer's Guide

1 Data Structure Index

1 Data Structure Index	1
1.1 Data Structures	1
2 File Index	2
2.1 File List	2
3 Data Structure Documentation	2
3.1 MemoryRegionStats_s Struct Reference	2
3.1.1 Detailed Description	3
3.1.2 Field Documentation	3
3.2 QueueMessage_s Struct Reference	4
3.2.1 Detailed Description	4
3.2.2 Field Documentation	4
3.3 SystemInfo_s Struct Reference	4
3.3.1 Detailed Description	5
3.3.2 Field Documentation	5
3.4 TaskInfo_s Struct Reference	6
3.4.1 Detailed Description	6
3.4.2 Field Documentation	6
3.5 TaskNotification_s Struct Reference	7
3.5.1 Detailed Description	7
3.5.2 Field Documentation	8
3.6 TaskRunTimeStats_s Struct Reference	8
3.6.1 Detailed Description	8
3.6.2 Field Documentation	8
4 File Documentation	9
4.1 config.h File Reference	9
4.1.1 Detailed Description	10
4.1.2 Macro Definition Documentation	10
4.2 HeliOS.h File Reference	13
4.2.1 Detailed Description	18
4.2.2 Macro Definition Documentation	18
4.2.3 Typedef Documentation	19
4.2.4 Enumeration Type Documentation	29
4.2.5 Function Documentation	30
Index	59

# 1 Data Structure Index

# 1.1 Data Structures

Here are the data structures with brief descriptions:

MemoryRegionStats_s	
Data structure for statistics on a memory region	2
QueueMessage_s	
Data structure for a message queue message	4
SystemInfo_s	
Data structure for system information	4
TaskInfo_s	
Data structure for information about a task	6
TaskNotification_s	
Data structure for direct to task notifications	7
TaskRunTimeStats_s	
Data structure for task runtime statistics	8

# 2 File Index

# 2.1 File List

Here is a list of all documented files with brief descriptions:

config.h
Kernel header file for user definable settings

9
HeliOS.h
Header file for end-user application code

13

# 3 Data Structure Documentation

# 3.1 MemoryRegionStats\_s Struct Reference

Data structure for statistics on a memory region.

#### **Data Fields**

- Word\_t largestFreeEntryInBytes
- Word\_t smallestFreeEntryInBytes
- Word\_t numberOfFreeBlocks
- Word\_t availableSpaceInBytes
- Word\_t successfulAllocations
- Word\_t successfulFrees
- Word\_t minimumEverFreeBytesRemaining

#### 3.1.1 Detailed Description

The MemoryRegionStats\_t data structure is used to store statistics about a HeliOS memory region. Statistics can be obtained for the heap and kernel memory regions.

See also

xMemGetHeapStats() xMemGetKernelStats() xMemoryRegionStats

#### 3.1.2 Field Documentation

# **3.1.2.1 availableSpaceInBytes** Word\_t MemoryRegionStats\_s::availableSpaceInBytes

Amount of free memory in bytes (i.e., numberOfFreeBlocks \* CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE).

#### **3.1.2.2 largestFreeEntryInBytes** Word\_t MemoryRegionStats\_s::largestFreeEntryInBytes

The largest free entry in bytes.

# **3.1.2.3 minimumEverFreeBytesRemaining** Word\_t MemoryRegionStats\_s::minimumEverFreeBytes↔ Remaining

Lowest water level since system initialization of free bytes of memory.

# $\textbf{3.1.2.4} \quad \textbf{numberOfFreeBlocks} \quad \texttt{Word\_t} \quad \texttt{MemoryRegionStats\_s::} \texttt{numberOfFreeBlocks}$

Number of free blocks - see CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE for block size in bytes.

#### **3.1.2.5** smallestFreeEntryInBytes Word\_t MemoryRegionStats\_s::smallestFreeEntryInBytes

The smallest free entry in bytes.

#### **3.1.2.6 successfulAllocations** Word\_t MemoryRegionStats\_s::successfulAllocations

Number of successful memory allocations.

#### **3.1.2.7 successfulFrees** Word\_t MemoryRegionStats\_s::successfulFrees

Number of successful memory "frees".

The documentation for this struct was generated from the following file:

· HeliOS.h

# 3.2 QueueMessage\_s Struct Reference

Data structure for a message queue message.

#### **Data Fields**

- · Base t messageBytes
- char messageValue [CONFIG\_MESSAGE\_VALUE\_BYTES]

#### 3.2.1 Detailed Description

The QueueMessage\_t data structure contains the message queue message returned by xQueuePeek() and xQueueReceive(). The QueueMessage\_t type should be declared as xQueueMessage.

#### See also

```
xQueueMessage
xQueuePeek()
xQueueReceive()
xMemFree()
CONFIG_MESSAGE_VALUE_BYTES
```

#### Warning

The memory allocated for an instance of xQueueMessage must be freed using xMemFree().

#### 3.2.2 Field Documentation

#### **3.2.2.1 messageBytes** Base\_t QueueMessage\_s::messageBytes

The number of bytes in the message Value member that makes up the message value. This cannot exceed CONFIG\_MESSAGE\_VALUE\_BYTES.

```
3.2.2.2 messageValue char QueueMessage_s::messageValue[CONFIG_MESSAGE_VALUE_BYTES]
```

the char array that contains the actual message value. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

• HeliOS.h

# 3.3 SystemInfo\_s Struct Reference

Data structure for system informaiton.

#### **Data Fields**

- char productName [OS\_PRODUCT\_NAME\_SIZE]
- · Base\_t majorVersion
- · Base t minorVersion
- · Base\_t patchVersion
- Base\_t numberOfTasks

#### 3.3.1 Detailed Description

The SystemInfo\_t data structure contains information about the HeliOS system and is returned by xSystemGetSystemInfo(). The SystemInfo\_t type should be declared as xSystemInfo.

#### See also

```
xSystemInfo
xSystemGetSystemInfo()
xMemFree()
```

#### Warning

The memory allocated for an instance of xSystemInfo must be freed using xMemFree().

#### 3.3.2 Field Documentation

# **3.3.2.1 majorVersion** Base\_t SystemInfo\_s::majorVersion

The major version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

```
\textbf{3.3.2.2} \quad \textbf{minorVersion} \quad \texttt{Base\_t} \; \texttt{SystemInfo\_s::minorVersion}
```

The minor version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

```
3.3.2.3 numberOfTasks Base_t SystemInfo_s::numberOfTasks
```

The number of tasks presently in a suspended, running or waiting state.

```
3.3.2.4 patchVersion Base_t SystemInfo_s::patchVersion
```

The patch version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

```
3.3.2.5 productName char SystemInfo_s::productName[OS_PRODUCT_NAME_SIZE]
```

The name of the operating system or product. Its length is defined by OS\_PRODUCT\_NAME\_SIZE. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

· HeliOS.h

# 3.4 TaskInfo\_s Struct Reference

Data structure for information about a task.

#### **Data Fields**

- · Base tid
- char name [CONFIG\_TASK\_NAME\_BYTES]
- TaskState\_t state
- Ticks\_t lastRunTime
- Ticks\_t totalRunTime

#### 3.4.1 Detailed Description

The TaskInfo\_t structure is similar to xTaskRuntimeStats\_t in that it contains runtime statistics for a task. However, TaskInfo\_t also contains additional details about a task such as its identifier, ASCII name and state. The TaskInfo\_t structure is returned by xTaskGetTaskInfo(). If only runtime statistics are needed, TaskRunTimeStats\_t should be used because of its lower memory footprint. The TaskInfo\_t type should be declared as xTaskInfo.

#### See also

```
xTaskInfo
xTaskGetTaskInfo()
xMemFree()
CONFIG_TASK_NAME_BYTES
```

#### Warning

The memory allocated for an instance of xTaskInfo must be freed using xMemFree().

#### 3.4.2 Field Documentation

# 3.4.2.1 id Base\_t TaskInfo\_s::id

The task identifier which is used by xTaskGetHandleById() to return the task handle.

#### **3.4.2.2 lastRunTime** Ticks\_t TaskInfo\_s::lastRunTime

The runtime duration in ticks the last time the task was executed by the scheduler.

```
3.4.2.3 name char TaskInfo_s::name[CONFIG_TASK_NAME_BYTES]
```

The name of the task which is used by xTaskGetHandleByName() to return the task handle. This is NOT a null terminated string.

```
3.4.2.4 state TaskState_t TaskInfo_s::state
```

The state the task is in which is one of four states specified in the TaskState\_t enumerated data type.

```
3.4.2.5 totalRunTime Ticks_t TaskInfo_s::totalRunTime
```

The total runtime duration in ticks the task has been executed by the scheduler.

The documentation for this struct was generated from the following file:

· HeliOS.h

# 3.5 TaskNotification\_s Struct Reference

Data structure for direct to task notifications.

#### **Data Fields**

- Base\_t notificationBytes
- char notificationValue [CONFIG\_NOTIFICATION\_VALUE\_BYTES]

#### 3.5.1 Detailed Description

The TaskNotification\_t data structure contains the direct to task notification returned by xTaskNotifyTake(). The TaskNotification\_t type should be declared as xTaskNotification.

#### See also

```
xTaskNotification
xTaskNotifyTake()
xMemFree()
CONFIG_NOTIFICATION_VALUE_BYTES
```

#### Warning

The memory allocated for an instance of xTaskNotification must be freed using xMemFree().

#### 3.5.2 Field Documentation

# **3.5.2.1 notificationBytes** Base\_t TaskNotification\_s::notificationBytes

The number of bytes in the notification Value member that makes up the notification value. This cannot exceed CONFIG NOTIFICATION VALUE BYTES.

```
3.5.2.2 notificationValue char TaskNotification_s::notificationValue[CONFIG_NOTIFICATION_VALUE_BYTES]
```

The char array that contains the actual notification value. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

· HeliOS.h

# 3.6 TaskRunTimeStats\_s Struct Reference

Data structure for task runtime statistics.

#### **Data Fields**

- · Base tid
- Ticks\_t lastRunTime
- Ticks\_t totalRunTime

#### 3.6.1 Detailed Description

The TaskRunTimeStats\_t structure contains task runtime statistics and is returned by xTaskGetAllRunTimeStats() and xTaskGetTaskRunTimeStats(). The TaskRunTimeStats\_t type should be declared as xTaskRunTimeStats.

#### See also

```
xTaskRunTimeStats
xTaskGetTaskRunTimeStats()
xTaskGetAllRunTimeStats()
xMemFree()
```

#### Warning

The memory allocated for an instance of xTaskRunTimeStats must be freed using xMemFree().

#### 3.6.2 Field Documentation

4 File Documentation 9

```
3.6.2.1 id Base_t TaskRunTimeStats_s::id
```

The task identifier which is used by xTaskGetHandleByld() to return the task handle.

```
3.6.2.2 lastRunTime Ticks_t TaskRunTimeStats_s::lastRunTime
```

The runtime duration in ticks the last time the task was executed by the scheduler.

```
3.6.2.3 totalRunTime Ticks_t TaskRunTimeStats_s::totalRunTime
```

The total runtime duration in ticks the task has been executed by the scheduler.

The documentation for this struct was generated from the following file:

· HeliOS.h

# 4 File Documentation

# 4.1 config.h File Reference

Kernel header file for user definable settings.

#### Macros

• #define CONFIG MESSAGE VALUE BYTES 0x8u /\* 8 \*/

Define to enable the Arduino API C++ interface.

#define CONFIG\_NOTIFICATION\_VALUE\_BYTES 0x8u /\* 8 \*/

Define the size in bytes of the direct to task notification value.

• #define CONFIG TASK NAME BYTES 0x8u /\* 8 \*/

Define the size in bytes of the ASCII task name.

#define CONFIG\_MEMORY\_REGION\_SIZE\_IN\_BLOCKS 0x18u /\* 24 \*/

Define the number of memory blocks available in all memory regions.

#define CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE 0x20u /\* 32 \*/

Define the memory block size in bytes for all memory regions.

#define CONFIG\_QUEUE\_MINIMUM\_LIMIT 0x5u /\* 5 \*/

Define the minimum value for a message queue limit.

• #define CONFIG\_STREAM\_BUFFER\_BYTES 0x20u /\* 32 \*/

Define the length of the stream buffer.

#define CONFIG\_TASK\_WD\_TIMER\_ENABLE

Enable task watchdog timers.

#define CONFIG\_DEVICE\_NAME\_BYTES 0x8u /\* 8 \*/

#### 4.1.1 Detailed Description

```
Author
```

```
Manny Peterson ( mannymsp@gmail.com)
```

Version

0.3.5

Date

2022-01-31

#### Copyright

HeliOS Embedded Operating System Copyright (C) 2020-2022 Manny Peterson mannymsp@gmail.com

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <a href="https://www.gnu.org/licenses/">https://www.gnu.org/licenses/</a>.

#### 4.1.2 Macro Definition Documentation

```
4.1.2.1 CONFIG_MEMORY_REGION_BLOCK_SIZE #define CONFIG_MEMORY_REGION_BLOCK_SIZE 0x20u /* 32 */
```

Setting CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE allows the end-user to define the size of a memory region block in bytes. The memory region block size should be set to achieve the best possible utilization of the available memory. The CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE setting effects both the heap and kernel memory regions. The default value is 32 bytes. The literal must be appended with a "u" to maintain MISRA C:2012 compliance.

```
xMemAlloc()
xMemFree()
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS
```

```
4.1.2.2 CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS #define CONFIG_MEMORY_REGION_SIZE_IN_← BLOCKS 0x18u /* 24 */
```

The heap memory region is used by tasks. Whereas the kernel memory region is used solely by the kernel for kernel objects. The CONFIG\_MEMORY\_REGION\_SIZE\_IN\_BLOCKS setting allows the end-user to define the size, in blocks, of all memory regions thus effecting both the heap and kernel memory regions. The size of a memory block is defined by the CONFIG\_MEMORY\_REGION\_BLOCK\_SIZE setting. The size of all memory regions needs to be adjusted to fit the memory requirements of the end-user's application. By default the CONFIG\_MEMORY\_\circ
REGION\_SIZE\_IN\_BLOCKS is defined on a per platform and/or tool-chain basis therefor it is not defined here by default. The literal must be appended with a "u" to maintain MISRA C:2012 compliance.

```
4.1.2.3 CONFIG_MESSAGE_VALUE_BYTES #define CONFIG_MESSAGE_VALUE_BYTES 0x8u /* 8 */
```

Because HeliOS kernel is written in C, the Arduino API cannot be called directly from the kernel. For example, assertions are unable to be written to the serial bus in applications using the Arduino platform/tool-chain. The CONFIG\_ENABLE\_ARDUINO\_CPP\_INTERFACE builds the included arduino.cpp file to allow the kernel to call the Arduino API through wrapper functions such as **ArduinoAssert**(). The arduino.cpp file can be found in the /extras directory. It must be copied into the /src directory to be built.

Note

On some MCU's like the 8-bit AVRs, it is necessary to undefine the DISABLE\_INTERRUPTS() macro because interrupts must be enabled to write to the serial bus.

Define to enable system assertions.

The CONFIG\_ENABLE\_SYSTEM\_ASSERT setting allows the end-user to enable system assertions in HeliOS. Once enabled, the end-user must define CONFIG\_SYSTEM\_ASSERT\_BEHAVIOR for there to be an effect. By default the CONFIG\_ENABLE\_SYSTEM\_ASSERT setting is not defined.

See also

```
CONFIG_SYSTEM_ASSERT_BEHAVIOR
```

Define the system assertion behavior.

The CONFIG\_SYSTEM\_ASSERT\_BEHAVIOR setting allows the end-user to specify the behavior (code) of the assertion which is called when CONFIG\_ENABLE\_SYSTEM\_ASSERT is defined. Typically some sort of output is generated over a serial or other interface. By default the CONFIG\_SYSTEM\_ASSERT\_BEHAVIOR is not defined.

Note

In order to use the **ArduinoAssert**() functionality, the CONFIG\_ENABLE\_ARDUINO\_CPP\_INTERFACE setting must be enabled.

See also

```
CONFIG_ENABLE_SYSTEM_ASSERT

CONFIG_ENABLE_ARDUINO_CPP_INTERFACE

#define CONFIG_SYSTEM_ASSERT_BEHAVIOR(f, 1) __ArduinoAssert__(f, 1)
```

Define the size in bytes of the message queue message value.

Setting the CONFIG\_MESSAGE\_VALUE\_BYTES allows the end-user to define the size of the message queue message value. The larger the size of the message value, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xQueueMessage

```
4.1.2.4 CONFIG_NOTIFICATION_VALUE_BYTES #define CONFIG_NOTIFICATION_VALUE_BYTES 0x8u /* 8 */
```

Setting the CONFIG\_NOTIFICATION\_VALUE\_BYTES allows the end-user to define the size of the direct to task notification value. The larger the size of the notification value, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xTaskNotification

#### 4.1.2.5 CONFIG\_QUEUE\_MINIMUM\_LIMIT #define CONFIG\_QUEUE\_MINIMUM\_LIMIT 0x5u /\* 5 \*/

Setting the CONFIG\_QUEUE\_MINIMUM\_LIMIT allows the end-user to define the MINIMUM length limit a message queue can be created with xQueueCreate(). When a message queue length equals its limit, the message queue will be considered full and return true when xQueueIsQueueFull() is called. A full queue will also not accept messages from xQueueSend(). The default value is 5. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xQueuelsQueueFull()

xQueueSend()

xQueueCreate()

# 4.1.2.6 CONFIG\_STREAM\_BUFFER\_BYTES #define CONFIG\_STREAM\_BUFFER\_BYTES 0x20u /\* 32 \*/

Setting CONFIG\_STREAM\_BUFFER\_BYTES will define the length of stream buffers created by xStreamCreate(). When the length of the stream buffer reaches this value, it is considered full and can no longer be written to by calling xStreamSend(). The default value is 32. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

```
4.1.2.7 CONFIG_TASK_NAME_BYTES #define CONFIG_TASK_NAME_BYTES 0x8u /* 8 */
```

Setting the CONFIG\_TASK\_NAME\_BYTES allows the end-user to define the size of the ASCII task name. The larger the size of the task name, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xTaskInfo

#### 4.1.2.8 CONFIG\_TASK\_WD\_TIMER\_ENABLE #define CONFIG\_TASK\_WD\_TIMER\_ENABLE

Defining CONFIG\_TASK\_WD\_TIMER\_ENABLE will enable the task wathdog timer feature. The default is enabled.

#### 4.2 HeliOS.h File Reference

Header file for end-user application code.

#### **Data Structures**

• struct TaskRunTimeStats s

Data structure for task runtime statistics.

struct TaskInfo\_s

Data structure for information about a task.

struct TaskNotification s

Data structure for direct to task notifications.

· struct QueueMessage\_s

Data structure for a message queue message.

struct SystemInfo\_s

Data structure for system informaiton.

struct MemoryRegionStats\_s

Data structure for statistics on a memory region.

#### **Macros**

#define DEREF\_TASKPARM(t, p) \*((t \*)p)

A C macro to simplify casting and dereferencing a task paramater.

#### **Typedefs**

typedef uint8\_t Base\_t

Type definition for the base data type.

typedef uint32\_t Word\_t

Type defintion for the word data type.

• typedef uint8\_t Byte\_t

Type defintion for the byte data type.

typedef uint16\_t HWord\_t

Type defintion for the half-word data type.

typedef uint32\_t Ticks\_t

The type definition for time expressed in ticks.

typedef size\_t Size\_t

The type defintion for storing the size of some object in memory.

• typedef Size\_t xSize

The type defintion for storing the size of some object in memory.

typedef struct TaskRunTimeStats\_s TaskRunTimeStats\_t

Data structure for task runtime statistics.

• typedef struct TaskInfo\_s TaskInfo\_t

Data structure for information about a task.

typedef struct TaskNotification\_s TaskNotification\_t

Data structure for direct to task notifications.

typedef struct QueueMessage s QueueMessage t

Data structure for a message queue message.

typedef struct SystemInfo\_s SystemInfo\_t

Data structure for system informaiton.

typedef struct MemoryRegionStats\_s MemoryRegionStats\_t

Data structure for statistics on a memory region.

typedef void Task t

Stub type definition for the task type.

typedef void StreamBuffer\_t

Stub type defintion for a stream buffer type.

typedef void TaskParm\_t

Type definition for the task parameter.

typedef void Queue t

Stub type definition for the message queue type.

· typedef void Timer\_t

Stub type definition for the timer type.

typedef void Addr\_t

Type defintion for the memory address data type.

typedef Addr\_t \* xAddr

Type defintion for the memory address data type.

• typedef Base txBase

Type definition for the base data type.

typedef Word\_t xWord

Type defintion for the word data type.

typedef HWord\_t xHWord

Type defintion for the half-word data type.

• typedef Timer\_t \* xTimer

Stub type definition for the timer type.

typedef Queue\_t \* xQueue

Stub type definition for the message queue type.

 $\bullet \ \ typedef \ QueueMessage\_t * xQueueMessage\\$ 

Data structure for a message queue message.

typedef TaskNotification\_t \* xTaskNotification

Data structure for direct to task notifications.

• typedef TaskInfo t \* xTaskInfo

Data structure for information about a task.

typedef TaskRunTimeStats\_t \* xTaskRunTimeStats

Data structure for task runtime statistics.

• typedef MemoryRegionStats\_t \* xMemoryRegionStats

Data structure for statistics on a memory region.

typedef Task\_t \* xTask

Stub type definition for the task type.

typedef StreamBuffer\_t \* xStreamBuffer

Stub type defintion for a stream buffer type.

typedef TaskParm\_t \* xTaskParm

Type definition for the task parameter.

typedef Ticks\_t xTicks

The type definition for time expressed in ticks.

typedef Byte\_t xByte

Type defintion for the byte data type.

typedef TaskState\_t xTaskState

Enumerated type for task states.

typedef SchedulerState\_t xSchedulerState

Enumerated type for scheduler states.

typedef SystemInfo\_t \* xSystemInfo

Data structure for system informaiton.

#### **Enumerations**

- enum TaskState\_t { TaskStateError , TaskStateSuspended , TaskStateRunning , TaskStateWaiting }
   Enumerated type for task states.
- $\bullet \ \ enum\ SchedulerState\_t\ \{\ SchedulerStateError\ ,\ SchedulerStateSuspended\ ,\ SchedulerStateRunning\ \}$

#### **Functions**

void xSystemInit (void)

System call to initialize the system.

Enumerated type for scheduler states.

void <u>SystemAssert</u> (const char \*file\_, int line\_)

System call to handle assertions.

xAddr xMemAlloc (const xSize size\_)

System call to allocate memory from the heap.

void xMemFree (const xAddr addr\_)

System call to free memory allocated from the heap.

xSize xMemGetUsed (void)

System call to return the amount of allocated heap memory.

xSize xMemGetSize (const xAddr addr\_)

System call to return the amount of heap memory allcoated for a given address.

xMemoryRegionStats xMemGetHeapStats (void)

System call to obtain statistics on the heap.

xMemoryRegionStats xMemGetKernelStats (void)

System call to obtain statistics on the kernel memory region.

xQueue xQueueCreate (xBase limit\_)

System call to create a new message queue.

• void xQueueDelete (xQueue queue\_)

System call to delete a message queue.

• xBase xQueueGetLength (xQueue queue\_)

System call to get the length of the message queue.

xBase xQueuelsQueueEmpty (xQueue queue\_)

System call to check if the message queue is empty.

• xBase xQueuelsQueueFull (xQueue queue\_)

System call to check if the message queue is full.

• xBase xQueueMessagesWaiting (xQueue queue\_)

System call to check if there are message queue messages waiting.

• xBase xQueueSend (xQueue queue\_, xBase messageBytes\_, const char \*messageValue\_)

System call to send a message using a message queue.

• xQueueMessage xQueuePeek (xQueue queue\_)

System call to peek at the next message in a message queue.

void xQueueDropMessage (xQueue queue\_)

System call to drop the next message in a message queue.

xQueueMessage xQueueReceive (xQueue queue )

System call to receive the next message in the message queue.

void xQueueLockQueue (xQueue queue\_)

System call to LOCK the message queue.

void xQueueUnLockQueue (xQueue queue )

System call to UNLOCk the message queue.

void xTaskStartScheduler (void)

System call to pass control to the HeliOS scheduler.

void xTaskResumeAll (void)

System call to set scheduler state to running.

void xTaskSuspendAll (void)

System call to set the scheduler state to suspended.

xSystemInfo xSystemGetSystemInfo (void)

The xSystemGetSystemInfo() system call will return the type xSystemInfo containing information about the system including the OS (product) name, its version and how many tasks are currently in the running, suspended or waiting states.

xTask xTaskCreate (const char \*name\_, void(\*callback\_)(xTask, xTaskParm), xTaskParm taskParameter\_)

System call to create a new task.

void xTaskDelete (xTask task\_)

System call to delete a task.

xTask xTaskGetHandleByName (const char \*name\_)

System call to get a task's handle by its ASCII name.

xTask xTaskGetHandleById (xBase id\_)

System call to get a task's handle by its task identifier.

xTaskRunTimeStats xTaskGetAllRunTimeStats (xBase \*tasks )

System call to return task runtime statistics for all tasks.

xTaskRunTimeStats xTaskGetTaskRunTimeStats (xTask task )

System call to return task runtime statistics for the specified task.

xBase xTaskGetNumberOfTasks (void)

System call to return the number of tasks regardless of their state.

xTaskInfo xTaskGetTaskInfo (xTask task )

System call to return the details of a task.

xTaskInfo xTaskGetAllTaskInfo (xBase \*tasks )

System call to return the details of all tasks.

xTaskState xTaskGetTaskState (xTask task\_)

System call to return the state of a task.

char \* xTaskGetName (xTask task\_)

System call to return the ASCII name of a task.

xBase xTaskGetId (xTask task\_)

System call to return the task identifier for a task.

void xTaskNotifyStateClear (xTask task\_)

System call to clear a waiting direct to task notification.

xBase xTaskNotificationIsWaiting (xTask task\_)

System call to check if a direct to task notification is waiting.

• Base\_t xTaskNotifyGive (xTask task\_, xBase notificationBytes\_, const char \*notificationValue\_)

System call to give another task a direct to task notification.

xTaskNotification xTaskNotifyTake (xTask task\_)

System call to take a direct to task notification from another task.

void xTaskResume (xTask task\_)

System call to resume a task.

void xTaskSuspend (xTask task\_)

System call to suspend a task.

void xTaskWait (xTask task )

System call to place a task in a waiting state.

void xTaskChangePeriod (xTask task\_, xTicks timerPeriod\_)

System call to set the task timer period.

xTicks xTaskGetPeriod (xTask task\_)

System call to get the task timer period.

void xTaskResetTimer (xTask task\_)

System call to reset the task timer.

xSchedulerState xTaskGetSchedulerState (void)

System call to get the state of the scheduler.

xTimer xTimerCreate (xTicks timerPeriod\_)

System call to create a new timer.

void xTimerDelete (xTimer timer )

System call will delete a timer.

void xTimerChangePeriod (xTimer timer\_, xTicks timerPeriod\_)

System call to change the period of a timer.

• xTicks xTimerGetPeriod (xTimer timer\_)

System call to get the period of a timer.

xBase xTimerIsTimerActive (xTimer timer\_)

System call to check if a timer is active.

xBase xTimerHasTimerExpired (xTimer timer )

System call to check if a timer has expired.

void xTimerReset (xTimer timer\_)

System call to reset a timer.

void xTimerStart (xTimer timer )

System call to start a timer.

void xTimerStop (xTimer timer )

The xTimerStop() system call will place the timer in the stopped state. Neither xTimerStart() nor xTimerStop() will reset the timer. Timers can only be reset with xTimerReset().

void xSystemHalt (void)

The xSystemHalt() system call will halt HeliOS.

void xTaskChangeWDPeriod (xTask \*task\_, xTicks wdTimerPeriod\_)

The xTaskChangeWDPeriod() will change the period on the task watchdog timer.

xTicks xTaskGetWDPeriod (xTask \*task\_)

The xTaskGetWDPeriod() return the current task watchdog timer.

xStreamBuffer xStreamCreate (void)

The xStreamCreate() system call will create a new stream buffer.

void xStreamDelete (xStreamBuffer stream\_)

The xStreamDelete() system call will delete a stream buffer.

xBase xStreamSend (xStreamBuffer stream\_, xByte byte\_)

The xStreamSend() system call will write one byte to the stream buffer.

xByte \* xStreamReceive (xStreamBuffer stream\_, HWord\_t \*bytes\_)

The xStreamReceive() system call will return the contents of the stream buffer.

xHWord xStreamBytesAvailable (xStreamBuffer stream\_)

The xStreamBytesAvailable() system call returns the length of the stream buffer.

void xStreamReset (xStreamBuffer stream\_)

The xStreamReset() system call will reset a stream buffer.

xBase xStreamIsEmpty (xStreamBuffer stream\_)

The xStreamIsEmpty() system call returns true if the stream buffer is empty.

xBase xStreamIsFull (xStreamBuffer steam\_)

The xStreamIsFull() system call returns true if the stream buffer is full.

- xBase xDeviceRegisterDevice (xBase(\*device\_self\_register\_)())
- xBase xDeviceWrite (xHWord uid\_, xHWord \*bytes\_, xByte \*data\_)
- xBase xDeviceRead (xHWord uid , xHWord \*bytes , xByte \*data )

#### 4.2.1 Detailed Description

**Author** 

```
Manny Peterson ( mannymsp@gmail.com)
```

Version

0.3.5

Date

2022-01-31

#### Copyright

HeliOS Embedded Operating System Copyright (C) 2020-2022 Manny Peterson mannymsp@gmail.com

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <a href="https://www.gnu.org/licenses/">https://www.gnu.org/licenses/</a>.

#### 4.2.2 Macro Definition Documentation

# **4.2.2.1 DEREF\_TASKPARM** #define DEREF\_TASKPARM( t, p) \*((t\*)p)

When a task paramater is passed to a task, it is passed as a pointer of type void. To use the paramater, it must first be cast to the correct type and dereferenced. The following is an example of how the DEREF\_TASKPARM() C macro simplifies that process.

```
void myTask_main(xTask task_, xTaskParm parm_) {
  int i;
  i = DEREF_TASKPARM(int, parm_);
  i++;
  DEREF_TASKPARM(int, parm_) = i;
  return;
}
```

#### **Parameters**

t	The data type to cast the task paramater to (e.g., int).
р	The task pointer, typically named parm

#### 4.2.3 Typedef Documentation

#### 4.2.3.1 Addr\_t typedef void Addr\_t

The xAddr type is used to store a memory address and is used to pass memory addresses back and forth between system calls and the end-user application. It is not necessary to use the xAddr type within the end-user application as long as the type is not used to interact with the HeliOS kernel through system calls.

```
4.2.3.2 Base_t typedef uint8_t Base_t
```

A simple data type is often needed as an argument for a system call or a return type. The Base\_t type is used in such a case where there are no other structural data requirements and is typically an unsigned 8-bit integer. The Base\_t type should be declared as xBase.

See also

xBase

```
4.2.3.3 Byte_t typedef uint8_t Byte_t
```

A byte is an 8-bit data type in HeliOS.

See also

xByte

```
4.2.3.4 HWord_t typedef uint16_t HWord_t
```

A half-word is a 16-bit data type in HeliOS.

See also

xHWord

# $\textbf{4.2.3.5} \quad \textbf{MemoryRegionStats\_t} \quad \texttt{typedef struct MemoryRegionStats\_s MemoryRegionStats\_t}$

The MemoryRegionStats\_t data structure is used to store statistics about a HeliOS memory region. Statistics can be obtained for the heap and kernel memory regions.

```
xMemGetHeapStats()
xMemGetKernelStats()
xMemoryRegionStats
```

#### 4.2.3.6 Queue\_t typedef void Queue\_t

The Queue\_t type is a stub type definition for the internal message queue structure and is treated as a message queue handle by most of the message queue related system calls. The members of the data structure are not accessible. The Queue\_t type should be declared as xQueue.

#### See also

xQueue

xQueueDelete()

#### Warning

The memory allocated for an instance of xQueue must be freed using xQueueDelete().

# $\textbf{4.2.3.7} \quad \textbf{QueueMessage\_t} \quad \texttt{typedef struct QueueMessage\_s QueueMessage\_t}$

The QueueMessage\_t data structure contains the message queue message returned by xQueuePeek() and xQueueReceive(). The QueueMessage\_t type should be declared as xQueueMessage.

#### See also

```
xQueueMessage
```

xQueuePeek()

xQueueReceive()

xMemFree()

CONFIG\_MESSAGE\_VALUE\_BYTES

# Warning

The memory allocated for an instance of xQueueMessage must be freed using xMemFree().

# 4.2.3.8 Size\_t typedef size\_t Size\_t

The Size\_t type is used to store the size of an object in memory and is always represented in bytes. Size\_t should always be declared as xSize.

#### See also

xSize

#### 4.2.3.9 StreamBuffer\_t typedef void StreamBuffer\_t

The StreamBuffer\_t type is a stub defintion for the internal stream buffer data structure and is treated as a handle by most of the stream system calls. The members of this data structure are not accessible. The StreamBuffer\_t type should be declared as xStreamBuffer.

#### See also

```
xStreamBuffer
xStreamDelete()
```

#### Warning

The memory allocated for an instance of the xStreamBuffer must be freed by xStreamDelete()

# **4.2.3.10** SystemInfo\_t typedef struct SystemInfo\_s SystemInfo\_t

The SystemInfo\_t data structure contains information about the HeliOS system and is returned by xSystemGetSystemInfo(). The SystemInfo\_t type should be declared as xSystemInfo.

#### See also

```
xSystemInfo
xSystemGetSystemInfo()
xMemFree()
```

#### Warning

The memory allocated for an instance of xSystemInfo must be freed using xMemFree().

#### 4.2.3.11 Task\_t typedef void Task\_t

The Task\_t type is a stub type definition for the internal task data structure and is treated as a task handle by most of the task related system calls. The members of the data structure are not accessible. The Task\_t type should be declared as xTask.

#### See also

```
xTask
xTaskDelete()
```

#### Warning

The memory allocated for an instance of xTask must be freed by xTaskDelete()

#### 4.2.3.12 TaskInfo\_t typedef struct TaskInfo\_s TaskInfo\_t

The TaskInfo\_t structure is similar to xTaskRuntimeStats\_t in that it contains runtime statistics for a task. However, TaskInfo\_t also contains additional details about a task such as its identifier, ASCII name and state. The TaskInfo\_t structure is returned by xTaskGetTaskInfo(). If only runtime statistics are needed, TaskRunTimeStats\_t should be used because of its lower memory footprint. The TaskInfo\_t type should be declared as xTaskInfo.

#### See also

```
xTaskInfo
xTaskGetTaskInfo()
xMemFree()
CONFIG_TASK_NAME_BYTES
```

#### Warning

The memory allocated for an instance of xTaskInfo must be freed using xMemFree().

# $\textbf{4.2.3.13} \quad \textbf{TaskNotification\_t} \quad \texttt{typedef struct TaskNotification\_s TaskNotification\_t}$

The TaskNotification\_t data structure contains the direct to task notification returned by xTaskNotifyTake(). The TaskNotification\_t type should be declared as xTaskNotification.

#### See also

```
xTaskNotification
xTaskNotifyTake()
xMemFree()
CONFIG NOTIFICATION VALUE BYTES
```

#### Warning

The memory allocated for an instance of xTaskNotification must be freed using xMemFree().

#### 4.2.3.14 TaskParm\_t typedef void TaskParm\_t

The TaskParm\_t type is used to pass a parameter to a task at the time of creation using xTaskCreate(). A task parameter is a pointer of type void and can point to any number of intrinsic types, arrays and/or user defined structures which can be passed to a task. It is up the the end-user to manage, allocate and free the memory related to these objects using xMemAlloc() and xMemFree(). The TaskParm\_t should be declared as xTaskParm.

#### See also

```
xTaskParm
xMemAlloc()
xMemFree()
```

#### Warning

The memory allocated for an instance of xTaskParm must be freed using xMemFree().

#### 4.2.3.15 TaskRunTimeStats\_t typedef struct TaskRunTimeStats\_s TaskRunTimeStats\_t

The TaskRunTimeStats\_t structure contains task runtime statistics and is returned by xTaskGetAllRunTimeStats() and xTaskGetTaskRunTimeStats(). The TaskRunTimeStats\_t type should be declared as xTaskRunTimeStats.

#### See also

```
xTaskRunTimeStats
xTaskGetTaskRunTimeStats()
xTaskGetAllRunTimeStats()
xMemFree()
```

#### Warning

The memory allocated for an instance of xTaskRunTimeStats must be freed using xMemFree().

#### 4.2.3.16 Ticks\_t typedef uint32\_t Ticks\_t

The xTicks type is used by several of the task and timer related system calls to express time. The unit of measure for time is always ticks.

#### See also

**xTicks** 

# 4.2.3.17 Timer\_t typedef void Timer\_t

The Timer\_t type is a stub type definition for the internal timer data structure and is treated as a timer handle by most of the timer related system calls. The members of the data structure are not accessible. The Timer\_t type should be declared as xTimer.

#### See also

```
xTimer xTimerDelete()
```

#### Warning

The memory allocated for an instance of xTimer must be freed using xTimerDelete().

```
4.2.3.18 Word_t typedef uint32_t Word_t
```

A word is a 32-bit data type in HeliOS.

See also

xWord

```
4.2.3.19 xAddr typedef Addr_t* xAddr
```

The xAddr type is used to store a memory address and is used to pass memory addresses back and forth between system calls and the end-user application. It is not necessary to use the xAddr type within the end-user application as long as the type is not used to interact with the HeliOS kernel through system calls.

```
4.2.3.20 xBase typedef Base_t xBase
```

A simple data type is often needed as an argument for a system call or a return type. The xBase type is used in such a case where there are no other structural data requirements is typically an unsigned 8-bit integer.

See also

Base t

```
4.2.3.21 xByte typedef Byte_t xByte
```

A byte is an 8-bit data type in HeliOS.

See also

Byte\_t

4.2.3.22 xHWord typedef HWord\_t xHWord

A half-word is a 16-bit data type in HeliOS.

See also

HWord\_t

#### **4.2.3.23 xMemoryRegionStats** typedef MemoryRegionStats\_t\* xMemoryRegionStats

The xMemoryRegionStats data structure is used to store statistics about a HeliOS memory region. Statistics can be obtained for the heap and kernel memory regions.

#### See also

```
xMemGetHeapStats()
xMemGetKernelStats()
MemoryRegionStats_t
```

#### 4.2.3.24 xQueue typedef Queue\_t\* xQueue

The xQueue type is a stub type definition for the internal message queue structure and is treated as a message queue handle by most of the message queue related system calls. The members of the data structure are not accessible.

#### See also

```
Queue_t
xQueueDelete()
```

#### Warning

The memory allocated for an instance of xQueue must be freed using xQueueDelete().

# 4.2.3.25 **xQueueMessage** typedef QueueMessage\_t\* xQueueMessage

The xQueueMessage data structure contains the message queue message returned by xQueuePeek() and xQueueReceive(). See QueueMessage\_t for information about the data structure's members.

#### See also

```
QueueMessage_t
xQueuePeek()
xQueueReceive()
xMemFree()
CONFIG_MESSAGE_VALUE_BYTES
```

# Warning

The memory allocated for an instance of xQueueMessage must be freed using xMemFree().

#### 4.2.3.26 xSchedulerState typedef SchedulerState\_t xSchedulerState

The scheduler can be in one of four possible states defined in the SchedulerState\_t enumerated type. The state of the scheduler is changed by calling xTaskSuspendAll() and xTaskResumeAll(). The state can be obtained by calling xTaskGetSchedulerState().

#### See also

```
xSchedulerState
xTaskSuspendAll()
xTaskResumeAll()
xTaskGetSchedulerState()
```

#### 4.2.3.27 xSize typedef Size\_t xSize

The xSize type is used to store the size of an object in memory and is always represented in bytes.

#### 4.2.3.28 xStreamBuffer typedef StreamBuffer\_t\* xStreamBuffer

The xStreamBuffer type is a stub defintion for the internal stream buffer data structure and is treated as a handle by most of the stream system calls. The members of this data structure are not accessible.

#### See also

```
StreamBuffer_t
xStreamDelete()
```

# Warning

The memory allocated for an instance of the xStreamBuffer must be freed by xStreamDelete()

#### 4.2.3.29 xSystemInfo typedef SystemInfo\_t\* xSystemInfo

The xSystemInfo data structure contains information about the HeliOS system and is returned by xSystemGetSystemInfo(). See xSystemInfo\_t for information about the data structure's members.

#### See also

```
SystemInfo_t
xSystemGetSystemInfo()
xMemFree()
```

#### Warning

The memory allocated for an instance of xSystemInfo must be freed using xMemFree().

```
4.2.3.30 xTask typedef Task_t* xTask
```

The xTask type is a stub type definition for the internal task data structure and is treated as a task handle by most of the task related system calls. The members of the data structure are not accessible.

#### See also

```
Task_t
xTaskCreate()
xTaskDelete()
```

#### Warning

The memory allocated for an instance of xTask must be freed by xTaskDelete()

# 4.2.3.31 xTaskInfo typedef TaskInfo\_t\* xTaskInfo

The xTaskInfo structure is similar to xTaskRunTimeStats in that it contains runtime statistics for a task. However, xTaskInfo also contains additional details about a task such as its identifier, ASCII name and state. The xTaskInfo structure is returned by xTaskGetTaskInfo(). If only runtime statistics are needed, xTaskRunTimeStats should be used because of its lower memory footprint. See TaskInfo t for information about the data structure's members.

#### See also

```
TaskInfo_t
xTaskGetTaskInfo()
xMemFree()
CONFIG_TASK_NAME_BYTES
```

#### Warning

The memory allocated for an instance of xTaskInfo must be freed using xMemFree().

#### 4.2.3.32 xTaskNotification typedef TaskNotification\_t\* xTaskNotification

The xTaskNotification data structure contains the direct to task notification returned by xTaskNotifyTake(). See TaskNotification t for information about the data structure's members.

#### See also

```
TaskNotification_t
xTaskNotifyTake()
xMemFree()
CONFIG NOTIFICATION VALUE BYTES
```

# Warning

The memory allocated for an instance of xTaskNotification must be freed using xMemFree().

#### 4.2.3.33 xTaskParm typedef TaskParm\_t\* xTaskParm

The xTaskParm type is used to pass a parameter to a task at the time of creation using xTaskCreate(). A task parameter is a pointer of type void and can point to any number of intrinsic types, arrays and/or user defined structures which can be passed to a task. It is up the the end-user to manage allocate and free the memory related to these objects using xMemAlloc() and xMemFree().

#### See also

```
TaskParm_t xMemAlloc() xMemFree()
```

#### Warning

The memory allocated for an instance of xTaskParm must be freed using xMemFree().

#### 4.2.3.34 xTaskRunTimeStats typedef TaskRunTimeStats\_t\* xTaskRunTimeStats

The xTaskRunTimeStats structure contains task runtime statistics and is returned by xTaskGetAllRunTimeStats() and xTaskGetTaskRunTimeStats(). See TaskRunTimeStats\_t for information about the data structure's members.

#### See also

```
TaskRunTimeStats_t
xTaskGetTaskRunTimeStats()
xTaskGetAllRunTimeStats()
xMemFree()
```

#### Warning

The memory allocated for an instance of xTaskRunTimeStats must be freed using xMemFree().

#### 4.2.3.35 xTaskState typedef TaskState\_t xTaskState

A task can be in one of the four possible states defined in the TaskState\_t enumerated type. The state of a task is changed by calling xTaskResume(), xTaskSuspend() or xTaskWait().

```
TaskState_t
xTaskResume()
xTaskSuspend()
xTaskWait()
```

```
4.2.3.36 xTicks typedef Ticks_t xTicks
```

The xTicks type is used by several of the task and timer related system calls to express time. The unit of measure for time is always ticks.

See also

Ticks\_t

#### 4.2.3.37 xTimer typedef Timer\_t\* xTimer

The xTimer type is a stub type definition for the internal timer data structure and is treated as a timer handle by most of the timer related system calls. The members of the data structure are not accessible.

See also

```
Timer_t xTimerDelete()
```

Warning

The memory allocated for an instance of xTimer must be freed using xTimerDelete().

```
4.2.3.38 xWord typedef Word_t xWord
```

A word is a 32-bit data type in HeliOS.

See also

Word\_t

#### 4.2.4 Enumeration Type Documentation

#### 4.2.4.1 SchedulerState\_t enum SchedulerState\_t

The scheduler can be in one of four possible states defined in the SchedulerState\_t enumerated type. The state of the scheduler is changed by calling xTaskSuspendAll() and xTaskResumeAll(). The state can be obtained by calling xTaskGetSchedulerState().

```
xSchedulerState
xTaskSuspendAll()
xTaskResumeAll()
```

#### Enumerator

SchedulerStateError	Not used.
SchedulerStateSuspended	State the scheduler is in after xTaskSuspendAll() is called.
SchedulerStateRunning	State the scheduler is in after xTaskResumeAll() is called.

#### 4.2.4.2 TaskState\_t enum TaskState\_t

A task can be in one of the four possible states defined in the TaskState\_t enumerated type. The state of a task is changed by calling xTaskResume(), xTaskSuspend() or xTaskWait(). The TaskState\_t enumerated type should be declared as xTaskState.

#### See also

```
xTaskState
```

xTaskResume()

xTaskSuspend()

xTaskWait()

#### **Enumerator**

TaskStateError	Returned by xTaskGetTaskState() when task cannot be found.
TaskStateSuspended	State a task is in when it is first created by xTaskCreate() or suspended by xTaskSuspend().
TaskStateRunning	State a task is in after xTaskResume() is called.
TaskStateWaiting	State a task is in after xTaskWait() is called.

#### 4.2.5 Function Documentation

```
4.2.5.1 __SystemAssert__() void __SystemAssert__ ( const char * file_, int line_ )
```

The **SystemAssert**() system call handles assertions. The **SystemAssert**() system call should not be called directly. Instead, the SYSASSERT() macro should be used. The system assertion functionality will only work when the CONFIG\_ENABLE\_SYSTEM\_ASSERT and CONFIG\_SYSTEM\_ASSERT\_BEHAVIOR settings are defined.

```
SYSASSERT

CONFIG_ENABLE_SYSTEM_ASSERT

CONFIG_SYSTEM_ASSERT_BEHAVIOR
```

# **Parameters**

file⇔	This is automatically defined by the compiler's definition of FILE
line⊷	This is automatically defined by the compiler's definition of LINE

# **4.2.5.2 xDeviceRead() xBase xDeviceRead ( xHWord uid\_, xHWord \* bytes\_, xByte \* data\_** )

#### **Parameters**

uid_	
bytes⊷	
_	
data⇔	

# Returns

xBase

# **4.2.5.3 xDeviceRegisterDevice() xBase xDeviceRegisterDevice** ( $xBase(*)() device\_self\_register\_)$

# **Parameters**

```
device_self_←
register_
```

#### Returns

xBase

#### **Parameters**

uid_	
bytes⊷	
_	
data↩	

#### Returns

xBase

```
4.2.5.5 xMemAlloc() xAddr xMemAlloc ( const xSize size_)
```

The xMemAlloc() system call allocates memory from the heap for HeliOS system calls and end-user tasks. The size of the heap, in bytes, is dependent on the CONFIG\_MEMORY\_REGION\_SIZE\_IN\_BLOCKS and CONFIG\_← MEMORY\_REGION\_BLOCK\_SIZE settings. xMemAlloc() functions similarly to calloc() in that it clears the memory it allocates.

#### See also

```
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS
CONFIG_MEMORY_REGION_BLOCK_SIZE
xMemFree()
```

#### **Parameters**

size⊷	The amount (size) of the memory to be allocated from the heap in bytes.
_	

# Returns

xAddr If successful, xMemAlloc() returns the address of the newly allocated memory. If unsuccessful, the system call will return null.

#### Note

HeliOS technically does not allocate memory from what is traditionally heap memory. HeliOS uses a private "heap" which is actually static memory allocated at compile time. This is done to maintain MISRA C:2012 compliance since standard library functions like malloc(), calloc() and free() are not permitted.

```
4.2.5.6 xMemFree() void xMemFree() const xAddr \ addr_{-})
```

The xMemFree() system call will free heap memory allocated by xMemAlloc() and other HeliOS system calls such as xSystemGetSystemInfo().

See also

xMemAlloc()

#### **Parameters**

addr⇔	The address of the allocated heap memory to be freed.
_	

#### Warning

xMemFree() cannot be used to free memory allocated for kernel objects. Memory allocated by xTaskCreate(), xTimerCreate() or xQueueCreate() must be freed by their respective delete system calls (i.e., xTaskDelete()).

# **4.2.5.7 xMemGetHeapStats()** xMemoryRegionStats xMemGetHeapStats (

The xMemGetHeapStats() system call will return statistics about the heap so the end-user can better understand the state of the heap.

See also

xMemoryRegionStats

Returns

xMemoryRegionStats Returns the xMemoryRegionStats structure or null if unsuccesful.

Warning

The memory allocated by xMemGetHeapStats() must be freed by xMemFree().

```
4.2.5.8 xMemGetKernelStats() xMemoryRegionStats xMemGetKernelStats ( void )
```

The xMemGetKernelStats() system call will return statistics about the kernel memory region so the end-user can better understand the state of kernel memory.

See also

xMemoryRegionStats

Returns

xMemoryRegionStats Returns the xMemoryRegionStats structure or null if unsuccesful.

Warning

The memory allocated by xMemGetKernelStats() must be freed by xMemFree().

```
4.2.5.9 xMemGetSize() xSize xMemGetSize ( const xAddr addr_)
```

The xMemGetSize() system call returns the amount of heap memory in bytes that is currently allocated to a specific address. If the address is null or invalid, xMemGetSize() will return zero bytes.

#### **Parameters**

addr⇔	The address of the allocated heap memory to obtain the size of the memory, in bytes, that is allocated.	1
_		l

#### Returns

Size\_t The amount of memory currently allocated to the specific address in bytes. If the address is invalid or null, xMemGetSize() will return zero.

#### Note

If the address addr\_points to a structure that, for example, is 48 bytes in size base on sizeof(), xMemGetSize() will return the number of bytes allocated by the block(s) that contain the structure. Assuming the default block size of 32, a 48 byte structure would require TWO blocks so xMemGetSize() would return 64 - not 48. xMemGetSize() also checks the health of the heap and will return zero if it detects a consistency issue with the heap. Thus, xMemGetSize() can be used to validate addresses before the objects they reference are accessed.

```
4.2.5.10 xMemGetUsed() xSize xMemGetUsed (void)
```

The xMemGetUsed() system call returns the amount of heap memory, in bytes, that is currently allocated. Calls to xMemAlloc() increases and xMemFree() decreases the amount of memory in use.

#### Returns

Size\_t The amount of memory currently allocated in bytes. If no heap memory is currently allocated, xMemGetUsed() will return zero.

#### Note

xMemGetUsed() returns the amount of heap memory that is currently allocated to end-user objects AND kernel objects. However, only end-user objects may be freed using xMemFree(). Kernel objects must be freed using their respective delete system call (e.g., xTaskDelete()).

```
4.2.5.11 xQueueCreate() xQueue xQueueCreate ( xBase limit_ )
```

The xQueueCreate() system call creates a message queue for inter-task communication.

#### See also

xQueue

xQueueDelete()

CONFIG\_QUEUE\_MINIMUM\_LIMIT

#### **Parameters**

limit←	The message limit for the queue. When this number is reach, the queue is considered full and
_	xQueueSend() will fail. The minimum limit for queues is dependent on the setting
	CONFIG_QUEUE_MINIMUM_LIMIT.

#### Returns

xQueue A queue is returned if successful, otherwise null is returned if unsuccessful.

#### Warning

The message queue memory can only be freed by xQueueDelete().

# 

The xQueueDelete() system call will delete a message queue created by xQueueCreate(). xQueueDelete() will delete a queue regardless of how many messages the queue contains at the time xQueueDelete() is called. Any messages the message queue contains will be deleted in the process of deleting the message queue.

#### See also

xQueueCreate()

#### **Parameters**

queue↔	The queue to be deleted.
_	

# **4.2.5.13 xQueueDropMessage()** void xQueueDropMessage ( $xQueue \ queue \_$ )

The xQueueDropMessage() system call will drop the next message from the message queue without returning the message.

#### **Parameters**

```
queue← The queue to drop the next message from.
```

```
4.2.5.14 xQueueGetLength() xBase xQueueGetLength ( <math>xQueue \ queue
```

The xQueueGetLength() system call returns the length of the queue (the number of messages the queue currently contains).

### **Parameters**

queue⊷	The queue to return the length of.

### Returns

xBase The number of messages in the queue. If unsuccessful or if the queue is empty, xQueueGetLength() returns zero.

```
4.2.5.15 xQueuelsQueueEmpty() xBase xQueueIsQueueEmpty ( xQueue \ queue \ )
```

The xQueuelsEmpty() system call will return a true or false dependent on whether the queue is empty (message queue length is zero) or contains one or more messages.

### **Parameters**

queue⊷	The queue to determine whether it is empty.

# Returns

xBase True if the queue is empty. False if the queue has one or more messages. xQueuelsQueueEmpty() will also return false if the queue parameter is invalid.

```
4.2.5.16 xQueuelsQueueFull() xBase xQueueIsQueueFull ( xQueue \ queue\_ )
```

The xQueuelsFull() system call will return a true or false dependent on whether the queue is full or contains zero messages. A queue is considered full if the number of messages in the queue is equal to the queue's length limit.

# **Parameters**

queue⊷	The queue to determine whether it is full.
_	

# Returns

xBase True if the queue is full. False if the queue has zero. xQueuelsQueueFull() will also return false if the queue parameter is invalid.

```
4.2.5.17 xQueueLockQueue() void xQueueLockQueue ( xQueue queue_ )
```

The xQueueLockQueue() system call will lock the message queue. Locking a message queue will prevent xQueueSend() from sending messages to the queue.

# **Parameters**

queue⊷	The queue to lock.
_	

# 4.2.5.18 **xQueueMessagesWaiting()** xBase xQueueMessagesWaiting ( $xQueue \ queue\_$ )

The xQueueMessageWaiting() system call returns true or false dependent on whether there is at least one message waiting. The message queue does not have to be full to return true.

# **Parameters**

queue⊷	The queue to determine whether one or more messages are waiting.

# Returns

xBase True if one or more messages are waiting. False if there are no messages waiting of the queue parameter is invalid.

```
4.2.5.19 xQueuePeek() xQueueMessage xQueuePeek ( xQueue \ queue )
```

The xQueuePeek() system call will return the next message in the specified message queue without dropping the message.

# See also

```
xQueueMessage
xMemFree()
```

queue⊷	The queue to return the next message from.

#### Returns

xQueueMessage The next message in the queue. If the queue is empty or the queue parameter is invalid, xQueuePeek() will return null.

# Warning

The memory allocated by xQueuePeek() must be freed by xMemFree().

```
4.2.5.20 xQueueReceive() xQueueMessage xQueueReceive ( xQueue \ queue \ )
```

The xQueueReceive() system call will return the next message in the message queue and drop it from the message queue.

# See also

```
xQueueMessage
xMemFree()
```

### **Parameters**

queue⊷	The queue to return the next message from.

# Returns

xQueueMessage The message returned from the queue. If the queue is empty of the queue parameter is invalid, xQueueReceive() will return null.

# Warning

The memory allocated by xQueueReceive() must be freed by xMemFree().

The xQueueSend() system call will send a message using the specified message queue. The size of the message value is passed in the message bytes parameter. The maximum message value size in bytes is dependent on the CONFIG\_MESSAGE\_VALUE\_BYTES setting.

### See also

```
CONFIG_MESSAGE_VALUE_BYTES
xQueuePeek()
xQueueReceive()
```

queue_	The queue to send the message to.
message <i>⊷</i> Bytes_	The number of bytes contained in the message value. The number of bytes must be greater than zero and less than or equal to the setting CONFIG_MESSAGE_VALUE_BYTES.
message⊷ Value_	The message value. If the message value is greater than defined in CONFIG_MESSAGE_VALUE_BYTES, only the number of bytes defined in CONFIG_MESSAGE_VALUE_BYTES will be copied into the message value. The message value is NOT a null terminated string.

# Returns

xBase xQueueSend() returns RETURN\_SUCCESS if the message was sent to the queue successfully. Otherwise RETURN\_FAILURE if unsuccessful.

```
4.2.5.22 xQueueUnLockQueue() void xQueueUnLockQueue ( xQueue queue_ )
```

The xQueueUnLockQueue() system call will unlock the message queue. Unlocking a message queue will allow xQueueSend() to send messages to the queue.

#### **Parameters**

queue⊷	The queue to unlock.

# **4.2.5.23 xStreamBytesAvailable()** xHWord xStreamBytesAvailable ( xStreamBuffer stream\_)

The xStreamBytesAvailable() system call will return the length of the stream buffer in bytes (i.e., bytes available to be received by xStreamReceive()).

## **Parameters**

stream⊷	The stream to operate on.
_	

# Returns

xHWord The length of the stream buffer in bytes.

```
4.2.5.24 xStreamCreate() xStreamBuffer xStreamCreate ( void )
```

The xStreamCreate() system call will create a new stream buffer. The memory for a stream buffer is allocated from kernel memory and therefor cannot be freed by calling xMemFree().

### Returns

xStreamBuffer The newly created stream buffer.

## Warning

The stream buffer created by xStreamCreate() must be freed by calling xStreamDelete().

```
4.2.5.25 xStreamDelete() void xStreamDelete ( xStreamBuffer stream_{-} )
```

The xStreamDelete() system call will delete a stream buffer and free its memory. Once a stream buffer is deleted, it can not be written to or read from.

#### **Parameters**

stream⊷	The stream buffer to operate on.

# **4.2.5.26 xStreamIsEmpty()** xBase xStreamIsEmpty ( xStreamBuffer stream\_ )

The xStreamIsEmpty() system call is used to determine if the stream buffer is empty. A stream buffer is considered empty when it's length is equal to zero. If the buffer is greater than zero in length, xStreamIsEmpty() will return false.

## **Parameters**

steam⇔	The stream buffer to operate on.
_	

# Returns

xBase Returns true if the stream buffer length is equal to zero in length, otherwise xStreamIsEmpty() will return false.

```
4.2.5.27 xStreamIsFull() xBase xStreamIsFull ( xStreamBuffer steam_ )
```

The xStreamIsFull() system call is used to determine if the stream buffer is full. A stream buffer is considered full when it's length is equal to CONFIG\_STREAM\_BUFFER\_BYTES. If the buffer is less than CONFIG\_STREAM\_← BUFFER\_BYTES in length, xStreamIsFull() will return false.

steam⇔	The stream buffer to operate on.

### Returns

xBase Returns true if the stream buffer is equal to CONFIG\_STREAM\_BUFFER\_BYTES in length, otherwise xStreamIsFull() will return false.

The xStreamReceive() system call will return the contents of the stream buffer. The contents are returned as a byte array whose length is known by the bytes\_paramater. Because the byte array is stored in the heap, it must be freed by calling xMemFree().

### **Parameters**

stream⇔	The stream to operate on.
_	
bytes⊷	The number of bytes returned (i.e., length of the byte array) by xStreamReceive().

# Returns

xByte\* The byte array containing the contents of the stream buffer.

# Warning

The byte array returned by xStreamReceive() must be freed by calling xMemFree().

```
4.2.5.29 xStreamReset() void xStreamReset() ( xStreamBuffer stream()
```

The xStreamRest() system call will clear the contents of the stream buffer and reset its length to zero.

stream⇔	The stream buffer to operate on.

```
4.2.5.30 xStreamSend() xBase xStreamSend ( xStreamBuffer stream_, xByte byte_)
```

The xStreamSend() system call will write one byte to the stream buffer. If the stream buffer's length is equal to CONFIG\_STREAM\_BUFFER\_BYTES (i.e., full) then the byte will not be written to the stream buffer and xStreamSend() will return RETURN\_FAILURE.

#### **Parameters**

<i>stream</i> ←	
byte_	

### Returns

xBase

# **4.2.5.31 xSystemGetSystemInfo()** xSystemInfo xSystemGetSystemInfo ( void )

### Returns

xSystemInfo The system info is returned if successful, otherwise null is returned if unsuccessful.

# See also

xSystemInfo xMemFree()

# Warning

The memory allocated by the xSystemGetSystemInfo() must be freed with xMemFree()

```
4.2.5.32 xSystemHalt() void xSystemHalt ( void )
```

The xSystemHalt() system call will halt HeliOS. Once xSystemHalt() is called, the system must be reset.

```
4.2.5.33 xSystemInit() void xSystemInit ( void )
```

The xSystemInit() system call initializes the required interrupt handlers and memory and must be called prior to calling any other system call.

The xTaskChangePeriod() system call will change the period (ticks) on the task timer for the specified task. The timer period must be greater than zero. To have any effect, the task must be in the waiting state set by calling xTaskWait() on the task. Once the timer period is set and the task is in the waiting state, the task will be executed every timerPeriod\_ ticks. Changing the period to zero will prevent the task from being executed even if it is in the waiting state unless it were to receive a direct to task notification.

### See also

```
xTaskWait()
xTaskGetPeriod()
xTaskResetTimer()
```

### **Parameters**

task_	The task to change the timer period for.
timer←	The timer period in ticks.
Period_	

The xTaskChangeWDPeriod() system call will change the task watchdog timer period. The period, measured in ticks, must be greater than zero to have any effect. If the tasks last runtime exceeds the task watchdog timer period, the task will automatically be placed in a suspended state.

# See also

```
xTaskGetWDPeriod()
```

### **Parameters**

task_	The task to change the task watchdog timer for.
wdTimer⊷	The task watchdog timer period which is measured in ticks. If zero, the task watchdog timer
Period_	will not have any effect.

The xTaskCreate() system call will create a new task. The task will be created with its state set to suspended. The xTaskCreate() and xTaskDelete() system calls cannot be called within a task. They MUST be called outside of the scope of the HeliOS scheduler.

name_	The ASCII name of the task which can be used by xTaskGetHandleByName() to obtain the
	task handle. The length of the name is depended on the CONFIG_TASK_NAME_BYTES.
	The task name is NOT a null terminated char string.
callback_	The address of the task main function. This is the function that will be invoked by the
	scheduler when a task is scheduled for execution.
task⊷	A pointer to any type or structure that the end-user wants to pass into the task as a
Parameter_	parameter. The task parameter is not required and may simply be set to null.

# Returns

xTask A handle to the newly created task.

### See also

```
xTask
```

xTaskParm

xTaskDelete()

xTaskState

CONFIG\_TASK\_NAME\_BYTES

### Warning

xTaskCreate() MUST be called outside the scope of the HeliOS scheduler (i.e., not from a task's main). The task memory can only be freed by xTaskDelete().

```
4.2.5.37 xTaskDelete() void xTaskDelete ( xTask task_ )
```

The xTaskDelete() system call will delete a task. The xTaskCreate() and xTaskDelete() system calls cannot be called within a task. They MUST be called outside of the scope of the HeliOS scheduler.

# **Parameters**

task⊷	The handle of the task to be deleted.
1_	

# Warning

xTaskDelete() MUST be called outside the scope of the HeliOS scheduler (i.e., not from a task's main).

```
4.2.5.38 xTaskGetAllRunTimeStats() xTaskRunTimeStats xTaskGetAllRunTimeStats ( xBase * tasks_{-})
```

The xTaskGetAllRunTimeStats() system call will return the runtime statistics for all of the tasks regardless of their state. The xTaskGetAllRunTimeStats() system call returns the xTaskRunTimeStats type. An xBase variable must be passed by reference to xTaskGetAllRunTimeStats() which will be updated by xTaskGetAllRunTimeStats() to contain the number of tasks so the end-user can iterate through the tasks. The xTaskRunTimeStats memory must be freed by xMemFree() after it is no longer needed.

### See also

```
xTaskRunTimeStats
xMemFree()
```

# **Parameters**

tasks⇔	A variable of type xBase passed by reference which will contain the number of tasks upon return. If no	
_	tasks currently exist, this variable will not be modified.	

#### Returns

xTaskRunTimeStats The runtime stats returned by xTaskGetAllRunTimeStats(). If there are currently no tasks then this will be null. This memory must be freed by xMemFree().

### Warning

The memory allocated by xTaskGetAllRunTimeStats() must be freed by xMemFree().

```
4.2.5.39 xTaskGetAllTaskInfo() xTaskInfo xTaskGetAllTaskInfo ( xBase * tasks_{-})
```

The xTaskGetAllTaskInfo() system call returns the xTaskInfo structure containing the details of ALL tasks including their identifier, name, state and runtime statistics.

# See also

xTaskInfo

# **Parameters**

tasks⇔	A variable of type xBase passed by reference which will contain the number of tasks upon return. If no
_	tasks currently exist, this variable will not be modified.

# Returns

xTaskInfo The xTaskInfo structure containing the tasks details. xTaskGetAllTaskInfo() returns null if there no tasks or if a consistency issue is detected.

# Warning

The memory allocated by xTaskGetAllTaskInfo() must be freed by xMemFree().

```
4.2.5.40 xTaskGetHandleById() xTask xTaskGetHandleById ( xBase id_ )
```

The xTaskGetHandleById() system call will return the task handle of the task specified by identifier identifier.

### See also

xBase

### **Parameters**

id⊷	The identifier of the task to return the handle of.
_←	

# Returns

xTask The task handle. xTaskGetHandleByld() returns null if the the task identifier cannot be found.

```
4.2.5.41 xTaskGetHandleByName() xTask xTaskGetHandleByName ( const char * name_ )
```

The xTaskGetHandleByName() system call will return the task handle of the task specified by its ASCII name. The length of the task name is dependent on the CONFIG\_TASK\_NAME\_BYTES setting. The name is compared byte-for-byte so the name is case sensitive.

### See also

```
CONFIG_TASK_NAME_BYTES
```

# **Parameters**

name←	The ASCII name of the task to return the handle of. The task name is NOT a null terminated string.
_	

# Returns

xTask The task handle. xTaskGetHandleByName() returns null if the name cannot be found.

```
4.2.5.42 xTaskGetId() xBase xTaskGetId ( xTask task_ )
```

The xTaskGetId() system call returns the task identifier for the task.

task⊷	The task to return the identifier of.

### Returns

xBase The identifier of the task. If the task cannot be found, xTaskGetId() returns zero (all tasks identifiers are 1 or greater).

```
4.2.5.43 xTaskGetName() char* xTaskGetName ( xTask task_{-} )
```

The xTaskGetName() system call returns the ASCII name of the task. The size of the task is dependent on the setting CONFIG\_TASK\_NAME\_BYTES. The task name is NOT a null terminated char string. The memory allocated for the char array must be freed by xMemFree() when no longer needed.

### See also

```
CONFIG_TASK_NAME_BYTES xMemFree()
```

# **Parameters**

task⊷	The task to return the name of.
_	

# Returns

char\* A pointer to the char array containing the ASCII name of the task. The task name is NOT a null terminated char string. xTaskGetName() will return null if the task cannot be found.

# Warning

The memory allocated by xTaskGetName() must be free by xMemFree().

```
4.2.5.44 xTaskGetNumberOfTasks() xBase xTaskGetNumberOfTasks ( void )
```

The xTaskGetNumberOfTasks() system call returns the current number of tasks regardless of their state.

# Returns

xBase The number of tasks.

```
4.2.5.45 xTaskGetPeriod() xTicks xTaskGetPeriod ( xTask task_ )
```

The xTaskGetPeriod() will return the period for the timer for the specified task. See xTaskChangePeriod() for more information on how the task timer works.

### See also

```
xTaskWait()
xTaskChangePeriod()
xTaskResetTimer()
```

#### **Parameters**

task⊷	The task to return the timer period for.
_	

### Returns

xTicks The timer period in ticks. xTaskGetPeriod() will return zero if the timer period is zero or if the task could not be found.

# $\textbf{4.2.5.46} \quad \textbf{xTaskGetSchedulerState()} \quad \textbf{xSchedulerState} \quad \textbf{xTaskGetSchedulerState (} \\ \text{void} \quad )$

The xTaskGetSchedulerState() system call will return the state of the scheduler. The state of the scheduler can only be changed using xTaskSuspendAll() and xTaskResumeAll().

# See also

```
xSchedulerState
xTaskSuspendAll()
xTaskResumeAll()
```

### Returns

xSchedulerState The state of the scheduler.

```
4.2.5.47 xTaskGetTaskInfo() xTaskInfo xTaskGetTaskInfo ( xTask task_ )
```

The xTaskGetTaskInfo() system call returns the xTaskInfo structure containing the details of the task including its identifier, name, state and runtime statistics.

# See also

xTaskInfo

task⊷	The task to return the details of.

### Returns

xTaskInfo The xTaskInfo structure containing the task details. xTaskGetTaskInfo() returns null if the task cannot be found.

# Warning

The memory allocated by xTaskGetTaskInfo() must be freed by xMemFree().

# 4.2.5.48 **xTaskGetTaskRunTimeStats()** xTaskRunTimeStats xTaskGetTaskRunTimeStats ( xTask task\_)

The xTaskGetTaskRunTimeStats() system call returns the task runtime statistics for one task. The xTaskGetTaskRunTimeStats() system call returns the xTaskRunTimeStats type. The memory must be freed by calling xMemFree() after it is no longer needed.

# See also

xTaskRunTimeStats xMemFree()

# **Parameters**

task⇔	The task to get the runtime statistics for.
_	

# Returns

xTaskRunTimeStats The runtime stats returned by xTaskGetTaskRunTimeStats(). xTaskGetTaskRunTimeStats() will return null of the task cannot be found.

### Warning

The memory allocated by xTaskGetTaskRunTimeStats() must be freed by xMemFree().

# **4.2.5.49 xTaskGetTaskState() x**TaskState **x**TaskGetTaskState ( **x**Task *task\_* )

The xTaskGetTaskState() system call will return the state of the task.

## See also

xTaskState

task⊷	The task to return the state of.

# Returns

xTaskState The xTaskState of the task. If the task cannot be found, xTaskGetTaskState() will return null.

```
4.2.5.50 xTaskGetWDPeriod() xTicks xTaskGetWDPeriod ( xTask * task_{-})
```

The xTaskGetWDPeriod() will return the current task watchdog timer for the task.

# See also

xTaskChangeWDPeriod()

### **Parameters**

task⊷	The task to get the task watchdog timer period for.
_	

# Returns

Ticks\_t The task watchdog timer period which is measured in ticks.

# 4.2.5.51 xTaskNotificationlsWaiting() xBase xTaskNotificationIsWaiting ( $xTask \ task$ )

The xTaskNotificationIsWaiting() system call will return true or false depending on whether there is a direct to task notification waiting for the task.

# **Parameters**

task⊷	The task to check for a waiting task notification.

# Returns

xBase Returns true if there is a task notification. False if there is no notification or if the task could not be found.

The xTaskNotifyGive() system call will give a direct to task notification to the specified task. The task notification bytes is the number of bytes contained in the notification value. The number of notification bytes must be between one and the CONFIG\_NOTIFICATION\_VALUE\_BYTES setting. The notification value must contain a pointer to a char array containing the notification value. If the task already has a waiting task notification, xTaskNotifyGive() will NOT overwrite the waiting task notification. xTaskNotifyGive() will return true if the direct to task notification was successfully given.

### See also

```
CONFIG_NOTIFICATION_VALUE_BYTES 
xTaskNotifyTake()
```

#### **Parameters**

task_	The task to send the task notification to.
notification⊷ Bytes_	The number of bytes contained in the notification value. The number must be between one and the CONFIG_NOTIFICATION_VALUE_BYTES setting.
notification <i>⊷</i> Value_	A char array containing the notification value. The notification value is NOT a null terminated string.

# Returns

xBase RETURN\_SUCCESS if the direct to task notification was successfully given, RETURN\_FAILURE if not.

The xTaskNotifyStateClear() system call will clear a waiting direct to task notification if one exists without returning the notification.

# **Parameters**

task⊷	The task to clear the notification for.
_	

```
4.2.5.54 xTaskNotifyTake() xTaskNotification xTaskNotifyTake ( xTask \ task)
```

The xTaskNotifyTake() system call will return the waiting direct to task notification if there is one. The xTaskNotifyTake() system call will return an xTaskNotification structure containing the notification bytes and its value. The memory allocated by xTaskNotifyTake() must be freed by xMemFree().

### See also

```
xTaskNotification
xTaskNotifyGive()
xMemFree()
CONFIG_NOTIFICATION_VALUE_BYTES
```

#### **Parameters**

task⇔	The task to return a waiting task notification.
_	

### Returns

xTaskNotification The xTaskNotification structure containing the notification bytes and value. xTaskNotifyTake() will return null if no waiting task notification exists or if the task cannot be found.

# Warning

The memory allocated by xTaskNotifyTake() must be freed by xMemFree().

The xTaskResetTimer() system call will reset the task timer. xTaskResetTimer() does not change the timer period or the task state when called. See xTaskChangePeriod() for more details on task timers.

# See also

```
xTaskWait()
xTaskChangePeriod()
xTaskGetPeriod()
```

# **Parameters**

task⇔	The task to reset the task timer for.
_	

```
4.2.5.56 xTaskResume() void xTaskResume ( xTask task_{-} )
```

The xTaskResume() system call will resume a suspended task. Tasks are suspended on creation so either xTaskResume() or xTaskWait() must be called to place the task in a state that the scheduler will execute.

#### See also

```
xTaskState
xTaskSuspend()
xTaskWait()
```

### **Parameters**

task⊷	The task to set its state to running.
_	

# 4.2.5.57 xTaskResumeAll() void xTaskResumeAll ( void )

The xTaskResumeAll() system call will set the scheduler state to running so the next call to xTaskStartScheduler() will resume execute of all tasks. The state of each task is not altered by xTaskSuspendAll() or xTaskResumeAll().

### See also

xTaskSuspendAll()

```
4.2.5.58 xTaskStartScheduler() void xTaskStartScheduler (
```

The xTaskStartScheduler() system call passes control to the HeliOS scheduler. This system call will not return until xTaskSuspendAll() is called. If xTaskSuspendAll() is called, xTaskResumeAll() must be called before xTaskStartScheduler() can be called again to continue executing tasks.

```
4.2.5.59 xTaskSuspend() void xTaskSuspend ( xTask task_{-} )
```

The xTaskSuspend() system call will suspend a task. A task that has been suspended will not be executed by the scheduler until xTaskResume() or xTaskWait() is called.

### See also

xTaskState xTaskResume() xTaskWait()

task⇔	The task to suspend.
_	

```
4.2.5.60 xTaskSuspendAll() void xTaskSuspendAll ( void )
```

The xTaskSuspendAll() system call will set the scheduler state to suspended so the scheduler will stop and return. The state of each task is not altered by xTaskSuspendAll() or xTaskResumeAll().

See also

xTaskResumeAll()

```
4.2.5.61 xTaskWait() void xTaskWait ( xTask task_ )
```

The xTaskWait() system call will place a task in the waiting state. A task must be in the waiting state for event driven multitasking with either direct to task notifications OR setting the period on the task timer with xTaskChangePeriod(). A task in the waiting state will not be executed by the scheduler until an event has occurred.

### See also

```
xTaskState
xTaskResume()
xTaskSuspend()
```

# **Parameters**

task⊷	The task to place in the waiting state.
_	

The xTimerChangePeriod() system call will change the period of the specified timer. The timer period is measured in ticks. If the timer period is zero, the xTimerHasTimerExpired() system call will always return false.

# See also

xTimerHasTimerExpired()

timer_	The timer to change the period for.
timer←	The timer period in is ticks. Timer period must be zero or greater.
Period_	

```
4.2.5.63 xTimerCreate() xTimer xTimerCreate ( xTicks timerPeriod_)
```

The xTimerCreate() system call will create a new timer. Timers differ from task timers in that they do not create events that effect the scheduling of a task. Timers can be used by tasks to initiate various task activities based on a specified time period represented in ticks. The memory allocated by xTimerCreate() must be freed by xTimerDelete(). Unlike tasks, timers may be created and deleted within tasks.

### See also

xTimer

xTimerDelete()

# **Parameters**

timer←	The number of ticks before the timer expires.
Period_	

# Returns

xTimer The newly created timer. If the timer period parameter is less than zero or xTimerCreate() was unable to allocate the required memory, xTimerCreate() will return null.

# Warning

The timer memory can only be freed by xTimerDelete().

```
4.2.5.64 xTimerDelete() void xTimerDelete ( xTimer timer_)
```

The xTimerDelete() system call will delete a timer. For more information on timers see the xTaskTimerCreate() system call.

# See also

xTimerCreate()

timer←	The timer to be deleted.
_	

```
4.2.5.65 xTimerGetPeriod() xTicks xTimerGetPeriod ( xTimer timer_ )
```

The xTimerGetPeriod() system call will return the current timer period for the specified timer.

# **Parameters**

timer⇔	The timer to get the timer period for.
_	

# Returns

xTicks The timer period. If the timer cannot be found, xTimerGetPeriod() will return zero.

# **4.2.5.66 xTimerHasTimerExpired()** xBase xTimerHasTimerExpired ( xTimer timer\_)

The xTimerHasTimerExpired() system call will return true or false dependent on whether the timer period for the specified timer has elapsed. xTimerHasTimerExpired() will NOT reset the timer. Timers will not automatically reset. Timers MUST be reset with xTimerReset().

# See also

xTimerReset()

# Parameters

timer⊷	The timer to determine if the period has expired.
_	

# Returns

xBase True if the timer has expired, false if the timer has not expired or could not be found.

```
4.2.5.67 xTimerlsTimerActive() xBase xTimerIsTimerActive ( xTimer timer_ )
```

The xTimerlsTimerActive() system call will return true of the timer has been started with xTimerStart().

### See also

xTimerStart()

timer←	The timer to check if active.

# Returns

xBase True if active, false if not active or if the timer could not be found.

```
4.2.5.68 xTimerReset() void xTimerReset ( xTimer timer_)
```

The xTimerReset() system call will reset the start time of the timer to zero.

# **Parameters**

timer←	The timer to be reset.
_	

# **4.2.5.69 xTimerStart()** void xTimerStart ( xTimer timer\_)

The xTimerStart() system call will place the timer in the running (active) state. Neither xTimerStart() nor xTimerStop() will reset the timer. Timers can only be reset with xTimerReset().

# See also

```
xTimerStop()
xTimerReset()
```

# **Parameters**

timer←	The timer to be started.

# See also

```
xTimerStart()
xTimerReset()
```

timer⇔	The timer to be stopped.

# Index

SystemAssert	SchedulerStateSuspended, 30
HeliOS.h, 30	Size_t, 20
	StreamBuffer_t, 20
Addr_t	SystemInfo_t, 21
HeliOS.h, 19	Task t, 21
availableSpaceInBytes	TaskInfo t, 21
MemoryRegionStats s, 3	TaskNotification_t, 22
	TaskParm_t, 22
Base_t	TaskRunTimeStats_t, 22
HeliOS.h, 19	TaskState_t, 30
Byte_t	TaskStateError, 30
HeliOS.h, 19	
	TaskStateRunning, 30
config.h, 9	TaskStateSuspended, 30
CONFIG_MEMORY_REGION_BLOCK_SIZE, 10	TaskStateWaiting, 30
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS,	Ticks_t, 23
10	Timer_t, 23
CONFIG MESSAGE VALUE BYTES, 11	Word_t, 23
CONFIG_NOTIFICATION_VALUE_BYTES, 11	xAddr, 24
CONFIG QUEUE MINIMUM LIMIT, 12	xBase, 24
CONFIG_STREAM_BUFFER_BYTES, 12	xByte, 24
CONFIG TASK NAME BYTES, 12	xDeviceRead, 31
CONFIG_TASK_WD_TIMER_ENABLE, 12	xDeviceRegisterDevice, 31
CONFIG_MEMORY_REGION_BLOCK_SIZE	xDeviceWrite, 31
config.h, 10	xHWord, 24
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS	xMemAlloc, 32
config.h, 10	xMemFree, 32
	xMemGetHeapStats, 33
CONFIG_MESSAGE_VALUE_BYTES	xMemGetKernelStats, 33
config.h, 11	xMemGetSize, 33
CONFIG_NOTIFICATION_VALUE_BYTES	xMemGetUsed, 34
config.h, 11	xMemoryRegionStats, 24
CONFIG_QUEUE_MINIMUM_LIMIT	xQueue, 25
config.h, 12	xQueueCreate, 34
CONFIG_STREAM_BUFFER_BYTES	xQueueDelete, 35
config.h, 12	xQueueDropMessage, 35
CONFIG_TASK_NAME_BYTES	xQueueGetLength, 35
config.h, 12	xQueueIsQueueEmpty, 36
CONFIG_TASK_WD_TIMER_ENABLE	xQueuelsQueueFull, 36
config.h, 12	xQueueLockQueue, 36
DEDEE TAGUERADA	xQueueMessage, 25
DEREF_TASKPARM	xQueueMessagesWaiting, 37
HeliOS.h, 18	xQueuePeek, 37
H-1:00 b 40	xQueueReceive, 38
HeliOS.h, 13	xQueueSend, 38
SystemAssert, 30	xQueueUnLockQueue, 39
Addr_t, 19	
Base_t, 19	xSchedulerState, 25
Byte_t, 19	xSize, 26
DEREF_TASKPARM, 18	xStreamBuffer, 26
HWord_t, 19	xStreamBytesAvailable, 39
MemoryRegionStats_t, 19	xStreamCreate, 39
Queue_t, 19	xStreamDelete, 40
QueueMessage_t, 20	xStreamIsEmpty, 40
SchedulerState_t, 29	xStreamIsFull, 40
SchedulerStateError, 30	xStreamReceive, 41
SchedulerStateRunning, 30	xStreamReset, 41

xStreamSend, 41	MemoryRegionStats_s, 3
xSystemGetSystemInfo, 42	lastRunTime
xSystemHalt, 42	TaskInfo_s, 6
xSystemInfo, 26	TaskRunTimeStats_s, 9
xSystemInit, 42	_ /
xTask, 26	majorVersion
xTaskChangePeriod, 42	SystemInfo_s, 5
xTaskChangeWDPeriod, 43	MemoryRegionStats_s, 2
xTaskCreate, 43	availableSpaceInBytes, 3
xTaskDelete, 44	largestFreeEntryInBytes, 3
xTaskGetAllRunTimeStats, 44	minimumEverFreeBytesRemaining, 3
xTaskGetAllTaskInfo, 45	numberOfFreeBlocks, 3
xTaskGetHandleByld, 45	smallestFreeEntryInBytes, 3
xTaskGetHandleByName, 46	successful Allocations, 3
xTaskGetId, 46	successfulFrees, 3
	MemoryRegionStats_t
xTaskGetName, 47	HeliOS.h, 19
xTaskGetNumberOfTasks, 47	messageBytes
xTaskGetPeriod, 47	QueueMessage_s, 4
xTaskGetSchedulerState, 48	messageValue
xTaskGetTaskInfo, 48	QueueMessage s, 4
xTaskGetTaskRunTimeStats, 49	minimumEverFreeBytesRemaining
xTaskGetTaskState, 49	MemoryRegionStats_s, 3
xTaskGetWDPeriod, 50	minorVersion
xTaskInfo, 27	
xTaskNotification, 27	SystemInfo_s, 5
xTaskNotificationIsWaiting, 50	name
xTaskNotifyGive, 50	TaskInfo s, 7
xTaskNotifyStateClear, 51	notificationBytes
xTaskNotifyTake, 51	TaskNotification_s, 8
xTaskParm, 27	notificationValue
xTaskResetTimer, 52	TaskNotification_s, 8
xTaskResume, 52	numberOfFreeBlocks
xTaskResumeAll, 53	MemoryRegionStats_s, 3
xTaskRunTimeStats, 28	numberOfTasks
xTaskStartScheduler, 53	SystemInfo_s, 5
xTaskState, 28 xTaskSuspend, 53	· _ ·
xTaskSuspendAll, 54	patchVersion
xTaskWait, 54	SystemInfo_s, 5
	productName
xTicks, 28 xTimer, 29	SystemInfo_s, 5
xTimer, 29 xTimerChangePeriod, 54	
xTimerCreate, 55	Queue_t
xTimerDelete, 55	HeliOS.h, 19
xTimerBelete, 33 xTimerGetPeriod, 55	QueueMessage_s, 4
xTimerGetFerlod, 55 xTimerHasTimerExpired, 56	messageBytes, 4
xTimerHasTimerExpired, 56	messageValue, 4
	QueueMessage_t
xTimerReset, 57 xTimerStart, 57	HeliOS.h, 20
xTimerStart, 57 xTimerStop, 57	
xWord, 29	SchedulerState_t
HWord t	HeliOS.h, 29
HeliOS.h, 19	SchedulerStateError
Helioon, 10	HeliOS.h, 30
id	SchedulerStateRunning
TaskInfo_s, 6	HeliOS.h, 30
TaskRunTimeStats_s, 8	SchedulerStateSuspended
<del>-</del> ·	HeliOS.h, 30 Size_t
largestFreeEntryInBytes	OIZG_t

HeliOS.h, 20	TaskRunTimeStats_s, 9
smallestFreeEntryInBytes	
MemoryRegionStats_s, 3	Word_t
state	HeliOS.h, 23
TaskInfo_s, 7	xAddr
StreamBuffer_t HeliOS.h, 20	HeliOS.h, 24
successfulAllocations	xBase
MemoryRegionStats s, 3	HeliOS.h, 24
successfulFrees	xByte
MemoryRegionStats_s, 3	HeliOS.h, 24
SystemInfo_s, 4	xDeviceRead
majorVersion, 5	HeliOS.h, 31 xDeviceRegisterDevice
minorVersion, 5	HeliOS.h, 31
numberOfTasks, 5 patchVersion, 5	xDeviceWrite
productName, 5	HeliOS.h, 31
SystemInfo_t	xHWord
HeliOS.h, 21	HeliOS.h, 24
	xMemAlloc
Task_t	HeliOS.h, 32
HeliOS.h, 21	xMemFree HeliOS.h, 32
TaskInfo_s, 6 id, 6	xMemGetHeapStats
lastRunTime, 6	HeliOS.h, 33
name, 7	xMemGetKernelStats
state, 7	HeliOS.h, 33
totalRunTime, 7	xMemGetSize
TaskInfo_t	HeliOS.h, 33
HeliOS.h, 21	xMemGetUsed
TaskNotification_s, 7	HeliOS.h, 34
notificationBytes, 8 notificationValue, 8	xMemoryRegionStats HeliOS.h, 24
TaskNotification t	xQueue
HeliOS.h, 22	HeliOS.h, 25
TaskParm_t	xQueueCreate
HeliOS.h, 22	HeliOS.h, 34
TaskRunTimeStats_s, 8	xQueueDelete
id, 8	HeliOS.h, 35
lastRunTime, 9	xQueueDropMessage
totalRunTime, 9 TaskRunTimeStats t	HeliOS.h, 35 xQueueGetLength
HeliOS.h, 22	HeliOS.h, 35
TaskState t	xQueuelsQueueEmpty
HeliOS.h, 30	HeliOS.h, 36
TaskStateError	xQueuelsQueueFull
HeliOS.h, 30	HeliOS.h, 36
TaskStateRunning	xQueueLockQueue
HeliOS.h, 30	HeliOS.h, 36
TaskStateSuspended	xQueueMessage HeliOS.h, 25
HeliOS.h, 30 TaskStateWaiting	xQueueMessagesWaiting
HeliOS.h, 30	HeliOS.h, 37
Ticks t	xQueuePeek
HeliOS.h, 23	HeliOS.h, 37
Timer_t	xQueueReceive
HeliOS.h, 23	HeliOS.h, 38
totalRunTime	xQueueSend
TaskInfo_s, 7	HeliOS.h, 38

xQueueUnLockQueue	xTaskGetSchedulerState
HeliOS.h, 39	HeliOS.h, 48
xSchedulerState	xTaskGetTaskInfo
HeliOS.h, 25	HeliOS.h, 48
xSize	xTaskGetTaskRunTimeStats
HeliOS.h, 26	HeliOS.h, 49
xStreamBuffer	xTaskGetTaskState
HeliOS.h, 26	HeliOS.h, 49
xStreamBytesAvailable	xTaskGetWDPeriod
HeliOS.h, 39	HeliOS.h, 50
xStreamCreate	xTaskInfo
HeliOS.h, 39	HeliOS.h, 27
xStreamDelete	xTaskNotification
HeliOS.h, 40	HeliOS.h, 27
xStreamIsEmpty	xTaskNotificationIsWaiting
HeliOS.h, 40	HeliOS.h, 50
xStreamIsFull	xTaskNotifyGive
HeliOS.h, 40	HeliOS.h, 50
xStreamReceive	xTaskNotifyStateClear
HeliOS.h, 41	HeliOS.h, 51
xStreamReset	xTaskNotifyTake
HeliOS.h, 41	HeliOS.h, 51
xStreamSend	xTaskParm
HeliOS.h, 41	HeliOS.h, 27
xSystemGetSystemInfo	xTaskResetTimer
HeliOS.h, 42	HeliOS.h, 52
xSystemHalt	xTaskResume
HeliOS.h, 42	HeliOS.h, 52
xSystemInfo	xTaskResumeAll
HeliOS.h, 26	HeliOS.h, 53
xSystemInit	xTaskRunTimeStats
HeliOS.h, 42	HeliOS.h, 28
xTask	xTaskStartScheduler
HeliOS.h, 26	HeliOS.h, 53
xTaskChangePeriod	xTaskState
HeliOS.h, 42	HeliOS.h, 28
xTaskChangeWDPeriod	xTaskSuspend
HeliOS.h, 43	HeliOS.h, 53
xTaskCreate	xTaskSuspendAll
HeliOS.h, 43	HeliOS.h, 54
xTaskDelete	xTaskWait
HeliOS.h, 44	HeliOS.h, 54
xTaskGetAllRunTimeStats	xTicks
HeliOS.h, 44	HeliOS.h, 28
xTaskGetAllTaskInfo	xTimer
HeliOS.h, 45	HeliOS.h, 29
xTaskGetHandleById	xTimerChangePeriod
HeliOS.h, 45	HeliOS.h, 54
xTaskGetHandleByName	xTimerCreate
HeliOS.h, 46	HeliOS.h, 55
xTaskGetId	xTimerDelete
HeliOS.h, 46	HeliOS.h, 55
xTaskGetName	xTimerGetPeriod
HeliOS.h, 47	HeliOS.h, 55
xTaskGetNumberOfTasks	xTimerHasTimerExpired
HeliOS.h, 47	HeliOS.h, 56
xTaskGetPeriod	xTimerIsTimerActive
HeliOS.h, 47	HeliOS.h, 56

xTimerReset
HeliOS.h, 57
xTimerStart
HeliOS.h, 57
xTimerStop
HeliOS.h, 57
xWord
HeliOS.h, 29