

Signal Processing Library

Function Reference Manual

Version 10.53

1 August, 2023

© 2023 Delta Numerix

Email: mailto:support@numerix-dsp.com
WWW: https://www.numerix-dsp.com/



Table of Contents

DOCUMENTATION OVERVIEW	25
Documentation Conventions	25
How To Use This Manual	25
SigLib Data Types	25
Siglib Data Types	20
FUNCTION DESCRIPTIONS	26
FREQUENCY DOMAIN FUNCTIONS	26
Fast Fourier Transform Functions (ffourier.c)	26
Radix-2 FFT Functions	
FFT Bit Reverse Addressing	
FFT Scaling (Radix-2 and Radix-4)	
SIF Fft	
SDA Rfft	
SDA Cfft	
SDA Cifft	
SDA BitReverseReorder	
SDA IndexBitReverseReorder	
SIF FastBitReverseReorder	
SDA_RealRealCepstrum	
SDA RealComplexCepstrum	
SDA_ComplexComplexCepstrum	
SIF FftTone	
SDA RfftTone	
SDA Rfftr	40
SIF Fft4	41
SDA_Rfft4	42
SDA_Cfft4	43
SDA_DigitReverseReorder4	44
SDA_IndexDigitReverseReorder4	45
SIF_FastDigitReverseReorder4	
SDA_Cfft2rBy1c	
SDA_Cfft2rBy1cr	
SDA_Cfft42rBy1c	49
SDA_Cfft42rBy1cr	
SDS_Cfft2	
SDA_Cfft2	
SDS_Cfft3	
SDA_Cfft3	54
Fourier Transform Functions (fourier c)	E
Fourier Transform Functions (fourier.c)	
SDA ZoomFft	
SIF ZoomFftSimple	
SDA ZoomEftSimple	60

SIF_FdHilbert	62
SDA_FdHilbert	63
SIF_FdAnalytic	64
SDA_FdAnalytic	65
SDA_InstantFreq	66
SDA_Rdft	67
SDA_Ridft	68
SDA_Cdft	69
SDA Cidft	70
SDA_FftShift	71
SDA CfftShift	72
SDA_FftExtend	73
SDA CfftExtend	74
SIF DctII	75
SDA DctII	76
SIF DctIIOrthogonal	77
SDA DctllOrthogonal	
_	
Arbitrary Length Fast Fourier Transform Functions (arbfft.c)	79
SIF_FftArb	79
SUF_FftArbAllocLength	80
SDA_RfftArb	81
SDA CfftArb	82
SDA CifftArb	83
_	
Power Spectrum Functions (pspect.c)	85
SIF_FastAutoCrossPowerSpectrum	
SDA_FastAutoPowerSpectrum	
SDA_FastCrossPowerSpectrum	
SIF_ArbAutoCrossPowerSpectrum	88
SDA_ArbAutoPowerSpectrum	89
SDA_ArbCrossPowerSpectrum	90
SIF_WelchPowerSpectrum	
SDA_WelchRealPowerSpectrum	92
SDA_WelchComplexPowerSpectrum	93
SIF_MagnitudeSquaredCoherence	94
SDA_MagnitudeSquaredCoherence	95
Frequency Domain Filtering Functions (fdfilter.c)	
SIF_FirOverlapAdd	
SDA_FirOverlapAdd	
SIF_FirOverlapSave	
SDA_FirOverlapSave	
SIF_FftConvolvePre	
SDA_FftConvolvePre	
SDA_FftConvolveArb	
SIF_FftCorrelatePre	
SDA_FftCorrelatePre	104
SDA_FftCorrelateArb	
	105
CHIRP Z-TRANSFORM FUNCTIONS (chirpz.c)	105 106
CHIRP Z-TRANSFORM FUNCTIONS (chirpz.c) SIF_Czt SIF Awn	105 106 107

SIF_VI	109
SIF Wm	110
_	
WINDOWING FUNCTIONS (window.c)	111
SIF_Window	111
SIF_TableTopWindow	112
SDA Window	113
SDA ComplexWindow	114
SDA WindowInverseCoherentGain	
SDA WindowEquivalentNoiseBandwidth	116
SDA WindowProcessingGain	
SDS I0Bessel	
_	
FIXED COEFFICIENT FILTER FUNCTIONS	119
FIR Filtering Functions (firfilt.c)	119
SIF_Fir	119
SDS Fir	120
SDA Fir	121
SDS FirAddSample	122
SDA FirAddSamples	
SIF Comb.	
SDS Comb	
SDA Comb	
SIF FirComplex	
SDS FirComplex	
SDA FirComplex	
SIF FirWithStore	
SDS FirWithStore	
-	
SDA_FirWithStore	
SIF_FirComplexWithStore	
SDS_FirComplexWithStore	
SDA_FirComplexWithStore	
SDS_FirAddSampleWithStore	
SDA_FirAddSamplesWithStore	
SIF_FirExtendedArray	
SDS_FirExtendedArray	
SDA_FirExtendedArray	
SIF_FirComplexExtendedArray	141
SDS_FirComplexExtendedArray	142
SDA_FirComplexExtendedArray	143
SDS_FirExtendedArrayAddSample	144
SDA_FirExtendedArrayAddSamples	145
SIF_FirLowPassFilter	
SIF_FirHighPassFilter	
SIF FirBandPassFilter	
SIF FirLowPassFilterWindow	
SIF_FirHighPassFilterWindow	
SIF FirBandPassFilterWindow	
SUF_FirKaiserApproximation	
SIF_FirMatchedFilter	
SDA_FirFilterInverseCoherentGain	
SIF_TappedDelayLine	155

SDS_TappedDelayLine	156
SDA_TappedDelayLine	157
SIF TappedDelayLineComplex	158
SDS_TappedDelayLineComplex	159
SDA TappedDelayLineComplex	
SIF TappedDelayLinelQ	
SDS TappedDelayLineIQ	
SDA_TappedDelayLineIQ	
SIF_FirPolyPhaseGenerate	
SIF FirZeroNotchFilter	
On _1 ii Zerorveterii iiter	
IIR Filtering Functions (iirfilt.c)	166
SIF lir	
SDS lir	
SDA lir	
SDS lirMac	
SDA lirMac	
SIF lirOrderN	
SDS lirOrderN	
—	
SDA_lirOrderN	
SIF_lirNc	
SDA_lirNc	
SDA_BilinearTransform	
SDS_PreWarp	
SDA_MatchedZTransform	
SDA_lirZplaneToCoeffs	
SDA_lirZplanePolarToCoeffs	
SDA_lirZplaneLpfToLpf	
SDA_lirZplaneLpfToHpf	184
SDA_lirZplaneLpfToBpf	185
SDA lirZplaneLpfToBsf	186
SDA lirModifyFilterGain	187
SIF_lirLowPassFilter	
SIF lirHighPassFilter	
SIF lirAllPassFilter	
SIF lirBandPassFilter	
SIF lirNotchFilter	
SIF lirPeakingFilter	
SIF lirLowShelfFilter	
SIF lirHighShelfFilter	
SDS lirRemoveDC	
SDA_lirRemoveDC	
SIF_OnePole	
SDS_OnePole	
SDA_OnePole	
SDS_OnePoleNormalized	
SDA_OnePoleNormalized	
SDS_OnePoleEWMA	
SDA_OnePoleEWMA	
SDA_OnePolePerSample	
SIF_OnePoleHighPass	
SDS_OnePoleHighPass	
SDA OnePoleHighPass	208

05, (_	6	201
	LinearMicrophoneArrayBeamPatternLinearMicrophoneArrayBeamPatternLinear	
	STIC PROCESSING FUNCTIONS (acoustic.c)	
_	•	
_	QFactorToBandwidth	
_	BandwidthToQFactor	
_	FrequenciesToQFactor	
	FrequenciesToCctavesFrequenciesToCentreFreqHz	
	FrequenciesToOctaves	
	EstimateBPFilterLength EstimateBPFilterError	
	ZTransformDB	
	ZTransform	
_	RootRaisedCosineFilter	
_	RaisedCosineFilter	
_	GaussianFilter2	
_	GaussianFilter	
	GoertzelDetectComplex	
	GoertzelDetectComplex	
	GoertzelDetect	
_	GoertzelDetect	
_	GoertzelFilter	
_	GoertzelFilter	
_	GoertzelFilter	
_	HilbertTransformer	
_	LeakyIntegrator2	
_	LeakyIntegrator1	
	_eakyIntegrator	
_	_Differentiate	
_	_Integrate	
	c Filtering Functions (filter.c)	
_		
_	lirNegateAlphaCoeffs	
_	lir2Pole	
_	lir2Pole	
_	ir2PoleLpf	
_	lirLpHpShift	
	lirLpLpShift	
_	_TranslateSPlaneCutOffFrequency	
_	irNormalizedSPlaneCoefficients	
	irNormalizedCoefficients	
	irNotchFilter2	
_	ZDomainCoefficientReorg	
	AllPole	
_	AllPole	
_	AllPole	
	AllPole	
	OnePoleHighPassCutOffFrequencyToFilterCoeff	
	OnePoleCutOffFrequencyToFilterCoeff	
_	OnePoleTimeConstantToFilterCoeff	
	OnePoleHighPassNormalizedOnePoleHighPassPerSample	
	OnePoleHighPassNormalized	

SDA_MicrophoneArrayCalculateDelays	258
SDA_MicrophoneArrayBeamPattern	259
SDA_MicrophoneArrayBeamPatternLinear	260
SDA_MicrophoneArrayBeamPatternLinear	
ADAPTIVE COEFFICIENT FILTER FUNCTIONS (adaptive.o	:)262
SIF_Lms	263
SDS Lms	264
SDA_LmsUpdate	265
SDA_LeakyLmsUpdate	
SDA NormalizedLmsUpdate	
SDA SignErrorLmsUpdate	
SDA SignDataLmsUpdate	
SDA SignSignLmsUpdate	
CONVOLUTION FUNCTIONS (convolve.c)	
SDA_ConvolveLinear	
SDA_ConvolvePartial	272
SDA_ConvolveCircular	273
SDA_ConvolveLinearComplex	274
SDA ConvolvePartialComplex	
SDA ConvolveCircularComplex	
SDA Deconvolution	
SIF FftDeconvolutionPre	
SDA FftDeconvolutionPre	
_	
CORRELATION FUNCTIONS (correlate.c)	
SDA_CorrelateLinear	280
SDA_CorrelatePartial	281
SDA CorrelateCircular	282
SDA Covariance	283
SDA CovariancePartial	
SDA_CorrelateLinearReturnPeak	
DELAY FUNCTIONS (delay.c)	298
DELAT TONOTIONS (delay.c)	200
Overview of SigLib delay functions	286
SIF_FixedDelay	286
SDS_FixedDelay	287
SDA_FixedDelay	288
SIF_FixedDelayComplex	
SDS_FixedDelayComplex	
SDA_FixedDelayComplex	
SDA_ShortFixedDelay	
SIF VariableDelay	
= -	
SDS_VariableDelay	
SDA_VariableDelay	
SIF_VariableDelayComplex	
SDS_VariableDelayComplex	
SDA_VariableDelayComplex	
SUF_IncreaseVariableDelay	
SUF_DecreaseVariableDelay	
SDA Align	301

IMAGE PROCESSING FUNCTIONS (image.c)	
SIM_Fft2d	
SIF_Fft2d	
SIM_Conv3x3	
SIM_Sobel3x3	306
SIM_SobelVertical3x3	307
SIM_SobelHorizontal3x3	308
SIM Median3x3	309
SIF ConvCoefficients3x3	310
SIM Max	
SIM_Min	312
IMAGE CODING FUNCTIONS (icoder.c)	313
SIF Dct8x8	
SIM Dct8x8	314
SIM Idct8x8	315
SIM ZigZagScan	
SIM ZigZagDescan	
_ 0 0	
SIGNAL GENERATION FUNCTIONS (siggen.c)	
SDA_SignalGenerate	
SDS_SignalGenerate	
SIF_Resonator	
SDA_Resonator	
SIF_Resonator1	
SDA_Resonator1	326
SDA_Resonator1Add	
SDA_SignalGeneratePolarWhiteNoise	328
SDS_SignalGeneratePolarWhiteNoise	329
SDA_SignalGeneratePolarGaussianNoise	330
SDS SignalGeneratePolarGaussianNoise	331
SDA SignalAddPolarJitterAndGaussianNoise	332
SDS SignalAddPolarJitterAndGaussianNoise	
SDA_Ramp	
SIF RandomNumber	
SDS RandomNumber	
SDA_RandomNumber	
COMMUNICATION FUNCTIONS	338
General Communications Functions (comms.c)	338
SDA BitErrorRate	
SDA Interleave	
SDA Deinterleave	
SCV_EuclideanDistance	
SCV_EuclideanDistanceSquared	
SCA EuclideanDistance	
SCA_LucidearibistanceSCA_EuclidearibistanceSquared	
SDS EuclideanDistance	
-	
SDS_EuclideanDistanceSquared	
SDA_EuclideanDistance	
SDA_EuclideanDistanceSquared	
SDS_ManchesterEncode	

SDS_ManchesterDecode	
SDS_ManchesterEncodeByte	351
SDS ManchesterDecodeByte	352
SIF_DetectNumericalWordSequence	353
SDS_DetectNumericalWordSequence	
SIF DetectNumericalBitSequence	
SDS_DetectNumericalBitSequence	
SIF_DetectCharacterSequence	
SDS_DetectCharacterSequence	
SDS ErrorVector	
SDS_ErrorVectorMagnitudePercent	
SDS_ErrorVectorMagnitudeDecibels	
SDS ReverseDiBits	
SDS_QpskBitErrorCount	
SDS BitErrorRate	
ODO_DILETOTALIC	
Communications Timing Detection Functions (timing.c)	365
SIF PhaseLockedLoop	
SDS_PhaseLockedLoop	
SDA_PhaseLockedLoop	
SIF CostasLoop	
SDS CostasLoop	
SDA CostasLoop	
SRF CostasLoop	
SIF 180DegreePhaseDetect	
SIF_180DegreePhaseDetect	
SIF_TriggerReverberator	
SDA_TriggerReverberator	
SDS_TriggerReverberator	
SDA TriggerSelector	
SIF EarlyLateGate	
SDA EarlyLateGate	
SDA_EarlyLateGate SDA EarlyLateGateDebug	
SDS EarlyLateGate	
SIF_EarlyLateGateSquarePulse	
SDA_EarlyLateGateSquarePulse	
SDA_EarlyLateGateSquarePulseDebugSDA_EarlyLateGateSquarePulseDebug	
SDS EarlyLateGateSquarePulse	
3D3_EarryLateGateSquareFulse	300
Convolutional Encode and Viterbi Decode Functions (viterbi.c.	389
SDS ConvEncoderK3	
SIF ViterbiDecoderK3	
SDS ViterbiDecoderK3	
SDS_ConvEncoderV32	
SIF ViterbiDecoderV32	
SDS ViterbiDecoderV32	
Analog Modulation Functions (mod_a.c)	396
SIF AmplitudeModulate	
SDA AmplitudeModulate	
SDS_AmplitudeModulate	
SIF_AmplitudeModulate2	
SDA AmplitudeModulate2	

	401
SIF_ComplexShift	402
SDA_ComplexShift	403
SIF FrequencyModulate	404
SDS_FrequencyModulate	405
SDA FrequencyModulate	
SDA_FrequencyDemodulate	
SIF_FrequencyModulateComplex	
SDS FrequencyModulateComplex	
SDA_FrequencyModulateComplex	
SDA DeltaModulate	
SDA DeltaDemodulate	
SDA DeltaModulate2	
SDA_Deitalviodulatez	413
Digital Modulation Functions (mod_d.c)	414
SIF CostasQamDemodulate	414
SDS CostasQamDemodulate	
SDS_CostasQamDemodulateDebug	
SDA CostasQamDemodulate	
SDA_CostasQamDemodulateDebug	
_	
SIF_QpskModulate	
SDA_QpskModulate	
SIF_QpskDemodulate	
SDA_QpskDemodulate	
SDA_QpskDemodulateDebug	
SDS_QpskDifferentialEncode	
SDS_QpskDifferentialDecode	431
Differential Encoder Introduction	422
Dilicicida Lilcodei illa oducaoli	
SIF_DifferentialEncoder	433
SIF_DifferentialEncoderSDS_DifferentialEncode	433 434
SIF_DifferentialEncoderSDS_DifferentialEncodeSDS_DifferentialDecode	433 434 435
SIF_DifferentialEncoderSDS_DifferentialEncodeSDS_DifferentialDecodeSIF_FskModulate	433 434 435 436
SIF_DifferentialEncoderSDS_DifferentialEncodeSDS_DifferentialDecodeSIF_FskModulateSDA_FskModulateByte	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulateByte	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulateByte SDA_FskModulateByte SDA_FskModulate SDA_FskDemodulate	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SIF_Qam16Modulate	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SDA_CpfskModulate SDA_Qam16Modulate SDA_Qam16Modulate	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SIF_Qam16Modulate	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SDA_CpfskModulate SDA_Qam16Modulate SDA_Qam16Modulate	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SIF_Qam16Modulate SIF_Qam16Modulate SIF_Qam16Modulate SIF_Qam16Demodulate	
SIF_DifferentialEncoder SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SDA_CpfskModulate SIF_Qam16Modulate SDA_Qam16Demodulate SIF_Qam16Demodulate SDA_Qam16Demodulate	
SIF_DifferentialEncode SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SDA_CpfskModulate SDA_Qam16Modulate SDA_Qam16Demodulate	433 434 435 436 437 438 439 440 441 441 442 443 443 444 445
SIF_DifferentialEncode SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SDA_CpfskModulate SIF_Qam16Modulate SIF_Qam16Demodulate SDA_Qam16Demodulate	433 434 435 436 437 438 439 440 441 442 443 444 445 445 446
SIF_DifferentialEncode SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_Qam16Modulate SIF_Qam16Modulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16DemodulateDebug SDA_Qam16DifferentialEncode SDA_Qam16DifferentialDecode SDA_Qam16DifferentialDecode SIF_OpskModulate	
SIF_DifferentialEncode SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SDA_CpfskModulate SDA_Qam16Modulate SIF_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16DifferentialEncode SDA_Qam16DifferentialDecode SDA_Qam16DifferentialDecode SDA_OpskModulate SDA_OpskModulate SDA_OpskModulate	433 434 435 436 437 438 439 440 441 442 443 444 445 445 445 446 447
SIF_DifferentialEncode SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SDA_Qam16Modulate SIF_Qam16Demodulate SIF_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16DifferentialEncode SDA_Qam16DifferentialDecode SDA_Qam16DifferentialDecode SIF_OpskModulate SDA_OpskModulate SDA_OpskModulate SIF_OpskDemodulate SIF_OpskDemodulate	433 434 435 436 437 438 439 440 441 442 443 444 445 445 446 447 450 451
SIF_DifferentialEncode SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SIF_Qam16Modulate SIF_Qam16Demodulate SIF_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16DifferentialEncode SDA_Qam16DifferentialDecode SDA_Qam16DifferentialDecode SDA_OpskModulate SDA_OpskDemodulate SIF_OpskDemodulate SDA_OpskDemodulate	433 434 435 436 437 438 439 440 441 442 443 444 445 445 446 447 448 449 450 451
SIF_DifferentialEncode SDS_DifferentialDecode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_FskModulate SDA_FskModulate SDA_FskDemodulate SDA_CpfskModulate SDA_CpfskModulate SIF_Qam16Modulate SIF_Qam16Modulate SIF_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16DifferentialEncode SDA_Qam16DifferentialDecode SDA_OpskModulate SIF_OpskModulate SDA_OpskDemodulate	433 434 435 436 437 438 439 440 441 441 442 443 444 445 445 445 450 451 452
SIF_DifferentialEncode SDS_DifferentialEncode SDS_DifferentialDecode SIF_FskModulate SDA_FskModulateByte SDA_FskDemodulateByte SDA_CpfskModulateByte SDA_FskModulate SDA_FskDemodulate SDA_FskDemodulate SDA_CpfskModulate SIF_Qam16Modulate SIF_Qam16Demodulate SIF_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16Demodulate SDA_Qam16DifferentialEncode SDA_Qam16DifferentialDecode SDA_Qam16DifferentialDecode SDA_OpskModulate SDA_OpskDemodulate SIF_OpskDemodulate SDA_OpskDemodulate	433 434 435 436 437 438 439 440 441 442 443 444 445 445 446 447 450 451 451 456

SDA_Bpski/iodulateByte	458
SIF_BpskDemodulate	459
SDA_BpskDemodulate	461
SDA_BpskDemodulateDebug	462
SIF_DpskModulate	
SDA DpskModulate	464
SDA DpskModulateByte	465
SIF DpskDemodulate	466
SDA DpskDemodulate	
SDA_DpskDemodulateDebug	
SIF PiByFourDQpskModulate	
SDA_PiByFourDQpskModulate	
SDS_ChannelizationCode	
SDA_ComplexQPSKSpread	
SDA ComplexQPSKDeSpread	
Modem Utility Functions (modem.c)	
SUF_AsyncCharacterLength	474
SDA_SyncToAsyncConverter	475
SDA_AsyncToSyncConverter	476
SIF_AsyncAddRemoveStopBits	477
SDA_AsyncRemoveStopBits	478
SDA_AsyncAddStopBits	479
SDA_DecreaseWordLength	480
SDA_IncreaseWordLength	
PRBS (prbs.c)	
SDS_Scrambler1417	
SDS_Descrambler1417	
SDS_Scrambler1417WithInversion	
SDS_Descrambler1417WithInversion	
SDS_Scrambler1823	486
SDS_Descrambler1823	487
SDS_Scrambler523	
SDS_Descrambler523	
SDS_ScramblerDescramblerPN9	490
SDS_SequenceGeneratorPN9	491
SDS_ScramblerDescramblerPN15	
SDS_SequenceGeneratorPN15	493
SDS_ScramblerDescramblergCRC24	494
SDS_SequenceGeneratorgCRC24	495
SDS_ScramblerDescramblergCRC16	496
SDS_SequenceGeneratorgCRC16	
SDS_ScramblerDescramblergCRC12	
SDS_SequenceGeneratorgCRC12	
SDS_ScramblerDescramblergCRC8	
SDS_SequenceGeneratorgCRC8	
SDS_LongCodeGenerator3GPPDL	
SDS LongCodeGenerator3GPPUL	
_ 0	
Multiplex Functions (mux.c)	504
SDA_Multiplex	

SDA Mux <i>N</i>	506
SDA DemuxN	
_	
Decimation And Interpolation Functions (decint.c).	
SIF_Decimate	
SDA_Decimate	
SIF_Interpolate	
SDA_Interpolate	
SIF_FilterAndDecimate	
SDA_FilterAndDecimate	
SIF_InterpolateAndFilter	514
SDA_InterpolateAndFilter	515
SDA_ResampleLinear	516
SDA_ResampleLinearNSamples	517
SDA_InterpolateLinear1D	518
SDA InterpolateLinear2D	
SIF ResampleSinc	520
SIF_ResampleWindowedSinc	
SDA ResampleSinc	
SDA_ResampleSincNSamples	
SIF InterpolateSinc1D	
SIF InterpolateWindowedSinc1D	
SDA InterpolateSinc1D	
SIF_ResampleLinearContiguous	
SDA_ResampleLinearContiguous	
SIF ResampleSincContiguous	
SIF_ResampleWindowedSincContiguous	
SDA_ResampleSincContiguous	
SDS InterpolateQuadratic1D	
SDS InterpolateQuadraticBSpline1D	
SDS_InterpolateQuadraticLagrange1D	
5D5_interpolateQuadraticLagrange1D	
DTMF Functions <i>(dtmf.c)</i>	537
SIF DtmfGenerate	
SDA DtmfGenerate	
SIF DtmfDetect	
SDA DtmfDetect	
SDA DtmfDetectAndValidate	
SUF_AsciiToKeyCode	
SUF KeyCodeToAscii	
501 <u>_</u> 110, 5000 10, 1001	
SPEECH PROCESSING FUNCTIONS (speech.c)	546
SIF_PreEmphasisFilter	
SDA PreEmphasisFilter	
SIF DeEmphasisFilter	
SDA_DeEmphasisFilter	
SDA_AdpcmEncoder	
SDA AdpcmEncoderDebug	
SDA AdpcmDecoder	
MINIMUM AND MAXIMUM FUNCTIONS (minmax.c).	553
SDA_Max	
SDA AbsMax	

SDA_	_IVIIN	.555
SDA	AbsMin	.556
SDA	Middle	557
_	Range	
_	MaxIndex	
_	AbsMaxIndex	
_	-	
_	_MinIndex	
_	_AbsMinIndex	
_	_Max	
_	_AbsMax	
SDS_	_Min	.565
SDS	AbsMin	.566
SDA	LocalMax	.567
_	_ LocalAbsMax	
_	LocalMin	
_	LocalAbsMin	
_	Max2	
_	-	
	_AbsMax2	
	_SignedAbsMax2	
_	_Min2	
	_AbsMin2	
SDA_	SignedAbsMin2	.576
SDA	PeakHold	.577
SDA	PeakHoldPerSample	.578
_	 DetectFirstPeakOverThreshold	
_	Round	
_	Round	
_	Clip	
_	- '	
	_Clip	
_	_Threshold	
_	_Threshold	
_	_SoftThreshold	
SDA_	_SoftThreshold	.587
SDS_	_ThresholdAndClamp	.588
SDA	ThresholdAndClamp	.589
SDS	_Clamp	.590
	 _Clamp	
	TestOverThreshold	
	_TestAbsOverThreshold	
	SelectMax	
	SelectMin	
_	_SelectMagnitudeSquaredMax	
	_SelectMagnitudeSquaredMin	
_	_SetMinValue	
_	_SetMinValue	
SDA_	_PeakToAverageRatio	.600
SDA	PeakToAveragePowerRatio	.601
_	PeakToAveragePowerRatioDB	
_	_ PeakToAverageRatioComplex	
	PeakToAveragePowerRatioComplex	
_	PeakToAveragePowerRatioDB	
_	MovePeakTowardsDeadBand	
_	Envelope	
O11 _E	-118 GIOPO	.007

SDS_Envelope	608
SDA_Envelope	609
SIF_EnvelopeRMS	610
SDS_EnvelopeRMS	611
SDA EnvelopeRMS	612
SIF EnvelopeHilbert	613
SDS_EnvelopeHilbert	614
SDA EnvelopeHilbert	
SDS_InterpolateThreePointQuadraticVertexMagnitude	
SDS_InterpolateThreePointQuadraticVertexLocation	
SDS_InterpolateArbitraryThreePointQuadraticVertexMagnitude	
SDS_InterpolateArbitraryThreePointQuadraticVertexLocation	
SDA_InterpolateThreePointQuadraticVertexMagnitude	
SDA_InterpolateThreePointQuadraticVertexLocation	621
SDA_InterpolateArbitraryThreePointQuadraticVertexMagnitude	
SDA_InterpolateArbitraryThreePointQuadraticVertexLocation	
SDA InterpolateArbitraryThreePointQuadraticPeakVertexMagnitude.	
SDA_InterpolateArbitraryThreePointQuadraticPeakVertexLocation	
SDA_interpolateArbitraryThreePointQuadraticFeakVertexLocation	
SDA_FirstMinVertexSDA_FirstMinVertexPos	
–	
SDA_FirstMaxVertex	
SDA_FirstMaxVertexPos	
SDA_NCreations	
SDA_NSmallest	631
MATH FUNCTIONS (smath.c)	632
SDA Divide	
–	
SDA_Divide2	633
SDA_Divide2SDA_Multiply	633 634
SDA_Divide2SDA_MultiplySDA_Multiply2	633 634 635
SDA_Divide2SDA_MultiplySDA_Multiply2SDS_ComplexMultiply2SDS_ComplexMultiplySDS_ComplexMultiply	633 634 635 636
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse.	633 634 635 636
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse	633 634 635 636 637
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDS_ComplexDivide	633 634 635 636 637 638
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply	633 634 635 636 637 638 639
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDS_ComplexInverse SDS_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexMultiply2	633 634 635 636 638 639 640
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDS_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexScalarDivide SDA_ComplexScalarDivide	633 634 635 636 638 639 640 641 642
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexScalarDivide SDA_ComplexScalarDivide SDA_ComplexScalarDivide SDA_ComplexScalarDivide	633 634 635 636 637 639 640 641 642
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexMultiply2 SDA_ComplexScalarDivide SDA_ComplexScalarDivide SDA_ComplexScalarDivide SDA_ComplexDivide2 SDA_RealDotProduct	633 634 635 636 638 639 641 642 643
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexScalarMultiply SDA_ComplexScalarDivide SDA_ComplexScalarDivide SDA_ComplexDivide2 SDA_RealDotProduct SDA_ComplexDotProduct	633 634 635 636 638 640 641 642 643 644 645
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexMultiply2 SDA_ComplexScalarDivide SDA_ComplexDivide2 SDA_RealDotProduct SDA_ComplexDotProduct SDA_SumAndDifference	633 634 635 637 638 640 641 642 643 645 646
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexScalarMultiply2 SDA_ComplexScalarDivide SDA_ComplexScalarDivide SDA_ComplexDivide2 SDA_RealDotProduct SDA_ComplexDotProduct SDA_SumAndDifference SDA_AddN	633 634 635 636 638 639 641 642 643 645 646
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexMultiply2 SDA_ComplexScalarDivide SDA_ComplexDivide2 SDA_RealDotProduct SDA_ComplexDotProduct SDA_SumAndDifference SDA_AddN SDA_WeightedSum	633 634 635 636 637 639 641 642 643 645 645 647
SDA_Divide2. SDA_Multiply. SDA_Multiply2. SDS_ComplexMultiply. SDS_ComplexInverse. SDA_ComplexInverse. SDA_ComplexDivide. SDA_ComplexScalarMultiply. SDA_ComplexScalarDivide. SDA_ComplexScalarDivide. SDA_ComplexDivide2. SDA_RealDotProduct. SDA_ComplexDotProduct. SDA_SumAndDifference. SDA_AddN. SDA_WeightedSum. SDA_Subtract2.	633 634 635 637 639 640 641 643 645 646 648 648
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexScalarDivide SDA_ComplexScalarDivide SDA_ComplexDivide2 SDA_RealDotProduct SDA_ComplexDotProduct SDA_SumAndDifference SDA_AddN SDA_WeightedSum SDA_Subtract2 SDA_Add	633 634 635 637 639 640 641 642 643 645 646 647 648 649
SDA_Divide2. SDA_Multiply. SDA_Multiply2. SDS_ComplexMultiply. SDS_ComplexInverse. SDA_ComplexDivide SDA_ComplexScalarMultiply. SDA_ComplexScalarMultiply. SDA_ComplexScalarDivide. SDA_ComplexScalarDivide. SDA_ComplexDivide2 SDA_RealDotProduct. SDA_ComplexDotProduct. SDA_SumAndDifference. SDA_AddN. SDA_WeightedSum. SDA_Subtract2. SDA_Add. SDA_PositiveOffset.	633 634 635 636 639 640 641 643 645 645 646 647 648 649 650
SDA_Divide2. SDA_Multiply. SDA_Multiply2. SDS_ComplexMultiply. SDS_ComplexInverse. SDA_ComplexDivide. SDA_ComplexScalarMultiply. SDA_ComplexScalarDivide. SDA_ComplexScalarDivide. SDA_ComplexScalarDivide. SDA_ComplexDivide2. SDA_RealDotProduct. SDA_ComplexDotProduct. SDA_SumAndDifference. SDA_AddN. SDA_WeightedSum. SDA_Subtract2. SDA_Add. SDA_PositiveOffset. SDA_NegativeOffset.	633634635637638639640641642643645646645646
SDA_Divide2 SDA_Multiply SDA_Multiply2 SDS_ComplexMultiply SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexDivide SDA_ComplexScalarMultiply SDA_ComplexScalarMultiply2 SDA_ComplexScalarDivide SDA_ComplexDivide2 SDA_RealDotProduct SDA_ComplexDotProduct SDA_SumAndDifference SDA_AddN SDA_WeightedSum SDA_Subtract2 SDA_Add SDA_PositiveOffset SDA_Negate	633634635637638639641642643645646645650651
SDA_Divide2 SDA_Multiply. SDA_Multiply2 SDS_ComplexMultiply. SDS_ComplexInverse. SDA_ComplexInverse. SDA_ComplexDivide. SDA_ComplexScalarMultiply. SDA_ComplexScalarDivide. SDA_ComplexScalarDivide. SDA_ComplexDivide2. SDA_RealDotProduct. SDA_ComplexDotProduct. SDA_SumAndDifference. SDA_AddN. SDA_WeightedSum. SDA_Subtract2. SDA_Add. SDA_PositiveOffset. SDA_NegativeOffset. SDA_Negate. SDA_Inverse.	633 634 635 636 639 640 641 643 645 645 646 646 651 651 653 654
SDA_Divide2 SDA_Multiply. SDA_Multiply2 SDS_ComplexMultiply. SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexScalarMultiply. SDA_ComplexScalarMultiply. SDA_ComplexScalarDivide. SDA_ComplexScalarDivide. SDA_ComplexDivide2 SDA_RealDotProduct. SDA_ComplexDotProduct. SDA_SumAndDifference. SDA_AddN. SDA_WeightedSum. SDA_Subtract2 SDA_Add. SDA_PositiveOffset. SDA_NegativeOffset. SDA_Negate. SDA_Inverse. SDA_Inverse. SDA_Square.	633634635636637638640641642643645646645651652653
SDA_Divide2 SDA_Multiply. SDA_Multiply2 SDS_ComplexMultiply. SDS_ComplexInverse. SDA_ComplexInverse. SDA_ComplexDivide. SDA_ComplexScalarMultiply. SDA_ComplexScalarDivide. SDA_ComplexScalarDivide. SDA_ComplexDivide2. SDA_RealDotProduct. SDA_ComplexDotProduct. SDA_SUMAndDifference. SDA_MeightedSum. SDA_WeightedSum. SDA_Subtract2. SDA_Add. SDA_PositiveOffset. SDA_Negate. SDA_Negate. SDA_Inverse. SDA_Square. SDA_Sqrt.	633634635637638639640641642643645646645650651653
SDA_Divide2 SDA_Multiply. SDA_Multiply2 SDS_ComplexMultiply. SDS_ComplexInverse SDA_ComplexInverse SDA_ComplexScalarMultiply. SDA_ComplexScalarMultiply. SDA_ComplexScalarDivide. SDA_ComplexScalarDivide. SDA_ComplexDivide2 SDA_RealDotProduct. SDA_ComplexDotProduct. SDA_SumAndDifference. SDA_AddN. SDA_WeightedSum. SDA_Subtract2 SDA_Add. SDA_PositiveOffset. SDA_NegativeOffset. SDA_Negate. SDA_Inverse. SDA_Inverse. SDA_Square.	633 634 635 636 637 638 640 641 643 645 645 646 651 651 653 654 655 656

	_	Roots	
	SDS	Factorial	.660
	SDS	Permutations	661
	SDS	Combinations	.662
	SIF	OverlapAndAddLinear	.663
	_	Overlap And Add Linear	
		OverlapAndAddLinearWithClip	
		OverlapAndAddArbitrary	
		OverlapAndAddArbitraryWithClip	
		DegreesToRadians	
	_	DegreesToRadians	
		RadiansToDegrees	
		RadiansToDegrees	
	_	DetectNAN	
	_		
	SDA_	_DetectNAN	.073
ח	SD 117	FILITY FUNCTIONS (dsputils.c)	67/
		Rotate	
	_	Reverse	
	_		
	_	Scale	
	_	MeanSquare	
	_	MeanSquareError	
	_	RootMeanSquare	
	_	Magnitude	
	_	MagnitudeSquared	
	SDS_	Magnitude	.682
		MagnitudeSquared	
	_	Phase	
		PhaseWrapped	
		PhaseUnWrapped	
	_	_MagnitudeAndPhaseWrapped	
		MagnitudeAndPhaseUnWrapped	
	SDA_	MagnitudeSquaredAndPhaseWrapped	.689
	SDA_	MagnitudeSquaredAndPhaseUnWrapped	.690
	SDA	PhaseWrap	691
		PhaseUnWrap	
		_Log2	
		 Log2	
	SDS	LogN	695
		LogN	
	_	LogDistribution	
	_	Сору	
	SDA	CopyWithStride	699
		CopyWithOverlap	
		CopyWithOverlap	
		CopyWithIndex	
		CopyWithIndex	
		20Log10	
	_	10Log10	
		LogMagnitude	
		LogMagnitudeLogMagnitudeAndPhaseWrapped	
	_	• • •	
		LogMagnitudeAndPhaseUnWrapped	
	SUA_	Lengthen	. 1 09

SDA	_Shorten	710
	_ ReSize	
_	ReSize	
	ReSizeInput	
-	ReSizeOutput	
	Clear	
-	gram Functions	
	Histogram	
	Histogram	
	_riistogramCumulative	
_	_	
-	_HistogramExtended	
	_HistogramExtendedCumulative	
-	_HistogramEqualize	
-	_Quantize	
	_Quantize	
	_Quantize_N	
-	_Quantize_N	
_	_Abs	
_	_PeakValueToBits	
-	_BitsToPeakValue	
SDS ₋	_VoltageTodBm	733
	_VoltageTodBm	
-	_dBmToVoltage	
	_dBmToVoltage	
	_VoltageTodB	
	_VoltageTodB	
-	_dBToVoltage	
	_dBToVoltage	
SDS	_PowerTodB	741
SDA	_PowerTodB	742
SDS	_dBToPower	743
SDA	dBToPower	744
SDS	Compare	745
	Compare	
SDS	 _CompareComplex	747
	CompareComplex	
	_ 	
	_ _AbsFrac	
	 Int	
	 Frac	
	 _AbsFrac	
	_SetMin	
	SetMax	
-	_SetRange	
	SetMean	
רעכ		
DSP U	TILITY FUNCTIONS (dsputil2.c)	759
	RealSpectralInverse	
	ComplexSpectralInverse	
-		
	FdInterpolate2	

SDS_TdPitchShift	763
SDA TdPitchShift	764
SDS EchoGenerate	765
SDA Power	766
SDS Polynomial	
SDA Polynomial	
SDS Modulo	
SDA Modulo	
<u> </u>	
Automatic Gain Control Functions	771
SDA_AgcPeak	
SIF AgcMeanAbs	
SDA AgcMeanAbs	
SIF_AgcMeanSquared	
SDA AgcMeanSquared	
SIF AgcEnvelopeDetector	
SDS AgcEnvelopeDetector	
SDA_AgcEnvelopeDetector	
SIF Drc	
SDS Drc	
SDA Drc	
-	
SDA_GroupDelay	
SDA_ZeroCrossingDetect	
SDS_ZeroCrossingDetect	
SDA_FirstZeroCrossingLocation	
SDA_ZeroCrossingCount	
SDA_LevelCrossingDetect	
SDS_LevelCrossingDetect	
SDA_FirstLevelCrossingLocation	
SDA_LevelCrossingCount	
SDA_ClearLocation	
SDA_SetLocation	
SDA_SortMinToMax	
SDA_SortMaxToMin	
SDA_SortMinToMax2	
SDA_SortMaxToMin2	
SDA_SortIndexed	
SDS_CountOneBits	
SDS_CountZeroBits	
SDS_CountLeadingOneBits	
SDS_CountLeadingZeroBits	803
SDA_Sign	804
SDA_Swap	805
SUF_ModuloIncrement	806
SUF_ModuloDecrement	807
SUF_IndexModuloIncrement	
SUF_IndexModuloDecrement	
SDA_Find	
SDA FindValue	
_	, , ,
DSP UTILITY FUNCTIONS (dsputil3.c)	812
SIF_DeGlitch	
SDS DeGlitch	813

SDA_DeGlitch	814
SDA_RemoveDuplicates	815
SDA_FindAllDuplicates	816
SDA FindFirstDuplicates	
SDA FindSortAllDuplicates	818
SDA FindSortFirstDuplicates	819
SDA_Shuffle	820
SDA InsertSample	
SDA InsertArray	
SDA_ExtractSample	
SDA_ExtractArrayٰ	
DATA TUBE CONVERGION FUNCTIONS (datate	
DATA TYPE CONVERSION FUNCTIONS (dataty	
SDA_SigLibDataToFix	
SDA_FixToSigLibData	
SDA_SigLibDataToImageData	
SDA_ImageDataToSigLibData	
SDA_SigLibDataToFix16	
SDA_Fix16ToSigLibData	
SDA_SigLibDataToFix32	
SDA_Fix32ToSigLibData	
SDS_SigLibDataToQFormatInteger	
SDS_QFormatIntegerToSigLibData	
SDA_SigLibDataToQFormatInteger	
SDA_QFormatIntegerToSigLibData	836
CONTROL FUNCTIONS (control.c)	837
SDS Pid	
SDA_Pwm	
ODDED ANALYSIS FUNCTIONS (and an a)	000
ORDER ANALYSIS FUNCTIONS (order.c)	
SDA_ExtractOrder	
SDA_SumLevel	
SDA_SumLevelWholeSpectrum	
SIF_OrderAnalysis	
SDA_OrderAnalysis	843
STATISTICS FUNCTIONS (stats.c)	845
SDA Sum	
SDA AbsSum	
SDA_SumOfSquares	
SDA Mean	
SDA AbsMean	
SDA_SubtractMean	
SDA SubtractMax	
SDA SampleSd	
SDA_PopulationSd	
SDA UnbiasedVariance	
SDA Median	
_	
REGRESSION ANALYSIS FUNCTIONS (regress	
SDA_LinraConstantCoeff	
SDA LinraRegressionCoeff	857

	SDA_LinraCorrelationCoeff	
	SDA_LinraEstimateX	
	SDA_LinraEstimateY	
	SDA_LograConstantCoeff	861
	SDA LograRegressionCoeff	862
	SDA_LograCorrelationCoeff	
	SDA_LograEstimateX	
	SDA_LograEstimateY	
	SDA_ExpraConstantCoeff	866
	SDA ExpraRegressionCoeff	
	SDA_ExpraCorrelationCoeff	
	SDA_ExpraEstimateX	
	SDA_ExpraEstimateY	
	SDA_ExpraEstiliate1	
	—	
	SDA_PowraCorrelationCoeff	
	SDA_PowraCorrelationCoeff	
	SDA_PowraEstimateX	
	SDA_PowraEstimateY	
	SDA_Detrend	
	SDA_ExtractTrend	877
_		
T	RIGONOMETRIC FUNCTIONS (trig.c)	
	SDA_Sin	
	SDA_Cos	
	SDA_Tan	
	SIF_FastSin	
	SDA_FastSin	882
	SDS_FastSin	883
	SIF_FastCos	884
	SDA FastCos	885
	SDS FastCos	886
	SIF FastSinCos	887
	SDA FastSinCos	888
	SDS FastSinCos.	
	SIF QuickSin	
	SDA_QuickSin	
	SDS QuickSin	
	SIF QuickCos	
	SDA QuickCos	
	SDS QuickCos	
	SIF QuickSinCos	
		
	SDA_QuickSinCos	
	SDS_QuickSinCos	
	SIF_QuickTan	
	SDA_QuickTan	
	SDS_QuickTan	
	SDA_Sinc	
	SDS_Sinc	
	SIF_QuickSinc	
	SDA_QuickSinc	
	SDS_QuickSinc	906
_		<i>-</i> -
C	OMPLEX VECTOR FUNCTIONS (complex c)	907

	_Polar	
SCV	_Rectangular	908
SCV	PolarToRectangular	909
	 RectangularToPolar	
	' Inverse	
	 Conjugate	
	Magnitude	
	_MagnitudeSquared	
	Phase	
	Multiply	
	_iwditipiy	
	_Divide	
	Subtract	
	_Log Exp	
	- '	
	_Expj	
	_Pow	
	_VectorAddScalar	
	_VectorSubtractScalar	
	_VectorMultiplyScalar	
	_VectorDivideScalar	
	_ScalarSubtractVector	
	_Roots	
	_Copy	
SCV	_Compare	932
00140	NEV ADDAY FUNCTIONS (seems/see s)	000
CUMP		
	PLEX ARRAY FUNCTIONS (complexa.c)	
SDA	_CreateComplexRect	933
SDA SDA	_CreateComplexRect	933 934
SDA SDA SDA	_CreateComplexRect	933 934 935
SDA SDA SDA SDA	_CreateComplexRect	933 934 935
SDA SDA SDA SDA	_CreateComplexRect	933 934 935 936
SDA SDA SDA SDA SDA	_CreateComplexRect	933 934 935 936 937 938
SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexRectExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRect	933 934 935 936 938 939
SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexPolar	933 934 935 936 937 938 939
SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexRectClearComplexRectClearComplexPolarFillComplexRectFillComplexPolarComplexPolarComplexPolar	933 934 935 936 937 938 939 940
SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexRectFillComplexPolarComplexPolarComplexPolarComplexRectangularToPolar	933 934 936 937 938 940 941
SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexRectFillComplexPolarComplexPolarComplexPolarComplexPolarToPolarComplexPolarToPolarRectangularToPolar	933 934 935 936 937 938 939 940 941 942
SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexRectFillComplexPolarComplexPolarComplexPolarComplexRectangularToPolar	933 934 935 936 937 938 939 940 941 942
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexRectFillComplexPolarComplexPolarComplexPolarComplexPolarToPolarComplexPolarToPolarRectangularToPolar	933 934 935 936 937 938 940 941 941 943
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexPolarClearComplexPolarFillComplexPolarFillComplexPolarComplexPolarComplexRectangularToPolarComplexPolarToRectangularPolarToRectangular.	933 934 935 936 937 938 940 941 941 943
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexRectFillComplexPolarComplexPolarComplexRectangularToPolarComplexPolarToRectangularRectangularToPolarPolarToRectangularComplexRectSqrt	933 934 935 936 937 939 940 941 942 943 945
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexPolarClearComplexPolarFillComplexPolarFillComplexPolarComplexPolarComplexRectangularToPolarComplexPolarToRectangularRectangularToPolarPolarToRectangularComplexRectSqrtComplexRectInverseComplexRectConjugate.	933 934 935 936 937 938 940 941 942 943 944 945
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexRectFillComplexPolarComplexRectangularToPolarComplexPolarToRectangularRectangularToPolarPolarToRectangularComplexRectSqrtComplexRectInverseComplexRectConjugateComplexRectMagnitude	933 934 935 936 937 938 940 941 942 943 944 945 947
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexPolarClearComplexPolarClearComplexPolarFillComplexPolarFillComplexPolarComplexPolarComplexRectangularToPolarComplexPolarToRectangularRectangularToPolarPolarToRectangularComplexRectSqrtComplexRectInverseComplexRectConjugate.	933 934 935 936 937 938 940 941 942 943 945 945 946 948
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	CreateComplexRectCreateComplexPolarExtractComplexRectExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexPolarComplexPolarComplexPolarToPolarComplexPolarToRectangularRectangularToPolarPolarToRectangularComplexRectSqrtComplexRectInverseComplexRectConjugateComplexRectMagnitude	933 934 935 936 937 938 940 941 943 944 945 946 947 949
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	CreateComplexRect. CreateComplexPolar. ExtractComplexRect. ExtractComplexPolar. ClearComplexRect. ClearComplexPolar. FillComplexRect. FillComplexPolar. ComplexPolar. ComplexRectangularToPolar. ComplexPolarToRectangular. RectangularToPolar. PolarToRectangular. ComplexRectSqrt. ComplexRectSqrt. ComplexRectConjugate. ComplexRectMagnitude. ComplexRectMagnitudeSquared. ComplexRectPhase. ComplexRectPhase. ComplexRectMultiply.	933 934 935 936 937 939 940 941 942 943 944 945 946 947 948 950
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRectCreateComplexPolarExtractComplexRectExtractComplexPolarClearComplexRectClearComplexPolarFillComplexRectFillComplexPolarComplexPolarComplexRectangularToPolarComplexPolarToRectangularRectangularToPolarPolarToRectangularComplexRectSqrtComplexRectSqrtComplexRectConjugateComplexRectMagnitudeComplexRectMagnitudeSquaredComplexRectPhaseComplexRectMultiplyComplexRectDivide	933 934 935 936 937 938 940 941 942 943 945 945 948 949 950
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	CreateComplexRectCreateComplexPolarExtractComplexRectExtractComplexPolarClearComplexPolarClearComplexPolarFillComplexRectFillComplexPolarComplexRectangularToPolarComplexPolarToRectangularRectangularToPolarComplexRectSqrtComplexRectSqrtComplexRectConjugateComplexRectMagnitudeComplexRectMagnitudeSquaredComplexRectPhaseComplexRectMultiplyComplexRectDivideComplexRectAdd.	933 934 935 936 937 938 949 941 942 943 944 945 946 947 949 950 951
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRect _CreateComplexPolar _ExtractComplexRect _ExtractComplexPolar _ClearComplexPolar _FillComplexRect _FillComplexRect _FillComplexPolar _ComplexRectangularToPolar _ComplexPolarToRectangular _RectangularToPolar _PolarToRectangular _ComplexRectSqrt _ComplexRectInverse _ComplexRectMagnitude _ComplexRectMagnitude _ComplexRectMagnitude _ComplexRectMagnitudeSquared _ComplexRectMultiply _ComplexRectMultiply _ComplexRectAdd _ComplexRectAdd _ComplexRectSubtract	933 934 935 936 937 939 940 941 942 943 944 945 946 947 950 951 953
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRect _CreateComplexPolar _ExtractComplexRect _ExtractComplexPolar _ClearComplexPolar _FillComplexRect _FillComplexRect _FillComplexPolar _ComplexRectangularToPolar _ComplexPolarToRectangular _RectangularToPolar _PolarToRectangular _ComplexRectSqrt _ComplexRectConjugate _ComplexRectMagnitude _ComplexRectMagnitudeSquared _ComplexRectPhase _ComplexRectMultiply _ComplexRectDivide _ComplexRectAdd _ComplexRectSubtract _ComplexRectLog _ComplexRectLog _ComplexRectLog _ComplexRectLog _ComplexRectLog	933 934 935 936 937 938 940 941 942 943 945 945 945 951 951 953
SDA SDA SDA SDA SDA SDA SDA SDA SDA SDA	_CreateComplexRect _CreateComplexPolar _ExtractComplexRect _ExtractComplexPolar _ClearComplexPolar _FillComplexRect _FillComplexRect _FillComplexPolar _ComplexRectangularToPolar _ComplexPolarToRectangular _RectangularToPolar _PolarToRectangular _ComplexRectSqrt _ComplexRectInverse _ComplexRectMagnitude _ComplexRectMagnitude _ComplexRectMagnitude _ComplexRectMagnitudeSquared _ComplexRectMultiply _ComplexRectMultiply _ComplexRectAdd _ComplexRectAdd _ComplexRectSubtract	933 934 935 936 937 938 949 941 943 944 945 946 947 948 949 950 951 952 953

SDA_ComplexRectPow	
SDA_ComplexRectAddScalar	959
SDA_ComplexRectSubtractScalar	960
SDA ComplexRectMultiplyScalar	961
SDA_ComplexRectDivideScalar	962
SDA ComplexScalarSubtractRect	
SDA_ComplexRectLinearInterpolate	
SDA ComplexPolarLinearInterpolate	
'	
MATRIX VECTOR FUNCTIONS (matrix.c)	966
SMX Transpose	
SMX Multiply	
SMX_CreateIdentity	969
SMX Inverse2x2	
SMX ComplexInverse2x2	971
SMX Inverse	
SMX_LuDecompose	973
SMX LuSolve	974
SMX Determinant	975
SMX LuDeterminant	
SMX RotateClockwise	
SMX RotateAntiClockwise	
SMX Reflect	979
SMX Flip	980
SMX InsertRow	
SMX ExtractRow	
SMX InsertColumn	
SMX ExtractColumn	
SMX InsertNewRow	985
SMX DeleteOldRow	
SMX InsertNewColumn	
SMX DeleteOldColumn	
SMX InsertRegion	
SMX_ExtractRegion	990
SMX InsertDiagonal	
SMX_ExtractDiagonal	
SMX_SwapRows	
SMX SwapColumns	
SMX Sum	
SMX ShuffleColumns	
SMX ShuffleRows	
SMX_ExtractCategoricalColumn	
g	
MATRIX VECTOR MACROS	999
SMX_Copy	999
SMX_Add	
SMX_Subtract	1001
SMX_MultiplyPiecewise	
SMX_ScalarMultiply	
_ · ·	
Machine Learning Functions	1004
SDA_TwoLayer2CategoryNetworkFit	
SDA TwoLayer2CategoryNetworkPredict	1006

SDA_TwoLayerNCategoryNetworkFit	1007
SDA_TwoLayerNCategoryNetworkPredict	1008
SDA_TwoLayer2CategoryWithBiasesNetworkFit	
SDA_TwoLayer2CategoryWithBiasesNetworkPredict	
SDA_TwoLayerNCategoryWithBiasesNetworkFit	
SDA_TwoLayerNCategoryWithBiasesNetworkPredict	
SDS ActivationReLU	
SDA ActivationReLU	
SDS_ActivationReLUDerivative	
SDA ActivationReLUDerivative	
—	
SDS_ActivationLeakyReLU	
SDA_ActivationLeakyReLU	
SDS_ActivationLeakyReLUDerivative	
SDA_ActivationLeakyReLUDerivative	
SDS_ActivationLogistic	
SDA_ActivationLogistic	
SDS_ActivationLogisticDerivative	1023
SDA_ActivationLogisticDerivative	1024
SDS_ActivationTanH	1025
SDA ActivationTanH	
SDS ActivationTanHDerivative	
SDA ActivationTanHDerivative	
UTILITY FUNCTIONS (siglib.c)	1029
SUF_SiglibVersion	
SUF_PrintArray	
SUF PrintFixedPointArray	
SUF_PrintComplexArray	
SUF PrintMatrix	
SUF_PrintPolar	
SUF_PrintRectangular	
SUF_PrintIIRCoefficients	
SUF_PrintCount	
SUF_PrintHigher	
SUF_PrintLower	
SUF_ClearDebugfprintf	
SUF_Debugfprintf	
SUF_Debugvfprintf	
SUF_DebugPrintArray	1043
SUF_DebugPrintFixedPointArray	1044
SUF_DebugPrintComplexArray	1045
SUF_DebugPrintComplex	1046
SUF_DebugPrintComplexRect	
SUF_DebugPrintComplexPolar	
SUF_DebugPrintMatrix	
SUF_DebugPrintPolar	
SUF_DebugPrintRectangular	
SUF_DebugPrintIIRCoefficients	
SUF_DebugPrintCount	
SUF_DebugPrintHigher	
SUF DebugPrintLower	
_ •	
SUF_DebugPrintInfo	
SUF_DebugPrintLine	1057

SUF_DebugPrintTime	1058
SUF_PrintRectangular	1059
SUF_PrintPolar	
SUF_DebugPrintRectangular	
SUF DebugPrintPolar	
SUF_MSDelay	
SUF StrError	
SUF DebugPrintMatrix	
SUF DebugPrintPolar	
SUF_DebugPrintRectangular	
SUF_DebugPrintIRCoefficients	
SUF_DebugPrintCount	
SUF_DebugPrintHigher	
SUF_DebugPrintLower	
SUF_DebugPrintInfo	
SUF_DebugPrintLine	
SUF_DebugPrintTime	
SUF_PrintRectangular	
SUF_PrintPolar	
SUF_DebugPrintRectangular	1078
SUF_DebugPrintPolar	1079
SUF_MSDelay	1080
SUF StrError	1081
_	
File Input/Output Functions (file_io.c)	1082
Data File Formats	
SUF BinReadData	1083
-	
SUF_BinWriteData	
-	1084
SUF_BinWriteData	1084 1085
SUF_BinWriteDataSUF_BinReadFile	1084 1085 1086
SUF_BinWriteDataSUF_BinReadFileSUF_BinWriteFile	1084 1085 1086 1087
SUF_BinWriteDataSUF_BinReadFileSUF_BinWriteFileSUF_PCMReadData	1084 1085 1086 1087
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData	1084 1085 1086 1087 1088
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMReadFile SUF_PCMWriteFile	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMReadFile SUF_PCMWriteFile SUF_CsvReadData	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMReadFile SUF_CMWriteFile SUF_CsvReadData SUF_CsvWriteData	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMReadFile SUF_CsvReadData SUF_CsvReadData SUF_CsvReadData SUF_CsvReadFile	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMWriteFile SUF_CsvReadData SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvWriteFile	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMReadFile SUF_CsvReadData SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvReadFile SUF_CsvReadMatrix	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMReadFile SUF_PCMWriteData SUF_CSVReadData SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvReadFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteMatrix	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMWriteFile SUF_CsvReadData SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteMatrix SUF_CsvWriteMatrix SUF_DatReadData	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMWriteFile SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvReadFile SUF_CsvReadFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteMatrix SUF_CsvWriteMatrix SUF_DatReadData SUF_DatWriteData	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMReadFile SUF_PCMWriteData SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvReadFile SUF_CsvReadMatrix SUF_CsvWriteMatrix SUF_DatReadData SUF_DatReadHeader	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMReadFile SUF_PCMWriteData SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteMatrix SUF_CsvWriteMatrix SUF_DatReadData SUF_DatReadHeader SUF_DatWriteHeader	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMWriteData SUF_PCMWriteFile SUF_CsvReadData SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteData SUF_CsvReadFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteMatrix SUF_CsvWriteMatrix SUF_DatReadData SUF_DatReadHeader SUF_DatWriteHeader SUF_DatWriteHeader SUF_SigReadData	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMReadFile SUF_PCMWriteData SUF_CsvReadData SUF_CsvReadData SUF_CsvWriteData SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteAddrix SUF_CsvWriteMatrix SUF_DatReadData SUF_DatReadData SUF_DatWriteData SUF_DatWriteHeader SUF_DatWriteHeader SUF_SigReadData SUF_SigReadData SUF_SigReadData SUF_SigWriteData	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMReadFile SUF_PCMReadFile SUF_CMReadData SUF_CSvReadData SUF_CsvReadData SUF_CsvReadFile SUF_CsvReadFile SUF_CsvReadMatrix SUF_CsvWriteFile SUF_CsvWriteMatrix SUF_CsvWriteMatrix SUF_DatReadData SUF_DatReadHeader SUF_DatWriteHeader SUF_SigReadData SUF_SigReadFile	
SUF_BinWriteData SUF_BinReadFile SUF_BinWriteFile SUF_PCMReadData SUF_PCMReadFile SUF_PCMReadFile SUF_CMReadData SUF_CsvReadData SUF_CsvReadData SUF_CsvReadFile SUF_CsvReadFile SUF_CsvWriteFile SUF_CsvWriteFile SUF_CsvWriteMatrix SUF_CsvWriteMatrix SUF_DatReadData SUF_DatReadHeader SUF_DatWriteHeader SUF_SigReadData SUF_SigReadFile SUF_SigReadFile SUF_SigReadFile SUF_SigWriteFile	
SUF_BinWriteData. SUF_BinReadFile. SUF_BinWriteFile. SUF_PCMReadData. SUF_PCMReadFile. SUF_PCMReadFile. SUF_PCMWriteData. SUF_CsvReadData. SUF_CsvReadData. SUF_CsvWriteData. SUF_CsvWriteData. SUF_CsvWriteFile. SUF_CsvWriteFile. SUF_CsvWriteMatrix. SUF_CsvWriteMatrix. SUF_DatReadData. SUF_DatReadHeader. SUF_DatWriteHeader. SUF_SigReadData. SUF_SigReadFile. SUF_SigWriteFile. SUF_SigCountSamplesInFile.	
SUF_BinWriteData. SUF_BinReadFile. SUF_BinWriteFile. SUF_PCMReadData. SUF_PCMReadFile. SUF_PCMWriteData. SUF_PCMWriteFile. SUF_CsvReadData. SUF_CsvReadFile. SUF_CsvWriteData. SUF_CsvWriteData. SUF_CsvWriteFile. SUF_CsvWriteFile. SUF_CsvWriteMatrix. SUF_DatReadData. SUF_DatReadData. SUF_DatWriteData. SUF_DatWriteHeader. SUF_SigReadData. SUF_SigReadFile. SUF_SigReadFile. SUF_SigWriteFile. SUF_SigCountSamplesInFile. SUF_XmtReadData.	
SUF_BinWriteData. SUF_BinReadFile. SUF_BinWriteFile. SUF_PCMReadData. SUF_PCMReadFile. SUF_PCMReadFile. SUF_PCMWriteData. SUF_CsvReadData. SUF_CsvReadData. SUF_CsvWriteData. SUF_CsvWriteData. SUF_CsvWriteFile. SUF_CsvWriteFile. SUF_CsvWriteMatrix. SUF_CsvWriteMatrix. SUF_DatReadData. SUF_DatReadHeader. SUF_DatWriteHeader. SUF_SigReadData. SUF_SigReadFile. SUF_SigWriteFile. SUF_SigCountSamplesInFile.	

SUF WriteWeightsBinaryFile	1109
SUF_ReadWeightsBinaryFile	1110
SUF WriteWeightsWithBiasesIntegerCFile	
SUF WriteWeightsWithBiasesFloatCFile	1112
SUF WriteWeightsWithBiasesBinaryFile	1113
SUF_ReadWeightsWithBiasesBinaryFile	1114
WAV File Functions	1115
SUF_WavReadData	1116
SUF_WavWriteData	1117
SUF_WavReadWord	1118
SUF_WavReadInt	1119
SUF_WavWriteWord	1120
SUF_WavWriteInt	1121
SUF_WavReadHeader	1122
SUF_WavWriteHeader	1123
SUF_WavDisplayInfo	
SUF_WavSetInfo	
SUF_WavFileLength	1126
SUF_WavReadFile	1127
SUF_WavWriteFile	
SUF_WavWriteFileScaled	1129
UTILITY MACROS (siglib macros.h)	1130

DOCUMENTATION OVERVIEW

The SigLib documentation is split in to three sections, a User's Guide gives an overview of the SigLib library, whilst the Reference Manual gives a function by function description of the library and the Host Function Reference Manual. Users will probably find it beneficial to read the user's guide to get an understanding of how SigLib functions, they will then probably find that the reference manual is sufficient guidance in every day usage. The on-line nature of the documentation allows it to be used in parallel with the development tools.

Separate documentation is also supplied for the SigLib utility programs.

Documentation Conventions

The SigLib documentation uses the following conventions:

The ANSI C standard conventions have been followed, for example hexadecimal numbers are prefixed by '0x'.

Names of directories, files and functions are given in italics.

Important programming information is indicated with the symbol:



How To Use This Manual

The functions are divided into modules, according to functionality.

The page per function section, in addition to giving a detailed description, also provide the function prototypes, describing all the function arguments. Each function description page also includes a function cross reference section, to other functions in the module.

For the sake of execution efficiency, few of the functions return error codes and none of them perform operations like array bounds checking. The onus lies with the programmer to ensure that the data passed to the functions is valid.

SigLib Data Types

SigLib uses two pseudo data types, these are SLData t and SLArrayIndex t the reason for using these types is to ease portability across different processors and systems. For many processors, including most floating point DSPs the actual data type is specified by a typedef in the SigLib header files.

FUNCTION DESCRIPTIONS

FREQUENCY DOMAIN FUNCTIONS

Fast Fourier Transform Functions (ffourier.c)

The Fast Fourier Transform (FFT) functions include support for both radix-2 and radix-4.

Radix-2 FFT Functions

The Fast Fourier Transform (FFT) functions all include code for handling the bit reversal however the exact operation of this is controlled through the use of conditional compilation statements at the top of the source file (*ffourier.c*).

The main FFT functions are initialised by the SIF Fft () function.

Different text books use different notations for the sign of the sine term, when performing FFTs and IFFTs, SigLib uses the following Radix 2 butterfly notation:

A
$$\supset$$
 C
B \supset D

$$Cr = Ar + Br$$

$$Ci = Ai + Bi$$

$$Dr = (Ar-Br) * Cos (Theta) + (Ai-Bi) * Sin (Theta)$$

$$Di = (Ai-Bi) * Cos (Theta) - (Ar-Br) * Sin (Theta)$$

It is recommended that users verify before hand that this is the notation, required, for their application. The phase differences, between the different notations is irrelevant, when performing a square magnitude sum on the results.

In order to be able to support different FFT lengths simultaneously it is necessary to initialise each length required with a separate call to SIF_Fft() function, with the coefficients and, if required, bit reverse address tables being located in separate arrays.

The transform length of the FFT must be a power of 2. The log₂ FFT length parameter is the logarithm to base 2 of the FFT length, this used to efficiently execute the correct number of stages.

The real FFT is almost twice as fast as the complex transform.

The real FFT function does not require any input data in the imaginary array.

FFT Bit Reverse Addressing

FFT bit reverse re-ordering happens in one of 3 ways, that are configured by passing the following to the function parameter pBitReverseAddressTable:

pBitReverseAddressTable	Bit Reverse Addressing Mode
SIGLIB_BIT_REV_NONE	No bit reverse addressing is performed
SIGLIB_BIT_REV_STANDARD	Bit reverse addressing is handled via computation of the addresses to swap
A valid memory address	Bit reverse addressing is handled via a look-up table so is faster but requires the use of the additional look-up table, in memory. Note: for this mode to work the look-up table must not be located at memory addresses $0x000$ or $0x001$

FFT Scaling (Radix-2 and Radix-4)

A Discrete Fourier Transform (DFT) scales the result with respect to the continuous time equivalent by a factor of N, where N is the size of the FFT. Some FFT functions account for this in the forward FFT, some in the inverse and some not at all - there seems to be no consensus on where to account for the scaling. It is not that any particular implementation is right or wrong but just that they are different. The SigLib library does not apply any scaling to the results of the FFT functions. We have chosen not to scale the results because this allows the user to choose a suitable scaling for their application.

SIF_Fft

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Fft (SLData_t *, Pointer to FFT coefficient table SLArrayIndex t *, Bit reverse mode flag / Pointer to bit

reverse address table

const SLArrayIndex t) FFT Size

DESCRIPTION

This function initializes the FFT functions, including twiddle factor array. Prior to using any of the FFT functions, the function SIF_Fft () must be called, this, amongst other things initialises the twiddle factor (coefficient) tables. If an application requires FFTs of different lengths then this function must be used to initialise separate coefficient tables and, if required, bit reverse address tables for each length.

NOTES ON USE

This function generates a table of overlapping sine and cosine data, commonly called a three quarters sine table. This table consists of floating-point data values. For fixed point implementations it will be necessary to generate the tables with the appropriate data, which will depend on the length of the table and the CPU word length.

CROSS REFERENCE

SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SDA_Rfftr, SDA_Cfft2rBy1c, SDA_Cfft2rBy1cr.

SDA_Rfft

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Rfft (SLData_t *, Real input/output arraypointer
SLData_t *, Imaginary output array pointer
SLData_t *, FFT coefficient pointer
const SLArrayIndex_t *, Bit reverse mode flag / Pointer to bit
reverse address table
const SLArrayIndex_t, FFT length
const SLArrayIndex_t) log2 FFT length

DESCRIPTION

This function performs a radix-2, decimation in frequency, real to complex fast Fourier transform, of arbitrary order greater than 3 (8 points). The transform is performed in-place, i.e. the result data is placed back in the source arrays.

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA Divide and SDA Multiply.

NOTES ON USE

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF_Fft, SDA_Cfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SDA_Rfftr, SDA_Cfft2rBy1c, SDA_Cfft2rBy1cr.

SDA_Cfft

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Cfft (SLData_t *, Real input/output array pointer
SLData_t *, Imaginary input/output array pointer
SLData_t *, FFT coefficient pointer
const SLArrayIndex_t *, Bit reverse mode flag / Pointer to bit
reverse address table
const SLArrayIndex_t, FFT length
const SLArrayIndex_t) log2 FFT length

DESCRIPTION

This function performs a radix-2, decimation in frequency, complex to complex fast Fourier transform, of arbitrary order greater than 3 (8 points). The transform is performed in-place, i.e. the result data is placed back in the source arrays.

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA Divide and SDA Multiply.

NOTES ON USE

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF_Fft, SDA_Rfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SDA_Rfftr, SDA_Cfft2rBy1c, SDA_Cfft2rBy1cr.

SDA_Cifft

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Cifft (SLData_t *, Real input/output array pointer
SLData_t *, Imaginary input/output array pointer
SLData_t *, FFT coefficient pointer
const SLArrayIndex_t *, Bit reverse mode flag / Pointer to bit
reverse address table
const SLArrayIndex_t, FFT length
const SLArrayIndex_t) log2 FFT length

DESCRIPTION

This function performs a radix-2 complex to complex inverse fast Fourier transform, of arbitrary order greater than 3 (8 points). The transform is performed in-place, i.e. the result data is placed back in the source arrays.

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA Divide and SDA Multiply.

NOTES ON USE

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF_Fft, SDA_Rfft, SDA_Cfft, SDA_FftShift, SDA_CfftShift, SDA_Rfftr, SDA_Cfft2rBy1c, SDA_Cfft2rBy1cr.

void SDA BitReverseReorder (const SLData t*, Input array pointer

SLData t*, Output array pointer

const SLArrayIndex t*, Bit reverse mode flag / Pointer to bit

reverse address table

const SLArrayIndex t) Array length

DESCRIPTION

This function will take linearly ordered data and change the ordering to bit reversed. This operation is reversible and so the same function can be used for taking bit reversed data and returning it in a linear order.

NOTES ON USE

CROSS REFERENCE

SDA_Rfft, SDA_Cfft, SDA_Cifft, SIF_FftArb, SDA_RfftArb, SDA_Rfftr.

void SDA_IndexBitReverseReorder (const SLArrayIndex_t*, Input array pointer SLArrayIndex_t *, Output array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function function will take a linearly ordered array of fixed point data and change the ordering to bit reversed. This operation is reversible and so the same function can be used for taking bit reversed data and returning it in a linear order.

This function is often used for indices that can be used for accessing arrays of floating point data.

NOTES ON USE

CROSS REFERENCE

SDA_Rfft, SDA_Cfft, SDA_Cifft, SIF_FftArb, SDA_RfftArb, SDA_Rfftr, SIF_FastBitReverseReorder.

 $void\ SIF_FastBitReverseReorder\ (const\ SLArrayIndex_t^*,\ Bit\ reverse\ address\ look\ up\ table\ pointer$

const SLArrayIndex_t)

Array length

DESCRIPTION

This function initialises the look up table fast bit reversing functions.

NOTES ON USE

This function only needs to be called if the SIF_Fft function is not used.

CROSS REFERENCE

 $SDA_IndexBitReverseReorder$

void SDA_RealRealCepstrum (SLData_t *, Real input data pointer

SLData_t *, Real destination data pointer

SLData_t *, Imaginary destination data pointer

const SLData_t *, FFT coefficient pointer

const SLArrayIndex_t *, Bit reverse mode flag / Pointer to bit

reverse address table

const SLArrayIndex_t, FFT length

const SLArrayIndex_t) Log2 FFT length

DESCRIPTION

This function performs a real cepstrum operation on the real input data sequence. The real cepstrum is defined by the following equation:

$$C_x[n] = \frac{1}{2\pi} \int_{-\infty}^{\pi} \log |X(e^{-j\omega})| e^{-j\omega n} d\omega$$

The cepstrum is defined as the Fourier transform of the logarithm of the magnitude of the Fourier transform of a sequence.

NOTES ON USE

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

The difference between the complex cepstrum and the real cepstrum is that the complex variant includes the unwrapped phase sequence.

CROSS REFERENCE

SDA RealComplexCepstrum and SDA ComplexComplexCepstrum.

void SDA_RealComplexCepstrum (SLData_t *, Real input data pointer
SLData_t *, Real destination data pointer
SLData_t *, Imaginary destination data pointer
const SLData_t *, FFT coefficient pointer
const SLArrayIndex_t *, Bit reverse mode flag / Pointer to bit
reverse address table
const SLArrayIndex_t, FFT length
const SLArrayIndex_t)
FFT length
Log2 FFT length

DESCRIPTION

This function performs a complex cepstrum operation on the real input data sequence. The complex cepstrum is defined by the following equation:

$$\hat{x}[n] = \frac{1}{2\pi} \int_{-\pi}^{\pi} [\log |X(e^{-j\omega})| + j \arg(X(e^{-j\omega}))] e^{-j\omega n} d\omega$$

'arg' is the unwrapped phase function.

Complex cepstrum refers to complex logarithm, not complex sequence.

The complex cepstrum of a real sequence is also a real sequence.

The cepstrum is defined as the Fourier transform of the logarithm of the magnitude of the Fourier transform of a sequence.

NOTES ON USE

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

The difference between the complex cepstrum and the real cepstrum is that the complex variant includes the unwrapped phase sequence.

CROSS REFERENCE

SDA RealRealCepstrum and SDA ComplexComplexCepstrum.

void SDA ComplexComplexCepstrum (SLData t*, Real input data pointer SLData t*, Imaginary input data pointer SLData t*, Real destination data pointer SLData t*, Imaginary destination data pointer const SLData t*, FFT coefficient pointer const SLArrayIndex t*, Bit reverse mode flag / Pointer to bit reverse address table const SLArrayIndex t, FFT length const SLArrayIndex t) Log2 FFT length

DESCRIPTION

This function performs a complex cepstrum operation on the complex input data sequence. The complex cepstrum is defined by the following equation:

$$\hat{x}[n] = \frac{1}{2\pi} \int_{-\pi}^{\pi} [\log |X(e^{-j\omega})| + j \arg(X(e^{-j\omega}))] e^{-j\omega n} d\omega$$

The cepstrum is defined as the Fourier transform of the logarithm of the magnitude of the Fourier transform of a sequence.

NOTES ON USE

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

CROSS REFERENCE

SDA RealRealCepstrum and SDA RealComplexCepstrum.

^{&#}x27;arg' is the unwrapped phase function.

SIF_FftTone

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_FftTone (SLData_t *, Pointer to FFT coefficient table SLArrayIndex t *, Bit reverse mode flag / Pointer to bit

SLArrayIndex_t *, Bi
reverse address table

const SLArrayIndex_t) FFT Size

DESCRIPTION

This function initializes the SDA_FftTone function.

This function calls SIF_Fft. Please read the notes for SIF_Fft for further details.

NOTES ON USE

CROSS REFERENCE

SIF_Fft and SDA_RfftTone.

SDA_RfftTone

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA RfftTone (const SLData t*, Real source array pointer SLData t*, Real array pointer SLData t*, Imaginary array pointer const SLData t*, FFT coefficient pointer Bit reverse mode flag / Pointer to bit const SLArrayIndex t*, reverse address table SLArrayIndex t*, Pointer to tone FFT bin number SLData t*, Pointer to tone signal magnitude const SLArrayIndex_t, FFT length const SLArrayIndex t) log2 FFT length

DESCRIPTION

This function returns the FFT bin and the linear magnitude of the peak frequency in the input signal.

This function calls SIF_Fft. Please read the notes for SIF_Fft for further details.

NOTES ON USE

This function is initialized by SIF_FftTone function, which must be called prior to calling this function.

CROSS REFERENCE

SIF FftTone.

SDA_Rfftr

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Rfftr (SLData_t *, Real input/output array pointer
SLData_t *, Imaginary output array pointer
SLData_t *, FFT coefficient pointer
const SLArrayIndex_t *, Bit reverse mode flag / Pointer to bit
reverse address table
const SLArrayIndex_t, FFT length
const SLArrayIndex_t) log2 FFT length

DESCRIPTION

This function performs a radix-2, decimation in frequency, real to real fast Fourier transform, of arbitrary order greater than 3 (8 points). The transform is performed in-place, i.e. the result data is placed back in the source arrays.

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA Divide and SDA Multiply.

NOTES ON USE

This function only returns the real component of the frequency domain response, saving approximately 10% of the MIPS required for a standard real to complex FFT.

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF Fft, SDA Rfft, SDA Cfft, SDA Cifft, SDA FftShift, SDA CfftShift.

SIF_Fft4

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Fft4 (SLData_t *, Pointer to FFT coefficient table

SLArrayIndex_t *, Digit reverse mode flag / Pointer to digit

reverse address table

const SLArrayIndex_t) FFT Size

DESCRIPTION

This function initializes the radix-4 FFT functions, including twiddle factor array. Prior to using any of the FFT functions, the function SIF_Fft4 () must be called, this, amongst other things initialises the twiddle factor (coefficient) tables. If an application requires FFTs of different lengths then this function must be used to initialise separate coefficient tables and, if required, bit reverse address tables for each length.

NOTES ON USE

This function generates a table of overlapping sine and cosine data, commonly called a three quarters sine table. This table consists of floating-point data values. For fixed point implementations it will be necessary to generate the tables with the appropriate data, which will depend on the length of the table and the CPU word length.

CROSS REFERENCE

SDA Rfft4, SDA Cfft4, SDA Cfft42rBy1c, SDA Cfft42rBy1cr.

SDA_Rfft4

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Rfft4 (SLData_t *, Real input/output array pointer
SLData_t *, Imaginary output array pointer
SLData_t *, FFT coefficient pointer
const SLArrayIndex_t *, Digit reverse mode flag / Pointer to digit
reverse address table
const SLArrayIndex_t, FFT length
const SLArrayIndex_t)
FFT length
log2 FFT length

DESCRIPTION

This function performs a radix-4, decimation in frequency, real to complex fast Fourier transform, of arbitrary order greater than 3 (16 points). The transform is performed in-place, i.e. the result data is placed back in the source arrays.

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA Divide and SDA Multiply.

NOTES ON USE

This function is initialized by SIF_Fft4() function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SDA Cfft4, SIF Fft4, SDA Cfft42rBy1c, SDA Cfft42rBy1cr.

SDA_Cfft4

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Cfft4 (SLData_t *, Real input/output array pointer
 SLData_t *, Imaginary input/output array pointer
 SLData_t *, FFT coefficient pointer
 const SLArrayIndex_t *, Digit reverse mode flag / Pointer to digit
reverse address table
 const SLArrayIndex_t, FFT length
 const SLArrayIndex_t) log2 FFT length

DESCRIPTION

This function performs a radix-4, decimation in frequency, complex to complex fast Fourier transform, of arbitrary order greater than 3 (16 points). The transform is performed in-place, i.e. the result data is placed back in the source arrays.

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA Divide and SDA Multiply.

NOTES ON USE

This function is initialized by SIF_Fft4() function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF Fft4, SDA Rfft4, SDA Cfft42rBy1c, SDA Cfft42rBy1cr.

void SDA_DigitReverseReorder4 (const SLData_t *, Input array pointer SLData_t *, Output array pointer const SLArrayIndex t) Array length

DESCRIPTION

This function will take linearly ordered data and change the ordering to radix-4 digit reversed. This operation is reversible and so the same function can be used for taking radix-4 digit reversed data and returning it in a linear order.

NOTES ON USE

CROSS REFERENCE

SDA Cfft4.

void SDA_IndexDigitReverseReorder4 (const SLArrayIndex_t*, Input array pointer SLArrayIndex_t *, Output array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function function will take a linearly ordered array of fixed point data and change the ordering to fast radix-4 digit reversed. This operation is reversible and so the same function can be used for taking bit reversed data and returning it in a linear order.

This function is often used for indices that can be used for accessing arrays of floating point data.

NOTES ON USE

CROSS REFERENCE

SDA_Rfft, SDA_Cfft, SDA_Cifft, SIF_FftArb, SDA_RfftArb, SDA_Rfftr, SIF_FastDigitReverseReorder4.

void SIF_FastDigitReverseReorder4 (const SLArrayIndex_t*, Digit reverse address look up table pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function initialises the look up table fast radix-4 digit reversing functions.

NOTES ON USE

This function only needs to be called if the SIF_Fft function is not used.

CROSS REFERENCE

SDA_IndexDigitReverseReorder4

```
void SDA Cfft2rBy1c (SLData t*,
                                           Pointer to input #1 array
       SLData t*,
                                           Pointer to input #2 array
                                           Pointer to output #1 array
       SLData t*,
                                           Pointer to output #2 array
       SLData t*,
       const SLData t*,
                                           Pointer to FFT coefficients
       const SLArrayIndex t*,
                                           Bit reverse mode flag / Pointer to bit
reverse address table
       const SLArrayIndex t,
                                           FFT length
       const SLArrayIndex t)
                                           log2 FFT length
```

DESCRIPTION

This function performs two radix-2 decimation in frequency, real to complex fast Fourier transforms using a single complex radix-2 FFT. The FFT can be of arbitrary order greater than 3 (8 points).

The results are returned in two separate arrays, one for each channel. Each array contains real and imaginary results:

```
real[0],..,real[N-1],imag[0],..,imag[N-1]
```

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA_Divide and SDA_Multiply.

NOTES ON USE

The original input data is destroyed by this function as it is used to calculate the intermediate results.

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF_Fft, SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SDA Rfftr, SDA Cfft2rBy1cr, SDA Cfft42rBy1c, SDA Cfft42rBy1cr.

```
void SDA Cfft2rBy1cr (SLData t*,
                                           Pointer to input #1 array
       SLData t*,
                                           Pointer to input #2 array
                                           Pointer to output #1 array
       SLData t*,
                                           Pointer to output #2 array
       SLData t*,
       const SLData t*,
                                           Pointer to FFT coefficients
       const SLArrayIndex t*,
                                           Bit reverse mode flag / Pointer to bit
reverse address table
       const SLArrayIndex t,
                                           FFT length
       const SLArrayIndex t)
                                           log2 FFT length
```

DESCRIPTION

This function performs two radix-2 decimation in frequency, real to real fast Fourier transforms using a single complex radix-2 FFT. The FFT can be of arbitrary order greater than 3 (8 points).

The results are returned in two separate arrays, one for each channel. Each array contains real and imaginary results:

```
real[0],..,real[N-1]
```

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA_Divide and SDA_Multiply.

NOTES ON USE

The original input data is destroyed by this function as it is used to calculate the intermediate results.

This function is initialized by SIF_Fft function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF_Fft, SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SDA Rfftr, SDA Cfft2rBy1c, SDA Cfft42rBy1c, SDA Cfft42rBy1cr.

```
void SDA Cfft42rBy1c (SLData_t *,
                                           Pointer to input #1 array
       SLData t*,
                                           Pointer to input #2 array
                                           Pointer to output #1 array
       SLData t*,
                                           Pointer to output #2 array
       SLData t*,
       const SLData t*,
                                           Pointer to FFT coefficients
       const SLArrayIndex t*,
                                           Digit reverse mode flag / Pointer to digit
reverse address table
       const SLArrayIndex t,
                                           FFT length
       const SLArrayIndex t)
                                           log2 FFT length
```

DESCRIPTION

This function performs two radix-4 decimation in frequency, real to complex fast Fourier transforms using a single complex radix-4 FFT. The FFT can be of arbitrary order greater than 2 (16 points).

The results are returned in two separate arrays, one for each channel. Each array contains real and imaginary results:

```
real[0],..,real[N-1],imag[0],..,imag[N-1]
```

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA_Divide and SDA_Multiply.

NOTES ON USE

The original input data is destroyed by this function as it is used to calculate the intermediate results.

This function is initialized by SIF_Fft4 function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF_Fft, SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SDA Rfftr, SDA Cfft2rBy1c, SDA Cfft2rBy1cr, SDA Cfft42rBy1cr.

```
void SDA Cfft42rBy1cr (SLData t*,
                                           Pointer to input #1 array
       SLData t*,
                                           Pointer to input #2 array
                                           Pointer to output #1 array
       SLData t*,
                                           Pointer to output #2 array
       SLData t*,
       const SLData t*,
                                           Pointer to FFT coefficients
       const SLArrayIndex t*,
                                           Digit reverse mode flag / Pointer to digit
reverse address table
       const SLArrayIndex t,
                                           FFT length
       const SLArrayIndex t)
                                           log2 FFT length
```

DESCRIPTION

This function performs two radix-4 decimation in frequency, real to real fast Fourier transforms using a single complex radix-4 FFT. The FFT can be of arbitrary order greater than 2 (16 points).

The results are returned in two separate arrays, one for each channel. Each array contains real and imaginary results:

```
real[0],..,real[N-1]
```

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA_Divide and SDA_Multiply.

NOTES ON USE

The original input data is destroyed by this function as it is used to calculate the intermediate results.

This function is initialized by SIF_Fft4 function, which must be called prior to calling this function.

See notes at top of FFT section.

CROSS REFERENCE

SIF_Fft, SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SDA Rfftr, SDA Cfft2rBy1c, SDA Cfft2rBy1cr, SDA Cfft42rBy1c.

SDS_Cfft2

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDS_Cfft2 (const SLData_t,
                                           Source sample real 1
                                           Source sample imaginary 1
       const SLData t,
                                           Source sample real 2
       const SLData t,
       const SLData t,
                                           Source sample imaginary 2
       SLData t*,
                                           Pointer to destination real 1
       SLData t*,
                                           Pointer to destination imaginary 1
       SLData t*,
                                           Pointer to destination real 2
       SLData t*)
                                           Pointer to destination imaginary 2
```

DESCRIPTION

This function performs a radix-2 FFT operation on the supplied data.

The advantage of this function over the array oriented version is that the source and destination data values do not need to be contiguous in memory.

NOTES ON USE

CROSS REFERENCE

SDA_Cfft2, SDS_Cfft3, SDA_Cfft3.

SDA_Cfft2

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDA_Cfft2 (const SLData_t *, Pointer to real source array const SLData_t *, Pointer to imaginary source array SLData_t *, Pointer to real destination array SLData_t *) Pointer to imaginary destination array
```

DESCRIPTION

This function performs a radix-2 FFT operation on the supplied data arrays.

NOTES ON USE

This function can operate "in-place" or not "in-place".

CROSS REFERENCE

SDS_Cfft2, SDS_Cfft3, SDA_Cfft3.

SDS_Cfft3

PROTOTYPE AND PARAMETER DESCRIPTION

void SDS_Cfft3 (const SLData_t,	Source sample real 1
const SLData_t,	Source sample imaginary 1
const SLData_t,	Source sample real 2
const SLData_t,	Source sample imaginary 2
const SLData_t,	Source sample real 3
const SLData_t,	Source sample imaginary 3
SLData_t *,	Pointer to destination real 1
SLData_t *,	Pointer to destination imaginary 1
SLData_t *,	Pointer to destination real 2
SLData_t *,	Pointer to destination imaginary 2
SLData_t *,	Pointer to destination real 3
SLData_t *)	Pointer to destination imaginary 3

DESCRIPTION

This function performs a radix-3 FFT operation on the supplied data.

The advantage of this function over the array oriented version is that the source and destination data values do not need to be contiguous in memory.

NOTES ON USE

CROSS REFERENCE

SDS_Cfft2, SDA_Cfft2, SDA_Cfft3.

SDA_Cfft3

PROTOTYPE AND PARAMETER DESCRIPTION

```
    void SDA_Cfft3 (const SLData_t *, const SLData_t *, SLData_t *, SLData_t *)
    Pointer to real source array
    Pointer to imaginary source array
    Pointer to real destination array
    Pointer to imaginary destination array
```

DESCRIPTION

This function performs a radix-3 FFT operation on the supplied data arrays.

NOTES ON USE

This function can operate "in-place" or not "in-place".

CROSS REFERENCE

SDS_Cfft2, SDA_Cfft2, SDS_Cfft3.

SLError_t SIF_ZoomFft (SLData_t *,	Pointer to real comb filter state array
SLData_t *,	Real comb filter sum
SLData_t *,	Pointer to imag. comb filter state array
SLData_t *,	Imaginary comb filter sum
SLArrayIndex_t *,	Comb filter phase
SLData_t *,	Pointer to sine look-up table
SLArrayIndex_t *,	Sine table phase for mixer
SLArrayIndex_t *,	Pointer to real decimator index
SLArrayIndex_t *,	Pointer to imaginary decimator index
SLArrayIndex_t *,	Pointer to real LPF index
SLArrayIndex_t *,	Pointer to imaginary LPF index
SLData_t *,	Pointer to real LPF state array
SLData_t *,	Pointer to imaginary LPF state array
SLData_t *,	Pointer to window look-up table
SLData_t *,	Pointer to FFT coefficient table
SLArrayIndex_t *,	Pointer to bit reverse address table
const SLArrayIndex_t,	Comb filter length
const SLArrayIndex_t,	Mixer sine table size
<pre>const SLArrayIndex_t,</pre>	FIR filter length
<pre>const SLArrayIndex_t)</pre>	FFT length

DESCRIPTION

This function initializes the zoom FFT function, including twiddle factor array. Amongst other things, this function initialises the twiddle factor tables and the sine wave table, for the mixer. If an application requires zoom-FFTs of different lengths then this function must be called, to change the length, between use.

NOTES ON USE

This function returns the error code from the SIF_Fft() and SIF_ComplexShift () functions that it calls.

CROSS REFERENCE


SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_ZoomFft, SIF_ZoomFftSimple, SDA_ZoomFftSimple.

void SDA ZoomFft (const SLData t*, Pointer to input array SLData t*, Pointer to real result array SLData t*, Pointer to imaginary result array Pointer to real comb filter state array SLData t*. Real comb filter sum SLData t*, SLData t*, Pointer to imag. comb filter state array Imaginary comb filter sum SLData t*, Comb filter phase SLArrayIndex t*, Pointer to sine look-up table const SLData t*, Pointer to sine table phase for mixer SLArrayIndex t*, const SLData t, Mix frequency const SLArrayIndex t, Length of comb filter Sine table size for mixer const SLArrayIndex t, const SLArrayIndex t, High decimation ratio SLData t*, Pointer to real LPF state array Pointer to imaginary LPF state array SLData t*, const SLData t*, Pointer to LPF coefficients SLArrayIndex t*, Pointer to real decimator index SLArrayIndex t*. Pointer to imaginary decimator index Pointer to real LPF index SLArrayIndex t*, SLArrayIndex t*, Pointer to imaginary LPF index Pointer to window look-up table const SLData t*, const SLData t*, Pointer to FFT coefficient table const SLArrayIndex t*, Pointer to bit reverse address table const SLArrayIndex t, Source array length const SLArrayIndex t, Intermediate array length FIR filter length const SLArrayIndex t, const SLFixData t, FIR decimation ratio const SLFixData t, Frequency reverse flag const SLArrayIndex t, FFT length const SLArrayIndex t) Log2 FFT length

DESCRIPTION

This function performs the following operations on the input signal: complex mix and high decimation comb filter, FIR low pass filter decimation, windowing, FFT and optional spectral reversal. The mix uses an arbitrary length sine table and mix frequency, the high decimation filter is a comb filter, again of arbitrary length. The FFT is a radix-2, decimation in frequency, complex fast Fourier transform, that must be a power of 2 in length and greater than 8 points. The transform is performed inplace, i.e. the result data is placed back in the source arrays.

The following diagram shows the complete structure of the zoom-FFT:



NOTES ON USE

The SDA_ZoomFft function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA_Divide and SDA_Multiply.

The decimation ratio of the high decimation filter should be a power of 2 where as that of the FIR filter can be any integer value.

See Notes for SDA Cfft function.

Prior to using this function, the function SIF ZoomFft must be called.

The frequency resolution = sample rate (Hz) / number of input samples – it is important that the algorithm is provided with a long enough input array.

The accuracy of the frequencies in the decimated output array are defined by to the resolution of the mix frequency. The incoming signal is mixed with the in-phase (cos) and quadrature-phase (sin) carriers and these are generated from a look-up table for maximum performance. The resolution of the carrier frequencies is defined by the length of the table. In most zoom-FFT algorithms it is best to use a look-up table that is at least as long as the FFT length and preferably longer. The higher the decimation factor, the longer the look-up-tables must be.

The first NULL in the high decimation filter is at the sample frequency / decimation filter length.

The decimation filter length is the length of the comb filter and must be chosen to match the signal bandwidth. The sine array length defines the length of the sinusoid array used for the mixing process. The decimation filter length and sine array length need to be chosen to optimise performance (Signal to noise ratio) and minimise memory usage.

The decimation FIR filters should be linear phase filter to maintain the phase relationships of all the frequencies in the signal being decimated.

The decimation ratios must be integer values.

The "Intermediate array length" parameter specifies the length of the real and complex arrays that are used between the high decimation filter and the FIR filter.

The "Frequency reverse flag" parameter allows the frequency spectrum to be reversed in situations where the down conversion process has reversed it with respect to the original input.

Ghost frequencies in the output spectrum are very common artefacts of using the traditional zoom FFT algorithm. The artefacts are usually created by the first stage of decimation (the high decimation comb filters) and are due to the fact that the roll-off of these filters is not very sharp and they have little attenuation. It is possible to remove them by using pure FIR filters instead of comb filters but this has massive performance implications for the algorithm so the practical solution to the problem is to try to ensure that these artefacts are located out of the frequency band of interest after the first stage and then to remove them using the second (FIR) stage.

CROSS REFERENCE

SIF_Fft, SDA_Cfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SIF_ZoomFft, SIF_ZoomFftSimple, SDA_ZoomFftSimple.

```
void SIF ZoomFftSimple (SLData t*,
                                          Comb filter 1 pointer
       SLData t*,
                                          Comb filter 1 sum
       SLData t*,
                                          Comb filter 2 pointer
                                          Comb filter 2 sum
       SLData t*,
       SLArrayIndex t*,
                                          Comb filter phase
       SLData t*,
                                          Sine table pointer
                                          Sine table phase for mixer
       SLArrayIndex t*,
      SLData t*,
                                          FFT coefficient pointer
       SLArrayIndex t*,
                                          Bit reverse mode flag / Pointer to bit
reverse address table
       const SLArrayIndex t,
                                          Decimation filter length
       const SLArrayIndex t,
                                          Mixer sine table length
       const SLArrayIndex t)
                                          FFT length
```

DESCRIPTION

This function initialises the simple zoom FFT function, including twiddle factor array. Amongst other things, this function initialises the twiddle factor tables and the sine wave table, for the mixer. If an application requires zoom-FFTs of different lengths then this function must be called, to change the length, between use.

NOTES ON USE

This function returns the error code from the SIF_Fft() and SIF_ComplexShift () functions that it calls.


CROSS REFERENCE

 $SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_ZoomFftSimple, SIF_ZoomFft, SDA_ZoomFft.$

```
void SDA ZoomFftSimple (const SLData t*,
                                                  Input array pointer
       SLData t*,
                                           Real result array pointer
       SLData t*.
                                           Imaginary result array pointer
                                           Comb filter 1 pointer
       SLData t*.
                                           Comb filter 1 sum
       SLData t*,
       SLData t*,
                                           Comb filter 2 pointer
       SLData t*.
                                           Comb filter 2 sum
       SLArrayIndex t*,
                                           Comb filter phase
                                           Sine table pointer
       const SLData t*,
                                           Sine table phase for mixer
       SLArrayIndex t*,
                                           Mix frequency
       const SLData t,
       const SLArrayIndex t,
                                           Length of comb filter
                                           Sine table length for mixer
       const SLArrayIndex t,
       const SLArrayIndex t,
                                           Decimation ratio
       const SLData t*,
                                           FFT coefficient pointer
       const SLArrayIndex t*,
                                           Bit reverse mode flag / Pointer to bit
reverse address table
                                           Source array length
       const SLArrayIndex t,
       const SLArrayIndex t,
                                           FFT length
                                           Log2 FFT length
       const SLArrayIndex t)
```

DESCRIPTION

This function performs complex mix and decimate on a signal and FFT. The mix uses an arbitrary length sine table and mix frequency, the decimation filter is a comb filter, again of arbitrary length. The filter is followed by a radix-2, decimation in frequency, complex fast Fourier transform that must be a power of two in length and greater than 8 points. The transform is performed in-place, i.e. the result data is placed back in the source arrays.



NOTES ON USE

This function does not scale the output, different applications may require different scaling, this can be achieved using the functions SDA Divide and SDA Multiply.

The decimation ratio is a power of 2 and defines the change in sample rate (Hz) between the input and output frequencies.

The decimation filter length is the length of the comb filter and must be chosen to match the signal bandwidth. The sine array length defines the length of the sinusoid array used for the mixing process. The decimation filter length and sine array length need to be chosen to optimise performance (Signal to noise ratio) and minimise memory usage.

See Notes for SDA Cfft function.

Prior to using this function, the function SIF_ZoomFftSimple must be called.

The frequency resolution = sample rate (Hz) / number of input samples – it is important that the algorithm is provided with a long enough input array.

The accuracy of the frequencies in the decimated output array are defined by to the resolution of the mix frequency. The incoming signal is mixed with the in-phase (cos) and quadrature-phase (sin) carriers and these are generated from a look-up table for maximum performance. The resolution of the carrier frequencies is defined by the length of the table. In most zoom-FFT algorithms it is best to use a look-up table that is at least as long as the FFT length and preferably longer. The higher the decimation factor, the longer the look-up-tables must be.

The first NULL in the decimation filter is at the sample frequency / decimation filter length.

The sine look-up tables that are allocated in the initialisation routine should be large enough for the required decimation ratio. The typical length should be at least 4 times the required decimation ratio. This function uses a single length N sine table. The cosine pointer index starts at (length \gg 2) to account for the phase.

Ghost frequencies in the output spectrum are very common artefacts of using the traditional zoom FFT algorithm. The artefacts are usually created by the high decimation comb filters and are due to the fact that the roll-off of these filters is not very sharp and they have little attenuation. If this output from this function exhibits ghost frequencies then the SDA_ZoomFft function should be used instead.

CROSS REFERENCE

SIF_Fft, SDA_Cfft, SDA_Cifft, SDA_FftShift, SDA_CfftShift, SIF ZoomFftSimple, SIF ZoomFft, SDA ZoomFft.

SIF_FdHilbert

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_FdHilbert (SLData_t *, FFT coefficient pointer

SLArrayIndex t*, Bit reverse mode flag / Pointer to bit

reverse address table

SLData_t *, Pointer to inverse FFT length const SLArrayIndex_t) Hilbert transformer length

DESCRIPTION

This function initializes the frequency domain Hilbert transformer function.

NOTES ON USE

The transform length must be a power of 2.

CROSS REFERENCE

SDA_FdHilbert, SDA_Rfft

SDA_FdHilbert

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDA FdHilbert (const SLData t*,
                                            Input array pointer
       SLData t*,
                                            Real destination array pointer
                                            Imaginary destination array pointer
       SLData t*,
                                            FFT coefficient pointer
       SLData t*,
       SLArrayIndex t*,
                                            Bit reverse mode flag / Pointer to bit
reverse address table
       const SLData t,
                                            Inverse FFT length
                                            Hilbert transform length
       const SLArrayIndex t,
       const SLArrayIndex t)
                                            log<sub>2</sub> Hilbert transform length
```

DESCRIPTION

This function implements the frequency domain Hilbert transformer function.

The Hilbert transform phase shifts every component in a signal by 90 degrees.

NOTES ON USE

The transform length must be a power of 2.

The function SIF_FdHilbert must be called prior to calling this function.

This function operates by taking the FFT of the input, rotating it through 90 degrees and performing the inverse complex FFT. The real destination array returns the real FFT output i.e. the phase shifted data, the imaginary destination array returns the imaginary FFT output i.e. noise due to calculation errors.

CROSS REFERENCE

SIF FdHilbert, SIF FdAnalytic, SDA FdAnalytic, SDA Rfft

void SIF_FdAnalytic (SLData_t *, FFT coefficient pointer

SLArrayIndex t*, Bit reverse mode flag / Pointer to bit

reverse address table

SLData_t *, Pointer to inverse FFT length const SLArrayIndex_t) Hilbert transformer length

DESCRIPTION

This function initializes the frequency domain analytic transform function.

NOTES ON USE

The transform length must be a power of 2.

CROSS REFERENCE

SDA_FdHilbert, SDA_Rfft

```
void SDA FdAnalytic (const SLData t*,
                                            Input array pointer
       SLData t*,
                                            Real destination array pointer
                                            Imaginary destination array pointer
       SLData t*,
                                            FFT coefficient pointer
       SLData t*,
       SLArrayIndex t*,
                                            Bit reverse mode flag / Pointer to bit
reverse address table
       const SLData t,
                                            Inverse FFT length
                                            Hilbert transform length
       const SLArrayIndex t,
       const SLArrayIndex_t)
                                            log<sub>2</sub> Hilbert transform length
```

DESCRIPTION

This function returns the analytic version of the input signal where the complex output contains the original input in the real array and the Hilbert transform of the input in the imaginary array. The Hilbert transform phase shifts every component in a signal by 90 degrees.

NOTES ON USE

The transform length must be a power of 2.

The function SIF FdAnalytic must be called prior to calling this function.

CROSS REFERENCE

SIF FdHilbert, SDA FdHilbert, SIF FdAnalytic, SDA Rfft

void SDA_InstantFreq (const SLData_t *, Leading phase input pointer const SLData_t *, Lagging phase input pointer SLData_t *, Destination array pointer const SLArrayIndex_t)

Array length

DESCRIPTION

This function calculates the instantaneous frequency from two waveforms which are PI/2 out of phase. This function is implemented as a two point differentiator and assumes that the sample rate is normalised to 1 (Hz).

NOTES ON USE

The accuracy of the result is greatly affected by the purity of the sine wave.

CROSS REFERENCE

SDA_FdHilbert, SIF_HilbertTransformer

SDA_Rdft

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDA_Rdft (const SLData_t *, Real input array pointer
SLData_t *, Real output array pointer
SLData_t *, Imaginary output array pointer
const SLArrayIndex_t) Transform length
```

DESCRIPTION

This function performs a real forward Fourier transform on the input data set.

NOTES ON USE

This function is included for reference purposes, in practice, the real FFT or arbitrary length FFT functions should always be used for reasons of speed.

There is no scaling on either the input or output of this function. 1/N DFT scaling is performed on the output of the inverse DFT function.

This function does not work "in-place".

CROSS REFERENCE

SDA Ridft, SDA Cdft, SDA Cidft, SDA Rfft, SDA RfftArb.

SDA_Ridft

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Ridft (const SLData_t *, Real input array pointer SLData_t *, Real output array pointer Imaginary output array pointer const SLArrayIndex_t)

Real input array pointer Imaginary output array pointer Transform length

DESCRIPTION

This function performs a real inverse Fourier transform on the input data set.

NOTES ON USE

The complex inverse FFT function should always be used for reasons of speed.

This function performs the 1/N DFT scaling on the output results.

This function does not work "in-place".

CROSS REFERENCE

SDA_Rdft, SDA_Cdft, SDA_Cidft, SDA_Cifft.

SDA_Cdft

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function performs a complex forward Fourier transform on the input data set.

NOTES ON USE

The FFT or arbitrary length FFT functions should always be used for reasons of speed.

There is no scaling on either the input or output of this function. 1/N DFT scaling is performed on the output of the inverse DFT function.

This function does not work "in-place".

CROSS REFERENCE

SDA Rdft, SDA Ridft, SDA Cidft, SDA Rfft, SDA RfftArb.

SDA_Cidft

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Ridft (const SLData_t *, Real input array pointer SLData_t *, Real output array pointer Imaginary output array pointer const SLArrayIndex_t)

Real input array pointer Imaginary output array pointer Transform length

DESCRIPTION

This function performs a complex inverse Fourier transform on the input data set.

NOTES ON USE

The complex inverse FFT function should always be used for reasons of speed.

This function performs the 1/N DFT scaling on the output results.

This function does not work "in-place".

CROSS REFERENCE

SDA_Rdft, SDA_Ridft, SDA_Cdft, SDA_Cifft.

SDA_FftShift

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function shifts the FFT results to locate the D.C. bin at the centre of the array, i.e. swap the left and right halves of the FFT result.

NOTES ON USE

This function is reversible, i.e. calling the same function will reverse the effect. SDA FftShift will also work "in-place".

CROSS REFERENCE

SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_ZoomFft.

SDA_CfftShift

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function shifts the FFT results to locate the D.C. bin at the centre of the array, i.e. swap the left and right halves of the FFT result.

NOTES ON USE

This function is reversible, i.e. calling the same function will reverse the effect. SDA CfftShift will also work "in-place".

CROSS REFERENCE


SDA Rfft, SDA Cfft, SDA Cifft, SDA ZoomFft.

Source array pointer
Destination array pointer
Source array length
Destination array length

DESCRIPTION

This function extends the real frequency domain dataset to a longer length by zero padding the centre. This is shown in the following diagrams.

Source frequency domain:



Destination extended frequency domain:



NOTES ON USE


CROSS REFERENCE

SDA Rfft, SDA Cfft, SDA CfftExtend.

DESCRIPTION

This function extends the complex frequency domain dataset to a longer length by zero padding the centre. This is shown in the following diagrams.

Source frequency domain:



Destination extended frequency domain:



NOTES ON USE

CROSS REFERENCE

SDA_Rfft, SDA_Cfft, SDA_Cifft, SDA_FftExtend.

SIF_DctII

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_DctII (SLData_t *, Pointer to cosine look up table const SLArrayIndex_t) DCT length

DESCRIPTION

This function initialises the type II DCT cosine table.

NOTES ON USE

CROSS REFERENCE

SDA_DctII, SIF_DctIIOrthogonal, SDA_DctIIOrthogonal.

SDA_DctII

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_DctII (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLData_t *, Pointer to cosine look up table SLArrayIndex_t)

DCT length

DESCRIPTION

This function performs the type II DCT.

NOTES ON USE

Reference:

https://en.wikipedia.org/wiki/Discrete cosine transform#Formal definition

CROSS REFERENCE

SIF_DctII, SIF_DctIIOrthogonal, SDA_DctIIOrthogonal.

void SIF_DctIIOrthogonal (SLData_t *, Pointer to square root half parameter SLData_t *, Pointer to output scale parameter SLData_t *, Pointer to cosine look up table

const SLArrayIndex_t) DCT length

DESCRIPTION

This function initialises the type II DCT cosine table and orthogonal scaling parameters.

NOTES ON USE

CROSS REFERENCE

SIF_DctII, SDA_DctII, SDA_DctIIOrthogonal.

void SDA_DctIIOrthogonal (const SLData_t *, Pointer to source array

SLData_t *, Pointer to destination array const SLData_t, Square root half parameter const SLData_t, Output scale parameter

const SLData t*, Pointer to cosine look up table

SLArrayIndex_t) DCT length

DESCRIPTION

This function performs the type II DCT with orthogonal scaling.

NOTES ON USE

Reference:

https://en.wikipedia.org/wiki/Discrete cosine transform#Formal definition

CROSS REFERENCE

SIF DctII, SDA DctII, SIF DctIIOrthogonal.

```
void SIF FftArb (SLData t*,
                                          AWNr coefficients pointer
       SLData t*,
                                          AWNi coefficients pointer
                                          WMr coefficients pointer
       SLData t*,
                                          WMi coefficients pointer
       SLData t*,
       SLData t*,
                                          vLr coefficients pointer
       SLData t*,
                                          vLi coefficients pointer
                                          FFT coefficient pointer
       SLData t*,
       SLArrayIndex t*,
                                          Bit reverse mode flag / Pointer to bit
reverse address table
       enum SLArbitraryFFT t*,
                                          Switch to indicate CZT or FFT pointer
       SLData t*,
                                          Pointer to the inverse FFT length
       SLData t*,
                                          Ptr. to inverse (array length * FFT
length)
       SLArrayIndex t*,
                                          FFT length pointer
                                          Log 2 FFT length pointer
       SLArrayIndex t*,
       const SLArrayIndex t)
                                          Source array length
```

DESCRIPTION

This function initialises the arbitrary length FFT functionality. When using this function, all of the parameters should be pointers to arrays or variables, except the array length parameter. The latter is the only parameter that needs to be specified prior to use, the contents of the remainder are initialised in this function. For further information on the parameters, for example the array lengths, please refer to the documentation for the FFT and chirp z-transform.

NOTES ON USE

This function requires that the FFT coefficient array at least the length of the largest FFT length. I.E. the next largest power of 2 that is greater than or equal to twice the length of the input data set.

The chirp z-transform is used for transforms where the vector length is not a power of 2.

CROSS REFERENCE

SDA RfftArb, SDA CfftArb, SUF FftArbAllocLength.

SLArrayIndex_t SUF_FftArbAllocLength (const SLArrayIndex_t) Source array length

DESCRIPTION

This function returns the length of the FFT that is required for the Arbitrary length FFT functions.

NOTES ON USE

CROSS REFERENCE

SIF_FftArb, SDA_RfftArb, SDA_CfftArb.

SDA_RfftArb

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDA RfftArb (const SLData t*,
                                           Real source array pointer
                                           Real destination array pointer
       SLData t*,
       SLData t*,
                                           Imaginary destination array pointer
                                           Real temporary array pointer
       SLData t*,
                                           Imaginary temporary array pointer
       SLData t*,
       const SLData t*,
                                           AWNr coefficients pointer
       const SLData t*,
                                           AWNi coefficients pointer
       const SLData t*,
                                           WMr coefficients pointer
                                           WMi coefficients pointer
       const SLData t*,
       const SLData t*,
                                           vLr coefficients pointer
                                           vLi coefficients pointer
       const SLData t*,
       const SLData t*,
                                           FFT coefficient pointer
                                           Bit reverse mode flag / Pointer to bit
       const SLArrayIndex t*,
reverse address table
                                           Switch to indicate CZT or FFT
       const enum SLArbitraryFFT t,
       const SLData t,
                                           Inverse FFT length
                                           Inverse (array length * FFT length)
       const SLData t,
       const SLArrayIndex t,
                                           FFT length
       const SLArrayIndex t,
                                           Log 2 FFT length
                                           Arbitrary FFT length
       const SLArrayIndex t)
```

DESCRIPTION

This function will calculate the forward real Fourier transform of an arbitrary length data set using either of two techniques, depending on the vector length. If the vector length is an integer power of two that the function performs a radix-2, decimation in frequency, real to complex fast Fourier transform, of arbitrary order greater than 3 (8 points). The transform is not performed in-place, i.e. the result data is placed in separate arrays to the source arrays.

If the array length is not an integer power of 2 then the function will use the chirp z-transform to calculate the Fourier transform. The SDA_Rfft function does scale the output, in order that it will exactly equal that of the same length pure Fourier transform.

NOTES ON USE

Care must be taken with the windowing of the input data to avoid edge effects. This function requires that the FFT coefficient array at least the length of the largest FFT length. I.E. the next largest power of 2 that is greater than or equal to twice the length of the input data set. The operational parameters (e.g. chirp z or FFT coefficients) for this function are initialised by the function SIF FftArb.

CROSS REFERENCE

SDA Rfft, SUF FftArbAllocLength, SDA Rdft, SIF FftArb, SDA CfftArb.

SDA_CfftArb

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDA CfftArb (const SLData t*,
                                           Real source array pointer
       const SLData t*,
                                           Imaginary source array pointer
       SLData t*,
                                           Real destination array pointer
                                           Imaginary destination array pointer
       SLData t*.
                                           Real temporary array pointer
       SLData t*,
       SLData t*,
                                           Imaginary temporary array pointer
       const SLData t*
                                           AWNr coefficients pointer
                                           AWNi coefficients pointer
       const SLData t*,
                                           WMr coefficients pointer
       const SLData t*,
       const SLData t*,
                                           WMi coefficients pointer
                                           vLr coefficients pointer
       const SLData t*,
       const SLData t*,
                                           vLi coefficients pointer
                                           FFT coefficient pointer
       const SLData t*,
       const SLArrayIndex t*,
                                           Bit reverse mode flag / Pointer to bit
reverse address table
       const enum SLArbitraryFFT t,
                                           Switch to indicate CZT or FFT
       const SLData t,
                                           Inverse FFT length
       const SLData t,
                                           Inverse (array length * FFT length)
       const SLArrayIndex t,
                                           FFT length
                                           Log 2 FFT length
       const SLArrayIndex t,
       const SLArrayIndex t)
                                           Arbitrary FFT length
```

DESCRIPTION

This function calculates the forward complex Fourier transform of an arbitrary length data set using either of two techniques, depending on the vector length. If the vector length is an integer power of two then the function performs a radix-2, decimation in frequency, complex fast Fourier transform, of arbitrary order greater than 3 (8 points). The transform is not performed in-place, i.e. the result data is placed in separate arrays to the source arrays.

If the array length is not an integer power of 2 then the function will use the chirp z-transform to calculate the Fourier transform. The function does scales the output, in order that it will exactly equal that of the same length pure Fourier transform.

NOTES ON USE

Care must be taken with the windowing of the input data to avoid edge effects. This function requires that the FFT coefficient array at least the length of the largest FFT length. I.E. the next largest power of 2 that is greater than or equal to twice the length of the input data set. The operational parameters (e.g. chirp z or FFT coefficients) for this function are initialised by the function SIF FftArb.

CROSS REFERENCE

SDA_Cfft, SUF_FftArbAllocLength, SDA_Cifft, SIF_FftArb, SDA_RfftArb, SDA_CifftArb.

```
Real source array pointer
void SDA CifftArb (const SLData t*,
       const SLData t*,
                                           Imaginary source array pointer
                                           Real destination array pointer
       SLData t*,
                                           Imaginary destination array pointer
       SLData t*,
                                           Real temporary array pointer
       SLData t*,
       SLData t*,
                                           Imaginary temporary array pointer
                                           AWNr coefficients pointer
       const SLData t *.
       const SLData t*,
                                           AWNi coefficients pointer
       const SLData t*,
                                           WMr coefficients pointer
                                           WMi coefficients pointer
       const SLData t*,
                                           vLr coefficients pointer
       const SLData t*,
       const SLData t*.
                                           vLi coefficients pointer
       const SLData t*,
                                           FFT coefficient pointer
       const SLArrayIndex t*,
                                           Bit reverse mode flag / Pointer to bit
reverse address table
       const enum SLArbitraryFFT t,
                                           Switch to indicate CZT or FFT
       const SLArrayIndex t,
                                           FFT length
       const SLArrayIndex t,
                                           Log 2 FFT length
       const SLArrayIndex t)
                                           Arbitrary FFT length
```

DESCRIPTION

This function calculates the inverse complex Fourier transform of an arbitrary length data set using either of two techniques, depending on the vector length. If the vector length is an integer power of two then the function performs a radix-2, decimation in frequency, complex inverse fast Fourier transform, of arbitrary order greater than 3 (8 points). The transform is not performed in-place, i.e. the result data is placed in separate arrays to the source arrays.

If the array length is not an integer power of 2 then the function calculates the inverse Fourier transform by conjugating the input sequence, applying the arbitrary length forward transform, using the chirp z-transform, and then conjugating the result. The function scales the output, in order that it will exactly equal that of the same length pure Fourier transform.

NOTES ON USE

Care must be taken with the windowing of the input data to avoid edge effects. This function requires that the FFT coefficient array at least the length of the largest FFT length. I.E. the next largest power of 2 that is greater than or equal to twice the length of the input data set. The operational parameters (e.g. chirp z or FFT coefficients) for this function are initialised by the function SIF_FftArb.

CROSS REFERENCE

 $SDA_Cfft, SUF_FftArbAllocLength, SDA_Cifft, SIF_FftArb, SDA_RfftArb, SDA_CfftArb.$

Power Spectrum Functions (pspect.c)

The XXX_FastAutoPowerSpectrum and XXX_FastCrossPowerSpectrum functions will perform the given functions on sequences where the length is a power of two and use the Fast Fourier transform functions.

The XXX_ArbAutoPowerSpectrum and XXX_ArbCrossPowerSpectrum functions will perform the given functions on an arbitrary length sequence and will use the arbitrary length Fourier transform functions. The use of the SigLib arbitrary length Fourier transform functionality makes this function more complex than performing a regular Fourier transform but this does provide a far higher level of performance.

SIF FastAutoCrossPowerSpectrum

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_FastAutoCrossPowerSpectrum (SLData_t *, FFT coefficient pointer SLArrayIndex_t *, Bit reverse mode flag / Pointer to bit reverse address table const SLArrayIndex t, FFT Size

const SLArrayIndex_t, FFT Size
SLData t*) Pointer to inverse FFT Size

DESCRIPTION

This function initializes the fast auto power spectrum and cross power spectrum function tables.

NOTES ON USE

Please refer to the documentation for the FFT functions for further details.

CROSS REFERENCE

SDA_FastAutoPowerSpectrum, SDA_FastCrossPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SIF_MagnitudeSquaredCoherence, SDA_MagnitudeSquaredCoherence.

void SDA_FastAutoPowerSpectrum (SLData_t *, Real array pointer
 SLData_t *, Imaginary array pointer
 const SLData_t *, FFT coefficient pointer
 const SLArrayIndex_t *, Bit reverse mode flag / Pointer to bit
reverse address table
 const SLArrayIndex_t, FFT length
 const SLArrayIndex_t, Log2 FFT length
 const SLData t) Inverse FFT Size

DESCRIPTION

This function returns the real auto power spectrum of the supplied data.

This function performs the following operations:

FFT Scaling to ensure that the FFT output matches the DFT $X_{\text{re}}{}^2 + X_{\text{im}}{}^2$

NOTES ON USE

This function works in-place so the input data is destroyed.

The imaginary input array is only used in the function, any input data is discarded.

The results are returned in the real input array.

The result array is of length (N/2)+1 because the results in bins 0 and N/2 are purely real.

CROSS REFERENCE

SIF_FastAutoCrossPowerSpectrum, SDA_FastCrossPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SIF_MagnitudeSquaredCoherence, SDA_MagnitudeSquaredCoherence.

void SDA FastCrossPowerSpectrum (SLData t*, Real array 1 pointer SLData t*, Imaginary array 1 pointer Real source array 2 pointer SLData t*, Imaginary source array 2 pointer SLData t*, const SLData t*, FFT coefficient pointer const SLArrayIndex t*, Bit reverse mode flag / Pointer to bit reverse address table const SLArrayIndex t, FFT length const SLArrayIndex t, Log2 FFT length Inverse FFT Size const SLData t)

DESCRIPTION

This function returns the real cross power spectrum of the supplied data.

This function performs the following operations:

FFTs Scaling to ensure that the FFT output matches the DFT $(X_{re} . Y_{re}) + (X_{im} + Y_{im})$

NOTES ON USE

This function works in-place so the input data is destroyed.

The imaginary input arrays are only used in the function, any input data is discarded. The results are returned in the first real input array.

If the real source array 1 pointer and the real source array 1 pointer point to the same array (i.e. auto power spectrum) then the result will be corrupted.

The result array is of length (N/2)+1 because the results in bins 0 and N/2 are purely real.

CROSS REFERENCE

SIF_FastAutoCrossPowerSpectrum, SDA_FastAutoPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SIF_MagnitudeSquaredCoherence, SDA_MagnitudeSquaredCoherence.

```
void SIF ArbAutoCrossPowerSpectrum (SLData t*, Pointer to AWNr coefficients
       SLData t*,
                                          Pointer to AWNi coefficients
       SLData t*
                                          Pointer to WMr coefficients
       SLData t*
                                          Pointer to WMi coefficients
       SLData t*.
                                          Pointer to vLr coefficients
       SLData t*
                                          Pointer to vLi coefficients
       SLData t*,
                                          FFT coefficients pointer
                                          Bit reverse mode flag / Pointer to bit
       SLArrayIndex t*,
reverse address table
       enum SLArbitraryFFT t*,
                                          Pointer to switch to indicate CZT or FFT
       SLArrayIndex_t * ,
                                          Pointer to FFT length
       SLArrayIndex t*,
                                          Pointer to Log 2 FFT length
       SLData t*,
                                          Pointer to inverse FFT Size
       SLData t*,
                                          Ptr. to inverse (array length * FFT
length)
       const SLArrayIndex t)
                                          Array length
```

DESCRIPTION

This function initializes the arbitrary length auto power spectrum and cross power spectrum function tables.

These functions use the arbitrary length FFT functions further details can be found in the documentation section for these functions.

NOTES ON USE

Please refer to the documentation for the FFT functions for further details.

```
SIF_FastAutoCrossPowerSpectrum, SDA_FastAutoPowerSpectrum, SDA_FastCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SIF_MagnitudeSquaredCoherence, SDA_MagnitudeSquaredCoherence.
```

```
void SDA ArbAutoPowerSpectrum (SLData t*, Real array pointer
       SLData t*,
                                          Imaginary array pointer
                                          Real temporary array pointer
       SLData t*.
       SLData t*,
                                          Imaginary temporary array pointer
       const SLData t*.
                                          Pointer to AWNr coefficients
       const SLData t*
                                          Pointer to AWNi coefficients
       const SLData t*
                                          Pointer to WMr coefficients
       const SLData t*
                                          Pointer to WMi coefficients
       const SLData t*,
                                          Pointer to vLr coefficients
       const SLData t*
                                          Pointer to vLi coefficients
       const SLData t*,
                                          FFT coefficient pointer
       const SLArrayIndex t*,
                                          Bit reverse mode flag / Pointer to bit
reverse address table
       const enum SLArbitraryFFT t,
                                          Switch to indicate CZT or FFT
       const SLArrayIndex t,
                                          FFT length
       const SLArrayIndex t,
                                          Log 2 FFT length
       const SLData t,
                                          Inverse FFT Size
       const SLData t,
                                          Inverse (array length * FFT length)
                                          Arbitrary FFT length
       const SLArrayIndex t)
```

DESCRIPTION

This function returns the real auto power spectrum of an arbitrary length sequence.

This function performs the following operations:

```
FFT Scaling to ensure that the FFT output matches the DFT X_{re^2} + X_{im}{}^2
```

NOTES ON USE

This function works in-place so the input data is destroyed.

The imaginary input array is only used in the function, any input data is discarded.

The results are returned in the real input array.

The result array is of length (N/2)+1 because the results in bins 0 and N/2 are purely real.

```
SIF_FastAutoCrossPowerSpectrum, SDA_FastAutoPowerSpectrum, SDA_FastCrossPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SIF_MagnitudeSquaredCoherence, SDA_MagnitudeSquaredCoherence.
```

```
void SDA ArbCrossPowerSpectrum (SLData t*, Real array 1 pointer
       SLData t*,
                                          Imaginary array 1 pointer
                                          Real source array 2 pointer
       SLData t*
                                          Imaginary source array 2 pointer
       SLData t*.
       SLData t*.
                                          Real temporary array pointer
       SLData t*,
                                          Imaginary temporary array pointer
       const SLData t*
                                          Pointer to AWNr coefficients
       const SLData t*
                                          Pointer to AWNi coefficients
       const SLData t*,
                                          Pointer to WMr coefficients
       const SLData t*
                                          Pointer to WMi coefficients
       const SLData t*.
                                          Pointer to vLr coefficients
       const SLData t*.
                                          Pointer to vLi coefficients
       const SLData t*,
                                          FFT coefficient pointer
       const SLArrayIndex t*,
                                          Bit reverse mode flag / Pointer to bit
reverse address table
       const enum SLArbitraryFFT t,
                                          Switch to indicate CZT or FFT
       const SLArrayIndex t,
                                          FFT length
       const SLArrayIndex t,
                                          Log 2 FFT length
       const SLData t,
                                          Inverse FFT Size
                                          Inverse (array length * FFT length)
       const SLData t,
                                          Arbitrary FFT length
       const SLArrayIndex t)
```

DESCRIPTION

This function returns the real cross power spectrum of the supplied data.

This function performs the following operations:

```
FFTs Scaling to ensure that the FFT output matches the DFT (X_{re} . Y_{re}) + (X_{im} + Y_{im})
```

NOTES ON USE

This function works in-place so the input data is destroyed.

The imaginary input arrays are only used in the function, any input data is discarded. The results are returned in the first real input array.

If the real source array 1 pointer and the real source array 1 pointer point to the same array (i.e. auto power spectrum) then the result will be corrupted.

The result array is of length (N/2)+1 because the results in bins 0 and N/2 are purely real.

```
SIF_FastAutoCrossPowerSpectrum, SDA_FastAutoPowerSpectrum, SDA_FastCrossPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SIF_MagnitudeSquaredCoherence, SDA_MagnitudeSquaredCoherence.
```

SLError_t SIF_WelchPowerSpectrum (SLArrayIndex_t *, Pointer to overlap source array index

SLData_t *, Window array pointer

const enum SLWindow t, Window type

const SLData_t, Window coefficient SLData_t *, FFT coefficient pointer

SLArrayIndex t*, Bit reverse mode flag / Pointer to bit

reverse address table

SLData t*, Pointer to the inverse FFT length

const SLArrayIndex t, FFT length

SLData t*, Pointer to the inverse of the number of

arrays averaged

const SLArrayIndex_t) Number of arrays averaged

DESCRIPTION

This function initializes the Welch power function.

NOTES ON USE

This function returns SIGLIB_NO_ERROR if No error occurred or SIGLIB PARAMETER ERROR if the window type parameter was incorrect.

CROSS REFERENCE

SIF FastAutoCrossPowerSpectrum, SDA FastAutoPowerSpectrum,

SDA FastCrossPowerSpectrum, SDA ArbAutoPowerSpectrum,

SDA ArbCrossPowerSpectrum, SDA WelchRealPowerSpectrum,

SDA WelchComplexPowerSpectrum, SIF MagnitudeSquaredCoherence,

SDA MagnitudeSquaredCoherence.

void SDA WelchRealPowerSpectrum (const SLData t*, Pointer to source data SLData t*, Pointer to destination data SLData t*, Pointer to real internal processing array Pointer to imag. internal processing array SLData t*, SLData t*, Pointer to internal overlap array SLArrayIndex t*, Pointer to overlap source array index Overlap between successive arrays SLArrayIndex t, const SLData t*, Pointer to window coefficients const SLData t*, Pointer to FFT coefficients const SLArrayIndex t*, Bit reverse mode flag / Pointer to bit reverse address table const SLArrayIndex t, FFT length const SLArrayIndex t, Log2 FFT length const SLData t, Inverse FFT length const SLArrayIndex t, Number of arrays averaged const SLData t, Inverse of number of arrays averaged const SLArrayIndex t) Source array length

DESCRIPTION

This function returns the Welch real auto power spectrum of the supplied data. This function performs the following operations:

Overlapping of data from the source array into the FFT processing arrays Windowing

FFT

 $X_{re}^2 + X_{im}^2$

Averaging of a given number of FFT periodograms

NOTES ON USE

This function does not work in-place. The results are placed in the result array. It is important to ensure that there is enough data in the source array to avoid overflow.

The result array is of length (N/2)+1 because the results in bins 0 and N/2 are purely real.

The imaginary input array is only used in the function, any input data is discarded.

CROSS REFERENCE

SIF_FastAutoCrossPowerSpectrum, SDA_FastCrossPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SIF_MagnitudeSquaredCoherence, SDA_MagnitudeSquaredCoherence.

void SDA_WelchComplexPowerSpectrum (const SLData_t *, Ptr. to real source data const SLData t*, Pointer to imaginary source data SLData t*, Pointer to destination data Pointer to real internal processing array SLData t*, Pointer to imag. internal processing array SLData t*, SLData t*, Pointer to internal real overlap array Pointer to internal imag. overlap array SLData t*, Pointer to overlap source array index SLArrayIndex t*, SLArrayIndex t, Overlap between successive arrays const SLData t*, Pointer to window coefficients const SLData t*, Pointer to FFT coefficients const SLArrayIndex t*, Bit reverse mode flag / Pointer to bit reverse address table const SLArrayIndex t, FFT length const SLArrayIndex t, Log2 FFT length const SLData t, Inverse FFT length const SLArrayIndex t, Number of arrays averaged const SLData t, Inverse of number of arrays averaged const SLArrayIndex t) Source array length

DESCRIPTION

This function returns the Welch complex auto power spectrum of the supplied data. This function performs the following operations:

Overlapping of data from the source array into the FFT processing arrays Windowing

FFT

 $X_{re}^2 + X_{im}^2$

Averaging of a given number of FFT periodograms

NOTES ON USE

This function does not work in-place. The results are placed in the result array. It is important to ensure that there is enough data in the source array to avoid overflow.

The result array is of length (N/2)+1 because the results with real data, in bins 0 and N/2, are purely real.

CROSS REFERENCE

SIF_FastAutoCrossPowerSpectrum, SDA_FastCrossPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SIF_MagnitudeSquaredCoherence, SDA_MagnitudeSquaredCoherence.

void SIF_MagnitudeSquaredCoherence (SLData_t *, FFT coefficient pointer SLArrayIndex t *, Bit reverse mode flag / Pointer to bit

reverse address table

const SLArrayIndex t, FFT Size

SLData t*) Pointer to inverse FFT Size

DESCRIPTION

This function initializes the magnitude squared coherence function tables.

NOTES ON USE

Please refer to the documentation for the FFT functions for further details.

CROSS REFERENCE

SDA_FastAutoPowerSpectrum, SDA_FastCrossPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SDA_MagnitudeSquaredCoherence.

LData_t *, Pointer to real array 1
Pointer to internal imaginary data 1
Pointer to real source data 2
Pointer to internal imaginary data 2
Pointer to internal temporary real data 1
Pointer to internal temp. imag. data 1
Pointer to internal temporary real data 2
Pointer to internal temp. imag. data 2
Pointer to FFT coefficients
Bit reverse mode flag / Pointer to bit
FFT length
Log2 FFT length
Inverse FFT length
5

DESCRIPTION

This function returns the magnitude squared coherence of the supplied data, according to the following equation:

$$MSC(f) = \frac{|P_{xy}(f)|^2}{P_{xx}(f)P_{yy}(f)}$$

Where:

Is $P_{xy}(f)$ the cross power spectrum of inputs x[n] and y[n] and:

and $P_{xx}(f)$ are the $P_{yy}(f)$ auto power spectra of inputs x[n] and y[n]

NOTES ON USE

This function places the results in real array 1. The data in imaginary array 1 and both array 2s are destroyed.

This function does not check for numerical overflow in the internal divide operation. The imaginary input arrays are only used in the function, any input data is discarded. The result array is of length (N/2)+1 because the results in bins 0 and N/2 are purely real.

CROSS REFERENCE

SIF_FastAutoCrossPowerSpectrum, SDA_FastCrossPowerSpectrum, SIF_ArbAutoCrossPowerSpectrum, SDA_ArbAutoPowerSpectrum, SDA_ArbCrossPowerSpectrum, SIF_WelchPowerSpectrum, SDA_WelchRealPowerSpectrum, SDA_WelchComplexPowerSpectrum, SIF_MagnitudeSquaredCoherence.

Frequency Domain Filtering Functions (fdfilter.c)

SIF FirOverlapAdd

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SIF FirOverlapAdd (const SLData t*, Time Domain coeffs pointer
       SLData t*,
                                          Real freq. domain coeffs pointer
       SLData t*,
                                          Imag. freq. domain coeffs pointer
                                          Overlap array pointer
       SLData t*,
                                          FFT coefficients pointer
       SLData t*,
       SLArrayIndex t*,
                                          FFT Bit reverse mode flag / Pointer to bit
reverse address table
       SLData t*,
                                          Pointer to inverse FFT length
       const SLArrayIndex t,
                                          FFT Length
       const SLArrayIndex t,
                                          Log10 FFT Length
       const SLArrayIndex t)
                                          Filter length
```

DESCRIPTION

This function initializes the frequency domain overlap-add function. The primary role for this function is to convert the time domain coefficients to the frequency domain and prepare the overlap array.

The overlap array must be of length "filter length -1".

NOTES ON USE

The FFT length must be greater than (Input length + Filter Length - 1).

CROSS REFERENCE

SDA FirOverlapAdd.

```
void SDA FirOverlapAdd (const SLData t*,
                                                  Source data pointer
       SLData t*,
                                          Destination data pointer
       const SLData t*,
                                          Real freq. domain coeffs pointer
       const SLData t*,
                                          Imaginary freq. domain coeffs pointer
       SLData t*,
                                          Overlap array pointer
       SLData t*,
                                          Temporary array pointer
                                          FFT coefficients pointer
       SLData t*,
       SLArrayIndex t*,
                                          FFT Bit reverse mode flag / Pointer to bit
reverse address table
       const SLData t,
                                          Inverse FFT length
       const SLArrayIndex t,
                                          FFT Length
       const SLArrayIndex t,
                                          Log 10 FFT Length
       const SLArrayIndex t,
                                          Filter length
       const SLArrayIndex t)
                                          Data set length
```

DESCRIPTION

This function implements the frequency domain overlap-add function. The continuous time domain data stream is split into blocks and the Fourier transform performed on the blocks. The final results are identical to those obtained with time domain filtering.

NOTES ON USE

The FFT length must be greater than (Input length + Filter Length - 1).

The processing delay is greater than the delay experienced with time domain filtering.

The overlap array must be of length "filter length -1".

CROSS REFERENCE

SIF FirOverlapAdd.

```
void SIF FirOverlapSave (const SLData t*,
                                                 Time Domain coeffs pointer
       SLData t*,
                                          Real freq. domain coeffs pointer
       SLData t*,
                                          Imag. freq. domain coeffs pointer
                                          Overlap array pointer
       SLData t*,
      SLData t*,
                                          FFT coefficients pointer
       SLArrayIndex t*,
                                          FFT Bit reverse mode flag / Pointer to bit
reverse address table
      SLData t*,
                                          Pointer to inverse FFT length
       const SLArrayIndex t,
                                          FFT Length
       const SLArrayIndex t,
                                          Log10 FFT Length
                                          Filter length
       const SLArrayIndex t)
```

DESCRIPTION

This function initializes the frequency domain overlap-save function. The primary role for this function is to convert the time domain coefficients to the frequency domain and prepare the overlap array.

NOTES ON USE

The FFT length must be greater than (Input length + Filter Length - 1). The array length must be greater than or equal to the length on the filter.

The overlap array must be of length "FFT length".

CROSS REFERENCE

SDA FirOverlapSave.

```
void SDA FirOverlapSave (const SLData t*,
                                                  Source data pointer
       SLData t*,
                                          Destination data pointer
       const SLData t*,
                                          Real freq. domain coeffs pointer
       const SLData t*,
                                          Imaginary freq. domain coeffs pointer
       SLData t*,
                                          Overlap array pointer
       SLData t*,
                                          Temporary array pointer
                                          FFT coefficients pointer
       SLData t*,
                                          FFT Bit reverse mode flag / Pointer to bit
       SLArrayIndex t*,
reverse address table
       const SLData t,
                                          Inverse FFT length
       const SLArrayIndex t,
                                          FFT Length
       const SLArrayIndex t,
                                          Log 10 FFT Length
       const SLArrayIndex t,
                                          Filter length
       const SLArrayIndex t)
                                          Data set length
```

DESCRIPTION

This function implements the frequency domain overlap-save function. The continuous time domain data stream is split into blocks and the Fourier transform performed on the blocks. The final results are identical to those obtained with time domain filtering.

NOTES ON USE

The FFT length must be greater than (Input length + Filter Length - 1). The array length must be greater than or equal to the length on the filter.

The processing delay is greater than the delay experienced with time domain filtering.

The overlap array must be of length "FFT length".

CROSS REFERENCE

SIF FirOverlapSave.

void SIF_FftConvolvePre (const SLData_t *, Pointer to time domain filter coeffs SLData_t *, Pointer to real freq. domain filter coeffs SLData_t *, Pointer to imag freq. domain filter coeffs SLData_t *, Pointer to imag freq. domain filter coeffs Pointer to FFT coefficients Pointer to FFT coefficients Pointer to bit reverse address table const SLArrayIndex_t, Filter length const SLArrayIndex_t, FFT length Log 2 FFT length

DESCRIPTION

This function initializes the frequency convolution function (SDA_FftConvolvePre).

This function converts the time domain filter coefficients to the frequency domain.

NOTES ON USE

The FFT length must be greater than (N + M - 1). Where N and M are the lengths of the two time domain arrays provided to the function SDA_FftConvolvePre.

The processing delay is greater than the delay experienced with time domain convolution.

CROSS REFERENCE

SDA_FftConvolvePre, SDA_FftConvolveArb, SIF_FftCorrelatePre, SDA_FftCorrelatePre, SDA_FftCorrelateArb.

void SDA FftConvolvePre (SLData t*, Pointer to real time domain source data SLData t*, Pointer to imag time domain source data Pointer to real freq. domain filter coeffs SLData t*, Pointer to imag freq. domain filter coeffs SLData t*, Pointer to destination array SLData t*, const SLData t*, Pointer to FFT coefficients const SLArrayIndex t*, Pointer to bit reverse address table const SLArrayIndex t, Source length const SLArrayIndex t, Filter length const SLArrayIndex t, FFT length Log 2 FFT length const SLArrayIndex t, const SLData t) Inverse FFT length

DESCRIPTION

This function performs the frequency convolution function of two discrete time domain sequences.

The time domain filter coefficients are pre-converted to the frequency domain using the function SIF_FftConvolvePre so this function is more efficient than performing the time domain to frequency domain conversion on both time domain sequences.

NOTES ON USE

The FFT length must be greater than (N + M - 1). Where N and M are the lengths of the two time domain arrays provided to the function.

The processing delay is greater than the delay experienced with time domain convolution.

The data in the source arrays is destroyed when this function is called. This function is not able to process the data "in-place".

CROSS REFERENCE

SIF_FftConvolvePre, SDA_FftConvolveArb, SIF_FftCorrelatePre, SDA_FftCorrelatePre, SDA_FftCorrelateArb.

```
Pointer to real time domain source data 1
void SDA FftConvolveArb (SLData t*,
       SLData t*,
                                           Pointer to imag. time domain src data 1
                                           Pointer to real time domain source data 2
       SLData t*,
                                           Pointer to imag. time domain src data 2
       SLData t*,
                                           Pointer to destination array
       SLData t*,
       const SLData t*,
                                           Pointer to FFT coefficients
       const SLArrayIndex t*,
                                           Pointer to bit reverse address table
       const SLArrayIndex t,
                                           Source 1 length
       const SLArrayIndex t,
                                           Source 2 length
       const SLArrayIndex t,
                                           FFT length
                                           Log 2 FFT length
       const SLArrayIndex t,
       const SLData t)
                                           Inverse FFT length
```

DESCRIPTION

This function performs the frequency convolution function of two discrete time domain sequences.

NOTES ON USE

The FFT length must be greater than (N + M - 1). Where N and M are the lengths of the two time domain arrays provided to the function.

The processing delay is greater than the delay experienced with time domain convolution.

The data in the source arrays is destroyed when this function is called. This function is not able to process the data "in-place".

```
SIF_FftConvolvePre, SDA_FftConvolvePre, SIF_FftCorrelatePre, SDA_FftCorrelatePre, SDA_FftCorrelateArb.
```

void SIF_FftCorrelatePre (const SLData_t *,Pointer to time domain filter coefficients SLData_t *, Pointer to real freq. domain filter coeffs SLData_t *, Pointer to imag freq. domain filter coeffs SLData_t *, Pointer to imag freq. domain filter coeffs Pointer to FFT coefficients Pointer to FFT coefficients Pointer to bit reverse address table const SLArrayIndex_t, Filter length const SLArrayIndex_t, FFT length Log 2 FFT length

DESCRIPTION

This function initializes the frequency correlation function (SDA_FftCorrelatePre).

This function converts the time domain sequence to the frequency domain.

NOTES ON USE

The FFT length must be greater than (N + M - 1). Where N and M are the lengths of the two time domain arrays provided to the function.

The processing delay is greater than the delay experienced with time domain correlation SDA FftCorrelatePre.

CROSS REFERENCE

SIF_FftConvolvePre, SDA_FftConvolvePre, SDA_FftConvolveArb, SDA_FftCorrelatePre, SDA_FftCorrelateArb.

```
void SDA FftCorrelatePre (SLData t*,
                                           Pointer to real time domain source data
       SLData t*,
                                           Pointer to imag time domain source data
       SLData t*,
                                           Pointer to real freq. domain filter coeffs
                                           Pointer to imag freq. domain filter coeffs
       SLData t*.
                                           Pointer to destination array
       SLData t*,
       const SLData t*,
                                           Pointer to FFT coefficients
       const SLArrayIndex t*,
                                           Pointer to bit reverse address table
       const SLArrayIndex_t,
                                           Source length
       const SLArrayIndex t,
                                           Filter length
       const SLArrayIndex t,
                                           FFT length
       const SLArrayIndex t,
                                           Log 2 FFT length
       const SLData t)
                                           Inverse FFT length
```

DESCRIPTION

This function performs the frequency domain correlation of two discrete time domain sequences.

The time domain filter coefficients are pre-converted to the frequency domain using the function SIF_FftCorrelatePre so this function is more efficient than performing the time domain to frequency domain conversion on both time domain sequences.

NOTES ON USE

The FFT length must be greater than (N + M - 1). Where N and M are the lengths of the two time domain arrays provided to the function.

The processing delay is greater than the delay experienced with time domain filtering.

The data in the source arrays is destroyed when this function is called. This function is not able to process the data "in-place".

CROSS REFERENCE

SIF_FftConvolvePre, SDA_FftConvolvePre, SDA_FftConvolveArb, SIF_FftCorrelatePre, SDA_FftCorrelateArb.

```
void SDA FftCorrelateArb (SLData_t *,
                                           Pointer to real time domain source data 1
       SLData t*,
                                           Pointer to imag time domain src. data 1
                                           Pointer to real time domain source data 2
       SLData t*,
                                           Pointer to imag time domain src. data 2
       SLData t*,
                                           Pointer to destination array
       SLData t*,
       const SLData t*,
                                           Pointer to FFT coefficients
       const SLArrayIndex t*,
                                           Pointer to bit reverse address table
       const SLArrayIndex t,
                                           Source 1 length
       const SLArrayIndex t,
                                           Source 2 length
       const SLArrayIndex t,
                                           FFT length
                                           Log 2 FFT length
       const SLArrayIndex t,
       const SLData t)
                                           Inverse FFT length
```

DESCRIPTION

This function performs the frequency domain correlation of two discrete time domain sequences.

NOTES ON USE

The FFT length must be greater than (N + M - 1). Where N and M are the lengths of the two time domain arrays provided to the function.

The processing delay is greater than the delay experienced with time domain filtering.

The data in the source arrays is destroyed when this function is called. This function is not able to process the data "in-place".

CROSS REFERENCE

SIF_FftConvolvePre, SDA_FftConvolvePre, SDA_FftConvolveArb, SIF_FftCorrelatePre, SDA_FftCorrelatePre.

CHIRP Z-TRANSFORM FUNCTIONS (chirpz.c)

The contour used for the chirp z-transform is defined as:


$$z_k = AW^{-k}$$
 $k=0,1,...,M-1$

A and W are complex numbers of the type:

$$W = W_0 e^{-j\phi_0}$$

$$A = A_0 e^{j\theta_0}$$

The Chirp z-transform



SIF_Czt

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SIF Czt (SLData t*,
                                           AWNr coefficients pointer
       SLData t*,
                                           AWNi coefficients pointer
       SLData t*,
                                           WMr coefficients pointer
                                           WMi coefficients pointer
       SLData t*.
       SLData t*,
                                           vLr coefficients pointer
       SLData t*,
                                           vLi coefficients pointer
                                           FFT coefficient pointer
       SLData t*,
       SLArrayIndex t*,
                                           Bit reverse mode flag / Pointer to bit
reverse address table
       const SLData t,
                                           Contour start radius
       const SLData t,
                                           Contour decay rate
                                           Contour start frequency
       const SLData t,
                                           Contour end frequency
       const SLData t,
                                           Sample rate (Hz)
       const SLData t,
       const SLArrayIndex t,
                                           Source array lengths
                                           Destination array lengths
       const SLArrayIndex t,
       const SLArrayIndex t,
                                           FFT length
                                           log2 FFT length
       const SLArrayIndex t)
```

DESCRIPTION

This function initializes the coefficients for the Chirp z-Transform, according to the contour specification supplied.

NOTES ON USE

The FFT length must be greater than (Input length + Output Length - 1). The contour spirals in for decays < 0 and out for decays > 0. The sampling, start and end frequencies should all be in the same units, usually Hertz.

This function requires that the FFT coefficient array at least the length of the largest FFT length. I.E. the next largest power of 2 that is greater than or equal to twice the length of the input data set.

CROSS REFERENCE

SIF_VI, SIF_Awn, SIF_Wm.

SIF_Awn

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Awn (SLData_t *, Real coefficient pointer SLData_t *, Imaginary coefficient pointer

 $\begin{array}{ll} const \ Complex, & A \ ^{(-1)} \\ const \ Complex, & W \\ const \ Complex, & W ^{(1/2)} \\ const \ SLArrayIndex_t) & Array \ length \end{array}$

DESCRIPTION

This function generates the complex window coefficients for the Chirp z-Transform.

NOTES ON USE

CROSS REFERENCE

SIF_V1, SIF_Wm, SIF_Czt.

SIF_VI

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Vl (SLData_t *, Real coefficient pointer SLData_t *, Imaginary coefficient pointer const Complex, W^(-1)
const Complex, W^(-1/2)
const SLArrayIndex_t, Source array length const SLArrayIndex_t, Destination array length const SLArrayIndex_t)
FFT array length

DESCRIPTION

This function generates the contour definition coefficients for the Chirp z-Transform.

NOTES ON USE

CROSS REFERENCE

SIF_Awn, SIF_Wm, SIF_Czt.

SIF_Wm

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Wm (SLData_t *, Real coefficient pointer

SLData_t *, Imaginary coefficient pointer

const Complex, W

const Complex, W^(1/2) const SLArrayIndex_t) Array length

DESCRIPTION

This function generates the weighting coefficients for the Chirp z-Transform.

NOTES ON USE

CROSS REFERENCE

SIF_Vl, SIF_Awn, SIF_Czt.

WINDOWING FUNCTIONS (window.c)

SIF Window

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function initializes the window coefficient array. The window types are defined as follows:

Enumerated type	Window type
SIGLIB_HANNING	Hanning
SIGLIB_HAMMING	Hamming
SIGLIB_GENERALIZED_COSINE	Generalized cosine
SIGLIB_BLACKMAN	Blackman
SIGLIB_BARTLETT_TRIANGLE_ZERO_END_POINTS	Bartlett / triangle with zero
	end points
SIGLIB_BARTLETT_TRIANGLE_NON_ZERO_END_POINTS	Bartlett / triangle with non-
	zero end points
SIGLIB_KAISER	Kaiser
SIGLIB_BLACKMAN_HARRIS	4th order Blackman-Harris
SIGLIB_RECTANGLE	Rectangle / none
SIGLIB_FLAT_TOP	Flat top

The window coefficient parameter is used to supply the beta coefficient to the Kaiser window. It is now used for any of the other window functions.

NOTES ON USE

This function returns SIGLIB_PARAMETER_ERROR if an incorrect window type is specified, otherwise it returns SIGLIB_NO_ERROR.

CROSS REFERENCE


SDA_Window, SDA_ComplexWindow, SDA_WindowInverseCoherentGain, SDA_WindowEquivalentNoiseBandwidth, SDA_WindowProcessingGain, SDS_I0Bessel.

SLError_t SIF_TableTopWindow (SLData_t *, Window array pointer const enum SLWindow_t, Window type const SLData_t, Window coefficient const SLArrayIndex_t, Table top length const SLArrayIndex t) Window length

DESCRIPTION

This function initializes the window coefficient array. Please refer to the function SIF_Window for a list of the window types supported.

The window generated will have a flat "table top" section in the middle of the array so the coefficient array will look like the following diagram:



The window coefficient parameter is used to supply the beta coefficient to the Kaiser window. It is now used for any of the other window functions.

NOTES ON USE

This function returns SIGLIB_PARAMETER_ERROR if an incorrect window type is specified, otherwise it returns SIGLIB NO ERROR.

CROSS REFERENCE

SDA_Window, SDA_ComplexWindow, SDA_WindowInverseCoherentGain, SDA_WindowEquivalentNoiseBandwidth, SDA_WindowProcessingGain, SDS_I0Bessel.

SDA_Window

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Window (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t *, Window array pointer const SLArrayIndex_t) Window length

DESCRIPTION

This function applies a window to the time domain array, prior to performing the FFT.

NOTES ON USE

The functions SIF_Window or SIF_TableTopWindow should be called prior to calling this function.

This function can operate in-place.

CROSS REFERENCE

SIF_Window, SIF_TableTopWindow, SDA_ComplexWindow, SDA_WindowInverseCoherentGain, SDA_WindowEquivalentNoiseBandwidth, SDA_WindowProcessingGain.

void SDA_ComplexWindow (const SLData_t *, Real source pointer
const SLData_t *, Imaginary source array pointer
SLData_t *, Real destination array pointer
SLData_t *, Imaginary destination array pointer
const SLData_t *, Real window array pointer
const SLData_t *, Imaginary window array pointer
const SLData_t *, Imaginary window array pointer
const SLArrayIndex_t) Window length

DESCRIPTION

This function applies window to the time domain array, prior to performing the FFT.

NOTES ON USE

This function can operate in-place.

The same window can be applied to both real and imaginary streams if the real and imaginary window pointers point to the same window array.

CROSS REFERENCE

SIF_Window, SDA_Window, SDA_WindowInverseCoherentGain, SDA WindowEquivalentNoiseBandwidth, SDA WindowProcessingGain.

SLData_t SDA_WindowInverseCoherentGain (const SLData_t *, Window data ptr. const SLArrayIndex_t) Window length

DESCRIPTION

This function returns the inverse coherent gain of the window, so that the gain can be normalised.

NOTES ON USE

CROSS REFERENCE

SIF_Window, SDA_Window, SDA_ComplexWindow, SDA_WindowEquivalentNoiseBandwidth, SDA_WindowProcessingGain.

SLData_t SDA_WindowEquivalentNoiseBandwidth (const SLData_t *, Window data pointer

const SLArrayIndex_t)

Window length

DESCRIPTION

This function returns the equivalent noise bandwidth (ENBW) of the window.

NOTES ON USE

CROSS REFERENCE

SIF_Window, SDA_Window, SDA_ComplexWindow, SDA_WindowInverseCoherentGain, SDA_WindowProcessingGain.

SLData_t SDA_WindowProcessingGain (const SLData_t *, Window data pointer const SLArrayIndex_t) Window length

DESCRIPTION

This function returns the processing gain of the window.

NOTES ON USE

CROSS REFERENCE

SIF_Window, SDA_Window, SDA_ComplexWindow, SDA_WindowInverseCoherentGain, SDA_WindowEquivalentNoiseBandwidth.

void SDS_I0Bessel (const) x

DESCRIPTION

This function returns the modified Bessel function I0(x).

NOTES ON USE

CROSS REFERENCE

SIF_Window, SDA_Window, SDA_ComplexWindow.

FIXED COEFFICIENT FILTER FUNCTIONS

FIR Filtering Functions (firfilt.c)

SIF Fir

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Fir (SLData_t *, Pointer to filter state array SLArrayIndex_t *, Pointer to filter index offset const SLArrayIndex t) Filter length

DESCRIPTION

This function initializes the FIR filter functionality and clears the state array and filter offset to zero.

NOTES ON USE

CROSS REFERENCE

SDS_Fir, SDA_Fir, SIF_FirWithStore, SDS_FirWithStore, SDA_FirWithStore, SDS_FirAddSample

SDS_Fir

PROTOTYPE AND PARAMETER DESCRIPTION


SLData_t SDS_Fir (const SLData_t, SLData_t *, Pointer to filter state array Pointer to filter coefficients SLArrayIndex_t *, Pointer to filter index offset const SLArrayIndex_t)

SLData_t *, Pointer to filter coefficients Pointer to filter index offset Filter length

DESCRIPTION

This function performs FIR filtering on a data sample. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

FIR Filter Structure



NOTES ON USE

The traditional method of viewing the state array is as a bucket brigade FIFO array, with data flowing in one end and falling out the other. On DSP devices that implement modulo addressing it is more efficient to use a circular array, so that for each new sample all the data does not have to be shifted up. For this reason each time the SDA_Fir function is called the current array pointer must be known. In order to make this function reusable it is necessary that each instance has a separate state array pointer, the address of which is passed to the function at call time.

Use of this function showed that the explicit test and modify for the array pointers, reaching the end of the array was more computationally efficient than using the modulo operator, which was usually handled via a function call.

SIF_Fir should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF_Fir, SDA_Fir, SIF_FirWithStore, SDS_FirWithStore, SDA_FirWithStore, SDS_FirAddSample

SDA_Fir


PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Fir (const SLData_t *,	Input array to be filtered
SLData_t *,	Filtered output array
SLData_t *,	Pointer to filter state array
const SLData_t *,	Pointer to filter coefficients
SLArrayIndex_t *,	Pointer to filter index offset
<pre>const SLArrayIndex_t,</pre>	Filter length
<pre>const SLArrayIndex_t)</pre>	Array length

DESCRIPTION

This function performs an FIR filtering on the array. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

FIR Filter Structure



NOTES ON USE

The traditional method of viewing the state array is as a bucket brigade FIFO array, with data flowing in one end and falling out the other. On DSP devices that implement modulo addressing it is more efficient to use a circular array, so that for each new sample all the data does not have to be shifted up. For this reason each time the SDA_Fir function is called the current array pointer must be known. In order to make this function reusable it is necessary that each instance has a separate state array pointer, the address of which is passed to the function at call time.

The input and output array pointers can point to the same array. SIF_Fir should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF_Fir, SDS_Fir, SIF_FirWithStore, SDS_FirWithStore, SDA_FirWithStore, SDS_FirAddSample

void SDS_FirAddSample (const SLData_t, Sample to add to delay line SLData_t *, Pointer to filter state array SLArrayIndex_t *, Pointer to filter index offset const SLArrayIndex_t) Filter length

DESCRIPTION

This function adds a new input sample into the filter delay line, without calculating the new output sample, thus saving a whole load of multiply accumulate functions.

NOTES ON USE

If you want to add samples to a complex FIR filter then this function should be called separately for the real sample/state array and the imaginary sample/state array.

CROSS REFERENCE

SIF_Fir, SDS_Fir, SDA_Fir, SIF_FirComplex, SDS_FirComplex, SDA_FirComplex

void SDA_FirAddSamples (const SLData_t *, Array of samples to add to delay line

SLData_t *, Pointer to filter state array SLArrayIndex t *, Pointer to filter index register

const SLArrayIndex t, Filter length

const SLArrayIndex t) Source array length

DESCRIPTION

This function adds a new input array of samples into the filter delay line, without calculating the new output sample, thus saving a whole load of multiply accumulate functions.

NOTES ON USE

If you want to add samples to a complex FIR filter then this function should be called separately for the real sample/state array and the imaginary sample/state array.

CROSS REFERENCE

SIF_Fir, SDS_Fir, SDA_Fir, SDS_FirAddSample, SIF_FirComplex, SDS_FirComplex, SDA_FirComplex

SIF_Comb

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Comb (SLData_t *, Pointer to filter state array SLArrayIndex_t *, Pointer to filter index register SLData_t *, Pointer to filter sum register const SLArrayIndex_t) Filter length

DESCRIPTION

This function initializes an N delay comb (moving average) filter functionality and clears the state array, filter index and filter sum to zero.

Comb filter output =
$$\sum_{n=0}^{n-N-1} x(n)$$

NOTES ON USE

This is a very efficient filter form, giving complete nulls at a frequency equal to the sample rate (Hz) divided by the delay length and it's harmonics.

When calculating the moving average it is common to expect the output to be:

Moving Average =
$$\sum_{n=0}^{n-N-1} x(n) / N$$

The only difference between the result returned from the Comb filter and the moving average sequences is the divide by N. The reason that the divide by N is not commonly calculated in DSP is because the divide operation is very expensive in terms of MIPS and the difference is purely in the scaling of the output. If you wish to account for the scaling then the easiest way to do it is to perform the following operation:

```
SDA_Multiply (DstArray, DstArray, INVERSE_COMB_FILTER_LENGTH, SAMPLE_LENGTH)
```

A more run-time efficient solution is to perform all of the DSP operations and leave the scaling to the very end.

CROSS REFERENCE

SDS Comb, SDA Comb

SDS_Comb

PROTOTYPE AND PARAMETER DESCRIPTION

```
SLData_t SDS_Comb (const SLData_t, SLData_t *, Pointer to filter state array SLArrayIndex_t *, Filter index pointer SLData_t *, Filter sum register pointer const SLArrayIndex_t) Filter length
```

DESCRIPTION

This function performs a comb (moving average) filter on a data sample. The filter will output the running sum of the previous N samples of the input signal.

NOTES ON USE

Please refer to SIF_Comb for further information.

CROSS REFERENCE

SIF_Comb, SDA_Comb

SDA_Comb

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDA_Comb (const SLData_t *, Source array pointer
SLData_t *, Destination array pointer
SLData_t *, Pointer to filter state array
SLArrayIndex_t *, Pointer to filter index register
SLData_t *, Pointer to filter sum register
const SLArrayIndex_t, Filter length
const SLArrayIndex_t) Array length
```

DESCRIPTION

This function performs a comb (moving average) filter on the data in the source array. The filter will output the running sum of the previous N samples of the input signal.

NOTES ON USE

Please refer to SIF_Comb for further information.

CROSS REFERENCE

SIF_Comb, SDS_Comb

void SIF_FirComplex (SLData_t *, Real Pointer to filter state array SLData_t *, Imaginary Pointer to filter state array SLArrayIndex_t *, Pointer to filter index register const SLArrayIndex_t)

Filter length

DESCRIPTION

This function initializes complex FIR filter functionality and clears the state arrays and filter index to zero.

NOTES ON USE

CROSS REFERENCE

SDS_FirComplex, SDA_FirComplex

```
Real input data sample
void SDS FirComplex (const SLData t*,
       const SLData t*,
                                           Imaginary input data sample
                                           Pointer to real destn. sample location
       SLData t*,
                                           Pointer to imag. destn. sample location
       SLData t*,
                                           Real state array pointer
       SLData t*,
       SLData t*,
                                           Imaginary state array pointer
       const SLData t*,
                                           Real coefficient array pointer
       const SLData t*,
                                           Imaginary coefficient array pointer
       SLArrayIndex t*,
                                           Filter index
                                           Filter length
       const SLArrayIndex t)
```

DESCRIPTION

This function performs a complex FIR filter on a complex data sample. The coefficients (taps) for the FIR filter are in the form of two linear arrays (real and imaginary) of N points, where N is the filter length.

NOTES ON USE

The real and imaginary components of the complex result are returned in the locations pointed to by the destination pointers.

The traditional method of viewing the state arrays is as a bucket brigade FIFO array, with data flowing in one end and falling out the other. For execution efficiency however it is more efficient to use a circular array, so that for each new sample all the data does not have to be shifted up. For this reason each time the SDS_FirComplex function is called the current array pointer must be known. In order to make this function reusable it is necessary that each instance has a separate state array pointer, the address of which is passed to the function at call time.

The input and output array pointers can point to the same array.

SIF_FirComplex should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

```
SIF\_FirComplex, SDA\_FirComplex, SDS\_FirAddSample, SDA\_FirAddSamples
```

```
Real input data to be filtered
void SDA FirComplex (const SLData t*,
       const SLData t*,
                                           Imaginary input data to be filtered
                                           Real destination array pointer
       SLData t*,
                                           Imaginary destination array pointer
       SLData t*,
                                           Real state array pointer
       SLData t*,
                                           Imaginary state array pointer
       SLData t*,
                                           Real coefficient array pointer
       const SLData t*,
       const SLData t*,
                                           Imaginary coefficient array pointer
       SLArrayIndex t*,
                                           Filter index
       const SLArrayIndex t,
                                           Filter length
       const SLArrayIndex t)
                                           Array length
```

DESCRIPTION

This function performs a complex FIR filter on a complex datthe array. The coefficients (taps) for the FIR filter are in the form of two linear arrays of N points (real and imaginary), where N is the filter length.

NOTES ON USE

The traditional method of viewing the state arrays is as a bucket brigade FIFO array, with data flowing in one end and falling out the other. For execution efficiency however it is more efficient to use a circular array, so that for each new sample all the data does not have to be shifted up. For this reason each time the SDA_FirComplex function is called the current array pointer must be known. In order to make this function reusable it is necessary that each instance has a separate state array pointer, the address of which is passed to the function at call time.

The input and output array pointers can point to the same array.

SIF_FirComplex should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

```
SIF_FirComplex, SDS_FirComplex, SDS_FirAddSample, SDA_FirAddSamples
```

void SIF_FirWithStore (SLData_t *, Pointer to filter state array const SLArrayIndex_t) Filter length

DESCRIPTION

This function initializes FIR With Store filter functionality and clears the state array to zero.

NOTES ON USE

CROSS REFERENCE


SDS_FirWithStore, SDA_FirWithStore, SIF_Fir, SDS_Fir, SDA_Fir, SDS_FirAddSample

SLData_t SDS_FirWithStore (const SLData_t, Input data sample to be filtered SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients const SLArrayIndex t) Filter length

DESCRIPTION

This function performs an FIR filter on a data sample. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

FIR Filter Structure



NOTES ON USE

This function implements the traditional method of viewing the state array, as a bucket brigade FIFO array, with data flowing in one end and falling out the other. This means that this implementation performs additional stores for the filter state but can be more efficient on architectures that do not support modulo data addressing.

The input and output array pointers can point to the same array.

SIF_FirWithStore should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE


SIF_FirWithStore, SDA_FirWithStore, SIF_Fir, SDS_Fir, SDA_Fir, SDS FirAddSample

void SDA_FirWithStore (const SLData_t *, Input array to be filtered SLData_t *, Filtered output array SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients SLArrayIndex_t *, Pointer to filter index offset const SLArrayIndex_t, Filter length const SLArrayIndex_t) Array length

DESCRIPTION

This function performs an FIR filter on the array. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

FIR Filter Structure



NOTES ON USE

This function implements the traditional method of viewing the state array, as a bucket brigade FIFO array, with data flowing in one end and falling out the other. This means that this implementation performs additional stores for the filter state but can be more efficient on architectures that do not support modulo data addressing.

The input and output array pointers can point to the same array.

SIF_FirWithStore should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

 $SIF_FirWithStore, SDS_FirWithStore, SIF_Fir, SDS_Fir, SDA_Fir, SDS_FirAddSample$

void SIF_FirComplexWithStore (SLData_t *, Real Pointer to filter state array SLData_t *, Imaginary Pointer to filter state array const SLArrayIndex_t) Filter length

DESCRIPTION

This function initializes complex FIR With Store filter functionality and clears the state arrays and filter index to zero.

NOTES ON USE

CROSS REFERENCE

 $SDS_FirComplexWithStore, SDA_FirComplexWithStore$

void SDS FirComplexWithStore (const SLData t*, Real input data sample const SLData t*, Imaginary input data sample SLData t*, Pointer to real destn. sample location Pointer to imag. destn. sample location SLData t*, Real state array pointer SLData t*, SLData t*, Imaginary state array pointer const SLData t*, Real coefficient array pointer const SLData t*, Imaginary coefficient array pointer const SLArrayIndex t) Filter length

DESCRIPTION

This function performs a complex FIR With Store filter on a complex data sample. The coefficients (taps) for the FIR filter are in the form of two linear arrays (real and imaginary) of N points, where N is the filter length.

NOTES ON USE

The real and imaginary components of the complex result are returned in the locations pointed to by the destination pointers.

This function implements the traditional method of viewing the state array, as a bucket brigade FIFO array, with data flowing in one end and falling out the other. This means that this implementation performs additional stores for the filter state but can be more efficient on architectures that do not support modulo data addressing.

The input and output array pointers can point to the same array.

SIF_FirComplexWithStore should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF_FirComplexWithStore, SDA_FirComplexWithStore, SDS_FirAddSampleWithStore, SDA_FirAddSamplesWithStore

void SDA_FirComplexWithStore (const SLData_t *, Real input data to be filtered

const SLData t*, Imaginary input data to be filtered Real destination array pointer SLData t*, Imaginary destination array pointer SLData t*, SLData t*, Real state array pointer Imaginary state array pointer SLData t*, Real coefficient array pointer const SLData t*, const SLData t*, Imaginary coefficient array pointer const SLArrayIndex t, Filter length Array length const SLArrayIndex t)

DESCRIPTION

This function performs a complex FIR With Store filter on a complex datthe array. The coefficients (taps) for the FIR filter are in the form of two linear arrays of N points (real and imaginary), where N is the filter length.

NOTES ON USE

This function implements the traditional method of viewing the state array, as a bucket brigade FIFO array, with data flowing in one end and falling out the other. This means that this implementation performs additional stores for the filter state but can be more efficient on architectures that do not support modulo data addressing.

The input and output array pointers can point to the same array.

SIF_FirComplexWithStore should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF_FirComplexWithStore, SDS_FirComplexWithStore, SDS FirAddSampleWithStore, SDA FirAddSamplesWithStore

void SDS_FirAddSampleWithStore (const SLData_t, Sample to add to delay line

SLData_t *, Pointer to filter state array

const SLArrayIndex t) Filter length

DESCRIPTION

This function adds a new input sample into the filter delay line, without calculating the new output sample, thus saving a whole load of multiply accumulate functions.

NOTES ON USE

If you want to add samples to a complex FIR filter then this function should be called separately for the real sample/state array and the imaginary sample/state array.

CROSS REFERENCE

SIF_FirWithStore, SDS_FirWithStore, SDA_FirWithStore, SIF FirComplexWithStore, SDS_FirComplexWithStore, SDA_FirComplexWithStore

void SDA_FirAddSamplesWithStore (const SLData_t *, Array of samples to add to delay line

SLData t*, Pointer to filter state array

const SLArrayIndex t, Filter length

const SLArrayIndex_t) Source array length

DESCRIPTION

This function adds a new input array of samples into the filter delay line, without calculating the new output sample, thus saving a whole load of multiply accumulate functions.

NOTES ON USE

If you want to add samples to a complex FIR filter then this function should be called separately for the real sample/state array and the imaginary sample/state array.

CROSS REFERENCE

SIF_FirWithStore, SDS_FirWithStore, SDA_FirWithStore, SIF FirComplexWithStore, SDS FirComplexWithStore, SDA FirComplexWithStore

```
void SIF_FirExtendedArray (SLData_t *, Pointer to filter state array Pointer to filter coefficients SLData_t *, Pointer to filter processing coefficients SLArrayIndex_t *, Pointer to filter processing coefficients Pointer to filter index offset Filter length
```

DESCRIPTION

This function initializes FIR filter with extended state and coefficient array functionality and clears the state array and filter offset to zero.

NOTES ON USE

The extended array functions use double length coefficient processing and state arrays to reduce the circular buffer overhead. These arrays should be created using the function SUF FirExtendedArrayAllocate().

CROSS REFERENCE

```
SDS_FirExtendedArray, SDA_FirExtendedArray, SIF_FirComplexExtendedArray, SDS_FirComplexExtendedArray, SDA_FirComplexExtendedArray, SDS_FirExtendedArrayAddSample, SDA_FirExtendedArrayAddSamples
```

SLData t SDS FirExtendedArray (const SLData t, Input data sample to be filtered

SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients SLArrayIndex_t *, Pointer to filter index offset

const SLArrayIndex t) Filter length

DESCRIPTION

This function performs the FIR filter with extended state and coefficient array on a data sample. The coefficients (taps) for the FIR filter are in the form of a duplicated linear array of 2xN points, where N is the filter length.

NOTES ON USE

The extended array functions use double length coefficient processing and state arrays to reduce the circular buffer overhead. These arrays should be created using the function SUF_FirExtendedArrayAllocate(). This algorithm requires additional memory for the filter state and coefficients but can be more efficient on architectures that do not support modulo data addressing.

SIF_FirExtendedArray() should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF_FirExtendedArray, SDA_FirExtendedArray, SIF_FirComplexExtendedArray, SDS_FirComplexExtendedArray, SDA_FirExtendedArrayAddSample, SDA_FirExtendedArrayAddSamples

void SDA_FirExtendedArray (const SLData_t *, Input array to be filtered

SLData_t *, Filtered output array
SLData_t *, Pointer to filter state array
const SLData_t *, Pointer to filter coefficients
SLArrayIndex_t *, Pointer to filter index offset

const SLArrayIndex_t, Filter length const SLArrayIndex_t) Array length

DESCRIPTION

This function performs the FIR filter with extended state and coefficient array on a datthe array. The coefficients (taps) for the FIR filter are in the form of a duplicated linear array of 2xN points, where N is the filter length.

NOTES ON USE

The extended array functions use double length coefficient processing and state arrays to reduce the circular buffer overhead. These arrays should be created using the function SUF_FirExtendedArrayAllocate(). This algorithm requires additional memory for the filter state and coefficients but can be more efficient on architectures that do not support modulo data addressing.

SIF_FirExtendedArray() should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF_FirExtendedArray, SDS_FirExtendedArray, SIF_FirComplexExtendedArray, SDS_FirComplexExtendedArray, SDA_FirComplexExtendedArray, SDS_FirExtendedArrayAddSample, SDA_FirExtendedArrayAddSamples

```
void SIF_FirComplexExtendedArray (SLData_t *, Real Pointer to filter state array
       SLData t*,
                                             Imaginary Pointer to filter state array
       const SLData t*,
                                             Pointer to real filter coefficients
       const SLData t*,
                                             Pointer to imaginary filter coefficients
       SLData t*,
                                             Pointer to real filter processing
coefficients
       SLData t*,
                                             Pointer to imaginary filter processing
coefficients
       SLArrayIndex t*,
                                             Pointer to filter index register
       const SLArrayIndex t)
                                             Filter length
```

DESCRIPTION

This function initializes complex FIR filter with extended state and coefficient array functionality and clears the state arrays and filter index to zero.

NOTES ON USE

The coefficient processing and state arrays should be created using the function SUF FirExtendedArrayAllocate().

CROSS REFERENCE

```
SIF_FirExtendedArray, SDS_FirExtendedArray, SDA_FirExtendedArray, SDS_FirComplexExtendedArray, SDA_FirComplexExtendedArray, SDS_FirExtendedArrayAddSample, SDA_FirExtendedArrayAddSamples
```

void SDS_FirComplexExtendedArray (const SLData_t *, Real input data sample

const SLData t*, Imaginary input data sample Pointer to real destn. sample location SLData t*, Pointer to imag. destn. sample location SLData t*, Real state array pointer SLData t*, SLData t*, Imaginary state array pointer Real coefficient array pointer const SLData t*, const SLData t*, Imaginary coefficient array pointer SLArrayIndex t*, Filter index Filter length const SLArrayIndex t)

DESCRIPTION

This function performs the FIR filter with extended state and coefficient array on a complex data sample. The coefficients (taps) for the FIR filter are in the form of two extended linear arrays (real and imaginary) of 2xN points, where N is the filter length.

NOTES ON USE

The real and imaginary components of the complex result are returned in the locations pointed to by the destination pointers.

This FIR filter method uses a duplicated state array and coefficient array to reduce the overhead of implementing a bucket brigade state array. This means that this implementation requires additional memory for the filter state and coefficients but can be more efficient on architectures that do not support modulo data addressing.

SIF_FirComplexExtendedArray should be called prior to using this function, to perform the required initialisation.

The input and output array pointers can point to the same array.

CROSS REFERENCE

SIF_FirExtendedArray, SDS_FirExtendedArray, SDA_FirExtendedArray, SIF_FirComplexExtendedArray, SDA_FirComplexExtendedArray, SDS_FirExtendedArrayAddSample, SDA_FirExtendedArrayAddSamples

void SDA_FirComplexExtendedArray (const SLData_t *, Real input data to be filtered

const SLData t*, Imaginary input data to be filtered Real destination array pointer SLData t*, SLData t*, Imaginary destination array pointer SLData_t *, Real state array pointer SLData t*, Imaginary state array pointer Real coefficient array pointer const SLData t*, Imaginary coefficient array pointer const SLData t*, SLArrayIndex t*, Filter index const SLArrayIndex t, Filter length const SLArrayIndex t) Array length

DESCRIPTION

This function performs the FIR filter with extended state and coefficient array on a complex datthe array. The coefficients (taps) for the FIR filter are in the form of two extended linear arrays (real and imaginary) of 2xN points, where N is the filter length.

NOTES ON USE

The real and imaginary components of the complex result are returned in the locations pointed to by the destination pointers.

This FIR filter method uses a duplicated state array and coefficient array to reduce the overhead of implementing a bucket brigade state array. This means that this implementation requires additional memory for the filter state and coefficients but can be more efficient on architectures that do not support modulo data addressing.

SIF_FirComplexExtendedArray should be called prior to using this function, to perform the required initialisation.

The input and output array pointers can point to the same array.

CROSS REFERENCE

SIF_FirExtendedArray, SDS_FirExtendedArray, SDA_FirExtendedArray, SIF_FirComplexExtendedArray, SDS_FirComplexExtendedArray, SDS_FirExtendedArrayAddSample, SDA_FirExtendedArrayAddSamples

void SDS_FirExtendedArrayAddSample (const SLData_t, Sample to add to delay line

SLData_t *, Pointer to filter state array
SLArrayIndex_t *, Pointer to filter index offset
const SLArrayIndex t) Filter length

DESCRIPTION

This function adds a new input sample into the filter with extended state and coefficient delay line, without calculating the new output sample, thus saving a whole load of multiply accumulate functions.

NOTES ON USE

If you want to add samples to a complex FIR filter then this function should be called separately for the real sample/state array and the imaginary sample/state array.

CROSS REFERENCE

SIF_FirExtendedArray, SDS_FirExtendedArray, SDA_FirExtendedArray, SIF_FirComplexExtendedArray, SDS_FirComplexExtendedArray, SDA_FirExtendedArray, SDA_FirExtendedArrayAddSamples

void SDA_FirExtendedArrayAddSamples (const SLData_t *, Array of samples to add to delay line

SLData_t *, Pointer to filter state array SLArrayIndex_t *, Pointer to filter index register

const SLArrayIndex_t, Filter length

const SLArrayIndex t) Source array length

DESCRIPTION

This function adds a new input array of samples into the filter with extended state and coefficient delay line, without calculating the new output sample, thus saving a whole load of multiply accumulate functions.

NOTES ON USE

If you want to add samples to a complex FIR filter then this function should be called separately for the real sample/state array and the imaginary sample/state array.

CROSS REFERENCE

SIF_FirExtendedArray, SDS_FirExtendedArray, SDA_FirExtendedArray, SIF_FirComplexExtendedArray, SDS_FirComplexExtendedArray, SDA_FirExtendedArray, SDA_FirExtendedArray, SDA_FirExtendedArrayAddSample

SLError_t SIF_FirLowPassFilter (SLData_t *, Filter coefficients array const SLData_t, Filter cut off frequency const enum SLWindow_t, Window type const SLArrayIndex t) Filter length

DESCRIPTION

This function generates the coefficients for a low-pass FIR filter. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

The filter is designed using the windowing method and the required window type can be chosen as a parameter to the function.

NOTES ON USE

This function generates a linear phase filter so the delay through the filter is equal to the middle sample in the coefficient array. So if the filter is 27 coefficients long then the middle sample is number 14 - C index 13. This means that the filter should always have an odd number of coefficients.

This function uses the malloc and free functions, it will return an error if these functions fail.

CROSS REFERENCE

SIF_Fir, SDA_Fir, SIF_FirHighPassFilter, SIF_FirBandPassFilter, SIF_FirLowPassFilterWindow, SIF_FirHighPassFilterWindow, SIF_FirBandPassFilterWindow

SLError_t SIF_FirHighPassFilter (SLData_t *, Filter coefficients array const SLData_t, Filter cut off frequency const enum SLWindow_t, Window type const SLArrayIndex t) Filter length

DESCRIPTION

This function generates the coefficients for a high-pass FIR filter. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

The filter is designed using the windowing method and the required window type can be chosen as a parameter to the function.

NOTES ON USE

This function generates a linear phase filter so the delay through the filter is equal to the middle sample in the coefficient array. So if the filter is 27 coefficients long then the middle sample is number 14 - C index 13. This means that the filter should always have an odd number of coefficients.

This function uses the malloc and free functions, it will return an error if these functions fail.

CROSS REFERENCE

SIF_Fir, SDA_Fir, SIF_FirLowPassFilter, SIF_FirBandPassFilter, SIF_FirLowPassFilterWindow, SIF_FirHighPassFilterWindow, SIF_FirBandPassFilterWindow

SLError_t SIF_FirBandPassFilter (SLData_t *, Filter coefficients array const SLData_t, Filter centre frequency const SLData_t, Filter bandwidth const enum SLWindow_t, Window type const SLArrayIndex t) Filter length

DESCRIPTION

This function generates the coefficients for a band-pass FIR filter. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

The filter is designed using the windowing method and the required window type can be chosen as a parameter to the function.

With appropriate parameter choice, this function can also generate low-pass and high-pass filters.

NOTES ON USE

This function generates a linear phase filter so the delay through the filter is equal to the middle sample in the coefficient array. So if the filter is 27 coefficients long then the middle sample is number 14 - C index 13. This means that the filter should always have an odd number of coefficients.

This function uses the malloc and free functions, it will return an error if these functions fail.

CROSS REFERENCE

SIF_Fir, SDA_Fir, SIF_FirLowPassFilter, SIF_FirHighPassFilter, SIF_FirLowPassFilterWindow, SIF_FirHighPassFilterWindow, SIF_FirBandPassFilterWindow

void SIF_FirLowPassFilterWindow (SLData_t *, Filter coefficients array const SLData_t, Filter cut off frequency const SLData_t *, Pointer to window coefficients const SLArrayIndex_t) Filter length

DESCRIPTION

This function generates the coefficients for a low-pass FIR filter. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

The filter is designed using the windowing method and the required window coefficients can be passed as a parameter to the function.

NOTES ON USE

This function generates a linear phase filter so the delay through the filter is equal to the middle sample in the coefficient array. So if the filter is 27 coefficients long then the middle sample is number 14 - C index 13. This means that the filter should always have an odd number of coefficients.

CROSS REFERENCE

SIF_Fir, SDA_Fir, SIF_FirLowPassFilter, SIF_FirHighPassFilter, SIF_FirBandPassFilter, SIF_FirHighPassFilterWindow, SIF_FirBandPassFilterWindow

void SIF_FirHighPassFilterWindow (SLData_t *, Filter coefficients array const SLData_t, Filter cut off frequency const SLData_t *, Pointer to window coefficients

const SLArrayIndex t) Filter length

DESCRIPTION

This function generates the coefficients for a high-pass FIR filter. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

The filter is designed using the windowing method and the required window coefficients can be passed as a parameter to the function.

NOTES ON USE

This function generates a linear phase filter so the delay through the filter is equal to the middle sample in the coefficient array. So if the filter is 27 coefficients long then the middle sample is number 14 - C index 13. This means that the filter should always have an odd number of coefficients.

CROSS REFERENCE

SIF_Fir, SDA_Fir, SIF_FirLowPassFilter, SIF_FirHighPassFilter, SIF_FirBandPassFilter, SIF_FirLowPassFilterWindow, SIF_FirBandPassFilterWindow

void SIF_FirBandPassFilterWindow (SLData_t *, Filter coefficients array

const SLData_t, Filter centre frequency

const SLData_t, Filter bandwidth

const SLData t*, Pointer to window coefficients

const SLArrayIndex t) Filter length

DESCRIPTION

This function generates the coefficients for a band-pass FIR filter. The coefficients (taps) for the FIR filter are in the form of a linear array of N points, where N is the filter length.

The filter is designed using the windowing method and the required window coefficients can be passed as a parameter to the function.

With appropriate parameter choice, this function can also generate low-pass and high-pass filters.

NOTES ON USE

This function generates a linear phase filter so the delay through the filter is equal to the middle sample in the coefficient array. So if the filter is 27 coefficients long then the middle sample is number 14 - C index 13. This means that the filter should always have an odd number of coefficients.

```
SIF_Fir, SDA_Fir, SIF_FirLowPassFilter, SIF_FirHighPassFilter, SIF_FirBandPassFilter, SIF_FirLowPassFilterWindow, SIF_FirHighPassFilterWindow
```

SLFixData_t SUF_FirKaiserApproximation (SLData_t, Pass-band cut off frequency

SLData_t, Stop-band cut off frequency

SLData_t, Pass-band ripple SLData_t, Stop-band attenuation SLData_t) Sample rate (Hz)

DESCRIPTION

This function provides an approximation for the length of an FIR filter of the given specification when designed using the Remez exchange algorithm, please note that this is different to the number of filters required to implement a Kaiser window'd filter. This function uses the Kaiser approximation, as follows:

$$N = (((-20.0 * log 10 (sqrt (\delta_1 - \delta_2))) - 13.0) / (14.6 * \delta_f)) + 1$$

Where:

$$\delta_l = 1 - 10^{(-A_{pass}/40)}$$

 $\delta_2 = 10^{(-A_{stop}/20)}$

$$\delta_f = (F_{stop} - F_{pass}) / F_s$$

 A_{pass} = Maximum pass-band ripple (dB)

 A_{stop} = Minimum stop-band ripple (dB)

NOTES ON USE

void SIF_FirMatchedFilter (SLData_t *, SLData_t *, Output matched filter coefficients const SLArrayIndex t)

Source signal Output matched filter coefficients Filter length

DESCRIPTION

This function generates a set of coefficients for an FIR matched filter from a given input signal. The source signal should represent a single symbol of information.

NOTES ON USE

CROSS REFERENCE

SIF_Fir, SDA_Fir, SDS_Fir

SLData_t SDA_FirFilterInverseCoherentGain (const SLData_t *, Filter coeff. ptr. const SLArrayIndex_t) Filter length

DESCRIPTION

This function returns the inverse coherent gain of the FIR filter, so that the gain can be normalised.

NOTES ON USE

CROSS REFERENCE

SIF_Fir, SDS_Fir, SDA_Fir, SIF_FirBandPassFilter, SIF_FirLowPassFilter, SIF_FirHighPassFilter.

void SIF_TappedDelayLine (SLData_t *, Pointer to state array SLArrayIndex_t *, Pointer to delay index const SLArrayIndex t) State array length

DESCRIPTION

This function initializes the scalar tapped delay line functions.

NOTES ON USE

For a discussion on how to use this function for implementing a sparse tapped delay line or multi-path delay line, please refer to the NOTES for the function SDS TappedDelayLine.

CROSS REFERENCE

SDS_TappedDelayLine, SDA_TappedDelayLine, SIF_TappedDelayLineComplex, SDS_TappedDelayLineComplex, SDA_TappedDelayLineIQ, SDA_TappedDelayLineIQ, SDS_TappedDelayLineIQ.

SLData_t SDS_TappedDelayLine (const SLData_t, Source sample

SLData_t *, Pointer to state array
SLArrayIndex_t *, Pointer to delay index
SLArrayIndex_t *, Pointer to taps locations
const SLData_t *, Pointer to taps gains
const SLArrayIndex_t, Number of taps
const SLArrayIndex_t) State array length

DESCRIPTION

This function returns the scalar tapped delayed value on a per-sample basis.

NOTES ON USE

The tapped delay function allows the implementation of a sparse tapped delay line (AKA FIR filter). This type of filter is typically used to implement a multi-path delay line for mobile communications simulation. The two primary source parameters are:

Pointer to taps locations array Pointer to taps gains array

An example sparse tapped delay line is shown in the following table:

0	1	2	3	4	5	6	7	8	9
10.0	0	0	13.1	0	15.2	0	17.3	0	19.4

The appropriate taps location array is as follows:

0 3 3 / 9	0	3	5	7	9
-------------------	---	---	---	---	---

The appropriate taps location array is as follows:

10.0	13.1	15.2	17 3	194
10.0	15.1	10.2	17.5	17.1

The delay length (state array length) parameter is set to 10.

```
SIF_TappedDelayLine, SDA_TappedDelayLine, SIF_TappedDelayLineComplex, SDS_TappedDelayLineComplex, SDA_TappedDelayLineIQ, SDA_TappedDelayLineIQ, SDS_TappedDelayLineIQ.
```

void SDA TappedDelayLine (const SLData t*, Pointer to source array SLData t*, Pointer to destination array SLData t*, Pointer to state array SLArrayIndex t*, Pointer to delay index SLArrayIndex t*, Pointer to taps locations const SLData t*, Pointer to taps gains const SLArrayIndex t, Number of taps const SLArrayIndex t, State array length const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the scalar tapped delayed value on an array basis.

NOTES ON USE

For a discussion on how to use this function for implementing a sparse tapped delay line or multi-path delay line, please refer to the NOTES for the function SDS_TappedDelayLine.

```
SIF_TappedDelayLine, SDS_TappedDelayLine, SIF_TappedDelayLineComplex, SDS_TappedDelayLineComplex, SDA_TappedDelayLineIQ, SDA_TappedDelayLineIQ, SDS_TappedDelayLineIQ.
```

void SIF_TappedDelayLineComplex (SLData_t *, Pointer to real state array SLData_t *, Pointer to imaginary state array SLArrayIndex_t *, Pointer to delay index const SLArrayIndex t) State array length

DESCRIPTION

This function initializes the complex tapped delay line functions.

NOTES ON USE

For a discussion on how to use this function for implementing a sparse tapped delay line or multi-path delay line, please refer to the NOTES for the function SDS_TappedDelayLine.

CROSS REFERENCE

SIF_TappedDelayLine, SDS_TappedDelayLine, SDA_TappedDelayLine, SDS_TappedDelayLineComplex, SDA_TappedDelayLineComplex, SIF_TappedDelayLineIQ, SDS_TappedDelayLineIQ, SDA_TappedDelayLineIQ.

void SDS_TappedDelayLineComplex (const SLData_t, Real source sample

const SLData_t, Imaginary source sample

SLData t*, Pointer to real destination sample

SLData t*, Pointer to imaginary destination sample

SLData t*, Pointer to real state array

SLData_t *, Pointer to imaginary state array

SLArrayIndex_t *, Pointer to delay index
SLArrayIndex_t *, Pointer to taps locations
const SLData_t *, Pointer to real taps gains

const SLData t*, Pointer to imaginary taps gains

const SLArrayIndex_t, Number of taps const SLArrayIndex_t) State array length

DESCRIPTION

This function returns the complex tapped delayed value on a per-sample basis. The function implements a complex sum of products operation between the data and the coefficients.

NOTES ON USE

For a discussion on how to use this function for implementing a sparse tapped delay line or multi-path delay line, please refer to the NOTES for the function SDS TappedDelayLine.

CROSS REFERENCE

SIF_TappedDelayLine, SDS_TappedDelayLine, SDA_TappedDelayLine, SIF_TappedDelayLineComplex, SDA_TappedDelayLineComplex, SIF_TappedDelayLineIQ, SDS_TappedDelayLineIQ, SDA_TappedDelayLineIQ.

void SDA_TappedDelayLineComplex (const SLData_t *, Ptr. to real source array

const SLData_t *, Pointer to imaginary source array SLData_t *, Pointer to real destination array

SLData_t *, Pointer to imaginary destination array

SLData t*, Pointer to real state array

SLData t*, Pointer to imaginary state array

SLArrayIndex_t *, Pointer to delay index
SLArrayIndex_t *, Pointer to taps locations
const SLData_t *, Pointer to real taps gains

const SLData_t *, Pointer to imaginary taps gains

const SLArrayIndex_t, Number of taps
const SLArrayIndex_t, State array length
const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the complex tapped delayed value on an array basis. The function implements a complex sum of products operation between the data and the coefficients.

NOTES ON USE

For a discussion on how to use this function for implementing a sparse tapped delay line or multi-path delay line, please refer to the NOTES for the function SDS_TappedDelayLine.

CROSS REFERENCE

SIF_TappedDelayLine, SDS_TappedDelayLine, SDA_TappedDelayLine, SIF_TappedDelayLineComplex, SDS_TappedDelayLineComplex, SIF_TappedDelayLineIQ, SDS_TappedDelayLineIQ, SDA_TappedDelayLineIQ.

void SIF_TappedDelayLineIQ (SLData_t *, Pointer to real state array SLData_t *, Pointer to imaginary state array SLArrayIndex_t *, Pointer to delay index const SLArrayIndex t) State array length

DESCRIPTION

This function initializes the IQ tapped delay line functions.

NOTES ON USE

For a discussion on how to use this function for implementing a sparse tapped delay line or multi-path delay line, please refer to the NOTES for the function SDS_TappedDelayLine.

CROSS REFERENCE

SIF_TappedDelayLine, SDS_TappedDelayLine, SDA_TappedDelayLine, SIF_TappedDelayLineComplex, SDS_TappedDelayLineComplex, SDA_TappedDelayLineIQ, SDA_TappedDelayLineIQ.

void SDS_TappedDelayLineIQ (const SLData t, Real source sample const SLData t, Imaginary source sample SLData t*, Pointer to real destination sample Pointer to imaginary destination sample SLData t*, SLData t*, Pointer to real state array SLData t*, Pointer to imaginary state array SLArrayIndex t*, Pointer to delay index SLArrayIndex t*, Pointer to taps locations const SLData t*, Pointer to real taps gains const SLData t*, Pointer to imaginary taps gains const SLArrayIndex t, Number of taps const SLArrayIndex t) State array length

DESCRIPTION

This function returns the complex tapped delayed value on a per-sample basis. The function implements a scalar sum of products operation between the data and the coefficients i.e. it separately multiplies the real data samples by the real coefficients and the imaginary data samples by the imaginary coefficients.

NOTES ON USE

For a discussion on how to use this function for implementing a sparse tapped delay line or multi-path delay line, please refer to the NOTES for the function SDS TappedDelayLine.

```
SIF_TappedDelayLine, SDS_TappedDelayLine, SDA_TappedDelayLine, SIF_TappedDelayLineComplex, SDS_TappedDelayLineComplex, SDA_TappedDelayLineIQ, SDA_TappedDelayLineIQ.
```

void SDA TappedDelayLineIQ (const SLData t*, Pointer to real source array const SLData t*, Pointer to imaginary source array Pointer to real destination array SLData t*, Pointer to imaginary destination array SLData t*, Pointer to real state array SLData t*, SLData t*, Pointer to imaginary state array Pointer to delay index SLArrayIndex t*, SLArrayIndex t*, Pointer to taps locations const SLData t*, Pointer to real taps gains const SLData t*, Pointer to imaginary taps gains const SLArrayIndex t, Number of taps const SLArrayIndex t, State array length Array length const SLArrayIndex t)

DESCRIPTION

This function returns the complex tapped delayed value on an array basis. The function implements a scalar sum of products operation between the data and the coefficients i.e. it separately multiplies the real data samples by the real coefficients and the imaginary data samples by the imaginary coefficients.

NOTES ON USE

For a discussion on how to use this function for implementing a sparse tapped delay line or multi-path delay line, please refer to the NOTES for the function SDS_TappedDelayLine.

```
SIF_TappedDelayLine, SDS_TappedDelayLine, SDA_TappedDelayLine, SIF_TappedDelayLineComplex, SDS_TappedDelayLineComplex, SDA_TappedDelayLineIQ, SDS_TappedDelayLineIQ.
```

void SIF FirPolyPhaseGenerate (const SLData t*, Input FIR coefficient pointer

SLData_t *, Output poly-phase coefficient pointer


SLData t **, Output filter coefficient pointers

SLArrayIndex t*, Output filter lengths

const SLArrayIndex t, Number of output filter phases

const SLArrayIndex t) Input filter length

DESCRIPTION



This function converts the coefficients for an FIR filter into those for an M phase poly-phase FIR filter.

NOTES ON USE

The input and output arrays are the same length but the coefficients are re-ordered into separate banks for each phase.

This function also returns an array of M pointers to the start of each phase within the output array and the lengths of each phase filter.

CROSS REFERENCE

SIF Fir, SDS Fir, SDA Fir.

void SIF_FirZeroNotchFilter (SLData_t *, Coefficients array const SLData_t) Notch centre frequency normalized to Fs = 1 Hz

DESCRIPTION

This function generates the coefficients for an FIR single conjugate zero notch filter. The conjugate zeros will be located on the unit circle at the specified frequency, as shown in the following diagram:

NOTES ON USE

To get a flat pass-band, the SIF_IirNotchFilter2() function should be used to design a suitable IIR biquad filter.


CROSS REFERENCE

SIF Fir, SDS Fir, SDA Fir.

IIR Filtering Functions (iirfilt.c)

The SigLib IIR filter functions implement cascaded second order biquad Direct Form II filters, as shown in the following diagram:

IIR Direct Form Type II Filter



The coefficients for the IIR filter are stored in a linear array, as follows:

stage 1
$$b(0), b(1), b(2), a(1), a(2)$$

stage 2 $b(0), b(1), b(2), a(1), a(2)$
.
stage N $b(0), b(1), b(2), a(1), a(2)$

This filter structure has been chosen for the best compromise between processing efficiency and stability. Odd order filters can be implemented using a cascade of second order structures with the final stage having coefficients a2 and b2 set to zero. This technique gives better run time performance for a generic IIR filter function than having to choose between first and second order sections within the filter function.

SigLib includes a defined constant IIR_COEFFS_PER_BIQUAD that defines the length of the memory space to store the coefficients for each biquad section. This can be used to allocate the necessary memory space.

The *z*-transform for the IIR biquad is as follows:

$$Y(z) = \frac{b(0) + b(1)z^{-1} + b(2)z^{-2}}{1 + a(1)z^{-1} + a(2)z^{-2}}X(z)$$

The negation of the denominator (a(1)) and a(2) coefficients is compatible with signal processing packages such as Digital Filter Plus and Matlab. If your filter design tools do not support this configuration then you will need to negate these coefficients prior to using them with SigLib (using the function SDA_IirNegateAlphaCoeffs ()). Or you can also use the SDS_IirMac () or SDA_IirMac () functions which do not negate the coefficients.

SIF_Iir

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Iir (SLData_t *, Pointer to filter state array const SLArrayIndex_t) Number of biquads

DESCRIPTION

This function initializes IIR filter functionality and clears all state arrays to zero.

NOTES ON USE

CROSS REFERENCE

 $SDS_Iir, SDA_Iir, SDS_IirMac, SDA_IirMac, SDA_BilinearTransform, SDA_IirZplaneToCoeffs.$

SDS_Iir

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_Iir (const SLData_t, SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients const SLArrayIndex_t) Number of biquads

DESCRIPTION

This function applies infinite impulse response (IIR) filter to a data stream, a sample at a time.

NOTES ON USE

Even though floating point data is used and the form of the filter chosen is very stable, care should be taken when dealing with filter poles that lie on, or near the unit circle.

SIF_Iir should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF_Iir, SDA_Iir, SDS_IirMac, SDA_IirMac, SDA_BilinearTransform, SDA_IirZplaneToCoeffs, SDA_IirNegateAlphaCoeffs.

SDA_Iir

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDA_Iir (const SLData_t *, Input array to be filtered SLData_t *, Filtered output array SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients const SLArrayIndex_t, Number of biquads const SLArrayIndex_t) Array length
```

DESCRIPTION

This function applies an infinite impulse response (IIR) filter to an array. The filter structure is Direct Form II (as shown in the following diagram) and has been chosen for the best compromise between processing efficiency and stability.

NOTES ON USE

Even though floating point data is used and the form of the filter chosen is very stable, care should be taken when dealing with filter poles that lie on, or near the unit circle.

SIF_Iir should be called prior to using this function, to perform the required initialisation.

```
SIF_Iir, SDS_Iir, SDS_IirMac, SDA_IirMac, SDA_IirNc, SDA_BilinearTransform, SDA_IirZplaneToCoeffs, SDA_IirNegateAlphaCoeffs.
```

SDS_IirMac

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_IirMac (const SLData_t, SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients const SLArrayIndex_t)

Number of biquads

DESCRIPTION

This function applies an infinite impulse response (IIR) filter to a data stream, a sample at a time.

NOTES ON USE

Even though floating point data is used and the form of the filter chosen is very stable, care should be taken when dealing with filter poles that lie on, or near the unit circle.

SIF_Iir should be called prior to using this function, to perform the required initialisation.

This function uses the MAC rather than MSUB operation so it does not negate the denominator (feedback) coefficients. If you wish to use the SigLib IIR filter design functions (or other similar filter design applications) then you will need to use the SDA_IirNegateAlphaCoeffs() function to negate the coefficients.

CROSS REFERENCE

SIF_Iir, SDS_Iir, SDA_Iir, SDA_IirMac, SDA_BilinearTransform, SDA_IirZplaneToCoeffs, SDA_IirNegateAlphaCoeffs.

```
void SDA_IirMac (const SLData_t *, SLData_t *, Filtered output array
SLData_t *, Pointer to filter state array
const SLData_t *, Pointer to filter coefficients
const SLArrayIndex_t, Number of biquads
const SLArrayIndex_t) Array length
```

DESCRIPTION

This function applies an infinite impulse response (IIR) filter to an array. The filter structure is Direct Form II (as shown in the following diagram) and has been chosen for the best compromise between processing efficiency and stability.

NOTES ON USE

Even though floating point data is used and the form of the filter chosen is very stable, care should be taken when dealing with filter poles that lie on, or near the unit circle.

SIF_Iir should be called prior to using this function, to perform the required initialisation

This function uses the MAC rather than MSUB operation so it does not negate the denominator (feedback) coefficients. If you wish to use the SigLib IIR filter design functions (or other similar filter design applications) then you will need to use the SDA IirNegateAlphaCoeffs() function to negate the coefficients.

```
SIF_Iir, SDS_Iir, SDA_Iir, SDS_IirMac, SDA_IirNc, SDA_BilinearTransform, SDA_IirZplaneToCoeffs, SDA_IirNegateAlphaCoeffs.
```

SIF IirOrderN

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_IirOrderN (SLData_t *, Pointer to filter state array SLArrayIndex_t *, Filter index pointer const SLArrayIndex t) Filter order

DESCRIPTION

This function initializes the N^{th} order IIR filter functionality and clears the state array to zero.

NOTES ON USE

The Nth order IIR filter functions implement a single structure for the entire filter, rather than the more traditional biquad implementation.

The state array should be the same size as the filter order.

CROSS REFERENCE

SDS IirOrderN, SDA IirOrderN.

SDS IirOrderN

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_IirOrderN (const SLData_t, Input sample

SLData_t *, Pointer to state array

const SLData_t *, Pointer to filter coefficients

SLArrayIndex t*, Pointer to filter index

const SLArrayIndex t) Filter order

DESCRIPTION

This function applies an N^{th} order filter to a data stream, a sample at a time.

NOTES ON USE

The Nth order IIR filter functions implement a single structure for the entire filter, rather than the more traditional biquad implementation.

Be aware that N^{th} order IIR filters can easily be unstable. Biquad format IIR filters are generally more stable.

The coefficient array is N+I feedforward coefficients followed by N feedback coefficients followed by:

N+1 feedforward coefficients -b(0), b(1), ... b(N)N feedback coefficients -a(1), ... a(N)

SIF_IirOrderN should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF IirOrderN, SDA IirOrderN.

void SDA_IirOrderN (const SLData_t *, SLData_t *, Pointer to source array to be filtered Pointer to filter output array Pointer to filter state array Pointer to filter state array Pointer to filter coefficients SLArrayIndex_t *, Pointer to filter state index Pointer to filter output array Pointer to filter state index Pointer to filter state array Pointer to filter state index Pointer to filter state array Pointer to filte

DESCRIPTION

This function applies an N^{th} order IIR filter to a data stream.

NOTES ON USE

The Nth order IIR filter functions implement a single structure for the entire filter, rather than the more traditional biquad implementation.

Be aware that $N^{\rm th}$ order IIR filters can easily be unstable. Biquad format IIR filters are generally more stable.

The coefficient array is N+I feedforward coefficients followed by N feedback coefficients followed by:

N+1 feedforward coefficients -b(0), b(1), ... b(N)N feedback coefficients -a(1), ... a(N)

SIF_IirOrderN should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF IirOrderN, SDS IirOrderN.

SIF_IirNc

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_IirNc (SLData_t *, Filter 1 state array pointer SLData_t *, Filter 2 state array pointer const SLArrayIndex t) Source array length

DESCRIPTION

This function initializes the non-causal zero phase IIR filter functionality and clear all state arrays to zero.

NOTES ON USE

The defined constant IIR_COEFFS_PER_BIQUAD defines the length of the memory space to store the coefficients for each biquad section. This can be used to allocate the necessary memory space form within the application.

CROSS REFERENCE


SDA_IirNc, SDA_BilinearTransform, SDA_IirZplaneToCoeffs.

Input array to be filtered
Filtered output array pointer
Filter 1 state array pointer
Filter 2 state array pointer
Pointer to filter coefficients
Number of biquads
Array length

DESCRIPTION

This function applies a non-causal zero phase infinite impulse response (IIR) filter coefficients to the array. The coefficients for the IIR filter are stored in a linear array, however the array locations represent:

The IIR filter form is Direct Form II and has been chosen for the best compromise between processing efficiency and stability.



NOTES ON USE

Even though floating point data is used and the form of the filter chosen is very stable, care should be taken when dealing with filter poles that lie on, or near the unit circle.

The input and output array pointers can point to the same array.

The two IIR filters use the same coefficients and are continuous across array boundaries however each filter must have a separate state array.

For more information, please see the documentation for SDA Iir function.

The defined constant IIR_COEFFS_PER_BIQUAD defines the length of the memory space to store the coefficients for each biquad section. This can be used to allocate the necessary memory space.

CROSS REFERENCE

SIF_IirNc, SDA_Iir, SDA_Iir, SDA_BilinearTransform, SDA IirZplaneToCoeffs.

void SDA_BilinearTransform (const SLComplexRect_s *, S-plane zeros

const SLComplexRect s*, S-plane poles SLComplexRect s *, Z-plane zeros SLComplexRect s *, Z-plane poles Sample rate (Hz) const SLData t, const SLData t, Pre-warp frequency const SLArrayIndex t, Pre-warp switch const SLArrayIndex t, Number of zeros const SLArrayIndex t) Number of poles

DESCRIPTION

This function converts s-plane poles and zeros to the z-plane, using the bilinear transformation:

$$z = \frac{1 + (T/2)s}{1 - (T/2)s}$$

This function provides optional pre-warping of the frequencies using the following equation:

$$\omega = \tan^{-1}(\frac{\Omega - T}{2})$$

The pre-warp switch parameter should be set to either 'SIGLIB ON' or 'SIGLIB OFF'.

NOTES ON USE

The poles and zeros returned are complex conjugate.

This function can accept filter specifications with a different number of poles and zeros. If the number of poles is greater than the number of zeros then additional zeros are added at z = 0 to make the numbers equal.

The function SDA IirModifyFilterGain can be used to set the filter gain.

Although this function supports pre-warping of the frequencies, it is often easier to pre-warp the frequencies of the filter before using this function. This can be done by using the function SDS PreWarp.

CROSS REFERENCE

SDA_Iir, SDA_Iir, SDA_IirZplaneToCoeffs, SDA_IirModifyFilterGain, SDA MatchedZTransform, SDS PreWarp.

SLData_t SDS_PreWarp (const SLData_t, Desired frequency (Hz) const SLData_t) Sample rate (Hz)

DESCRIPTION

This function pre-warps the desired analog frequency, so that it may be used in the bilinear transform. The function returns the warped frequency.

NOTES ON USE

CROSS REFERENCE

SDA_BilinearTransform.

void SDA_MatchedZTransform (const SLComplexRect_s *, S-plane zeros

const SLComplexRect_s *, S-plane poles
SLComplexRect_s *, Z-plane zeros
SLComplexRect_s *, Z-plane poles
const SLData_t, Sample rate (Hz)
const SLArrayIndex_t, Number of zeros
const SLArrayIndex_t) Number of poles

DESCRIPTION

This function converts s-plane poles and zeros to the z-plane, using the matched z-transform.

NOTES ON USE

The poles and zeros returned are complex conjugate.

This function can accept filter specifications with a different number of poles and zeros.

The function SDA_IirModifyFilterGain can be used to set the filter gain.

CROSS REFERENCE

SDA_Iir, SDA_Iir, SDA_IirZplaneToCoeffs, SDA_IirModifyFilterGain, SDA_BilinearTransform.

void SDA_IirZplaneToCoeffs (const SLComplexRect_s *, Source Z-plane zeros

const SLComplexRect_s *, Source Z-plane poles SLData_t *, IIR filter coefficients

const SLArrayIndex_t, Number of zero conjugate pairs const SLArrayIndex_t) Number of pole conjugate pairs

DESCRIPTION

This function converts z-plane poles and zeros, in rectangular format, to second order (biquad) filter coefficients. The coefficients are stored in the order: A0, A1, A2, B1, B2,

NOTES ON USE

The poles and zeros are assumed to be complex conjugate I.E. each biquad will consist of a complex conjugate pair of poles and a complex conjugate pair of zeros. For example a simple 2nd order low-pass filter may have the following pole and zero conjugate pairs:

Poles: Magnitude 0.9, Angle 30 degrees (0.778 + j 0.45)

Magnitude 0.9, Angle -30 degrees (0.778 - j 0.45)

Zeros: Magnitude 1.0, Angle 90 degrees (0.0 + j 1.0)

Magnitude 1.0, Angle -90 degrees (0.0 - j 1.0)

These only need to be specified using either of the conjugate pair values, for example:

Pole: 0.778 + j 0.45Zero: 0.0 + j 1.0

I.E. you should not specify both of the conjugate poles and zeros as inputs.

This function can accept filter specifications with a different number of poles and zeros. Additional poles and zeros for the IIR biquads will be added and these will be located at the origin.

CROSS REFERENCE

SDA Iir, SDS Iir, SDA IirZplanePolarToCoeffs, SDA BilinearTransform.

void SDA IirZplanePolarToCoeffs (const SLComplexPolar s *, Z-plane zeros

const SLComplexPolar s *, Z-plane zeros

SLData_t *, IIR filter coefficients const SLArrayIndex_t, Number of zeros const SLArrayIndex_t) Number of poles

DESCRIPTION

This function converts z-plane poles and zeros, in polar format, to second order (biquad) filter coefficients. The coefficients are stored in the order: A0, A1, A2, B1, B2,

NOTES ON USE

The poles and zeros are assumed to be complex conjugate I.E. each biquad will consist of a complex conjugate pair of poles and a complex conjugate pair of zeros. For example a simple 2nd order low-pass filter may have the following pole and zero conjugate pairs:

Poles: Magnitude 0.9, Angle 30 degrees

Magnitude 0.9, Angle -30 degrees

Zeros: Magnitude 1.0, Angle 90 degrees

Magnitude 1.0, Angle -90 degrees

These only need to be specified using either of the conjugate pair values, for example:

Pole: 0.778 + j 0.45Zero: 0.0 + j 1.0

And the number of pole and zero conjugate pairs specified to the function will both be 1.

This function can accept filter specifications with a different number of poles and zeros.

CROSS REFERENCE

SDA Iir, SDS Iir, SDA IirZplaneToCoeffs, SDA BilinearTransform.

void SDA_IirZplaneLpfToLpf (const SLComplexRect_s *, Source z-plane zeros

const SLComplexRect_s *, Source Z-plane poles
SLComplexRect_s *, Destination Z-plane zeros
SLComplexRect_s *, Destination Z-plane poles
const SLData_t, Source cut-off frequency
const SLData_t, Destination cut-off frequency

const SLData t, Sample rate (Hz)

const SLArrayIndex_t, Number of zero conjugate pairs const SLArrayIndex_t) Number of pole conjugate pairs

DESCRIPTION

This function converts the z-plane poles and zeros of a low-pass filter with a different cut-off frequency.

NOTES ON USE

The poles and zeros are assumed to be complex conjugate.

CROSS REFERENCE

SDA_IirZplaneLpfToLpf, SDA_IirZplaneLpfToHpf, SDA_IirZplaneLpfToBpf, SDA_IirZplaneLpfToBsf.

void SDA_IirZplaneLpfToHpf (const SLComplexRect_s *, Source Z-plane zeros

const SLComplexRect_s *, Source Z-plane poles
SLComplexRect_s *, Destination Z-plane zeros
SLComplexRect_s *, Destination Z-plane poles
const SLData_t, Source cut-off frequency
const SLData_t, Destination cut-off frequency

const SLData t, Sample rate (Hz)

const SLArrayIndex_t, Number of zero conjugate pairs const SLArrayIndex_t) Number of pole conjugate pairs

DESCRIPTION

This function converts the z-plane poles and zeros of a low-pass filter to a high-pass filter.

NOTES ON USE

The poles and zeros are assumed to be complex conjugate.

CROSS REFERENCE

 $SDA_IirZplaneLpfToLpf, SDA_IirZplaneLpfToBpf, SDA_IirZplaneLpfToBsf.$

void SDA_IirZplaneLpfToBpf (const SLComplexRect_s *, Source Z-plane zeros

const SLComplexRect_s *, Source Z-plane poles
SLComplexRect_s *, Destination Z-plane zeros
SLComplexRect_s *, Destination Z-plane poles
const SLData_t, Source cut-off frequency

const SLData_t, Destination lower cut-off frequency const SLData_t, Destination upper cut-off frequency

const SLData_t, Sample rate (Hz)

const SLArrayIndex_t, Number of zero conjugate pairs const SLArrayIndex_t) Number of pole conjugate pairs

DESCRIPTION

This function converts the z-plane poles and zeros of a low-pass filter to a band-pass filter.

NOTES ON USE

The poles and zeros are assumed to be complex conjugate.

CROSS REFERENCE

 $SDA_IirZplaneLpfToLpf, SDA_IirZplaneLpfToHpf, SDA_IirZplaneLpfToBsf.$

void SDA_IirZplaneLpfToBsf (const SLComplexRect_s *, Source Z-plane zeros

const SLComplexRect_s *, Source Z-plane poles
SLComplexRect_s *, Destination Z-plane zeros
SLComplexRect_s *, Destination Z-plane poles
const SLData_t, Source cut-off frequency
const SLData_t Destination lower cut-off frequency

const SLData_t, Destination lower cut-off frequency const SLData_t, Destination upper cut-off frequency

const SLData_t, Sample rate (Hz)

const SLArrayIndex_t, Number of zero conjugate pairs const SLArrayIndex_t) Number of pole conjugate pairs

DESCRIPTION

This function converts the z-plane poles and zeros of a low-pass filter to a band-stop filter.

NOTES ON USE

The poles and zeros are assumed to be complex conjugate.

CROSS REFERENCE

SDA_IirZplaneLpfToLpf, SDA_IirZplaneLpfToHpf, SDA_IirZplaneLpfToBpf.

SLData_t SDA_IirModifyFilterGain (const SLData_t *, Source IIR filter coefficients

SLData t*, Destination IIR filter coefficients

const SLData_t, Centre Frequency const SLData_t, Desired filter gain const SLArrayIndex t) Number of biquads

DESCRIPTION

This function modifies the gain of the IIR filter at a particular centre frequency to any desired value. The function will return to gain of the original filter at the desired frequency. The centre frequency is normalised to a sample rate of 1 Hz.

NOTES ON USE

Reference: Maurice Bellanger; Digital Processing Of Signals (Theory and Practice), P160.

CROSS REFERENCE

SDA BilinearTransform.

void SIF_IirLowPassFilter (SLData_t *, Pointer to output IIR filter coefficients const SLData_t, Filter cut-off frequency const SLData_t) Filter Q factor

DESCRIPTION

This function generates the coefficients for a single IIR Biquad low-pass filter, from the supplied parameters.

NOTES ON USE

The coefficients are in the standard SigLib order: b(0), b(1), b(2), a(1), a(2).

References:

Discrete-Time Digital Signal Processing - Oppenheim, Schafer & Buck, 2ed, 1998, Chapter 7 Filter Design Techniques

Robert Bristow-Johnson "Cookbook formulae for audio EQ biquad filter coefficients": http://www.musicdsp.org/files/audio-eq-cookbook.txt.

CROSS REFERENCE

SIF_IirHighPassFilter, SIF_IirAllPassFilter, SIF_IirBandPassFilter, SIF_IirNotchFilter, SIF_IirPeakingFilter, SIF_IirLowShelfFilter, SIF_IirHighShelfFilter.

void SIF_IirHighPassFilter (SLData_t *, Const SLData_t, Const SLData_t)

Pointer to output IIR filter coefficients
Filter cut-off frequency
Filter Q factor

DESCRIPTION

This function generates the coefficients for a single IIR Biquad high-pass filter, from the supplied parameters.

NOTES ON USE

The coefficients are in the standard SigLib order: b(0), b(1), b(2), a(1), a(2).

References:

Discrete-Time Digital Signal Processing - Oppenheim, Schafer & Buck, 2ed, 1998, Chapter 7 Filter Design Techniques

Robert Bristow-Johnson "Cookbook formulae for audio EQ biquad filter coefficients": http://www.musicdsp.org/files/audio-eq-cookbook.txt.

CROSS REFERENCE

SIF_IirLowPassFilter, SIF_IirAllPassFilter, SIF_IirBandPassFilter, SIF_IirNotchFilter, SIF_IirPeakingFilter, SIF_IirLowShelfFilter, SIF_IirHighShelfFilter.

void SIF_IirAllPassFilter (SLData_t *, Const SLData_t, Const SLData_t)

Pointer to output IIR filter coefficients
Filter cut-off frequency
Filter Q factor

DESCRIPTION

This function generates the coefficients for a single IIR Biquad all-pass filter, from the supplied parameters.

NOTES ON USE

The coefficients are in the standard SigLib order: b(0), b(1), b(2), a(1), a(2).

References:

Discrete-Time Digital Signal Processing - Oppenheim, Schafer & Buck, 2ed, 1998, Chapter 7 Filter Design Techniques

Robert Bristow-Johnson "Cookbook formulae for audio EQ biquad filter coefficients": http://www.musicdsp.org/files/audio-eq-cookbook.txt.

CROSS REFERENCE

SIF_IirLowPassFilter, SIF_IirHighPassFilter, SIF_IirBandPassFilter, SIF_IirNotchFilter, SIF_IirPeakingFilter, SIF_IirLowShelfFilter, SIF_IirHighShelfFilter.

void SIF_IirBandPassFilter (SLData_t *, const SLData_t, const SLData_t)

Pointer to output IIR filter coefficients
Filter cut-off frequency (low)
Filter cut-off frequency (high)

DESCRIPTION

This function generates the coefficients for a single IIR Biquad band-pass filter, from the supplied parameters.

NOTES ON USE

The coefficients are in the standard SigLib order: b(0), b(1), b(2), a(1), a(2).

References:

Discrete-Time Digital Signal Processing - Oppenheim, Schafer & Buck, 2ed, 1998, Chapter 7 Filter Design Techniques

Robert Bristow-Johnson "Cookbook formulae for audio EQ biquad filter coefficients": http://www.musicdsp.org/files/audio-eq-cookbook.txt.

CROSS REFERENCE

SIF_IirLowPassFilter, SIF_IirHighPassFilter, SIF_IirAllPassFilter, SIF_IirNotchFilter, SIF_IirPeakingFilter, SIF_IirLowShelfFilter, SIF_IirHighShelfFilter.

void SIF_IirNotchFilter (SLData_t *,Pointer to output IIR filter coefficients const SLData_t, Filter cut-off frequency const SLData_t) Filter Q factor

DESCRIPTION

This function generates the coefficients for a single IIR Biquad notch filter, from the supplied parameters.

NOTES ON USE

The coefficients are in the standard SigLib order: b(0), b(1), b(2), a(1), a(2).

References:

Discrete-Time Digital Signal Processing - Oppenheim, Schafer & Buck, 2ed, 1998, Chapter 7 Filter Design Techniques

Robert Bristow-Johnson "Cookbook formulae for audio EQ biquad filter coefficients": http://www.musicdsp.org/files/audio-eq-cookbook.txt.

CROSS REFERENCE

SIF_IirLowPassFilter, SIF_IirHighPassFilter, SIF_IirAllPassFilter, SIF_IirBandPassFilter, SIF_IirPeakingFilter, SIF_IirLowShelfFilter, SIF_IirHighShelfFilter.

void SIF_IirPeakingFilter (SLData_t *, Const SLData_t, Const SLData_t, Const SLData_t, Const SLData_t, Const SLData_t, Const SLData_t)

Pointer to output IIR filter coefficients Filter cut-off frequency Filter Q factor Filter gain (dB)

DESCRIPTION

This function generates the coefficients for a single IIR Biquad peaking filter, from the supplied parameters.

NOTES ON USE

The coefficients are in the standard SigLib order: b(0), b(1), b(2), a(1), a(2).

References:

Discrete-Time Digital Signal Processing - Oppenheim, Schafer & Buck, 2ed, 1998, Chapter 7 Filter Design Techniques

Robert Bristow-Johnson "Cookbook formulae for audio EQ biquad filter coefficients": http://www.musicdsp.org/files/audio-eq-cookbook.txt.

CROSS REFERENCE

SIF_IirLowPassFilter, SIF_IirHighPassFilter, SIF_IirAllPassFilter, SIF_IirBandPassFilter, SIF_IirNotchFilter, SIF_IirLowShelfFilter, SIF_IirHighShelfFilter.

void SIF_IirLowShelfFilter (SLData_t *, Const SLData_t, Const SLData_t, Const SLData_t, Const SLData_t, Const SLData_t, Const SLData_t)

Pointer to output IIR filter coefficients Filter cut-off frequency Filter Q factor Filter shelf gain (dB)

DESCRIPTION

This function generates the coefficients for a single IIR Biquad low shelf filter, from the supplied parameters.

NOTES ON USE

The coefficients are in the standard SigLib order: b(0), b(1), b(2), a(1), a(2).

References:

Discrete-Time Digital Signal Processing - Oppenheim, Schafer & Buck, 2ed, 1998, Chapter 7 Filter Design Techniques

Robert Bristow-Johnson "Cookbook formulae for audio EQ biquad filter coefficients": http://www.musicdsp.org/files/audio-eq-cookbook.txt.

CROSS REFERENCE

SIF_IirLowPassFilter, SIF_IirHighPassFilter, SIF_IirAllPassFilter, SIF_IirBandPassFilter, SIF_IirNotchFilter, SIF_IirPeakingFilter, SIF_IirHighShelfFilter.

void SIF_IirHighShelfFilter (SLData_t *, const SLData_t, const SLData_t, const SLData_t, const SLData_t, const SLData_t, const SLData_t)

Pointer to output IIR filter coefficients Filter cut-off frequency Filter Q factor Filter shelf gain (dB)

DESCRIPTION

This function generates the coefficients for a single IIR Biquad high shelf filter, from the supplied parameters.

NOTES ON USE

The coefficients are in the standard SigLib order: b(0), b(1), b(2), a(1), a(2).

References:

Discrete-Time Digital Signal Processing - Oppenheim, Schafer & Buck, 2ed, 1998, Chapter 7 Filter Design Techniques

Robert Bristow-Johnson "Cookbook formulae for audio EQ biquad filter coefficients": http://www.musicdsp.org/files/audio-eq-cookbook.txt.

CROSS REFERENCE

SIF_IirLowPassFilter, SIF_IirHighPassFilter, SIF_IirAllPassFilter, SIF_IirBandPassFilter, SIF_IirNotchFilter, SIF_IirPeakingFilter, SIF_IirLowShelfFilter.

SLData_t SDS_IirRemoveDC (SLData_t, Input sample SLData_t *, Previous input sample SLData_t *, Previous output sample const SLData_t) Convergence rate

DESCRIPTION

This function uses a simple feedback filter to remove the D.C. component of a signal. The convergence rate parameter defines the rate at which the filter will converge on the D.C. level. A value of 0.9 will converge (and hence diverge) quickly, where as a value of 0.99999 will converge slowly.

This function works on a per-sample basis.

NOTES ON USE

CROSS REFERENCE

SDA_IirRemoveDC.

```
void SDA_IirRemoveDC (const SLData_t *,Pointer to input array SLData_t *, Pointer to output array SLData_t *, Previous input sample SLData_t *, Previous output sample const SLData_t, Convergence rate const SLArrayIndex_t) Array length
```

DESCRIPTION

This function uses a simple feedback filter to remove the D.C. component of a signal. The convergence rate parameter defines the rate at which the filter will converge on the D.C. level. A value of 0.9 will converge (and hence diverge) quickly, where as a value of 0.99999 will converge slowly.

This function works on an array of data.

NOTES ON USE

CROSS REFERENCE

SDS IirRemoveDC.

SLData_t SIF_OnePole (SLData_t *) Feedback state

DESCRIPTION

This function initialises the state variable for the functions SDS_OnePole, SDA OnePole, SDS OnePoleNormalized and SDA OnePoleNormalized.

NOTES ON USE

CROSS REFERENCE

SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

SDS_OnePole

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_OnePole (const SLData_t, Input data to be filtered const SLData_t, Feedback alpha SLData_t*)

SLData_t *)

Feedback state

DESCRIPTION

This function performs a one-pole filter on single samples of data. The coefficient for the filter is specified in the parameter list. The "feedback state" parameter is a pointer to a single SLData t location. Separate "feedback states" are required for each filter.

The one-pole filter implements the following equation:

$$y(n)=x(n)+alpha.y(n-1)$$

NOTES ON USE

The function SIF OnePole should be called to initialise "feedback state" to zero.

CROSS REFERENCE

SIF_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDA_OnePoleHighPas, SDA_OnePoleHighPass, SDA_OnePoleHighPass, SDA_OnePoleHighPass, SDA_OnePoleHighPass, SDA_OneP

SDA OnePoleHighPassNormalized, SDA OnePoleHighPassPerSample,

SDS OnePoleTimeConstantToFilterCoeff,

SDS OnePoleCutOffFrequencyToFilterCoeff,

SDS OnePoleHighPassCutOffFrequencyToFilterCoeff

```
void SDA_OnePole (const SLData_t *, Input array to be filtered SLData_t *, Filtered output array const SLData_t, Feedback alpha SLData_t *, Feedback state const SLArrayIndex_t) Array length
```

DESCRIPTION

This function performs a one-pole filter on successive samples in the array. The coefficient for the filter is specified in the parameter list. The "feedback state" parameter is a pointer to a single SLData_t location. Separate "feedback states" are required for each filter.

The one-pole filter implements the following equation:

$$y(n)=x(n)+alpha.y(n-1)$$

NOTES ON USE

The function SIF OnePole should be called to initialise "feedback state" to zero.

CROSS REFERENCE

```
SIF_OnePole, SDS_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff
```

SLData_t SDS_OnePoleNormalized (const SLData_t, Input data to be filtered const SLData_t, Feedback alpha SLData_t*) Feedback state

DESCRIPTION

This function performs a normalized gain one-pole filter on single samples of data. The coefficient for the filter is specified in the parameter list. The one-pole filter has been designed so that the step response gain is normalized to 1.0, i.e. the input data is multiplied by (1.0 - Alpha). The "feedback state" parameter is a pointer to a single SLData_t location. Separate "feedback states" are required for each filter.

NOTES ON USE

The function SIF OnePole should be called to initialise "feedback state" to zero.

The one-pole filter implements the following equation:

$$y(n)=(1-alpha).x(n)+alpha.y(n-1)$$

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

void SDA_OnePoleNormalized (const SLData_t *, Input array to be filtered

SLData_t *, Filtered output array const SLData_t, Feedback alpha SLData_t *, Feedback state const SLArrayIndex t) Array length

DESCRIPTION

This function performs a normalized gain one-pole filter on successive samples in the array. The coefficient for the filter is specified in the parameter list. The one-pole filter has been designed so that the step response gain is normalized to 1.0, i.e. the input data is multiplied by (1.0 - Alpha). The "feedback state" parameter is a pointer to a single SLData_t location. Separate "feedback states" are required for each filter.

The one-pole filter implements the following equation:

$$y(n)=(1-alpha).x(n)+alpha.y(n-1)$$

NOTES ON USE

The function SIF OnePole should be called to initialise "feedback state" to zero.

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

SLData_t SDS_OnePoleEWMA (const SLData_t, Input data to be filtered const SLData_t, Feedback alpha SLData_t*) Feedback state

DESCRIPTION

This function performs an exponentially weighted moving average one-pole filter on single samples of data. The coefficient for the filter is specified in the parameter list. The one-pole filter has been designed so that the step response gain is normalized to 1.0. The "feedback state" parameter is a pointer to a single SLData_t location. Separate "feedback states" are required for each filter.

NOTES ON USE

The function SIF OnePole should be called to initialise "feedback state" to zero.

The one-pole filter implements the following equation:

$$y(n)=alpha.x(n)+(1-alpha).y(n-1)$$

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

void SDA_OnePoleEWMA (const SLData_t *, Input array to be filtered SLData_t *, Filtered output array const SLData_t, Feedback alpha SLData_t *, Feedback state const SLArrayIndex_t) Array length

DESCRIPTION

This function performs an exponentially weighted moving average one-pole filter on successive samples in the array. The coefficient for the filter is specified in the parameter list. The one-pole filter has been designed so that the step response gain is normalized to 1.0. The "feedback state" parameter is a pointer to a single SLData_t location. Separate "feedback states" are required for each filter.

The one-pole filter implements the following equation:

$$y(n)=alpha.x(n)+(1-alpha).y(n-1)$$

NOTES ON USE

The function SIF OnePole should be called to initialise "feedback state" to zero.

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff


void SDA_OnePolePerSample (const SLData_t *, Data to be filtered

SLData_t *, Filtered output array

SLData_t *, State array const SLData_t, Feedback alpha const SLArrayIndex t) Array length

DESCRIPTION

This function performs a normalized one-pole filter on data between successive arrays. The coefficient for the filter is specified in the parameter list. The one-pole filter has been designed so that the net gain to the signal is zero.



The one-pole filter implements the following equation:

$$y(n)=(1-alpha).x(n)+alpha.y(n-1)$$

NOTES ON USE

For initialisation, the "feedback state" array should be initialised to zero.

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

SLData_t SIF_OnePoleHighPass (SLData_t *) Feedback state

DESCRIPTION

This function initialises the state variable for the functions SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized and SDA_OnePoleHighPassNormalized.

NOTES ON USE

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SDA_OnePolePerSample, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

SLData_t SDS_OnePoleHighPass (const SLData_t, Input data to be filtered const SLData_t, Feedback alpha SLData_t*) Feedback state

DESCRIPTION

This function performs a one pole high pass filter on single samples of data. The coefficient for the filter is specified in the parameter list. The "feedback state" parameter is a pointer to a single SLData_t location. Separate "feedback states" are required for each filter.

The one-pole filter implements the following equation:

$$y(n)=x(n)+alpha.y(n-1)$$

NOTES ON USE

The function SIF_OnePoleHighPass should be called to initialise "feedback state" to zero.

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

void SDA_OnePoleHighPass (const SLData_t *, Input array to be filtered

SLData_t *, Filtered output array const SLData_t, Feedback alpha SLData_t *, Feedback state const SLArrayIndex_t) Array length

DESCRIPTION

This function performs a one pole high pass filter on successive samples in the array. The coefficient for the filter is specified in the parameter list. The "feedback state" parameter is a pointer to a single SLData_t location. Separate "feedback states" are required for each filter.

The one-pole filter implements the following equation:

$$y(n)=x(n)+alpha.y(n-1)$$

NOTES ON USE

The function SIF_OnePoleHighPass should be called to initialise "feedback state" to zero.

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

SLData_t SDS_OnePoleHighPassNormalized (const SLData_t, Input data to be filtered

const SLData_t, Feedback alpha SLData_t*) Feedback state

DESCRIPTION

This function performs a one-pole filter high pass on single samples of data. The coefficient for the filter is specified in the parameter list. The one-pole filter has been designed so that the step response gain is normalized to 1.0, i.e. the input data is multiplied by (1.0 - Alpha). The "feedback state" parameter is a pointer to a single SLData t location. Separate "feedback states" are required for each filter.

NOTES ON USE

The function SIF_OnePoleHighPass should be called to initialise "feedback state" to zero.

The one-pole filter implements the following equation:

$$y(n)=(1-alpha).x(n)+alpha.y(n-1)$$

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleEWMA, SDA_OnePoleEWMA,

SDA OnePolePerSample, SIF OnePoleHighPass, SDS OnePoleHighPass,

 $SDA_OnePoleHighPass, SDA_OnePoleHighPassNormalized,$

 $SDA_OnePoleHighPassPerSample,\ SDS_OnePoleTimeConstantToFilterCoeff,$

 $SDS_OnePoleCutOffFrequencyToFilterCoeff,\\$

 $SDS\ One Pole High Pass Cut Off Frequency To Filter Coeff$

void SDA_OnePoleHighPassNormalized (const SLData_t *, Input array to be filtered

SLData_t *, Filtered output array const SLData_t, Feedback alpha SLData_t *, Feedback state const SLArrayIndex t) Array length

DESCRIPTION

This function performs a one pole high pass filter on successive samples in the array. The coefficient for the filter is specified in the parameter list. The one-pole filter has been designed so that the step response gain is normalized to 1.0, i.e. the input data is multiplied by (1.0 - Alpha). The "feedback state" parameter is a pointer to a single SLData_t location. Separate "feedback states" are required for each filter.

The one-pole filter implements the following equation:

$$y(n)=(1-alpha).x(n)+alpha.y(n-1)$$

NOTES ON USE

The function SIF OnePole should be called to initialise "feedback state" to zero.

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassPerSample, SDS_OnePoleTimeConstantToFilterCoeff, SDS_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff


void SDA OnePoleHighPassPerSample (const SLData t*, Data to be filtered

SLData t*, Filtered output array

SLData_t *, State array
const SLData_t, Feedback alpha
const SLArrayIndex t) Array length

DESCRIPTION

This function performs a normalized one pole high pass filter on data between successive arrays. The coefficient for the filter is specified in the parameter list. The one-pole filter has been designed so that the net gain to the signal is zero.



The one-pole filter implements the following equation:

$$y(n)=(1-alpha).x(n)+alpha.y(n-1)$$

NOTES ON USE

For initialisation, the "feedback state" array should be initialised to zero.

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized,

SDA OnePoleNormalized, SDS OnePoleEWMA, SDA OnePoleEWMA,

 $SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass,$

SDA OnePoleHighPass, SDS OnePoleHighPassNormalized,

SDA OnePoleHighPassNormalized, SDS OnePoleTimeConstantToFilterCoeff,

SDS OnePoleCutOffFrequencyToFilterCoeff,

SDS OnePoleHighPassCutOffFrequencyToFilterCoeff

SLData_t SDS_OnePoleTimeConstantToFilterCoeff (const SLData_t, Period (ms) const SLData_t) Sample rate (Hz)

DESCRIPTION

This function converts the one-pole time constant (in milliseconds) to a coefficient that decays to -3 dB in the specified time period. The following equation is used:

 $attack_decay_coeff = exp(exp(-1.0) / (attack_decay_period_ms * sample_frequency * 0.001))$

NOTES ON USE

CROSS REFERENCE

SIF_OnePole, SDS_OnePole, SDA_OnePole, SDS_OnePoleNormalized, SDA_OnePoleNormalized, SDA_OnePoleNormalized, SDS_OnePoleEWMA, SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass, SDA_OnePoleHighPass, SDS_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleHighPassNormalized, SDA_OnePoleCutOffFrequencyToFilterCoeff, SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff

SLData_t SDS_OnePoleCutOffFrequencyToFilterCoeff (const SLData_t, Cut-off frequency (Hz)

const SLData t)

Sample rate (Hz)

DESCRIPTION

This function converts the one-pole cut-off frequency to a coefficient that decays to -3 dB at the specified frequency. The following equation is used:

attack decay coeff = exp(-2 * Pi * (cut-off frequency / sample frequency))

NOTES ON USE

CROSS REFERENCE

SIF OnePole, SDS OnePole, SDA OnePole, SDS OnePoleNormalized,

SDA OnePoleNormalized, SDS OnePoleEWMA, SDA OnePoleEWMA,

SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass,

SDA OnePoleHighPass, SDS OnePoleHighPassNormalized,

SDA OnePoleHighPassNormalized, SDA OnePoleHighPassPerSample,

SDS OnePoleTimeConstantToFilterCoeff,

 $SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff$

SLData_t SDS_OnePoleHighPassCutOffFrequencyToFilterCoeff (const SLData_t, Cut-off frequency

const SLData t)

Sample rate (Hz)

DESCRIPTION

This function converts the one-pole high pass filter cut-off frequency to a coefficient that decays to -3 dB at the specified frequency. The following equation is used:

attack decay coeff = -exp(-2 * Pi * (cut-off frequency / sample frequency))

NOTES ON USE

CROSS REFERENCE

SIF OnePole, SDS OnePole, SDA OnePole, SDS OnePoleNormalized,

SDA OnePoleNormalized, SDS OnePoleEWMA, SDA OnePoleEWMA,

SDA_OnePolePerSample, SIF_OnePoleHighPass, SDS_OnePoleHighPass,

SDA OnePoleHighPass, SDS OnePoleHighPassNormalized,

SDA OnePoleHighPassNormalized, SDA OnePoleHighPassPerSample,

SDS OnePoleTimeConstantToFilterCoeff,

 $SDS_OnePoleCutOffFrequencyToFilterCoeff$

SIF_AllPole

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_AllPole (SLData_t *, Pointer to filter state array SLArrayIndex_t *, Filter index pointer const SLArrayIndex_t) Filter order

DESCRIPTION

This function initialises the all pole filter functionality and clears the state array to zero.

NOTES ON USE

The state array should be the same size as the filter order.

CROSS REFERENCE

SDS_AllPole, SDA_AllPole.

SDS_AllPole

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_AllPole (const SLData_t, Input sample SLData_t *, Pointer to state array const SLData_t *, Pointer to filter coefficients SLArrayIndex_t *, Pointer to filter index const SLArrayIndex t) Filter order

DESCRIPTION

This function applies an all-pole filter to a data stream, a sample at a time.

NOTES ON USE

Be aware that all-pole filters can easily be unstable.

SIF_AllPole should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF_AllPole, SDA_AllPole.

SDA_AllPole

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_AllPole (const SLData_t *, Pointer to source array to be filtered SLData_t *, Pointer to filter output array SLData_t *, Pointer to filter state array Pointer to filter coefficients SLArrayIndex_t *, Pointer to filter state index const SLArrayIndex_t, Filter order const SLArrayIndex_t) Array length

DESCRIPTION

This function applies an all-pole filter to a data stream.

NOTES ON USE

Be aware that all-pole filters can easily be unstable.

SIF_AllPole should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF AllPole, SDS AllPole.

SDA_AllPole

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SDA_AllPole (const SLData_t *, Pointer to source array to be filtered SLData_t *, Pointer to filter output array SLData_t *, Pointer to filter state array Pointer to filter coefficients SLArrayIndex_t *, Pointer to filter state index const SLArrayIndex_t, Filter order const SLArrayIndex_t) Array length
```

DESCRIPTION

This function applies an all-pole filter to a data stream.

NOTES ON USE

Be aware that all-pole filters can easily be unstable.

SIF_AllPole should be called prior to using this function, to perform the required initialisation.

CROSS REFERENCE

SIF AllPole, SDS AllPole.

void SDA_ZDomainCoefficientReorg (const SLData_t *, Pointer to z-domain source coefficient array,

SLComplexRect_s *, Pointer to destination z-domain poles SLComplexRect_s *, Pointer to destination z-domain zeros

const SLArrayIndex t) Filter order

DESCRIPTION

This function separates and re-organizes the z-domain coefficient array that is generated in Digital Filter Plus so that the coefficients can be used by SigLib. The output results in separate arrays for the poles and zeros..

NOTES ON USE


CROSS REFERENCE

SLError_t SIF_IirNotchFilter2 (SLData_t *, Pointer to filter coefficients

const SLData_t, Notch frequency const SLData_t, Pole magnitude const SLArrayIndex t) Filter order

DESCRIPTION

This function initialises the coefficients of an IIR notch filter where the zeros are placed on the unit circle at the specified frequency and the poles are at the same frequency (θ) but located at the given magnitude (M) within the unit circle. The arrangement for a single biquad is shown in the following diagram.



NOTES ON USE

The frequency parameter is in Hz, with a normalized sampling rate of 1.0 Hz.

CROSS REFERENCE

SIF Iir, SDA Iir, SDS Iir.

SLError_t SIF_IirNormalizedCoefficients (SLData_t *, Pointer to filter coefficients enum SLIIRNormalizedCoeffs_t, Filter coefficient type const SLArrayIndex_t) Filter order

DESCRIPTION

This function returns a set of IIR biquad filter coefficients for a filter with the following cut-off frequency:

Sample Rate	Cut-off Frequency
2π radians sec ⁻¹	1.0 radians sec ⁻¹
1.0 Hz	$1.0 / 2\pi = 0.15915 \text{ Hz}$

The coefficients can be converted to low-pass and high-pass filters using SDA_IirLpLpShift, SDA_IirLpHpShift respectively and from these it is possible to generate band-pass and notch filters.

The type of filter prototypes supported by this function are specified in the "filter coefficient type" parameter and are:

NOTES ON USE

The maximum filter order for this function is 10 and is controlled by the constant: SIGLIB MAX NORMALIZED IIR FILTER ORDER.

Transforming the coefficients in the digital domain is not a monotonic transformation. I.E. The transform does not guarantee to maintain the gain and phase responses. If you wish to maintain the gain and phase then you should start with and modify the S-Plane coefficients. You can use the function SIF_IirNormalizedSPlaneCoefficients for this purpose.

CROSS REFERENCE

SDA_IirLpLpShift, SDA_IirLpHpShift, SIF_IirNormalizedSPlaneCoefficients.

SLError_t SIF_IirNormalizedSPlaneCoefficients (SLComplexRect_s *,

Pointer to filter poles

enum SLIIRNormalizedCoeffs_t,

Filter coefficient type

const SLArrayIndex_t)

Filter order

DESCRIPTION

This function returns a set of poles for a filter with the following cut-off frequency:

Sample Rate	Cut-off Frequency
2π radians sec ⁻¹	1.0 radians sec ⁻¹
1.0 Hz	$1.0 / 2\pi = 0.15915 \text{ Hz}$

The coefficients can be converted to low-pass and high-pass filters using SDA_IirLpLpShift, SDA_IirLpHpShift respectively and from these it is possible to generate band-pass and notch filters.

The type of filter prototypes supported by this function are specified in the "filter coefficient type" parameter and are:

NOTES ON USE

The maximum filter order for this function is 10 and is controlled by the constant: SIGLIB MAX NORMALIZED IIR FILTER ORDER.

The poles of an IIR biquad section are assumed to be complex conjugate so this function only returns one value of the conjugate pair hence the number of poles returned = ((FILTER ORDER+1)>>1).

The function SDA_TranslateSPlaneCutOffFrequency can be used to translate the cutoff frequency to any desired frequency.

CROSS REFERENCE

SDA_IirLpLpShift, SDA_IirLpHpShift, SIF_IirNormalizedCoefficients, SDA TranslateSPlaneCutOffFrequency.

void SDA_TranslateSPlaneCutOffFrequency (const SLComplexRect_s *,

Pointer to source filter poles / zeros

SLComplexRect_s *, Pointer to destination filter poles / zeros

const SLData_t, New cut-off frequency

const SLArrayIndex t) Filter order

DESCRIPTION

This function translates the cut-off frequency of a filter specified in the S-plane by translating the poles or zeros of the filter.

NOTES ON USE

CROSS REFERENCE

SDA_BilinearTransform, SDA_MatchedZTransform, SIF IirNormalizedSPlaneCoefficients.

SLData_t SDA_IirLpLpShift (const SLData_t *, Source coefficients SLData_t *, Destination coefficients const SLData_t, Original cut-off frequency const SLData_t, Required cut-off frequency const SLData_t, Sample rate (Hz) const SLArrayIndex_t) Number of biquads

DESCRIPTION

This function modifies the cut-off frequency of a low pass IIR biquad filter from the original cut-off frequency to the required frequency. This function returns the gain scaling factor at the centre frequency (D.C) of the filter.

NOTES ON USE

When this function is used to modify the cut-off frequency of the filter it will also modify the pass-band gain. There are two options for handling the gain change: 1/SDA_IirLpLpShift returns the scaling factor to normalise the filter gain this allows the input or output data to be multiplied by the scaling factor to maintain the required pass-band gain.

2/ Use the function SDA_IirModifyFilterGain to adjust the gain of the filter at the centre frequency of the filter (D.C. for a low-pass filter).

Option 2 is usually the preferred method because it maintains the maximum dynamic range of the signal.

CROSS REFERENCE

SDA IirLpHpShift.

SLData_t SDA_IirLpHpShift (const SLData_t *, Source coefficients SLData_t *, Destination coefficients const SLData_t, Original cut-off frequency const SLData_t, Required cut-off frequency const SLData_t, Sample rate (Hz) const SLArrayIndex_t) Number of biquads

DESCRIPTION

Convert the low pass biquad IIR filter into a high pass filter and modify the cut-off frequency from the original cut-off frequency to the required frequency. This function returns the gain scaling factor at the centre frequency (Nyquist frequency) of the filter.

NOTES ON USE

When this function is used to modify the cut-off frequency of the filter it will also modify the pass-band gain. There are two options for handling the gain change: 1/SDA_IirLpHpShift returns the scaling factor to normalise the filter gain this allows the input or output data to be multiplied by the scaling factor to maintain the required pass-band gain.

2/ Use the function SDA_IirModifyFilterGain to adjust the gain of the filter at the centre frequency of the filter (Nyquist frequency for a high-pass filter).

Option 2 is usually the preferred method because it maintains the maximum dynamic range of the signal.

CROSS REFERENCE


SDA IirLpLpShift.

void SIF_Iir2PoleLpf (SLData_t *, Pointer to filter state array SLData_t *, Pointer to filter coefficients array const SLData_t, Cut-off frequency const SLData_t) Pole radius

DESCRIPTION

This function generates the feedback coefficients for a two-pole IIR low-pass filter, with the following flow diagram:

IIR Two Pole Filter



NOTES ON USE

CROSS REFERENCE

SDS_Iir2Pole, SDA_Iir2Pole.

SDS_Iir2Pole

PROTOTYPE AND PARAMETER DESCRIPTION


SLData_t SDS_Iir2Pole (const SLData_t, SLData_t *, Const SLData_t *)

Input data sample to be filtered Pointer to filter state array Pointer to filter coefficients array

DESCRIPTION

This function implements a 2 pole IIR filter, on a per-sample basis, with the following flow diagram:

IIR Two Pole Filter



NOTES ON USE

CROSS REFERENCE

SIF_Iir2PoleLpf, SDS_Iir2Pole, SDA_Iir2Pole.


void SDA_Iir2Pole (const SLData_t *, Input array to be filtered SLData_t *, Filtered output array SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients array const SLArrayIndex_t)

Array length

DESCRIPTION

This function implements a 2 pole IIR filter, on an array basis, with the following flow diagram:

IIR Two Pole Filter



NOTES ON USE

CROSS REFERENCE

SIF_Iir2PoleLpf, SDS_Iir2Pole.

void SDA_IirNegateAlphaCoeffs (const SLData_t *, Pointer to source filter

coefficients array

SLData_t *, Pointer to destn. filter coefficients array

const SLArrayIndex_t) Number of biquads

DESCRIPTION

This function negates the denominator (feedback) coefficients of an IIR filter to allow support for devices that implement MAC or MSUB operations. Also this allows coefficients to be used with SigLib that have been designed using filter design tools that do negate the feedback coefficients.

NOTES ON USE

CROSS REFERENCE

SIF Iir, SDS Iir, SDA Iir, SDS IirMac, SDA IirMac.

```
void SDA_Integrate (const SLData_t *, Input array pointer SLData_t *, Output data pointer const SLData_t, Integrate reset level const SLData_t, SLData_t *, SLData_t *, Integral sum pointer const SLArrayIndex t)

Input array pointer Output data pointer Integrate reset level Sum decay value Integral sum pointer Array length
```

DESCRIPTION

This function integrates the signal in the array. The function includes support for decaying the summation by a constant factor and resetting the sum, when it reaches a fixed peak value. The latter function is often termed integrate and dump. The fixed value, to which the integrator is allowed to rise is tested in both the positive and negative direction.

NOTES ON USE

The decay factor is a gain factor on the integration so for 0 decay the value 1.0 must be used.

The pointer to the integral sum value is used for continuity across array boundaries.

CROSS REFERENCE

SDA Differentiate, SDS LeakyIntegrator1, SDS LeakyIntegrator2

void SDA_Differentiate (const SLData_t *, Input array pointer SLData_t *, Output array pointer SLData_t *, Previous data value pointer const SLArrayIndex_t) Array length

DESCRIPTION

Differentiate the signal in the array, i.e. return the difference between two successive samples.

NOTES ON USE

The pointer to the previous data value is used for continuity across array boundaries.

CROSS REFERENCE

SDA_Integrate

void SIF_LeakyIntegrator (SLData_t *) Pointer to integrator state variable

DESCRIPTION

Initialize the leaky integrator functions.

NOTES ON USE

CROSS REFERENCE

SDS_LeakyIntegrator1, SDS_LeakyIntegrator2

SLData t SDS LeakyIntegrator1 (const SLData t, Source data value

SLData t*, Pointer to integrator state variable

const SLData t, Leak output value

const SLData_t) Peak value of integrator state variable

DESCRIPTION

This function implements a leaky integrator. The state value is not allowed to overflow the peak level, even temporarily

NOTES ON USE

The function SIF LeakyIntegrator should be called prior to calling this function.

The Leak output value is the constant value that is subtracted from the integrator state variable prior to adding in the new data.

The peak value is that level above which the state variable can not exceed.

CROSS REFERENCE

SDA Integrate, SIF LeakyIntegrator, SDS LeakyIntegrator2

SLData t SDS LeakyIntegrator2 (const SLData t, Source data value

SLData_t *, Pointer to integrator state variable

const SLData t, Leak output value

const SLData t) Peak value of integrator state variable

DESCRIPTION

Implement a leaky integrator. The state value is allowed to overflow the peak level temporarily as SLArrayIndex_t as the accumulator value is below the peak level when the function returns.

NOTES ON USE

The function SIF LeakyIntegrator should be called prior to calling this function.

The Leak output value is the constant value that is subtracted from the integrator state variable after adding in the new data.

The peak value is that level above which the state variable can not exceed.

CROSS REFERENCE

SDA Integrate, SIF LeakyIntegrator, SDS LeakyIntegrator1

void SIF_HilbertTransformer (SLData_t *, Filter coefficients array const SLArrayIndex_t) Filter length

DESCRIPTION

This function initialises the coefficients of an FIR Hilbert transformer filter.

The Hilbert transform uses an N coefficient FIR filter to phase shift every component in a signal by 90 degrees (N is odd ordered).

The defining equations for the Hilbert transform are:

$$h(n) = \frac{2}{n * \pi} * \sin^2(\frac{n * \pi}{2})$$
 for $n = \pm 1, \pm 2, \pm \frac{N}{2}$
and $h(0) = 0$ for $n = 0$

NOTES ON USE

N must be odd.

CROSS REFERENCE

SDS_Fir, SDA_Fir, SDA_FdHilbert.

SLData_t SIF_GoertzelFilter (SLData_t *, State array pointer const SLData_t, Centre frequency const SLArrayIndex t) Array length

DESCRIPTION

This function returns the coefficient for a Goertzel IIR filter. This parameter must be passed to the Goertzel filter and detect functions. The filter is a band-pass filter with the specified centre frequency.

NOTES ON USE

The frequency is normalised to Fs = 1.0.

CROSS REFERENCE

 $SDA_Goertzel Filter, SDA_Goertzel Detect, SUF_Estimate BPFilter Length, SUF_Estimate BPFilter Error.$

void SDA_GoertzelFilter (const SLData_t *, Input array pointer SLData_t *, Output array pointer SLData_t *, State array pointer const SLData_t, Filter coefficient const SLArrayIndex t) Array length

DESCRIPTION

This function applies the real Goertzel IIR filter to the data stream. A Goertzel filter is an IIR filter that selects a specified pass band in a filtered signal. The filter has the following flow diagram:

NOTES ON USE

Best performance can be obtained if N can be chosen so that the array length * the frequency gives a value that is close to an integer. This filter does not maintain the complex (phase) information because the value for $-W_N^*$ is $\cos(2\pi k/N)$.


CROSS REFERENCE

SIF_GoertzelFilter, SDS_GoertzelFilter, SDA_GoertzelDetect, SUF_EstimateBPFilterLength, SUF_EstimateBPFilterError.

void SDS_GoertzelFilter (const SLData_t, Input data sample SLData_t *, State array pointer const SLData_t) Filter coefficient

DESCRIPTION

This function applies the real Goertzel IIR filter to the data stream, on a per-sample basis. A Goertzel filter is an IIR filter that selects a specified pass band in a filtered signal. The filter has the following flow diagram:



NOTES ON USE

Best performance can be obtained if N can be chosen so that the array length * the frequency gives a value that is close to an integer. This filter does not maintain the complex (phase) information because the value for $-W_N^*$ is $\cos(2\pi k/N)$.

CROSS REFERENCE

SIF_GoertzelFilter, SDA_GoertzelFilter, SDA_GoertzelDetect, SUF EstimateBPFilterLength, SUF EstimateBPFilterError.

SLData_t SIF_GoertzelDetect (const SLData_t, Centre frequency const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the coefficient for a Goertzel detector. This parameter must be passed to the Goertzel detect function. The filter is a band-pass filter with the specified centre frequency.

NOTES ON USE

The frequency is normalised to Fs = 1.0.

CROSS REFERENCE

 $SDA_Goertzel Detect, SUF_Estimate BPF ilter Length, \\ SUF_Estimate BPF ilter Error.$

SLData_t SDA_GoertzelDetect (const SLData_t *, Source array pointer const SLData_t, Filter coefficient const SLArrayIndex t) Filter length

DESCRIPTION

This function applies the Goertzel IIR filter to the data stream and returns the power squared of the signal in the filter pass band. The filter has the following flow diagram:

This detector returns the magnitude squared filter output i.e. real² + imaginary². The Goertzel detector is often used to detect particular individual frequencies, a common application is the detection of DTMF tones. $-W_N^* = \cos(2\pi k/N) - j \sin(2\pi k/N)$.

NOTES ON USE

Best performance can be obtained if N can be chosen so that the array length * the frequency gives a value that is close to an integer.

CROSS REFERENCE

 $SIF_Goertzel Detect, SDA_Goertzel Filter, SUF_Estimate BPFilter Length, SUF_Estimate BPFilter Error.$

SLComplexRect_s SIF_GoertzelDetectComplex (const SLData_t, Centre frequency const SLArrayIndex_t)

Array length

DESCRIPTION

This function returns the complex coefficient for a Goertzel IIR filter. This parameter must be passed to the complex Goertzel detect function. The filter is a band-pass filter with the specified centre frequency.

NOTES ON USE

The frequency is normalised to Fs = 1.0.


CROSS REFERENCE

 $SDA_Goertzel Detect, SDA_Goertzel Detect Complex, \\ SUF_Estimate BPFilter Length, SUF_Estimate BPFilter Error.$

SLComplexRect_s SDA_GoertzelDetectComplex (const SLData_t *, Src pointer const SLComplexRect_s, Complex filter coefficient const SLArrayIndex_t) Filter length

DESCRIPTION

This function applies the Goertzel IIR filter to the data stream and returns the frequency domain coefficients for the signal in the filter pass band. The filter has the following flow diagram:



This detector is exactly identical to the discrete Fourier transform. The Goertzel detector is often used to detect particular individual frequencies, a common application is the detection of DTMF tones. $W_{N}^{*} = \cos(2\pi k/N) - j \sin(2\pi k/N)$.

NOTES ON USE

Best performance can be obtained if N can be chosen so that the array length * the frequency gives a value that is close to an integer.

CROSS REFERENCE

SIF_GoertzelDetectComplex, SDA_GoertzelDetect, SDA_GoertzelDetectComplex, SUF_EstimateBPFilterLength, SUF_EstimateBPFilterError.

void SIF_GaussianFilter (SLData_t *, const SLData_t, const SLArrayIndex_t)

Filter coefficients array Standard deviation of the distribution Filter length

DESCRIPTION

This function initialises the coefficients of an FIR Gaussian filter.

The distribution has a mean of zero but is centred around the centre coefficient of the array (N is odd ordered). The Gaussian filter exhibits no oscillations in its frequency response, which is also Gaussian in nature.

The defining equations for the Gaussian filter are:

$$G(x) = \frac{1.0}{\sqrt{2\pi} \sigma} e^{-\frac{x^2}{2\sigma^2}}$$

where σ is the standard deviation of the distribution. The coefficient equation is:

$$h(n) = \frac{2}{n * \pi} * \sin^2(\frac{n * \pi}{2})$$
 for $n = \pm 1, \pm 2, \pm \frac{N}{2}$
and $h(0) = 0$ for $n = 0$

NOTES ON USE

The filter length (number of coefficients) must be odd.

CROSS REFERENCE

SIF_Fir, SDA_Fir, SDS_Fir, SIF_GaussianFilter2.

void SIF_GaussianFilter2 (SLData_t *, Filter coefficients array const SLData_t, Filter bandwidth const SLArrayIndex_t) Filter length

DESCRIPTION

This function initialises the coefficients of an FIR Gaussian filter.

The pass-band bandwidth is specified by the "Bandwidth" parameter. The coefficient equation is:

$$h(n) = \frac{2}{n^* \pi} * \sin^2 \left(\frac{n^* \pi}{2}\right)$$
 for $n = \pm 1, \pm 2, \pm \frac{N}{2}$
and $h(0) = 0$ for $n = 0$

NOTES ON USE

The filter length (number of coefficients) must be odd.

CROSS REFERENCE

SIF Fir, SDA Fir, SDS Fir, SIF GaussianFilter.

void SIF_RaisedCosineFilter (SLData_t *, Pointer to filter coefficients const SLData_t, Symbol period const SLData_t, Alpha const SLArrayIndex t) Filter length

DESCRIPTION

This function initialises the coefficients of an FIR raised cosine filter. The defining equation for the coefficients of the raised cosine filter is:

$$h(t) = \frac{\operatorname{sinc}\left(\frac{\pi t}{T}\right) \cos\left(\frac{\pi \alpha t}{T}\right)}{1 - 4\left(\frac{\alpha t}{T}\right)^2}$$

Where $0 \le \alpha \le 1.0$ and the symbol rate (B) = 1/T.

$$h(n) = \frac{2}{n^* \pi} * \sin^2 \left(\frac{n^* \pi}{2}\right)$$
 for $n = \pm 1, \pm 2, \pm \frac{N}{2}$
and $h(0) = 0$ for $n = 0$

NOTES ON USE

The number of coefficients will be odd. This function detects possible issues such as $\cos (\pi/2)$ and generates the coefficient as a linear interpolation of the two adjacent coefficients.

The filter index is k = -N to +N, where N = (Length -1)/2.

The sample rate is normalised to 1.0 Hz

Alpha is the excess bandwidth of the filter beyond the -3dB point. For the raised cosine filter:

alpha = 0 - Ideal LPF with $F_{cut-off}$ = Nyquist Frequency alpha = 1 - Smooth roll off but doubles signal bandwidth

The minimum pre-amble is one symbol when using this function.

CROSS REFERENCE

SIF Fir, SDA Fir, SDS Fir.

void SIF_RootRaisedCosineFilter (SLData_t *, Filter coeffs. pointer

const SLData_t, Symbol period

const SLData_t, Alpha

const SLArrayIndex_t) Filter length

DESCRIPTION

This function initialises the coefficients of an FIR square root raised cosine filter. The defining equation for the coefficients of the square root raised cosine filter is:

$$h(t) = \frac{4\alpha}{\pi\sqrt{T}} \frac{\sin\left((1-\alpha)\frac{\pi t}{T}\right)}{1-\left(4\frac{\alpha t}{T}\right)^2}$$

Where $0 < \alpha < 1.0$ and the symbol rate (B) = 1/T.

$$h(n) = \frac{2}{n^* \pi} * \sin^2 \left(\frac{n^* \pi}{2}\right)$$
 for $n = \pm 1, \pm 2, \pm \frac{N}{2}$
and $h(0) = 0$ for $n = 0$

NOTES ON USE

The number of coefficients will be odd. This function detects possible issues such as $\cos(\pi/2)$ and generates the coefficient as a linear interpolation of the two adjacent coefficients. The filter index is k = -N to +N, where N = (Length -1)/2. The sample rate is normalised to 1.0 Hz Alpha is the excess bandwidth of the filter beyond the -3dB point. For the square root raised cosine filter

alpha = 0 - Ideal LPF with $F_{\text{cut-off}}$ = Nyquist Frequency

alpha = 1 - Smooth roll off but doubles signal bandwidth

The minimum pre-amble is one symbol when using this function.

CROSS REFERENCE

SLData_t SDS_ZTransform (const SLComplexRect_s, Location in z-plane to calculate

const SLComplexRect_s *, Pointer to numerator coefficients const SLComplexRect_s *, Pointer to denominator coefficients const SLArrayIndex_t, Number of numerator coefficients const SLArrayIndex_t) Number of denominator coefficients

DESCRIPTION

This function returns the magnitude of the z-transform, calculated at the specific location in the z-plane.

NOTES ON USE

The number of numerator or denominator coefficients may be zero. If the number of numerator or denominator coefficients is non zero then they must both be the same otherwise the function will return 0.

CROSS REFERENCE

SDS ZTransformDB.

SLData_t SDS_ZTransformDB (const SLComplexRect_s, Location in z-plane to calculate

const SLComplexRect_s *, Pointer to numerator coefficients const SLComplexRect_s *, Pointer to denominator coefficients const SLArrayIndex_t, Number of numerator coefficients const SLArrayIndex_t) Number of denominator coefficients

DESCRIPTION

This function returns the magnitude of the z-transform in dB, calculated at the specific location in the z-plane.

NOTES ON USE

The number of numerator or denominator coefficients may be zero. If the number of numerator or denominator coefficients is non zero then they must both be the same otherwise the function will return 0.

CROSS REFERENCE

SDS ZTransform.

SLArrayIndex_t SUF_EstimateBPFilterLength (const SLData_t, Sample rate (Hz)

const SLData_t, Centre frequency
const SLArrayIndex_t, Minimum filter length
const SLArrayIndex_t) Maximum filter length

DESCRIPTION

This function analyzes the given range of band-pass filter lengths and estimates the length that provides the minimum side lobe error / Gibbs effect.

Side lobe error is estimated from the fractional component of the number of cycles of the input waveform in the filter state array, for the given sample rate.

This function is useful for the estimation of filter lengths for band-pass FIR and other equivalent filters (e.g. Goertzel filters, as used in DTMF detectors).

NOTES ON USE

CROSS REFERENCE

SUF EstimateBPFilterError.

void SUF_EstimateBPFilterError (const SLData_t, Sample rate (Hz) const SLData_t, Centre frequency const SLArrayIndex_t, Minimum filter length const SLArrayIndex_t, Maximum filter length SLData t*)

Void SUF_EstimateBPFilterError (const SLData_t, Sample rate (Hz)

Centre frequency

Minimum filter length

Pointer to error array

DESCRIPTION

This function analyzes the given range of band-pass filter lengths and estimates the magnitude of the side lobe error / Gibbs effect for each filter length. The error values for all the filter lengths are written into the error array.

Side lobe error is estimated from the fractional component of the number of cycles of the input waveform in the filter state array, for the given sample rate.

This function is useful for the estimation of band-pass filter lengths for FIR and other equivalent filters (e.g. Goertzel filters, as used in DTMF detectors).

NOTES ON USE

It is important to ensure that the error array is long enough to store all of the error results for all of the filter lengths calculated.

CROSS REFERENCE

SUF EstimateBPFilterLength.

SLData_t SUF_FrequenciesToOctaves (const SLData_t Fl, Low frequency const SLData_t Fh) High frequency

DESCRIPTION

This function returns the octave band magnitude for the given frequency band.

NOTES ON USE

CROSS REFERENCE

SUF_FrequenciesToOctaves, SUF_FrequenciesToCentreFreqHz, SUF_FrequenciesToQFactor, SUF_BandwidthToQFactor and SUF_QFactorToBandwidth.

SLData_t SUF_FrequenciesToCentreFreqHz (const SLData_t Fl, Low frequency const SLData_t Fh) High frequency

DESCRIPTION

This function returns the centre frequency for the given frequency band.

NOTES ON USE

CROSS REFERENCE

SUF_FrequenciesToOctaves, SUF_FrequenciesToCentreFreqHz, SUF_FrequenciesToQFactor, SUF_BandwidthToQFactor and SUF_QFactorToBandwidth.

SLData_t SUF_FrequenciesToQFactor (const SLData_t Fl, Low frequency const SLData_t Fh)

High frequency

DESCRIPTION

This function returns the Q factor for the given frequency band.

NOTES ON USE

CROSS REFERENCE

SUF_FrequenciesToOctaves, SUF_FrequenciesToCentreFreqHz, SUF_FrequenciesToQFactor, SUF_BandwidthToQFactor and SUF_QFactorToBandwidth.

SLData t SUF BandwidthToQFactor (const SLData t BW) Bandwidth

DESCRIPTION

This function returns the Q factor for the given frequency bandwidth.

NOTES ON USE

CROSS REFERENCE

SUF_FrequenciesToOctaves, SUF_FrequenciesToCentreFreqHz, SUF_FrequenciesToQFactor, SUF_BandwidthToQFactor and SUF_QFactorToBandwidth.

SLData t SUF QFactorToBandwidth (const SLData t QFactor) Q factor

DESCRIPTION

This function returns the bandwidth for the given Q factor.

NOTES ON USE

CROSS REFERENCE

SUF_FrequenciesToOctaves, SUF_FrequenciesToCentreFreqHz, SUF_FrequenciesToQFactor, SUF_BandwidthToQFactor and SUF_QFactorToBandwidth.

ACOUSTIC PROCESSING FUNCTIONS (acoustic.c)

SDA LinearMicrophoneArrayBeamPattern

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_LinearMicrophoneArrayBeamPattern (const SLFixData_t, Number of microphones

const SLData_t,
Const SLData_t,
Surce signal frequency (Hz)
SLData_t *,
SLData_t *,
Pointer to response angles array (Degrees)
SLData_t *,
Pointer to response gain array (dB)
Const SLData_t,
Calculation start angle (Degrees)
Const SLData_t,
Calculation end angle (Degrees)
Const SLFixData_t)
Number of angles to calculate

DESCRIPTION

This function calculates the beam pattern for a linear microphone array, for a given number of microphones; microphone spacing and source signal frequency.

Calculates antenna gains, in dB, between the start angle and the end angle.

NOTES ON USE

The output is in the following format:

Beam angles Degrees Beam gains dB

CROSS REFERENCE

 $SDA_Linear Microphone Array Beam Pattern Linear,\\SDA_Microphone Array Calculate Delays, SDA_Microphone Array Beam Pattern,\\SDA_Microphone Array Beam Pattern Linear$

Microphone spacing (meters)

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_LinearMicrophoneArrayBeamPatternLinear (const SLFixData_t,

Number of microphones

const SLData t,

const SLData_t,
SLData_t *,
Ptr to response angles array (Degrees)
SLData_t *,
Pointer to response gain array (dB)
const SLData_t,
Calculation start angle (Degrees)
const SLData_t,
Calculation end angle (Degrees)
Number of angles to calculate

DESCRIPTION

This function calculates the beam pattern for a linear microphone array, for a given number of microphones; microphone spacing and source signal frequency.

Calculates antenna gains between the start angle and the end angle.

The gain values are linear, rather than dB

NOTES ON USE

The output is in the following format:

Beam angles Degrees
Beam gains dB

CROSS REFERENCE

SDA LinearMicrophoneArrayBeamPattern,

 $SDA_Microphone Array Calculate Delays, SDA_Microphone Array Beam Pattern,$

 $SDA_Microphone Array Beam Pattern Linear$

void SDA_MicrophoneArrayCalculateDelays (const SLFixData_t, Number of microphones

```
SLMicrophone_s *, Microphone configuration const SLData_t) Angle to steer beam (Degrees)
```

DESCRIPTION

This function calculates the delays required to steer the beam of an arbitrary array of microphones into a particular direction.

NOTES ON USE

The microphone details are defined as follows:

Here is an example of a microphone declaration:

Applying the SDA_MicrophoneArrayCalculateDelays() function to the microphone array will update the delay elements to steer the beam.

CROSS REFERENCE

```
SDA_LinearMicrophoneArrayBeamPattern,
SDA_LinearMicrophoneArrayBeamPatternLinear,
```

SDA MicrophoneArrayBeamPattern, SDA MicrophoneArrayBeamPatternLinear

void SDA_MicrophoneArrayBeamPattern (const SLFixData_t, Number of microphones

const SLMicrophone_s *, Microphone configuration const SLData t, Source signal frequency

const SLData t, Source signal radius from centre of

microphone array

SLData_t *, Pointer to response angles array SLData_t *, Pointer to response gain array const SLData_t, Calculation start angle (Degrees) const SLData_t, Calculation end angle (Degrees) const SLFixData_t, Number of angles to calculate

const SLData_t) Sample rate (Hz)

DESCRIPTION

This function calculates the beam pattern for an arbitrary microphone array, for a given number of microphones and source signal frequency.

Calculates antenna gains, in dB, between the start angle and the end angle.

NOTES ON USE

The output is in the following format:

Beam angles Degrees Beam gains dB

The delays provided in the microphone configuration are quantized to the supplied sample rate.

CROSS REFERENCE

SDA LinearMicrophoneArrayBeamPattern,

SDA LinearMicrophoneArrayBeamPatternLinear,

 $SDA_Microphone Array Calculate Delays, SDA_Microphone Array Beam Pattern Linear$

void SDA_MicrophoneArrayBeamPatternLinear (const SLFixData_t, Number of microphones

const SLMicrophone_s *, Microphone configuration const SLData_t, Source signal frequency

const SLData t, Source signal radius from centre of

microphone array

SLData_t *, Pointer to response angles array SLData_t *, Pointer to response gain array const SLData_t, Calculation start angle (Degrees) const SLData_t, Calculation end angle (Degrees) const SLFixData_t, Number of angles to calculate

const SLData t) Sample rate (Hz)

DESCRIPTION

This function calculates the beam pattern for an arbitrary microphone array, for a given number of microphones and source signal frequency.

Calculates antenna gains between the start angle and the end angle.

The gain values are linear, rather than dB.

NOTES ON USE

The output is in the following format:

Beam angles Degrees Beam gains dB

The delays provided in the microphone configuration are quantized to the supplied sample rate.

CROSS REFERENCE

SDA LinearMicrophoneArrayBeamPattern,

SDA LinearMicrophoneArrayBeamPatternLinear,

SDA MicrophoneArrayCalculateDelays, SDA MicrophoneArrayBeamPattern

SLData_t SDS_TemperatureToSpeedOfSoundInAir (const SLData_t temp)

DESCRIPTION

This function calculates the speed of sound in air for a given air temperature.

NOTES ON USE

CROSS REFERENCE

 $SDA_Linear Microphone Array Beam Pattern,\\$


SDA LinearMicrophoneArrayBeamPatternLinear,

SDA_MicrophoneArrayCalculateDelays, SDA_MicrophoneArrayBeamPattern,

SDA_MicrophoneArrayBeamPatternLinear

ADAPTIVE COEFFICIENT FILTER FUNCTIONS (adaptive.c)

The adaptive filter (AF) functions updates the adaptive transversal filter with the Lease Mean Square (LMS) algorithms. The systems are configured as follows:



Where x(n) is the input signal, y(n) the output, d(n) is the desired signal and e(n) the error between the actual output and the desired.

When implementing adaptive filters, especially in fixed point devices, it is common that quantization leads to the growth of the magnitudes of the coefficients. In order to overcome this problem it is common to multiply the coefficients by a constant that is less than 1.0 (e.g. 0.99) after adaptation.

In many applications it is useful to move the location of the data peak to some other normalized position this can be achieved using the function SDA_MovePeakTowardsDeadBand ().

SIF_Lms

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SIF_Lms (SLData_t *, LMS Pointer to filter state array SLData_t *, LMS Pointer to filter coefficients SLArrayIndex_t *, Pointer to LMS filter index SLArrayIndex_t *, Pointer to LMS filter updater index const SLArrayIndex_t) Adaptive filter length
```

DESCRIPTION

This function initializes the adaptive filter functionality and clears all state arrays, filter index and filter updater index to zero.

NOTES ON USE

CROSS REFERENCE

```
SDS_Lms, SDA_LmsUpdate, SDA_LeakyLmsUpdate, SDA_NormalizedLmsUpdate, SDA_SignErrorLmsUpdate, SDA_SignDataLmsUpdate, SDA_SignSignLmsUpdate.
```

SDS_Lms

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_Lms (const SLData_t, SLData_t *, LMS Pointer to filter state array LMS Pointer to filter coefficients SLArrayIndex_t *, LMS Pointer to filter index offset const SLArrayIndex t)

LMS filter length

DESCRIPTION

This function applies the adaptive transversal filter to the input data stream a sample at a time. this function is almost identical to the SDS_Fir routine, however for the sake of neatness separate functions are used.

NOTES ON USE

The traditional method of viewing the state array is as a bucket brigade FIFO array, with data flowing in one end and falling out the other. For execution efficiency however it is more efficient to use a circular array, so that for each new sample all the data does not have to be shifted up. For this reason each time the SDS_Lms function is called the current array pointer must be known. In order to make this function reusable it is necessary that each instance has a separate pointer, the address of which is passed to the function at call time.

CROSS REFERENCE

SIF_Lms, SDA_LmsUpdate, SDA_LeakyLmsUpdate, SDA_NormalizedLmsUpdate, SDA_SignErrorLmsUpdate, SDA_SignDataLmsUpdate, SDA_SignSignLmsUpdate...

void SDA_LmsUpdate (const SLData_t *, SLData_t *, SLData_t *, LMS Pointer to filter coefficients SLArrayIndex_t *, LMS Pointer to filter index offset const SLArrayIndex_t, LMS filter length const SLData_t, Adaptation step length Error

DESCRIPTION

This function updates the adaptive transversal filter with the Lease Mean Square (LMS) algorithm. The following coefficient update algorithm is used:

$$y(n) = \sum_{k=0}^{N-1} w(k) * x(n-k)$$

$$e(n) = d(n) - y(n)$$

$$w(k) = w(k) + u * e(n) * x(n-k) k = 0,1,2,...,N-1$$

NOTES ON USE

CROSS REFERENCE

SIF_Lms, SDS_Lms, SDA_LeakyLmsUpdate, SDA_NormalizedLmsUpdate, SDA_SignErrorLmsUpdate, SDA_SignDataLmsUpdate, SDA_SignSignLmsUpdate.

void SDA_LeakyLmsUpdate (const SLData_t *, Pointer to filter state array SLData_t *, LMS Pointer to filter coefficients SLArrayIndex_t *, LMS Pointer to filter index offset const SLArrayIndex_t, LMS filter length const SLData_t, Adaptation step length const SLData_t, Coefficient decay const SLData_t) Error

DESCRIPTION

This function updates the adaptive transversal filter with leaky LMS algorithm. The following coefficient update algorithm is used:

One common problem with the LMS algorithm is that over time the coefficients can "grow" and the filter can become unstable. The leaky LMS algorithm reduces the possibility of this by applying a decay to the coefficients.

$$y(n) = \sum_{k=0}^{N-1} w(k) * x(n-k)$$

$$e(n) = d(n) - y(n)$$

$$w(k) = w(k) * DecayRate + u * e(n) * x(n-k) k = 0.1.2....N-1$$

NOTES ON USE

CROSS REFERENCE

SIF_Lms, SDS_Lms, SDA_LmsUpdate, SDA_NormalizedLmsUpdate, SDA_SignErrorLmsUpdate, SDA_SignDataLmsUpdate, SDA_SignSignLmsUpdate.

void SDA_NormalizedLmsUpdate (const SLData_t *, Filter state pointer SLData_t *, LMS Pointer to filter coefficients SLArrayIndex_t *, LMS Pointer to filter index offset SLData_t *, Signal power const SLArrayIndex_t, LMS filter length const SLData_t, Adaptation step length

Error

DESCRIPTION

const SLData t)

This function updates the adaptive transversal filter with the normalised LMS algorithm. The following coefficient update algorithm is used:

$$y(n) = \sum_{k=0}^{N-1} w(k) * x(n-k)$$

$$e(n) = d(n) - y(n)$$

$$w(k) = w(k) + (u * a / Power) * e(n) * x(n-k) k = 0,1,2,..., N-1$$

The normalised LMS algorithm reduces the dependency of convergence speed on the input signal power, at a cost of increased computational complexity. The algorithm applies automatic gain control to the input signal. The equation for the AGC is:

$$Power(n) = (1-b) * Power(n-1) + bx(0)^{2}$$

NOTES ON USE

Note variables a and b are the same value and this is a common technique in most applications.

The signal power parameter should be initialised to SIGLIB ZERO.

CROSS REFERENCE

SIF_Lms, SDS_Lms, SDA_LmsUpdate, SDA_LeakyLmsUpdate, SDA_SignErrorLmsUpdate, SDA_SignDataLmsUpdate, SDA_SignSignLmsUpdate.

void SDA_SignErrorLmsUpdate (const SLData_t *, LMS filter state pointer SLData_t *, LMS Pointer to filter coefficients SLArrayIndex_t *, LMS Pointer to filter index offset const SLArrayIndex_t, LMS filter length const SLData_t, Adaptation step length const SLData_t)

Error

DESCRIPTION

This function updates the adaptive transversal filter with sign error LMS algorithm. The following coefficient update algorithm is used:

$$y(n) = \sum_{k=0}^{N-1} w(k) * x(n-k)$$

$$e(n) = d(n) - y(n)$$

$$w(k) = w(k) + u * sign[e(n)] * x(n-k) k = 0,1,2,...,N-1$$

Where
$$sign[x] = 1.0$$
 for $x \ge 0$ and $sign[x] = -1.0$ for $x < 0$

The sign error LMS function is one of a group of functions that allows for more efficient execution on a range of processors, typically fixed point. The mathematical simplification is through taking the sign of the error component.

NOTES ON USE

CROSS REFERENCE

SIF_Lms, SDS_Lms, SDA_LmsUpdate, SDA_LeakyLmsUpdate, SDA_NormalizedLmsUpdate, SDA_SignDataLmsUpdate, SDA_SignSignLmsUpdate.

void SDA_SignDataLmsUpdate (const SLData_t *, Pointer to filter state array SLData_t *, LMS Pointer to filter coefficients SLArrayIndex_t *, LMS Pointer to filter index offset const SLArrayIndex_t, LMS filter length const SLData_t, Adaptation step length const SLData_t)

Error

DESCRIPTION

This function updates the adaptive transversal filter with the sign data LMS algorithm. The following coefficient update algorithm is used:

$$y(n) = \sum_{k=0}^{N-1} w(k) * x(n-k)$$

$$e(n) = d(n) - y(n)$$

$$w(k) = w(k) + u * e(n) * sign[x(n-k)] k = 0,1,2,..., N-1$$

Where sign[x] = 1.0 for $x \ge 0$ and sign[x] = -1.0 for x < 0

The sign data LMS function is one of a group of functions that allows for more efficient execution on a range of processors, typically fixed point. The mathematical simplification is through taking the sign of the data component.

NOTES ON USE

CROSS REFERENCE

SIF_Lms, SDS_Lms, SDA_LmsUpdate, SDA_LeakyLmsUpdate, SDA_NormalizedLmsUpdate, SDA_SignErrorLmsUpdate, SDA_SignSignLmsUpdate.

void SDA_SignSignLmsUpdate (const SLData_t *, Pointer to filter state array SLData_t *, LMS Pointer to filter coefficients SLArrayIndex_t *, LMS Pointer to filter index offset const SLArrayIndex_t, LMS filter length const SLData_t, Adaptation step length const SLData_t)

Error

DESCRIPTION

This function updates the adaptive transversal filter with the sign-sign LMS algorithm. The following coefficient update algorithm is used:

$$y(n) = \sum_{k=0}^{N-1} w(k) * x(n-k)$$

$$e(n) = d(n) - y(n)$$

$$w(k) = w(k) + u * sign[e(n)] * sign[x(n-k)] k = 0,1,2,...,N-1$$

Where sign[x] = 1.0 for $x \ge 0$ and sign[x] = -1.0 for x < 0

The sign-sign LMS function is one of a group of functions that allows for more efficient execution on a range of processors, typically fixed point. The mathematical simplification is through taking the sign of both the error and the data components.

NOTES ON USE

CROSS REFERENCE

SIF_Lms, SDS_Lms, SDA_LmsUpdate, SDA_LeakyLmsUpdate, SDA_NormalizedLmsUpdate, SDA_SignErrorLmsUpdate, SDA_SignDataLmsUpdate.

CONVOLUTION FUNCTIONS (convolve.c)

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_ConvolveLinear (const SLData_t *, Input array pointer const SLData_t *, Impulse response data pointer SLData_t *, Destination array pointer const SLArrayIndex_t, Input data length const SLArrayIndex_t) Impulse response length

DESCRIPTION

This function performs a linear (zero padded) convolution between two arrays. One array containing the input data, and one containing the impulse response function, to which that data is being applied.

The equation for this function is:

$$y[m] = \sum_{n=0}^{W-1} (w[n] * x[m-n]) \quad 0 \le m < W+X-1$$

NOTES ON USE

This function is almost identical to the FIR filter function, it is however treated as a separate function for the sake of completeness and because treating the functions separately fits more naturally into many applications.

This function treats all data outside the specified arrays as zero.

The Destination array length must be greater than or equal to W+X-I

The input and output arrays can be of different lengths.

CROSS REFERENCE

SDA_ConvolveCircular, SDA_ConvolvePartial, SDA_CorrelateLinear, SDA_CorrelateCircular, SDA_ConvolveLinearComplex, SDA_ConvolvePartialComplex, SDA_ConvolveCircularComplex

void SDA_ConvolvePartial (const SLData_t *, Input array pointer const SLData_t *, Impulse response data pointer SLData_t *, Destination array pointer const SLArrayIndex_t, Input data length const SLArrayIndex t) Impulse response length

DESCRIPTION

This function performs a linear (non-zero padded) convolution between two arrays. One array containing the input data, and one containing the impulse response function, to which that data is being applied.

The equation for thisl function is:

$$y[m] = \sum_{n=0}^{W-1} (w[n] * x[m+W-1-n]) \quad 0 \le m < W-X$$

NOTES ON USE

This function only convolves the data where the arrays completely overlap each other. The Destination array length is equal to X-W+1.

The input array 1 must be larger than or equal to input array 2.

CROSS REFERENCE

SDA_ConvolveLinear, SDA_ConvolveCircular, SDA_CorrelateLinear, SDA_CorrelateCircular, SDA_ConvolveLinearComplex, SDA_ConvolvePartialComplex, SDA_ConvolveCircularComplex

void SDA_ConvolveCircular (const SLData_t *, Input array pointer const SLData_t *, Impulse response data pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Input data length

DESCRIPTION

This function performs a circular convolution between two arrays. One array containing the input data, and one containing the impulse response function, to which that data is being applied.

The equation for this function is:

$$y[m] = \sum_{n=0}^{N-1} (w[n].x[|m-n+N|_N]) \quad 0 \le m < N-1$$

NOTES ON USE

The input and output arrays must be the same length.

CROSS REFERENCE

SDA_ConvolveLinear, SDA_ConvolvePartial, SDA_CorrelateLinear, SDA_CorrelateCircular, SDA_ConvolveLinearComplex, SDA_ConvolvePartialComplex, SDA_ConvolveCircularComplex

void SDA_ConvolveLinearComplex (const SLData_t *, Pointer to real input array

const SLData_t *, Pointer to imaginary input array const SLData_t *, Pointer to real impulse response

const SLData t*, Pointer to imaginary impulse response

SLData t*, Pointer to real destination array

SLData_t *, Pointer to imaginary destination array

const SLArrayIndex t, Input data length

const SLArrayIndex t) Impulse response length

DESCRIPTION

This function performs a linear (zero padded) convolution between two complex data sequences. One sequence containing the input data, and one containing the impulse response function, to which that data is being applied.

The equation for this function is:

$$y[m] = \sum_{n=0}^{W-1} (w[n] * x[m-n]) \quad 0 \le m < W+X-1$$

NOTES ON USE

This function treats all data outside the specified sequences as zero. The Destination sequence length must be greater than or equal to W+X-I The input and output sequences can be of different lengths.

CROSS REFERENCE

SDA_ConvolveLinear, SDA_ConvolveCircular, SDA_ConvolvePartial, SDA_CorrelateLinear, SDA_CorrelateCircular, SDA_ConvolvePartialComplex, SDA_ConvolveCircularComplex

void SDA_ConvolvePartialComplex (const SLData_t *, Pointer to real input array

const SLData_t *, Pointer to imaginary input array const SLData_t *, Pointer to real impulse response

const SLData_t *, Pointer to imaginary impulse response

SLData t*, Pointer to real destination array

SLData_t *, Pointer to imaginary destination array

const SLArrayIndex t, Input data length

const SLArrayIndex t) Impulse response length

DESCRIPTION

This function performs a linear (non-zero padded) convolution between two complex data sequences. One sequence containing the input data, and one containing the impulse response function, to which that data is being applied.

The equation for this function is:

$$y[m] = \sum_{n=0}^{W-1} (w[n] * x[m+W-1-n]) \quad 0 \le m < W-X$$

NOTES ON USE

This function only convolves the data where the sequences completely overlap each other.

The Destination array length is equal to X-W+I.

The input sequence 1 must be larger than or equal to input sequence 2.

CROSS REFERENCE

SDA_ConvolveLinear, SDA_ConvolvePartial, SDA_ConvolveCircular, SDA_CorrelateLinear, SDA_CorrelateCircular, SDA_ConvolveLinearComplex, SDA_ConvolveCircularComplex

void SDA_ConvolveCircularComplex (const SLData_t *, Pointer to real input array

const SLData_t *, Pointer to imaginary input array const SLData_t *, Pointer to real impulse response

const SLData_t *, Pointer to imaginary impulse response

SLData t*, Pointer to real destination array

SLData t*, Pointer to imaginary destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function performs a circular convolution between two complex data sequences. One sequence containing the input data, and one containing the impulse response function, to which that data is being applied.

The equation for this function is:

$$y[m] = \sum_{n=0}^{N-1} (w[n].x[|m-n+N|_N]) \quad 0 \le m < N-1$$

NOTES ON USE

The input and output sequences must be the same length.

CROSS REFERENCE

SDA_ConvolveLinear, SDA_ConvolvePartial, SDA_ConvolveCircular, SDA_CorrelateLinear, SDA_CorrelateCircular, SDA_ConvolveLinearComplex, SDA_ConvolvePartialComplex

```
void SDA Deconvolution (SLData t*,
                                          Pointer to real source array
       SLData t*,
                                          Pointer to imag. source array
                                          Pointer to real impulse response array
       SLData t*,
                                          Pointer to imag. impulse response array
       SLData t*,
       const SLData t,
                                          Minimum value to avoid divide by zero
       const SLData t*,
                                          FFT length
       const SLArrayIndex t*,
                                          FFT bit reversed address look up table
       const SLArrayIndex t,
                                          FFT length
       const SLArrayIndex_t,
                                          Log2 FFT length
       const SLArrayIndex t)
                                          Inverse FFT length
```

DESCRIPTION

This function performs a frequency domain deconvolution between two arrays. One array containing the input data, and one containing the impulse response function that is being deconvolved from the original.

NOTES ON USE

The input and output arrays must be the same length – and zero padded to the length of the FFT.

The results are returned in the source arrays.

The impulse response data is destroyed in the process.

The minimum value must be set to avoid division by zero in the deconvolution process.

CROSS REFERENCE

SDA_ConvolveLinear, SDA_ConvolvePartial, SDA_CorrelateLinear, SDA CorrelateCircular, SIF FftDeconvolutionPre, SDA FftDeconvolutionPre

```
void SIF FftDeconvolutionPre (const SLData t*, Pointer to impulse response array
       SLData t*,
                                          Pointer to real FT(1/(impulse response))
array
       SLData t*,
                                          Pointer to imaginary FT(1/(impulse
response)) array
       const SLData t,
                                          Minimum value to avoid divide by zero
       const SLData t*,
                                          FFT coefficients
       const SLArrayIndex t*,
                                          FFT Bit reversed address look up table
       const SLArrayIndex_t,
                                          FFT length
                                          Log2 FFT length
       const SLArrayIndex t)
```

DESCRIPTION

This function initialized the SDA_FftDeconvolutionPre() function, which uses precalculated frequency domain coefficients for the system impulse response.

NOTES ON USE

CROSS REFERENCE

SDA_ConvolveLinear, SDA_ConvolvePartial, SDA_CorrelateLinear, SDA CorrelateCircular, SDA FftDeconvolution, SDA FftDeconvolutionPre

```
void SDA FftDeconvolutionPre (SLData t*,
                                                  Pointer to real source array
SLData t*,
                                           Pointer to imaginary source array
const SLData t*,
                                           Pointer to real FT(1/(impulse response))
array
                                           Pointer to imaginary FT(1/(impulse
const SLData t*,
response)) array
const SLData t*,
                                           FFT coefficients
const SLArrayIndex t*,
                                           FFT Bit reversed address look up table
const SLArrayIndex_t,
                                           FFT length
                                           log2 FFT length
const SLArrayIndex t,
                                           Inverse FFT Size
const SLData t)
```

DESCRIPTION

This function performs a frequency domain deconvolution between two arrays. One array containing the input data, and one containing the impulse response function that is being deconvolved from the original. This function uses pre-calculated frequency domain coefficients for the system impulse response.

NOTES ON USE

The input and output arrays must be the same length – and zero padded to the length of the FFT.

The results are returned in the source arrays.

The impulse response data is destroyed in the process.

The minimum value must be set to avoid division by zero in the deconvolution process.

CROSS REFERENCE

SDA_ConvolveLinear, SDA_ConvolvePartial, SDA_CorrelateLinear, SDA CorrelateCircular, SDA FftDeconvolution, SIF FftDeconvolution

void SDA_CorrelateLinear (const SLData_t *, Source array 1 pointer const SLData_t *, Source array 2 pointer SLData_t *, Destination array pointer const SLArrayIndex_t, Length of source array 1 const SLArrayIndex_t, Length of source array 2 const SLArrayIndex_t) Number of correlations

DESCRIPTION

This function performs a linear cross correlation between two data vectors, the addresses of which are passed to the function.

The equation for the SDA CorrelateLinear function is:

$$y[n] = \sum_{m=0}^{L-1-n} (w[m] * x[m+n]) \quad 0 \le m < L$$

Where:

w is source array 1x is source array 2L is the Number of correlations

NOTES ON USE

To perform auto-correlation, the address of the vector array to be correlated should be passed twice.

The number of correlations must be ≥ 1 .

Corr(w,x) := corr(x,w) in fact corr(w,x) is time reversed from corr(x,w).

CROSS REFERENCE

SDA_CorrelatePartial, SDA_CorrelateCircular, SDA_Covariance, SDA_CorrelateLinearReturnPeak

void SDA_CorrelatePartial (const SLData_t *, Source array 1 pointer const SLData_t *, Source array 2 pointer SLData_t *, Destination array pointer const SLArrayIndex_t, Length of source array 1 const SLArrayIndex_t)

Length of source array 2

DESCRIPTION

This function performs a non-overlapped linear cross correlation between two data vectors, the addresses of which are passed to the function.

NOTES ON USE

To perform auto-correlation, the address of the vector array to be correlated should be passed twice.

The number of correlations must be ≥ 1 .

CROSS REFERENCE

SDA_CorrelateLinear, SDA_CorrelateCircular, SDA_Covariance, SDA_CorrelateLinearReturnPeak

void SDA_CorrelateCircular (const SLData_t *, Input array 1 pointer const SLData_t *, Input array 2 pointer SLData_t *, Destination array pointer const SLArrayIndex t)

Length of input arrays

DESCRIPTION

This function performs a cyclic cross correlation between two data vectors, the addresses of which are passed to the function.

The equation for the SDA_CorrelateCircular function is:

$$y[m] = \sum_{n=0}^{N-1} (w[n].x[|n+m|_{N}]) \quad 0 \le m < N$$

NOTES ON USE

To perform auto-correlation, the address of the vector array to be correlated should be passed twice.

Both input arrays are the same length

CROSS REFERENCE

SDA_CorrelateLinear, SDA_CorrelatePartial, SDA_Covariance, SDA_CorrelateLinearReturnPeak

```
Source array 1 pointer
void SDA Covariance (SLData t*,
       const SLData t*,
                                           Source array 2 pointer
                                           Destination array pointer
       SLData t*,
       const SLData t,
                                           Inverse of length of array #1
       const SLData t,
                                           Inverse of length of array #2
       const SLArrayIndex t,
                                           Length of source array 1
                                           Length of source array 2
       const SLArrayIndex t,
                                           Number of correlations
       const SLArrayIndex t)
```

DESCRIPTION

This function returns the covariance of two vectors, where the covariance is defined as the correlation of the two vectors, with the means subtracted from the two signals.

NOTES ON USE

WARNING: THIS FUNCTION DESTROYS THE SOURCE ARRAYS.

This function calls the SDA_CorrelateLinear function.

This function destroys the data in the source arrays.

The "inverse of array length" parameters is used to avoid having to perform a divide operation within the function. This improves run-time performance.

CROSS REFERENCE

SDA_CorrelateLinear, SDA_CorrelatePartial, SDA_CorrelateCircular, SDA CovariancePartial, SDA CorrelateLinearReturnPeak.

```
void SDA_CovariancePartial (SLData_t *, Source array 1 pointer const SLData_t *, Source array 2 pointer SLData_t *, Destination array pointer const SLData_t, Inverse of length of array #1 const SLData_t, Length of source array 1 const SLArrayIndex_t, Length of source array 2
```

DESCRIPTION

This function returns the covariance of two vectors, where the covariance is defined as the correlation of the two vectors, with the means subtracted from the two signals.

NOTES ON USE

WARNING: THIS FUNCTION DESTROYS THE SOURCE ARRAYS.

This function calls the SDA CorrelatePartial function.

This function destroys the data in the source arrays.

The "inverse of array length" parameters is used to avoid having to perform a divide operation within the function. This improves run-time performance.

CROSS REFERENCE

SDA_CorrelateLinear, SDA_CorrelatePartial, SDA_CorrelateCircular, SDA Covariance, SDA CorrelateLinearReturnPeak.

void SDA_CorrelateLinearReturnPeak (const SLData_t *, Source array 1 pointer

const SLData_t *, Source array 2 pointer
SLData_t *, Peak value result pointer
SLArrayIndex_t *, Peak index result pointer
const SLArrayIndex_t, Length of source array 1
const SLArrayIndex_t, Length of source array 2
const SLArrayIndex_t) Number of correlations

DESCRIPTION

This function performs a linear cross correlation between two data vectors, the addresses of which are passed to the function. It then returns the magnitude of the cross correlation peak and the index of that peak in the cross correlation result.

The equation for the SDA CorrelateLinear function is:

$$y[n] = \sum_{m=0}^{L-1-n} (w[m] * x[m+n]) \quad 0 \le m < L$$

Where:

w is source array 1x is source array 2L is the Number of correlations

NOTES ON USE

To perform auto-correlation, the address of the vector array to be correlated should be passed twice.

The number of correlations must be ≥ 1 .

Corr(w,x) := corr(x,w) in fact corr(w,x) is time reversed from corr(x,w).

CROSS REFERENCE

SDA_CorrelateLinear, SDA_CorrelatePartial, SDA_CorrelateCircular, SDA_Covariance, SDA_CovariancePartial

DELAY FUNCTIONS (delay.c)

Overview of SigLib delay functions

SigLib includes two different sets of delay functions. The first set of functions (SDS_FixedDelay, SDA_FixedDelay, SDS_FixedDelayComplex, SDA_FixedDelayComplex) implement a fixed length delay while the second set of functions (SDS_VariableDelay, SDA_VariableDelay, SDS_VariableDelayComplex, SDA_VariableDelayComplex) implement a variable length delay where the delay can be increased and decreased as required, for example to track timing offsets in a modem.

One other function (SDA_ShortFixedDelay) is provided that provides a simple delay function where the delay length must be less than the length of the source array.

SIF FixedDelay

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_FixedDelay (SLData_t *, State array pointer
SLArrayIndex_t *, Pointer to delay index
const SLArrayIndex_t) Delay length

DESCRIPTION

This function initializes the delay functions SDS_FixedDelay, SDA_FixedDelay or SDA_ShortFixedDelay. Initialises the state array and the delay index to zero.

NOTES ON USE

If this function is used to initialise SDA_ShortFixedDelay then the delay index pointer can be set to SIGLIB NULL FIX DATA PTR and it will be ignored.

CROSS REFERENCE

SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SDA_ShortFixedDelay, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex.

SLData_t SDS_FixedDelay (const SLData_t, Input sample to delay SLData_t *, State array pointer SLArrayIndex_t *, Delay index const SLArrayIndex t) Delay length

DESCRIPTION

This function delays the data by N samples. This function works as a FIFO buffer.

NOTES ON USE

You must initialise the delay using the function SIF FixedDelay.

The state array must be at least as long as the delay length.

The xxx_FIFODelay functions provide generic FIFO functionality with the ability to increase and decrease the delay on-the-fly.

CROSS REFERENCE

SIF_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex.

```
void SDA_FixedDelay (const SLData_t *, Source array pointer SLData_t *, Destination array pointer SLData_t *, State array pointer SLArrayIndex_t *, Delay index const SLArrayIndex_t)

Delay length
```

DESCRIPTION

This function delays the data by N samples. This function works as a FIFO buffer.

NOTES ON USE

You must initialise the delay using the function SIF FixedDelay.

The state array must be at least as long as the delay length.

The xxx_FIFODelay functions provide generic FIFO functionality with the ability to increase and decrease the delay on-the-fly.

CROSS REFERENCE

```
SIF_FixedDelay, SDS_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex.
```

void SIF_FixedDelayComplex (SLData_t *, Real state array pointer

SLData_t *, Imaginary state array pointer

SLArrayIndex_t *, Pointer to delay index

const SLArrayIndex t) Delay length

DESCRIPTION

This function initializes the delay functions SDS_FixedDelayComplex and SDA FixedDelayComplex. Initialises the state array and the delay index to zero.

NOTES ON USE

CROSS REFERENCE

SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex.

void SDS FixedDelayComplex (const SLData t, Real input sample to delay const SLData t, Imaginary input sample to delay SLData t*, Real destination sample pointer Imaginary destination sample pointer SLData t*, SLData t*, Real state array pointer SLData t*, Imaginary state array pointer SLArrayIndex t*, Delay index Delay length const SLArrayIndex t)

DESCRIPTION

This function delays the complex data by N samples. This function works as a FIFO buffer.

NOTES ON USE

You must initialise the delay using the function SIF FixedDelayComplex.

The state arrays must be at least as long as the delay length.

The xxx_FIFODelay functions provide generic FIFO functionality with the ability to increase and decrease the delay on-the-fly.

CROSS REFERENCE

SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex.

void SDA_FixedDelayComplex (const SLData_t *, Real source array pointer const SLData_t *, Imaginary source array pointer SLData_t *, Real destination array pointer SLData_t *, Imaginary destination array pointer SLData_t *, Real state array pointer SLData_t *, Imaginary state array pointer SLData_t *, Imaginary state array pointer SLArrayIndex_t *, Delay index const SLArrayIndex_t)

Delay length

DESCRIPTION

This function delays the complex data by N samples. This function works as a FIFO buffer.

NOTES ON USE

You must initialise the delay using the function SIF FixedDelayComplex.

The state arrays must be at least as long as the delay length.

The xxx_FIFODelay functions provide generic FIFO functionality with the ability to increase and decrease the delay on-the-fly.

CROSS REFERENCE

SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex.

void SDA_ShortFixedDelay (const SLData_t *, Source array pointer SLData_t *, Destination array pointer SLData_t *, Temporary delayed array pointer SLData_t *, Temporary destination array pointer const SLArrayIndex_t, Sample delay count const SLArrayIndex_t) Delay length

DESCRIPTION

This function delays the data in the array by N samples, any remaining data will be carried over and will be used in succeeding functions.

NOTES ON USE

This function will work in-place.

The delay length must be less than the length of the source array.

The temporary array must be the same length as the length of the delay and should be initialised using the functions SDA Clear or SIF FixedDelay prior to use.

The xxx_FIFODelay functions provide generic FIFO functionality with the ability to increase and decrease the delay on-the-fly.

CROSS REFERENCE

SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay.

SLError_t SIF_VariableDelay (SLData_t *, Pointer to the delay state array SLArrayIndex_t *, Pointer to the FIFO input index SLArrayIndex_t *, Pointer to the FIFO output index SLArrayIndex_t *, Variable FIFO delay length const SLArrayIndex_t, Initial FIFO delay value const SLArrayIndex_t) Maximum delay length

DESCRIPTION

This function initialises the FIFO Delay functions.

NOTES ON USE

The index pointers are used to access the FIFO for the input and output streams. These values are initialised by the function.

The length of the delay state array must be at least the size of the maximum FIFO delay length.

The minimum delay length (in number of samples) is equal to zero.

The maximum delay length (in number of samples) is equal to MaxDelayLength - 1. This function returns SIGLIB_ERROR if the requested initial FIFO delay is less than zero or greater than the maximum allowable delay

The variable FIFO delay parameter is used to track the depth of the delay in the state array to ensure that it does not overflow. This is used by the functions SUF_IncreaseVariableDelay and SUF_DecreaseVariableDelay.

CROSS REFERENCE

```
SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SDS_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex, SUF_IncreaseVariableDelay, SUF_DecreaseVariableDelay.
```

SLData_t SDS_VariableDelay (const SLData_t, Input value

SLData_t *, Pointer to the delay state array SLArrayIndex_t *, Pointer to the FIFO input index SLArrayIndex_t *, Pointer to the FIFO output index

const SLArrayIndex t) Maximum delay length

DESCRIPTION

This function implements a FIFO Delay on a single input sample and generates a single output sample.

NOTES ON USE

The delay through this function can be modified on-the-fly using the functions SUF IncreaseVariableDelay and SUF DecreaseVariableDelay.

CROSS REFERENCE

SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex, SUF_IncreaseVariableDelay, SUF_DecreaseVariableDelay.

void SDA_VariableDelay (const SLData_t *, Pointer to the input array SLData_t *, Pointer to the output array SLData_t *, Pointer to the delay state array SLArrayIndex_t *, Pointer to the FIFO input index SLArrayIndex_t *, Pointer to the FIFO output index const SLArrayIndex_t, Maximum delay length const SLArrayIndex_t) Input / output array length

DESCRIPTION

This function implements a FIFO Delay on a stream of samples.

NOTES ON USE

The delay through this function can be modified on-the-fly using the functions SUF IncreaseVariableDelay and SUF DecreaseVariableDelay.

CROSS REFERENCE

SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex, SUF_IncreaseVariableDelay, SUF_DecreaseVariableDelay.

SLError_t SIF_VariableDelayComplex (SLData_t *, Pointer to real delay state array SLData_t *, Pointer to imaginary delay state array SLArrayIndex_t *, Pointer to the FIFO input index SLArrayIndex_t *, Pointer to the FIFO output index SLArrayIndex_t *, Variable FIFO delay length const SLArrayIndex_t, Initial FIFO delay value const SLArrayIndex_t) Maximum delay length

DESCRIPTION

This function initialises the complex FIFO Delay functions.

NOTES ON USE

The index pointers are used to access the FIFO for the input and output streams. These values are initialised by the function.

The length of the delay state arrays must be at least the size of the maximum FIFO delay length.

The minimum delay length (in number of samples) is equal to zero.

The maximum delay length (in number of samples) is equal to MaxDelayLength - 1. This function returns SIGLIB_ERROR if the requested initial FIFO delay is less than zero or greater than the maximum allowable delay

The variable FIFO delay parameter is used to track the depth of the delay in the state array to ensure that it does not overflow. This is used by the functions SUF_IncreaseVariableDelay and SUF_DecreaseVariableDelay.

CROSS REFERENCE

```
SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SDS_VariableDelayComplex, SDA_VariableDelayComplex, SUF_IncreaseVariableDelay, SUF_DecreaseVariableDelay.
```

void SDS_VariableDelayComplex (const SLData_t, Real input value

const SLData t, Imaginary input value Pointer to real output value SLData t*, Pointer to imaginary output value SLData t*, SLData t*, Pointer to real delay state array SLData t*, Pointer to imaginary delay state array Pointer to the FIFO input index SLArrayIndex t*, SLArrayIndex t*, Pointer to the FIFO output index const SLArrayIndex_t) Maximum delay length

DESCRIPTION

This function implements a FIFO Delay on a single complex input sample and generates a single complex output sample.

NOTES ON USE

The delay through this function can be modified on-the-fly using the functions SUF_IncreaseVariableDelay and SUF_DecreaseVariableDelay.

CROSS REFERENCE

```
SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDA_VariableDelayComplex, SUF_IncreaseVariableDelay, SUF_DecreaseVariableDelay.
```

void SDA VariableDelayComplex (const SLData t*, Pointer to the real input array const SLData t*, Pointer to the imaginary input array SLData t*, Pointer to the real output array Pointer to the imaginary output array SLData t*, Pointer to real delay state array SLData t*, SLData t*, Pointer to imaginary delay state array Pointer to the FIFO input index SLArrayIndex t*, SLArrayIndex t*, Pointer to the FIFO output index const SLArrayIndex_t, Maximum delay length

Input / output array length

DESCRIPTION

const SLArrayIndex t)

This function implements a FIFO Delay on a stream of samples.

NOTES ON USE

The delay through this function can be modified on-the-fly using the functions SUF_IncreaseVariableDelay and SUF_DecreaseVariableDelay.

CROSS REFERENCE

SIF_FixedDelay, SDS_FixedDelay, SDA_FixedDelay, SIF_FixedDelayComplex, SDS_FixedDelayComplex, SDA_FixedDelayComplex, SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_FifoComplexDelay, SDS_FifoComplexDelay, SUF_IncreaseVariableDelay, SUF_DecreaseVariableDelay.

SLArrayIndex_t SUF_IncreaseVariableDelay (SLArrayIndex_t *, Pointer to the FIFO output index

SLArrayIndex_t *, Pointer to delay length const SLArrayIndex t) Maximum delay length

DESCRIPTION

This function increments the FIFO delay length.

NOTES ON USE

This function returns an error if the incremented delay is greater than the maximum allowable delay and it does not adjust the delay.

CROSS REFERENCE

SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_VariableDelayComplex, SDS_VariableDelayComplex, SDA_VariableDelayComplex, SDA_VariableDelayComplex, SUF_DecreaseVariableDelay.

SLArrayIndex_t SUF_DecreaseVariableDelay (SLArrayIndex_t *, Pointer to the FIFO output index

SLArrayIndex_t *, Pointer to delay length const SLArrayIndex_t) Maximum delay length

DESCRIPTION

This function decrements the FIFO delay length.

NOTES ON USE

This function returns SIGLIB_ERROR if the decremented delay is less than zero and it does not adjust the delay.

CROSS REFERENCE

SIF_VariableDelay, SDS_VariableDelay, SDA_VariableDelay, SIF_FifoComplexDelay, SDS_FifoComplexDelay, SDA_FifoComplexDelay, SUF_IncreaseVariableDelay.

SDA_Align

PROTOTYPE AND PARAMETER DESCRIPTION

SLArrayIndex_t SDA_Align (const SLData_t *, Pointer to source array #1 const SLData_t *, Pointer to source array #2 SLData_t *, Pointer to destination array #1 SLData_t *, Pointer to destination array #2 const enum SLAlign_t, Alignment mode const SLArrayIndex_t, Source array #1 length const SLArrayIndex_t) Source array #2 length

DESCRIPTION

This function first locates the cross-correlation peak (using SDA_CorrelateLinearReturnPeak()) then aligns the two arrays.

The return value is the length of the destination arrays.

NOTES ON USE

The two available alignment types are:

SIGLIB_ALIGN_EXTEND	Zero pads each array so that no data is lost
SIGLIB_ALIGN_CROP	Crops the output so that only the overlaped data is returned

It is important to ensure that the destination arrays are long enough to hold the worst case output: Source array #1 length + Source array #1 length -1.

CROSS REFERENCE

SDA CorrelateLinearReturnPeak

IMAGE PROCESSING FUNCTIONS (image.c)

Due to the memory requirements of image processing applications, LARGE memory models may be required for some processors. When using the image processing functions on a 16 bit processor it is often necessary to use the "huge" keyword when declaring pointers. The definition of whether the "huge" keyword is required in the function declaration is located in the processor specific section of the *siglib.h* file. To select the "huge" declaration, set the defined constant _SL_HUGE_ARRAYS to "1". If the "huge" keyword is unnecessary then this should be set to "0".

The SigLib Windows DLL libraries are compiled for either 32 or 64 bits so _SL_HUGE_ARRAYS should be set to "0" at all times.

SIM_Fft2d

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SIM Fft2d (const SLImageData t*,
                                           Source image pointer
       const SLImageData t*,
                                           Destination image pointer
       const SLData t*,
                                           FFT coefficients pointer
       SLImageData t*,
                                           Pointer to FFT calculation array
       SLData t*,
                                           Pointer to real FFT calculation array
       SLData t*,
                                           Pointer to imag. FFT calculation array
       const SLData t,
                                           1.0 / Dimension - used for FFT scaling
       const SLArrayIndex t*,
                                           Bit reverse mode flag / Pointer to bit
reverse address table
       const SLArrayIndex t,
                                           Dimension of image
       const SLArrayIndex t)
                                           Log2 of dimension of image
```

DESCRIPTION

This function performs a two dimensional FFT on an image.

NOTES ON USE

The program is currently written for the integer based machines, because of memory limitations etc. all temporary pixel storage is in fixed point format and the data after each FFT is scaled to fit. The function can be easily ported to any environment and it becomes significantly simpler on systems with more memory and on systems with floating point capability. The latter will allow the removal of all of the scaling that has currently been included, to facilitate pixel storage in a single byte of memory. The final results are logarithmic, to maintain the best dynamic range.

There are many different techniques for performing a multi-dimensional FFT, the actual technique chosen often depends on the hardware architecture. On large workstations with a linear address space it is often more computationally efficient to perform the whole 2D FFT as a single process. When using general purpose floating point DSPs, with on-chip memory or when using some of the more modern RISC processors with on-chip cache, it is often more efficient to perform the row and column FFTs separately in this memory. There is an overhead associated with transferring the data in and out of on-chip memory, but this does not usually outweigh the benefit of performing the FFT in on-chip memory. It is for this reason that the SigLib SIM_Fft2d function performs the row and column FFTs separately.

Further parameter details: The pointer to FFT calculation array - this is a pointer to an array of type SLImageData_t that is the same size as the source image. Pointer to real and imaginary FFT calculation arrays - these are pointers to arrays of type SLData_t that are as long as one dimension of the image – either row or column.

Please also refer to the notes about the regular FFT functions.

CROSS REFERENCE

SIF_Fft2d

void SIF_Fft2d (SLData_t *, FFT coefficient pointer

SLArrayIndex t*, Bit reverse mode flag / Pointer to bit

reverse address table

const SLArrayIndex_t) Dimension of image

DESCRIPTION

This function initializes 2D FFT function, including twiddle factor array. Prior to using the 2D FFT function, the function SIF_Fft2d() must be called.

NOTES ON USE

Please also refer to the notes about the regular FFT functions.

CROSS REFERENCE

SIM Fft2d

void SIM_Conv3x3 (const SLImageData_t *, Source array pointer SLImageData_t *, Destination array pointer const SLData_t *, Coefficients array pointer const SLArrayIndex_t, Line length const SLArrayIndex t) Column length

DESCRIPTION

This function convolves an arbitrary n x m image with a 3x3 kernel.

NOTES ON USE

CROSS REFERENCE

SIM_SobelVertical3x3, SIM_SobelHorizontal3x3, SIM_Median3x3, SIM_Sobel3x3, SIF_ConvCoefficients3x3

SIM_Sobel3x3

PROTOTYPE AND PARAMETER DESCRIPTION

void SIM_Sobel3x3 (const SLImageData_t *,Source array pointerSLImageData_t *,Destination array pointerconst SLArrayIndex_t,Line lengthconst SLArrayIndex_t)Column length

DESCRIPTION

This function convolves an arbitrary n x m image with a 3x3 Sobel filter kernel.

NOTES ON USE

CROSS REFERENCE

SIM_SobelVertical3x3, SIM_SobelHorizontal3x3, SIM_Median3x3, SIM_Sobel3x3

void SIM_SobelVertical3x3 (const SLImageData_t *, Source array pointer

SLImageData_t *, Destination array pointer

const SLArrayIndex_t, Line length const SLArrayIndex_t) Column length

DESCRIPTION

The SIM_SobelVertical3x3 function performs a two dimensional Sobel vertical edge detection filter on the image. The coefficients for the filter are:

$$S = \begin{bmatrix} -1 & 0 & 1 \\ -2 & 0 & 2 \\ -1 & 0 & 1 \end{bmatrix}$$

NOTES ON USE

This filter gives better performance if the image has been cleaned up by low pass filtering and thresholding.

CROSS REFERENCE

SIM_Sobel3x3, SIM_SobelHorizontal3x3, SIM_Median3x3

void SIM_SobelHorizontal3x3 (const SLImageData_t *, Source array Pointer

SLImageData_t *, Destination array pointer

const SLArrayIndex_t, Line length const SLArrayIndex_t) Column length

DESCRIPTION

The SIM_SobelHorizontal3x3 function performs a two dimensional horizontal Sobel edge detection filter on the image. The coefficients for the filter are:

$$S = \begin{bmatrix} -1 & -2 & -1 \\ 0 & 0 & 0 \\ 1 & 2 & 1 \end{bmatrix}$$

NOTES ON USE

This filter gives better performance if the image has been cleaned up by low pass filtering and thresholding.

CROSS REFERENCE

SIM_Median3x3, SIM_Sobel3x3, SIM_SobelVertical3x3

SIM_Median3x3

PROTOTYPE AND PARAMETER DESCRIPTION

void SIM_Median3x3 (const SLImageData_t *, Source array pointer SLImageData_t *, Destination array pointer

const SLArrayIndex_t, Line length const SLArrayIndex_t) Column length

DESCRIPTION

The SIM_Median3x3 function performs a two dimensional median filter on the image.

NOTES ON USE

The 3x3 median filter is good at removing impulse noise unlike the 3x3 convolution it also good for preserving spatial resolution. It performs well on binary noise, but poorly on Gaussian. The median filter also doesn't perform well if there are more than 4 noise pixels per kernel.

CROSS REFERENCE

SIM Conv3x3, SIM SobelVertical3x3, SIM SobelHorizontal3x3

SLError_t SIF_ConvCoefficients3x3 SLData_t *, Pointer to coefficient array enum SL3x3Coeffs_t) Filter type

DESCRIPTION

This function initializes the coefficients for the following 3x3 convolution kernels:

Edge enhancement (SIGLIB EDGE ENHANCEMENT):

$$h = \begin{bmatrix} -1 & -1 & -1 \\ -1 & 8 & -1 \\ -1 & -1 & -1 \end{bmatrix}$$

Horizontal edge detection (SIGLIB_HORIZONTAL_EDGE):

$$h = \begin{bmatrix} -1 & -1 & -1 \\ 0 & 0 & 0 \\ 1 & 1 & 1 \end{bmatrix}$$

Vertical edge detection (SIGLIB VERTICAL EDGE):

$$h = \begin{bmatrix} -1 & 0 & 1 \\ -1 & 0 & 1 \\ -1 & 0 & 1 \end{bmatrix}$$

NOTES ON USE

CROSS REFERENCE

SIM_Conv3x3, SIM_Sobel3x3, SIM_SobelVertical3x3, SIM_SobelHorizontal3x3, SIM_Median3x3

SLImageData_t SIM_Max (const SLImageData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the maximum data value in the image array.

NOTES ON USE

CROSS REFERENCE

SIM_Max.

SLImageData_t SIM_Min (const SLImageData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the minimum data value in the image array.

NOTES ON USE

CROSS REFERENCE

SIM_Max.

IMAGE CODING FUNCTIONS (icoder.c)

SIF Dct8x8

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Dct8x8 (void)

Void

DESCRIPTION

This function initialises the coefficient table for the 8 x 8 DCT. The coefficients are scaled to give a symmetric DCT / inverse DCT pair. The frequency domain coefficients produced by this technique will have a larger dynamic rage than the input time domain data. Typically the dynamic range will be larger by a factor of about 4 to 6.

NOTES ON USE

CROSS REFERENCE

SIM Dct8x8, SIM Idct8x8, SIM ZigZagScan, SIM ZigZagDescan

void SIM_Dct8x8 (const SLData_t *, Source array pointer SLData_t *)

Source array pointer Destination array pointer

DESCRIPTION

This function performs an 8 x 8 DCT on the data.

NOTES ON USE

CROSS REFERENCE

SIF_Dct8x8, SIM_Idct8x8, SIM_ZigZagScan, SIM_ZigZagDescan

void SIM_Idct8x8 (const SLData_t *, Source array pointer SLData_t *)

Source array pointer Destination array pointer

DESCRIPTION

This function performs an inverse 8 x 8 DCT on the data.

NOTES ON USE

CROSS REFERENCE

SIF_Dct8x8, SIM_Dct8x8, SIM_ZigZagScan, SIM_ZigZagDescan

void SIM_ZigZagScan (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex t) Array lengths

DESCRIPTION

This function performs a zig-zag scan of the square 2D source array and place the results in a 1D array. In the zig-zag scan, the destination array is linearly addressed and the pointer to the source array must be non-linearly modified at the boundaries of the square matrix.

NOTES ON USE

The source array must be square and the two arrays must have the same number of elements.

CROSS REFERENCE

SIF Dct8x8, SIM Dct8x8, SIM Idct8x8, SIM ZigZagDescan

void SIM_ZigZagDescan (const SLData_t *,Source array pointer SLData_t *, Destination array pointer const SLArrayIndex t) Array lengths

DESCRIPTION

This function performs a linear scan of the 1D source array and place the results in a zig-zag scanned square 2D array. In the zig-zag de-scan, the source array is linearly addressed and the pointer to the destination array must be non-linearly modified at the boundaries of the square matrix.

NOTES ON USE

The destination array must be square and the two arrays must have the same number of elements.

CROSS REFERENCE

SIF Dct8x8, SIM Dct8x8, SIM Idct8x8, SIM ZigZagScan

```
SLError t SDA SignalGenerate (SLData t*,
                                                  Destination array pointer
       const enum SLSignal t,
                                           Signal type
       const SLData t,
                                           Peak value of signal
       const enum SLSignalFillMode t,
                                           Array fill mode, fill up or add to
       SLData t,
                                           Signal frequency
       const SLData t,
                                           Signal offset
       const SLData t,
                                           Control parameter
                                           End value
       const SLData t,
       SLData t*,
                                           Phase offset
       SLData t*,
                                           Current value
       const SLArrayIndex t)
                                           Array length
```

DESCRIPTION

This function fills the array with a signal, according to the equation specified, the following is a list of the possible types, for the signal specification parameter:

```
SIGLIB_SINE_WAVE,
SIGLIB_COSINE_WAVE,
SIGLIB_WHITE_NOISE - normal distribution,
SIGLIB_GAUSSIAN_NOISE - Gaussian distribution,
SIGLIB_CHIRP_NL - non-linear chirp,
SIGLIB_CHIRP_LIN - linear chirp,
SIGLIB_SQUARE_WAVE,
SIGLIB_TRIANGLE_WAVE
SIGLIB_IMPULSE,
SIGLIB_IMPULSE_STREAM,
SIGLIB_STEP,
SIGLIB_PN_SEQUENCE.
```

In addition to specifying the signal type, the mode with which the signal data is entered into the array can be specified. The two possibilities are: SIGLIB_FILL and SIGLIB_ADD. The former writes the data directly into the array, the latter adds the data to the existing contents of the array.

Some of the function parameters are obvious in their meaning and use, however the following will clarify some points. The signal type, <code>SLSignal_t</code>, should be one of the enumerated signal types, previously mentioned. The peak parameter specifies the largest positive value, that the signal will attain, all other values are scaled to this value accordingly. The array fill mode specifies whether to overwrite, or add to the existing array contents. The signal frequency parameter specifies the frequency, normalised to a sample rate of 1.0 (Hz). Signal offset adds a specified DC offset to the signal, before storing it.

The frequency parameter is normalised to a sample rate of 1 Hz, therefore to calculate the entry for a particular frequency, at a particular sample rate, use:

$$y[m] = \sum_{n=0}^{N-1} (w[n].x[|n+m|_N]) \quad 0 \le m < N$$

To fill any array with a single cycle wave, use:

frequency parameter
$$= \frac{1}{\text{array length}}$$

The control parameter has different applications for different signal types. For the SQUARE wave it defines the duty cycle. For the TRIANGLE wave it specifies whether the signal is: a positively increasing, negatively decreasing, or a symmetric waveform. For the chirp signals this parameter specifies the rate of change of the frequency (the chirp) of the SINE wave (see below). In a linear chirp the frequency is incremented by a fixed value each time whereas in a non-linear chirp the frequency is multiplied by a constant factor so in the latter case the frequency variation increases with each sample. The control parameter also specifies the delay for an IMPULSE signal, in bins, from the start of the array. The PN_SEQUENCE signal requires that this parameter specifies the number of discrete levels that are generated, between 0 and the value specified by the peak parameter.

The GAUSSIAN_NOISE option uses the Box-Muller method for generating Gaussian (normally) distributed random noise. The only parameter that mathematically effects the outcome is the 'control parameter', which supplies the variance of the noise and can be any positive real number, as required. You should initialise the GaussPhase variable to <code>SIGLIB_ZERO</code> prior to calling this function. When using the <code>SIGLIB_GAUSSIAN_NOISE</code> option to generate a signal with a given signal to noise ratio (SNR) then the following equation should be used:

$$SNR = \frac{average power of the signal}{variance of the Gaussian noise}$$

When generating random numbers, SigLib uses the defined constant "SL_RANDOMIZE" to define whether the sequence should use the system default seed for the pseudo random sequence. Setting SL_RANDOMIZE to "1" will use the system clock to initialise the seed. Setting SL_RANDOMIZE to "0" will use the system default seed.

The phase offset address parameter is used to store the current phase of the signal. This parameter ensures that the function does not introduce any discontinuities across array boundaries. The phase for the sine and cosine functions are in radians.

The current value parameter is used by the pseudo-random sequence generation function, to save the current value, so that sequences longer than a single array length may be generated. The reason for passing an address is that in any particular process many different signals may be required and each will require a separate current value register. For the chirp signal this specifies the current value being output and is used to maintain the signal phase across array boundaries.

The end value parameter is used by when generating a chirp signal to specify the end frequency for the chirp.

The TRIANGLE waveform generator can generate three forms of triangular wave, a positively increasing, negatively decreasing, or a symmetric wave. The symmetric generation function actually generates a positively offset waveform, then the offset is removed before the data is stored. The reason for this is that the offset parameter must keep track, not only of the current amplitude, but whether the signal is increasing or decreasing in amplitude. The current value is therefore stored with a sign corresponding to the sign of the differential of the signal.

The IMPULSE and IMPULSE_STREAM signals are respectively a single impulse, in the array and a stream of impulses, with a frequency as defined by the frequency parameter.

The STEP signal generates a "0" level for all vector indices less than the control parameter and a "peak" level for all indices greater than or equal to the control parameter. Note: for users of the SigLib DLLs via the BASIC language, this is declared as STEP SIGNAL to avoid confusion with the "step" keyword.

The SDA_SignalGenerate function allows for the generation of two types of CHIRP signal, a linear and a non-linear one, each has its own benefits and applications. The two functions are similar in function, they will both allow chirps to be generated, between a lower and an upper limit and when the limits are reached, the frequency will change to the other limit. The functions are used slightly differently, as described here.

Both the signal types require a chirp rate specification, for the non-linear chirp signal, this must be greater than 1.0 for an increasing frequency wave, or less than 1.0 for a decreasing frequency wave. For the linear chirp signal, the chirp rate specified must be greater than zero for an increasing frequency wave, or less than zero for a decreasing frequency wave, in this case:

chirp rate =
$$\frac{f_{\text{max}} - f_{\text{min}}}{\text{chirp period * sample rate}}$$

NOTES ON USE

When signals are being generated that do not use the phase or current value parameters, it is recommended that the parameter is defined as SIGLIB NULL FLOAT PTR in the function call.

If a PN sequence is required, centred about 0 then the peak value should be twice the required value and an offset of -peak must be used. For example for a PN signal with range +/- 0.9, the peak must be 1.8 and the offset -0.9.

EXAMPLE

If we wish to generate a chirp signal with the following characteristics defined using the #define statements:

SAMPLE_RATE CHIRP_START_FREQ CHIRP_END_FREQ SAMPLE LENGTH The Sample rate (Hz)
Start frequency of the chirp (Hz)
End frequency of the chirp (Hz)
Length of the chirp in samples

Then we would use the following code sample:

```
SDA_SignalGenerate (pSrc, SIGLIB_CHIRP_LIN, SIGLIB_ONE, SIGLIB_FILL, (CHIRP_START_FREQ / SAMPLE_RATE), SIGLIB_ZERO, ((CHIRP_END_FREQ - CHIRP_START_FREQ) / (SAMPLE_LENGTH * SAMPLE_RATE)), (CHIRP_END_FREQ / SAMPLE_RATE), &ChirpPhase, &ChirpValue, SAMPLE_LENGTH)
```

The following function call generates Gaussian noise with a variance of 4.0:

CROSS REFERENCE

SDS_SignalGenerate

Macros: SDA_SignalGenerateKronekerDeltaFunction, SDA_SignalGenerateWhiteNoise, SDS_SignalGenerateWhiteNoise, SDA_SignalGenerateGaussianNoise, SDS_SignalGenerateGaussianNoise.

```
Destination sample pointer
SLError t SDS SignalGenerate (SLData t*,
       const enum SLSignal t,
                                          Signal type
       const SLData t,
                                          Peak value of signal
       const enum SLSignalFillMode t,
                                          Array fill mode, fill up or add to
                                          Signal frequency
       SLData t,
       const SLData t,
                                          Signal offset
       const SLData t,
                                          Control parameter
       const SLData t,
                                          End value
       SLData_t *,
                                          Phase offset
       SLData t*)
                                          Current value
```

DESCRIPTION

This function generates a single sample of a signal, according to the equation specified, the following is a list of the possible types, for the signal specification parameter:

```
SIGLIB_SINE_WAVE,
SIGLIB_COSINE_WAVE,
SIGLIB_WHITE_NOISE - normal distribution,
SIGLIB_GAUSSIAN_NOISE - Gaussian distribution,
SIGLIB_CHIRP_NL - non-linear chirp,
SIGLIB_CHIRP_LIN - linear chirp,
SIGLIB_SQUARE_WAVE,
SIGLIB_TRIANGLE_WAVE
SIGLIB_IMPULSE,
SIGLIB_IMPULSE_STREAM,
SIGLIB_STEP,
SIGLIB_PN SEQUENCE.
```

For complete details of the parameters to this function, please see SDA SignalGenerate.

CROSS REFERENCE

SDA SignalGenerate

Macros: SDA SignalGenerateKronekerDeltaFunction,

SDA_SignalGenerateWhiteNoise, SDS_SignalGenerateWhiteNoise,

SDA SignalGenerateGaussianNoise, SDS SignalGenerateGaussianNoise.

SIF_Resonator

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SIF_Resonator (SLData_t *, Pointer to filter state array const SLData_t, Resonant frequency SLData_t *, Pointer to cosine coefficient SLData_t *)

Pointer to sine coefficient Pointer to sine coefficient
```

DESCRIPTION

This function initializes the resonator coefficients and clears the state array to zero.

NOTES ON USE

The resonant frequency is normalised to a sample rate of 1.0 Hertz.

CROSS REFERENCE

SDA_Resonator, SDA_Resonator1, SDA_Resonator1Add

SDA_Resonator

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Resonator (const SLData_t *, Input array
SLData_t *, Output array
SLData_t *, State array pointer
const SLData_t, Cosine coefficient
const SLData_t, Sine coefficient
const SLArrayIndex_t) Array length


DESCRIPTION

This function applies a resonator with the following z-transform to the input data stream:

$$H(z) = \frac{\sin \varpi_0 z^{-1}}{1 - 2\cos \varpi_0 z^{-1} + z^{-2}}$$

Resonators are often used with an impulse input to generate sinusoidal outputs.

The flow diagram for the resonator is as follows:



NOTES ON USE

This function works 'in-place' i.e. the input and output array pointers can point to the same array.

CROSS REFERENCE

SIF_Resonator, SDA_Resonator1, SDA_Resonator1Add

SIF_Resonator1

PROTOTYPE AND PARAMETER DESCRIPTION

```
void SIF_Resonator1 (SLData_t *, Pointer to filter state array const SLData_t, Resonant frequency SLData_t *, Pointer to cosine coefficient SLData_t *, Pointer to sine coefficient SLFixData_t *) Pointer to first iteration flag
```

DESCRIPTION

Initialise resonator coefficients, clears the state array to zero and initializes first iteration flag.

NOTES ON USE

The resonant frequency is normalised to a sample rate of 1.0 Hertz.

CROSS REFERENCE

SDA Resonator, SDA Resonator1, SDA Resonator1Add

void SDA_Resonator1 (SLData_t *,	Destination array pointer
const SLData_t,	Output signal magnitude
SLData_t *,	State array pointer
SLFixData_t *,	Pointer to first iteration flag
const SLData_t,	Cosine coefficient
const SLData_t,	Sine coefficient
<pre>const SLArrayIndex_t)</pre>	Array length


DESCRIPTION

This function generates a sinusoidal output at the specified frequency. This function is equivalent to applying an impulse to a resonator with the following z-transform:

$$H(z) = \frac{\sin \varpi_0 z^{-1}}{1 - 2\cos \varpi_0 z^{-1} + z^{-2}}$$

The flow diagram for the resonator is as follows:

Resonator Structure



NOTES ON USE

The first iteration flag must be initialised to SIGLIB TRUE

CROSS REFERENCE

SIF Resonator, SDA Resonator, SDA Resonator1Add

void SDA_Resonator1Add (SLData_t *, Const SLData_t, Output signal magnitude SLData_t *, State array pointer SLFixData_t *, Pointer to first iteration flag const SLData_t, Cosine coefficient const SLData_t, Sine coefficient const SLArrayIndex_t) Array length


DESCRIPTION

This function generates a sinusoidal output at the specified frequency and adds the result to the data already in the destination array. This function is equivalent to applying an impulse to a resonator with the following z-transform:

$$H(z) = \frac{\sin \varpi_0 z^{-1}}{1 - 2\cos \varpi_0 z^{-1} + z^{-2}}$$

The flow diagram for the resonator is as follows:

Resonator Structure



NOTES ON USE

The first iteration flag must be initialised to SIGLIB TRUE

CROSS REFERENCE

SIF Resonator, SDA Resonator1

void SDA_SignalGeneratePolarWhiteNoise (SLComplexRect_s *, Destn. array ptr.

const SLData t, Peak level

const enum SLSignalFillMode t, Array fill mode, fill up or add to

const SLArrayIndex t) Array length

DESCRIPTION

This function fills an array with a polar white noise signal. I.E. the noise pattern on a constellation diagram will be circular, as opposed to square if the pattern was generated using a rectangular distribution. The magnitude and the angle of the noise points are independently generated by normally distributed random number generators. The angle values are distributed between $-\pi$ and $+\pi$ while the magnitude values are distributed between 0 and the Peak value.

NOTES ON USE

The array fill mode specifies whether to overwrite, or add to the existing array contents.

CROSS REFERENCE

SDA_SignalGenerate, SDS_SignalGenerate, SDS_SignalGeneratePolarWhiteNoise, SDA_SignalGeneratePolarGaussianNoise, SDS_SignalGeneratePolarGaussianNoise

SLComplexRect_s SDS_SignalGeneratePolarWhiteNoise (const SLData_t Peak)
Peak level

DESCRIPTION

This function generates a single sample of a polar white noise signal. I.E. the noise pattern on a constellation diagram will be circular, as opposed to square if the pattern was generated using a rectangular distribution. The magnitude and the angle of the noise points are independently generated by normally distributed random number generators. The angle values are distributed between $-\pi$ and $+\pi$ while the magnitude values are distributed between 0 and the Peak value.

NOTES ON USE

CROSS REFERENCE

SDA_SignalGenerate, SDS_SignalGenerate, SDA_SignalGeneratePolarWhiteNoise, SDA_SignalGeneratePolarGaussianNoise, SDS_SignalGeneratePolarGaussianNoise

void SDA_SignalGeneratePolarGaussianNoise (SLComplexRect_s *,

Destination array pointer

const SLData_t, Noise variance SLData_t *, Phase offset SLData_t *, Current value

const enum SLSignalFillMode_t, Array fill mode, fill up or add to

const SLArrayIndex_t) Array length

DESCRIPTION

This function fills an array with a polar Gaussian noise signal. I.E. the noise pattern on a constellation diagram will be circular, as opposed to square if the pattern was generated using a rectangular distribution. The magnitude of the noise signal is generated by a Gaussian distributed random number generator and the angle of the noise points are generated by a normally distributed random number generator. The angle values are distributed between $-\pi/2$ and $+\pi/2$ while the magnitude values are centred on 0,0 and have a variance specified by the appropriate parameter.

NOTES ON USE

The noise phase offset parameter must be initialized to zero prior to calling this function.

The array fill mode specifies whether to overwrite, or add to the existing array contents.

CROSS REFERENCE

SDA_SignalGenerate, SDS_SignalGenerate, SDA_SignalGeneratePolarWhiteNoise, SDS_SignalGeneratePolarWhiteNoise, SDS_SignalGeneratePolarGaussianNoise

SLComplexRect_s SDS_SignalGeneratePolarGaussianNoise (const SLData_t,

Noise variance

SLData_t *, Phase offset SLData_t *) Current value

DESCRIPTION

This function generates a single sample of a polar Gaussian noise signal. I.E. the noise pattern on a constellation diagram will be circular, as opposed to square if the pattern was generated using a rectangular distribution. The magnitude of the noise signal is generated by a Gaussian distributed random number generator and the angle of the noise points are generated by a normally distributed random number generator. The angle values are distributed between $-\pi/2$ and $+\pi/2$ while the magnitude values are centred on 0,0 and have a variance specified by the appropriate parameter.

NOTES ON USE

The noise phase offset parameter must be initialized to zero prior to calling this function.

CROSS REFERENCE

SDA_SignalGenerate, SDS_SignalGenerate, SDA_SignalGeneratePolarWhiteNoise, SDA_SignalGeneratePolarWhiteNoise, SDA_SignalGeneratePolarGaussianNoise

void SDA_SignalAddPolarJitterAndGaussianNoise (const SLComplexRect_s *,

Source array pointer SLComplexRect s*, Destination array pointer const SLData t, Jitter sine wave frequency const SLData t, Jitter sine wave magnitude SLData t*, Jitter sine wave phase offset const SLData t, Noise variance SLData t*, Noise phase offset SLData t*, Noise current value const SLArrayIndex t) Array length

DESCRIPTION

This function adds jitter with a sinusoidal distribution and polar Gaussian noise to the source signal constellation diagram.

The noise pattern on a constellation diagram will be circular, as opposed to square if the pattern was generated using a rectangular distribution. The magnitude of the noise signal is generated by a Gaussian distributed random number generator and the angle of the noise points are generated by a normally distributed random number generator. The angle values are distributed between $-\pi/2$ and $+\pi/2$ while the magnitude values are centred on 0,0 and have a variance specified by the appropriate parameter.

NOTES ON USE

The noise phase offset parameter must be initialized to zero prior to calling this function.

CROSS REFERENCE

SDS SignalAddPolarJitterAndGaussianNoise

void SDS_SignalAddPolarJitterAndGaussianNoise (const SLComplexRect_s *,

Source array pointer

SLComplexRect_s *, Destination array pointer
const SLData_t, Jitter sine wave frequency
const SLData_t, Jitter sine wave magnitude
SLData_t *, Jitter sine wave phase offset
const SLData_t, Noise variance
SLData_t *, Noise phase offset
SLData_t *, Noise current value

const SLArrayIndex_t) Array length

DESCRIPTION

This function adds jitter with a sinusoidal distribution and polar Gaussian noise to the source signal constellation diagram, on a per-sample basis.

The noise pattern on a constellation diagram will be circular, as opposed to square if the pattern was generated using a rectangular distribution. The magnitude of the noise signal is generated by a Gaussian distributed random number generator and the angle of the noise points are generated by a normally distributed random number generator. The angle values are distributed between $-\pi/2$ and $+\pi/2$ while the magnitude values are centred on 0,0 and have a variance specified by the appropriate parameter.

NOTES ON USE

The noise phase offset parameter must be initialized to zero prior to calling this function.

CROSS REFERENCE

SDA SignalAddPolarJitterAndGaussianNoise

SDA_Ramp

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Ramp (SLData_t *,
const SLData_t,
const SLData_t,
const SLData_t,
const SLArrayIndex_t)Destination array pointer
Start value
Increment value
Array length

DESCRIPTION

This function generates a ramp with incrementing N values starting with the start value and incrementing by the increment value.

If the increment value is negative the data will ramp down.

NOTES ON USE

CROSS REFERENCE

SDS_SignalGenerate, SDA_SignalGenerate.

void SIF_RandomNumber (void)

DESCRIPTION

This function initializes the random number generator seed.

NOTES ON USE

CROSS REFERENCE

SDS_RandomNumber, SDA_RandomNumber, SDS_SignalGenerate, SDA_SignalGenerate.

SLData_t SDS_RandomNumber (const SLData_t, Lower bound const SLData_t) Upper bound

DESCRIPTION

This function generates and returns a random number, between the lower and upper bounds, using the rand() function.

Use the function SIF RandomNumber() to initialize the random number seed.

NOTES ON USE

CROSS REFERENCE

SIF_RandomNumber, SDA_RandomNumber, SDS_SignalGenerate, SDA_SignalGenerate.

void SDA_RandomNumber (SLData_t *,
const SLData_t,
const SLData_t,
const SLArrayIndex_t)Destination array pointer
Lower bound
Upper bound
Array length

DESCRIPTION

This function fills an array with random numbers, between the lower and upper bounds, using the rand() function.

Use the function SIF_RandomNumber() to initialize the random number seed.

NOTES ON USE

CROSS REFERENCE

 $SIF_RandomNumber, SDS_RandomNumber, SDA_RandomNumber, SDS_SignalGenerate.$

COMMUNICATION FUNCTIONS

General Communications Functions (comms.c)

SDA BitErrorRate

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_BitErrorRate (const SLChar_t *, Source 1 pointer const SLChar_t *, Source 2 pointer const SLData_t, Inverse of the number of bits const SLArrayIndex_t) Sample array length

DESCRIPTION

This function returns the bit error rate between the two data streams.

NOTES ON USE

The "inverse of the number of bits" parameter is used to avoid having to perform a divide operation within the function. This improves run-time performance.

CROSS REFERENCE

SDA_Interleave

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Interleave (const SLData_t *, Source pointer SLData_t *, Destination pointer const SLArrayIndex_t, Stride const SLArrayIndex t) Array Length

DESCRIPTION

This function interleaves the samples in the data stream.

NOTES ON USE

During the interleave, the data is effectively written into an array along the horizontal lines and read out along the vertical columns. In de interleaving, the reverse is true. Care should be taken when interleaving multiplexed data streams because the individual channels can be re-ordered in such a way that the samples are again in sequential locations.

This technique can be useful in telecommunications, to avoid burst errors.

It is important that the array length is an integer multiple of the stride.

For a ramp (0 to 11.0) input and a stride of 3, the rearranged order of the data is:

Input Data 0.0, 1.0, 2.0, 3.0, 4.0, 5.0, 6.0, 7.0, 8.0, 9.0, 10.0, 11.0 Output Data 0.0, 3.0, 6.0, 9.0, 1.0, 4.0, 7.0, 10.0, 2.0, 5.0, 8.0, 11.0

CROSS REFERENCE SDA Deinterleave

void SDA_Deinterleave (const SLData_t *, Source pointer

SLData_t *, Destination pointer

const SLArrayIndex t, Stride

const SLArrayIndex_t) Array Length

DESCRIPTION

This function de-interleaves the samples in the data stream.

NOTES ON USE

During the interleave, the data is effectively written into an array along the horizontal lines and read out along the vertical columns. In de interleaving, the reverse is true. Care should be taken when interleaving multiplexed data streams because the individual channels can be re-ordered in such a way that the samples are again in sequential locations.

This technique can be useful in telecommunications, to avoid burst errors.

It is important that the array length is an integer multiple of the stride.

For an interleaved ramp (0 to 11.0) input and a stride of 3, the rearranged order of the data is:

Interleaved Input Data 0.0, 3.0, 6.0, 9.0, 1.0, 4.0, 7.0, 10.0, 2.0, 5.0, 8.0, 11.0 Output Data 0.0, 1.0, 2.0, 3.0, 4.0, 5.0, 6.0, 7.0, 8.0, 9.0, 10.0, 11.0

CROSS REFERENCE SDA Interleave

SLData_t SCV_EuclideanDistance (const SLComplexRect_s, const SLComplexRect_s) Source vector 2

DESCRIPTION

This function returns the Euclidean distance between two complex samples.

NOTES ON USE

CROSS REFERENCE

SCV_EuclideanDistanceSquared, SCA_EuclideanDistance, SCA_EuclideanDistanceSquared, SDS_EuclideanDistance, SDS_EuclideanDistanceSquared, SDA_EuclideanDistance, SDA_EuclideanDistanceSquared

SLData_t SCV_EuclideanDistanceSquared (const SLComplexRect_s, vector 1

const SLComplexRect s) Source vector 2

DESCRIPTION

This function returns the square of the Euclidean distance between two complex samples.

NOTES ON USE

If you are comparing Euclidean distances then the square root of the regular function is an unnecessary overhead and the squared version of the function is equally useful but more efficient.

CROSS REFERENCE

SCV_EuclideanDistance, SCA_EuclideanDistance, SCA_EuclideanDistanceSquared, SDS_EuclideanDistance, SDS_EuclideanDistanceSquared, SDA_EuclideanDistance, SDA_EuclideanDistanceSquared

void SCA_EuclideanDistance (const SLComplexRect_s *, Pointer to source vector #1

const SLComplexRect_s *, Pointer to source vector #2
SLData_t *, Pointer to destination
const SLArrayIndex_t) Number of samples

DESCRIPTION

This function returns the Euclidean distance between successive complex samples in the source arrays.

NOTES ON USE

CROSS REFERENCE

SCV_EuclideanDistance, SCV_EuclideanDistanceSquared,

SCA EuclideanDistanceSquared, SDS EuclideanDistance,

SDS EuclideanDistanceSquared, SDA EuclideanDistance,

SDA_EuclideanDistanceSquared

void SCA_EuclideanDistanceSquared (const SLComplexRect_s *, Pointer to source vector #1

const SLComplexRect_s *, Pointer to source vector #2
SLData_t *, Pointer to destination
const SLArrayIndex t) Number of samples

DESCRIPTION

This function returns the Euclidean distance squared between successive complex samples in the source arrays.

NOTES ON USE

If you are comparing Euclidean distances then the square root of the regular function is an unnecessary overhead and the squared version of the function is equally useful but more efficient.

CROSS REFERENCE

SCV_EuclideanDistance, SCV_EuclideanDistanceSquared, SCA_EuclideanDistance, SDS_EuclideanDistance, SDS_EuclideanDistanceSquared, SDA_EuclideanDistance, SDA_EuclideanDistanceSquared

SLData_t SDS_EuclideanDistance (const SLData_t, Source #1 x-axis value

const SLData_t, Source #1 y-axis value const SLData_t, Source #2 x-axis value const SLData_t) Source #2 y-axis value

DESCRIPTION

This function returns the Euclidean distance between two points given the provided x, y coordinates on a 2D plane.

NOTES ON USE

CROSS REFERENCE

SCV_EuclideanDistance, SCV_EuclideanDistanceSquared,

SCA EuclideanDistance, SCA EuclideanDistanceSquared,

SDS EuclideanDistanceSquared, SDA EuclideanDistance,

SDA_EuclideanDistanceSquared

SLData_t SDS_EuclideanDistanceSquared (const SLData_t, Source #1 x-axis value

const SLData_t, Source #1 y-axis value const SLData_t, Source #2 x-axis value const SLData_t) Source #2 y-axis value

DESCRIPTION

This function returns the Euclidean distance squared between two points given the provided x, y coordinates on a 2D plane.

NOTES ON USE

If you are comparing Euclidean distances then the square root of the regular function is an unnecessary overhead and the squared version of the function is equally useful but more efficient.

CROSS REFERENCE

SCV_EuclideanDistance, SCV_EuclideanDistanceSquared, SCA_EuclideanDistance, SCA_EuclideanDistanceSquared, SDS_EuclideanDistance, SDA_EuclideanDistanceSquared

SLData_t SDS_EuclideanDistance (const SLData_t *, Pointer to source #1 x-axis values

```
const SLData_t *, Pointer to source #1 y-axis values const SLData_t *, Pointer to source #2 x-axis values const SLData_t *, Pointer to source #2 y-axis values SLData_t *, Pointer to destination const SLArrayIndex_t) Number of samples
```

DESCRIPTION

This function returns the Euclidean distance between two points given the provided x, y coordinates on a 2D plane, for all samples in arrays of data.

NOTES ON USE

CROSS REFERENCE

SCV_EuclideanDistance, SCV_EuclideanDistanceSquared, SCA_EuclideanDistanceSquared, SDS_EuclideanDistanceSquared, SDS_EuclideanDistanceSquared

SLData_t SDS_EuclideanDistanceSquared (const SLData_t *, Pointer to source #1 x-axis values

```
const SLData_t *, Pointer to source #1 y-axis values const SLData_t *, Pointer to source #2 x-axis values const SLData_t *, Pointer to source #2 y-axis values SLData_t *, Pointer to destination const SLArrayIndex_t) Number of samples
```

DESCRIPTION

This function returns the Euclidean distance squared between two points given the provided x, y coordinates on a 2D plane, for all samples in arrays of data.

NOTES ON USE

If you are comparing Euclidean distances then the square root of the regular function is an unnecessary overhead and the squared version of the function is equally useful but more efficient.

CROSS REFERENCE

SCV_EuclideanDistance, SCV_EuclideanDistanceSquared, SCA_EuclideanDistanceSquared, SDS_EuclideanDistance, SDS_EuclideanDistanceSquared, SDS_EuclideanDistance

SLChar_t SDS_ManchesterEncode (const SLChar_t Input) Input bit

DESCRIPTION

This function takes an input bit and applies Manchester encoding to generate an output dibit.

NOTES ON USE

CROSS REFERENCE

SDS_ManchesterDecode, SDS_ManchesterEncodeByte, SDS_ManchesterDecodeByte

SLChar_t SDS_ManchesterDecode (const SLChar_t Input) Input dibit

DESCRIPTION

This function takes an input dibit and applies Manchester decoding to generate an output bit.

NOTES ON USE

This function returns 0x3 if the input dibit pair is invalid.

CROSS REFERENCE

 $SDS_ManchesterEncode, SDS_ManchesterEncodeByte, \\SDS_ManchesterDecodeByte$

SLFixData_t SDS_ManchesterEncodeByte (const SLChar_t Input) Input byte

DESCRIPTION

This function takes an input byte and applies Manchester encoding to each bit to generate an outputs 8 dibits.

NOTES ON USE

CROSS REFERENCE

SDS_ManchesterEncode, SDS_ManchesterDecode, SDS ManchesterDecodeByte

SLFixData_t SDS_ManchesterDecodeByte (const SLFixData_t Input) Input dibits

DESCRIPTION

This function takes an input sequence of 8 dibits and applies Manchester decoding to generate an output byte, which is stored in a data word of type SLFixData t.

NOTES ON USE

This function returns SIGLIB ERROR if the input dibit pair is invalid.

CROSS REFERENCE

SDS_ManchesterEncode, SDS_ManchesterDecode, SDS ManchesterEncodeByte

void SIF_DetectNumericalWordSequence (SLFixData_t *, Ptr. to bit mask register

SLFixData_t *, Detector state array

SLArrayIndex_t, Word length

SLArrayIndex_t) Synchronization sequence length

DESCRIPTION

This function initializes the numerical word sequence detection function.

NOTES ON USE

The state array must be as long as the sequence that is being detected.

CROSS REFERENCE

SDS_DetectNumericalWordSequence, SIF_DetectNumericalBitSequence, SDS_DetectNumericalBitSequence, SIF_DetectCharacterSequence,

SLFixData_t SDS_DetectNumericalWordSequence (SLFixData_t, Input word

SLFixData t*, Synchronization sequence

SLFixData_t, Input bit mask SLFixData_t *, Detector state array

SLArrayIndex t) Synchronization sequence length

DESCRIPTION

This function detects the presence of a numerical words sequence in a stream of words that are passed to the function. It will return <code>SIGLIB_TRUE</code> if the sequence is detected and <code>SIGLIB_FALSE</code> if it is not detected.

This function will detect only the exact word pattern.

NOTES ON USE

The function SIF_DetectNumericalWordSequence must be called prior to calling this function.

CROSS REFERENCE

SIF_DetectNumericalWordSequence, SIF_DetectNumericalBitSequence, SDS_DetectNumericalBitSequence, SIF_DetectCharacterSequence, SDS_DetectCharacterSequence.

void SIF_DetectNumericalBitSequence (SLFixData_t *, Ptr. to bit mask register SLFixData_t *, Detector state variable SLArrayIndex t) Synchronization sequence length

DESCRIPTION

This function initializes the numerical bit sequence detection function.

NOTES ON USE

The state variable must be at least as long as the sequence that is being detected. The standard fixed point word length for SigLib is either 16 or 32 bits – please refer to the SigLib User's Guide for further information. If an application requires the detection of bit sequences that are longer than the SigLib fixed point word length then the synchronization sequence must be split into multiple sequences with a maximum length equal to the chosen SigLib fixed point word length. The results of multiple calls to SDS DetectNumericalBitSequence can be combined using the AND (&) function.

CROSS REFERENCE

SIF_DetectNumericalWordSequence, SDS_DetectNumericalWordSequence, SDS_DetectNumericalBitSequence, SIF_DetectCharacterSequence, SDS_DetectCharacterSequence.

SLArrayIndex t SDS DetectNumericalBitSequence (SLFixData t, Input word

SLFixData t, Synchronization sequence

SLFixData t, Synchronization sequence bit mask

SLFixData_t *, Detector state variable SLArrayIndex t) Input word length

DESCRIPTION

This function detects the presence of a numerical bit sequence in a stream of bits that can be spread across multiple input words. If the required sequence is detected it will return the bit index of the last bit in the sequence otherwise it will return SIGLIB_SEQUENCE_NOT_DETECTED. Please note, all bits are processed MSB first so bit offset 0 is the MSB in the received word (As per ITU-T Recommendation V.8).

This function will detect a given bit pattern and it does not need to be aligned on a specific word boundary.

NOTES ON USE

The function SIF_DetectNumericalBitSequence must be called prior to calling this function please also read the notes for this function.

CROSS REFERENCE

 $SIF_DetectNumericalWordSequence, SDS_DetectNumericalWordSequence, SIF_DetectNumericalBitSequence, SIF_DetectCharacterSequence, SDS_DetectCharacterSequence.$

void SIF_DetectCharacterSequence (SLChar_t *, Detector state array SLArrayIndex_t) Synchronization sequence length

DESCRIPTION

This function initializes the character sequence detection function.

NOTES ON USE

The state array must be as long as the sequence that is being detected.

CROSS REFERENCE

SIF_DetectNumericalWordSequence, SDS_DetectNumericalWordSequence, SIF_DetectNumericalBitSequence, SDS_DetectNumericalBitSequence, SDS_DetectCharacterSequence.

SLFixData t SDS DetectCharacterSequence (SLChar t, Input character

SLChar_t *, Synchronization sequence

SLChar t*, Detector state array

SLArrayIndex t) Synchronization sequence length

DESCRIPTION

This function detects the presence of an arbitrary character sequence it will return SIGLIB TRUE if the sequence is detected and SIGLIB FALSE if it is not detected.

NOTES ON USE

The function SIF_DetectCharacterSequence must be called prior to calling this function.

This function is case sensitive.

You can use the character formatted or numerical sequence detection functions depending on which part of the modem it is required to detect the start of the frame.

For binary sequence detection the input characters should be the values '0' or '1' depending on the binary value the represent. For hexadecimal sequence detection the input characters should be the values '0' to '9' or 'A' to 'F' depending on the binary value the represent.

CROSS REFERENCE

 $SIF_DetectNumericalWordSequence, SDS_DetectNumericalWordSequence, SIF_DetectNumericalBitSequence, SDS_DetectNumericalBitSequence, SIF_DetectCharacterSequence.$

SLData_t SDS_ErrorVector (const SLComplexRect_s, Ideal point const SLComplexRect_s) Received point

DESCRIPTION

This function calculates the absolute vector difference between two vectors.

NOTES ON USE

CROSS REFERENCE

SDS_ErrorVectorMagnitudePercent, SDS_ErrorVectorMagnitudeDecibels.

SLData_t SDS_ErrorVectorMagnitudePercent (const SLComplexRect_s, Ideal point const SLComplexRect_s) Received point

DESCRIPTION

This function calculates the percentage vector difference between two vectors.

NOTES ON USE

CROSS REFERENCE

SDS_ErrorVector, SDS_ErrorVectorMagnitudeDecibels.

SLData_t SDS_ErrorVectorMagnitudeDecibels (const SLComplexRect_s, Ideal point const SLComplexRect_s) Received point

DESCRIPTION

This function calculates the absolute vector difference between two vectors and returns the result in dB.

NOTES ON USE

CROSS REFERENCE

SDS ErrorVector, SDS ErrorVectorMagnitudePercent.

SLFixData_t SDS_ReverseDiBits (const SLFixData_t) Input di-bits

DESCRIPTION

This function reverses the order of the di-bit pair in the input value..

NOTES ON USE

CROSS REFERENCE

void SDS_QpskBitErrorCount (const SLFixData_t, Input di-bits const SLFixData_t, Output data bits SLFixData_t *, Pointer to bit count SLFixData_t *) Pointer to bit error count

DESCRIPTION

This function calculates the running sum of the number of bits and the number of bit errors in the input QPSK di-bit sequence. The final bit error rate can be calculated using SDS BitErrorRate.

NOTES ON USE

CROSS REFERENCE SDS_BitErrorRate.

SLData_t SDS_BitErrorRate (const SLFixData_t, Bit count const SLFixData_t) Bit error count

DESCRIPTION

This function returns the bit error rate given the total number of bits and the number of bit errors.

NOTES ON USE


CROSS REFERENCE

 $SDS_QpskBitErrorCount, SDA_BitErrorRate.$

void SIF PhaseLockedLoop (SLData t*, VCO phase SLData t*, VCO Fast sine look up table const SLArrayIndex t, VCO Fast sine look up table size const SLData t, LPF cut-off frequency Pointer to loop filter state SLData t*, const SLData t*, Pointer to loop filter coefficients SLArrayIndex t*, Pointer to loop filter index const SLArrayIndex t, Loop filter length SLData_t *, Pointer to Hilbert xform filter state const SLData t*, Pointer to Hilbert xform filter coeffs SLArrayIndex t*, Pointer to Hilbert xform filter index const SLArrayIndex t, Hilbert xform filter length SLData t*) Pointer to delayed sample

DESCRIPTION

This function initialises the phase locked loop (PLL) functions. The block diagram for the PLL is shown in the following diagram:



NOTES ON USE

The filters are all FIR and must be of odd order.

CROSS REFERENCE

SDS PhaseLockedLoop, SDA PhaseLockedLoop.

SLData_t SDS_PhaseLockedLoop (const SLData_t, Source data

SLData_t *, VCO phase
const SLData_t, VCO modulation index
SLData_t *, VCO Fast sine look up table
const SLArrayIndex t, VCO Fast sine look up table size

const SLData_t, Carrier frequency

SLData t*, Pointer to loop filter state

const SLData_t *, Pointer to loop filter coefficients SLArrayIndex t *, Pointer to loop filter index

const SLArrayIndex_t, Loop filter length

SLData_t *, Pointer to Hilbert xform filter state const SLData_t *, Pointer to Hilbert xform filter coeffs SLArrayIndex_t *, Pointer to Hilbert xform filter index

const SLArrayIndex_t, Hilbert xform filter length SLData t*) Pointer to delayed sample

DESCRIPTION

This function applies a continuous wave input to the phase locked loop and outputs the phase locked signal. This function uses the frequency modulator function to perform the Voltage Controlled Oscillator functionality.

NOTES ON USE

The filters are all FIR and must be of odd order. The output is in-phase with the original input signal.

If this function proves to be unstable then the most likely cause is that the modulation index for the VCO is too large.

CROSS REFERENCE

SIF PhaseLockedLoop, SDA PhaseLockedLoop.

void SDA_PhaseLockedLoop (const SLData_t *, Source pointer

SLData_t *, Destination pointer

SLData t*, VCO phase

const SLData_t, VCO modulation index
SLData_t *, VCO Fast sine look up table
const SLArrayIndex t, VCO Fast sine look up table size

const SLData t, Carrier frequency

SLData t*, Pointer to loop filter state

const SLData_t *, Pointer to loop filter coefficients SLArrayIndex_t *, Pointer to loop filter index

const SLArrayIndex t, Loop filter length

SLData_t *, Pointer to Hilbert xform filter state const SLData_t *, Pointer to Hilbert xform filter coeffs SLArrayIndex_t *, Pointer to Hilbert xform filter index

const SLArrayIndex_t, Hilbert xform filter length SLData_t *, Pointer to delayed sample

const SLArrayIndex t) Sample size

DESCRIPTION

This function applies a continuous wave input to the phase locked loop and outputs the phase locked signal. This function uses the frequency modulator function to perform the Voltage Controlled Oscillator functionality.

NOTES ON USE

The filters are all FIR and must be of odd order. The output is in-phase with the original input signal.

If this function proves to be unstable then the most likely cause is that the modulation index for the VCO is too large.

CROSS REFERENCE

SIF PhaseLockedLoop, SDS PhaseLockedLoop.

```
SLError t SIF CostasLoop (SLData t*,
                                            VCO phase
       SLData t,
                                            VCO fast sine look up table
       const SLArrayIndex t,
                                            VCO fast sine look up table size
       const SLData t,
                                            LPF cut-off frequency
       SLData t*,
                                            Pointer to loop filter 1 state
       SLArrayIndex t*,
                                            Pointer to loop filter 1 index
                                            Pointer to loop filter 2 state
       SLData t*,
       SLArrayIndex t*,
                                            Pointer to loop filter 2 index
       SLData t*,
                                            Pointer to loop filter coefficients
                                            Loop filter length
       const SLArrayIndex t,
                                            Pointer to loop filter state
       SLData t*,
                                            Pointer to delayed sample
       SLData t*)
```

DESCRIPTION

This function initialises the Costas loop phase detector functions.

In the two functions SDA_CostasLoop and SDS_CostasLoop the SLCostasLoopFeedbackMode_t parameter selects between the following phase detector options:

```
SIGLIB_COSTAS_LOOP_MULTIPLY_LOOP,
SIGLIB_COSTAS_LOOP_POLARITY_LOOP,
SIGLIB_COSTAS_LOOP_HARD_LIMITED_LOOP
```

NOTES ON USE


The loop filters 1 and 2 are both FIR and must be of odd order to ensure that the group delays are integer in length. The loop filter is a one-pole filter, with a single coefficient and state. The output is in phase with the original signal.

This function uses the frequency modulator function to perform the Voltage Controlled Oscillator functionality. The VCO gain depends on the magnitudes of the input signal and also the filter gain. If the Costas loop becomes unstable then the usual cause is the VCO gain is too high.


In order to allocate the Costas loop look up table it is necessary to use the SUF_CostasLoopArrayAllocate() to malloc the look-up-table memory, rather than SUF VectorArrayAllocate().

The flow diagrams for the different phase detector modes are shown in the following diagrams:


SIGLIB COSTAS LOOP MULTIPLY LOOP



SIGLIB_COSTAS_LOOP_POLARITY_LOOP



SIGLIB_COSTAS_LOOP_HARD_LIMITED_LOOP



CROSS REFERENCE

SDS_CostasLoop, SDA_CostasLoop, SRF_CostasLoop.

SLData_t SDS_CostasLoop (const SLData_t, Source data

SLData_t *, VCO phase

const SLData_t, VCO modulation index SLData_t *, VCO fast sine look up table const SLArrayIndex t, VCO fast sine look up table size

const SLData_t, Carrier frequency

SLData_t *, Pointer to loop filter 1 state
SLArrayIndex_t *, Pointer to loop filter 1 index
SLData_t *, Pointer to loop filter 2 state
SLArrayIndex_t *, Pointer to loop filter 2 index
const SLData_t *, Pointer to loop filter coefficients

const SLArrayIndex t, Loop filter length

SLData_t *, Pointer to loop filter state const SLData_t, Loop filter coefficient const enum SLCostasLoopFeedbackMode_t,Loop feedback mode SLData_t *) Pointer to delayed sample

DESCRIPTION

This function applies a continuous wave input to the Costas loop and outputs the inphase phase locked signal.

NOTES ON USE

See SIF CostasLoop

CROSS REFERENCE

SIF CostasLoop, SDA CostasLoop, SRF CostasLoop.

void SDA_CostasLoop (const SLData_t *, Source data pointer

SLData t*, VCO phase

const SLData_t, VCO modulation index
SLData_t *, VCO fast sine look up table
const SLArrayIndex t, VCO fast sine look up table size

const SLData_t, Carrier frequency

SLData_t *, Pointer to loop filter 1 state
SLArrayIndex_t *, Pointer to loop filter 1 index
SLData_t *, Pointer to loop filter 2 state
SLArrayIndex_t *, Pointer to loop filter 2 index
const SLData_t *, Pointer to loop filter coefficients

const SLArrayIndex t, Loop filter length

SLData_t *, Pointer to loop filter state const SLData_t, Loop filter coefficient const enum SLCostasLoopFeedbackMode t,Loop feedback mode

SLData t*, Pointer to delayed sample

const SLArrayIndex_t) Sample size

DESCRIPTION

This function applies a continuous wave input to the Costas loop and outputs the inphase phase locked signal.

NOTES ON USE

See SIF CostasLoop

CROSS REFERENCE

SIF CostasLoop, SDS CostasLoop, SRF CostasLoop.

SLError_t SRF_CostasLoop (SLData_t *, VCO phase SLData t*, Pointer to loop filter 1 state Pointer to loop filter 1 index SLArrayIndex t*, SLData t*, Pointer to loop filter 2 state SLArrayIndex t*, Pointer to loop filter 2 index const SLArrayIndex t, Loop filter length SLData t*, Pointer to loop filter state Pointer to delayed sample SLData_t *)

DESCRIPTION

This function resets the Costas loop phase detector functions, including the filter state arrays, without reinitializing the look up tables.

NOTES ON USE

CROSS REFERENCE

SIF_CostasLoop, SDS_CostasLoop, SDA_CostasLoop.

void SIF_180DegreePhaseDetect (SLData_t *, Fast sine look up table phase SLData t*, Pointer to fast sine look up table const SLArrayIndex t, Fast sine look up table size LPF cut-off frequency const SLData t, SLData t*, Pointer to filter state array Pointer to filter coefficients SLData t*, SLArrayIndex t*, Pointer to filter index const SLArrayIndex t, Filter length SLArrayIndex_t *) Pointer to sign of previous output

DESCRIPTION

This function initialises the 180 degree phase reversal detector function.

NOTES ON USE

CROSS REFERENCE

SDA 180DegreePhaseDetect

SLArrayIndex_t SDA_180DegreePhaseDetect (const SLData_t *, Src data pointer


SLData t*, Destination data pointer Fast sine look up table phase SLData t*, const SLData t*, Pointer to fast sine look up table const SLArrayIndex t, Fast sine look up table size const SLData t, Carrier frequency Pointer to filter state array SLData t*, Pointer to filter coefficients const SLData t*, SLArrayIndex t*, Pointer to filter index const SLArrayIndex t, Filter length

SLArrayIndex t*, Pointer to sign of previous output

const SLArrayIndex t) Length of input array

DESCRIPTION

This function implements a 180 degree phase reversal detector. The block diagram for the detector is shown in the following diagram:



This function stores the output of the Low Pass Filter and returns the location of the phase change in the array or SIGLIB NO PHASE CHANGE if no phase change was detected.

NOTES ON USE

The exact location of the phase change will be delayed by the group delay of the filter.

CROSS REFERENCE

SIF 180DegreePhaseDetect

void SIF_TriggerReverberator (SLArrayIndex_t *, Pointer to trigger counter SLFixData_t *, Pointer to trigger detected flag SLFixData_t *) Pointer to trigger updated flag

DESCRIPTION

This function initialises the trigger reverberator function.

NOTES ON USE

CROSS REFERENCE

SDA_TriggerReverberator

void SDA_TriggerReverberator (const SLData_t *, Pointer to source trigger sequence

SLData_t *, Pointer to destination trigger sequence

SLArrayIndex_t *, Pointer to trigger counter
SLFixData_t *, Pointer to trigger detected flag
SLFixData_t *, Pointer to trigger updated flag

const SLArrayIndex_t, Nominal period of output clock sequence

const SLArrayIndex t) Length of trigger sequences

DESCRIPTION

This function implements a timing reverberator which ensures a continuously running clock when the original input clock stops.

If the phase of the input clock stream changes then the output clock will resynchronize to the source clock as follows:

If the source timing clock is late then the period of the output clock is increased by one sample.

If the source timing clock is early then the period of the output clock is decreased by one sample.

The trigger updated flag is used to ensure that the trigger timing is modified by a maximum of one sample per symbol period. This improves the performance in a noisy environment.

NOTES ON USE

The function SIF TriggerReverberator must be called prior to using this function.

CROSS REFERENCE

SDS TriggerReverberator, SIF TriggerReverberator

SLData t SDS TriggerReverberator (const SLData t *, Source trigger sample

SLArrayIndex_t *, Pointer to trigger counter SLFixData_t *, Pointer to trigger detected flag SLFixData_t *, Pointer to trigger updated flag

const SLArrayIndex t) Nominal period of output clock sequence

DESCRIPTION

This function implements a timing reverberator which ensures a continuously running clock when the original input clock stops.

If the phase of the input clock stream changes then the output clock will resynchronize to the source clock as follows:

If the source timing clock is late then the period of the output clock is increased by one sample.

If the source timing clock is early then the period of the output clock is decreased by one sample.

The trigger updated flag is used to ensure that the trigger timing is modified by a maximum of one sample per symbol period. This improves the performance in a noisy environment.

NOTES ON USE

The function SIF TriggerReverberator must be called prior to using this function.

CROSS REFERENCE

SDA_TriggerReverberator, SIF_TriggerReverberator

SLArrayIndex_t SDA_TriggerSelector (const SLData_t *, Source data sequence

SLData t*, Destination data sequence

const SLData t*, Trigger sequence

const SLArrayIndex t) Length of source sequence

DESCRIPTION

This function selects an output sample depending on the value of the input clock. If the Nth value in the trigger sequence has the value 1.0 then the corresponding value in the source data sequence is written to the destination array, otherwise no value is written to the output array.

This function returns the number of output samples that are written to the output array.

NOTES ON USE

EXAMPLE

Trigger sequence

0.0, 1.0, 0.0, 1.0, 0.0, 0.0, 1.0, 0.0, 1.0, 0.0

Input sequence

0.0, 1.0, 2.0, 3.0, 4.0, 5.0, 6.0, 7.0, 8.0, 9.0

Output sequence

1.0, 3.0, 6.0, 8.0

CROSS REFERENCE


SLError t SIF EarlyLateGate (SLData t*, Pointer to matched filter signal SLData t*, Pointer to matched filter state array SLData t*. Pointer to matched filter coefficients SLArrayIndex t*, Pointer to matched filter index SLData t*, Pointer to early gate state array SLArrayIndex t*, Pointer to early gate delay index const SLArrayIndex t, Early gate delay length SLData t*, Pointer to loop filter state array Pointer to loop filter coefficients SLData t*, SLArrayIndex t*, Pointer to loop filter index const SLArrayIndex t, Loop filter length Loop filter cut-off / centre frequency const SLData t, SLFixData t*, Pointer to pulse detector threshold flag SLData t*, Pointer to zero crossing previous sample SLArrayIndex t*, Pointer to trigger counter SLFixData t*, Pointer to trigger detected flag SLFixData t*, Pointer to trigger updated flag const enum SLELGTriggerTiming t, Trigger timing mode SLArrayIndex t*, Pointer to trigger latency const SLArrayIndex t) Samples per symbol

DESCRIPTION

This function initialises the early-late gate timing function, including the matched filter, which is generated from the impulse response of a single symbol. The trigger timing mode parameter specifies the location of the timing pulse with respect to the symbol pulses. The options for the "trigger timing mode" parameter are as follows:

```
SIGLIB_ELG_TRIGGER_START - Locate the trigger at the start of the symbol - Locate the trigger in the middle of the symbol
```

The early late gate timing error detector has the following flow diagram:




The following description describes how the Early Late Gate Timing Error Detector (ELG-TED) works.


For a given pulse:



The cross correlation function is:



When the magnitude of the early and late gates matches then the centre location is that of the middle of the pulse, as shown:



In some applications it is required to detect the start of the pulse and in others (as shown above) it is necessary to detect the middle. This variation is supported through the use of the "trigger timing mode" parameter.

NOTES ON USE

CROSS REFERENCE

SDA_EarlyLateGate, SDA_EarlyLateGateDebug, SDS_EarlyLateGate, SIF_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse.

void SDA EarlyLateGate (const SLData t*, Pointer to source array SLData t*, Pointer to trigger output SLData t*, Pointer to matched filter state array SLData t*, Pointer to matched filter coefficients Pointer to matched filter index SLArrayIndex t*, SLData t*, Pointer to early gate state array SLArrayIndex t*, Pointer to early gate delay index Early gate delay length const SLArrayIndex t, Pointer to loop filter state array SLData t*, Pointer to loop filter coefficients SLData t*, Pointer to loop filter index SLArrayIndex t*, const SLArrayIndex t, Loop filter length const SLData t, Noise threshold SLFixData t*, Pointer to pulse detector threshold flag SLData t*, Pointer to zero crossing previous sample SLArrayIndex t*, Pointer to trigger counter SLFixData t*, Pointer to trigger detected flag SLFixData t*, Pointer to trigger updated flag const SLArrayIndex t, Samples per symbol Source array length const SLArrayIndex t)

DESCRIPTION

This function implements the early-late gate timing function.

The signal is pre-filtered with a matched filter and then the result provided to the early late gate detector. The timing signal is not updated if the signal level is below the noise threshold parameter. The output is a pulse stream synchronized to the period of the input data stream. The trigger output is designed to be free running during a period of symbols where there is no magnitude level change.

NOTES ON USE

The function SIF_EarlyLateGate must be called prior to using this function. Please refer to the documentation for SIF_EarlyLateGate for further implementation details.

CROSS REFERENCE

SIF_EarlyLateGate, SDA_EarlyLateGateDebug, SDS_EarlyLateGate, SIF_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse.

void SDA_EarlyLateGateDebug (const SLData_t *, Pointer to source array

SLData_t *, Pointer to trigger output

SLData_t *, Pointer to matched filter state array SLData_t *, Pointer to matched filter coefficients

SLArrayIndex_t *, Pointer to matched filter index SLData_t *, Pointer to early gate state array SLArrayIndex t *, Pointer to early gate delay index

const SLArrayIndex_t, Early gate delay length

SLData_t *, Pointer to loop filter state array
SLData_t *, Pointer to loop filter coefficients
SLArrayIndex t *, Pointer to loop filter index

const SLArrayIndex_t, Loop filter length const SLData t, Noise threshold

SLFixData_t *, Pointer to pulse detector threshold flag SLData t *, Pointer to zero crossing previous sample

SLArrayIndex_t *, Pointer to trigger counter
SLFixData_t *, Pointer to trigger detected flag
SLFixData_t *, Pointer to trigger updated flag
SLData_t *, Pointer to matched filter output
SLData_t *, Pointer to loop filter output

const SLArrayIndex_t, Samples per symbol const SLArrayIndex_t) Source array length

DESCRIPTION

This function implements the early-late gate timing function. The matched filter and loop filter outputs are stored for debugging.

The signal is pre-filtered with a matched filter and then the result provided to the early late gate detector. The timing signal is not updated if the signal level is below the noise threshold parameter. The output is a pulse stream synchronized to the period of the input data stream. The trigger output is designed to be free running during a period of symbols where there is no magnitude level change.

NOTES ON USE

The function SIF_EarlyLateGate must be called prior to using this function. Please refer to the documentation for SIF_EarlyLateGate for further implementation details.

CROSS REFERENCE

SIF_EarlyLateGate, SDA_EarlyLateGate, SDS_EarlyLateGate, SIF_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse.

SLData_t SDS_EarlyLateGate (const SLData_t, Source data value

SLData_t *, Pointer to matched filter state array
SLData_t *, Pointer to matched filter coefficients
SLArrayIndex_t *, Pointer to matched filter index
SLData_t *, Pointer to early gate state array
SLArrayIndex_t *, Pointer to early gate delay index

const SLArrayIndex_t, Early gate delay length

SLData_t *, Pointer to loop filter state array SLData_t *, Pointer to loop filter coefficients SLArrayIndex t *, Pointer to loop filter index

const SLArrayIndex_t, Loop filter length const SLData_t, Noise threshold

SLFixData_t *, Pointer to pulse detector threshold flag SLData_t *, Pointer to zero crossing previous sample

SLArrayIndex_t *, Pointer to trigger counter
SLFixData_t *, Pointer to trigger detected flag
SLFixData_t *, Pointer to trigger updated flag

const SLArrayIndex t) Samples per symbol

DESCRIPTION

This function implements the early-late gate timing function on a per-sample basis.

The signal is pre-filtered with a matched filter and then the result provided to the early late gate detector. The timing signal is not updated if the signal level is below the noise threshold parameter. The output is a pulse stream synchronized to the period of the input data stream. The trigger output is designed to be free running during a period of symbols where there is no magnitude level change.

NOTES ON USE

The function SIF_EarlyLateGate must be called prior to using this function. Please refer to the documentation for SIF EarlyLateGate for further implementation details.

CROSS REFERENCE

SIF_EarlyLateGate, SDA_EarlyLateGate, SDA_EarlyLateGateDebug, SIF_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse.

SLError_t SIF_EarlyLateGateSquarePulse (SLData_t *, Pointer to matched filter state array

SLArrayIndex t*, Pointer to matched filter index SLData t*, Pointer to matched filter sum SLData t*, Pointer to early gate state array SLArrayIndex t*, Pointer to early gate delay index const SLArrayIndex t, Early gate delay length SLData t*, Pointer to loop filter state array Pointer to loop filter coefficients SLData t*, SLArrayIndex t*, Pointer to loop filter index const SLArrayIndex t, Loop filter length Loop filter cut-off / centre frequency const SLData t, SLFixData t*, Pointer to pulse detector threshold flag SLData t*, Pointer to zero crossing previous sample SLArrayIndex t*, Pointer to trigger counter SLFixData t*, Pointer to trigger detected flag SLFixData t*, Pointer to trigger updated flag


const enum SLELGTriggerTiming_t, Trigger timing mode
SLArrayIndex_t *, Pointer to trigger latency
const SLArrayIndex_t) Samples per symbol

DESCRIPTION

This function initialises the early-late gate timing function, including the matched filter. The matched filter is optimized for square pulse signals and uses a comb filter for the implementation. The trigger timing mode parameter specifies the location of the timing pulse with respect to the symbol pulses. The options for the trigger timing mode are as follows:

```
SIGLIB_ELG_TRIGGER_START - Locate the trigger at the start of the symbol - Locate the trigger in the middle of the symbol
```

The early late gate timing error detector has the following flow diagram:




The following description describes how the Early Late Gate Timing Error Detector (ELG-TED) works.


For a given pulse:



The cross correlation function is:



When the magnitude of the early and late gates matches then the centre location is that of the middle of the pulse, as shown:



In some applications it is required to detect the start of the pulse and in others (as shown above) it is necessary to detect the middle. This variation is supported through the use of the "trigger timing mode" parameter.

NOTES ON USE

CROSS REFERENCE

SIF_EarlyLateGate, SDA_EarlyLateGate, SDA_EarlyLateGateDebug, SDS_EarlyLateGate, SDA_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulseDebug, SDS_EarlyLateGateSquarePulse.

void SDA_EarlyLateGateSquarePulse (const SLData_t *, Pointer to source data

SLData t*, Pointer to trigger output

SLData_t *, Pointer to matched filter state array SLArrayIndex_t *, Pointer to matched filter index SLData_t *, Pointer to matched filter sum SLData_t *, Pointer to early gate state array SLArrayIndex t *, Pointer to early gate delay index

const SLArrayIndex_t, Early gate delay length

SLData_t *, Pointer to loop filter state array SLData_t *, Pointer to loop filter coefficients SLArrayIndex t *, Pointer to loop filter index

const SLArrayIndex_t, Loop filter length const SLData t, Noise threshold

SLFixData_t *, Pointer to pulse detector threshold flag SLData t *, Pointer to zero crossing previous sample

SLArrayIndex_t *, Pointer to trigger counter SLFixData_t *, Pointer to trigger detected flag SLFixData_t *, Pointer to trigger updated flag

const SLArrayIndex_t, Samples per symbol const SLArrayIndex_t) Source array length

DESCRIPTION

This function implements the early-late gate timing function.

The signal is pre-filtered with a matched filter and then the result provided to the early late gate detector. The timing signal is not updated if the signal level is below the noise threshold parameter. The output is a pulse stream synchronized to the period of the input data stream. The trigger output is designed to be free running during a period of symbols where there is no magnitude level change.

NOTES ON USE

The function SIF_EarlyLateGateSquarePulse must be called prior to using this function. Please refer to the documentation for SIF_EarlyLateGateSquarePulse for further implementation details.

CROSS REFERENCE

SIF_EarlyLateGate, SDA_EarlyLateGate, SDA_EarlyLateGateDebug, SDS_EarlyLateGate, SIF_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulseDebug, SDS_EarlyLateGateSquarePulse.

void SDA EarlyLateGateSquarePulseDebug (const SLData t*, Pointer to src. data

SLData t*, Pointer to trigger output

SLData t*, Pointer to matched filter state array SLArrayIndex t*, Pointer to matched filter index SLData t*, Pointer to matched filter sum SLData t*, Pointer to early gate state array SLArrayIndex t*, Pointer to early gate delay index

Early gate delay length const SLArrayIndex t,

SLData t*, Pointer to loop filter state array Pointer to loop filter coefficients SLData t*, Pointer to loop filter index SLArrayIndex t*,

Loop filter length

const SLArrayIndex t, Noise threshold const SLData t,

SLFixData t*, Pointer to pulse detector threshold flag SLData t*, Pointer to zero crossing previous sample

SLArrayIndex t*, Pointer to trigger counter Pointer to trigger detected flag SLFixData t*, SLFixData t*, Pointer to trigger updated flag Pointer to matched filter output SLData t*, Pointer to loop filter output SLData t*,

const SLArrayIndex t, Samples per symbol Source array length const SLArrayIndex t)

DESCRIPTION

This function implements the early-late gate timing function. The matched filter and loop filter outputs are stored for debugging.

The signal is pre-filtered with a matched filter and then the result provided to the early late gate detector. The timing signal is not updated if the signal level is below the noise threshold parameter. The output is a pulse stream synchronized to the period of the input data stream. The trigger output is designed to be free running during a period of symbols where there is no magnitude level change.

NOTES ON USE

The function SIF EarlyLateGateSquarePulse must be called prior to using this function. Please refer to the documentation for SIF EarlyLateGateSquarePulse for further implementation details.

CROSS REFERENCE

SIF EarlyLateGate, SDA EarlyLateGate, SDA EarlyLateGateDebug, SDS EarlyLateGate, SIF EarlyLateGateSquarePulse, SDA EarlyLateGateSquarePulse, SDS EarlyLateGateSquarePulse.

SLData_t SDS_EarlyLateGateSquarePulse (const SLData_t, Source data value

SLData_t *, Pointer to matched filter state array SLArrayIndex_t *, Pointer to matched filter index SLData_t *, Pointer to matched filter sum SLData_t *, Pointer to early gate state array SLArrayIndex_t *, Pointer to early gate delay index

const SLArrayIndex_t, Early gate delay length

SLData_t *, Pointer to loop filter state array SLData_t *, Pointer to loop filter coefficients SLArrayIndex t *, Pointer to loop filter index

const SLArrayIndex_t, Loop filter length const SLData_t, Noise threshold

SLFixData_t *, Pointer to pulse detector threshold flag SLData_t *, Pointer to zero crossing previous sample

SLArrayIndex_t *, Pointer to trigger counter
SLFixData_t *, Pointer to trigger detected flag
SLFixData_t *, Pointer to trigger updated flag

const SLArrayIndex t) Samples per symbol

DESCRIPTION

This function implements the early-late gate timing function on a per-sample basis.

The signal is pre-filtered with a matched filter and then the result provided to the early late gate detector. The timing signal is not updated if the signal level is below the noise threshold parameter. The output is a pulse stream synchronized to the period of the input data stream. The trigger output is designed to be free running during a period of symbols where there is no magnitude level change.

NOTES ON USE

The function SIF_EarlyLateGateSquarePulse must be called prior to using this function. Please refer to the documentation for SIF_EarlyLateGateSquarePulse for further implementation details.

CROSS REFERENCE

SIF_EarlyLateGate, SDA_EarlyLateGate, SDA_EarlyLateGateDebug, SDS_EarlyLateGate, SIF_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulse, SDA_EarlyLateGateSquarePulseDebug.

Convolutional Encode and Viterbi Decode Functions (viterbi.c)

The convolutional encoder and Viterbi decoder functions include several sections of code that is conditionally compiled, depending on the value of certain defined constants that are located at the top of the source file (*viterbi.c*). In all cases, the #define statements should be set to '1' to enable the appropriate code and '0' to disable it.

For the Viterbi decoders, it may be necessary to normalise the error accumulation to avoid numerical overflow. This can be controlled using the following definitions:

```
K3_NORMALISE_ERROR
V32 NORMALISE ERROR
```

The following conditional compilation switches also control the debug feedback, using printf statements:

DEBUG	Global debug enable / disable switch
K3_DEBUG_ERROR_ACC	K=3 Viterbi decoder error accumulation
K3_DEBUG_TRACE_BACK	K=3 Viterbi decoder trace back path
V32_DEBUG_CONV_ENC	V.32 convolutional encoder
V32_DEBUG_CHANNEL_DATA	V.32 channel data
V32 DEBUG ERROR ACC	Debug V.32 error accumulation
V32 DEBUG TRACE BACK	V.32 trace back path
	_

unsigned int SDS_ConvEncoderK3 (unsigned SLChar_t, Input character SLArrayIndex_t *) Pointer to convolutional encoder state

DESCRIPTION

This function implements a K=3, rate 1/2 convolutional encoder on a source character (8 bits). The output is a short integer (16 bits), with two output bits for every input bit.

NOTES ON USE

The convolutional encoder state is a single word of type SLArrayIndex_t.

Please also refer to the notes at the top of the convolutional encoder / Viterbi decoder section.

CROSS REFERENCE

SIF_ViterbiDecoderK3, SDS_ViterbiDecoderK3.

```
void SIF_ViterbiDecoderK3 (SLFixData_t *, Bit counter
SLChar_t *, Storage to build decoded bits into a byte
SLData_t *, Accumulated error array
SLArrayIndex_t *, Survivor state history table
SLArrayIndex_t *, State history array offset
SLFixData_t *, Trace back mode flag
const SLArrayIndex_t) Trace back depth
```

DESCRIPTION

This function initialises the K=3, rate 1/2 Viterbi decoder function.

NOTES ON USE

Bit counter parameter counts the bits into the output word so they are correctly aligned, this accounts for the delay through the decoder.

The survivor state history table is a two dimensional array of dimension: [TRACE_BACK_TABLE_LENGTH][SIGLIB_VITK3_NUMBER_OF_STATES]. Where SIGLIB_VITK3_NUMBER_OF_STATES is defined by the SigLib library. The accumulated error array is of dimension SIGLIB_VITK3_NUMBER_OF_STATES.

The trace back mode flag parameter is set to SIGLIB_TRUE when in trace back mode. The state history array offset parameter tracks the offset into the circular state history array.

Please also refer to the notes at the top of the convolutional encoder / Viterbi decoder section.

CROSS REFERENCE

SDS ConvEncoderK3, SDS ViterbiDecoderK3.

SLChar t SDS ViterbiDecoderK3 (SLData t*, Source data pointer SLFixData t*, Bit counter SLChar t*, Storage to build decoded bits into a byte Accumulated error array SLData t*, SLArrayIndex t*, Survivor state history table SLArrayIndex t*, Offset into state history array SLFixData t*, Trace back mode flag const SLArrayIndex t) Trace back depth

DESCRIPTION

This function implements a K=3, rate 1/2 Viterbi decoder on a short integer (16 bits) input. The output is a character (8 bits). Two input bits are used to generate every output bit.

NOTES ON USE

Bit counter parameter counts the bits into the output word so they are correctly aligned, this accounts for the delay through the decoder.

The survivor state history table is a two dimensional array of dimension: [TRACE_BACK_TABLE_LENGTH][SIGLIB_VITK3_NUMBER_OF_STATES]. Where SIGLIB_VITK3_NUMBER_OF_STATES is defined by the SigLib library. The accumulated error array is of dimension SIGLIB_VITK3_NUMBER_OF_STATES.

The trace back mode flag parameter is set to SIGLIB_TRUE when in trace back mode. The state history array offset parameter tracks the offset into the circular state history array.

Please also refer to the notes at the top of the convolutional encoder / Viterbi decoder section.

CROSS REFERENCE

SDS_ConvEncoderK3, SIF_ViterbiDecoderK3.

SLComplexRect_s SDS_ConvEncoderV32 (unsigned SLChar_t, Input nibble SLArrayIndex_t *, Differential encoder state SLArrayIndex t *) Convolutional encoder state

DESCRIPTION

This function implements a V.32 convolutional encoder on an source nibble (4 bits). The output is a complex number, which represents that positioning of the points in the V.32 constellation diagram. This function also implements the differential encoder functionality, which is part of the V.32 specification.

NOTES ON USE

The convolutional encoder state and differential encoder state are both single words of type SLArrayIndex t.

Please also refer to the notes at the top of the convolutional encoder / Viterbi decoder section.

CROSS REFERENCE

SIF ViterbiDecoderV32, SDS ViterbiDecoderV32.

```
void SIF_ViterbiDecoderV32 (SLData_t *, Accumulated error array SLArrayIndex_t *, Survivor state history table SLArrayIndex_t *, Offset into state history array SLFixData_t *, Trace back mode flag const SLArrayIndex t) Trace back depth
```

DESCRIPTION

This function initialises the V.32 Viterbi decoder function.

NOTES ON USE

The survivor state history table is a two dimensional array of dimension: [TRACE_BACK_TABLE_LENGTH][SIGLIB_VITV32_NUMBER_OF_STATES]. Where SIGLIB_VITV32_NUMBER_OF_STATES is defined by the SigLib library. The accumulated error array is of dimension: SIGLIB_VITV32_NUMBER_OF_STATES.

SIGLIB_VIIV32_NUMBER_UF_STATES.

The trace back mode flag parameter is set to SIGLIB_TRUE when in trace back mode. The state history array offset parameter tracks the offset into the circular state history array.

Please also refer to the notes at the top of the convolutional encoder / Viterbi decoder section.

CROSS REFERENCE

SDS ConvEncoderV32, SDS ViterbiDecoderV32.

Channel data SLChar t SDS ViterbiDecoderV32 (SLComplexRect s, SLData t*, Accumulated error array SLArrayIndex t*, Survivor state history table Offset into state history array SLArrayIndex t*, SLArrayIndex t*, Q4Q3 History table SLArrayIndex t*, Differential decoder state SLFixData t*, Trace back mode flag const SLArrayIndex t) Trace back depth

DESCRIPTION

This function implements a V.32 Viterbi decoder on a complex source number, which represents that position of the received sample on the V.32 constellation diagram. The output is a nibble (4 bits). This function also implements the differential decoder functionality, which is part of the V.32 specification.

NOTES ON USE

The survivor state history table and nearest Q4Q3 history array are both two dimensional arrays of dimension:

[TRACE_BACK_TABLE_LENGTH][SIGLIB_VITV32_NUMBER_OF_STATES]. Where SIGLIB_VITV32_NUMBER_OF_STATES is defined by the SigLib library. The accumulated error array is of dimension: SIGLIB_VITV32_NUMBER_OF_STATES.

The differential decoder state is a single words of type SLArrayIndex t.

The trace back mode flag parameter is set to SIGLIB_TRUE when in trace back mode. The state history array offset parameter tracks the offset into the circular state history array.

Please also refer to the notes at the top of the convolutional encoder / Viterbi decoder section.

CROSS REFERENCE

SDS ConvEncoderV32, SIF ViterbiDecoderV32.

Analog Modulation Functions (mod a.c)

SIF AmplitudeModulate

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_AmplitudeModulate (SLData_t *, Carrier table pointer SLArrayIndex_t *, Carrier table index const SLArrayIndex_t) Modulator array length

DESCRIPTION

This function initialized the amplitude modulation functions SDA_AmplitudeModulate and SDS_AmplitudeModulate. These functions utilize a look up table for the carrier that represents an integer number of samples per cycle. For example, a carrier frequency of 200 KHz, with a sample rate of 1 MHz gives a look up table length of $1e^6/2e^5=5$ samples.

If your application requires a carrier frequency that is not an integer number of samples in length then you are advised to use the XXX_AmplitudeModulate2 functions.

NOTES ON USE

CROSS REFERENCE

SDA_AmplitudeModulate, SDS_AmplitudeModulate, SIF AmplitudeModulate2, SDA AmplitudeModulate2, SDS AmplitudeModulate2.

void SDA_AmplitudeModulate (const SLData_t *, Modulating signal source pointer

const SLData t *, Carrier table pointer

SLData t*, Modulated signal destination pointer

SLArrayIndex_t *, Carrier table index const SLArrayIndex_t, Modulator array length const SLArrayIndex_t) Sample array size

DESCRIPTION

This function amplitude modulates one signal with another, it can be identically used for modulation and demodulation.

NOTES ON USE

This function operates on an array oriented basis.

The function SIF_AmplitudeModulate should be called prior to using this function. Please read the notes for SIF_AmplitudeModulate.

This function can work in-place.

CROSS REFERENCE

SIF_AmplitudeModulate, SDS_AmplitudeModulate, SIF_AmplitudeModulate2, SDA_AmplitudeModulate2, SDS_AmplitudeModulate2.

SLData_t SDS_AmplitudeModulate (const SLData_t, Modulating signal source data

const SLData_t *, Carrier table pointer
SLArrayIndex_t *, Carrier table index
const SLArrayIndex t) Modulator array length

DESCRIPTION

This function amplitude modulates one signal with another, it can be identically used for modulation and demodulation.

NOTES ON USE

This function operates on a per sample basis.

The function SIF_AmplitudeModulate should be called prior to using this function. Please read the notes for SIF_AmplitudeModulate.

CROSS REFERENCE

SIF_AmplitudeModulate, SDA_AmplitudeModulate, SIF AmplitudeModulate2, SDA AmplitudeModulate2, SDS AmplitudeModulate2.

void SIF_AmplitudeModulate2 (SLData_t *, Carrier table pointer SLData_t *, Carrier table phase const SLArrayIndex_t) Modulator array length

DESCRIPTION

This function initialized the amplitude modulation functions SDA_AmplitudeModulate2 and SDS_AmplitudeModulate2. These functions utilize a look up table for the carrier that represents a single over-sampled cosine wave form. The modulators step through the look up table with a phase integrator that is proportional to the carrier frequency normalized to a sampling rate of 1.0 Hz. The carrier phase uses a floating point variable so it can support a very large range of carrier frequencies with high accuracy.

NOTES ON USE

CROSS REFERENCE

SIF_AmplitudeModulate, SDA_AmplitudeModulate, SDS_AmplitudeModulate2.

void SDA_AmplitudeModulate2 (const SLData_t *, Modulating signal source pointer

const SLData t *, Carrier table pointer

SLData t*, Modulated signal destination pointer

SLData_t *, Carrier table phase const SLData_t, Carrier frequency const SLArrayIndex_t, Modulator array length const SLArrayIndex_t) Sample array size

DESCRIPTION

This function amplitude modulates one signal with another, it can be identically used for modulation and demodulation.

NOTES ON USE

The carrier frequency is normalized to 1.0 Hz.

This function operates on an array oriented basis.

The function SIF_AmplitudeModulate2 should be called prior to using this function. Please read the notes for SIF_AmplitudeModulate2.

This function can work in-place.

CROSS REFERENCE

SIF_AmplitudeModulate, SDA_AmplitudeModulate, SDS AmplitudeModulate, SIF AmplitudeModulate2.

SLData_t SDS_AmplitudeModulate2 (const SLData_t, Modulating signal source data

const SLData_t *, Carrier table pointer
SLData_t *, Carrier table phase
const SLData_t, Carrier frequency
const SLArrayIndex t) Modulator array length

DESCRIPTION

This function amplitude modulates one signal with another, it can be identically used for modulation and demodulation.

NOTES ON USE

The carrier frequency is normalized to 1.0 Hz.

This function operates on a per sample basis.

The function SIF_AmplitudeModulate2 should be called prior to using this function. Please read the notes for SIF_AmplitudeModulate2.

CROSS REFERENCE

SIF_AmplitudeModulate, SDA_AmplitudeModulate, SDS AmplitudeModulate, SIF AmplitudeModulate2.

```
SLError t SIF ComplexShift (SLData t*, Comb filter 1 pointer
       SLData t*,
                                          Comb filter 1 running sum
                                          Comb filter 2 pointer
       SLData t*,
                                          Comb filter 2 running sum
       SLData t*,
                                          Comb filter phase
       SLArrayIndex t*,
       SLData t*,
                                          Sine table pointer
                                          Sine table phase for mixer
       SLArrayIndex t*,
                                          Length of comb filter
       const SLArrayIndex t,
       const SLArrayIndex_t)
                                          Length of demodulation sine table
```

DESCRIPTION

This function initializes the complex frequency shifting function.

NOTES ON USE

This function initialises a table containing a sinusoidal waveform. This table consists of floating-point data values. For fixed point implementations it will be necessary to generate the tables with the appropriate data, which will depend on the length of the table and the CPU word length.

This function returns the error code from the SDA_SignalGenerate() function that it calls.

CROSS REFERENCE

SDA ComplexShift.


void SDA_ComplexShift (const SLData_t *, Modulating signal pointer

SLData t*, Modulated signal destination pointer Comb filter 1 pointer SLData t*, Comb filter 1 running sum SLData t*, SLData t*, Comb filter 2 pointer SLData t*, Comb filter 2 running sum SLArrayIndex t*, Comb filter phase const SLData t*, Sine table pointer SLArrayIndex t*, Sine table phase for mixer const SLData t, Mix frequency Length of comb filter const SLArrayIndex t, Sine table length for mixer const SLArrayIndex t,

Sample array length

DESCRIPTION

This function performs a complex frequency shift with the following structure:



const SLArrayIndex t)

Sum can be Square magnitude sum, or Quadrature - In-phase, this routine uses square magnitude sum.

NOTES ON USE

This function uses a single length N sine table. The cosine pointer index starts at (length >> 2) to account for the phase.

CROSS REFERENCE

SIF_ComplexShift.

SLData_t SIF_FrequencyModulate (SLData_t *, Pointer to carrier phase SLData_t *, Pointer to LUT array const SLArrayIndex_t) Table length

DESCRIPTION

This function initializes the fast cosine look up table for the frequency modulation functions.

NOTES ON USE

The array contains one complete cycle of a cosine wave (0 to 2π), with N samples.

CROSS REFERENCE

SDS_FrequencyModulate, SDA_FrequencyModulate, SIF_FrequencyModulateComplex, SDS_FrequencyModulateComplex, SDA_FrequencyModulateComplex.

SLData_t SDS_FrequencyModulate (const SLData_t, Modulating signal

const SLData_t , Carrier frequency const SLData_t , Modulation index SLData_t *, Phase offset

const SLData_t *, Fast sine look up table const SLArrayIndex t) Look up table size

DESCRIPTION

This function frequency modulates a carrier signal with another. The modulation index specifies the frequency change per unit input amplitude change on the modulating signal.

The output phase is modified by the carrier frequency (normalized to 1.0 Hz) plus the product of the modulation index and the magnitude of the input signal.

This function can also be used as a voltage controlled oscillator (VCO / NCO).

NOTES ON USE

This function can operate on individual samples and uses the fast sine wave look up table technique.

If this function proves to be unstable then the most likely cause is that the modulation index is too large.

The function SIF FrequencyModulate must be called prior to calling this function.

CROSS REFERENCE

SIF_FrequencyModulate, SDA_FrequencyModulate, SDA_FrequencyDemodulate, SIF_FrequencyModulateComplex, SDS_FrequencyModulateComplex, SDA_FrequencyModulateComplex.

void SDA FrequencyModulate (const SLData t*, Modulating signal

SLData t*, Modulated signal destination pointer

const SLData_t , Carrier frequency const SLData_t , Modulation index SLData_t *, Phase offset

const SLData_t *, Fast sine look up table const SLArrayIndex_t, Look up table size

const SLArrayIndex_t) Array length

DESCRIPTION

This function frequency modulates a carrier signal with another. The modulation index specifies the frequency change per unit input amplitude change on the modulating signal.

The output phase is modified by the carrier frequency (normalized to 1.0 Hz) plus the product of the modulation index and the magnitude of the input signal.

This function can also be used as a voltage controlled oscillator (VCO / NCO).

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation. It uses the fast sine wave look up table technique

If this function proves to be unstable then the most likely cause is that the modulation index is too large.

The function SIF FrequencyModulate must be called prior to calling this function.

CROSS REFERENCE

SIF_FrequencyModulate, SDS_FrequencyModulate, SDA_FrequencyDemodulate, SIF_FrequencyModulateComplex, SDS_FrequencyModulateComplex.

void SDA_FrequencyDemodulate (const SLData_t *, Modulated signal

SLData_t *, Demodulated signal destination pointer

SLData_t *, Previous value of differential SLData_t *, Previous value of envelope

const SLData_t, Envelope decay factor

const SLArrayIndex_t) Array length

DESCRIPTION

This function demodulates an FM signal using the direct method i.e. differentiate and envelope detect.

The function is required to maintain the signal magnitude and envelope magnitude to ensure continuous operation across array boundaries. This is achieved using the previous value of differential and previous value of envelope variables. It is also necessary to specify the envelope decay factor to define how aggressively the envelope tracks the signal.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SIF_FrequencyModulate, SDS_FrequencyModulate, SDA_FrequencyModulate, SIF_FrequencyModulateComplex, SDS_FrequencyModulateComplex.

void SIF_FrequencyModulateComplex (SLData_t *, Pointer to carrier phase SLData_t *, Pointer to LUT array const SLArrayIndex_t) Table length

DESCRIPTION

This function initializes the fast cosine look up table for the complex frequency modulation functions.

NOTES ON USE

The array contains one and one quarter of a cosine wave (0 to $5.\pi/2$), with 5*N/4 samples.

CROSS REFERENCE

SIF_FrequencyModulate, SDS_FrequencyModulate, SDA_FrequencyModulate, SDA_FrequencyDemodulate, SDS_FrequencyModulateComplex, SDA_FrequencyModulateComplex.

```
void SDS FrequencyModulateComplex (const SLData t, Modulating signal source
       SLData t*,
                                          Real modulated signal destination
pointer
       SLData t*,
                                          Imaginary modulated signal destination
pointer
       const SLData t,
                                          Carrier frequency
       const SLData t,
                                          Modulation index
       SLData t*,
                                          Pointer to carrier phase
       const SLData t*,
                                          Fast sine / cosine look up table
       const SLArrayIndex t)
                                          Look up table size
```

DESCRIPTION

This function frequency modulates a complex carrier signal (In-phase and quadrature) with another. The modulation index specifies the frequency change per unit input amplitude change on the modulating signal.

The output phase is modified by the carrier frequency (normalized to 1.0 Hz) plus the product of the modulation index and the magnitude of the input signal.

This function can also be used as a voltage controlled oscillator (VCO / NCO) to generate a complex I-Q signal.

NOTES ON USE

This function operates on individual samples and uses the fast sine/cosine wave look up table technique.

If this function proves to be unstable then the most likely cause is that the modulation index is too large.

The function SIF_FrequencyModulateComplex must be called prior to calling this function.

CROSS REFERENCE

```
SIF_FrequencyModulate, SDS_FrequencyModulate, SDA_FrequencyModulate, SDA_FrequencyDemodulate, SIF_FrequencyModulateComplex, SDA_FrequencyModulateComplex.
```

void SDA FrequencyModulateComplex (const SLData t*, Modulating signal source pointer SLData t*, Real modulated signal destination pointer SLData t*, Imaginary modulated signal destination pointer Carrier frequency const SLData t, Modulation index const SLData t, SLData t*, Pointer to carrier phase const SLData t*, Fast cosine look up table const SLArrayIndex t, Look up table size const SLArrayIndex t) Array length

DESCRIPTION

This function frequency modulates a complex carrier signal (In-phase and quadrature) with another. The modulation index specifies the frequency change per unit input amplitude change on the modulating signal.

The output phase is modified by the carrier frequency (normalized to 1.0 Hz) plus the product of the modulation index and the magnitude of the input signal.

This function can also be used as a voltage controlled oscillator (VCO / NCO) to generate a complex I-Q signal.

NOTES ON USE

This function operates on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation. It uses the fast sine wave look up table technique

If this function proves to be unstable then the most likely cause is that the modulation index is too large.

The function SIF_FrequencyModulateComplex must be called prior to calling this function.

CROSS REFERENCE

```
SIF_FrequencyModulate, SDS_FrequencyModulate, SDA_FrequencyDemodulate, SDA_FrequencyDemodulate, SIF FrequencyModulateComplex, SDS FrequencyModulateComplex.
```

void SDA_DeltaModulate (const SLData_t *, Input data pointer SLData_t *, Destination data pointer SLData_t *, Current integrator sum const SLData_t, Delta const SLArrayIndex t) Array length

DESCRIPTION

This function delta modulates an input signal. The delta modulation index "delta" specifies the fixed increment or decrement on the current integrator sum. The "current integrator sum" parameter is used to maintain continuity over consecutive arrays.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA DeltaDemodulate, SDA DeltaModulate2

void SDA_DeltaDemodulate (const SLData_t *, Input data pointer SLData_t *, Destination data pointer SLData_t *, Current integrator sum const SLArrayIndex_t) Array length

DESCRIPTION

This function demodulates an input delta modulated signal generated by either SDA_DeltaModulate or SDA_DeltaModulate2. The "current integrator sum" is used to maintain continuity over consecutive arrays.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA DeltaModulate, SDA DeltaModulate2

void SDA_DeltaModulate2 (const SLData_t *, Input data pointer SLData_t *, Destination data pointer SLData_t *, Current integrator sum const SLData_t, Integration maximum value const SLArrayIndex_t)

Array length

DESCRIPTION

This function delta modulates an input signal. The integration maximum value parameter specifies the largest increment that can be applied to the current integrator sum. The "current integrator sum" parameter is used to maintain continuity over consecutive arrays.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA DeltaDemodulate, SDA DeltaModulate

VCO phase SLError t SIF CostasQamDemodulate (SLData t*, VCO look up table SLData t*, const SLArrayIndex t, VCO look up table size const SLData t, Low-pass filter cut-off frequency SLData t*, Pointer to loop filter 1 state Pointer to loop filter 1 index SLArrayIndex t*, Pointer to loop filter 2 state SLData t*, SLArrayIndex t*, Pointer to loop filter 2 index SLData t*, Pointer to loop filter coefficients Loop filter length const SLArrayIndex t, SLData t*, Pointer to loop filter state SLData t*, Pointer to delayed sample SLData t*, Pointer to matched filter state array SLArrayIndex t*, Pointer to matched filter index SLData t*, Pointer to matched filter sum SLData t*, Pointer to early gate state array SLArrayIndex t*, Pointer to early gate delay index Early gate delay length const SLArrayIndex t, Pointer to loop filter state array SLData t*, Pointer to loop filter coefficients SLData t*, Pointer to loop filter index SLArrayIndex t*, const SLArrayIndex t, Loop filter length Loop filter cut-off / centre frequency const SLData t, SLFixData t*, Pointer to pulse detector threshold flag SLData t*, Pointer to zero crossing previous sample SLArrayIndex t*, Pointer to trigger counter SLFixData t*, Pointer to trigger detected flag SLFixData t*, Pointer to trigger updated flag SLArrayIndex t*, Pointer to Early-late gate trigger latency const SLArrayIndex t, Samples per symbol Pointer to ELG real output SLData t*, synchronization delay state array SLData t*, Pointer to ELG imaginary output synchronization delay state array SLArrayIndex t*) Pointer to ELG synch. delay index


DESCRIPTION

This function initialises the SDS_CostasQamDemodulate, SDS_CostasQamDemodulateDebug, SDA_CostasQamDemodulate and SDA_CostasQamDemodulateDebug functions.

The Costas Loop based QAM demodulation functions are the preferred functions for demodulating any type of QAM based modulation, including BPSK, QPSK (4-QAM),

DQPSK, π /4DQPSK, 8-PSK and any other QAM variation. The demodulation functions actually return the demodulated IQ sample for each symbol and these can be decoded to give the desired output bit sequence.

The following diagram shows the structure of the Costas loop QAM demodulator:



The Costas loop supports all of the phase error detector modes of the standard Costas loop functions but this diagram has been simplified for clarity.

The Costas loop is used to extract the remote carrier synchronization and the symbol synchronizer (an Early-late-gate Timing Error Detector) locks to the remote symbol timing. The symbol synchronizer also uses the SDS_TriggerReverberator function to ensure that the early-late gate trigger continues even when the symbol magnitude does not vary.

NOTES ON USE

When decoding an arbitrary sequence of data there are a few considerations to be made with respect to the timing and synchronization. The first is that it may be necessary to have separate Costas loop gains for the acquisition and tracking modes. The second consideration is that it is common to have to search for a synchronization sequence of received symbols. Although SigLib supports both array and sample oriented versions of the Costas loop QAM demodulation functions, both of these requirements are typically more easily handled when the per-sample function is used (SDS CostasQamDemodulate).

The Costas loop is responsible for the acquisition of the carrier frequency. It is a feedback loop that uses the error between the received carrier phase and the internal carrier signal phase (generated by the Voltage Controlled Oscillator -VCO). When using the Costas Loop it is typical to acquire a rough estimate very quickly and then track the actual frequency more accurately and more slowly. The way to do this is to use two different values for the VCO feedback parameter - one for acquisition and one for tracking. The feedback value is just a gain that is applied to the VCO input to change the rate at which the Costas loop tracks the phase of the incoming signal. If this value it too small then it won't acquire the phase and if it is too big then it will become unstable. Swapping between acquisition and tracking mode requires knowledge of how close to synchronization the Costas loop is and this is typically done by looking at the error magnitude in the demodulated symbol.

The SDS_CostasQamDemodulate, SDS_CostasQamDemodulateDebug, SDA_CostasQamDemodulate and SDA_CostasQamDemodulateDebug functions use the Costas loop and Early-late gate square pulse synchronization functions. For further details, please read the SIF_CostasLoop, SDS_CostasLoop, SDA_CostasLoop, SIF_EarlyLateGateSquarePulse, SDS_EarlyLateGateSquarePulse and SDS_TriggerReverberator function documentation.

In order to allocate the Costas loop look up table it is necessary to use the SUF_CostasLoopArrayAllocate() to malloc the look-up-table memory, rather than SUF_VectorArrayAllocate().

CROSS REFERENCE

 $SDS_CostasQamDemodulate, SDS_CostasQamDemodulateDebug, SDA_CostasQamDemodulate, SDA_CostasQamDemodulateDebug.$

SLArrayIndex t SDS CostasQamDemodulate (const SLData t, Source data sample SLData t*, Pointer to real destination symbol point SLData t*, Pointer to imag. destination symbol point SLData t*, VCO phase VCO modulation index const SLData t, SLData t*, VCO look up table const SLArrayIndex t, VCO look up table size Carrier frequency const SLData t, SLData t*, Pointer to loop filter 1 state Pointer to loop filter 1 index SLArrayIndex t*, Pointer to loop filter 2 state SLData t*, SLArrayIndex t*, Pointer to loop filter 2 index Pointer to loop filter coefficients const SLData t*, const SLArrayIndex t, Loop filter length SLData t*, Pointer to loop filter state Loop filter coefficient const SLData t, const enum SLCostasLoopFeedbackMode t, Loop feedback mode Pointer to delayed sample SLData t*, SLData t*, Pointer to matched filter state array SLArrayIndex t*, Pointer to matched filter index SLData t*, Pointer to matched filter sum SLData t*, Pointer to early gate state array Pointer to early gate delay index SLArrayIndex t*, Early gate delay length const SLArrayIndex t, SLData t*, Pointer to loop filter state array Pointer to loop filter coefficients SLData t*, Pointer to loop filter index SLArrayIndex t*, const SLArrayIndex t, Loop filter length Loop filter cut-off / centre frequency const SLData t, SLFixData t*, Pointer to pulse detector threshold flag SLData t*, Pointer to zero crossing previous sample Pointer to trigger counter SLArrayIndex t*, SLFixData t*, Pointer to trigger detected flag Pointer to trigger updated flag SLFixData t*, Samples per symbol const SLArrayIndex t, Pointer to ELG real output SLData_t *, synchronization delay state array SLData t*, Pointer to ELG imaginary output synchronization delay state array SLArrayIndex t*, Pointer to ELG synch. delay index const SLArrayIndex t) ELG output synchronization delay length

DESCRIPTION

This function implements the Costas loop QAM demodulator on an individual sample. It will output a single IQ sample if one has been decoded.

NOTES ON USE

For further information on the Costas loop QAM demodulator functions please refer to the SIF CostasQamDemodulate documentation.

CROSS REFERENCE

SIF_CostasQamDemodulate, SDS_CostasQamDemodulateDebug, SDA CostasQamDemodulate, SDA CostasQamDemodulateDebug.

SLArrayIndex t SDS CostasQamDemodula	ateDebug (const SLData t, Src. sample
SLData t *,	Pointer to real destination symbol point
SLData t *,	Pointer to imag. destination symbol point
SLData t *,	VCO phase
const SLData t,	VCO modulation index
SLData t*,	VCO look up table
const SLArrayIndex_t,	VCO look up table size
const SLData t,	Carrier frequency
SLData t*,	Pointer to loop filter 1 state
SLArrayIndex t*,	Pointer to loop filter 1 index
SLData t*,	Pointer to loop filter 2 state
SLArrayIndex t*,	Pointer to loop filter 2 index
const SLData t *,	Pointer to loop filter coefficients
const SLData_t , const SLArrayIndex t,	Loop filter length
SLData t*,	Pointer to loop filter state
const SLData t,	Loop filter coefficient
— ·	
const enum SLCostasLoopFeedback	
SLData_t *,	Pointer to delayed sample
SLData_t *,	Pointer to matched filter state array
SLArrayIndex_t *,	Pointer to matched filter index
SLData_t *,	Pointer to matched filter sum
SLData_t *,	Pointer to early gate state array
SLArrayIndex_t *,	Pointer to early gate delay index
const SLArrayIndex_t,	Early gate delay length
SLData_t *,	Pointer to loop filter state array
SLData_t *,	Pointer to loop filter coefficients
SLArrayIndex_t *,	Pointer to loop filter index
const SLArrayIndex_t,	Loop filter length
const SLData_t,	Loop filter cut-off / centre frequency
SLFixData_t *,	Pointer to pulse detector threshold flag
SLData_t *,	Pointer to zero crossing previous sample
SLArrayIndex_t *,	Pointer to trigger counter
SLFixData_t *,	Pointer to trigger detected flag
SLFixData_t *,	Pointer to trigger updated flag
const SLArrayIndex_t,	Samples per symbol
SLData_t *,	Pointer to ELG real output
synchronization delay state array	
SLData_t *,	Pointer to ELG imaginary output
synchronization delay state array	
SLArrayIndex_t *,	Pointer to ELG synch. delay index
const SLArrayIndex_t,	ELG output synchronization delay length
SLData_t *,	Pointer to debug real filter output
SLData_t *,	Pointer to debug imaginary filter output
SLData_t *,	Pointer to debug ELG trigger output
SLArrayIndex_t *)	Pointer to debug ELG trigger count
DESCRIPTION	

This function implements the Costas loop QAM demodulator on an individual sample. It will output a single IQ sample if one has been decoded.

NOTES ON USE

For further information on the Costas loop QAM demodulator functions please refer to the SIF_CostasQamDemodulate documentation.

This function also saves the real and imaginary (I and Q) output samples from the Costas loop low-pass filters along with the early-late gate trigger so that this information can be used to analyze the performance of the demodulator.

CROSS REFERENCE

SIF_CostasQamDemodulate, SDS_CostasQamDemodulate, SDA CostasQamDemodulate, SDA CostasQamDemodulateDebug.

SLArrayIndex t SDA CostasQamDemodulate (const SLData t*, Source data ptr. SLData t*, Real destination data pointer SLData t*, Imaginary destination data pointer SLData t*, VCO phase VCO modulation index const SLData t, SLData t*, VCO look up table const SLArrayIndex t, VCO look up table size Carrier frequency const SLData t, SLData t*, Pointer to loop filter 1 state Pointer to loop filter 1 index SLArrayIndex t*, Pointer to loop filter 2 state SLData t*, SLArrayIndex t*, Pointer to loop filter 2 index Pointer to loop filter coefficients const SLData t*, const SLArrayIndex t, Loop filter length SLData t*, Pointer to loop filter state Loop filter coefficient const SLData t, const enum SLCostasLoopFeedbackMode t, Loop feedback mode Pointer to delayed sample SLData t*, SLData t*, Pointer to matched filter state array SLArrayIndex t*, Pointer to matched filter index SLData t*, Pointer to matched filter sum SLData t*, Pointer to early gate state array Pointer to early gate delay index SLArrayIndex t*, Early gate delay length const SLArrayIndex t, SLData t*, Pointer to loop filter state array Pointer to loop filter coefficients SLData t*, SLArrayIndex t*, Pointer to loop filter index const SLArrayIndex t, Loop filter length Loop filter cut-off / centre frequency const SLData t, SLFixData t*, Pointer to pulse detector threshold flag SLData t*, Pointer to zero crossing previous sample SLArrayIndex t*, Pointer to trigger counter SLFixData t*, Pointer to trigger detected flag Pointer to trigger updated flag SLFixData t*, Samples per symbol const SLArrayIndex t, Pointer to ELG real output SLData_t *, synchronization delay state array SLData t*, Pointer to ELG imaginary output synchronization delay state array SLArrayIndex t*, Pointer to ELG synch. delay index const SLArrayIndex t, ELG output synchronization delay length const SLArrayIndex t) Source array length

DESCRIPTION

This function implements the Costas loop QAM demodulator on an array of input samples. It will output an arbitrary number of IQ samples depending on how many are decoded in the data stream. The return value is the number of decoded IQ constellation points in the output array.

NOTES ON USE

For further information on the Costas loop QAM demodulator functions please refer to the SIF CostasQamDemodulate documentation.

CROSS REFERENCE

SIF_CostasQamDemodulate, SDS_CostasQamDemodulate, SDS_CostasQamDemodulateDebug, SDA_CostasQamDemodulateDebug.

SLArrayIndex t SDA CostasQamDemodu	lateDebug (const SLData t*, Src. ptr.
SLData t *,	Real destination data pointer
SLData t *,	Imaginary destination data pointer
SLData_t *,	VCO phase
const SLData t,	VCO modulation index
SLData t *,	VCO look up table
const SLArrayIndex t,	VCO look up table size
const SLData t,	Carrier frequency
SLData_t *,	Pointer to loop filter 1 state
SLArrayIndex_t*,	Pointer to loop filter 1 index
SLData t *,	Pointer to loop filter 2 state
SLArrayIndex t*,	Pointer to loop filter 2 index
const SLData t *,	Pointer to loop filter coefficients
const SLArrayIndex t,	Loop filter length
SLData t *,	Pointer to loop filter state
const SLData t,	Loop filter coefficient
const enum SLCostasLoopFeedback	Mode t, Loop feedback mode
SLData t*,	Pointer to delayed sample
SLData t *,	Pointer to matched filter state array
SLArrayIndex t*,	Pointer to matched filter index
SLData t*,	Pointer to matched filter sum
SLData t *,	Pointer to early gate state array
SLArrayIndex t*,	Pointer to early gate delay index
const SLArrayIndex t,	Early gate delay length
SLData t *,	Pointer to loop filter state array
SLData t *,	Pointer to loop filter coefficients
SLArrayIndex t*,	Pointer to loop filter index
const SLArrayIndex t,	Loop filter length
const SLData t,	Loop filter cut-off / centre frequency
SLFixData $t^{\overline{*}}$,	Pointer to pulse detector threshold flag
SLData t *,	Pointer to zero crossing previous sample
SLArrayIndex t*,	Pointer to trigger counter
SLFixData t*,	Pointer to trigger detected flag
SLFixData t *,	Pointer to trigger updated flag
const SLArrayIndex_t,	Samples per symbol
SLData t *,	Pointer to ELG real output
synchronization delay state array	•
SLData t*,	Pointer to ELG imaginary output
synchronization delay state array	
SLArrayIndex t*,	Pointer to ELG synch. delay index
const SLArrayIndex t,	ELG output synchronization delay length
const SLArrayIndex_t,	Source array length
SLData_t *,	Pointer to debug real filter output
SLData t *,	Pointer to debug imaginary filter output
SLData t *)	Pointer to debug ELG trigger output
DESCRIPTION	- 55 .

This function implements the Costas loop QAM demodulator on an array of input samples. It will output an arbitrary number of IQ samples depending on how many are

decoded in the data stream. The return value is the number of decoded IQ constellation points in the output array.

NOTES ON USE

For further information on the Costas loop QAM demodulator functions please refer to the SIF CostasQamDemodulate documentation.

This function also saves the real and imaginary (I and Q) output samples from the Costas loop low-pass filters along with the early-late gate trigger so that this information can be used to analyze the performance of the demodulator.

CROSS REFERENCE

SIF_CostasQamDemodulate, SDS_CostasQamDemodulate, SDS_CostasQamDemodulateDebug, SDA_CostasQamDemodulate.


void SIF_QpskModulate (SLData_t *,	Carrier table pointer
const SLData_t,	Carrier phase increment per sample
	$(radians / 2\pi)$
const SLArrayIndex_t,	Carrier sine table length
SLData_t *,	Carrier phase pointer
SLArrayIndex_t *,	Sample clock pointer
SLComplexRect_s *,	Magnitude pointer
SLData_t *,	RRCF Tx I delay pointer
SLArrayIndex_t *,	RRCF Tx I Filter Index pointer
SLData_t *,	RRCF Tx Q delay pointer
SLArrayIndex_t *,	RRCF Tx Q Filter Index pointer
SLData_t *,	RRCF coefficients pointer
const SLData_t,	RRCF Period
const SLData_t,	RRCF Roll off
const SLArrayIndex_t,	RRCF length
<pre>const SLArrayIndex_t)</pre>	RRCF enable / disable switch

DESCRIPTION

This function initialises the QPSK modulation function SDA_QpskModulate and also for the optional square root raised cosine filter.

NOTES ON USE

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application. The sine and cosine carriers are generated from an overlapped 5/4 sine table and generate the 4 points on the constellation diagram with equal real and imaginary magnitudes i.e. they are on the 45° points, as shown in the following diagram:



Note : Uses bit ordering as per ITU-T V.8

It is possible to arbitrarily rotate the constellation diagram by re-generating the 5/4 sine table with a different phase offset, after this function has returned.

CROSS REFERENCE SDA QpskModulate

Source data di-bit void SDA QpskModulate (const SLFixData t,

> SLData t*, Destination array const SLData t*, Carrier table pointer const SLArrayIndex t, Carrier sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer Carrier table increment const SLArrayIndex t, const SLFixData t, Samples per symbol RRCF Tx I delay pointer SLData t*, RRCF Tx I Filter Index pointer SLArrayIndex t*, RRCF Tx Q delay pointer SLData t*, RRCF Tx Q Filter Index pointer SLArrayIndex t*,

SLData t*, RRCF coefficients pointer

const SLArrayIndex t, RRCF length

RRCF enable / disable switch const SLArrayIndex t)

DESCRIPTION

This function QPSK modulates one symbol of the carrier with a di-bit of source data.

NOTES ON USE

The Destination array length must be a modulo of the number of samples per symbol.

SIF QpskModulate must be called prior to using this function.

The SigLib QPSK functions use a simple mapping of the input nibble to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application. For details on differentially encoding the data, see the SDS QpskDifferentialEncode function.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SIF QpskModulate, SDA QpskDemodulate, SDA QpskDemodulateDebug

void SIF QpskDemodulate (SLData t*, Carrier table pointer const SLData t, Carrier phase increment per sample (radians / 2π) Carrier sine table length const SLArrayIndex t, SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer SLData t*, RRCF Rx I delay pointer RRCF Rx I Filter Index pointer SLArrayIndex t*, RRCF Rx Q delay pointer SLData t*, RRCF Rx Q Filter Index pointer SLArrayIndex t*, SLData t*, RRCF coefficients pointer const SLData t, RRCF Period const SLData t, RRCF Roll off const SLArrayIndex t, RRCF length RRCF enable / disable switch const SLArrayIndex t)

DESCRIPTION

This function initialises the QPSK demodulation function SDA_QpskDemodulate.

The function provides for the initialisation of an optional square root raised cosine filter.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for

demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application. The sine and cosine carriers are generated from an overlapped 5/4 sine table and generate the 4 points on the constellation diagram with equal real and imaginary magnitudes i.e. they are on the 45° points. It is possible to arbitrarily rotate the constellation diagram by re-generating the 5/4 sine table with a different phase offset, after this function has returned.

CROSS REFERENCE

SDA QpskModulate, SDA QpskDemodulate, SDA QpskDemodulateDebug

SLFixData_t SDA_QpskDemodulate (const SLData_t *, Source array

const SLData t*, Carrier table pointer const SLArrayIndex t, Carrier sine table length Carrier phase pointer SLData t*, SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer const SLArrayIndex t, Carrier table increment const SLFixData t, Samples per symbol RRCF Rx I delay pointer SLData t*, RRCF Rx I Filter Index pointer SLArrayIndex t*, SLData t*, RRCF Rx Q delay pointer SLArrayIndex t*, RRCF Rx O Filter Index pointer SLData t*, RRCF coefficients pointer const SLArrayIndex t, RRCF length

const SLArrayIndex_t) RRCF enable / disable switch

DESCRIPTION

This function QPSK demodulates the data stream and returns the demodulated di-bit.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

SIF OpskDemodulate must be called prior to using this function.

The Source array length must be a modulo of the number of samples per symbol.

The SigLib QPSK functions use a simple mapping of the input nibble to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application. For details on differentially decoding the data, see the SDS QpskDifferentialDecode function.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SIF QpskDemodulate, SDA QpskModulate, SDA QpskDemodulateDebug

SLFixData t SDA QpskDemodulateDebug (const SLData t *, Source pointer

const SLData t*, Carrier table pointer const SLArrayIndex t, Carrier sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer const SLArrayIndex t, Carrier table increment const SLFixData t, Samples per symbol RRCF Rx I delay pointer SLData t*, RRCF Rx I Filter Index pointer SLArrayIndex t*, RRCF Rx Q delay pointer SLData t*, SLArrayIndex t*, RRCF Rx Q Filter Index pointer RRCF Coeffs pointer SLData t*, const SLArrayIndex t, RRCF length const SLArrayIndex t, RRCF enable / disable switch SLData t*, Eye samples pointer Pointer to constellation diagram structure SLComplexRect s *)

DESCRIPTION

This function QPSK demodulates the data stream and returns the demodulated di-bit, whilst also providing additional debug information - an eye diagram and a constellation diagram.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

SIF QpskDemodulate must be called prior to using this function.

The Source array length and the eye samples Destination array length must be a modulo of the number of samples per symbol. The constellation point returns a single point per symbol.

The SigLib QPSK functions use a simple mapping of the input nibble to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application. For details on differentially decoding the data, see the SDS QpskDifferentialDecode function.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SIF_QpskDemodulate, SDA_QpskModulate, SDA_QpskDemodulateDebug

SLFixData_t SDS_QpskDifferentialEncode (const SLFixData_t, Transmit di-bit SLFixData_t *) Previous transmit quadrant pointer

DESCRIPTION

This function differentially encodes the input di-bit for the QPSK modulation function and returns the encoded di-bit.

NOTES ON USE

Differential encoding is used to overcome phase errors in the receiver i.e. "false lock".

The SigLib QPSK functions use a simple mapping of the input di-bit to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SDA_QpskModulate, SDA_QpskDemodulate, SDA_QpskDemodulateDebug, SDS_QpskDifferentialDecode, SIF_DifferentialEncoder, SDS_DifferentialEncode, SDS_DifferentialDecode, SUF_DifferentialEncoderArrayAllocate

SLFixData_t SDS_QpskDifferentialDecode (const SLFixData_t, Mapped receive di-bit

SLFixData t*)

Previous receive di-bit pointer

DESCRIPTION

This function differentially decodes the input di-bit (returned from the QPSK demodulation function) and returns the decoded di-bit.

NOTES ON USE

Differential encoding is used to overcome phase errors in the receiver i.e. "false lock".

The SigLib QPSK functions use a simple mapping of the input di-bit to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application.


This function processes the data word, least significant bit first.

CROSS REFERENCE

SDA_QpskModulate, SDA_QpskDemodulate, SDA_QpskDemodulateDebug, SDS_QpskDifferentialEncode, SIF_DifferentialEncoder, SDS_DifferentialEncode, SDS_DifferentialDecode, SUF_DifferentialEncoderArrayAllocate

Differential Encoder Introduction

The differential encoder and decoder functions use look-up-tables to efficiently encode and decode the source words. The encoder and decoder lookup tables can be created for any arbitrary mapping function. The look-up tables are 2D arrays, with the following square structure:



As an example, the following look-up-tables implement the V series QPSK standard differential encoder / decoder functions:

Encoder:

1, 3, 0, 2, 3, 2, 1, 0, 0, 1, 2, 3, 1

Decoder:

2, 3, 0, 1, 0, 2, 1, 3, 3, 1, 2, 0, 1, 0, 3, 2

void SIF_DifferentialEncoder (SLArrayIndex_t *, Pointer to encoder look-up-table SLArrayIndex_t *, Pointer to decoder look-up-table const SLFixData_t) Word length to encode / decode

DESCRIPTION

This function generates the encoder and decoder look-up-tables for the following encoding function, with the given number of bits for the input and output words:

$$y[n] = (x[n] - x[n-1]) % M$$

NOTES ON USE

Differential encoding is used to overcome phase errors in the receiver i.e. "false lock".

CROSS REFERENCE

SDA_QpskModulate, SDA_QpskDemodulate, SDA_QpskDemodulateDebug, SDS_QpskDifferentialEncode, SDS_DifferentialEncode, SDS_DifferentialEncode, SUF_DifferentialEncoderArrayAllocate

SLFixData t SDS DifferentialEncode (const SLFixData t, Source word to encode

SLFixData t*, Encoder / decoder table

const SLFixData_t, Word length to encode / decode const SLFixData_t, Bit mask for given word length SLFixData_t*) Previously encoded word

DESCRIPTION

This function differentially encodes the input data according to the mapping in the supplied look-up-table.

NOTES ON USE

CROSS REFERENCE

SDA_QpskModulate, SDA_QpskDemodulate, SDA_QpskDemodulateDebug, SDS_QpskDifferentialEncode, SDS_QpskDifferentialDecode, SIF_DifferentialEncoder, SDS_DifferentialDecode, SUF_DifferentialEncoderArrayAllocate

SLFixData t SDS DifferentialDecode (const SLFixData t, Source word to encode

SLFixData t*, Encoder / decoder table

const SLFixData_t, Word length to encode / decode const SLFixData_t, Bit mask for given word length SLFixData_t*) Previously decoded word

DESCRIPTION

This function differentially decodes the data according to the mapping in the supplied look-up-table..

NOTES ON USE

CROSS REFERENCE

SDA_QpskModulate, SDA_QpskDemodulate, SDA_QpskDemodulateDebug, SDS_QpskDifferentialEncode, SIF_DifferentialEncoder, SDS_DifferentialEncode, SUF_DifferentialEncoderArrayAllocate

void SIF FskModulate (SLData t*, Carrier sinusoid table

const SLData_t, Carrier phase increment per sample

(radians / 2π)

const SLArrayIndex t) Sine table length

DESCRIPTION

This function initialises the FSK modulation and demodulation functions SDA_FskModulate and SDA_FskDemodulate. This function also initialises the continuous phase FSK modulation and function SDA_CpfskModulate.

NOTES ON USE

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application.

This function processes the data word, LSB first.

CROSS REFERENCE

SDA_FskModulateByte, SDA_FskDemodulateByte, SDA_CpfskModulateByte, SDA_FskModulate, SDA_FskDemodulate, SDA_CpfskModulate

void SDA FskModulateByte (SLFixData t, Source data byte

SLData_t *, Destination data pointer const SLData_t *, Carrier sinusoid table SLData_t *, Level '1' carrier phase SLData_t *, Level '0' carrier phase

const SLData_t, Level '1' carrier phase increment const SLData_t, Level '0' carrier phase increment

const SLFixData_t, Samples per symbol const SLArrayIndex_t) Sine table length

DESCRIPTION

This function FSK modulates one signal with a data stream, specified in the source byte. The function modulates a '1' bit or a '0' bit to the specified frequency.

NOTES ON USE

The Destination array length must be equal to or greater than the number of samples per symbol x the number of bits in the binary input word. This function modulates a single cosine wave.

SIF FskModulate must be called prior to using this function.

The phase parameters must be initialised to SIGLIB ZERO in the calling function.

This function processes the data word, LSB first.

CROSS REFERENCE

SIF_FskModulate, SDA_FskDemodulateByte, SDA_CpfskModulateByte, SDA_FskModulate, SDA_FskDemodulate, SDA_CpfskModulate

SLFixData_t SDA_FskDemodulateByte (const SLData_t *, Source data pointer

const SLData_t *, Level '1' filter pointer const SLData_t *, Level '0' filter pointer

const SLArrayIndex t, Filter length

const SLFixData t) Samples per symbol

DESCRIPTION

This function demodulates an FSK or a continuous phase FSK data stream and returns the demodulated byte.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

The filters are band pass filters centred on the frequencies of the two carrier signals. These can be generated by using the function SIF_FirBandPassFilter. SIF_FirBandPassFilter generates a linear phase filter so the delay through the filter is equal to the middle sample in the coefficient array. So if the filter is 27 coefficients long then the middle sample is number 14 – C index 13. This should be used to align the input data with the output demodulated symbol – a phase offset to the input data may have to be used to correctly align the output symbols.

This function processes the data word, LSB first.

CROSS REFERENCE

 $SIF_FskModulate, SDA_FskModulateByte, SDA_CpfskModulateByte, SDA_FskModulate, SDA_FskModulate, SDA_FskModulate$

void SDA CpfskModulateByte (SLFixData t, Source data byte SLData t*, Destination data pointer const SLData t*, Carrier sinusoid table SLData t*, Carrier phase const SLData t, Level '1' carrier phase increment const SLData t, Level '0' carrier phase increment Samples per symbol const SLFixData t, Sine table length const SLArrayIndex t)

DESCRIPTION

This function FSK modulates one signal with a data stream, specified in the source byte and maintains the phase across the symbol boundaries. The function modulates a '1' bit or a '0' bit to the specified frequency.

NOTES ON USE

The Destination array length must be equal to or greater than the number of samples per symbol x the number of bits in the binary input word. This function modulates a single cosine wave.

SIF FskModulate must be called prior to using this function.

The phase parameter must be initialised to SIGLIB ZERO in the calling function.

This function processes the data word, LSB first.

CROSS REFERENCE

SIF_FskModulate, SDA_FskModulateByte, SDA_FskDemodulateByte, SDA FskModulate, SDA FskModulate

```
void SDA FskModulate (SLFixData t,
                                           Source data bit
       SLData t*,
                                           Destination data pointer
       const SLData t*,
                                           Carrier sinusoid table
       SLData t*,
                                           Level '1' carrier phase
       SLData t*,
                                           Level '0' carrier phase
       const SLData t,
                                           Level '1' carrier phase increment
                                           Level '0' carrier phase increment
       const SLData t,
                                           Samples per symbol
       const SLFixData t,
       const SLArrayIndex_t)
                                           Sine table length
```

DESCRIPTION

This function FSK modulates one signal with a data bit, specified in the source bit. The function modulates a '1' bit or a '0' bit to the specified frequency.

NOTES ON USE

The Destination array length must be equal to or greater than the number of samples per symbol. This function modulates a single cosine wave.

SIF_FskModulate must be called prior to using this function.

The phase parameters must be initialised to SIGLIB ZERO in the calling function.

CROSS REFERENCE

```
SIF_FskModulate, SDA_FskModulateByte, SDA_FskDemodulateByte, SDA CpfskModulateByte, SDA FskDemodulate, SDA CpfskModulate
```

SLFixData_t SDA_FskDemodulate (const SLData_t *, Source data pointer

const SLData_t *, Level '1' filter pointer const SLData_t *, Level '0' filter pointer

const SLArrayIndex t, Filter length

const SLFixData t) Samples per symbol

DESCRIPTION

This function demodulates an FSK or a continuous phase FSK data stream and returns the demodulated bit.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

The filters are band pass filters centred on the frequencies of the two carrier signals. These can be generated by using the function SIF_FirBandPassFilter. SIF_FirBandPassFilter generates a linear phase filter so the delay through the filter is equal to the middle sample in the coefficient array. So if the filter is 27 coefficients long then the middle sample is number 14 – C index 13. This should be used to align the input data with the output demodulated symbol – a phase offset to the input data may have to be used to correctly align the output symbols.

CROSS REFERENCE

SIF_FskModulate, SDA_FskModulateByte, SDA_FskDemodulateByte, SDA CpfskModulateByte, SDA FskModulate, SDA CpfskModulate

void SDA CpfskModulate (SLFixData t, Source data bit SLData t*, Destination data pointer const SLData t*, Carrier sinusoid table SLData t*, Carrier phase const SLData t, Level '1' carrier phase increment const SLData t, Level '0' carrier phase increment Samples per symbol const SLFixData t, Sine table length const SLArrayIndex t)

DESCRIPTION

This function FSK modulates one signal with a data bit, specified in the source bit and maintains the phase across the symbol boundaries. The function modulates a '1' bit or a '0' bit to the specified frequency.

NOTES ON USE

The Destination array length must be equal to or greater than the number of samples per symbol. This function modulates a single cosine wave.

SIF FskModulate must be called prior to using this function.

The phase parameter must be initialised to SIGLIB ZERO in the calling function.

CROSS REFERENCE

SIF_FskModulate, SDA_FskModulateByte, SDA_FskDemodulateByte, SDA CpfskModulateByte, SDA FskModulate, SDA FskDemodulate

void SIF Qam16Modulate (SLData t*, Carrier table pointer const SLData t, Carrier phase increment per sample (radians / 2π) Carrier sine table length const SLArrayIndex t, Carrier phase pointer SLData t*, SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer RRCF Tx. I delay pointer SLData t*, RRCF Tx. I Filter Index pointer SLArrayIndex t*, RRCF Tx. Q delay pointer SLData t*, RRCF Tx. Q Filter Index pointer SLArrayIndex t*, SLData t*, RRCF coefficients pointer const SLData t, **RRCF** Period const SLData t, RRCF Roll off const SLArrayIndex t, RRCF length RRCF enable / disable switch const SLArrayIndex t)

DESCRIPTION

This function initialises the QAM-16 modulation function SDA_Qam16Modulate. The function provides for the initialisation of an optional square root raised cosine filter.

The QAM-16 modulation and demodulation functions uses the following bit mapping for the constellation diagram.

0x0	0x1		0x2	0x3
0x4	0x5	<u> </u>	0x6	0x7
0x8	0x9		0xa	0xb
0xc	0xd		0xe	0xf

Different QAM-16 variations can be supported by remapping the bits appropriately in the Tx and Rx constellation diagram structures.

NOTES ON USE

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application.

The carrier frequency parameter should be normalised to 1.0 Hz, as with most SigLib functions.

CROSS REFERENCE

SDA_Qam16Modulate, SIF_Qam16Demodulate, SDA_Qam16Demodulate, SDA_Qam16DemodulateDebug

Source data nibble void SDA Qam16Modulate (const SLFixData t,

> SLData t*, Destination array const SLData t*, Carrier table pointer const SLArrayIndex_t, Carrier sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer Carrier table increment const SLArrayIndex t, const SLFixData t, Samples per symbol SLData t*, RRCF Tx I delay pointer RRCF Tx I Filter Index pointer SLArrayIndex t*, RRCF Tx Q delay pointer SLData t*, RRCF Tx Q Filter Index pointer SLArrayIndex t*, SLData t*, RRCF coefficients pointer const SLArrayIndex t, RRCF length

const SLArrayIndex t) RRCF enable / disable switch

DESCRIPTION

This function QAM-16 modulates one symbol of the carrier with a nibble of source data.

NOTES ON USE

The Destination array length must be a modulo of the number of samples per symbol.

SIF Qam16Modulate must be called prior to using this function.

The SigLib QAM-16 functions use a simple mapping of the input nibble to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application. For details on differentially encoding the data, see the SDA Qam16DifferentialEncode function.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SIF Qam16Modulate, SIF Qam16Demodulate, SDA Qam16Demodulate, SDA Qam16DemodulateDebug

void SIF Qam16Demodulate (SLData t*, Carrier table pointer const SLData t, Carrier phase increment per sample (radians / 2π) Carrier sine table length const SLArrayIndex t, SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer RRCF Rx I delay pointer SLData t*, RRCF Rx I Filter Index pointer SLArrayIndex t*, RRCF Rx Q delay pointer SLData t*, SLArrayIndex t*, RRCF Rx Q Filter Index pointer SLData t*, RRCF coefficients pointer const SLData t, **RRCF** Period const SLData t, RRCF Roll off const SLArrayIndex t, RRCF length RRCF enable / disable switch const SLArrayIndex t)

DESCRIPTION

This function initialises the QAM-16 demodulation function SDA_Qam16Demodulate. The function provides for the initialisation of an optional square root raised cosine filter.

The QAM-16 modulation and demodulation functions uses the following bit mapping for the constellation diagram.

0x0	0x1		0x2	0x3
0x4	0x5		0x6	0x7
0x8	0x9	 	0xa	0xb
0xc	0xd		0xe	0xf

Different QAM-16 variations can be supported by remapping the bits appropriately in the Tx and Rx constellation diagram structures.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application.

CROSS REFERENCE

SIF_Qam16Modulate, SDA_Qam16Modulate, SDA_Qam16Demodulate, SDA_Qam16DemodulateDebug

SLFixData t SDA Qam16Demodulate (const SLData t*, Source array

const SLData t*, Carrier table pointer const SLArrayIndex t, Carrier sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer const SLArrayIndex t, Carrier table increment const SLFixData t, Samples per symbol RRCF Rx I delay pointer SLData t*, RRCF Rx I Filter Index pointer SLArrayIndex t*, RRCF Rx Q delay pointer SLData t*, SLArrayIndex t*, RRCF Rx O Filter Index pointer RRCF coefficients pointer SLData t*, const SLArrayIndex t, RRCF length

const SLArrayIndex t) RRCF enable / disable switch

DESCRIPTION

This function QAM-16 demodulates the data stream and returns the demodulated nibble.

NOTES ON USE

Here This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

SIF Qam16Demodulate must be called prior to using this function.

The Source array length must be a modulo of the number of samples per symbol.

The SigLib QAM-16 functions use a simple mapping of the input nibble to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application. For details on differentially decoding the data, see the SDA Qam16DifferentialDecode function.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SIF Qam16Modulate, SDA Qam16Modulate, SIF Qam16Demodulate, SDA Qam16DemodulateDebug

SLFixData_t SDA_Qam16DemodulateDebug (const SLData_t *, Source pointer

const SLData t*, Carrier table pointer const SLArrayIndex t, Carrier sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer const SLArrayIndex t, Carrier table increment const SLFixData t, Samples per symbol RRCF Rx I delay pointer SLData t*, RRCF Rx I Filter Index pointer SLArrayIndex t*, RRCF Rx Q delay pointer SLData t*, SLArrayIndex t*, RRCF Rx Q Filter Index pointer RRCF Coeffs pointer SLData t*, const SLArrayIndex t, RRCF length const SLArrayIndex t, RRCF enable / disable switch SLData t*, Eye samples pointer Pointer to constellation diagram structure SLComplexRect s *)

DESCRIPTION

This function QAM-16 demodulates the data stream and returns the demodulated nibble, whilst also providing additional debug information - an eye diagram and a constellation diagram.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

SIF Qam16Demodulate must be called prior to using this function.

The Source array length and the eye samples array length must be a modulo of the number of samples per symbol. The constellation point returns a single point per symbol.

The SigLib QAM-16 functions use a simple mapping of the input nibble to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application. For details on differentially decoding the data, see the SDA_Qam16DifferentialDecode function.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SIF_Qam16Modulate, SDA_Qam16Modulate, SIF_Qam16Demodulate, SDA_Qam16DemodulateDebug

SLFixData_t SDA_Qam16DifferentialEncode (const SLFixData_t, SLFixData_t *)

Previous Tx nibble pointer

Tx nibble

DESCRIPTION

This function differentially encodes the input nibble for the QAM-16 modulation function and returns the encoded nibble.

NOTES ON USE

Differential encoding is used to overcome phase errors in the receiver i.e. "false lock".

The SigLib QAM-16 functions use a simple mapping of the input nibble to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SDA_Qam16Modulate, SDA_Qam16Demodulate, SDA_Qam16DemodulateDebug, SDA_Qam16DifferentialDecode

SLFixData_t SDA_Qam16DifferentialDecode (const SLFixData_t, Mapped Rx nibble

SLFixData_t *) Previous Rx nibble pointer

DESCRIPTION

This function differentially decodes the input nibble (returned from the QAM-16 demodulation function) and returns the decoded nibble.

NOTES ON USE

Differential encoding is used to overcome phase errors in the receiver i.e. "false lock".

The SigLib QAM-16 functions use a simple mapping of the input nibble to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application.

This function processes the data word, least significant bit first.

CROSS REFERENCE


SIF_Qam16Modulate, SDA_Qam16Modulate, SDA_Qam16Demodulate, SDA_Qam16DemodulateDebug, SDA_Qam16DifferentialEncode

void SIF OpskModulate (SLData t*, Carrier table pointer const SLData t, Carrier phase increment per sample (radians / 2π) const SLArrayIndex t, Sine table length Carrier phase pointer SLData t*, SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer RRCF Tx I delay pointer SLData t*, RRCF Tx I Filter Index pointer SLArrayIndex t*, RRCF Tx Q delay pointer SLData t*, RRCF Tx Q Filter Index pointer SLArrayIndex t*, SLData t*, RRCF Coeffs pointer const SLData t, **RRCF** Period const SLData t, RRCF Roll off const SLArrayIndex t, RRCF size const SLArrayIndex t) RRCF enable / disable switch

DESCRIPTION

This function initialises the 8-PSK (Octal OPSK) modulation function SDA_OpskModulate. The function provides for the initialisation of an optional square root raised cosine filter.

The 8-PSK modulation and demodulation functions uses the following bit mapping for the constellation diagram.



Different 8-PSK variations can be supported by remapping the bits appropriately in the Tx and Rx constellation diagram structures.

NOTES ON USE

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application.

The carrier frequency parameter should be normalised to 1.0 Hz, as with most SigLib functions.

CROSS REFERENCE

SDA_OpskModulate, SIF_OpskDemodulate, SDA_OpskDemodulate, SDA OpskDemodulateDebug

void SDA_OpskModulate (const SLFixData_t, Tx tri-bit,

SLData_t *, Destination data array pointer

const SLData t*, Carrier table pointer const SLArrayIndex_t, Sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer const SLArrayIndex t, Carrier table increment const SLFixData t, Samples per symbol RRCF Tx I delay pointer SLData t*,

SLArrayIndex_t *, RRCF Tx I Filter Index pointer

SLData t*, RRCF Tx T The index pointer

SLArrayIndex_t *, RRCF Tx Q Filter Index pointer

SLData t*, RRCF Coeffs pointer

const SLArrayIndex_t, RRCF size

const SLArrayIndex t) RRCF enable / disable switch

DESCRIPTION

This function 8-PSK modulates one symbol of the carrier with a tribit of source data.

NOTES ON USE

The Destination array length must be a modulo of the number of samples per symbol.

SIF OpskModulate must be called prior to using this function.

The SigLib 8-PSK functions use a simple mapping of the input tribit to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application.

This function processes the data word, least significant bit first.

CROSS REFERENCE


 $SIF_OpskModulate, SIF_OpskDemodulate, SDA_OpskDemodulate, SDA_OpskDemodulateDebug$

void SIF OpskDemodulate (SLData t*, Carrier table pointer const SLData t, Carrier phase increment per sample (radians / 2π) const SLArrayIndex t, Sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer RRCF Rx I delay pointer SLData t*, RRCF Rx I Filter Index pointer SLArrayIndex t*, RRCF Rx Q delay pointer SLData t*, RRCF Rx Q Filter Index pointer SLArrayIndex t*, SLData t*, RRCF Coeffs pointer **RRCF** Period const SLData t, const SLData t, RRCF Roll off const SLArrayIndex t, RRCF size const SLArrayIndex t) RRCF enable / disable switch

DESCRIPTION

This function initialises the 8-PSK demodulation function SDA_OpskDemodulate. The function provides for the initialisation of an optional square root raised cosine filter.

The 8-PSK modulation and demodulation functions uses the following bit mapping for the constellation diagram.



Different 8-PSK variations can be supported by remapping the bits appropriately in the Tx and Rx constellation diagram structures.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM/8-PSK signals is to use the CostasQamDemodulate functions.

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application.

CROSS REFERENCE

 $SIF_OpskModulate, SDA_OpskModulate, SDA_OpskDemodulate, SDA_OpskDemodulateDebug$

SLFixData t SDA OpskDemodulate (const SLData t *, Source data pointer

const SLData t*, Carrier table pointer const SLArrayIndex t, Sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s*, Magnitude pointer SLData t*, DemodErrorArray const SLArrayIndex t, Carrier table increment const SLFixData t, Samples per symbol RRCF Rx I delay pointer SLData t*, RRCF Rx I Filter Index pointer SLArrayIndex t*, RRCF Rx Q delay pointer SLData t*, RRCF Rx Q Filter Index pointer SLArrayIndex t*, SLData t*, RRCF Coeffs pointer const SLArrayIndex t, RRCF size const SLArrayIndex t) RRCF enable / disable switch

DESCRIPTION

This function 8-PSK (OPSK) demodulates the data stream and returns the demodulated tribit.

NOTES ON USE

Here This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM/8-PSK signals is to use the CostasQamDemodulate functions.

SIF OpskDemodulate must be called prior to using this function.

The Source array length must be a modulo of the number of samples per symbol.

The SigLib 8PSK (OPSK) functions use a simple mapping of the input tribit to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SIF OpskModulate, SDA OpskModulate, SIF OpskDemodulate, SDA OpskDemodulateDebug

SLFixData t SDA OpskDemodulateDebug (const SLData_t *, Source data pointer

const SLData t*, Carrier table pointer const SLArrayIndex t, Sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer SLData t*, DemodErrorArray const SLArrayIndex t, Carrier table increment Samples per symbol const SLFixData t, RRCF Rx I delay pointer SLData t*, SLArrayIndex t*, RRCF Rx I Filter Index pointer SLData t*, RRCF Rx Q delay pointer SLArrayIndex t*, RRCF Rx Q Filter Index pointer SLData t*, RRCF Coeffs pointer RRCF size const SLArrayIndex t, RRCF enable / disable switch const SLArrayIndex t, SLData t*, Eye samples pointer

SLComplexRect s *) Pointer to constellation diagram structure

DESCRIPTION

This function 8-PSK demodulates the data stream and returns the demodulated tribit, whilst also providing additional debug information - an eye diagram and a constellation diagram.

NOTES ON USE

Here This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM/8-PSK signals is to use the CostasQamDemodulate functions.

SIF OpskDemodulate must be called prior to using this function.

The Source array length and the eye samples array length must be a modulo of the number of samples per symbol. The constellation point returns a single point per symbol.

The SigLib 8PSK (OPSK) functions use a simple mapping of the input tribit to the transmitted constellation point. This mapping allows a flexible re-mapping of the points for the required application.

This function processes the data word, least significant bit first.

CROSS REFERENCE

SIF OpskModulate, SDA OpskModulate, SIF OpskDemodulate, SDA OpskDemodulateDebug

void SIF_BpskModulate (SLData_t *, const SLData_t, Carrier table Carrier phase increment per sample (radians $/ 2\pi$)
SLData t *, Pointer to carrier table Carrier phase increment per sample (radians $/ 2\pi$)

SLData_t *, Pointer to the sample count const SLArrayIndex t) Carrier table length

DESCRIPTION

This function initialises the BPSK modulation functions SDA_BpskModulate and SDA_BpskModulateByte.

NOTES ON USE

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application.

CROSS REFERENCE

SDA_BpskModulate, SDA_BpskModulateByte, SIF_BpskDemodulate, SDA_BpskDemodulate, SDA_BpskDemodulateDebug.

void SDA_BpskModulate (SLFixData_t, Modulating bit SLData_t *, Modulated signal Carrier table pointer SLData_t *, Carrier phase pointer const SLArrayIndex_t, Samples per symbol const SLData_t, Carrier phase increment pointer const SLArrayIndex t) Sine table size

DESCRIPTION

This function BPSK modulates one signal with a data stream, specified in the source bit. The function modulates a '1' bit or a '0' bit to the required phase.

NOTES ON USE

The Destination array length must be equal to or greater than the number of samples per bit. This function modulates a single cosine wave.

SIF_BpskModulate must be called prior to using this function.

The phase parameters must be initialised to SIGLIB ZERO in the calling function.

CROSS REFERENCE

SIF_BpskModulate, SDA_BpskModulateByte, SIF_BpskDemodulate, SDA_BpskDemodulate, SDA_BpskDemodulateDebug.

void SDA_BpskModulateByte (SLArrayIndex_t, Modulating byte

SLData_t *, Modulated signal const SLData_t *, Carrier table pointer SLData_t *, Carrier phase pointer const SLArrayIndex_t, Samples per symbol

const SLData t, Carrier phase increment pointer

const SLArrayIndex t) Sine table size

DESCRIPTION

This function BPSK modulates one signal with a data stream, specified in the source byte. The function modulates a '1' bit or a '0' bit to the required phase.

NOTES ON USE

The Destination array length must be equal to or greater than the number of samples per symbol x the number of bits in the binary input word. This function modulates a single cosine wave.

SIF BpskModulate must be called prior to using this function.

The phase parameters must be initialised to SIGLIB ZERO in the calling function.

This function processes the data word, LSB first.


CROSS REFERENCE

SIF_BpskModulate, SDA_BpskModulate, SIF_BpskDemodulate, SDA_BpskDemodulate, SDA_BpskDemodulateDebug.

void SIF BpskDemodulate (SLData t*, VCO phase SLData t, VCO Fast sine look up table const SLArrayIndex t, VCO Fast sine look up table size Carrier phase increment per sample const SLData t, (radians / 2π) SLData t*, Pointer to loop filter 1 state Pointer to loop filter 1 index SLArrayIndex t*, Pointer to loop filter 2 state SLData t*, SLArrayIndex t*, Pointer to loop filter 2 index Pointer to loop filter coefficients SLData t*, const SLArrayIndex t, Loop filter length SLData t*, Pointer to loop filter state SLData t*, Pointer to delayed sample SLArrayIndex t*, Pointer to Rx sample clock SLData t*) Pointer to sample sum

DESCRIPTION

This function initialises the BPSK demodulation functions SDA_BpskDemodulate and SDA_BpskDemodulateDebug. The BPSK demodulation functions use a Costas loop, the block diagram for the Costas loop is shown in the following diagram:



NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

The loop filters 1 and 2 are both FIR and must be of odd order. The loop filter is a one-pole filter, with a single coefficient and state.

One issue that is critical to demodulating a data stream is knowing when an individual symbol starts and stops. The filters within the Costas loop of the demodulator have delays that must be accounted for. This is handled in the receive sample clock parameter. In order to find out what the exact timing of the symbols is it is handy to use the SDA_BpskDemodulateDebug function, which saves the output of the real path Costas loop filter.

In order to allocate the Costas loop look up table it is necessary to use the SUF_CostasLoopArrayAllocate() to malloc the look-up-table memory, rather than SUF_VectorArrayAllocate().

CROSS REFERENCE

SIF_BpskModulate, SDA_BpskModulateByte, SDA_BpskDemodulate, SDA_BpskDemodulateDebug.

SLFixData_t SDA_BpskDemodulate (const SLData_t *, Source data pointer

SLData_t *, VCO phase
const SLData_t, VCO modulation index
SLData_t *, VCO Fast sine look up table
const SLArrayIndex t, VCO Fast sine look up table size

const SLData_t, Carrier frequency

SLData_t *, Pointer to loop filter 1 state
SLArrayIndex_t *, Pointer to loop filter 1 index
SLData_t *, Pointer to loop filter 2 state
SLArrayIndex_t *, Pointer to loop filter 2 index
const SLData_t *, Pointer to loop filter coefficients

const SLArrayIndex t, Loop filter length

SLData_t *, Pointer to loop filter state const SLData_t, Loop filter coefficient SLData_t *, Pointer to delayed sample

const SLArrayIndex_t, Sample size

SLArrayIndex_t *, Pointer to Rx sample clock SLData_t *) Pointer to sample sum

DESCRIPTION

This function BPSK demodulates one symbol of the source signal and returns the demodulated bit.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

SIF_BpskDemodulate must be called prior to using this function. This function uses the Costas loop function. For further details, please read the SIF_CostasLoop, SDS_CostasLoop and SDA_CostasLoop function documentation.

In order to allocate the Costas loop look up table it is necessary to use the SUF_CostasLoopArrayAllocate() to malloc the look-up-table memory, rather than SUF_VectorArrayAllocate().

CROSS REFERENCE

SIF_BpskModulate, SDA_BpskModulateByte, SIF_BpskDemodulate, SDA_BpskDemodulateDebug.

SLFixData_t SDA_BpskDemodulateDebug (const SLData_t *, Source data pointer

SLData_t *, VCO phase
const SLData_t, VCO modulation index
SLData_t *, VCO Fast sine look up table
const SLArrayIndex_t, VCO Fast sine look up table size

const SLData t, Carrier frequency

SLData_t *, Pointer to loop filter 1 state
SLArrayIndex_t *, Pointer to loop filter 1 index
SLData_t *, Pointer to loop filter 2 state
SLArrayIndex_t *, Pointer to loop filter 2 index
const SLData_t *, Pointer to loop filter coefficients

const SLArrayIndex t, Loop filter length

SLData_t *, Pointer to loop filter state const SLData_t, Loop filter coefficient SLData_t *, Pointer to delayed sample

const SLArrayIndex t, Sample size

SLArrayIndex_t *, Pointer to Rx sample clock SLData t *, Pointer to sample sum

SLData t*) Pointer to Costas loop filter output

DESCRIPTION

This function BPSK demodulates one symbol of the source signal and returns the demodulated bit. It also provides the output of the real path loop filter output, which can be used to extract the symbol timing, which is used in the sample counter to decide when the individual symbols start and stop.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

SIF_BpskDemodulate must be called prior to using this function. This function uses the Costas loop. For further details, please read the SIF_CostasLoop, SDS_CostasLoop and SDA_CostasLoop function documentation. In order to allocate the Costas loop look up table it is necessary to use the SUF_CostasLoopArrayAllocate() to malloc the look-up-table memory, rather than SUF_VectorArrayAllocate().

CROSS REFERENCE

SIF_BpskModulate, SDA_BpskModulateByte, SIF_BpskDemodulate, SDA_BpskDemodulate.

void SIF_DpskModulate (SLData_t *, const SLData_t, Carrier phase increment per sample (radians / 2π)

SLData_t *, Pointer to carrier table (radians / 2π)

SLData_t *, Pointer to the sample count (sine carrier table length (sLData_t *) Pointer to modulation phase value)

DESCRIPTION

This function initialises the DPSK modulation functions SDA_DpskModulate and SDA_DpskModulateByte.

DPSK uses the following phase changes for '0' or '1' bits:

- 0 Phase change 180 degrees
- 1 Phase change 0 degrees

NOTES ON USE

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application.

CROSS REFERENCE

SDA_DpskModulate, SDA_DpskModulateByte, SIF_DpskDemodulate, SDA_DpskDemodulate, SDA_DpskDemodulateDebug.

void SDA DpskModulate (SLFixData t, Modulating bit SLData t*, Modulated signal const SLData t*, Carrier table pointer SLData t*, Carrier phase pointer const SLArrayIndex t, Samples per symbol const SLData t, Carrier phase increment pointer const SLArrayIndex t, Sine carrier table length Pointer to modulation phase value SLData t*)

DESCRIPTION

This function DPSK modulates one signal with a data stream, specified in the source bit. The function modulates a '1' bit or a '0' bit to the required phase.

NOTES ON USE

The Destination array length must be equal to or greater than the number of samples per bit. This function modulates a single cosine wave.

SIF DpskModulate must be called prior to using this function.

The phase parameters must be initialised to SIGLIB ZERO in the calling function.

CROSS REFERENCE

SIF_DpskModulate, SDA_DpskModulateByte, SIF_DpskDemodulate, SDA_DpskDemodulate, SDA_DpskDemodulateDebug.

void SDA DpskModulateByte (SLFixData t, Modulating byte SLData t*, Modulated signal const SLData t*, Carrier table pointer SLData t*, Carrier phase pointer const SLArrayIndex t, Samples per symbol const SLData t, Carrier phase increment pointer Sine carrier table length const SLArrayIndex t, Pointer to modulation phase value SLData t*)

DESCRIPTION

This function DPSK modulates one signal with a data stream, specified in the source byte. The function modulates a '1' bit or a '0' bit to the required phase.

NOTES ON USE

The Destination array length must be equal to or greater than the number of samples per symbol x the number of bits in the binary input word. This function modulates a single cosine wave.

SIF_DpskModulate must be called prior to using this function.

The phase parameters must be initialised to SIGLIB ZERO in the calling function.

This function processes the data word, LSB first.

CROSS REFERENCE

SIF_DpskModulate, SDA_DpskModulate, SIF_DpskDemodulate, SDA_DpskDemodulate, SDA_DpskDemodulateDebug.

void SIF DpskDemodulate (SLData t*, VCO phase SLData t, VCO Fast sine look up table const SLArrayIndex t, VCO Fast sine look up table size const SLData t, Carrier phase increment per sample (radians / 2π) SLData t*, Pointer to loop filter 1 state SLArrayIndex t*, Pointer to loop filter 1 index Pointer to loop filter 2 state SLData t*, SLArrayIndex t*, Pointer to loop filter 2 index Pointer to loop filter coefficients SLData t*, Loop filter length const SLArrayIndex t, SLData t*, Pointer to loop filter state Pointer to delayed sample SLData t*, SLArrayIndex t*, Pointer to Rx sample clock SLData t*) Pointer to sample sum

DESCRIPTION

This function initialises the function SDA_DpskDemodulate. DPSK modulates the phase by 180 degrees for a binary '0' or 0 degrees for a binary '1'.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

The loop filters 1 and 2 are both FIR and must be of odd order. The loop filter is a one-pole filter, with a single coefficient and state.

One issue that is critical to demodulating a data stream is knowing when an individual symbol starts and stops. The filters within the Costas loop of the demodulator have delays that must be accounted for. This is handled in the receive sample clock parameter. In order to find out what the exact timing of the symbols is it is handy to use the SDA_DpskDemodulateDebug function, which saves the output of the real path Costas loop filter.

In order to allocate the Costas loop look up table it is necessary to use the SUF_CostasLoopArrayAllocate() to malloc the look-up-table memory, rather than SUF VectorArrayAllocate().

CROSS REFERENCE

SIF_DpskModulate, SDA_DpskModulate, SDA_DpskModulateByte, SDA_DpskDemodulate, SDA_DpskDemodulateDebug.

SLFixData_t SDA_DpskDemodulate (const SLData_t *, Source data pointer

SLData_t *, VCO phase

const SLData_t, VCO modulation index
SLData_t *, VCO Fast sine look up table
const SLArrayIndex t, VCO Fast sine look up table size

const SLData_t, Carrier frequency

SLData_t *, Pointer to loop filter 1 state
SLArrayIndex_t *, Pointer to loop filter 1 index
SLData_t *, Pointer to loop filter 2 state
SLArrayIndex_t *, Pointer to loop filter 2 index
const SLData_t *, Pointer to loop filter coefficients

const SLArrayIndex t, Loop filter length

SLData_t *, Pointer to loop filter state const SLData_t, Loop filter coefficient SLData_t *, Pointer to delayed sample

const SLArrayIndex t, Sample size

SLArrayIndex t*, Pointer to receive sample clock

SLData t*) Pointer to sample sum

DESCRIPTION

This function DPSK demodulates one symbol of the source signal and returns the demodulated bit.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

SIF DpskDemodulate must be called prior to using this function.

This function uses the Costas loop function. For further details, please read the SIF CostasLoop, SDS CostasLoop and SDA CostasLoop function documentation.

In order to allocate the Costas loop look up table it is necessary to use the SUF_CostasLoopArrayAllocate() to malloc the look-up-table memory, rather than SUF VectorArrayAllocate().

CROSS REFERENCE

SIF_DpskModulate, SDA_DpskModulateByte, SIF_DpskDemodulate, SDA_DpskDemodulate, SDA_DpskDemodulateDebug.

SLFixData_t SDA_DpskDemodulateDebug (const SLData_t *, Source data pointer

SLData_t *, VCO phase
const SLData_t, VCO modulation index
SLData_t *, VCO Fast sine look up table
const SLArrayIndex t, VCO Fast sine look up table size

const SLData t, Carrier frequency

SLData_t *, Pointer to loop filter 1 state
SLArrayIndex_t *, Pointer to loop filter 1 index
SLData_t *, Pointer to loop filter 2 state
SLArrayIndex_t *, Pointer to loop filter 2 index
const SLData_t *, Pointer to loop filter coefficients

const SLArrayIndex t, Loop filter length

SLData_t *, Pointer to loop filter state const SLData_t, Loop filter coefficient SLData_t *, Pointer to delayed sample

const SLArrayIndex_t, Sample size

SLArrayIndex_t *, Pointer to Rx sample clock
SLData_t *, Previous received sample sum
SLData_t *) Pointer to filter output data

DESCRIPTION

This function DPSK demodulates one symbol of the source signal and returns the demodulated bit. This function also returns the output of the internal filter for debugging information.

NOTES ON USE

This function is provided for compatibility reasons. The preferred method for demodulating BPSK/QPSK/QAM signals is to use the CostasQamDemodulate functions.

SIF DpskDemodulate must be called prior to using this function.

This function uses the Costas loop function. For further details, please read the SIF_CostasLoop, SDS_CostasLoop and SDA_CostasLoop function documentation.

In order to allocate the Costas loop look up table it is necessary to use the SUF_CostasLoopArrayAllocate() to malloc the look-up-table memory, rather than SUF VectorArrayAllocate().

CROSS REFERENCE

SIF_DpskModulate, SDA_DpskModulateByte, SIF_DpskDemodulate, SDA_DpskDemodulate, SDA_DpskDemodulateDebug.

void SIF_PiByFourDQpskModulate (SLData_t *, Carrier table pointer const SLData t, Carrier phase increment per sample (radians / 2π) const SLArrayIndex_t, Carrier sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer Magnitude pointer SLComplexRect s *, SLData t*, RRCF Tx. I delay pointer SLArrayIndex t*, RRCF Tx. I Filter Index pointer RRCF Tx. Q delay pointer SLData t*, RRCF Tx. Q Filter Index pointer SLArrayIndex t*, SLData t*, RRCF coefficients pointer const SLData t, RRCF Period const SLData t, RRCF Roll off const SLArrayIndex t, RRCF length const SLArrayIndex t, RRCF enable / disable switch SLArrayIndex t*) Pointer to previous output symbol for differential coding

DESCRIPTION

This function initialises the $\pi/4$ Differential QPSK modulation function SDA_PiByFourDQpskModulate.

The function provides for the initialisation of an optional square root raised cosine filter.

NOTES ON USE

The carrier sinusoid table length must be large enough to provide the required frequency resolution for the application.

The carrier frequency parameter should be normalised to 1.0 Hz, as with most SigLib functions.

CROSS REFERENCE SDA PiByFourDQpskModulate

void SDA_PiByFourDQpskModulate (const SLFixData_t, Source data di-bit

SLData t*, Destination array const SLData t*, Carrier table pointer const SLArrayIndex t, Carrier sine table length SLData t*, Carrier phase pointer SLArrayIndex t*, Sample clock pointer SLComplexRect s *, Magnitude pointer const SLArrayIndex t, Carrier table increment const SLFixData t, Samples per symbol RRCF Tx I delay pointer SLData t*, RRCF Tx I Filter Index pointer SLArrayIndex t*, SLData t*, RRCF Tx Q delay pointer RRCF Tx Q Filter Index pointer SLArrayIndex t*, SLData t*, RRCF coefficients pointer

const SLArrayIndex_t, RRCF length

const SLArrayIndex t, RRCF enable / disable switch

SLArrayIndex t*) Pointer to previous output symbol for

differential coding

DESCRIPTION

This function $\pi/4$ Differential QPSK modulates one symbol of the carrier with a di-bit of source data.

NOTES ON USE

The Destination array length must be a modulo of the number of samples per symbol.

SIF PiByFourDQpskModulate must be called prior to using this function.

This function processes the data word, least significant bit first.


CROSS REFERENCE

SIF PiByFourDQpskModulate

void SDS_ChannelizationCode (SLData_t *,Channelization code array const SLArrayIndex_t, Spreading factor const SLArrayIndex_t) Channelization code index

DESCRIPTION

This function generate the 3GPP 25.141 UMTS compliant channelization code for the given spreading factor and code index, as shown in the following diagram:



NOTES ON USE

CROSS REFERENCE


void SDA ComplexQPSKSpread (const SLFixData t, Source sample SLComplexRect s *, Pointer to destination array const SLData t*, In-phase channelization code const SLData t*, Quadrature-phase channelization code const SLData t, In-phase weighting value const SLData t, Quadrature-phase weighting value const SLComplexRect s *, Complex scrambling code const SLArrayIndex t) Spreading factor

DESCRIPTION

This function performs QPSK channelization, weighting, spreading and scrambling according to 3GPP 25.141 on a single di-bit pair. The input di-bits are mapped to the four complex points: (1, 0), (0, 1), (-1, 0) and (0, -1), as shown in the following diagram:

Note : Uses bit ordering as per ITU-T V.8

With the output dibits arranged on the points: (1, 1), (-1, 1), (-1, -1) and (1, -1), as follows:



Note : Uses bit ordering as per ITU-T V.8

NOTES ON USE

The output from this function are the magnitudes of the I, Q carriers, which must be modulated using a function such as SDA_QpskModulate.

CROSS REFERENCE

 $SDA_ComplexQPSKDeSpread, SDA_QpskModulate, SDA_QpskDemodulate.$

SLFixData_t SDA_ComplexQPSKDeSpread (const SLComplexRect_s *,

Pointer to source array
const SLData t*,
In-phase channelization code

const SLData t *, Quadrature-phase channelization code

const SLData t, In-phase weighting value

const SLData t, Quadrature-phase weighting value

const SLComplexRect_s *, Complex scrambling code SLData t *, Demodulator error array

const SLArrayIndex t) Spreading factor

DESCRIPTION

This function performs QPSK de-scrambling, de-spreading de-weighting and dechannelization according to 3GPP 25.141 and generates a single di-bit output pair. The input di-bits are arranged on the four complex points: (1, 1), (-1, 1), (-1, -1) and (1, -1), as shown in the following diagram:

Note: Uses bit ordering as per

ITU-T V.8

With the output dibits arranged on the points: (1, 0), (0, 1), (-1, 0) and (0, -1) as per:

Note: Uses bit ordering as per

ITU-T V.8

NOTES ON USE

The input to this function are the magnitudes of the I, Q carriers, which must be demodulated at the front end using a function such as SDA_QpskDemodulate.

CROSS REFERENCE

SDA ComplexQPSKSpread, SDA QpskModulate, SDA QpskDemodulate.

Modem Utility Functions (modem.c)

SUF_AsyncCharacterLength

PROTOTYPE AND PARAMETER DESCRIPTION

SLArrayIndex_t SUF_AsyncCharacterLength (

const SLArrayIndex t, Number of bits in the data word

const enum SLParity t, Parity type

const SLArrayIndex t) Number of stop bits

DESCRIPTION

This function returns the length of an asynchronous character that is made up of the start, data, parity and stop bits.

NOTES ON USE

The parity types supported are as follows:

```
SIGLIB_NO_PARITY,
SIGLIB_EVEN_PARITY,
SIGLIB ODD PARITY
```

CROSS REFERENCE

 $SDA_SyncToAsyncConverter, SDA_AsyncToSyncConverter.$

SLArrayIndex_t SDA_SyncToAsyncConverter (const SLUInt8_t *, Ptr. to src. data

SLUInt8_t *, Pointer to destination data const SLArrayIndex t, Number of bits in the data word

const enum SLParity_t, Parity type

const SLArrayIndex_t, Number of stop bits const SLArrayIndex_t) Source array length

DESCRIPTION

This function converts a synchronous data stream to an asynchronous one via the addition of start, parity and stop bits.

The output is packed into 8 bit bytes, regardless of the number of data bits in the input byte.

NOTES ON USE

The parity types supported are as follows:

```
SIGLIB_NO_PARITY,
SIGLIB_EVEN_PARITY,
SIGLIB_ODD_PARITY
```

This function has been tested with:

Parity = Even, Odd and None Stop bits = 0, 1 and 2 Data bits per asynchronous word = 7, 8, 9, 10 and 11

If the output data sequence does not fill an integer number of output bytes then the unused bits in the final byte are filled with stop bits.

CROSS REFERENCE

 $SUF_A sync Character Length, SDA_A sync To Sync Converter.$

SLArrayIndex_t SDA_AsyncToSyncConverter (const SLUInt8_t *, Ptr. to src. data

SLUInt8_t *, Pointer to destination data const SLArrayIndex t, Number of bits in the data word

const enum SLParity_t, Parity type

SLArrayIndex t*, Pointer to parity error flag

const SLArrayIndex t) Source array length

DESCRIPTION

This function converts an asynchronous data stream to a asynchronous one via the removal of start, parity and stop bits.

NOTES ON USE

The parity types supported are as follows:

```
SIGLIB_NO_PARITY,
SIGLIB_EVEN_PARITY,
SIGLIB ODD PARITY
```

This function has been tested with:

Parity = Even, Odd and None Stop bits = 0, 1 and 2 Data bits per asynchronous word = 7, 8, 9, 10 and 11

This function does not look for a specific number of stop bits because it supports stop bit deletion in the transmitter. This is used for rate matching. The parity error flag will return -1 if no parity errors were detected or the location of the byte, in the frame, if a parity error was detected.

CROSS REFERENCE

 $SUF_A sync Character Length\ ,\ SDA_Sync To A sync Converter.$

void SIF_AsyncAddRemoveStopBits (SLArrayIndex_t *) Pointer to counter for adding and removing stop bits

DESCRIPTION

This function initialises the functions that are used for adding and removing stop bits from an asynchronous bit stream.

NOTES ON USE

CROSS REFERENCE

SDA_SyncToAsyncConverter, SDA_AsyncToSyncConverter, SDA_AsyncRemoveStopBits, SDA_AsyncAddStopBits.

SLArrayIndex_t SDA_AsyncRemoveStopBits (const SLUInt8_t *, Pointer to src. data

SLUInt8_t *, Pointer to destination data const SLArrayIndex_t, Number of bits in the data word

const enum SLParity_t, Parity type

const SLArrayIndex t, Ratio of stop bits removed

SLArrayIndex t*, Pointer to stop bits removed counter

const SLArrayIndex t) Source array length

DESCRIPTION

This function removes a given ratio of stop bits. If the RemoveRatio parameter is set to N then 1:N stop bits are removed. If N = 1 then all stop bits are removed.

A common requirement for asynchronous to synchronous converters in a modem is to add or remove a given ratio of the stop bits to allow for clock rate variations.

Please note: if you remove 1:N stop bits and then add 1:(N-1) you will not return to exactly the same sequence that you started with. This is because the stop bit add and remove functions work on ratios so there is no guarantee that stop bits will be replaced in their original locations only that the final number is the same.

NOTES ON USE

The parity types supported are as follows:

```
SIGLIB_NO_PARITY,
SIGLIB_EVEN_PARITY,
SIGLIB_ODD_PARITY
```

This function requires an integer number of characters to be stored in the source array.

CROSS REFERENCE

SDA_SyncToAsyncConverter, SDA_AsyncToSyncConverter, SIF_AsyncAddRemoveStopBits, SDA_AsyncAddStopBits.

SLArrayIndex_t SDA_AsyncAddStopBits (const SLUInt8_t *, Pointer to src. data

SLUInt8_t *, Pointer to destination data const SLArrayIndex t, Number of bits in the data word

const enum SLParity_t, Parity type

const SLArrayIndex t, Ratio of stop bits added

SLArrayIndex_t *, Pointer to stop bits added counter

const SLArrayIndex t) Source array length

DESCRIPTION

This function adds a given ratio of stop bits. If the AddRatio parameter is set to N then 1 new stop bit will be added after N stop bits have been received.

If N = 1 then every other output stop bit will be a new one.

A common requirement for asynchronous to synchronous converters in a modem is to add or remove a given ratio of the stop bits to allow for clock rate variations.

Please note: if you remove 1:N stop bits and then add 1:(N-1) you will not return to exactly the same sequence that you started with. This is because the stop bit add and remove functions work on ratios so there is no guarantee that stop bits will be replaced in their original locations only that the final number is the same.

NOTES ON USE

The parity types supported are as follows:

```
SIGLIB_NO_PARITY,
SIGLIB_EVEN_PARITY,
SIGLIB ODD PARITY
```

This function requires an integer number of characters to be stored in the source array.

CROSS REFERENCE

```
SDA_SyncToAsyncConverter, SDA_AsyncToSyncConverter, SIF AsyncAddRemoveStopBits, SDA AsyncRemoveStopBits.
```

SLArrayIndex_t SDA_DecreaseWordLength (const SLUInt8_t *, Pointer to src. data

SLUInt8 t*, Pointer to destination data

const SLArrayIndex_t, Input word length const SLArrayIndex_t, Output word length const SLArrayIndex_t) Source array length

DESCRIPTION

This function decreases the length of the binary words in the input stream.

Only the desired N bits in the output word length are significant the remainder are set to 0.

In modem applications it is commonly necessary to transmit symbols with different numbers of bits. For example 16QAM uses 4 bits per symbol. The function SDA_DecreaseWordLength will take an input sequence with a given word length and reduce it to a sequence with a shorter word length while still retaining the same total number of bits in the overall sequence.

NOTES ON USE

CROSS REFERENCE

SDA_IncreaseWordLength.

SLArrayIndex_t SDA_IncreaseWordLength (const SLUInt8_t *, Pointer to src. data

SLUInt8 t*, Pointer to destination data

const SLArrayIndex_t, Input word length const SLArrayIndex_t, Output word length const SLArrayIndex_t) Source array length

DESCRIPTION

This function increases the length of the binary words in the input stream.

Only the desired N bits in the output word length are significant the remainder are set to 0.

In modem applications it is commonly necessary to transmit symbols with different numbers of bits. For example 16QAM uses 4 bits per symbol. The function SDA_DecreaseWordLength will take an input sequence with a given word length and reduce it to a sequence with a shorter word length while still retaining the same total number of bits in the overall sequence.

NOTES ON USE

CROSS REFERENCE

SDA DecreaseWordLength.

SLFixData_t SDS_Scrambler1417 (const SLFixData_t, Source byte SLUInt32_t *) Shift register

DESCRIPTION


This function executes a self synchronising Pseudo Random Binary Sequence (PRBS) Cyclic Redundancy Check (CRC) scrambler having the generating polynomial: $1 + x^{-14} + x^{-17}$.

$$D_s = D_i + D_{s.x^{-14}} + D_{s.x^{-17}}$$

Ds is the data sequence at the output of the scrambler

Di is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.



NOTES ON USE

The input data is handled least significant bit first. The scrambled byte is returned from the function.

CROSS REFERENCE

SDS Descrambler1417.

SLFixData_t SDS_Descrambler1417 (const SLFixData_t, Source byte SLUInt32_t *) Shift register

DESCRIPTION


This function executes a self synchronising Pseudo Random Binary Sequence (PRBS) Cyclic Redundancy Check (CRC) de-scrambler having the generating polynomial: $1 + x^{-14} + x^{-17}$.

$$Do = Ds (1 + x^{-14} + x^{-17})$$

Ds is the data sequence at the output of the scrambler

Do is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.



NOTES ON USE

The input data is handled least significant bit first. The de-scrambled byte is returned from the function

CROSS REFERENCE

SDS Scrambler1417.

SLFixData t SDS Scrambler1417WithInversion (const SLFixData t, Source byte

SLUInt32 t*, Shift register

SLFixData_t *, Ones bit count pointer
SLFixData_t *) Bit inversion flag pointer

DESCRIPTION

This function executes a self synchronising Pseudo Random Binary Sequence (PRBS) Cyclic Redundancy Check (CRC) scrambler having the generating polynomial: $1 + x^{-14} + x^{-17}$.

$$D_s = D_i + D_{s.x^{-14}} + D_{s.x^{-17}}$$


Ds is the data sequence at the output of the scrambler

Di is the data sequence applied to the scrambler

+ denotes modulo 2 addition

. denotes binary multiplication.

This function detects a sequence of 64 consecutive ones at the output of the scrambler (Ds) and, if detected, inverts the next input to the scrambler (Di). The counter is reset to zero.



NOTES ON USE

The input data is handled least significant bit first. The scrambled byte is returned from the function.

The ones bit count and bit inversion flag parameters should be initialised to zero.

CROSS REFERENCE

 $SDS_Descrambler 1417 With Inversion.$

SLFixData_t SDS_Descrambler1417WithInversion (const SLFixData_t, Source byte

SLUInt32_t *,	Shift register
SLFixData_t *,	Ones bit count pointer
SLFixData_t *)	Bit inversion flag pointer

DESCRIPTION

This function executes a self synchronising Pseudo Random Binary Sequence (PRBS) Cyclic Redundancy Check (CRC) de-scrambler having the generating polynomial: $1 + x^{-14} + x^{-17}$.


$$Do = Ds (1 + x^{-14} + x^{-17})$$

Ds is the data sequence at the output of the scrambler

Do is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.

This function detects a sequence of 64 consecutive ones at the input to the descrambler (Ds) and, if detected, inverts the next output from the descrambler (Do). The counter is reset to zero.



NOTES ON USE

The input data is handled least significant bit first. The de-scrambled byte is returned from the function

The ones bit count and bit inversion flag parameters should be initialised to zero.

CROSS REFERENCE

SDS_Scrambler1417WithInversion.

DESCRIPTION


This function executes a self synchronising Pseudo Random Binary Sequence (PRBS) Cyclic Redundancy Check (CRC) scrambler having the generating polynomial: $1 + x^{-18} + x^{-23}$.

$$D_s = D_i + D_{s.x^{-18}} + D_{s.x^{-23}}$$

Ds is the data sequence at the output of the scrambler

Di is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.



NOTES ON USE

The input data is handled least significant bit first. The scrambled byte is returned from the function

CROSS REFERENCE

SDS Descrambler1823.

SLFixData_t SDS_Descrambler1823 (const SLFixData_t, Source byte SLUInt32 t*) Shift register

DESCRIPTION


This function executes a self synchronising Pseudo Random Binary Sequence (PRBS) Cyclic Redundancy Check (CRC) de-scrambler having the generating polynomial: $1 + x^{-18} + x^{-23}$.

$$Do = Ds (1 + x^{-18} + x^{-23})$$

Ds is the data sequence at the output of the scrambler

Do is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.



NOTES ON USE

The input data is handled least significant bit first. The de-scrambled byte is returned from the function

CROSS REFERENCE

SDS Scrambler1823.

DESCRIPTION


This function executes a self synchronising Pseudo Random Binary Sequence (PRBS) Cyclic Redundancy Check (CRC) scrambler having the generating polynomial: $1 + x^{-5} + x^{-23}$.

$$D_s = D_i + D_{s.x^{-5}} + D_{s.x^{-23}}$$

Ds is the data sequence at the output of the scrambler

Di is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.



NOTES ON USE

The input data is handled least significant bit first. The scrambled byte is returned from the function

CROSS REFERENCE

SDS Descrambler523.

DESCRIPTION


This function executes a self synchronising Pseudo Random Binary Sequence (PRBS) Cyclic Redundancy Check (CRC) de-scrambler having the generating polynomial: $1 + x^{-5} + x^{-23}$.

$$Do = Ds (1 + x^{-5} + x^{-23})$$

Ds is the data sequence at the output of the scrambler

Do is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.



NOTES ON USE

The input data is handled least significant bit first. The de-scrambled byte is returned from the function

CROSS REFERENCE

SDS Scrambler1823.

SLFixData_t SDS_ScramblerDescramblerPN9 (const SLFixData_t, Source byte SLUInt32_t *) Shift register

DESCRIPTION


This function executes a Pseudo Random Binary Sequence (PRBS) scrambler / descrambler having the generating polynomial: $x^9 + x^4 + 1$.

$$D_s = D_i (x^9 + x^4 + 1)$$

Ds is the data sequence at the output of the scrambler

Di is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.



NOTES ON USE

The input data is handled least significant bit first. The scrambled / de-scrambled byte is returned from the function


CROSS REFERENCE

SDS_SequenceGeneratorPN9, SDS_ScramblerDescramblerPN15, SDS_SequenceGeneratorPN15.

SLFixData_t SDS_SequenceGeneratorPN9 (SLUInt32_t *) Shift register

DESCRIPTION

This function generates a Pseudo Random Binary Sequence (PRBS) with a generating polynomial: $x^9 + x^4 + 1$.



NOTES ON USE

The shift register contents should be initialized with the seed value prior to calling this function.

CROSS REFERENCE

SDS_ScramblerDescramblerPN9, SDS_ScramblerDescramblerPN15, SDS SequenceGeneratorPN15.

SLFixData_t SDS_ScramblerDescramblerPN15 (const SLFixData_t, Source byte SLUInt32_t *) Shift register

DESCRIPTION


This function executes a Pseudo Random Binary Sequence (PRBS) scrambler / descrambler having the generating polynomial: $x^{15} + x^{14} + 1$.

$$Ds = Di(x^{15} + x^{14} + 1)$$

Ds is the data sequence at the output of the scrambler

Di is the data sequence applied to the scrambler

- + denotes modulo 2 addition
- . denotes binary multiplication.



NOTES ON USE

The input data is handled least significant bit first. The scrambled / de-scrambled byte is returned from the function


CROSS REFERENCE

 $SDS_Sequence Generator PN9, SDS_Scrambler Descrambler PN9, SDS_Sequence Generator PN15.$

SLFixData_t SDS_SequenceGeneratorPN15 (SLUInt32_t *) Shift register

DESCRIPTION

This function generates a Pseudo Random Binary Sequence (PRBS) with a generating polynomial: $x^{15} + x^{14} + 1$.



NOTES ON USE

The shift register contents should be initialized with the seed value prior to calling this function.

CROSS REFERENCE

SDS_ScramblerDescramblerPN9, SDS_SequenceGeneratorPN9, SDS ScramblerDescramblerPN15.

SLFixData_t SDS_ScramblerDescramblergCRC24 (const SLFixData_t, Source byte SLUInt32_t *) Shift register

DESCRIPTION

This function executes a Pseudo Random Binary Sequence (PRBS) scrambler / descrambler having the 3GPP UMTS compliant generating polynomial:

$$gCRC24(D) = D^{24} + D^{23} + D^6 + D^5 + D + 1.$$

Where:

$$Ds = Di (D^{24} + D^{23} + D^6 + D^5 + D + 1)$$

Ds is the data sequence at the output of the scrambler Di is the data sequence applied to the scrambler + denotes modulo 2 addition . denotes binary multiplication.

NOTES ON USE

The input data is handled least significant bit first. The scrambled / de-scrambled byte is returned from the function

CROSS REFERENCE

 $SDS_S equence Generatorg CRC24, SDS_S crambler Descramblerg CRC16, SDS_S equence Generatorg CRC16, SDS_S crambler Descramblerg CRC12, SDS_S equence Generatorg CRC12, SDS_S crambler Descramblerg CRC8, SDS_S equence Generatorg CRC8.$

SLFixData_t SDS_SequenceGeneratorgCRC24 (SLUInt32_t *) Shift register

DESCRIPTION

This function generates a Pseudo Random Binary Sequence (PRBS) with a 3GPP UMTS compliant generating polynomial:

$$gCRC24(D) = D^{24} + D^{23} + D^6 + D^5 + D + 1.$$

NOTES ON USE

The shift register contents should be initialized with the seed value prior to calling this function.

CROSS REFERENCE

SDS_ScramblerDescramblergCRC24, SDS_ScramblerDescramblergCRC16, SDS_SequenceGeneratorgCRC16, SDS_ScramblerDescramblergCRC12, SDS_SequenceGeneratorgCRC12, SDS_ScramblerDescramblergCRC8, SDS_SequenceGeneratorgCRC8.

SLFixData_t SDS_ScramblerDescramblergCRC16 (const SLFixData_t, Source byte SLUInt32_t *) Shift register

DESCRIPTION

This function executes a Pseudo Random Binary Sequence (PRBS) scrambler / descrambler having the 3GPP UMTS compliant generating polynomial:

$$gCRC16(D) = D^{16} + D^{12} + D^5 + 1.$$

Where:

$$Ds = Di (D^{16} + D^{12} + D^5 + 11)$$

Ds is the data sequence at the output of the scrambler Di is the data sequence applied to the scrambler + denotes modulo 2 addition . denotes binary multiplication.

NOTES ON USE

The input data is handled least significant bit first. The scrambled / de-scrambled byte is returned from the function

CROSS REFERENCE

 $SDS_ScramblerDescramblergCRC24, SDS_SequenceGeneratorgCRC24, SDS_SequenceGeneratorgCRC16, SDS_ScramblerDescramblergCRC12, SDS_SequenceGeneratorgCRC12, SDS_ScramblerDescramblergCRC8, SDS_SequenceGeneratorgCRC8.$

SLFixData_t SDS_SequenceGeneratorgCRC16 (SLUInt32_t *) Shift register

DESCRIPTION

This function generates a Pseudo Random Binary Sequence (PRBS) with a 3GPP UMTS compliant generating polynomial:

$$gCRC16(D) = D^{16} + D^{12} + D^5 + 1.$$

NOTES ON USE

The shift register contents should be initialized with the seed value prior to calling this function.

CROSS REFERENCE

 $SDS_ScramblerDescramblergCRC24, SDS_SequenceGeneratorgCRC24, SDS_ScramblerDescramblergCRC16, SDS_ScramblerDescramblergCRC12, SDS_SequenceGeneratorgCRC12, SDS_ScramblerDescramblergCRC8, SDS_SequenceGeneratorgCRC8.$

SLFixData_t SDS_ScramblerDescramblergCRC12 (const SLFixData_t, Source byte SLUInt32_t *) Shift register

DESCRIPTION

This function executes a Pseudo Random Binary Sequence (PRBS) scrambler / descrambler having the 3GPP UMTS compliant generating polynomial:

$$gCRC24(D) = D^{12} + D^{11} + D^3 + D^2 + D + 1.$$

Where:

$$Ds = Di (D^{12} + D^{11} + D^3 + D^2 + D + 1)$$

Ds is the data sequence at the output of the scrambler Di is the data sequence applied to the scrambler + denotes modulo 2 addition . denotes binary multiplication.

NOTES ON USE

The input data is handled least significant bit first. The scrambled / de-scrambled byte is returned from the function

CROSS REFERENCE

 $SDS_ScramblerDescramblergCRC24, SDS_SequenceGeneratorgCRC24, SDS_ScramblerDescramblergCRC16, SDS_SequenceGeneratorgCRC16, SDS_SequenceGeneratorgCRC12, SDS_ScramblerDescramblergCRC8, SDS_SequenceGeneratorgCRC8.$

SLFixData_t SDS_SequenceGeneratorgCRC12 (SLUInt32_t *) Shift register

DESCRIPTION

This function generates a Pseudo Random Binary Sequence (PRBS) with a 3GPP UMTS compliant generating polynomial:

$$gCRC12(D) = D^{12} + D^{11} + D^3 + D^2 + D + 1.$$

NOTES ON USE

The shift register contents should be initialized with the seed value prior to calling this function.

CROSS REFERENCE

SDS_ScramblerDescramblergCRC24, SDS_SequenceGeneratorgCRC24, SDS_ScramblerDescramblergCRC16, SDS_SequenceGeneratorgCRC16, SDS_ScramblerDescramblergCRC12, SDS_ScramblerDescramblergCRC8, SDS_SequenceGeneratorgCRC8.

SLFixData_t SDS_ScramblerDescramblergCRC8 (const SLFixData_t, Source byte SLUInt32_t *) Shift register

DESCRIPTION

This function executes a Pseudo Random Binary Sequence (PRBS) scrambler / descrambler having the 3GPP UMTS compliant generating polynomial:

$$gCRC8(D) = D^8 + D^7 + D^4 + D^3 + D + 1.$$

Where:

$$Ds = Di (D^8 + D^7 + D^4 + D^3 + D + 1)$$

Ds is the data sequence at the output of the scrambler Di is the data sequence applied to the scrambler + denotes modulo 2 addition . denotes binary multiplication.

NOTES ON USE

The input data is handled least significant bit first. The scrambled / de-scrambled byte is returned from the function

CROSS REFERENCE

SDS_ScramblerDescramblergCRC24, SDS_SequenceGeneratorgCRC24, SDS_ScramblerDescramblergCRC16, SDS_SequenceGeneratorgCRC16, SDS_ScramblerDescramblergCRC12, SDS_SequenceGeneratorgCRC12, SDS_SequenceGeneratorgCRC12, SDS_SequenceGeneratorgCRC8.

SLFixData_t SDS_SequenceGeneratorgCRC8 (SLUInt32_t *) Shift register

DESCRIPTION

This function generates a Pseudo Random Binary Sequence (PRBS) with a 3GPP UMTS compliant generating polynomial:

$$gCRC8(D) = D^8 + D^7 + D^4 + D^3 + D + 1.$$

NOTES ON USE

The shift register contents should be initialized with the seed value prior to calling this function.

CROSS REFERENCE

SDS_ScramblerDescramblergCRC24, SDS_SequenceGeneratorgCRC24, SDS_ScramblerDescramblergCRC16, SDS_SequenceGeneratorgCRC16, SDS_ScramblerDescramblergCRC12, SDS_SequenceGeneratorgCRC12, SDS_ScramblerDescramblergCRC8.

void SDS_LongCodeGenerator3GPPDL (SLComplexRect_s *, Pointer to destination array


SLUInt32_t *, X shift register SLUInt32_t *, Y shift register const SLArrayIndex t) Output array length

DESCRIPTION

This function generates a 3GPP downlink long code PN sequence using the generating polynomials:

X sequence: $X^{18} + X^7 + 1$ Y sequence: $X^{18} + X^{10} + X^7 + X^5 + 1$

The diagram for the 3GPP downlink long code generator is:



The binary values are mapped to balanced output signals as follows:

Binary value = 0 - Output = +1Binary value = 1 - Output = -1

NOTES ON USE

The shift register contents should be initialized with the seed value prior to calling this function.

CROSS REFERENCE

SDS_LongCodeGenerator3GPPUL.

void SDS_LongCodeGenerator3GPPUL (SLComplexRect_s *, Pointer to destination array

SLUInt32_t *, X shift register
SLUInt32_t *, Y shift register
const SLArrayIndex t) Output array length


DESCRIPTION

This function generates a 3GPP uplink long code PN sequence using the generating polynomials:

X sequence: $X^{25} + X^3 + 1$

Y sequence: $X^{25} + X^3 + X^2 + X + 1$

The diagram for the 3GPP uplink long code generator is:



The binary values are mapped to balanced output signals as follows:

Binary value = 0 - Output = +1

Binary value = 1 - Output = -1

NOTES ON USE

The shift register contents should be initialized with the seed value prior to calling this function.

CROSS REFERENCE

SDS LongCodeGenerator3GPPDL.

void SDA_Multiplex (const SLData_t *, const SLData_t *, SLData_t *, SLData_t *, Pointer to source multiplexed array Input data for frame sample index Pointer to destination multiplexed array const SLArrayIndex_t, Frame sample index to insert data Number of frames in array const SLArrayIndex_t) Number of samples in frame

DESCRIPTION

This function inserts the new data into the selected frame index.

NOTES ON USE

This function overwrites the data in the selected frame index in the multiplexed stream.

CROSS REFERENCE

SDA Demultiplex, SDA MuxN, SDA DemuxN.

const SLArrayIndex t)

void SDA_Demultiplex (const SLData_t *, Pointer to source multiplexed array SLData_t *, Pointer to destination array const SLArrayIndex_t, Frame sample index to extract const SLArrayIndex_t, Number of frames in array

Number of samples in frame

DESCRIPTION

This function extracts the data from the selected frame index.

NOTES ON USE

CROSS REFERENCE

SDA_Multiplex, SDA_Mux*N*, SDA_Demux*N*.

SDA_MuxN

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_MuxN (const SLData_t *, Source array pointer 1

const SLData_t *, SLData_t *, const SLArrayIndex t) Source array pointer *N*Destination array pointer
Source array length

DESCRIPTION

This function multiplexes N channels of data into one single channel.

NOTES ON USE

The destination array will be N times the length of the source arrays.

 $2 \le N \le 8$.

CROSS REFERENCE

SDA_Multiplex, SDA_Demultiplex, SDA_Demux*N*.

SLData_t SDA_DemuxN (const SLData_t *, Source array pointer SLData_t *, Destination array pointer 1

SLData_t *, Destination array pointer N const SLArrayIndex_t) Destination array length

DESCRIPTION

This function de-multiplex N channels of data from the one single channel.

NOTES ON USE

The source array will be N times the length of the destination arrays.

 $2 \le N \le 8$.

CROSS REFERENCE

SDA_Multiplex, SDA_Demultiplex, SDA_MuxN.

Decimation And Interpolation Functions (decint.c)

SIF_Decimate

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Decimate (SLArrayIndex_t *) Pointer to decimation index register

DESCRIPTION

This function initialises the decimation function SDA_Decimate and initialises the index register to zero.

NOTES ON USE

CROSS REFERENCE

 $SDA_Interpolate, SDA_FilterAndDecimate, SDA_InterpolateAndFilter, SDA_ResampleLinear$

void SDA_Decimate (const SLData_t *, SLData_t *, Pointer to source array Pointer to destination array const SLFixData_t, Decimation ratio SLArrayIndex_t *, Pointer to source array index const SLArrayIndex_t)

Source array length

DESCRIPTION

This function decimates the sample rate of the data by the given ratio.

NOTES ON USE

This function supports decimation across contiguous arrays through the use of the source array index parameter, which must be initialised to zero before calling this function.

This function will work in-place.

This function does not low pass pre-filter the source data. This should be performed using the FIR filter functions.

CROSS REFERENCE

SIF_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SDA_InterpolateAndFilter, SDA_ResampleLinear

void SIF_Interpolate (SLArrayIndex_t *) Pointer to interpolation index register

DESCRIPTION

This function initialises the interpolation function SDA_Interpolate and initialises the index register to zero.

NOTES ON USE

CROSS REFERENCE

 $SDA_Interpolate, SDA_FilterAndDecimate, SDA_InterpolateAndFilter, SDA_ResampleLinear$

void SDA_Interpolate (const SLData_t *, SLData_t *, Pointer to source array Pointer to destination array Interpolation ratio SLArrayIndex_t *, Pointer to destination array index const SLArrayIndex_t)

Pointer to source array Pointer to destination array Interpolation ratio Pointer to destination array index Destination array length

DESCRIPTION

This function interpolates the sample rate of the data by the given ratio.

NOTES ON USE

This function supports interpolation across contiguous arrays through the use of the destination array index parameter.

This function does NOT work in-place.

This function does not low pass post-filter the interpolated data. This should be performed using the FIR filter functions.

This function does not verify that there is sufficient data in the source array to avoid overrun.

CROSS REFERENCE

SIF_Interpolate, SDA_Decimate, SDA_FilterAndDecimate, SDA_InterpolateAndFilter, SDA_ResampleLinear

void SIF_FilterAndDecimate (SLData_t *, Pointer to filter state array

SLArrayIndex_t *, Pointer to decimation index register

SLArrayIndex_t *, Pointer to filter index register

const SLArrayIndex_t); Filter length

DESCRIPTION

This function initialises the SDA_FilterAndDecimate function.

NOTES ON USE

CROSS REFERENCE

SDA_Interpolate, SDA_Decimate, SDA_FilterAndDecimate, SDA InterpolateAndFilter, SDA ResampleLinear

void SDA_FilterAndDecimate (const SLData_t *, Pointer to source array

SLData_t *, Pointer to destination array

const SLFixData t, Decimation ratio

SLArrayIndex_t *, Pointer to source array index SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients SLArrayIndex t *, Pointer to filter offset register

const SLArrayIndex t, Filter length

const SLArrayIndex t) Source array length

DESCRIPTION

This function pre-filters the source data using the supplied filter coefficients and decimates the sample rate of the data by the given ratio.

NOTES ON USE

This function supports decimation across contiguous arrays through the use of the source array index parameter.

This function will work in-place.

The FIR filter should be linear phase filter to maintain the phase relationships of all the frequencies in the signal being decimated.

The decimation ratio must be an integer value.

CROSS REFERENCE

SDA_Interpolate, SDA_Decimate, SIF_FilterAndDecimate, SDA InterpolateAndFilter, SDA ResampleLinear

void SIF_InterpolateAndFilter (SLData_t *, Pointer to filter state array

SLArrayIndex_t *, Pointer to interpolation index register

SLArrayIndex t*, Pointer to filter index register

const SLArrayIndex_t); Filter length

DESCRIPTION

This function initialises the SDA_InterpolateAndFilter function.

NOTES ON USE

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SDA_InterpolateAndFilter, SDA_ResampleLinear, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

void SDA_InterpolateAndFilter (const SLData_t *, Pointer to source array

SLData_t *, Pointer to destination array

const SLFixData t, Interpolation ratio

SLArrayIndex t*, Pointer to destination array index

SLData_t *, Pointer to filter state array const SLData_t *, Pointer to filter coefficients SLArrayIndex t *, Pointer to filter offset register

const SLArrayIndex_t, Filter length

const SLArrayIndex t) Destination array length

DESCRIPTION

This function interpolates the sample rate of the data by the given ratio and low pass post-filters the destination data using the supplied filter coefficients.

NOTES ON USE

This function supports interpolation across contiguous arrays through the use of the destination array index parameter.

This function does NOT work in-place.

This function does not verify that there is sufficient data in the source array to avoid overrun of that array.

The FIR filter should be linear phase filter to maintain the phase relationships of all the frequencies in the signal being interpolated.

The interpolation ratio must be an integer value.

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_ResampleLinear, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

SLArrayIndex_t SDA_ResampleLinear (const SLData_t *, Source array pointer

SLData_t *, Destination array pointer const SLData_t, New sample period const SLArrayIndex t) Source array length


DESCRIPTION

This function uses linear interpolation to resample the data in the source array. The input sample rate is normalized to 1.0 (Hz) and the new sample period is relative to the normalized input sample rate. The following table shows the range of numbers that are used for the new sample period for both interpolation and decimation:

Range for new sample period

Decimation (sample rate decrease) > 1.0 Interpolation (sample rate increase) < 1.0

The interpolation operation is summarized in the following diagram:



The interpolated y value is calculate using the following equation:

$$y = y_0 + \frac{x - x_0}{x_1 - x_0} (y1 - y0)$$

This function returns the number of re-sampled output data points.

NOTES ON USE

This function is not designed for use in streaming applications, where the SDA_FilterAndDecimate and SDA_InterpolateAndFilter functions are much more appropriate.

CROSS REFERENCE

SDA Decimate, SDA Interpolate, SDA FilterAndDecimate,

SIF InterpolateAndFilter, SDA InterpolateAndFilter,

SDA ResampleLinearNSamples, SDA ResampleSinc,

SIF ResampleLinearContiguous and SDA ResampleLinearContiguous,

SDS InterpolateQuadratic1D, SDS InterpolateQuadraticBSpline1D,

SDS InterpolateQuadraticLagrange1D

SLArrayIndex_t SDA_ResampleLinearNSamples (const SLData_t *, Source pointer

SLData_t *, Destination array pointer const SLData_t, New sample period const SLArrayIndex_t, Source array length const SLArrayIndex_t) Destination array length


DESCRIPTION

This function uses linear interpolation to resample the data in the source array. The input sample rate is normalized to 1.0 (Hz) and the new sample period is relative to the normalized input sample rate. The following table shows the range of numbers that are used for the new sample period for both interpolation and decimation:

Range for new sample period

Decimation (sample rate decrease)	> 1.0
Interpolation (sample rate increase)	< 1.0

The interpolation operation is summarized in the following diagram:



The interpolated y value is calculate using the following equation:

$$y = y_0 + \frac{x - x_0}{x_1 - x_0} (y_1 - y_0)$$

The function only outputs N samples. If the re-sampling shortens the array then it is zero padded. If the re-sampling lengthens the array then it is truncated. This function returns the number of re-sampled output valid data points – i.e. if the output array contains 100 data samples and 50 zero padded samples then this function will return 100.

NOTES ON USE

This function is not designed for use in streaming applications, where the SDA_FilterAndDecimate and SDA_InterpolateAndFilter functions are much more appropriate.

CROSS REFERENCE


SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SDA_ResampleLinearNSamples, SDA_ResampleSinc, SIF_ResampleLinearContiguous and SDA_ResampleLinearContiguous, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D,

SDS InterpolateQuadraticLagrange1D

SLData_t SDA_InterpolateLinear1D (const SLData_t *, Y Source array pointer const SLData_t, Input x value const SLArrayIndex t) Source array length

DESCRIPTION

This function uses linear interpolation to calculate the interpolated value of y, for a given x. The source y samples are stored in the source array, with the array index being the x value and the interpolated value is the return value from the function. The interpolation operation is summarized in the following diagram:



The interpolated y value is calculate using the following equation:

$$y = y_0 + \frac{x - \chi_0}{\chi_1 - \chi_0} (y1 - y0)$$

NOTES ON USE

If the input x value is beyond the length of the y input array then this function will return SIGLIB ZERO.

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SDA_ResampleLinear, SDA_InterpolateLinear2D, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticLagrange1D

SLData_t SDA_InterpolateLinear2D (const SLData_t *, X Source array pointer


const SLData t*, Pointer to Y source array

const SLData t, Input x value

const SLArrayIndex t) Source array length

DESCRIPTION

This function uses linear interpolation to calculate the interpolated value of y, for a given x. The x and y samples are stored in separate arrays and the interpolated value is the return value from the function. The interpolation operation is summarized in the following diagram:



The interpolated *y* value is calculate using the following equation:

$$y = y_0 + \frac{x - x_0}{x_1 - x_0} (y1 - y0)$$

NOTES ON USE

If the input x value lies outside the magnitude range of the x input array then this function will return SIGLIB ZERO.

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SDA_ResampleLinear, SDA_InterpolateLinear1D, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticLagrange1D

void SIF_ResampleSinc (SLData_t *, Pointer to sinc look up table SLData_t *, Pointer to phase gain const SLArrayIndex_t, Number of adjacent samples const SLArrayIndex_t)

Look up table length

DESCRIPTION

This function initializes the SDA_ResampleSinc function with a sinc (sin(x)/x) look up table. Please refer to the documentation for SIF_QuickSinc for further details.

NOTES ON USE

Sinc interpolation allows a linear time or frequency axis to be rescaled into another linear or even a logarithmic axis. The error in these functions is < 1% as long as the signal frequency is $< 0.3 F_s$. The function assumes all values outside the source array are 0.0

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSincContiguous, SIF_ResampleWindowedSincContiguous and SDA_ResampleSincContiguous, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

void SIF_ResampleWindowedSinc (SLData_t *, Pointer to sinc look up table

SLData t*, Pointer to phase gain

const SLArrayIndex_t, Number of adjacent samples SLData t *, Pointer to window LUT array

const enum SLWindow t, Window type

const SLData_t, Window coefficient

const SLArrayIndex_t) Look up table length

DESCRIPTION

This function initializes the SDA_ResampleSinc function with a windowed sinc (sin(x)/x) look up table. Please refer to the documentation for SIF_QuickSinc and SIF Window for further details.

NOTES ON USE

Sinc interpolation allows a linear time or frequency axis to be rescaled into another linear or even a logarithmic axis. The error in these functions is < 1% as long as the signal frequency is $< 0.3 F_s$. The function assumes all values outside the source array are 0.0

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSincContiguous, SIF_ResampleWindowedSincContiguous and SDA_ResampleSincContiguous, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

SLArrayIndex_t SDA_ResampleSinc (const SLData_t *, Pointer to src. array

SLData_t *, Pointer to destination array const SLData_t *, Pointer to sinc look up table const SLData_t, Look up table phase gain const SLData_t, New sample period const SLArrayIndex t, Number of adjacent samples

tonst SEATTayIndex_t, Trumber of adjacent sample

const SLArrayIndex t) Source array length


DESCRIPTION

This function uses sinc (sin(x)/x) interpolation to resample the data in the source array. The input sample rate is normalized to 1.0 (Hz) and the new sample period is relative to the normalized input sample rate. The following table shows the range of numbers that are used for the new sample period for both interpolation and decimation:

Range for new sample period

Decimation (sample rate decrease) > 1.0 Interpolation (sample rate increase) < 1.0

The interpolation operation is summarized in the following diagram where the interpolated point is generated from the summations of the number of adjacent samples specified in the parameter list:



This function returns the number of re-sampled output data points.

NOTES ON USE

This function uses the quick sinc look up table for calculating the sinc function. You must call either SIF_ResampleSinc or SIF_ResampleWindowedSinc before calling this function.

This function is not designed for use in streaming applications, where the SDA_FilterAndDecimate and SDA_InterpolateAndFilter functions are much more appropriate.

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SDA_ResampleLinear, SDA_ResampleSincNSamples, SIF_ResampleSincContiguous, SIF_ResampleWindowedSincContiguous and SDA_ResampleSincContiguous, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

SLArrayIndex_t SDA_ResampleSincNSamples (const SLData_t *, Ptr. to src. array

<i>-</i> - 1	1 \	,
SLData_t *,	Pointer to destination array	
const SLData_t *,	Pointer to sinc look up table	
const SLData_t,	Look up table phase gain	
const SLData_t,	New sample period	
const SLArrayIndex_t,	Number of adjacent samples	
const SLArrayIndex_t,	Source array length	
const SLArrayIndex t)	Destination array length	


DESCRIPTION

This function uses sinc (sin(x)/x) interpolation to resample the data in the source array. The input sample rate is normalized to 1.0 (Hz) and the new sample period is relative to the normalized input sample rate. The following table shows the range of numbers that are used for the new sample period for both interpolation and decimation:

Range for new sample period

Decimation (sample rate decrease)	> 1.0
Interpolation (sample rate increase)	< 1.0

The interpolation operation is summarized in the following diagram where the interpolated point is generated from the summations of the number of adjacent samples specified in the parameter list:



The function only outputs N samples. If the re-sampling shortens the array then it is zero padded. If the re-sampling lengthens the array then it is truncated. This function returns the number of re-sampled output valid data points – i.e. if the output array contains 100 data samples and 50 zero padded samples then this function will return 100.

NOTES ON USE

This function uses the quick sinc look up table for calculating the sinc function. You must call either SIF_ResampleSinc or SIF_ResampleWindowedSinc before calling this function.

This function is not designed for use in streaming applications, where the SDA_FilterAndDecimate and SDA_InterpolateAndFilter functions are much more appropriate.

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SDA_ResampleLinear, SDA_ResampleSinc, SIF_ResampleSincContiguous, SIF_ResampleWindowedSincContiguous and SDA_ResampleSincContiguous, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

void SIF_InterpolateSinc1 (SLData_t *, Pointer to sinc look up table SLData_t *, Pointer to phase gain const SLArrayIndex_t, Number of adjacent samples const SLArrayIndex_t) Look up table length

DESCRIPTION

This function initializes the SDA_InterpolateSinc1 function with a sinc (sin(x)/x) look up table. Please refer to the documentation for SIF QuickSinc for further details.

NOTES ON USE

CROSS REFERENCE

SDA_InterpolateLinear1D, SDA_InterpolateLinear2D and SDA_InterpolateSinc1D, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBspline1D, SDS_InterpolateQuadraticLagrange1D

void SIF_InterpolateWindowedSinc1D (SLData_t *, Pointer to sinc look up table

SLData t*, Pointer to phase gain

const SLArrayIndex_t, Number of adjacent samples SLData t*, Pointer to window LUT array

const enum SLWindow_t, Window type
const SLData_t, Window coefficient
const SLArrayIndex t) Look up table length

DESCRIPTION

This function initializes the SDA_InterpolateSinc1D function with a windowed sinc (sin(x)/x) look up table. Please refer to the documentation for SIF_QuickSinc and SIF Window for further details.

NOTES ON USE

CROSS REFERENCE


SDA_InterpolateLinear1D, SDA_InterpolateLinear2D and SDA_InterpolateSinc1D, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBspline1D, SDS_InterpolateQuadraticLagrange1D

SLData_t SDA_InterpolateSinc1D (const SLData_t *, Pointer to 'y' source array const SLData_t, Input 'x' value

SLData_t *, Pointer to sinc look up table const SLData_t, Look up table phase gain const SLArrayIndex_t, Number of adjacent samples const SLArrayIndex_t) Source array length

DESCRIPTION

This function uses sinc (sin(x)/x) interpolation to calculate the interpolated value of y, for a given x. The source y samples are located in the source array, with the array index being the x value and the interpolated value is the return value from the function. The interpolation operation is summarized in the following diagram where the interpolated point is generated from the summations of the number of adjacent samples specified in the parameter list:



NOTES ON USE

This function uses the quick sinc look up table for calculating the sinc function.

You must call either SIF_InterpolateSinc1 or SIF_InterpolateWindowedSinc1 before calling this function.

CROSS REFERENCE

SDA_InterpolateLinear1D, SDA_InterpolateLinear2D and SIF_InterpolateSinc1D, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBspline1D, SDS_InterpolateQuadraticLagrange1D

void SIF_ResampleLinearContiguous (SLData_t *, Pointer to previous X value SLData_t *)

Pointer to previous Y value

DESCRIPTION

This function initializes the SDA ResampleLinearContiguous function.

NOTES ON USE

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSinc, SIF_ResampleWindowedSinc, SDA_ResampleSinc and SDA_ResampleLinear, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

SLArrayIndex_t SDA_ResampleLinearContiguous (const SLData_t *, Pointer to Y source array

SLData_t *,	Pointer to destination array
SLData_t *,	Pointer to previous X value
SLData_t *,	Pointer to previous Y value
const SLData_t,	New sampling period
<pre>const SLArrayIndex_t)</pre>	Source array length


DESCRIPTION

This function uses linear interpolation to resample the data in the source array. The input sample rate is normalized to 1.0 (Hz) and the new sample period is relative to the normalized input sample rate. The following table shows the range of numbers that are used for the new sample period for both interpolation and decimation:

Range for new sample period

Decimation (sample rate decrease)	> 1.0
Interpolation (sample rate increase)	< 1.0

The interpolation operation is summarized in the following diagram:



The interpolated y value is calculate using the following equation:

$$y = y_0 + \frac{x - x_0}{x_1 - x_0} (y1 - y0)$$

This function returns the number of re-sampled output data points.

NOTES ON USE

This function is not designed for use in streaming applications, where the SDA_FilterAndDecimate and SDA_InterpolateAndFilter functions are much more appropriate.

This function operates contiguously across array boundaries.

The function SIF_ResampleLinearContiguous must be called before calling this function.

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter and SIF_ResampleLinearContiguous, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

void SIF_ResampleSincContiguous (SLData_t *, Pointer to previous X value SLData_t *, Pointer to LUT array SLData_t *, Pointer to data history array SLData_t *, Pointer to sinc LUT phase gain const SLArrayIndex_t, Number of adjacent samples const SLArrayIndex_t) Sinc look up table length

DESCRIPTION

This function initializes the SDA_ResampleSincContiguous function with a sinc (sin(x)/x) look up table. Please refer to the documentation for SIF_QuickSinc for further details.

NOTES ON USE

Sinc interpolation allows a linear time or frequency axis to be rescaled into another linear or even a logarithmic axis. The error in these functions is < 1% as long as the signal frequency is $< 0.3 F_s$. The function assumes all values outside the source array are 0.0

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSinc, SIF_ResampleWindowedSinc and SDA_ResampleSinc, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

void SIF_ResampleWindowedSincContiguous (SLData_t *, Pointer to previous X value

SLData t*, Pointer to LUT array Pointer to data history array SLData t*, SLData t*, Pointer to sinc LUT phase gain const SLArrayIndex t, Number of adjacent samples SLData t*, Pointer to window LUT array const enum SLWindow t, Window type Window coefficient const SLData_t, const SLArrayIndex t) Sinc look up table length

DESCRIPTION

This function initializes the SDA_ResampleSincContiguous function with a windowed sinc (sin(x)/x) look up table. Please refer to the documentation for SIF QuickSinc and SIF Window for further details.

NOTES ON USE

Sinc interpolation allows a linear time or frequency axis to be rescaled into another linear or even a logarithmic axis. The error in these functions is < 1% as long as the signal frequency is < 0.3 F_s . The function assumes all values outside the source array are 0.0

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSinc, SIF_ResampleWindowedSinc and SDA_ResampleSinc, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

SLArrayIndex_t SDA_ResampleSincContiguous (const SLData_t *, Pointer to Y source array

SLData t*, Pointer to destination array Pointer to previous X value SLData t*, Pointer to LUT array SLData t*, SLData t*, Pointer to data history array SLData t*, Pointer to sinc LUT phase gain New sampling period const SLData t, const SLArrayIndex t, Number of adjacent samples const SLArrayIndex t) Source array length


DESCRIPTION

This function uses sinc (sin(x)/x) interpolation to resample the data in the source array. The input sample rate is normalized to 1.0 (Hz) and the new sample period is relative to the normalized input sample rate. The following table shows the range of numbers that are used for the new sample period for both interpolation and decimation:

Range for new sample period

Decimation (sample rate decrease) > 1.0 Interpolation (sample rate increase) < 1.0

The interpolation operation is summarized in the following diagram where the interpolated point is generated from the summations of the number of adjacent samples specified in the parameter list:



This function returns the number of re-sampled output data points.

NOTES ON USE

This function uses the quick sinc look up table for calculating the sinc function. You must call either SIF_ResampleSincContiguous or SIF ResampleWindowedSincContiguous before calling this function.

This function is not designed for use in streaming applications, where the SDA_FilterAndDecimate and SDA_InterpolateAndFilter functions are much more appropriate.

This function operates contiguously across array boundaries.

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSinc, SIF_ResampleWindowedSinc and SDA_ResampleSinc, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D, SDS_InterpolateQuadraticLagrange1D

SLData_t SDS_InterpolateQuadratic1D (const SLData_t, x(0) input sample magnitude

const SLData_t,	x(1) input sample magnitude
const SLData_t,	x(2) input sample magnitude
const SLData_t)	Delta x

DESCRIPTION

This function uses 2^{nd} order quadratic spline interpolation to interpolate the y value for a given x input.

The x value is a delta of the distance between the previous known x sample and the subsequent x sample and has a range $0 \le \delta x \le 1$.

The following diagram shows the δx used to calculate the output interpolated y value.



NOTES ON USE

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSinc, SIF_ResampleWindowedSinc, SDA_ResampleSinc, SDS_InterpolateQuadraticLagrange1D and SDS_InterpolateQuadraticBSpline1D

SLData_t SDS_InterpolateQuadraticBSpline1D (const SLData_t, x(0) input sample magnitude

const SLData_t,	x(1) input sample magnitude
const SLData_t,	x(2) input sample magnitude
const SLData_t)	Delta x

DESCRIPTION

This function uses 2^{nd} order quadratic B-Spline interpolation to interpolate the y value for a given x input.

The x value is a delta of the distance between the previous known x sample and the subsequent x sample and has a range $0 \le \delta x \le 1$.

The following diagram shows the δx used to calculate the output interpolated y value.



NOTES ON USE

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSinc, SIF_ResampleWindowedSinc, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticLagrange1D and SDA_ResampleSinc

SLData_t SDS_InterpolateQuadraticLagrange1D (const SLData_t, x(0) input sample magnitude


const SLData_t,	x(1) input sample magnitude
const SLData_t,	x(2) input sample magnitude
const SLData_t)	Delta x

DESCRIPTION

This function uses 2^{nd} order quadratic Lagrange interpolation to interpolate the y value for a given x input.

The x value is a delta of the distance between the previous known x sample and the subsequent x sample and has a range $0 \le \delta x \le 1$.

The following diagram shows the δx used to calculate the output interpolated y value.



NOTES ON USE

CROSS REFERENCE

SDA_Decimate, SDA_Interpolate, SDA_FilterAndDecimate, SIF_InterpolateAndFilter, SDA_InterpolateAndFilter, SIF_ResampleSinc, SIF_ResampleWindowedSinc, SDS_InterpolateQuadratic1D, SDS_InterpolateQuadraticBSpline1D and SDA_ResampleSinc

DTMF Functions (dtmf.c)

These function generate and detect standard DTMF tones, according to the following table:

Freq. (Hz)	1209	1336	1477	1633
697	1	2	3	A
770	4	5	6	В
852	7	8	9	C
941	*	0	#	D

This functions accept or return the SigLib key codes. These key codes are a mapping of the standard keys, according to the following table:

Standard keys	SigLib mapping
1 2 3 A	0 1 2 3
4 5 6 B	4 5 6 7
7 8 9 C	8 9 10 11
* 0 # D	12 13 14 15

SigLib includes functions for encoding and decoding the mapping. In addition to the key codes, SigLib functions also return status information from the detector functions. Further details are included with the appropriate functions.

The SigLib DTMF detection functionality is based on the Goertzel algorithm (the most popular technique for this application). The output of the Goertzel filters pass into a decision logic section which selects the most appropriate DTMF tone from the received signal. The 'detect and validate' function also includes a threshold level so that the detector will not give spurious results when low level noise is received. The standard example analyses the primary 8 DTMF frequencies and does not look at harmonics (a simple modification). The decision is dependent on the magnitudes of these primary frequencies.

The Goertzel filters process discrete arrays of data and while the standard length for 8 kHz sampling is 102 samples. Faster sampling rates will require proportionately longer arrays and possible modification of the scaling in the decision logic section. If a different sample rate or array length is required then it is necessary to ensure that the filter centre frequencies and array length provide an integer number of cycles to minimise edge effects.

The DTMF detector frequencies in the file *siglib_constants.h* do not align exactly with the ITU standard frequencies. These frequencies have deliberately been chosen to avoid the edge effects usually associated with DFTs processing non integer numbers of cycles in a sinusoid. They are the nearest whole frequencies to those defined by the ITU when using a 102 sample input array.

When developing a DTMF detection algorithm the best place to start is to use the \\SigLib\Examples\DTMFWav.c or \\SigLib\Examples\gen_dtmf.c examples, which are designed to be processor independent and processes real DTMF tones stored in a .wav file with an 8 kHz sample rate. gen_dtmf.c takes an input specification from the file 'dtmf.txt' and generates DTMF sequences from this specification prior to trying to detect the tones. Long sequences of DTMF tones can

be generated by modification of 'dtmf.txt' without any modification of the source code.

There are several primary issues to consider when detecting DTMF tones:

- The period of the tone being detected the standard example uses 100 ms.
- The scaling of the input signal the standard examples use 16 bit signed numbers.
- The sample rate the standard example uses 8 kHz sampling.

While the standard SigLib DTMF algorithms are very robust and have been used, unmodified in many applications, our libraries have not been tested against any standards and we make no claims that they conform to any specification. It may be necessary to modify the decision logic section to meet specific application requirements.

void SIF_DtmfGenerate (SLData_t *, Pointer to DTMF generator coefficients const SLData_t) Sample rate (Hz)

DESCRIPTION

This function initialises the DTMF signal generation function.

The DTMF generator coefficient table is an array of length SIGLIB DTMF FTABLE LENGTH. The values in this array are initialised in this function.

NOTES ON USE

CROSS REFERENCE

SDA DtmfGenerate

SLError_t SDA_DtmfGenerate (SLData_t *, Destination array pointer

const SLFixData t, Key code

const SLData_t, Half peak output signal magnitude SLData_t *, Pointer to DTMF generator coefficients

const SLArrayIndex t) Array length

DESCRIPTION

This function generates standard DTMF tones and takes as its input the SigLib key codes. The output magnitude can be modified to suite the application.

NOTES ON USE

The function SIF DtmfGenerate must be called prior to using this function.

The DTMF generator coefficient table is an array of length SIGLIB DTMF FTABLE LENGTH.

The parameter described as "Half peak output signal magnitude" defines the magnitude of each of the composite signals that make up the DTMF tone. I.E. The total output signal magnitude can be twice this magnitude.

This function returns: SIGLIB_ERROR if the user supplies an incorrect key code, otherwise it returns SIGLIB_NO_ERROR.

The SigLib key code can be generated from the ASCII code using the function SUF AsciiToKeyCode.

CROSS REFERENCE

SIF_DtmfGenerate, SIF_DtmfDetect, SDA_DtmfDetect, SUF AsciiToKeyCode, SUF KeyCodeToAscii

SIF_DtmfDetect

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_DtmfDetect (SLData_t *, Pointer to filter state array const SLData_t, Sample rate (Hz) const SLArrayIndex_t) Array length

DESCRIPTION

This function initialises the DTMF signal generation function.

The state array is used by the Goertzel filter during the detection process, it should be of length <code>SIGLIB_DTMF_STATE_LENGTH</code>. The array contents are initialised to zero by this function.

The array length parameter specifies the length of the array containing the data that will be detected.

NOTES ON USE

CROSS REFERENCE

SDA DtmfDetect, SUF EstimateBPFilterLength, SUF EstimateBPFilterError

SLStatus_t SDA_DtmfDetect (SLData_t *, Source array pointer
SLData_t *, Detection Pointer to filter state array
const SLArrayIndex_t) Array length

DESCRIPTION

This function detects standard DTMF tones and returns the following information:

- The key code, which can be converted to the ASCII code using the function SUF KeyCodeToAscii.
- SIGLIB_NO_DTMF_SIGNAL Indicates that the signal is above the threshold but no DTMF signal has been detected.

NOTES ON USE

The function SIF DtmfDetect must be called prior to using this function.

The filter state array parameter is a pointer to the state array for the Goertzel filter used in the detector.

CROSS REFERENCE

SIF_DtmfGenerate, SDA_DtmfGenerate, SIF_DtmfDetect, SDA_DtmfDetectAndValidate, SUF_AsciiToKeyCode, SUF_KeyCodeToAscii, SUF_EstimateBPFilterLength, SUF_EstimateBPFilterError

SLStatus_t SDA_DtmfDetectAndValidate (SLData_t *, Source array pointer

SLData_t *, Pointer to filter state array const SLData_t, Threshold for signal energy SLStatus_t *, Previous key code pointer SLFixData_t *, Key code run length pointer SLFixData_t *, Key code registration flag pointer

const SLArrayIndex t) Array length

DESCRIPTION

This function detects standard DTMF tones and returns the key code. This function validates the detected signal and returns the following information:

- The key code, which can be converted to the ASCII code using the function SUF KeyCodeToAscii.
- SIGLIB_NO_SIGNAL_PRESENT Indicates that the signal level is below the threshold.
- SIGLIB_NO_DTMF_SIGNAL Indicates that the signal is above the threshold but no DTMF signal has been detected.
- SIGLIB_DTMF_CONTINUATION Indicates that the signal is the same code as the previous one. This can be used along with the key code run length when trying to detect the length of a tone.

NOTES ON USE

The function SIF_DtmfDetect must be called prior to using this function. The filter state array parameter is a pointer to the state array for the Goertzel filter used in the detector. The threshold parameter is used to detect whether there is any signal present or not. This value should be set to a signal energy level that is slightly higher than the channel noise floor.

The previous key code parameter is used by the function to indicate what was the previously detected key. This should be initialised to SIGLIB_NO_DTMF_SIGNAL. The key code run length parameter is used in the function to count and return the length of the DTMF tone in number of sample arrays. The key code registration flag parameter is used by the function to register when a detected key is a continuation of a previous one. This should be initialised to SIGLIB FALSE.

CROSS REFERENCE

SIF_DtmfGenerate, SDA_DtmfGenerate, SIF_DtmfDetect, SDA_DtmfDetect, SUF_AsciiToKeyCode, SUF_KeyCodeToAscii, SUF_EstimateBPFilterLength, SUF_EstimateBPFilterError

SLFixData_t SUF_AsciiToKeyCode (SLFixData_t) ASCII key code

DESCRIPTION

This function translates ASCII key codes to SigLib key codes.

NOTES ON USE

An invalid key code is returned as error code SIGLIB NO DTMF KEY.

CROSS REFERENCE

 $SIF_DtmfGenerate, SDA_DtmfGenerate, SIF_DtmfDetect, SDA_DtmfDetect, SUF_KeyCodeToAscii$

SLFixData_t SUF_KeyCodeToAscii (SLFixData_t) ASCII key code

DESCRIPTION

This function translates SigLib key codes to ASCII key codes.

NOTES ON USE

An invalid key code is returned as error code SIGLIB NO DTMF KEY.

CROSS REFERENCE

 $SIF_DtmfGenerate, SDA_DtmfGenerate, SIF_DtmfDetect, SDA_DtmfDetect, SUF_AsciiToKeyCode$

SPEECH PROCESSING FUNCTIONS (speech.c)

SIF_PreEmphasisFilter

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_PreEmphasisFilter (SLData_t *) Pointer to filter state

DESCRIPTION

This function initialises the speech processing pre-emphasis filter function SDA_PreEmphasisFilter ().

NOTES ON USE

CROSS REFERENCE

SDA_PreEmphasisFilter, SIF_DeEmphasisFilter, SDA_DeEmphasisFilter.

void SDA_PreEmphasisFilter (SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLData_t, Filter coefficient SLData_t *, Pointer to filter state const SLArrayIndex t) Array length

DESCRIPTION

This function implements a speech processing pre-emphasis filter.

NOTES ON USE

CROSS REFERENCE

SIF PreEmphasisFilter, SIF DeEmphasisFilter, SDA DeEmphasisFilter.

void SIF_DeEmphasisFilter (SLData_t *) Pointer to filter state

DESCRIPTION

This function initialises the speech processing de-emphasis filter function SDA DeEmphasisFilter ().

NOTES ON USE

CROSS REFERENCE

SIF_PreEmphasisFilter, SDA_PreEmphasisFilter, SDA_DeEmphasisFilter.

void SDA_DeEmphasisFilter (SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLData_t, Filter coefficient SLData_t *, Pointer to filter state const SLArrayIndex_t) Array length

DESCRIPTION

This function implements a speech processing pre-emphasis filter.

NOTES ON USE

CROSS REFERENCE

SIF PreEmphasisFilter, SDA PreEmphasisFilter, SIF DeEmphasisFilter.

void SDA_AdpcmEncoder (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function applies a one bit per sample ADPCM encoder to an individual frame of data. The previous sample is used as the estimate for the next sample.

NOTES ON USE

This function uses the following adaptive step size algorithm:

If the estimate is lower than the input then double the step size and transmit +1 If the estimate is higher than the input then restart with the default step size and transmit 0

The first sample in the destination frame is the first sample of the input frame so that transmission errors do not propagate beyond a single frame.

CROSS REFERENCE

SDA AdpcmEncoderDebug, SDA AdpcmDecoder.

void SDA_AdpcmEncoderDebug (const SLData_t *, Pointer to source array

SLData_t *, Pointer to destination array SLData_t *, Pointer to estimate array

const SLArrayIndex t) Array length

DESCRIPTION

This function applies a one bit per sample ADPCM encoder to an individual frame of data. The previous sample is used as the estimate for the next sample.

NOTES ON USE

This function uses the following adaptive step size algorithm:

If the estimate is lower than the input then double the step size and transmit +1 If the estimate is higher than the input then restart with the default step size and transmit 0

The first sample in the destination frame is the first sample of the input frame so that transmission errors do not propagate beyond a single frame.

This function saves the estimate array so that it can be compared to the output of the decoder - they should be identical.

CROSS REFERENCE

SDA AdpcmEncoder, SDA AdpcmDecoder.

void SDA_AdpcmDecoder (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function applies a one bit per sample ADPCM decoder to an individual frame of data. The previous sample is used as the estimate for the next sample.

NOTES ON USE

CROSS REFERENCE

SDA_AdpcmEncoder, SDA_AdpcmEncoderDebug.

MINIMUM AND MAXIMUM FUNCTIONS (minmax.c)

SDA_Max

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Max (const SLData_t *, Array pointer const SLArrayIndex t) Array length

DESCRIPTION

This function returns the maximum data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SLData_t SDA_AbsMax (const SLData_t *, Array pointer const SLArrayIndex_t)

Array length

DESCRIPTION

This function returns the maximum absolute data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SDA_Min

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Min (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the minimum data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SLData_t SDA_AbsMin (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the minimum absolute data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SDA_Middle

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Middle (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the middle data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SDA_Range

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Range (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the range of the values in the array. I.E. the difference between the maximum and the minimum values.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Middle, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalAbsMax, SDA_LocalAbsMin, SDA_LocalAbsMin, SDA_NSmallest.

SLArrayIndex_t SDA_MaxIndex (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the location of the maximum data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_NLargest, SDA_NSmallest.

SLArrayIndex_t SDA_AbsMaxIndex (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the location of the maximum absolute data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_AbsMax, SDA_Scale, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_NLargest, SDA_NSmallest.

SLArrayIndex_t SDA_MinIndex (const SLData_t *, Array pointer const SLArrayIndex t) Array length

DESCRIPTION

This function returns the location of the minimum data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Scale, SDA_AbsMax, SDA_Min, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMinIndex, SDA_NLargest, SDA_NSmallest.

SLArrayIndex_t SDA_AbsMinIndex (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the location of the minimum absolute data value in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_AbsMin, SDA_Scale, SDA_AbsMax, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_NLargest, SDA_NSmallest.

SDS_Max

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_Max (const SLData_t, Sample 1 const SLData_t) Sample 2

DESCRIPTION

This function returns the maximum value of the two samples.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_NLargest, SDA_NSmallest.

SLData_t SDS_AbsMax (const SLData_t, Sample 1 const SLData_t) Sample 2

DESCRIPTION

This function returns the maximum absolute value of the two samples.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_NLargest, SDA_NSmallest.

SDS_Min

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_Min (const SLData_t, Sample 1 const SLData_t) Sample 2

DESCRIPTION

This function returns the minimum value of the two samples.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_NLargest, SDA_NSmallest.

SLData_t SDS_AbsMin (const SLData_t, Sample 1 const SLData_t) Sample 2

DESCRIPTION

This function returns the minimum absolute value of the two samples.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_NLargest, SDA_NSmallest.

SLData_t SDA_LocalMax (const SLData_t *pSrc, Pointer to source array

const SLArrayIndex t, Location

const SLArrayIndex t, Number (N) of samples to search either

side of centre

const SLArrayIndex t) Array length

DESCRIPTION

This function returns the maximum data value in a small section of an array. The section is defined as the region around (N samples either side of) a centre location. E.g. If the location is 15 and N is 10 then the function will search the 21 samples centred on the 15th sample in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SLData t SDA LocalAbsMax (const SLData t *pSrc, Pointer to source array

const SLArrayIndex t, Location

const SLArrayIndex_t, Number (N) of samples to search either

side of centre

const SLArrayIndex t) Array length

DESCRIPTION

This function returns the maximum of the absolute data values within in a small section of an array. The section is defined as the region around (N samples either side of) a centre location. E.g. If the location is 15 and N is 10 then the function will search the 21 samples centred on the 15th sample in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SDA_LocalMin

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_LocalMin (const SLData_t *pSrc, Pointer to source array

const SLArrayIndex_t, Location

const SLArrayIndex_t, Number (N) of samples to search either

side of centre

const SLArrayIndex t) Array length

DESCRIPTION

This function returns the maximum data value in a small section of an array. The section is defined as the region around (N samples either side of) a centre location. E.g. If the location is 15 and N is 10 then the function will search the 21 samples centred on the 15th sample in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SLData_t SDA_LocalAbsMin (const SLData_t *pSrc, Pointer to source array

const SLArrayIndex t, Location

const SLArrayIndex_t, Number (N) of samples to search either

side of centre

const SLArrayIndex t) Array length

DESCRIPTION

This function returns the minimum of the absolute data values within a small section of an array. The section is defined as the region around (N samples either side of) a centre location. E.g. If the location is 15 and N is 10 then the function will search the 21 samples centred on the 15^{th} sample in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_NLargest, SDA_NSmallest.

SDA_Max2

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Max2 (const SLData_t *, Source array pointer #1 const SLData_t *, Source array pointer #2 SLData_t *, Destination array pointer const SLArrayIndex_t)

Array lengths

DESCRIPTION

For each sample in the source arrays, this function selects the maximum value and store it in the destination array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_Min, SDA_AbsMin, SDA_AbsMax2, SDA Min2, SDA AbsMin2, SDA NLargest, SDA NSmallest.

void SDA_AbsMax2 (const SLData_t *, Source array pointer #1 const SLData_t *, Surce array pointer #2 SLData_t *, Destination array pointer const SLArrayIndex_t)

Source array pointer #2 Destination array pointer Array lengths

DESCRIPTION

For each sample in the source arrays, this function selects the maximum of the absolute values and store it in the destination array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_Min, SDA_AbsMin, SDA_Max2, SDA_SignedAbsMax2, SDA_Min2, SDA_AbsMin2, SDA_NLargest, SDA_NSmallest.

void SDA_SignedAbsMax2 (const SLData_t *, Source array pointer #1 const SLData_t *, Source array pointer #2 SLData_t *, Destination array pointer const SLArrayIndex_t)

Array lengths

DESCRIPTION

For each sample in the source arrays, select the maximum of the absolute value and store the corresponding original value (including sign) in the destination array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_Min, SDA_AbsMin, SDA_Max2, SDA Min2, SDA AbsMin2, SDA NLargest, SDA NSmallest.

SDA_Min2

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Min2 (const SLData_t *, Source array pointer #1 const SLData_t *, Source array pointer #2 SLData_t *, Destination array pointer const SLArrayIndex_t)

Array lengths

DESCRIPTION

For each sample in the source arrays, this function selects the minimum value and store it in the destination array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_Min, SDA_AbsMin, SDA_Max2, SDA AbsMax2, SDA AbsMin2, SDA NLargest, SDA NSmallest.

SDA_AbsMin2

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_AbsMin2 (const SLData_t *, Source array pointer #1 const SLData_t *, Surce array pointer #2 SLData_t *, Destination array pointer const SLArrayIndex_t)

Source array pointer #2 Destination array pointer Array lengths

DESCRIPTION

For each sample in the source arrays, this function selects the minimum of the absolute values and store it in the destination array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_Min, SDA_AbsMin, SDA_SignedAbsMin2, SDA_Max2, SDA_AbsMax2, SDA_Min2, SDA_NLargest, SDA_NSmallest.

void SDA_SignedAbsMin2 (const SLData_t *, Source array pointer #1 const SLData_t *, Source array pointer #2 SLData_t *, Destination array pointer const SLArrayIndex_t)

Array lengths

DESCRIPTION

For each sample in the source arrays, select the minimum of the absolute value and store the corresponding original value (including sign) in the destination array.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_AbsMax, SDA_Min, SDA_AbsMin, SDA_Max2, SDA Min2, SDA AbsMin2, SDA NLargest, SDA NSmallest.

```
void SDA_PeakHold (const SLData_t *, Source array pointer SLData_t *, Peak array pointer const SLData_t, Peak decay rate SLData_t *, Previous peak value pointer const SLArrayIndex_t) Array lengths
```

DESCRIPTION

This function calculates the envelope of the signal using a decaying peak hold. The decay can be set on the peak signal, to enable it to follow decreasing signals. The pseudo code for the algorithm used is:

NOTES ON USE

The "pointer to previous peak value" parameter is used so that the function is reentrant and so that multiple streams can be processed simultaneously. It should be initialised to zero or other suitable value before calling this function. When the peak array is initialized to zero this algorithm only works on positive numbers.

CROSS REFERENCE

SDA PeakHoldPerSample


void SDA_PeakHoldPerSample (const SLData_t *, Source array pointer

SLData_t *, Output peak array pointer

const SLData_t, Peak decay rate const SLArrayIndex t) Array lengths

DESCRIPTION

This function calculates a "per sample" peak hold across successive arrays, the decay can be set on the peak signal, to enable it to follow the envelope of the signal. The following diagram shows how the system is configured:



NOTES ON USE

The array holding the peak values should be maintained in the calling function so that the data can be passed to SDA PeakHoldPerSample () on the next iteration.

You are advised to clear the peak array to zero, for example using SDA_Clear () function, before calling SDA_PeakHoldPerSample () for the first time.

CROSS REFERENCE

SDA PeakHold

 $SLArrayIndex_t \ SDA_DetectFirstPeakOverThreshold \ (const \ SLData_t \ *, \ Pointer \ to \ Po$

source array


const SLData_t, Threshold over which peak will be detected

const SLArrayIndex t) Array length

DESCRIPTION

This function returns the index of the first peak in an array that is over the given threshold. This function is commonly used with the FFT function for tracking the fundamental frequency in a signal.

The operation of this function is showed in the following diagram.



NOTES ON USE

CROSS REFERENCE

```
void SDS_Round (const SLData_t, Data sample const enum SLRoundingMode_t) Rounding mode
```

DESCRIPTION

This function rounds the sample to an integer, according to the rounding mode parameter which may take one of the following parameters:

```
SIGLIB_ROUND_UP,
SIGLIB_ROUND_TO_NEAREST,
SIGLIB_ROUND_DOWN,
SIGLIB_ROUND_TO_ZERO,
SIGLIB_ROUND_AWAY_FROM_ZERO.
```

NOTES ON USE

CROSS REFERENCE

 SDA_Round

```
void SDA_Round (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const enum SLRoundingMode_t, const SLArrayIndex_t) Rounding mode Array length
```

DESCRIPTION

This function rounds the samples in the array to integers, according to the rounding mode parameter which may take one of the following parameters:

```
SIGLIB_ROUND_UP,
SIGLIB_ROUND_TO_NEAREST,
SIGLIB_ROUND_DOWN,
SIGLIB_ROUND_TO_ZERO,
SIGLIB_ROUND_AWAY_FROM_ZERO.
```

NOTES ON USE

The source and destination pointers can point to the same array.

CROSS REFERENCE

SDS Round

SDS_Clip

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_Clip (const SLData_t, Input sample value to clip to const enum SLClipMode t)

SLData_t, Input sample value to clip to Direction to clip signal

DESCRIPTION

This function clips (I.E. clamps) the data sample to a given value, depending on the clip mode:

Clip Mode	Description
SIGLIB_CLIP_ABOVE	Clip any values above the clip level
SIGLIB_CLIP_BELOW	Clip any values below the clip level
SIGLIB_CLIP_BOTH	Clip any values above the clip level and any below the negative of the clip level
SIGLIB_CLIP_BOTH_BELOW	Clip any positive values below the clip level and any negative values above the negative of the given clip level

NOTES ON USE

CROSS REFERENCE

SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

SDA_Clip

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Clip (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t, Clip level const enum SLClipMode_t, const SLArrayIndex_t) Direction to clip signal Array length

DESCRIPTION

This function clips (I.E. clamps) the data in the array to a given value, depending on the clip mode:

Clip Mode	Description
SIGLIB_CLIP_ABOVE	Clip any values above the clip level
SIGLIB_CLIP_BELOW	Clip any values below the clip level
SIGLIB_CLIP_BOTH	Clip any values above the clip level and any below the negative of the clip level
SIGLIB_CLIP_BOTH_BELOW	Clip any positive values below the clip level and any negative values above the negative of the given clip level

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDS_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

void SDS_Threshold (const SLData_t, Input sample const SLData_t, Threshold const enum SLThresholdMode t) Threshold type

DESCRIPTION

This function applies a threshold to the sample. If the input is >= the threshold then it is passed to the output array, otherwise the output is set to zero.

The two types of threshold function are: SIGLIB_SINGLE_SIDED_THOLD and SIGLIB_DOUBLE_SIDED_THOLD where single sided sets values less than the threshold value to zero. The double sided threshold sets values between the threshold value and minus the threshold value to zero. All other values are left unchanged.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

void SDA_Threshold (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t, Threshold const enum SLThresholdMode_t, const SLArrayIndex_t) Threshold type Array length

DESCRIPTION

This function applies a threshold to the samples in the array. If the input is >= the threshold then it is passed to the output array, otherwise the output is set to zero.

The two types of threshold function are: SIGLIB_SINGLE_SIDED_THOLD and SIGLIB_DOUBLE_SIDED_THOLD where single sided sets values less than the threshold value to zero. The double sided threshold sets values between the threshold value and minus the threshold value to zero. All other values are left unchanged.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

void SDS_SoftThreshold (const SLData_t, Input sample const SLData_t) Threshold

DESCRIPTION

This function applies a "soft threshold" to the sample. The soft threshold sets values between the threshold value and minus the threshold value to zero. All other values have the threshold value subtracted from them. This operation removes the amplitude discontinuity that is present in the double-sided threshold function.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

void SDA_SoftThreshold (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t, Threshold const SLArrayIndex t) Array length

DESCRIPTION

This function applies a "soft threshold" to the samples in the array. The soft threshold sets values between the threshold value and minus the threshold value to zero. All other values have the threshold value subtracted from them. This operation removes the amplitude discontinuity that is present in the double-sided threshold function.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

void SDS_ThresholdAndClamp (const SLData_t *, Input value

const SLData_t, Threshold
const SLData_t, Clamp level
const enum SLThresholdMode t) Threshold type

DESCRIPTION

This function applies a threshold to the sample. If the input is >= than the threshold then it is set to the clamp value, otherwise the output is set to zero.

The two types of threshold function are: SIGLIB_SINGLE_SIDED_THOLD and SIGLIB_DOUBLE_SIDED_THOLD where single sided sets values less than the threshold value to zero. The double sided threshold sets values between the threshold value and minus the threshold value to zero. All other values are set to the clamp value.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDA_SoftThreshold, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

void SDA_ThresholdAndClamp (const SLData_t *, Source array pointer

SLData_t *, Destination array pointer

const SLData_t, Threshold
const SLData_t, Clamp level
const enum SLThresholdMode_t, Threshold type
const SLArrayIndex_t) Array length

DESCRIPTION

This function applies a threshold to the samples in the array. If the input is >= than the threshold then it is set to the clamp value, otherwise the output is set to zero.

The two types of threshold function are: SIGLIB_SINGLE_SIDED_THOLD and SIGLIB_DOUBLE_SIDED_THOLD where single sided sets values less than the threshold value to zero. The double sided threshold sets values between the threshold value and minus the threshold value to zero. All other values are set to the clamp value.

NOTES ON USE

This function is very useful for creating a data mask that can be applied to other arrays. For example, setting the clamp level to 1 creates a mask where values above the threshold are 1 and all other values are 0. Then multiplying the second array by the mask will only provide samples in the mask frame through.

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

SDS_Clamp

PROTOTYPE AND PARAMETER DESCRIPTION

void SDS_Clamp (const SLData_t *, Input sample const SLData_t, Threshold const SLData_t, Clamp value const enum SLThresholdMode t) Threshold type

DESCRIPTION

This function thresholds the sample. If the level is above the threshold then set the value to the clamping value. The two types of clamping function are: SIGLIB_SINGLE_SIDED_THOLD and SIGLIB_DOUBLE_SIDED_THOLD where single sided sets values above the threshold value to the clamping value. The double sided threshold sets values above the threshold value and below the negative of the threshold value to the clamping value or minus the clamping value respectively. All other values are left unchanged.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_SoftThreshold, SDA_ThresholdAndClamp, SDA_ThresholdAndClamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

SDA_Clamp

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Clamp (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t, Threshold Clamp value const enum SLThresholdMode_t, const SLArrayIndex_t) Threshold type Array length

DESCRIPTION

This function thresholds the samples in the array. If the level is above the threshold then set the value to the clamping value. The two types of clamping function are: SIGLIB_SINGLE_SIDED_THOLD and SIGLIB_DOUBLE_SIDED_THOLD where single sided sets values above the threshold value to the clamping value. The double sided threshold sets values above the threshold value and below the negative of the threshold value to the clamping value or minus the clamping value respectively. All other values are left unchanged.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_SoftThreshold, SDA_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

SLArrayIndex_t SDA_TestOverThreshold (const SLData_t *, Source array pointer const SLData_t, Threshold const SLArrayIndex t) Array length

DESCRIPTION

This function tests the thresholds of the samples in the array. If any sample in the array is over the threshold level then this function will return the location of the first sample that is greater than the threshold. If there are no samples greater than the threshold then this function will return: SIGLIB SIGNAL NOT PRESENT.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestAbsOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

SLArrayIndex_t SDA_TestAbsOverThreshold (const SLData_t *, Source pointer const SLData_t, Threshold const SLArrayIndex_t) Array length

DESCRIPTION

This function tests the absolute thresholds of the samples in the array. If the absolute value of any sample in the array is over the threshold level then this function will return the location of the first sample that has an absolute value greater than the threshold. If there are no samples greater than the threshold then this function will return: SIGLIB SIGNAL NOT PRESENT.

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDS_SetMinValue, SDA_SetMinValue.

void SDA_SelectMax (const SLData_t *,
const SLData_t *,
SLData_t *,Source array pointer 1
Source array pointer 2
Destination array pointer
Sample array length

DESCRIPTION

This function selects the maximum level from either array 1 or array 2 and place it in the destination array.

NOTES ON USE

CROSS REFERENCE

SDA_SelectMin, SDA_SelectMagnitudeSquaredMax, SDA_SelectMagnitudeSquaredMin

void SDA_SelectMin (const SLData_t *,
const SLData_t *,
SLData_t *,Source array pointer 1
Source array pointer 2
Destination array pointer
Sample array length

DESCRIPTION

This function selects the minimum level from either array 1 or array 2 and place it in the destination array.

NOTES ON USE

CROSS REFERENCE

SDA_SelectMax, SDA_SelectMagnitudeSquaredMax, SDA_SelectMagnitudeSquaredMin

```
void SDA_SelectMagnitudeSquaredMax (const SLData_t *, Real Source 1 const SLData_t *, Imaginary source array 1 pointer const SLData_t *, Real source array 2 pointer const SLData_t *, Imaginary source array 2 pointer SLData_t *, Real destination array pointer SLData_t *, Imaginary destination array pointer const SLArrayIndex t) Sample array length
```

DESCRIPTION

This function selects the maximum magnitude squared level from either arrays 1 (real + complex) or arrays 2 (real + complex) and place it in the destination arrays (real + complex).

NOTES ON USE

CROSS REFERENCE

 $SDA_SelectMax, SDA_SelectMin, SDA_SelectMagnitudeSquaredMin$

void SDA_SelectMagnitudeSquaredMin (const SLData_t *, Real src. array 1 pointer

```
const SLData_t *, Imaginary source array 1 pointer const SLData_t *, Real source array 2 pointer const SLData_t *, Imaginary source array 2 pointer SLData_t *, Real destination array pointer SLData_t *, Imaginary destination array pointer const SLArrayIndex_t) Sample array length
```

DESCRIPTION

This function selects the minimum magnitude squared level from either arrays 1 (real + complex) or arrays 2 (real + complex) and place it in the destination arrays (real + complex).

NOTES ON USE

CROSS REFERENCE

SDA_SelectMax, SDA_SelectMin, SDA_SelectMagnitudeSquaredMax

void SDS_SetMinValue (const SLData_t, Input Sample const SLData_t) Input Sample Minimum value

DESCRIPTION

This function sets the minimum sample value i.e.:

if the value is positive (or zero) and below the minimum value then it is set to the minimum value

if the value is negative and above the minimum value then it is set to the negative of the minimum value

otherwise the value is unchanged

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDA_SetMinValue.

void SDA_SetMinValue (const SLData_t *, Pointer to source array

SLData_t *, Pointer to destination array

const SLData_t, Minimum value const SLArrayIndex t) Array length

DESCRIPTION

This function sets the minimum value in the source array i.e.:

if the value is positive (or zero) and below the minimum value then it is set to the minimum value

if the value is negative and above the minimum value then it is set to the negative of the minimum value

otherwise the value is unchanged

NOTES ON USE

CROSS REFERENCE

SDS_Clip, SDA_Clip, SDS_Threshold, SDA_Threshold, SDS_SoftThreshold, SDA_SoftThreshold, SDS_ThresholdAndClamp, SDA_ThresholdAndClamp, SDS_Clamp, SDA_Clamp, SDA_TestOverThreshold, SDA_TestAbsOverThreshold, SDS_SetMinValue.

SLData_t SDA_PeakToAverageRatio (const SLData_t *, Pointer to source data const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the ratio of the peak value to the average value of the input scalar data.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Mean, SDA_PeakToAveragePowerRatio, SDA_PeakToAveragePowerRatioDB, SDA_PeakToAverageRatioComplex, SDA_PeakToAveragePowerRatioComplex, SDA_PeakToAveragePowerRatioComplexDB

SLData_t SDA_PeakToAveragePowerRatio (const SLData_t *, Pointer to source const SLArrayIndex t)

Array length

DESCRIPTION

This function returns the ratio of the peak power to the average power of the input scalar data.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Mean, SDA_PeakToAverageRatio, SDA_PeakToAveragePowerRatioDB, SDA_PeakToAverageRatioComplex, SDA_PeakToAveragePowerRatioComplex, SDA_PeakToAveragePowerRatioComplexDB

SLData_t SDA_PeakToAveragePowerRatioDB (const SLData_t *, Pointer to source const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the ratio of the peak power to the average power, in dB, of the input scalar data.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Mean, SDA_PeakToAverageRatio, SDA_PeakToAveragePowerRatio, SDA_PeakToAveragePowerRatioComplex, SDA_PeakToAveragePowerRatioComplex, SDA_PeakToAveragePowerRatioComplexDB

SLData_t SDA_PeakToAverageRatioComplex (const SLData_t *, Pointer to real source array

const SLData_t *, Pointer to imaginary source array

const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the ratio of the peak value to the average value of the input complex data.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Mean, SDA_PeakToAverageRatio, SDA_PeakToAveragePowerRatioDB, SDA_PeakToAveragePowerDB, SDA_PeakToAveragePo

SDA_PeakToAveragePowerRatioComplex,

SDA_PeakToAveragePowerRatioComplexDB

SLData_t SDA_PeakToAveragePowerRatioComplex (const SLData_t *, Pointer to real source array

const SLData_t *, Pointer to imaginary source array

const SLArrayIndex t) Array length

DESCRIPTION

This function returns the ratio of the peak power to the average power of the input complex data.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Mean, SDA_PeakToAverageRatio, SDA_PeakToAveragePowerRatio, SDA_PeakToAveragePowerRatioDB, SDA_PeakToAverageRatioComplex, SDA_PeakToAveragePowerRatioComplexDB

SLData_t SDA_PeakToAveragePowerRatioComplexDB (const SLData_t *,

Pointer to real source array

const SLData t*, Pointer to imaginary source array

const SLArrayIndex t) Array length

DESCRIPTION

This function returns the ratio of the peak power to the average power, in dB, of the input complex data.

NOTES ON USE

CROSS REFERENCE

SDA_Max, SDA_Mean, SDA_PeakToAverageRatio, SDA_PeakToAveragePowerRatioDB, SDA_PeakToAverageRatioComplex, SDA_PeakToAveragePowerRatioComplex

void SDA_MovePeakTowardsDeadBand (const SLData_t *, Pointer to source array

SLData_t *, Pointer to destination array const SLArrayIndex_t, Dead-band low-point const SLArrayIndex_t, Dead-band high-point

const SLArrayIndex t) Array length

DESCRIPTION

This function locates the peak value and then shifts all of the data so that the peak moves towards the dead-band. The function accepts a dead-band, within which the data is not shifted.

This function shifts the peak by one location on each iteration.

NOTES ON USE

CROSS REFERENCE

void SIF_Envelope (SLData_t *) Pointer to filter state variable

DESCRIPTION

This function initializes the envelope detection function.

NOTES ON USE

CROSS REFERENCE

SDS_Envelope, SDA_Envelope, SIF_EnvelopeRMS, SDS_EnvelopeRMS, SDA_EnvelopeRMS, SIF_EnvelopeHilbert, SDS_EnvelopeHilbert, SDA_EnvelopeHilbert

SLData_t SDS_Envelope (const SLData_t, Source sample const SLData_t, Attack coefficient const SLData_t, Decay coefficient SLData_t *)

SUData_t SDS_Envelope (const SLData_t, Surce sample Attack coefficient Decay coefficient Pointer to filter state variable

DESCRIPTION

This function generates an envelope of the input sequence using a single one-pole filter.

NOTES ON USE

A larger one-pole filter coefficient leads to a smoother response but may miss high frequency artefacts.

CROSS REFERENCE

SIF_Envelope, SDA_Envelope, SIF_EnvelopeRMS, SDS_EnvelopeRMS, SDA_EnvelopeRMS, SIF_EnvelopeHilbert, SDS_EnvelopeHilbert, SDA_EnvelopeHilbert

void SDA_Envelope (const SLData_t *, SLData_t *, Pointer to source array Pointer to destination array Attack coefficient Const SLData_t, Decay coefficient SLData_t *, Pointer to filter state variable Const SLArrayIndex t)

Pointer to source array Pointer to destination array Attack coefficient Decay coefficient Pointer to filter state variable Input array length

DESCRIPTION

This function generates an envelope of the input sequence using a single one-pole filter.

NOTES ON USE

A larger one-pole filter coefficient leads to a smoother response but may miss high frequency artefacts.

CROSS REFERENCE

SIF_Envelope, SDS_Envelope, SIF_EnvelopeRMS, SDS_EnvelopeRMS, SDA_EnvelopeRMS, SIF_EnvelopeHilbert, SDS_EnvelopeHilbert, SDA_EnvelopeHilbert

void SIF_EnvelopeRMS (SLData_t *) Pointer to filter state variable

DESCRIPTION

This function initializes the envelope detection function, with RMS.

NOTES ON USE

CROSS REFERENCE

SIF_Envelope, SDS_Envelope, SDA_Envelope, SDS_EnvelopeRMS, SDA_EnvelopeRMS, SIF_EnvelopeHilbert, SDS_EnvelopeHilbert, SDA_EnvelopeHilbert

SLData_t SDS_EnvelopeRMS (const SLData_t, Source sample const SLData_t, Attack coefficient const SLData_t, Decay coefficient SLData_t *)

SLData_t *)

Pointer to filter state variable

DESCRIPTION

This function generates an envelope of the input sequence using a single one-pole filter, with RMS.

NOTES ON USE

A larger one-pole filter coefficient leads to a smoother response but may miss high frequency artefacts.

CROSS REFERENCE

SIF_Envelope, SDS_Envelope, SDA_Envelope, SIF_EnvelopeRMS, SDA_EnvelopeRMS, SIF_EnvelopeHilbert, SDS_EnvelopeHilbert, SDA_EnvelopeHilbert

void SDA_EnvelopeRMS (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLData_t, Attack coefficient const SLData_t, Decay coefficient SLData_t *, Pointer to filter state variable const SLArrayIndex t) Input array length

DESCRIPTION

This function generates an envelope of the input sequence using a single one-pole filter, with RMS.

NOTES ON USE

A larger one-pole filter coefficient leads to a smoother response but may miss high frequency artefacts.

CROSS REFERENCE

SIF_Envelope, SDS_Envelope, SDA_Envelope, SIF_EnvelopeRMS, SDS_EnvelopeRMS, SIF_EnvelopeHilbert, SDS_EnvelopeHilbert, SDA_EnvelopeHilbert

void SIF_EnvelopeHilbert (SLData_t *, coefficient array

SLData_t *, Pointer to Hilbert transform filter

SLArrayIndex_t *, Pointer to filter state array

SLData_t *, Pointer to filter index

SLData_t *, Pointer to filter index

Pointer to filter delay compensator array

const SLArrayIndex_t, Filter length

const SLArrayIndex_t, Filter group delay

SLData_t *) Pointer to one-pole state variable

DESCRIPTION

This function initializes the envelope detection function using the Hilbert transform.

NOTES ON USE

CROSS REFERENCE

SIF_Envelope, SDS_Envelope, SDA_Envelope, SIF_EnvelopeRMS, SDS_EnvelopeRMS, SDA_EnvelopeRMS SDS_EnvelopeHilbert, SDA_EnvelopeHilbert

SLData t SDS EnvelopeHilbert (const SLData t, Source sample const SLData t*, Pointer to Hilbert transform filter coefficient array SLData t*, Pointer to filter state array SLArrayIndex t*, Pointer to filter index SLData t*, Pointer to filter delay compensator array SLArrayIndex t*, Pointer to delay index const SLArrayIndex_t, Filter length const SLArrayIndex t, Filter group delay one-pole filter coefficient const SLData t, Pointer to one-pole state variable SLData t*)

DESCRIPTION

This function generates an envelope of the input sequence, where the envelope is the absolute maximum of the signal and the Hilbert transformed signal. The absolute maximum is then one-pole filtered to smooth the response.

NOTES ON USE

Critical parameters for this function are the filter length and the one-pole filter coefficient.

Longer filter lengths are required for lower frequency signals but this leads to a longer group delay.

A larger one-pole filter coefficient leads to a smoother response but may miss high frequency artefacts.

CROSS REFERENCE

```
SIF_Envelope, SDS_Envelope, SDA_Envelope, SIF_EnvelopeRMS, SDS_EnvelopeRMS, SDA_EnvelopeRMS, SIF_EnvelopeHilbert, SDA_EnvelopeHilbert
```

```
void SDA EnvelopeHilbert (const SLData t*,
                                                   Pointer to source array
       SLData t*,
                                            Pointer to destination array
       const SLData t*,
                                            Pointer to Hilbert transform filter
coefficient array
       SLData t*,
                                            Pointer to filter state array
       SLArrayIndex t*,
                                            Pointer to filter index
                                            Pointer to temp. analytical signal array
       SLData t*,
                                            Pointer to filter delay compensator array
       SLData t*,
       SLData t*,
                                            Pointer to temporary delay array
       const SLArrayIndex_t,
                                            Filter length
                                            Filter group delay
       const SLArrayIndex t,
       const SLData t,
                                            one-pole filter coefficient
       SLData t*,
                                            Pointer to one-pole state variable
       const SLArrayIndex t)
                                            Input array length
```

DESCRIPTION

This function generates an envelope of the input sequence, where the envelope is the absolute maximum of the signal and the Hilbert transformed signal. The absolute maximum is then one-pole filtered to smooth the response.

NOTES ON USE

Critical parameters for this function are the filter length and the one-pole filter coefficient.

Longer filter lengths are required for lower frequency signals but this leads to a longer group delay.

A larger one-pole filter coefficient leads to a smoother response but may miss high frequency artefacts.

CROSS REFERENCE


```
SIF_Envelope, SDS_Envelope, SDA_Envelope, SIF_EnvelopeRMS, SDS_EnvelopeRMS, SDA_EnvelopeRMS, SIF_EnvelopeHilbert, SDS_EnvelopeHilbert
```

SLData_t SDS_InterpolateThreePointQuadraticVertexMagnitude (const SLData_t, y0 const SLData_t, y1 const SLData_t) y2

DESCRIPTION

This function returns the y-axis magnitude of the vertex (positive or negative) generated from the three points, y0, y1 and y2, assuming the x-axis values are x0=0, x1=1, x2=2.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS_InterpolateThreePointQuadraticVertexLocation,

SDS InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticPeakVertexMagnitude,

$SDS\ Interpolate Three Point Quadratic Vertex Location$


PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_InterpolateThreePointQuadraticVertexLocation (const SLData_t, y0 const SLData_t, y1 const SLData_t) y2

DESCRIPTION

This function returns the x-axis location of the vertex (positive or negative) generated from the three points, y0, y1 and y2, assuming the x-axis values are x0=0, x1=1, x2=2.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS_InterpolateThreePointQuadraticVertexMagnitude,

SDS InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticPeakVertexMagnitude,


SLData_t SDS_InterpolateArbitraryThreePointQuadraticVertexMagnitude (const SLData_t, x0

a_t, x0	
const SLData_t,	y0
const SLData_t,	x 1
const SLData_t,	y1
const SLData_t,	x2
const SLData t)	y2

DESCRIPTION

This function returns the y-axis magnitude of the vertex (positive or negative) generated from the three arbitrary points, x0/y0, x1/y1 and x2/y2.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS InterpolateThreePointQuadraticVertexMagnitude,

 $SDS_InterpolateThreePointQuadraticVertexLocation,$

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,

 $SDA_Interpolate Arbitrary Three Point Quadratic Peak Vertex Magnitude,\\$

SDS InterpolateArbitraryThreePointQuadraticVertexLocation

PROTOTYPE AND PARAMETER DESCRIPTION


SLData_t SDS_InterpolateArbitraryThreePointQuadraticVertexLocation (const SLData_t, x0

ιια_ι, Λ0	
const SLData_t,	y0
const SLData_t,	x1
const SLData_t,	y1
const SLData_t,	x2
const SLData t)	y2

DESCRIPTION

This function returns the x-axis location of the vertex (positive or negative) generated from the three arbitrary points, x0/y0, x1/y1 and x2/y2.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS InterpolateThreePointQuadraticVertexMagnitude,

SDS InterpolateThreePointQuadraticVertexLocation,

SDS InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,


 $SDA_Interpolate Arbitrary Three Point Quadratic Peak Vertex Magnitude, \\$

SLData_t SDA_InterpolateThreePointQuadraticVertexMagnitude (const SLData_t *)
Pointer to source array

DESCRIPTION

This function returns the y-axis magnitude of the vertex (positive or negative) generated from the three points, y0, y1 and y2, located in the source array indices 0, 1 and 2.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS InterpolateThreePointQuadraticVertexMagnitude,

SDS InterpolateThreePointQuadraticVertexLocation,

SDS InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,


SDA InterpolateArbitraryThreePointQuadraticPeakVertexMagnitude,

SLData_t SDA_InterpolateThreePointQuadraticVertexLocation (const SLData_t *)
Pointer to source array

DESCRIPTION

This function returns the x-axis location of the vertex (positive or negative) generated from the three points, y0, y1 and y2, located in the source array indices 0, 1 and 2.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS InterpolateThreePointQuadraticVertexMagnitude,

SDS InterpolateThreePointQuadraticVertexLocation,

SDS InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,


 $SDA_Interpolate Arbitrary Three Point Quadratic Peak Vertex Magnitude,$

DESCRIPTION

This function returns the y-axis magnitude of the vertex (positive or negative) generated from the three arbitrary points, x0/y0, x1/y1 and x2/y2.

The function first searches the array for the index of the absolute peak value which is selected to be the x1value. X0 is the previous value and x2 is the subsequent value in the source array. The associated y0, y1 and y2 values are calculated from the array index of the peak location.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS InterpolateThreePointQuadraticVertexMagnitude,

SDS InterpolateThreePointQuadraticVertexLocation,

SDS InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticPeakVertexMagnitude,

$SDA\ Interpolate Arbitrary Three Point Quadratic Vertex Location$


PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function returns the x-axis location of the vertex (positive or negative) generated from the three arbitrary points, x0/y0, x1/y1 and x2/y2.

The function first searches the array for the index of the absolute peak value which is selected to be the x1 value. X0 is the previous value and x2 is the subsequent value in the source array. The associated y0, y1 and y2 values are calculated from the array index of the peak location.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS InterpolateThreePointQuadraticVertexMagnitude,

SDS InterpolateThreePointQuadraticVertexLocation,

 $SDS_Interpolate Arbitrary Three Point Quadratic Vertex Magnitude,$

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticVertexMagnitude,

 $SDA_Interpolate Arbitrary Three Point Quadratic Peak Vertex Magnitude,\\$

$SDA\ Interpolate Arbitrary Three Point Quadratic Peak Vertex Magnitude$

PROTOTYPE AND PARAMETER DESCRIPTION


SLData_t SDA_InterpolateArbitraryThreePointQuadraticPeakVertexMagnitude (
 const SLData_t *, Pointer to source array
 const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the y-axis magnitude of the vertex (positive only) generated from the three arbitrary points, x0/y0, x1/y1 and x2/y2.

The function first searches the array for the index of the peak value which is selected to be the x1value. X0 is the previous value and x2 is the subsequent value in the source array. The associated y0, y1 and y2 values are calculated from the array index of the peak location.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS InterpolateThreePointQuadraticVertexMagnitude,

SDS InterpolateThreePointQuadraticVertexLocation,

SDS InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexLocation,

 $SDA_Interpolate Arbitrary Three Point Quadratic Vertex Magnitude,\\$

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,

$SDA\ Interpolate Arbitrary Three Point Quadratic Peak Vertex Location$

PROTOTYPE AND PARAMETER DESCRIPTION


SLData_t SDA_InterpolateArbitraryThreePointQuadraticPeakVertexLocation (
 const SLData_t *, Pointer to source array
 const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the x-axis location of the vertex (positive only) generated from the three arbitrary points, x0/y0, x1/y1 and x2/y2.

The function first searches the array for the index of the peak value which is selected to be the x1 value. X0 is the previous value and x2 is the subsequent value in the source array. The associated y0, y1 and y2 values are calculated from the array index of the peak location.

The function uses quadratic interpolation, as shown in the following diagram.



NOTES ON USE

It is important that k_m is the largest positive or smallest negative value in the sequence.

CROSS REFERENCE

SDS InterpolateThreePointQuadraticVertexMagnitude,

SDS InterpolateThreePointQuadraticVertexLocation,

SDS InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDS InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateThreePointQuadraticVertexMagnitude,

SDA InterpolateThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticVertexMagnitude,

SDA InterpolateArbitraryThreePointQuadraticVertexLocation,

SDA InterpolateArbitraryThreePointQuadraticPeakVertexMagnitude

SLData_t SDA_FirstMinVertex (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the first minimum vertex value in an array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_FirstMinVertex, SDA_FirstMinVertexPos, SDA_FirstMaxVertex, SDA_FirstMaxVertexPos, SDA_NLargest, SDA_NSmallest.

SLData_t SDA_FirstMinVertexPos (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the index of the first minimum vertex in an array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_FirstMinVertex, SDA_FirstMaxVertex, SDA_FirstMaxVertexPos, SDA_NLargest, SDA_NSmallest.

SLData_t SDA_FirstMaxVertex (const SLData_t *, Array pointer const SLArrayIndex_t)

Array length

DESCRIPTION

This function returns the first maximum vertex value in an array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_FirstMinVertex, SDA_FirstMinVertexPos, SDA_FirstMaxVertexPos, SDA_NLargest, SDA_NSmallest.

SLData_t SDA_FirstMaxVertexPos (const SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the index of the first maximum vertex in an array.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_FirstMinVertexPos, SDA_FirstMaxVertex, SDA_NLargest, SDA_NSmallest.

void SDA_NLargest (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t, Source array length Number of values to find

DESCRIPTION

This function returns the first N largest values in the source array, the order is largest to smallest.

This algorithm supports duplicate numbers.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_FirstMinVertexPos, SDA_FirstMaxVertex, SDA_FirstMaxVertexPos, SDA_NLargest, SDA_NSmallest.

void SDA_NSmallest (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t, Source array length const SLArrayIndex t) Number of values to find

DESCRIPTION

This function returns the first N smallest values in the source array, the order is smallest to largest.

This algorithm supports duplicate numbers.

NOTES ON USE

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_AbsMax, SDA_AbsMin, SDA_Middle, SDA_MaxIndex, SDA_AbsMaxIndex, SDA_MinIndex, SDA_AbsMinIndex, SDA_LocalMax, SDA_LocalAbsMax, SDA_LocalMin, SDA_LocalAbsMin, SDA_FirstMinVertexPos, SDA_FirstMaxVertex, SDA_FirstMaxVertexPos, SDA_NLargest, SDA_NSmallest.

MATH FUNCTIONS (smath.c)

SDA_Divide

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Divide (const SLData_t *, Source array pointer const SLData_t, Divisor SLData_t *, Destination array pointer const SLArrayIndex t) Array length

DESCRIPTION

This function divides all entries in the array of data by a scalar value.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA_Divide2, SDA_Multiply, SDA_Max, SDA_Min, SDA_Scale, SDA AbsMax, SDA AbsMin.

SDA_Divide2

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Divide2 (const SLData_t *,
const SLData_t *,Source array pointer 1SLData_t *,
const SLArrayIndex_t)Destination array pointerArray lengths

DESCRIPTION

This function divides one vector array by another, entry by entry, place the results in a third array, the destination array may be one of the source arrays.

NOTES ON USE

CROSS REFERENCE

SDA_Divide, SDA_Multiply, SDA_Multiply2, SDA_Max, SDA_Min, SDA_Scale.

SDA_Multiply

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Multiply (const SLData_t *, Source array pointer const SLData_t, Scalar multiplier SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function multiplies all entries in the array of data by a scalar value.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA_Divide, SDA_Max, SDA_Min, SDA_Scale, SDA_ComplexMultiply2, SDA_Multiply2, SDA_RealDotProduct, SDA_ComplexDotProduct.

void SDA_Multiply2 (const SLData_t *,
const SLData_t *,
SLData_t *,
const SLArrayIndex_t)Source array pointer 1
Source array pointer 2
Destination array pointer
Array lengths

DESCRIPTION

This function multiplies two arrays together, entry by entry, place the results in a third array, the destination array may be one of the source arrays.

NOTES ON USE

CROSS REFERENCE

SDA_Divide, SDA_Divide2, SDA_Multiply, SDA_Max, SDA_Min, SDA_Scale, SDA_Multiply, SDA_ComplexMultiply2, SDA_RealDotProduct, SDA_ComplexDotProduct.

void SDS_ComplexMultiply (const SLData	_t, Real source 1
const SLData_t,	Imaginary source 1
const SLData_t,	Real source 2
const SLData_t,	Imaginary source 2
SLData_t *,	Real result
SLData_t *)	Imaginary result

DESCRIPTION

This function multiplies the contents of one complex variable by another - the real and imaginary components are stored in separate memory locations.

$$(a + jb) * (c + jd) = (ac - bd) + j(ad + bc)$$

NOTES ON USE

CROSS REFERENCE

SDS_ComplexInverse, SDS_ComplexDivide, SDA_ComplexRectMultiply, SDA_ComplexRectDivide, SCV_Multiply, SCV_Inverse, SCV_Divide.

DESCRIPTION

This function inverts the complex variable - the real and imaginary components are stored in separate memory locations.

$$1/(a+jb) = (a-jb) / (a^2 + b^2)$$

NOTES ON USE

CROSS REFERENCE

SDA_ComplexInverse, SDS_ComplexMultiply, SDS_ComplexDivide, SDA_ComplexRectMultiply, SDA_ComplexRectDivide, SCV_Multiply, SCV_Inverse, SCV_Divide.

void SDA_ComplexInverse (const SLData_t *, Pointer to real source array 1 const SLData_t *, Pointer to imaginary source array 1 SLData_t *, Pointer to real destination array SLData_t *, Pointer to imaginary destination array const SLArrayIndex t) Array lengths

DESCRIPTION

This function inverts the complex values in the source array - the real and imaginary components are stored in separate arrays.

$$1/(a+jb) = (a-jb)/(a^2+b^2)$$

NOTES ON USE

CROSS REFERENCE

SDS_ComplexInverse, SDS_ComplexMultiply, SDS_ComplexDivide, SDA_ComplexRectMultiply, SDA_ComplexRectDivide, SCV_Multiply, SCV_Inverse, SCV_Divide.

void SDS_ComplexDivide (const SLData_t, Numerator source 1 const SLData_t, Numerator source 1 const SLData_t, Denominator source 2 const SLData_t, Denominator source 2 SLData_t *, Real result Imaginary result

DESCRIPTION

This function divides the contents of one complex variable by another - the real and imaginary components are stored in separate memory locations.

$$1/(a+jb) = (a-jb) / (a^2 + b^2)$$

(a+jb) * (c+jd) = (ac-bd) + j(ad+bc)

NOTES ON USE

CROSS REFERENCE

SDS_ComplexMultiply, SDS_ComplexInverse, SDA_ComplexRectMultiply, SDA_ComplexRectDivide, SCV_Multiply, SCV_Inverse, SCV_Divide.

void SDA_ComplexScalarMultiply (const SLData_t *, Real source array 1 const SLData_t *, Imaginary source array 1 pointer const SLData_t, Scalar multiplier SLData_t *, Real destination array pointer SLData_t *, Imaginary destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function multiplies the contents of the complex arrays by the scalar value.

NOTES ON USE

CROSS REFERENCE

SDA_Divide, SDA_Divide2, SDA_Multiply, SDA_Max, SDA_Min, SDA_Scale, SDA_Multiply2, SDA_ComplexMultiply2, SDA_RealDotProduct, SDA_ComplexDotProduct.

void SDA_ComplexMultiply2 (const SLData_t *, Real source array 1 const SLData_t *, Imaginary source array 1 pointer const SLData_t *, Real source array 2 pointer const SLData_t *, Imaginary source array 2 pointer SLData_t *, Real destination array pointer SLData_t *, Imaginary destination array pointer const SLArrayIndex_t) Array lengths

DESCRIPTION

This function complex multiplies two vectors together, entry by entry, place the results in a third array, using the following equation:

$$(a + jb).(c + jd) = (ac - bd) + j(ad + bc)$$

NOTES ON USE

The destination array may be any of the source arrays.

CROSS REFERENCE

SDA_Divide, SDA_Divide2, SDA_Multiply, SDA_Max, SDA_Min, SDA_Scale, SDA_Multiply2, SDA_ComplexScalarMultiply, SDA_RealDotProduct, SDA_ComplexDotProduct.

void SDA_ComplexScalarDivide (const SLData_t *, Pointer to real numerator source array

const SLData_t *, Pointer to imag. numerator source array const SLData_t, Scalar divisor SLData_t *, Pointer to real destination array SLData_t *, Pointer to imaginary destination array const SLArrayIndex_t) Array lengths

DESCRIPTION

This function divides the complex vector arrays by the divisor.

NOTES ON USE

CROSS REFERENCE

SDA_Divide, SDA_Divide2, SDA_Multiply, SDA_Max, SDA_Min, SDA_Scale, SDA_Multiply2, SDA_ComplexDivide2, SDA_RealDotProduct, SDA_ComplexDotProduct.

void SDA_ComplexDivide2 (const SLData_t *, Pointer to real numerator source array const SLData_t *, Pointer to imag. numerator source array const SLData_t *, Pointer to real denominator source array const SLData_t *, Pointer to imag denominator source array SLData_t *, Pointer to real destination array SLData_t *, Pointer to imaginary destination array const SLArrayIndex t) Array lengths

DESCRIPTION

This function complex divides the numerator vector by the denominator.

NOTES ON USE

The destination array may be either of the source arrays.

CROSS REFERENCE

SDA_Divide, SDA_Divide2, SDA_Multiply, SDA_Max, SDA_Min, SDA_Scale, SDA_Multiply2, SDA_ComplexScalarDivide, SDA_RealDotProduct, SDA_ComplexDotProduct.

DESCRIPTION

This function returns the vector dot product of the two real vectors, using the following equation:

$$(x,y) = \sum_{i=1}^{N} x_i \cdot y_i$$

This operation is also sometimes referred to as the *inner product*.

NOTES ON USE

CROSS REFERENCE

SDA_Divide, SDA_Divide2, SDA_Multiply, SDA_Max, SDA_Min, SDA_Scale, SDA_Multiply, SDA_Multiply2, SDA_ComplexMultiply2 SDA_ComplexDotProduct.

SLComplexRect_s SDA_ComplexDotProduct (const SLData_t *, Real src. vector 1 ptr.

const SLData_t *, Imaginary source vector 1 pointer const SLData_t *, Real source vector 2 pointer const SLData_t *, Imaginary source vector 2 pointer const SLArrayIndex t) Vector lengths

DESCRIPTION

This function returns the vector dot product of the two complex vectors, using the following equation:

$$(x,y) = \sum_{i=1}^{N} x_i \cdot \overline{y}_i$$

This operation is also sometimes referred to as the *inner product*.

$$\overline{y}$$
 is the complex conjugate of the vector

NOTES ON USE

CROSS REFERENCE

SDA_Divide, SDA_Divide2, SDA_Multiply, SDA_Max, SDA_Min, SDA_Scale, SDA_Multiply, SDA_Multiply2, SDA_ComplexMultiply2 SDA RealDotProduct.

void SDA_SumAndDifference (const SLData_t *, Source array pointer 1

const SLData_t *, Source array pointer 2

SLData_t *, Sum destination array pointer

SLData t*, Difference destination array pointer

const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the sum and difference between the samples in the two arrays.

NOTES ON USE

CROSS REFERENCE

SDA_AddN, SDA_Subtract2

void SDA_AddN (const SLData_t *, Source array pointer 1

> const SLData t*, SLData_t *,

const SLArrayIndex_t)

Source array pointer NDestination array pointer

Array length

DESCRIPTION

This function adds the contents of N arrays together.

NOTES ON USE

 $2 \le N \le 5$.

CROSS REFERENCE

SDA_Subtract2

```
void SDA_WeightedSum (const SLData_t *, Source array pointer 1 const SLData_t *, Source array pointer 2 SLData_t *, Destination array pointer SLData_t, Weighting factor for vector 1 const SLArrayIndex t)

Array length
```

DESCRIPTION

This function adds the contents of one array to the other and place the results in a third. The values in array 1 are pre-multiplied by a constant weighting value. i.e.: Destination[i] = (Weight * Source1[i]) + Source2[i].

NOTES ON USE

CROSS REFERENCE

void SDA_Subtract2 (const SLData_t *,
const SLData_t *,
SLData_t *,Source array pointer 1
Source array pointer 2
Destination array pointer
Array length

DESCRIPTION

This function subtracts the contents of one array from the other and place the results in a third.

i.e. Destination = Source1 - Source2.

NOTES ON USE

CROSS REFERENCE

SDA AddN

SDA_Add

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Add (const SLData_t *,
const SLData_t,Source array pointerSLData_t *,
const SLArrayIndex_t)Destination array pointerArray length

DESCRIPTION

This function adds the scalar offset to each value in an array.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE SDA PositiveOffset, SDA NegativeOffset

SLData_t SDA_PositiveOffset (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function adds an offset to the data to ensure that all the values are positive and the smallest value is zero.

NOTES ON USE

CROSS REFERENCE SDA_Add, SDA_NegativeOffset

SLData_t SDA_NegativeOffset (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function adds an offset to the data to ensure that all the values are negative and the largest value is zero.

NOTES ON USE

CROSS REFERENCE SDA_Add, SDA_PositiveOffset

void SDA_Negate (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function negates all entries in the array of data.

NOTES ON USE

The source and destination pointers can point to the same array.

void SDA_Inverse (const SLData_t *, Source data pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the reciprocal of the data in the array.

NOTES ON USE

The source and destination pointers can point to the same location.

void SDA_Square (const SLData_t *, Source data pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the square of the data in the array.

NOTES ON USE

The source and destination pointers can point to the same location.

SDA_Sqrt

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Sqrt (const SLData_t *, Source data pointer
SLData_t *, Destination array pointer
const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the square root of the data in the array.

NOTES ON USE

The source and destination pointers can point to the same location.

```
void SDA_Difference (const SLData_t *, Const SLData_t *, SLData_t *, SLData_t *, Const SLArrayIndex_t)

Pointer to source array 1
Pointer to source array 2
Pointer to destination array
Array length
```

DESCRIPTION

This function returns the differences of the data in the two arrays. The difference value is always positive.

NOTES ON USE

The source and destination pointers can point to the same location.

CROSS REFERENCE SDA_SumOfDifferences

SLData_t SDA_SumOfDifferences (const SLData_t *, Pointer to source array 1 const SLData_t *, Pointer to source array 2 const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the sum of the differences of the data in the two arrays. The difference value is always positive.

NOTES ON USE

The source and destination pointers can point to the same location.

CROSS REFERENCE SDA_Difference

SDS_Roots

PROTOTYPE AND PARAMETER DESCRIPTION

void SDS_Roots (const SLData_t a,a valueconst SLData_t b,b valueconst SLData_t c,c value

SLData_t *Root1, Pointer to root # 1 SLData_t *Root2) Pointer to root # 2

DESCRIPTION

This function returns the real roots of the bi-quadratic equation:

$$ax^2 + bx + c = 0$$

The polynomial factors are given by the equation:

$$Roots = \frac{-b \pm \sqrt{b^2 - 4ac}}{2a}$$

NOTES ON USE

The values a, b and c must be real numbers, as must the roots. If the values of a, b and c will lead to complex roots then the function will return <code>SIGLIB_DOMAIN_ERROR</code>, otherwise the function returns <code>SIGLIB_NO ERROR</code>.

CROSS REFERENCE SCV_Roots

SLData_t SDS_Factorial (const SLData_t Input) Input value

DESCRIPTION

This function returns the factorial of the input value.

NOTES ON USE

CROSS REFERENCE

 $SDS_Permutations\ , SDS_Combinations$

SLData_t SDS_Permutations (const SLData_t n, Set size const SLData_t k) Selection size

DESCRIPTION

This function returns the number of permutations (arrangements) of n items taking k at a time, which is represented as ${}^{n}P_{k}$.

NOTES ON USE

CROSS REFERENCE

SDS_Factorial, SDS_Combinations

SLData_t SDS_Combinations (const SLData_t n, Set size const SLData_t k) Selection size

DESCRIPTION

This function returns the number of combinations of n items taking k at a time, which is represented as ${}^{n}C_{k}$.

NOTES ON USE

CROSS REFERENCE

SDS_Factorial, SDS_Permutations

Pointer to the value used to

Array length

DESCRIPTION

This function initializes the linear overlap and add function.

NOTES ON USE

CROSS REFERENCE

SDA_OverlapAndAddLinear, SDA_OverlapAndAddLinearWithClip, SDA_OverlapAndAddArbitrary, SDA_OverlapAndAddArbitraryWithClip

void SDA_OverlapAndAddLinear (const SLData_t *, Ptr. to source array 1

const SLData_t *, Pointer to source array 2
SLData_t *, Pointer to destination array
const SLData_t, Increment / decrement value

const SLArrayIndex t) Array length

DESCRIPTION

This function performs a linear overlap and add of the data in the two arrays. The data linearly ramps between the values in one array to the values in the second.

NOTES ON USE

CROSS REFERENCE

SIF_OverlapAndAddLinear, SDA_OverlapAndAddLinearWithClip, SDA_OverlapAndAddArbitrary, SDA_OverlapAndAddArbitraryWithClip

void SDA_OverlapAndAddLinearWithClip (const SLData_t *, Pointer to source array 1

const SLData_t *, Pointer to source array 2
SLData_t *, Pointer to destination array
const SLData_t, Threshold limiting value
const SLData_t, Increment / decrement value
const SLArrayIndex t) Array length

DESCRIPTION

This function performs a linear overlap and add of the data in the two arrays. The data linearly ramps between the values in one array to the values in the second.

This function also applies a threshold and ensures that the addition operation does not overflow.

NOTES ON USE

CROSS REFERENCE

SIF_OverlapAndAddLinear, SDA_OverlapAndAddLinear, SDA OverlapAndAddArbitrary, SDA OverlapAndAddArbitraryWithClip

void SDA_OverlapAndAddArbitrary (const SLData_t *, Ptr. to source array 1

const SLData t*, Pointer to source array 2

const SLData_t *, Pointer to window function array SLData_t *, Pointer to destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function performs an overlap and add of the data in the two arrays. The interarray scaling function is performed by the data supplied in the windowing array.

NOTES ON USE

CROSS REFERENCE

SIF_OverlapAndAddLinear, SDA_OverlapAndAddLinear, SDA_OverlapAndAddLinearWithClip, SDA_OverlapAndAddArbitraryWithClip.

void SDA_OverlapAndAddArbitraryWithClip (const SLData_t *, Pointer to source array 1

const SLData_t *, Pointer to source array 2
const SLData_t *, Pointer to window function array
SLData_t *, Pointer to destination array
const SLData_t, Threshold limiting value
const SLArrayIndex t) Array length

DESCRIPTION

This function performs an overlap and add of the data in the two arrays. The interarray scaling function is performed by the data supplied in the windowing array.

This function also applies a threshold and ensures that the addition operation does not overflow.

NOTES ON USE

CROSS REFERENCE

SIF_OverlapAndAddLinear, SDA_OverlapAndAddLinear, SDA OverlapAndAddLinearWithClip, SDA OverlapAndAddArbitrary.

SLData_t SDS_DegreesToRadians (const SLData_t) Angle in degrees

DESCRIPTION

This function converts and angle in degrees to radians.

NOTES ON USE

CROSS REFERENCE

 $SDA_DegreesToRadians, SDS_RadiansToDegrees, SDA_RadiansToDegrees.$

void SDA_DegreesToRadians (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function converts an array of angles in degrees to radians.

NOTES ON USE

CROSS REFERENCE

SDS_DegreesToRadians, SDS_RadiansToDegrees, SDA_RadiansToDegrees.

SLData_t SDS_RadiansToDegrees (const SLData_t) Angle in radians

DESCRIPTION

This function converts and angle in radians to degrees.

NOTES ON USE

CROSS REFERENCE

SDS_DegreesToRadians, SDA_DegreesToRadians, SDA_RadiansToDegrees.

void SDA_RadiansToDegrees (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function converts an array of angles in radians to degrees.

NOTES ON USE

CROSS REFERENCE

SDS_DegreesToRadians, SDA_DegreesToRadians, SDS_RadiansToDegrees.

void SDS_DetectNAN (const SLData_t)
Source sample

DESCRIPTION

This function checks if the sample is NaN or +/- infinity. It returns either:

0 if the value is either: NaN or +/- infinity -1 if the value is NOT NaN or +/- infinity

NOTES ON USE

This function does not work with the same logic as isinfinite (). It uses the same logic as SDA_DetectNAN(), which returns the location of the first NaN in the array.

CROSS REFERENCE

SDA_DetectNaN

SLArrayIndex_t SDA_DetectNAN (const SLData_t *, Source array pointer const SLArrayIndex_t) Source array length

DESCRIPTION

This function checks if any of the samples in the array are NaN or +/- infinity. It returns either:

The location of the first element that is either: NaN or +/- infinity -1 if the value is NOT NaN or +/- infinity

NOTES ON USE

This function does not work with the same logic as isinfinite ().

CROSS REFERENCE

SDS DetectNaN

DSP UTILITY FUNCTIONS (*dsputils.c***)**

SDA_Rotate

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Rotate (const SLData_t *, Source array pointer
SLData_t *, Destination array pointer
const SLArrayIndex_t, Number of bins to rotate data
const SLArrayIndex_t) Array length

DESCRIPTION

This function rotates the data in the array by n samples from left to right. For right to left rotation, the number of rotation steps must be set to (Length - N), where N is the required number of steps.

NOTES ON USE

This function does not support in-place operation.

CROSS REFERENCE

SDA Reverse

SDA_Reverse

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Reverse (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function reverses the order of the data in the array i.e. it reflects the values around the centre value(s).

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array.

CROSS REFERENCE

SDA Rotate

SDA_Scale

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Scale (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t, Maximum scaled value const SLArrayIndex_t) Array length

DESCRIPTION

This function scales, or normalize, the largest absolute data value in the array equal to the maximum scaled value, all other entries in the array will be scaled accordingly.

NOTES ON USE

If the largest absolute value in the array is negative, then this (absolute value) will be used to scale the array. The function returns the scalar value, used to scale the data.

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA_Multiply, SDA_Divide, SDA_Max, SDA_Min, SDA_AbsMax, SDA_AbsMin.

SLData_t SDA_MeanSquare (const SLData_t *, Source array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the mean square value of the samples in the array i.e.:

$$\frac{\sum\limits_{n=0}^{N-1}x(n)^2}{N}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_RootMeanSquare$

SLData_t SDA_MeanSquareError (const SLData_t *, Source pointer 1

const SLData t*, Source pointer 2

const SLArrayIndex t, Inverse of the array length

const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the mean square error of the samples in the arrays, using the following equation:

$$MSE = \frac{1}{L} \sum_{n=0}^{L-1} (X(n) - Y(n))^{2}$$

NOTES ON USE

The "inverse of array length" parameter is used to avoid having to perform a divide operation within the function. This improves run-time performance.

CROSS REFERENCE

SDA MeanSquare

DESCRIPTION

This function returns the root mean square value of the samples in the array i.e.:

$$V_{\text{RMS}} = \sqrt{\frac{\sum\limits_{n=0}^{N-1} x(n)^2}{N}}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_Mean Square$

Real data source pointer Imaginary data source pointer Destination array pointer Array length

DESCRIPTION

This function performs the following operation:

$$|X[k]| = \sqrt{X[k].X*[k]}$$

Which is mathematically the same as:

Magnitude =
$$\sqrt{Real^2 + Imaginary^2}$$

for all values in the real and complex arrays.

NOTES ON USE

CROSS REFERENCE

SDA_LogMagnitude, SDA_MagnitudeSquared, SDA_PhaseWrapped, SDA_PhaseUnWrapped, SDS_Magnitude, SDS_MagnitudeSquared and SDS_Phase.

void SDA_MagnitudeSquared (const SLData_t *, Real data source pointer
 const SLData_t *, Imaginary data source pointer
 SLData_t *, Destination array pointer
 const SLArrayIndex_t) Array length

DESCRIPTION

This function performs the following operation:

$$|X[k]|^2 = X[k].X*[k]$$

Which is mathematically the same as:

$$Magnitude^2 = Real^2 + Imaginary^2$$

for all values in the real and complex arrays.

NOTES ON USE

CROSS REFERENCE

SDA_LogMagnitude, SDA_Magnitude, SDA_PhaseWrapped, SDA_PhaseUnWrapped, SDS_Magnitude, SDS_MagnitudeSquared and SDS_Phase.

SLData_t SDS_Magnitude (const SLData_t, Real data value const SLData_t *)

Imaginary data value

DESCRIPTION

This function returns the magnitude of the input using the following equation:

$$|X[k]| = \sqrt{X[k].X*[k]}$$

Which is mathematically the same as:

$$Magnitude = \sqrt{Real^2 + Imaginary^2}$$

NOTES ON USE

CROSS REFERENCE

SDA_Magnitude, SDA_MagnitudeSquared, SDA_PhaseWrapped, SDA_PhaseUnWrapped, SDS_MagnitudeSquared and SDS_Phase.

SLData_t SDS_MagnitudeSquared (const SLData_t, Real data value const SLData_t *) Imaginary data value

DESCRIPTION

This function returns the magnitude squared value of the input using the following equation:

$$|X[k]|^2 = X[k].X*[k]$$

Which is mathematically the same as:

$$Magnitude^2 = Real^2 + Imaginary^2$$

NOTES ON USE

CROSS REFERENCE

SDA_Magnitude, SDA_MagnitudeSquared, SDA_PhaseWrapped, SDA_PhaseUnWrapped, SDS_Magnitude and SDS_Phase.

SDS_Phase

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function returns the phase of the complex vector, according to the following equation:

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

NOTES ON USE

CROSS REFERENCE

SDA_PhaseWrapped, SDA_PhaseUnWrapped, SDA_Magnitude, SDA_PhaseUnWrap, SDS_Magnitude, SDS_MagnitudeSquared.

DESCRIPTION

This function calculates the phase of a signal from a complex vector, according to the following equation:

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

The phase output of this function is wrapped between $-\pi$ and $+\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseUnWrapped, SDA_Magnitude, SDA_MagnitudeSquared, SDA_PhaseUnWrap, SDS_Magnitude, SDS_MagnitudeSquared and SDS_Phase.

void SDA_PhaseUnWrapped (const SLData_t *, Real source pointer const SLData_t *, Imaginary source pointer SLData_t *, Destination phase array pointer const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the phase of a signal from a complex vector, according to the following equation:

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

The phase output of this function is NOT wrapped between $-\pi$ and $+\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseWrapped, SDA_Magnitude, SDA_MagnitudeSquared, SDA PhaseUnWrap, SDS Magnitude, SDS MagnitudeSquared and SDS Phase.

void SDA_MagnitudeAndPhaseWrapped (const SLData_t *, Real source pointer

const SLData_t *, Imaginary source pointer
SLData_t *, Magnitude destination pointer
SLData_t *, Phase destination pointer

const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the magnitude and phase of a signal from a complex vector, according to the following equations:

Magnitude =
$$\sqrt{\text{Real}^2 + \text{Imaginary}^2}$$

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

The phase output of this function is wrapped between $-\pi$ and $+\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseUnWrapped, SDA_Magnitude, SDA_MagnitudeSquared, SDA_PhaseUnWrap, SDS_Magnitude, SDS_MagnitudeSquared and SDS_Phase.

void SDA_MagnitudeAndPhaseUnWrapped (const SLData_t *, Real source pointer

const SLData_t *, Imaginary source pointer
SLData_t *, Magnitude destination pointer
SLData_t *, Phase destination pointer

const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the magnitude and phase of a signal from a complex vector, according to the following equations:

Magnitude =
$$\sqrt{\text{Real}^2 + \text{Imaginary}^2}$$

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

The phase output of this function is NOT wrapped between $-\pi$ and $+\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseWrapped, SDA_Magnitude, SDA_MagnitudeSquared, SDA_PhaseUnWrap, SDS_Magnitude, SDS_MagnitudeSquared and SDS_Phase.

void SDA MagnitudeSquaredAndPhaseWrapped (const SLData_t *, Real src. ptr.

const SLData t*, Imaginary source pointer

SLData t*, Magnitude squared destination pointer

SLData t*, Phase destination pointer

const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the magnitude squared and phase of a signal from a complex vector, according to the following equations:

$$Magnitude^2 = Real^2 + Imaginary^2$$

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

The phase output of this function is wrapped between $-\pi$ and $+\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseUnWrapped, SDA_Magnitude, SDA_MagnitudeSquared, SDA PhaseUnWrap, SDS Magnitude, SDS MagnitudeSquared and SDS Phase.

void SDA_MagnitudeSquaredAndPhaseUnWrapped (const SLData_t *, Real src. ptr.

const SLData t*, Imaginary source pointer

SLData t*, Magnitude squared destination pointer

SLData t*, Phase destination pointer

const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the magnitude squared and phase of a signal from a complex vector, according to the following equations:

$$Magnitude^2 = Real^2 + Imaginary^2$$

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

The phase output of this function is NOT wrapped between $-\pi$ and $+\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseWrapped, SDA_Magnitude, SDA_MagnitudeSquared, SDA PhaseUnWrap, SDS Magnitude, SDS MagnitudeSquared and SDS Phase.

void SDA_PhaseWrap (const SLData_t *, Source phase pointer SLData_t *, Destination phase array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the phase of the signal wrapped between $-\pi \le \phi \le +\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseUnWrap, SDA_PhaseWrapped and SDA_PhaseUnWrapped

void SDA_PhaseUnWrap (const SLData_t *, Source phase pointer SLData_t *, Destination phase array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the unwrapped phase of the signal.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseWrap, SDA_PhaseWrapped and SDA_PhaseUnWrapped

SLData_t SDS_Log2 (const SLData_t) Source number

DESCRIPTION

This function returns the Logarithm of a number, to base 2.

NOTES ON USE

This function includes error detection to avoid SDS_Log2(0). SDS_Log2Macro() implements the same functionality but without the error detection overhead.

CROSS REFERENCE

SDS_Log2Macro, SDA_Log2, SDS_LogN, SDA_LogN, SDA LogDistribution

SDA_Log2

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Log2 (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the Logarithm of the numbers in the source array, to base 2.

NOTES ON USE

CROSS REFERENCE SDS_Log2, SDS_LogN, SDA_LogN, SDA_LogDistribution

SLData_t SDS_LogN (const SLData_t, Source number const SLData_t) Base number

DESCRIPTION

This function returns the Logarithm of a number, to base N.

NOTES ON USE

CROSS REFERENCE SDS_Log2, SDA_Log2, SDA_LogN, SDA_LogDistribution

SDA_LogN

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_LogN (const SLData_t *,
SLData_t *,
const SLData_t,
const SLArrayIndex_t)Pointer to source array
Pointer to destination array
Base number
Array length

DESCRIPTION

This function returns the Logarithm of the numbers in the source array, to base N.

NOTES ON USE

CROSS REFERENCE SDS_Log2, SDA_Log2, SDS_LogN, SDA_LogDistribution

void SDA_LogDistribution (SLData_t *, Pointer to destination array

const SLData_t, Start value
const SLData_t, End value
const SLArrayIndex_t) Number of steps

DESCRIPTION

This function generates a sequence with a logarithmic distribution.

NOTES ON USE

CROSS REFERENCE

SDS_Log2, SDA_Log2, SDS_LogN, SDA_LogN

SDA_Copy

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Copy (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex t) Array length

DESCRIPTION

This function copies the contents of one array of data into another array, with a fixed increment of one memory location between samples.

NOTES ON USE

CROSS REFERENCE

SDA_CopyWithStride, SIF_CopyWithOverlap, SDA_CopyWithOverlap, SIF_CopyWithIndex, SDA_CopyWithIndex

void SDA_CopyWithStride (const SLData_t *, Source array pointer const SLArrayIndex_t, Source array stride SLData_t *, Destination array pointer const SLArrayIndex_t, Destination array stride const SLArrayIndex_t) Array length

DESCRIPTION

This function copies the contents of one array of data into another array, with a different stride (pointer address increment) for each vector pointer.

NOTES ON USE

This function is very useful when performing image processing or multi-dimensional operations that require the processing to be performed on separate dimensions. For example performing an operation on a column in an image.

It is often more efficient (especially in C) to extract that information from an array, process it and put it back than process the data in-place.

CROSS REFERENCE

SDA_Copy, SIF_CopyWithOverlap, SDA_CopyWithOverlap, SIF_CopyWithIndex, SDA_CopyWithIndex

void SIF_CopyWithOverlap (SLArrayIndex_t *) Pointer to source array index

DESCRIPTION

This function initializes the copy with overlap function.

NOTES ON USE

CROSS REFERENCE

SDA_Copy, SDA_CopyWithStride, SDA_CopyWithOverlap, SIF_CopyWithIndex, SDA_CopyWithIndex

SLArrayIndex_t SDA_CopyWithOverlap (const SLData_t *, Pointer to source data

SLData_t *, Pointer to destination array SLData_t *, Pointer to overlap array SLArrayIndex_t *, Pointer to source array index

const SLArrayIndex_t, Source array length const SLArrayIndex_t, Overlap length

const SLArrayIndex t) Destination array length

DESCRIPTION

This function copies successive arrays of length "destination array length" of data from the source array to the destination array. For each successive copy, this function ensures that there are "overlap length" of samples overlapped between the successive destination arrays.

The return value from this function is the source array index so that it can be tested to see if the value is greater than or equal to the source array length, in which case, the output array is incomplete and further data must be placed in the array to fill it.

NOTES ON USE

The value returned in the "source array index" parameter indicates the completion state of the function. It will return the following values:

"Returned value" >= "Source array The full "Destination array length" of data has NOT been copied. You will need to call this

function again with a new source array of

data.

0 <= "Returned value" < "Source The full "Destination array length" of data has

array length" been copied correctly.

"Returned value" < 0 There is overlapping data from the previous

source array that is required in the output array – this data will have been stored in the

"overlap array".

The function SIF CopyWithOverlap () should be called prior to calling this function.

CROSS REFERENCE

SDA_Copy, SDA_CopyWithStride, SIF_CopyWithOverlap, SIF_CopyWithIndex, SDA_CopyWithIndex

void SIF_CopyWithIndex (SLArrayIndex_t *) Pointer to source array index

DESCRIPTION

This function initializes the copy with index function.

NOTES ON USE

CROSS REFERENCE

SDA_Copy, SDA_CopyWithStride, SIF_CopyWithOverlap, SDA_CopyWithOverlap, SDA_CopyWithIndex

SLArrayIndex_t SDA_CopyWithIndex (const SLData_t *, Pointer to source data

SLData_t *, Pointer to destination array SLArrayIndex_t *, Pointer to source array index

const SLArrayIndex_t, Source array length

const SLArrayIndex t, Stride length

const SLArrayIndex_t) Destination array length

DESCRIPTION

This function copies successive arrays of length "destination array length" of data from the source array to the destination array. For each successive copy, this function ensures that there are "stride length" of samples indexed into the source array and copied to the successive destination arrays.

The return value from this function is the number of samples copied from the source array to the destination array.

If copyLength < dstLength then the destination array is zero padded.

NOTES ON USE

It is important that the source array length is greater than or equal to the destination array length.

The function SIF CopyWithIndex () should be called prior to calling this function.

CROSS REFERENCE

SDA_Copy, SDA_CopyWithStride, SIF_CopyWithOverlap, SDA_CopyWithOverlap, SIF_CopyWithIndex

void SDA_20Log10 (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function scales all array entries by 20 * log₁₀, to give a dB output.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA_LogMagnitude and SDA_10Log10

SDA_10Log10

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_10Log10 (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function scales all array entries by 10 * log₁₀, to give a dB output.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA LogMagnitude and SDA 20Log10

void SDA_LogMagnitude (const SLData_t *, Real source array pointer const SLData_t *, Imaginary source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the log magnitude of the complex data, using the following equation:

$$y(n) = 10*\log_{10}(real^2 + imag^2) = 20*\log_{10}(\sqrt{real^2 + imag^2})$$

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SDA_Magnitude, SDA_MagnitudeSquared, SDA_10Log10 and SDA_20Log10

void SDA_LogMagnitudeAndPhaseWrapped (const SLData_t *, Real src. ptr. const SLData_t *, Imaginary source pointer SLData_t *, Magnitude destination pointer SLData_t *, Phase destination pointer const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the log magnitude and phase of a signal from a complex vector, according to the following equations:

$$y(n) = 10*log_{10}(real^{2} + imag^{2}) = 20*log_{10}(\sqrt{real^{2} + imag^{2}})$$

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

The phase output of this function is wrapped between $-\pi$ and $+\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseUnWrapped, SDA_Magnitude, SDA_MagnitudeSquared, SDA PhaseUnWrap, SDS Magnitude, SDS MagnitudeSquared and SDS Phase.

void SDA_LogMagnitudeAndPhaseUnWrapped (const SLData_t *, Real src. ptr.

const SLData_t *, Imaginary source pointer
SLData_t *, Magnitude destination pointer
SLData_t *, Phase destination pointer

const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the log magnitude and phase of a signal from a complex vector, according to the following equations:

$$y(n) = 10*log_{10}(real^2 + imag^2) = 20*log_{10}(\sqrt{real^2 + imag^2})$$

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

The phase output of this function is NOT wrapped between $-\pi$ and $+\pi$.

NOTES ON USE

CROSS REFERENCE

SDA_PhaseWrapped, SDA_Magnitude, SDA_MagnitudeSquared, SDA PhaseUnWrap, SDS Magnitude, SDS MagnitudeSquared and SDS Phase.

void SDA_Lengthen (const SLData_t *,
SLData_t *,
const SLArrayIndex_t,
const SLArrayIndex_t)Source array pointer
Destination array pointer
Source array length
Destination array length

DESCRIPTION

This function copies the contents of one array into another longer array, extend the data with zero. This operation is also known as zero padding.

NOTES ON USE

CROSS REFERENCE

SIF_ReSize and SDA_ReSize

SDA_Shorten

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Shorten (const SLData_t *,
SLData_t *,
const SLArrayIndex_t)Source array pointer
Destination array pointer
Destination array length

DESCRIPTION

This function copies the contents of one array into another shorter array, discard the excess data.

NOTES ON USE

CROSS REFERENCE

SIF_ReSize and SDA_ReSize

void SIF_ReSize (SLArrayIndex_t *) Pointer to state array length

DESCRIPTION

This function initializes the SDA_ReSize function.

NOTES ON USE

CROSS REFERENCE

SDA_Lengthen, SDA_Shorten, SDA_ReSize, SDA_ReSizeInput and SDA_ReSizeOutput

SDA_ReSize

PROTOTYPE AND PARAMETER DESCRIPTION

SLArrayIndex_t SDA_ReSize (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array SLData_t *, Pointer to state array

SLArrayIndex_t *, Pointer to state array length

const SLArrayIndex_t, Source array length const SLArrayIndex_t) Destination array length

DESCRIPTION

This function appends the input data to the end of the data in the state array, that was carried over from the last iteration. If the resulting data set is long enough to fill the output array then this amount of data is copied to the output array and the state array updated. If there is not enough data in the state array then all the data is maintained in the state array and the Destination array length is 0 samples long.

This function maintains contiguous data streams across input and output array boundaries.

NOTES ON USE

The function SIF_ReSize must be called prior to calling this function.

It is important to ensure that the state array is long enough to hold all overlap data required by the application. For performance reasons, this function does not check the size of the state array against the amount of data that needs to be stored inside.

This function does not work in-place.

CROSS REFERENCE

SDA_Lengthen, SDA_Shorten, SIF_ReSize, SDA_ReSizeInput and SDA_ReSizeOutput

SLArrayIndex t SDA ReSizeInput (const SLData t *, Pointer to source array

SLData t*, Pointer to state array

SLArrayIndex_t *, Pointer to state array length

const SLArrayIndex_t) Source array length

DESCRIPTION

This function appends the input data to the end of the data in the state array, that was carried over from the last iteration.

This function maintains contiguous data streams across input and output array boundaries.

NOTES ON USE

The function SIF_ReSize must be called prior to calling this function.

It is important to ensure that the state array is long enough to hold all overlap data required by the application. For performance reasons, this function does not check the size of the state array against the amount of data that needs to be stored inside.

CROSS REFERENCE

 $SDA_Lengthen, SDA_Shorten, SIF_ReSize, SDA_ReSize \ and \\ SDA_ReSizeOutput$

SLArrayIndex_t SDA_ReSizeOutput (SLData_t *, Pointer to destination array

SLData t*, Pointer to state array

SLArrayIndex_t *, Pointer to state array length const SLArrayIndex_t)

Destination array length

DESCRIPTION

This function resizes the output array. If the data set in the state array long enough to fill the output array then the "destination array length" data is copied to the output array and any remaining data is maintained in the state array. If there is not enough data in the state array then the destination array length is 0 samples long.

This function maintains contiguous data streams across input and output array boundaries.

NOTES ON USE

The function SIF ReSize must be called prior to calling this function.

It is important to ensure that the state array is long enough to hold all overlap data required by the application. For performance reasons, this function does not check the size of the state array against the amount of data that needs to be stored inside.

CROSS REFERENCE

SDA_Lengthen, SDA_Shorten, SIF_ReSize, SDA_ReSize and SDA_ReSizeInput

SDA_Fill

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Fill (SLData_t *,Array pointerconst SLData_t,Fill valueconst SLArrayIndex_t)Array length

DESCRIPTION

This function fills all the entries in an array with a scalar value.

NOTES ON USE

CROSS REFERENCE

void SDA_Clear (SLData_t *, Array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function clears the contents of the array to zero.

NOTES ON USE

CROSS REFERENCE

These functions generate a histogram of the source data where the destination array length defines the number of bins in the histogram.

The bin width (h) for the number of output bins (k) is given by the following equation: $h = \int max \ x - min \ x / k$

The histogram is calculated in one of two ways:

1/ If either or both the source minimum and maximum values are non-zero then the histogram is calculated for all values between the minimum and maximum levels. All values outside this range are discarded.

2/ If both the source minimum and maximum values are equal to zero then the function first calculates the minimum and maximum values in the source array and then calculates the histogram over this range. You can also set both of these parameters to SIGLIB HISTOGRAM AUTOSCALE to achieve the same effect.

The histogram summation array is continuously incremented so that the results of successive histograms are cumulative. Therefore prior to commencing the first histogram in a series, it is necessary to use the SIF_Histogram function.

The histogram array uses floating point numbers. IEEE 754 can represent integer values without error up to 2²⁴ for single precision format and 2⁵³ for double precision format. This prevents rounding errors for all results within these ranges. If you wish to convert the results to fixed point format, when using these functions on devices that do not use IEEE 754 format you should use the function SDA_SigLibDataToFix to ensure that the results are rounded correctly.

For multiple dimension arrays, the source array length must be the product of all the dimension lengths.

EXAMPLES

There are two primary ways of rounding floating-point numbers when calculating histograms. The first is to round down to the integer number and the second is to round to the nearest. The SigLib histogram functions support both of these modes as described in these examples.

For these examples we will assume a range of histogram values from -2.0 to +2.0.

Example 1

In this example we will use 4 bins for the histogram result and all the floating point numbers will be rounded down, as follows:

Bin	Bin Median Value	Bin Numerical Range
Number		_
0	-1.5	$-2.0 \le n < -1.0$
1	-0.5	$-1.0 \le n < 0.0$
2	0.5	$0.0 \le n < 1.0$
3	1.5	$1.0 \le n \le 2.0$

For this scenario you would use the following SigLib function call:

```
SDA_Histogram (pSourceData, /* Input array pointer */
pHistogram, /* Histogram array pointer */
-2.0F, /* Lower range limit */
2.0F, /* Upper range limit */
SOURCE_LENGTH, /* Input array length */
4) /* Histogram array length */
```

The benefit of this approach is that all the bins are the same width but the numbers are all rounded towards zero, which may lead to a bias in the results.

Example 2

In this example we will use 5 bins for the histogram result and all the floating point numbers will be rounded to the nearest integer, as follows:

Bin	Bin Median Value	Bin Numerical Range
Number		
0	-1.75	$-2.0 \le n < -1.5$
1	-1.0	$-1.5 \le n < -0.5$
2	0.0	$-0.5 \le n < 0.5$
3	1.0	$0.5 \le n < 1.5$
4	1.75	$1.5 \le n \le 2.0$

For this scenario you would use the following SigLib function call:

```
SDA_Histogram (pSourceData, /* Input array pointer */
pHistogram, /* Histogram array pointer */
-2.0F, /* Lower range limit */
2.0F, /* Upper range limit */
SOURCE_LENGTH, /* Input array length */
5) /* Histogram array length */
```

The benefit of this approach is that all numbers are rounded to the median value, which removes bias from the results but the two bins at the extremities (bins 0 and N-1) are smaller than the other bins.

Example 3

In this example we will use 5 bins for the histogram result and all the floating point numbers will be rounded to the nearest integer, as follows:

Bin	Bin Median Value	Bin Numerical Range
Number		_
0	-2.0	$-2.5 \le n < -1.5$
1	-1.0	$-1.5 \le n < -0.5$
2	0.0	$-0.5 \le n < 0.5$
3	1.0	$0.5 \le n < 1.5$
4	2.0	$1.5 \le n \le 2.5$

For this scenario you would use the following SigLib function call:

```
SDA_Histogram (pSourceData, /* Input array pointer */
pHistogram, /* Histogram array pointer */
-2.5F, /* Lower range limit */
2.5F, /* Upper range limit */
SOURCE_LENGTH, /* Input array length */
5) /* Histogram array length */
```

The benefit of this approach is that all numbers are rounded to the median value, which removes bias from the results plus the bins are all the same width. The disadvantage is that the input range is extended beyond the integer numbers of the histogram.

SIF_Histogram

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_Histogram (SLData_t *, Histogram array pointer const SLArrayIndex_t) Histogram array length

DESCRIPTION

This function clears the histogram array prior to calling the functions SDA_Histogram, SDA_HistogramCumulative, SDA_HistogramExtended and SDA_HistogramExtendedCumulative.

NOTES ON USE

See section titled "Histogram Functions", above, which includes examples.

CROSS REFERENCE

SDA_Histogram, SDA_HistogramCumulative, SDA_HistogramExtended, SDA HistogramExtendedCumulative

void SDA_Histogram (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t, Source minimum level const SLData_t, Source maximum level const SLArrayIndex_t, const SLArrayIndex_t) Source array length Destination array length

DESCRIPTION

This function generates a histogram of the source data where the destination array length defines the number of bins in the histogram.

NOTES ON USE

See section titled "Histogram Functions", above, which includes examples.

CROSS REFERENCE

SIF_Histogram, SDA_HistogramCumulative, SDA_HistogramExtended, SDA_HistogramExtendedCumulative

void SDA_HistogramCumulative (const SLData_t *, Source array pointer

SLData_t *, Destination array pointer const SLData_t, Source minimum level const SLData_t, Source maximum level const SLArrayIndex_t, Source array length const SLArrayIndex_t) Destination array length

DESCRIPTION

This function generates a histogram of the source data where the destination array length defines the number of bins in the histogram.

NOTES ON USE

See section titled "Histogram Functions", above, which includes examples.

CROSS REFERENCE

SIF_Histogram, SDA_Histogram, SDA_HistogramExtended, SDA_HistogramExtendedCumulative

void SDA_HistogramExtended (const SLData_t *, Source array pointer

SLData_t *, Destination array pointer const SLData_t, Source minimum level const SLData_t, Source maximum level const SLArrayIndex_t, Source array length const SLArrayIndex t) Destination array length

DESCRIPTION

This function generates a histogram of the source data where the destination array length defines the number of bins in the histogram.

NOTES ON USE

See section titled "Histogram Functions", above, which includes examples.

CROSS REFERENCE

SIF_Histogram, SDA_Histogram, SDA_HistogramCumulative, SDA_HistogramExtendedCumulative

void SDA_HistogramExtendedCumulative (const SLData_t *, Src array pointer

SLData_t *, Destination array pointer const SLData_t, Source minimum level const SLData_t, Source maximum level const SLArrayIndex_t, Source array length const SLArrayIndex_t) Destination array length

DESCRIPTION

This function generates a histogram of the source data where the destination array length defines the number of bins in the histogram.

NOTES ON USE

See section titled "Histogram Functions", above, which includes examples.

CROSS REFERENCE

 $SIF_Histogram, SDA_Histogram, SDA_Histogram Cumulative, SDA_Histogram Extended$

void SDA_HistogramEqualize (const SLData_t *, Source array pointer

SLData_t *, Destination array pointer

const SLData_t, New peak value const SLArrayIndex_t) Source array length

DESCRIPTION

This function equalizes the histogram of the array. This function takes the absolute maximum value in the array and multiplies it up to the new peak value.

NOTES ON USE

If a data set needs to have its histogram equalized and the tail of the histogram already extends to the limit of the numerical bounds being used then the data should be clipped to a pre-set maximum before being equalized.

CROSS REFERENCE

SDA HistogramEqualize

void SDA_Quantize (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t, Quantisation number of bits const SLData_t, Peak input value const SLArrayIndex_t) Array length

DESCRIPTION

This function quantizes the data in the array to N bits.

NOTES ON USE

The peak input value parameter is used to sale the data according to the maximum possible input data value, which could be floating point.

CROSS REFERENCE SDS_Quantize, SDA_Quantize_N, SDS_Quantize_N

SDS_Quantize

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_Quantize (const SLData_t, const SLArrayIndex_t, const SLData_t)

Source sample
Quantisation number of bits
Peak input value

DESCRIPTION

This function quantizes the data to N bits.

NOTES ON USE

The peak input value parameter is used to sale the data according to the maximum possible input data value, which could be floating point.

CROSS REFERENCE

SDA_Quantize_N, SDS_Quantize_N

void SDA_Quantize_N (const SLData_t *,Pointer to source arraySLData_t *,Pointer to destination arrayconst SLData_t,Quantisation numberconst SLArrayIndex_t)Source array size

DESCRIPTION

This function quantizes the data in the array to the nearest multiple of N, using floor function.

NOTES ON USE

CROSS REFERENCE SDA_Quantize, SDS_Quantize_N

SLData_t SDS_Quantise_N (const SLData_t, Source sample const SLData_t) Quantisation number

DESCRIPTION

This function quantizes the data to the nearest multiple of N, using floor function.

NOTES ON USE

CROSS REFERENCE SDA_Quantize, SDS_Quantize, SDA_Quantize_N

SDA_Abs

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Abs (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array lengths

DESCRIPTION

This function calculates the absolute values in an array.

NOTES ON USE

This function can operate on separate source and destination arrays or the source and destination pointers can reference the same array, for in-place operation.

CROSS REFERENCE

SLData_t SDS_PeakValueToBits (SLData_t, enum SLSignalSign_t)

Peak value, Sign type of the signal

DESCRIPTION

This function converts the peak value to a number of bits i.e. how many bits in a fixed point word are required to represent the given value.

NOTES ON USE

This function supports signed or unsigned words using the type SIGLIB_SIGNED_DATA or SIGLIB UNSIGNED DATA.

CROSS REFERENCE SDS_BitsToPeakValue

SLData_t SDS_BitsToPeakValue (SLData_t, enum SLSignalSign_t)

Number of bits
Sign type of the signal

DESCRIPTION

This function converts the number of bits to the peak value i.e. what is the largest positive number that can be represented using the given number of bits.

NOTES ON USE

This function supports signed or unsigned words using the type SIGLIB_SIGNED_DATA or SIGLIB UNSIGNED DATA.

CROSS REFERENCE SDS_PeakValueToBits

SLData_t SDS_VoltageTodBm (SLData_t, Linear value SLData_t) Zero dBm level

DESCRIPTION

This function converts the linear voltage value to dBm.

NOTES ON USE

This function requires that the zero dBm level is provided. For example, if a signed 16 bit word length is being used then a signal of 0 dBm would have a peak level of 32767.

This function is also implemented as a macro: SDS_VoltageTodBmMacro().

CROSS REFERENCE

SDA_VoltageTodBm, SDS_dBmToVoltage, SDA_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDS_PowerTodB, SDA_PowerTodB, SDS_dBToPower, SDA_dBToPower

void SDA_VoltageTodBm (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLData_t, Zero dBm level const SLArrayIndex t) Array lengths

DESCRIPTION

This function converts the linear values to dBm.

NOTES ON USE

This function requires that the zero dBm level is provided. For example, if a signed 16 bit word length is being used then a signal of 0 dBm would have a peak level of 32767.

CROSS REFERENCE

SDS_VoltageTodBm, SDS_dBmToVoltage, SDA_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDS_PowerTodB, SDA_PowerTodB, SDS_dBToPower, SDA_dBToPower

SLData_t SDS_dBmToVoltage (SLData_t, dBm input value SLData_t) Zero dBm level

DESCRIPTION

This function converts the dBm value to linear.

This function is also implemented as a macro: SDS_dBmToVoltageMacro().

NOTES ON USE

This function requires that the zero dBm level is provided. For example, if a signed 16 bit word length is being used then a signal of 0 dBm would have a peak level of 32767.

CROSS REFERENCE

SDS_VoltageTodBm, SDA_VoltageTodBm, SDA_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDS_PowerTodB, SDA_PowerTodB, SDS_dBToPower, SDA_dBToPower

void SDA_dBmToVoltage (const SLData_t *, Pointer to source array

SLData t*, Pointer to destination array

const SLData_t, Zero dBm level const SLArrayIndex t) Array lengths

DESCRIPTION

This function converts the dBm values to linear.

NOTES ON USE

This function requires that the zero dBm level is provided. For example, if a signed 16 bit word length is being used then a signal of 0 dBm would have a peak level of 32767.

CROSS REFERENCE

SDS_VoltageTodBm, SDA_VoltageTodBm, SDS_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDS_PowerTodB, SDA_PowerTodB, SDS_dBToPower, SDA_dBToPower

SLData_t SDS_VoltageTodB (const SLData_t) Linear voltage gain

DESCRIPTION

This function converts the linear voltage gain to dB.

This function is also implemented as a macro: SDS_VoltageTodBMacro().

NOTES ON USE

CROSS REFERENCE

SDS_VoltageTodBm , SDA_VoltageTodBm, SDS_dBmToVoltage, SDA_dBmToVoltage, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDS_PowerTodB, SDA_PowerTodB, SDS_dBToPower, SDA_dBToPower

void SDA_VoltageTodB (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array lengths

DESCRIPTION

This function converts the linear voltage gains to dB.

NOTES ON USE

CROSS REFERENCE

SDS_VoltageTodBm, SDA_VoltageTodBm, SDS_dBmToVoltage, SDA_dBmToVoltage, SDA_dBmToVoltage, SDS_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDS_PowerTodB, SDA_PowerTodB, SDS_dBToPower, SDA_dBToPower

SLData_t SDS_dBToVoltage (const SLData_t) dB value

DESCRIPTION

This function converts the dBm gain to linear voltage.

This function is also implemented as a macro: SDS_dBToVoltageMacro().

NOTES ON USE

CROSS REFERENCE

 $SDS_VoltageTodBm, SDA_VoltageTodBm, SDA_dBmToVoltage, SDA_dBmToVoltage, SDA_dBmToVoltage, SDA_VoltageTodB, SDA_dBToVoltage, SDS_PowerTodB, SDA_PowerTodB, SDS_dBToPower, SDA_dBToPower SDA_dBTOPOWER SDA_SDA_SDA_SDA_SDA_SDA_SDA$

void SDA_dBToVoltage (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array lengths

DESCRIPTION

This function converts the dBm gains to linear voltage.

NOTES ON USE

CROSS REFERENCE

SDS_VoltageTodBm, SDA_VoltageTodBm, SDS_dBmToVoltage, SDA_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDS_PowerTodB, SDA_PowerTodB, SDS_dBToPower, SDA_dBToPower

SLData_t SDS_PowerTodB (const SLData_t) Linear voltage gain

DESCRIPTION

This function converts the linear power gain to dB.

This function is also implemented as a macro: SDS_PowerTodBMacro().

NOTES ON USE

CROSS REFERENCE

SDS_VoltageTodBm , SDA_VoltageTodBm, SDS_dBmToVoltage, SDA_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, S

void SDA_PowerTodB (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex t) Array lengths

DESCRIPTION

This function converts the linear power gains to dB.

NOTES ON USE

CROSS REFERENCE

SDS_VoltageTodBm, SDA_VoltageTodBm, SDS_dBmToVoltage, SDA_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDA_dBToVoltage, SDS_PowerTodB, SDS_dBToPower, SDA_dBToPower

SLData_t SDS_dBToPower (const SLData_t) dB value

DESCRIPTION

This function converts the dBm gain to linear power.

This function is also implemented as a macro: SDS_dBToPowerMacro().

NOTES ON USE

CROSS REFERENCE

SDS_VoltageTodBm, SDA_VoltageTodBm, SDA_dBmToVoltage, SDA_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDA_dBToVoltage, SDA_DOWNETTODB, S

void SDA_dBToPower (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array lengths

DESCRIPTION

This function converts the dBm gains to linear power.

NOTES ON USE

CROSS REFERENCE

SDS_VoltageTodBm, SDA_VoltageTodBm, SDS_dBmToVoltage, SDA_dBmToVoltage, SDS_VoltageTodB, SDA_VoltageTodB, SDS_dBToVoltage, SDA_dBToVoltage, SDA_DVoltage, SD

SDS_Compare

PROTOTYPE AND PARAMETER DESCRIPTION

SLFixData_t SDS_Compare (const SLData_t, Source value #1 const SLData_t, Source value #2 const SLData_t) Threshold

DESCRIPTION

This function compares the value of sample #1 with the value of sample #2 and returns the following values:

SIGLIB_TRUE - if the difference between sample is less than the threshold. SIGLIB FALSE - if the difference between sample is greater than the threshold.

NOTES ON USE

CROSS REFERENCE

SDA_CompareComplex, SDS_CompareComplex, SDA_CompareComplex

```
SLFixData_t SDA_Compare (const SLData_t *, Source array pointer #1 const SLData_t *, Source array pointer #2 const SLData_t, Threshold const SLArrayIndex_t) Array length
```

DESCRIPTION

This function compares the contents of array #1 with those of array #2 and returns the following values:

```
{\tt SIGLIB\_TRUE - if the difference between samples is less than the threshold.} \\ {\tt SIGLIB\_FALSE - if the difference between samples is greater than the threshold.} \\
```

NOTES ON USE

CROSS REFERENCE

SDA CompareComplex, SDS CompareComplex, SDA CompareComplex

```
SLFixData_t SDS_CompareComplex (const SLData_t *, Real sample #1 const SLData_t *, Imaginary sample #1 const SLData_t *, Real sample #2 const SLData_t *, Imaginary sample #2 const SLData_t ) Imaginary sample #2 Threshold
```

DESCRIPTION

This function compares the real and imaginary values of the complex samples and returns the following values:

SIGLIB_TRUE - if the difference between samples is less than the threshold. SIGLIB_FALSE - if the difference between samples is greater than the threshold.

NOTES ON USE

CROSS REFERENCE

SDS Compare, SDA Compare, SDA CompareComplex

```
SLFixData_t SDA_CompareComplex (const SLData_t *, Real source array ptr #1 const SLData_t *, Imaginary source array pointer #1 const SLData_t *, Real source array pointer #2 const SLData_t *, Imaginary source array pointer #2 const SLData_t, Threshold const SLArrayIndex_t) Array length
```

DESCRIPTION

This function compares the real and imaginary contents of complex array #1 with those of complex array #2 and returns the following values:

 ${\tt SIGLIB_TRUE - if the difference between samples is less than the threshold.} \\ {\tt SIGLIB_FALSE - if the difference between samples is greater than the threshold.} \\$

NOTES ON USE

CROSS REFERENCE

SDS Compare, SDA Compare, SDS CompareComplex

SLData_t SDS_Int (const SLData_t) Source sample

DESCRIPTION

This function returns the integer component of the source sample.

NOTES ON USE

CROSS REFERENCE

SDS_Frac, SDS_AbsFrac, SDA_Int, SDA_Frac, SDA_AbsFrac.

SLData_t SDS_Frac (const SLData_t) Source sample

DESCRIPTION

This function returns the fractional component of the source sample.

NOTES ON USE

CROSS REFERENCE

SDS_Int, SDS_AbsFrac, SDA_Int, SDA_Frac, SDA_AbsFrac.

SLData_t SDS_AbsFrac (const SLData_t) Source sample

DESCRIPTION

This function returns the absolute value of the fractional component of the source sample.

NOTES ON USE

CROSS REFERENCE

SDS_Int, SDS_Frac, SDA_Int, SDA_Frac, SDA_AbsFrac.

SDA_Int

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Int (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array lengths

DESCRIPTION

This function returns the integer components of all of the samples in the source array.

NOTES ON USE

CROSS REFERENCE

SDS_Int, SDS_Frac, SDS_AbsFrac, SDA_Frac, SDA_AbsFrac.

SDA_Frac

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Frac (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array lengths

DESCRIPTION

This function returns the fractional components of all of the samples in the source array.

NOTES ON USE

CROSS REFERENCE

SDS_Int, SDS_Frac, SDS_AbsFrac, SDA_Int, SDA_AbsFrac.

SDA_AbsFrac

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_AbsFrac (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array lengths

DESCRIPTION

This function returns the absolute values of the fractional components of all of the samples in the source array.

NOTES ON USE

CROSS REFERENCE

SDS_Int, SDS_Frac, SDS_AbsFrac, SDA_Int, SDA_Frac.

SDA_SetMin

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_SetMin (SLData_t *,Pointer to source arraySLData_t *,Pointer to destination arrayconst SLData_t,New minimum valueconst SLArrayIndex_t)Array lengths

DESCRIPTION

This function sets the minimum value in the data set. The difference between the previous minimum and new minimum is added to all of the values.

NOTES ON USE

CROSS REFERENCE

SDA_SetMax, SDA_SetRange, SDA_SetMean.

void SDA_SetMax (SLData_t *,Pointer to source arraySLData_t *,Pointer to destination arrayconst SLData_t,New maximum valueconst SLArrayIndex_t)Array lengths

DESCRIPTION

This function sets the maximum value in the data set. The difference between the previous maximum and new maximum is added to all of the values.

NOTES ON USE

CROSS REFERENCE

SDA_SetMin, SDA_SetRange, SDA_SetMean.

void SDA_SetRange (SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLData_t, New minimum value const SLData_t, New maximum value const SLArrayIndex_t) Array lengths

DESCRIPTION

This function scales the data set in the source array to the new minimum and maximum values.

NOTES ON USE

CROSS REFERENCE

SDA_SetMin, SDA_SetMax, SDA_SetMean.

void SDA_SetMean (SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLData_t, New mean value const SLData_t, Inverse of the array lengths const SLArrayIndex_t)

Array lengths

DESCRIPTION

This function scales the data set in the source array to the new mean value.

NOTES ON USE

CROSS REFERENCE

SDA_SetMin, SDA_SetMax, SDA_SetRange.

DSP UTILITY FUNCTIONS (*dsputil2.c***)**

SDA_RealSpectralInverse

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_RealSpectralInverse (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex t) Array lengths

DESCRIPTION

This function inverts the spectrum of a real time domain signal, by negating alternate time domain samples.

NOTES ON USE

For spectral inversion of a continuous signal, it is important that the array length is an even number.

This function can be used to mirror the frequency response of a filter about Fs / 4, in which case it is important that the central coefficient is not inverted, which will destroy the filter phase response.

CROSS REFERENCE

SDA ComplexSpectralInverse

void SDA_ComplexSpectralInverse (const SLData_t *, Real source pointer const SLData_t *, Imaginary source array pointer SLData_t *, Real destination array pointer SLData_t *, Imaginary destination array pointer const SLArrayIndex t)

Array lengths

DESCRIPTION

This function inverts the spectrum of a complex time domain signal, by negating alternate time domain samples, in both the real and imaginary planes.

NOTES ON USE

For spectral inversion of a continuous signal, it is important that the array length is an even number.

This function can be used to mirror the frequency response of a filter about Fs / 4, in which case it is important that the central coefficient is not inverted, which will destroy the filter phase response.

CROSS REFERENCE

SDA RealSpectralInverse

void SDA_FdInterpolate (const SLData_t *, Real source array pointer
const SLData_t *, Imaginary source array pointer
SLData_t *, Real destination array pointer
SLData_t *, Imaginary destination array pointer
const SLFixData_t, Ratio up
const SLFixData_t, Ratio down
const SLArrayIndex_t) Array lengths

DESCRIPTION

This function interpolates the frequency spectrum of a signal, to obtain a pitch shifted spectrum.

NOTES ON USE

This technique benefits from carefully chosen array lengths, especially when using windowed and overlapped arrays, to smooth out transitions, between blocks. The array lengths should be as large as possible, without adding too much delay.

CROSS REFERENCE

SDS TdPitchShift, SDA FdInterpolate2.

```
void SDA_FdInterpolate2 (const SLData_t *, Real source pointer
const SLData_t *, Imaginary source array pointer
SLData_t *, Real destination array pointer
const SLData_t *, Imaginary destination array pointer
const SLArrayIndex_t, Source array length
const SLArrayIndex_t) Destination array length
```

DESCRIPTION

This function interpolates a signal, in the frequency domain, to increase the number of samples in the output array This algorithm is equivalent to a $\sin(x)/x$ time-domain interpolation process.

NOTES ON USE

This technique benefits from carefully chosen array lengths, especially when using windowed and overlapped arrays, to smooth out transitions, between blocks. The array lengths should be as large as possible, without adding too much delay.

CROSS REFERENCE

SDS TdPitchShift, SDA FdInterpolate.

SLData_t SDS_TdPitchShift (const SLData_t, Input sample SLData_t *, Pitch shift array pointer SLArrayIndex_t *, Input array offset SLData_t *, Output array offset SLData_t *, Previous sample const SLData_t, Pitch shift ratio const SLArrayIndex t) Length of pitch shift array

DESCRIPTION

This function pitch shifts a sample, in the time domain, using a circular array, this function will shift the frequency up, or down, depending on whether the ratio is greater than, or less than 1.0 respectively.

NOTES ON USE

This technique benefits from carefully chosen array lengths, however some distortion will be seen as the pointers "cross over". Incorporated in the function is a smoothing filter, that can reduce this effect, another technique is to linearly interpolate samples, as the pointers cross. As with the frequency domain interpolation, the array lengths should be as large as possible, without adding too much delay.

The input array offset parameter should be initialised to zero in the calling function. The output array offset and previous sample parameters should be initialised to SIGLIB_ZERO in the calling function.

CROSS REFERENCE

SDA FdInterpolate, SDA TdPitchShift

void SDA TdPitchShift (const SLData t*, Pointer to source array SLData t*, Pointer to destination array SLData t*, Pitch shift array pointer SLArrayIndex t*, Input array offset SLData t*, Output array offset SLData t*, Previous sample const SLData t, Pitch shift ratio const SLArrayIndex t, Length of pitch shift array const SLArrayIndex_t) Array length

DESCRIPTION

This function pitch shifts an array of samples, in the time domain, using a circular array, this function will shift the frequency up, or down, depending on whether the ratio is greater than, or less than 1.0 respectively.

NOTES ON USE

This technique benefits from carefully chosen array lengths, however some distortion will be seen as the pointers "cross over". Incorporated in the function is a smoothing filter, that can reduce this effect, another technique is to linearly interpolate samples, as the pointers cross. As with the frequency domain interpolation, the array lengths should be as large as possible, without adding too much delay.

The input array offset parameter should be initialised to zero in the calling function. The output array offset and previous sample parameters should be initialised to SIGLIB ZERO in the calling function.

CROSS REFERENCE

SDA FdInterpolate, SDS TdPitchShift

SLData_t SDS_EchoGenerate (const SLData_t, Input sample SLData_t *, Echo state array pointer SLArrayIndex_t *, Echo array data input location const SLData_t, Echo delay const SLData_t, Echo decay const enum SLEcho_t, Echo type const SLArrayIndex_t) Echo array length

DESCRIPTION

This function generates an echo, which is superimposed on a signal, by delaying it and adding it to the original. The data is delayed, using a circular array. Two forms of echo can be generated:

SIGLIB_ECHO Produces a feedback echo
SIGLIB REVERB Produces a feed forward echo.

The delay applied to the signal is a fraction of the echo array length, to get this as a time, in seconds, the sample rate (Hz) and the array length must be used, as follows:

$$Time delay(Secs) = Echodelay * \frac{Buffer length}{Sample rate}$$

NOTES ON USE

The Echo array data input location parameter should be initialised to zero in the calling function.

CROSS REFERENCE

void SDA_Power (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t, Power to raise data to const SLArrayIndex_t) Array length

DESCRIPTION

This function raises the data in the array to a power, on a per-sample basis.

NOTES ON USE

The source and destination pointers can point to the same array.

CROSS REFERENCE

SLData_t SDS_Polynomial (const	SLData_t, Data sample
const SLData_t,	x^0 coefficient
const SLData_t,	x^1 coefficient
const SLData_t,	x^2 coefficient
const SLData_t,	x^3 coefficient
const SLData_t,	x^4 coefficient
const SLData_t)	x^5 coefficient

DESCRIPTION

This function equates the polynomial:

$$y = C0 + C1*x + C2*x^2 + C3*x^3 + C4*x^4 + C5*x^5$$

NOTES ON USE

This function is very useful for adding a scale and an offset to a vector (using C0 and C1), prior to displaying it.

CROSS REFERENCE

SDA_Polynomial

SLData t SDA_Polynomial (const SLData_t *, Source array pointer SLData t*, Destination array pointer const SLData t, x^0 coefficient const SLData t, x^1 coefficient const SLData t, x^2 coefficient const SLData t, x^3 coefficient x^4 coefficient const SLData t, const SLData t, x^5 coefficient const SLArrayIndex_t) Array length

DESCRIPTION

This function equates the polynomial, on a per sample basis:

$$y = C0 + C1*x + C2*x^2 + C3*x^3 + C4*x^4 + C5*x^5$$

NOTES ON USE

This function is very useful for adding a scale and an offset to a vector (using C0 and C1), prior to displaying it. The source and destination pointers can point to the same array.

CROSS REFERENCE

SDS Polynomial

SDS_Modulo

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_Modulo (const SLData_t, Source data const SLData_t, Modulo number const enum SLModuloMode_t) Modulo mode

DESCRIPTION

This function returns the sample modulo N. The two types of modulo are: $SIGLIB_SINGLE_SIDED_MODULO$ and $SIGLIB_DOUBLE_SIDED_MODULO$ where single sided wraps the number between 0 and Max and the double sided between -Max and + Max.

NOTES ON USE

CROSS REFERENCE

 SDA_Modulo

void SDA_Modulo (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLData_t, Modulo number const enum SLModuloMode_t, const SLArrayIndex_t) Modulo mode Array length

DESCRIPTION

This function returns the samples in the array modulo N. The two types of modulo are: SIGLIB_SINGLE_SIDED_MODULO and SIGLIB_DOUBLE_SIDED_MODULO where single sided wraps the number between 0 and Max and the double sided between - Max and + Max.

NOTES ON USE

CROSS REFERENCE

SDS Modulo

Automatic Gain Control Functions

SigLib includes a number of functions for applying automatic gain control (AGC) to a data stream.

The $xxx_AgcEnvelopeDetector$ functions are recommended for real-time applications such as speech etc.

void SDA AgcPeak (const SLData t*, Source array pointer SLData t*, Destination array pointer const SLData t, Desired signal magnitude to attain const SLData t, Minimum threshold Sensitivity of attack gain adjustment const SLData t, const SLData t, Sensitivity of decay gain adjustment SLData t*, Pointer to gain value Pointer to maximum value SLData t*, const SLArrayIndex t, History array length const SLArrayIndex t) Array length

DESCRIPTION

This function provides an automatic gain control function by adjusting the gain dependent on the peak level in the previous N output samples in the history array. If the peak output magnitude is lower than the desired magnitude then the gain is increased otherwise it is decreased. The attack and decay sensitivities adjust the amounts by which the gain will be increased (attack) or decreased (decay) when modified. The sensitivities are multiplying factors, the attack sensitivity should be a value greater than, but very close to, 1.0 and the decay sensitivity should be less than, but very close to, 1.0.

NOTES ON USE

The minimum threshold parameter specifies the level below which the gain value is not adjusted, this is used to ensure that the AGC gain during periods of "silence".

The feedback calculates the error over a small history of the output data stream, different applications will require different sub-array lengths and hence different sensitivity coefficients. The source array length must be an integer multiple of the history array length.

The gain value should be initialised to 1.0 (or another suitable value) before calling this function.

This function will always be stable.

CROSS REFERENCE

SIF_AgcMeanAbs, SDA_AgcMeanAbs, SIF_AgcMeanSquared, SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS_AgcEnvelopeDetector, SDA_AgcEnvelopeDetector, SDA_Drc, SDA_Drc

```
void SIF AgcMeanAbs (SLData t*,
                                          Moving average state array
       SLArrayIndex t*,
                                          Moving average state array index
       SLData t*,
                                          Pointer to moving average sum
                                          Pointer to AGC gain
       SLData t*,
       SLData t*,
                                          Pointer to scaled desired mean level
       SLData t*,
                                          Pointer to threshold mean level
       const SLData t,
                                          Desired level of AGC output
       const SLData t,
                                          Threshold for update of AGC
       const SLArrayIndex_t)
                                          Length of moving average
```

DESCRIPTION

This function initializes the SDA AgcMeanAbs function.

NOTES ON USE

The minimum threshold parameter specifies the level below which the gain value is not adjusted, this is used to ensure that the AGC gain during periods of "silence". This level is converted to a mean absolute value.

CROSS REFERENCE

```
SDA_AgcPeak, SDA_AgcMeanAbs, SIF_AgcMeanSquared, SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS_AgcEnvelopeDetector, SDA_AgcEnvelopeDetector, SDS_Drc, SDA_Drc
```


void SDA AgcMeanAbs (const SLData t*, Pointer to source array

SLData t*, Pointer to destination array const SLData t, Desired scaled value const SLData t, Threshold scaled value const SLData t, Attack sensitivity const SLData t, Decay sensitivity SLData t*, Moving average state array Moving average state array index SLArrayIndex t*, SLData t*, Pointer to moving average sum Pointer to AGC gain SLData t*, const SLArrayIndex t, Length of moving average state array

Length of input array

DESCRIPTION

const SLArrayIndex t)



This function provides an automatic gain control function by adjusting the gain dependent on the mean (moving average) of the absolute level in the previous Noutput samples. If the output mean is lower than the desired mean then the gain is increased otherwise it is decreased. The attack and decay sensitivities adjust the amounts by which the gain will be increased (attack) or decreased (decay) when modified. The sensitivities are multiplying factors, the attack sensitivity should be a value greater than, but very close to, 1.0 and the decay sensitivity should be less than, but very close to, 1.0.

NOTES ON USE

The gain value should be initialised to 1.0 (or another suitable value) before calling this function.

This function will always be stable and is optimised to process sinusoidal waveforms.

This function does not use the divide by N to calculate the true moving averages instead all numbers are scaled by N and handled accordingly.

CROSS REFERENCE

SDA_AgcPeak, SIF_AgcMeanAbs, SIF_AgcMeanSquared, SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS_AgcEnvelopeDetector, SDA_AgcEnvelopeDetector, SIF_Drc, SDS_Drc, SDA_Drc

void SIF AgcMeanSquared (SLData t*, Moving average state array SLArrayIndex t*, Moving average state array index SLData t*, Pointer to moving average sum Pointer to AGC gain SLData t*, SLData t*, Ptr to scaled desired mean squared level SLData t*, Pointer to threshold mean squared level const SLData t, Desired level of AGC output const SLData t, Threshold for update of AGC const SLArrayIndex_t) Length of moving average

DESCRIPTION

This function initializes the SDA AgcMeanSquared function.

NOTES ON USE

The minimum threshold parameter specifies the level below which the gain value is not adjusted, this is used to ensure that the AGC gain during periods of "silence". This level is converted to a mean absolute value.

CROSS REFERENCE

```
SDA_AgcPeak, SIF_AgcMeanAbs, SDA_AgcMeanAbs, SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS_AgcEnvelopeDetector, SDA_AgcEnvelopeDetector, SDA_Drc
```

void SDA_AgcMeanSquared (const SLData_t *, Pointer to source array

SLData_t *, Pointer to destination array const SLData_t, Desired scaled value const SLData_t, Threshold scaled value const SLData_t, Attack sensitivity const SLData_t, Decay sensitivity

SLData_t *, Moving average state array
SLArrayIndex_t *, Moving average state array index
SLData_t *, Pointer to moving average sum

SLData_t *, Pointer to AGC gain

const SLArrayIndex t, Length of moving average state array

const SLArrayIndex_t) Length of input array

DESCRIPTION

This function provides an automatic gain control function by adjusting the gain dependent on the mean (moving average) of the squared values in the previous N output samples. If the output mean squared value is lower than the desired mean squared value then the gain is increased otherwise it is decreased. The attack and decay sensitivities adjust the amounts by which the gain will be increased (attack) or decreased (decay) when modified. The sensitivities are multiplying factors, the attack sensitivity should be a value greater than, but very close to, 1.0 and the decay sensitivity should be less than, but very close to, 1.0.

NOTES ON USE

The gain value should be initialised to 1.0 (or another suitable value) before calling this function.

This function will always be stable and is optimised to process sinusoidal waveforms.

This function does not use the divide by N to calculate the true moving averages instead all numbers are scaled by N and handled accordingly.

CROSS REFERENCE

```
SDA_AgcPeak, SIF_AgcMeanAbs, SDA_AgcMeanAbs, SIF_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS_AgcEnvelopeDetector, SDA_AgcEnvelopeDetector, SDA_Drc, SDA_Drc
```

void SIF_AgcEnvelopeDetector (const SLData_t, Envelope detector time constant

const SLData t, Sample rate

SLData_t *, Pointer to One-pole filter state variable SLData_t *, Pointer to One-pole filter coefficient

SLData t*) Pointer to AGC gain variable

DESCRIPTION

This function initializes the xxx_AgcEnvelopeDetector functions that implement automatic gain control.

NOTES ON USE

CROSS REFERENCE

SDA_AgcPeak, SIF_AgcMeanAbs, SDA_AgcMeanAbs, SIF_AgcMeanSquared. SDA_AgcMeanSquared. SDS_AgcEnvelopeDetector, SDA_AgcEnvelopeDetector, SIF_Drc, SDS_Drc, SDA_Drc

SLData_t SDS_AgcEnvelopeDetector (cons	st SLData_t, Source sample	
const SLData_t,	AGC desired output level	
const SLData_t,	AGC minimum threshold below which	
no gain control occurs		
const SLData_t,	AGC slow attack sensitivity	
const SLData_t,	AGC slow decay sensitivity	
const SLData_t,	AGC fast attack sensitivity	
const SLData_t,	AGC fast decay sensitivity	
SLData_t *,	Pointer to One-pole filter state variable	
const SLData_t,	One-pole filter coefficient	
SLData_t *,	Pointer to AGC gain variable	
const SLData_t,	AGC maximum gain value	
const SLData_t)	AGC maximum attenuation value	

DESCRIPTION

This function provides an automatic gain control function by adjusting the gain dependent on the envelope of the input samples. The envelope is computed using a normalized gain One-pole filter, for which the feedback coefficient is calculate from the desired time constant in the initialization function SIF AgcEnvelopeDetector.

A minimum threshold is applied to the envelope output, below which no gain control occurs.

If the envelope output is above the minimum threshold then gain will be applied to the envelope output, which is used to adjust the gain according to the attack and decay sensitivities. If the envelope output is lower than the desired level then the gain is increased otherwise it is decreased. The attack and decay sensitivities adjust the amounts by which the gain will be increased (attack) or decreased (decay) when modified. The sensitivities are multiplying factors, the attack sensitivity should be a value greater than, but very close to, 1.0 and the decay sensitivity should be less than, but very close to, 1.0.

NOTES ON USE

This function also includes maximum values for the gain and attenuation. This function operates on a per-sample basis and is optimized for lower latency, for real-time applications.

CROSS REFERENCE

```
SDA_AgcPeak, SIF_AgcMeanAbs, SDA_AgcMeanAbs, SIF_AgcMeanSquared. SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDA_AgcEnvelopeDetector, SIF_Drc, SDS_Drc, SDA_Drc
```

void SDA_AgcEnvelopeDetector (const SL	Data_t *, Pointer to source array	
SLData_t *,	Pointer to destination array	
const SLData_t,	AGC desired output level	
const SLData_t,	AGC minimum threshold below which	
no gain control occurs		
const SLData_t,	AGC slow attack sensitivity	
const SLData_t,	AGC slow decay sensitivity	
const SLData_t,	AGC fast attack sensitivity	
const SLData_t,	AGC fast decay sensitivity	
SLData_t *,	Pointer to One-pole filter state variable	
const SLData_t,	One-pole filter coefficient	
SLData_t *,	Pointer to AGC gain variable	
const SLData_t,	AGC maximum gain value	
const SLData_t,	AGC maximum attenuation value	
const SLArrayIndex_t)	Array length	

DESCRIPTION

This function provides an automatic gain control function by adjusting the gain dependent on the envelope of the input samples. The envelope is computed using a normalized gain One-pole filter, for which the feedback coefficient is calculate from the desired time constant in the initialization function SIF_AgcEnvelopeDetector.

A minimum threshold is applied to the envelope output, below which no gain control occurs.

If the envelope output is above the minimum threshold then gain will be applied to the envelope output, which is used to adjust the gain according to the attack and decay sensitivities. If the envelope output is lower than the desired level then the gain is increased otherwise it is decreased. The attack and decay sensitivities adjust the amounts by which the gain will be increased (attack) or decreased (decay) when modified. The sensitivities are multiplying factors, the attack sensitivity should be a value greater than, but very close to, 1.0 and the decay sensitivity should be less than, but very close to, 1.0.

NOTES ON USE

This function also includes maximum values for the gain and attenuation. This function operates on a per-array basis and is optimized for run-time performance.

CROSS REFERENCE

```
SDA_AgcPeak, SIF_AgcMeanAbs, SDA_AgcMeanAbs, SIF_AgcMeanSquared. SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS AgcEnvelopeDetector, SIF Drc, SDS Drc, SDA Drc
```

void SIF_Drc (SLData_t *); Pointer to envelope follower state variable

DESCRIPTION

This function initializes the xxx_Drc functions, that implement dynamic range compression.

NOTES ON USE

When executing the example (drc.c) you may observe what looks like an anomaly shown here:

This is a direct result of the envelope follower not enabling the dynamic range control until the signal has crossed the desired threshold.

CROSS REFERENCE

SDA_AgcPeak, SIF_AgcMeanAbs, SDA_AgcMeanAbs, SIF_AgcMeanSquared. SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS AgcEnvelopeDetector, SDA AgcEnvelopeDetector, SDA Drc

SLData_t SDS_Drc (const SLData_t, Input sample

SLData_t *, Pointer to envelope follower state

variable

const SLData t, Envelope follower one-pole filter

coefficient

const SLData t, Envelope follower threshold to enable

DRC functionality

const SLDrcLevelGainTable *, Pointer to Thresholds/Gains table

const SLArrayIndex_t, Number of knees const SLData t) Number of knees Makeup gain

DESCRIPTION

This function provides dynamic range control by adjusting the gain dependent on the magnitude of the input samples.

An envelope follower is used to track the input signal level. A minimum threshold is applied to the envelope output, below which no dynamic range control occurs. The envelope is computed using a normalized gain One-pole filter, for which the feedback coefficient is calculate from the desired time constant in the initialization function SIF_Drc.

This function supports any number of knees, which are the points at which increasing compression (attenuation) occurs, applying successive levels of compression above each knee level.

This function also includes a makeup gain option, that is applied to the output after dynamic range conversion, to compensate for the loss of loudness in the process.

NOTES ON USE

This function operates on a per-sample basis and is optimized for lower latency, for real-time applications.

CROSS REFERENCE

SDA_AgcPeak, SIF_AgcMeanAbs, SDA_AgcMeanAbs, SIF_AgcMeanSquared. SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS AgcEnvelopeDetector, SDA AgcEnvelopeDetector, SDA Drc

void SDA Drc (const SLData t*, Pointer to source array SLData t*, Pointer to destination array SLData t*, Pointer to envelope follower state variable const SLData t, Envelope follower one-pole filter coefficient const SLData t, Envelope follower threshold to enable DRC functionality const SLDrcLevelGainTable *, Pointer to Thresholds/Gains table const SLArrayIndex t, Number of knees const SLData t, Makeup gain Array length const SLArrayIndex t)

DESCRIPTION

This function provides dynamic range control by adjusting the gain dependent on the magnitude of the input samples.

An envelope follower is used to track the input signal level. A minimum threshold is applied to the envelope output, below which no dynamic range control occurs. The envelope is computed using a normalized gain One-pole filter, for which the feedback coefficient is calculate from the desired time constant in the initialization function SIF_Drc.

This function supports any number of knees, which are the points at which increasing compression (attenuation) occurs, applying successive levels of compression above each knee level.

This function also includes a makeup gain option, that is applied to the output after dynamic range conversion, to compensate for the loss of loudness in the process.

NOTES ON USE

This function operates on a per-array basis and is optimized for run-time performance.

CROSS REFERENCE

SDA_AgcPeak, SIF_AgcMeanAbs, SDA_AgcMeanAbs, SIF_AgcMeanSquared. SDA_AgcMeanSquared. SIF_AgcEnvelopeDetector, SDS AgcEnvelopeDetector, SDA AgcEnvelopeDetector, SDS Drc

void SDA_GroupDelay (const SLData_t *, Phase signal array pointer SLData_t *, Destination array pointer SLData_t *, Previous phase value pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the group delay of the phase signal source, essentially this is a differentiating function however it will allow for the fact that most phase sources wrap at +/- PI.

NOTES ON USE

The previous phase value should be initialised to zero. This indirect access technique has been used to allow the function to be re-entrant and to be applied to multiple streams simultaneously.

CROSS REFERENCE

SDA_PhaseWrapped, SDA_PhaseUnWrapped, SDA_RectangularToPolar

SLFixData_t SDA_ZeroCrossingDetect (const SLData_t *, Source array pointer SLData_t *, Destination array pointer SLData_t *, Previous source data value pointer const enum SLLevelCrossingMode_t, Level crossing type - +ve, -ve, both const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the number of zero crossings in the source array and sets the values in the destination array to zero except where a zero crossing is detected in the input array. The zero crossings are detected according to the SLLevelCrossingMode t parameter as follows:

SIGLIB_POSITIVE_LEVEL_CROSS	Negative to positive zero	+1
	crossings	
SIGLIB_NEGATIVE_LEVEL_CROSS	Positive to negative zero	-1
	crossings	
SIGLIB_ALL_LEVEL_CROSS	All zero crossings	+1 for positive zero crossings and -1 for
		negative zero
		crossings

NOTES ON USE

The destination and source array pointers can point to the same array.

The pointer to previous source data value parameter should be set to zero prior to calling this function, it is used to carry the data over array boundaries.

CROSS REFERENCE

SDS_ZeroCrossingDetect, SDA_FirstZeroCrossingLocation, SDA_ZeroCrossingCount, SDA_LevelCrossingDetect, SDS_LevelCrossingDetect, SDA_FirstLevelCrossingLocation, SDA_LevelCrossingCount.

SLData_t SDS_ZeroCrossingDetect (const SLData_t, Source sample SLData_t *, Previous source data value pointer const enum SLLevelCrossingMode t) Level crossing type - +ve, -ve, both

DESCRIPTION

This function returns zero if no zero crossing is detected and returns the zero crossings according to the SLLevelCrossingMode_t parameter as follows:

SIGLIB_POSITIVE_LEVEL_CROSS	Negative to positive zero	+1
	crossings	
SIGLIB_NEGATIVE_LEVEL_CROSS	Positive to negative zero	-1
	crossings	
SIGLIB_ALL_LEVEL_CROSS	All zero crossings	+1 for positive zero crossings and -1 for negative zero
		crossings

NOTES ON USE

The pointer to previous source data value parameter should be set to zero prior to calling this function, it is used to carry the data over subsequent calls to this function.

CROSS REFERENCE

SDA_ZeroCrossingDetect, SDA_FirstZeroCrossingLocation, SDA_ZeroCrossingCount, SDA_LevelCrossingDetect, SDS_LevelCrossingDetect, SDA_FirstLevelCrossingLocation, SDA_LevelCrossingCount.

SLFixData_t SDA_FirstZeroCrossingLocation (const SLData_t *, Source array pointer

SLData_t *, Previous source data value pointer const enum SLLevelCrossingMode_t, Level crossing type - +ve, -ve, both const SLArrayIndex t) Array length

DESCRIPTION

This function returns the location of the first sample after the signal has crossed zero according to the SLLevelCrossingMode t parameter as follows:

SIGLIB_POSITIVE_LEVEL_CROSS	Negative to positive zero crossings	+1
SIGLIB_NEGATIVE_LEVEL_CROSS	Positive to negative zero crossings	-1
SIGLIB_ALL_LEVEL_CROSS	All zero crossings	+1 for positive zero crossings and -1 for negative zero crossings

NOTES ON USE

The pointer to previous source data value parameter should be set to zero prior to calling this function and is used to carry the data over array boundaries.

This function returns SIGLIB_LEVEL_CROSSING_NOT_DETECTED if no zero crossings have been detected.

CROSS REFERENCE

SDA_ZeroCrossingDetect, SDS_ZeroCrossingDetect, SDA_ZeroCrossingCount, SDA_LevelCrossingDetect, SDS_LevelCrossingDetect, SDA_FirstLevelCrossingLocation, SDA_LevelCrossingCount.

SLFixData_t SDA_ZeroCrossingCount (const SLData_t *, Source array pointer SLData_t *, Previous source data value pointer const enum SLLevelCrossingMode_t, Level crossing type - +ve, -ve, both const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the number of zero crossings in the source array. The zero crossings are detected according to the <code>SLLevelCrossingMode_t</code> parameter as follows:

SIGLIB_POSITIVE_LEVEL_CROSS	Negative to positive zero crossings	+1
SIGLIB_NEGATIVE_LEVEL_CROSS	Positive to negative zero crossings	-1
SIGLIB_ALL_LEVEL_CROSS	All zero crossings	+1 for positive zero crossings and -1 for negative zero crossings

NOTES ON USE

The pointer to previous source data value parameter should be set to zero prior to calling this function, it is used to carry the data over array boundaries.

CROSS REFERENCE

SDA_ZeroCrossingDetect, SDS_ZeroCrossingDetect, SDA_FirstZeroCrossingLocation, SDA_LevelCrossingDetect, SDS_LevelCrossingDetect, SDA_FirstLevelCrossingLocation, SDA_LevelCrossingCount.

SLFixData_t SDA_LevelCrossingDetect (const SLData_t *, Source array pointer SLData_t *, Destination array pointer SLData_t *, Previous source data value pointer const enum SLLevelCrossingMode_t, Level crossing type - +ve, -ve, both const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the number of level crossings in the source array and sets the values in the destination array to level except where a level crossing is detected in the input array. The level crossings are detected according to the SLLevelCrossingMode t parameter as follows:

SIGLIB_POSITIVE_LEVEL_CROSS	Negative to positive zero	+1
	crossings	
SIGLIB_NEGATIVE_LEVEL_CROSS	Positive to negative zero	-1
	crossings	
SIGLIB_ALL_LEVEL_CROSS	All zero crossings	+1 for positive zero
		crossings and -1 for
		negative zero
		crossings

NOTES ON USE

The destination and source array pointers can point to the same array.

The pointer to previous source data value parameter should be set to zero prior to calling this function, it is used to carry the data over array boundaries.

CROSS REFERENCE

SDA_ZeroCrossingDetect, SDS_ZeroCrossingDetect, SDA_FirstZeroCrossingLocation, SDA_ZeroCrossingCount, SDS_LevelCrossingDetect, SDA_FirstLevelCrossingLocation, SDA_LevelCrossingCount.

SLData_t SDS_LevelCrossingDetect (const SLData_t, Source sample SLData_t *, Previous source data value pointer const enum SLLevelCrossingMode t) Level crossing type - +ve, -ve, both

DESCRIPTION

This function returns zero if no level crossing is detected and returns the level crossings according to the SLLevelCrossingMode t parameter as follows:

SIGLIB_POSITIVE_LEVEL_CROSS	Negative to positive zero crossings	+1
SIGLIB_NEGATIVE_LEVEL_CROSS	Positive to negative zero crossings	-1
SIGLIB_ALL_LEVEL_CROSS	All zero crossings	+1 for positive zero crossings and -1 for negative zero crossings

NOTES ON USE

The pointer to previous source data value parameter should be set to zero prior to calling this function, it is used to carry the data over subsequent calls to this function.

CROSS REFERENCE

SDA_ZeroCrossingDetect, SDS_ZeroCrossingDetect, SDA_FirstZeroCrossingLocation, SDA_ZeroCrossingCount, SDA_LevelCrossingDetect, SDA_FirstLevelCrossingLocation, SDA_LevelCrossingCount.

SLFixData_t SDA_FirstLevelCrossingLocation (const SLData_t *, Source array pointer

SLData_t *, Previous source data value pointer const enum SLLevelCrossingMode_t, Level crossing type - +ve, -ve, both const SLArrayIndex t) Array length

DESCRIPTION

This function returns the location of the first sample after the signal has crossed the given level according to the SLLevelCrossingMode t parameter as follows:

SIGLIB_POSITIVE_LEVEL_CROSS	Negative to positive zero	+1
	crossings	
SIGLIB_NEGATIVE_LEVEL_CROSS	Positive to negative zero	-1
	crossings	
SIGLIB_ALL_LEVEL_CROSS	All zero crossings	+1 for positive zero crossings and -1 for negative zero crossings

NOTES ON USE

The pointer to previous source data value parameter should be set to zero prior to calling this function and is be used to carry the data over array boundaries.

This function returns SIGLIB_LEVEL_CROSSING_NOT_DETECTED if no level crossings have been detected.

CROSS REFERENCE

SDA_ZeroCrossingDetect, SDS_ZeroCrossingDetect, SDA_FirstZeroCrossingLocation, SDA_ZeroCrossingCount, SDA_LevelCrossingDetect, SDS_LevelCrossingDetect, SDA_LevelCrossingCount.

SLFixData_t SDA_LevelCrossingCount (const SLData_t *, Source array pointer SLData_t *, Previous source data value pointer const enum SLLevelCrossingMode_t, Level crossing type - +ve, -ve, both const SLArrayIndex t) Array length

DESCRIPTION

This function returns the number of level crossings in the source array. The level crossings are detected according to the <code>SLLevelCrossingMode_t</code> parameter as follows:

SIGLIB_POSITIVE_LEVEL_CROSS	Negative to positive zero crossings	+1
SIGLIB_NEGATIVE_LEVEL_CROSS	Positive to negative zero crossings	-1
SIGLIB_ALL_LEVEL_CROSS	All zero crossings	+1 for positive zero crossings and -1 for negative zero crossings

NOTES ON USE

The pointer to previous source data value parameter should be set to zero prior to calling this function, it is used to carry the data over array boundaries.

CROSS REFERENCE

SDA_ZeroCrossingDetect, SDS_ZeroCrossingDetect, SDA_FirstZeroCrossingLocation, SDA_ZeroCrossingCount, SDA_LevelCrossingDetect, SDS_LevelCrossingDetect, SDA_FirstLevelCrossingLocation.

SLArrayIndex_t SDA_ClearLocation (SLData_t *, Array pointer const SLArrayIndex_t, Location to clear const SLArrayIndex_t) Array length

DESCRIPTION

This function sets the data at the required location to zero.

NOTES ON USE

CROSS REFERENCE SDA_SetLocation

SLArrayIndex_t SDA_SetLocation (SLData_t *, Array pointer

const SLArrayIndex t, Location to set

const SLData t Value to write to array

const SLArrayIndex_t) Array length

DESCRIPTION

This function sets the data at the required location to the provided value.

NOTES ON USE

CROSS REFERENCE SDA_ClearLocation

SLArrayIndex_t SDA_SortMinToMax (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function sorts the data in the array, according to value. The order of the data in the returned array is minimum first, maximum last.

This function uses the bubble sorting algorithm.

NOTES ON USE

The destination and source array pointers can point to the same array.

CROSS REFERENCE

SDA_SortMaxToMin, SDA_SortMinToMax2, SDA_SortMaxToMin2, SDA SortIndexed.

SLArrayIndex_t SDA_SortMaxToMin (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex t)

Array length

DESCRIPTION

This function sorts the data in the array, according to value. The order of the data in the returned array is maximum first, minimum last.

This function uses the bubble sorting algorithm.

NOTES ON USE

The destination and source array pointers can point to the same array.

CROSS REFERENCE

SDA_SortMinToMax, SDA_SortMinToMax2, SDA_SortMaxToMin2, SDA SortIndexed.

SLArrayIndex_t SDA_SortMinToMax2 (const SLData_t *, Source array pointer #1

const SLData_t *, Source array pointer #2
SLData_t *, Destination array pointer #1
SLData_t *, Destination array pointer #2

const SLArrayIndex t) Array length

DESCRIPTION

This function sorts the data in the array, according to value. The order of the data in the returned array is minimum first, maximum last.

This function performs the same operation on both source arrays. This can be helpful if you want to use the second array to generate an index array for applying the same sorting algorithm to further arrays.

This function uses the bubble sorting algorithm.

NOTES ON USE

The destination and source array pointers can point to the same array.

CROSS REFERENCE

 $SDA_SortMinToMax,\ SDA_SortMaxToMin,\ SDA_SortMaxToMin2,\\ SDA_SortIndexed.$

SLArrayIndex_t SDA_SortMaxToMin2 (const SLData_t *, Source array pointer #1

const SLData_t *, Source array pointer #2
SLData_t *, Destination array pointer #1
SLData_t *, Destination array pointer #2

const SLArrayIndex t) Array length

DESCRIPTION

This function sorts the data in the array, according to value. The order of the data in the returned array is maximum first, minimum last.

This function performs the same operation on both source arrays. This can be helpful if you want to use the second array to generate an index array for applying the same sorting algorithm to further arrays.

This function uses the bubble sorting algorithm.

NOTES ON USE

The destination and source array pointers can point to the same array.

CROSS REFERENCE

 $SDA_SortMinToMax,\ SDA_SortMaxToMin, SDA_SortMinToMax2, SDA_SortIndexed.$

SLArrayIndex_t SDA_SortIndexed (const SLData_t *, Source array pointer

const SLArrayIndex_t *, Index Array Pointer
SLData_t *, Destination array pointer
const SLArrayIndex_t) Array length

DESCRIPTION

This function sorts the data in the array, using the index array to provide the output location for the sample.

NOTES ON USE

This function will not work in-place.

CROSS REFERENCE

 $SDA_SortMinToMax,\ SDA_SortMaxToMin,\ SDA_SortMinToMax2,\ SDA_SortMaxToMin2.$

SLFixData_t SDS_CountOneBits (const SLFixData_t) Input word

DESCRIPTION

This function counts the number of "one" bits in the input data word.

NOTES ON USE

CROSS REFERENCE

 $SDS_CountZeroBits, SDS_CountLeadingOneBits, \\SDS_CountLeadingZeroBits.$

SLFixData_t SDS_CountZeroBits (const SLFixData_t) Input word

DESCRIPTION

This function counts the number of "zero" bits in the input data word.

NOTES ON USE

CROSS REFERENCE

 $SDS_CountOneBits, SDS_CountLeadingOneBits, SDS_CountLeadingZeroBits.$

SLFixData_t SDS_CountLeadingOneBits (const SLFixData_t) Input word

DESCRIPTION

This function counts the number of leading "one" bits in the input data word.

NOTES ON USE

CROSS REFERENCE

 $SDS_CountOneBits, SDS_CountZeroBits, SDS_CountLeadingZeroBits.$

SLFixData_t SDS_CountLeadingZeroBits (const SLFixData_t) Input word

DESCRIPTION

This function counts the number of leading "zero" bits in the input data word.

NOTES ON USE

CROSS REFERENCE

SDS_CountOneBits, SDS_CountZeroBits, SDS_CountLeadingOneBits.

SDA_Sign

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Sign (const SLData_t *,Source array pointerSLData_t *,Destination array pointerconst SLArrayIndex_t)Sample array length

DESCRIPTION

This function returns the sign of the values in the source vector. I.E:

NOTES ON USE

CROSS REFERENCE

void SDA_Swap (SLData_t *,Source array pointer 1SLData_t *,Source array pointer 2const SLArrayIndex_t)Sample array length

DESCRIPTION

This function swaps the elements in each array.

Source1[0] <-> Source2[0] Source1[2] <-> Source2[1]

 $. \\ Source1[N] <-> Source2[N]$

NOTES ON USE

CROSS REFERENCE

SLFixData_t SUF_ModuloIncrement (const SLFixData_t, Input value const SLFixData_t, Increment value const SLFixData_t) Modulo value

DESCRIPTION

This function increments the fixed point value using modulo N arithmetic.

NOTES ON USE

CROSS REFERENCE

 $SUF_ModuloDecrement, SUF_IndexModuloIncrement, \\SUF_IndexModuloDecrement$

SLFixData_t SUF_ModuloDecrement (const SLFixData_t, Input value const SLFixData_t, Decrement value const SLFixData_t) Modulo value

DESCRIPTION

This function decrements the fixed point value using modulo N arithmetic.

NOTES ON USE

CROSS REFERENCE

 $SUF_ModuloIncrement, SUF_IndexModuloIncrement, \\SUF_IndexModuloDecrement$

const SLArrayIndex_t) Modulo value

DESCRIPTION

This function increments the fixed point array index value using modulo N arithmetic.

NOTES ON USE

CROSS REFERENCE

 $SUF_Index Modulo Decrement, \ SUF_Modulo Increment, \\ SUF_Modulo Decrement$

const SLArrayIndex_t) Modulo value

DESCRIPTION

This function decrements the fixed point array index value using modulo N arithmetic.

NOTES ON USE

CROSS REFERENCE

 $SUF_Index Modulo Increment, \ SUF_Modulo Increment, \ SUF_Modulo Decrement$

SDA Find

PROTOTYPE AND PARAMETER DESCRIPTION

```
SLArrayIndex_t SDA_Find (const SLData_t *, Pointer to source array SLData_t *, Pointer to data destination array SLArrayIndex_t *, Pointer to location destination array const enum SLFindType_t, Find type const SLArrayIndex t) Array length
```

DESCRIPTION

This function locates all the values in the source array that match the specification in 'FindType'. The type options are:

```
SIGLIB_FIND_GREATER_THAN_ZERO
SIGLIB_FIND_GREATER_THAN_OR_EQUAL_TO_ZERO
SIGLIB_FIND_EQUAL_TO_ZERO
SIGLIB_FIND_LESS_THAN_ZERO
SIGLIB_FIND_LESS_THAN_OR_EQUAL_TO_ZERO
SIGLIB_FIND_NOT_EQUAL_TO_ZERO
```

When the function locates a value in the source array it writes the value to the data destination array and the index of the value to the location destination array.

This function returns the number of elements of the given type that have been found.

NOTES ON USE

The output array length will be variable, dependent on the source data. The safest way to use this function is to allocate the destination arrays to have the same input lengths as the source array.

CROSS REFERENCE

SDA FindValue

```
SLArrayIndex_t SDA_FindValue (const SLData_t *, Pointer to source array const SLData_t, Desired value SLData_t *, Pointer to data destination array SLArrayIndex_t *, Pointer to location destination array const enum SLFindType_t, Find type const SLArrayIndex_t) Find type

**Total Construction**

**Pointer to source array Pointer to source array Pointer to data destination array Pointer to location destination array Find type

**Total Construction**

**Pointer to source array Pointer to SLArray Pointer to data destination array Pointer to location destin
```

DESCRIPTION

This function locates all the values in the source array that match the desired value and the specification in 'FindType'. The type options are:

```
SIGLIB_FIND_GREATER_THAN_ZERO
SIGLIB_FIND_GREATER_THAN_OR_EQUAL_TO_ZERO
SIGLIB_FIND_EQUAL_TO_ZERO
SIGLIB_FIND_LESS_THAN_ZERO
SIGLIB_FIND_LESS_THAN_OR_EQUAL_TO_ZERO
SIGLIB_FIND_NOT_EQUAL_TO_ZERO
```

When the function locates a value in the source array it writes the value to the data destination array and the index of the value to the location destination array.

This function returns the number of elements of the given type that have been found.

NOTES ON USE

The output array length will be variable, dependent on the source data. The safest way to use this function is to allocate the destination arrays to have the same input lengths as the source array.

CROSS REFERENCE

SDA Find

DSP UTILITY FUNCTIONS (dsputil3.c)

SIF_DeGlitch

PROTOTYPE AND PARAMETER DESCRIPTION

void SIF_DeGlitch (SLArrayIndex_t *, Count of number of samples out of range SLData_t, Initial level holdover SLData_t *)

Current level holdover

DESCRIPTION

This function initializes the de-glitch / de-bounce functions.

NOTES ON USE

The de-glitch functions hold over the existing signal level when the input signal crosses the threshold level for less than a specified number of samples.

CROSS REFERENCE

SDS DeGlitch, SDA DeGlitch

SDS DeGlitch

PROTOTYPE AND PARAMETER DESCRIPTION

```
SLData_t SDS_DeGlitch (SLData_t,
SLArrayIndex_t *,
Count of number of samples out of range
const enum SLDeGlitchMode_t,
const SLArrayIndex_t,
Count of number of samples out of range
Switch to indicate de-glitch mode
Glitch length threshold
Glitch level threshold
SLData_t *)
Current level holdover
```

DESCRIPTION

This function performs a de-glitch / de-bounce function on the source data, on a per sample basis.

NOTES ON USE

The de-glitch functions hold over the existing signal level when the input signal crosses the threshold level for less than a specified number of samples.

The de-glitch mode parameter has the following options:

SIGLIB_DEGLITCH_ABOVE	Check for glitches above the threshold level
SIGLIB_DEGLITCH_BOTH	Check for glitches above and below the threshold level
SIGLIB_DEGLITCH_BELOW	Check for glitches below the threshold level

CROSS REFERENCE

SIF DeGlitch, SDA DeGlitch

SDA DeGlitch

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA DeGlitch (SLData t*, Pointer to source array SLData t*, Pointer to destination array SLArrayIndex t*, Count of number of samples out of range Switch to indicate de-glitch mode const enum SLDeGlitchMode t, Glitch length threshold const SLArrayIndex t, const SLData t, Glitch level threshold SLData t*, Current level holdover const SLArrayIndex t) Array length

DESCRIPTION

This function performs a de-glitch / de-bounce function on the source data, on an array basis. This function works across array boundaries

NOTES ON USE

The de-glitch functions hold over the existing signal level when the input signal crosses the threshold level for less than a specified number of samples.

The de-glitch mode parameter has the following options:

```
SIGLIB_DEGLITCH_ABOVE Check for glitches above the threshold level

SIGLIB_DEGLITCH_BOTH Check for glitches above and below the threshold level

SIGLIB_DEGLITCH_BELOW Check for glitches below the threshold level
```

CROSS REFERENCE

SIF DeGlitch, SDS DeGlitch

SLArrayIndex_t SDA_RemoveDuplicates (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Source array length

DESCRIPTION

This function removes duplicate entries from an array. The entries in the destination array appear in the order they were in the source array.

Return value: Number of elements in destination array.

NOTES ON USE

The order of the data is unchanged.

Result array length will be shorter than or equal to the length of the source array.

CROSS REFERENCE

SDA_FindAllDuplicates, SDA_FindFirstDuplicates, SDA FindSortAllDuplicates, SDA FindSortFirstDuplicates

SLArrayIndex_t SDA_FindAllDuplicates (const SLData_t *, Ptr to src array 1

const SLData_t *, Pointer to source array 2
SLData_t *, Pointer to destination array
const SLArrayIndex_t, Source array length 1
const SLArrayIndex t) Source array length 2

DESCRIPTION

This function searches the first array for all values that are entries in the second array.

Return value: Number of elements in destination array.

NOTES ON USE

The order of the data in the result array will appear in the order of the entries in the first array.

Result array length will be shorter than or equal to the length of the first source array.

Duplicate numbers in the first array will be duplicated in the result array.

CROSS REFERENCE

SDA_RemoveDuplicates, SDA_FindFirstDuplicates, SDA_FindSortAllDuplicates, SDA_FindSortFirstDuplicates

SLArrayIndex_t SDA_FindFirstDuplicates (const SLData_t *, Ptr to src array 1

const SLData_t *, Pointer to source array 2
SLData_t *, Pointer to destination array
const SLArrayIndex_t, Source array length 1
const SLArrayIndex_t) Source array length 2

DESCRIPTION

This function searches the first array for all values that are entries in the second array.

Return value: Number of elements in destination array.

NOTES ON USE

The order of the data in the result array will appear in the order of the entries in the first array.

Result array length will be shorter than or equal to the length of the first source array.

Duplicate numbers in the first array will be removed from the result array so that values only appear once.

CROSS REFERENCE

SDA_RemoveDuplicates, SDA_FindAllDuplicates, SDA FindSortAllDuplicates, SDA FindSortFirstDuplicates

SLArrayIndex_t SDA_FindSortAllDuplicates (const SLData_t *, Ptr. to src. array 1

const SLData_t *, Pointer to source array 2
SLData_t *, Pointer to destination array
const SLArrayIndex_t, Source array length 1
const SLArrayIndex t) Source array length 2

DESCRIPTION

This function searches the first array for all values that are entries in the second array and sorts them in order minimum to maximum.

Return value: Number of elements in destination array.

NOTES ON USE

The order of the data in the result array will sorted from the smallest to largest magnitude.

Result array length will be shorter than or equal to the length of the first source array.

Duplicate numbers in the first array will be duplicated in the result array.

CROSS REFERENCE

SDA_RemoveDuplicates, SDA_FindAllDuplicates, SDA FindFirstDuplicates, SDA FindSortFirstDuplicates

SLArrayIndex_t SDA_FindSortFirstDuplicates (const SLData_t *, Ptr to src array 1

const SLData_t *, Pointer to source array 2
SLData_t *, Pointer to destination array
const SLArrayIndex_t, Source array length 1
const SLArrayIndex t) Source array length 2

DESCRIPTION

This function searches the first array for all values that are entries in the second array and sorts them in order minimum to maximum.

Return value: Number of elements in destination array.

NOTES ON USE

The order of the data in the result array will sorted from the smallest to largest magnitude.

Result array length will be shorter than or equal to the length of the first source array.

Duplicate numbers in the first array will be removed from the result array so that values only appear once.

CROSS REFERENCE

SDA_RemoveDuplicates, SDA_FindAllDuplicates, SDA FindFirstDuplicates, SDA FindSortAllDuplicates

SDA_Shuffle

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function shuffles the order of the data in the array.

NOTES ON USE

As the size of the array approaches RAND_MAX, the result becomes less random. The solution is to use a better random number generator or call the function multiple times.

CROSS REFERENCE

 $SMX_ShuffleColumns, SMX_ShuffleRows$

void SDA_InsertSample (const SLData_t *, Pointer to source array

const SLData_t, New sample

SLData_t *, Pointer to destination array const SLArrayIndex_t, New sample location const SLArrayIndex_t) Source array length

DESCRIPTION

This function inserts the sample into the array, at the given location, and shifts all the data to the right of this location right by one sample.

NOTES ON USE

This function can work in-place. I.E. the source and destination pointers can point to the same array.

CROSS REFERENCE

SDA InsertArray, SDA ExtractSample, SDA ExtractArray

```
void SDA_InsertArray (const SLData_t *, Pointer to source array const SLData_t *, Pointer to new sample array SLData_t *, Pointer to new sample array const SLArrayIndex_t, New sample location const SLArrayIndex_t, New sample array length const SLArrayIndex_t) Source array length
```

DESCRIPTION

This function inserts the array of samples into the source array, at the given location, and shifts all the data to the right of this location right by number of new samples.

NOTES ON USE

This function can work in-place. I.E. the source and destination pointers can point to the same array.

CROSS REFERENCE

SDA_InsertSample, SDA_ExtractSample, SDA_ExtractArray

SLData_t SDA_ExtractSample (const SLData_t *, Pointer to source array

SLData_t *, Pointer to destination array

const SLArrayIndex_t, New sample location const SLArrayIndex_t) Source array length

DESCRIPTION

This function extracts a single sample from the array, at the given location, and shifts all the data to the right of this location left by one sample.

The extracted value is function's return value.

NOTES ON USE

This function can work in-place. I.E. the source and destination pointers can point to the same array.

CROSS REFERENCE

SDA_InsertSample, SDA_InsertArray, SDA_ExtractArray

void SDA_ExtractArray (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array Pointer to extracted sample array const SLArrayIndex_t, Extracted sample location const SLArrayIndex_t, Extracted sample array length const SLArrayIndex_t) Source array length

DESCRIPTION

This function extracts the array of samples from the array, at the given location, and shifts all the data to the right of the extracted array left by the number of extracted samples.

NOTES ON USE

This function can work in-place. I.E. the source and destination pointers can point to the same array.

CROSS REFERENCE

SDA InsertSample, SDA InsertArray, SDA ExtractSample

DATA TYPE CONVERSION FUNCTIONS (datatype.c)

SDA_SigLibDataToFix

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_SigLibDataToFix (const SLData_t *, Source array pointer SLFixData_t *, Destination array pointer const SLArrayIndex_t) Sample array length

DESCRIPTION

This function converts the input native SigLib data type to the native SigLib fixed point data type.

NOTES ON USE

This function uses rounding to nearest integer value to avoid floating point to fixed point conversion issues.

CROSS REFERENCE

SDA_FixToSigLibData, SDA_SigLibDataToImageData, SDA_ImageDataToSigLibData, SDA_Fix16ToSigLibData, SDA_SigLibDataToFix16, SDA_Fix32ToSigLibData, SDA_SigLibDataToFix32, SDS_QFormatIntegerToSigLibData, SDS_SigLibDataToQFormatInteger, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

void SDA_FixToSigLibData (const SLFixData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Sample array length

DESCRIPTION

This function converts the input native SigLib fixed point data type to the native SigLib data type.

NOTES ON USE

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_SigLibDataToImageData, SDA_ImageDataToSigLibData, SDA_Fix16ToSigLibData, SDA_SigLibDataToFix16, SDA_Fix32ToSigLibData, SDA_SigLibDataToFix32, SDS_QFormatIntegerToSigLibData, SDS_SigLibDataToQFormatInteger, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

void SDA_SigLibDataToImageData (const SLData_t *, Source array pointer SLFixData_t *, Destination array pointer const SLArrayIndex_t) Sample array length

DESCRIPTION

This function converts the input native SigLib data type to the native SigLib image data type.

NOTES ON USE

It is assumed that the image data type will be fixed point so this function uses rounding to nearest integer value to avoid floating point to fixed point conversion issues.

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData, SDA_ImageDataToSigLibData, SDA_Fix16ToSigLibData, SDA_SigLibDataToFix16, SDA_Fix32ToSigLibData, SDA_SigLibDataToFix32, SDS_QFormatIntegerToSigLibData, SDS_SigLibDataToQFormatInteger, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

void SDA_ImageDataToSigLibData (const SLFixData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Sample array length

DESCRIPTION

This function converts the input native SigLib image data type to the native SigLib data type.

NOTES ON USE

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData, SDA_SigLibDataToImageData, SDA_Fix16ToSigLibData, SDA_SigLibDataToFix16, SDA_Fix32ToSigLibData, SDA_SigLibDataToFix32, SDS_QFormatIntegerToSigLibData, SDS_SigLibDataToQFormatInteger, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

void SDA_SigLibDataToFix16 (SLData_t *, Pointer to source array SLInt16_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function converts the input native SigLib fixed point data type to 16 bit (short) fixed point data.

NOTES ON USE

This function uses rounding to nearest integer value to avoid floating point to fixed point conversion issues.

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData, SDA_SigLibDataToImageData, SDA_ImageDataToSigLibData, SDA_Fix16ToSigLibData, SDA_SigLibDataToFix32, SDA_Fix32ToSigLibData, SDS_QFormatIntegerToSigLibData, SDS_SigLibDataToQFormatInteger, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

void SDA_Fix16ToSigLibData (SLInt16_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function converts the input 16 bit (short) fixed point data type to the native SigLib data type.

NOTES ON USE

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData, SDA_SigLibDataToImageData, SDA_ImageDataToSigLibData, SDA_SigLibDataToFix16, SDA_SigLibDataToFix32, SDA_Fix32ToSigLibData, SDS_QFormatIntegerToSigLibData, SDS_SigLibDataToQFormatInteger, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

void SDA_SigLibDataToFix32 (SLData_t *, Pointer to source array SLInt32_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function converts the input native SigLib fixed point data type to 32 bit (long) fixed point data.

NOTES ON USE

This function uses rounding to nearest integer value to avoid floating point to fixed point conversion issues.

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData, SDA_SigLibDataToImageData, SDA_ImageDataToSigLibData, SDA_SigLibDataToFix16, SDA_Fix16ToSigLibData, SDA_Fix32ToSigLibData, SDS_QFormatIntegerToSigLibData, SDS_SigLibDataToQFormatInteger, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

void SDA_Fix32ToSigLibData (SLInt32_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function converts the input 32 bit (long) fixed point data type to the native SigLib data type.

NOTES ON USE

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData, SDA_SigLibDataToImageData, SDA_ImageDataToSigLibData, SDA_SigLibDataToFix16, SDA_Fix16ToSigLibData, SDA_SigLibDataToFix32, SDS_QFormatIntegerToSigLibData, SDS_SigLibDataToQFormatInteger, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

SLFixData_t SDS_SigLibDataToQFormatInteger (const SLData_t x, Source value const SLFixData_t, m const SLFixData_t) n

DESCRIPTION

This function converts the SigLib native data to Q format fixed point data type m.n.

NOTES ON USE

For run time optimization reasons this function does not check the fixed point word length so it is important to ensure that the sum of m+n is <= to the fixed point word length.

The macro siglib fix word length provides the fixed point word length.

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData, SDA_SigLibDataToImageData, SDA_ImageDataToSigLibData, SDA_SigLibDataToFix16, SDA_Fix16ToSigLibData, SDA_SigLibDataToFix32, SDA_Fix32ToSigLibData, SDS_QFormatIntegerToSigLibData, SDA_QFormatIntegerToSigLibData, SDA_SigLibDataToQFormatInteger.

SLData_t SDS_QFormatIntegerToSigLibData (const SLFixData_t, Q format integer data

const SLFixData t) n

DESCRIPTION

This function converts the Q format fixed point data type m.n to SigLib native data.

NOTES ON USE

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData,

SDA SigLibDataToImageData, SDA ImageDataToSigLibData,

SDA SigLibDataToFix16, SDA Fix16ToSigLibData, SDA SigLibDataToFix32,

SDA Fix32ToSigLibData, SDS SigLibDataToQFormatInteger,

SDA QFormatIntegerToSigLibData, SDA SigLibDataToQFormatInteger.

void SDA_SigLibDataToQFormatInteger (const SLData_t *, Pointer to source array

SLFixData t*, Pointer to destination array

const SLFixData_t, m const SLFixData_t, n

const SLArrayIndex t) Array length

DESCRIPTION

This function converts the SigLib native data to Q format fixed point data type m.n.

NOTES ON USE

For run time optimization reasons this function does not check the fixed point word length so it is important to ensure that the sum of m+n is <= to the fixed point word length.

The macro siglib fix word length provides the fixed point word length.

CROSS REFERENCE

SDA SigLibDataToFix, SDA FixToSigLibData,

SDA SigLibDataToImageData, SDA ImageDataToSigLibData,

SDA SigLibDataToFix16, SDA Fix16ToSigLibData, SDA SigLibDataToFix32,

SDA Fix32ToSigLibData, SDS QFormatIntegerToSigLibData,

SDS SigLibDataToQFormatInteger, SDA QFormatIntegerToSigLibData.

void SDA_QFormatIntegerToSigLibData (const SLFixData_t *, Pointer to source array

SLData t*, Pointer to destination array

const SLFixData t, m

const SLArrayIndex t) Array length

DESCRIPTION

This function converts the Q format fixed point data type m.n to SigLib native data.

NOTES ON USE

CROSS REFERENCE

SDA_SigLibDataToFix, SDA_FixToSigLibData, SDA_SigLibDataToImageData, SDA_ImageDataToSigLibData,

SDA SigLibDataToFix16, SDA Fix16ToSigLibData, SDA SigLibDataToFix32,

SDA Fix32ToSigLibData, SDS QFormatIntegerToSigLibData,

 $SDS_SigLibDataToQFormatInteger, SDA_SigLibDataToQFormatInteger.$

```
void SDS_Pid (const SLData_t, Proportional constant const SLData_t, Integral constant const SLData_t, Differential constant const SLData_t, Error SLData_t *, Control signal Previous error SLData_t *, Previous error Previous error difference
```

DESCRIPTION

This function calculates the control signal required, as calculated from the proportional, integral and differential coefficients and the system error. The error being the difference between the set point and the current system output (the reset).

The function SDS_Pid accepts a pointer to the control signal as a parameter and does not return the control signal.

NOTES ON USE

Allowance must be made in the coefficients, for the system sample period, this is not done in this implementation of the PID process, for computational efficiency. Some common methods of specifying the PI and D coefficients assume that the integral and differential parts of the function inherently allow for the sample period. To convert incompatible coefficients to the SigLib format, it is only necessary to multiply the integral coefficient by the sample period and to divide the differential coefficient by the sample period.

The control signal, previous error and previous error difference parameters should be initialised to SIGLIB_ZERO in the calling function.

CROSS REFERENCE

```
void SDA_Pwm (const SLData_t *, Source array pointer SLData_t *, Destination array pointer SLData_t *, Ramp array pointer SLData_t *, Ramp phase array pointer const SLData_t, Pulse repetition frequency const SLArrayIndex t)

Array length
```

DESCRIPTION

This function generates a pulse width modulated signal from the modulating input signal. The pulse repetition frequency is set via the appropriate parameter.

NOTES ON USE

CROSS REFERENCE

ORDER ANALYSIS FUNCTIONS (order.c)

These functions provide a suite of functionality for analyzing the orders of signals.

SDA_ExtractOrder

PROTOTYPE AND PARAMETER DESCRIPTION

SLData t SDA ExtractOrder (const SLData t *, Pointer to source array

const SLArrayIndex t, Order to extract

const SLArrayIndex_t, Number of adjacent samples to search

const SLData t, First order frequency

const SLArrayIndex t, FFT length

const SLData t, Sample period (s) = 1/(Sample rate (Hz))

const SLArrayIndex t) Input array length

DESCRIPTION

This function extracts the order results from a re-ordered array The "Order to extract" parameter specifies which order to extract. The function scans the specified number of adjacent samples and returns the peak value. The "First order frequency" parameter specifies which FFT bin contains the desired first order signal.

NOTES ON USE

CROSS REFERENCE

SDA_SumLevel, SDA_SumLevelWholeSpectrum, SIF_OrderAnalysis, SDA_OrderAnalysis.

SLData_t SDA_SumLevel (const SLData_t *, Pointer to source array const enum SLSignalCoherenceType_t, Signal source type const SLArrayIndex_t, Log magnitude flag const SLArrayIndex_t)

Input array length

DESCRIPTION

This function sums the magnitudes of the 5 largest orders. The signal coherence type specifies whether the signal is of type:

```
SIGLIB_SIGNAL_COHERENT,
SIGLIB_SIGNAL_INCOHERENT
```

The "Log magnitude flag" specifies whether the input data is in linear or dB format.

NOTES ON USE

CROSS REFERENCE

SDA_ExtractOrder, SDA_SumLevelWholeSpectrum, SIF_OrderAnalysis, SDA_OrderAnalysis.

SLData_t SDA_SumLevelWholeSpectrum (const SLData_t *, Ptr. to src. array const enum SLSignalCoherenceType_t, Signal coherence type const SLArrayIndex_t, Log magnitude flag const SLData_t, Linear scaling value const SLArrayIndex_t) Input array length

DESCRIPTION

This function sums the magnitudes of the whole spectrum. The signal coherence type specifies whether the signal is of type:

```
SIGLIB_SIGNAL_COHERENT, SIGLIB_SIGNAL_INCOHERENT
```

The "Log magnitude flag" specifies whether the input data is in linear or dB format. The linear scaling value specifies a scaling for the linear output.

NOTES ON USE

CROSS REFERENCE

SDA_ExtractOrder, SDA_SumLevel, SIF_OrderAnalysis, SDA_OrderAnalysis.

void SIF OrderAnalysis (SLData t*, Pointer to sinc LUT array SLData t*, Pointer to phase gain Number of adjacent samples const SLArrayIndex t, const SLArrayIndex t, Look up table length SLData t*, Window coefficients pointer const enum SLWindow t, Window type const SLData t, Window coefficient SLData t*, Window inverse coherent gain SLData t*, Pointer to FFT coefficients SLArrayIndex t*, Pointer to bit reverse address table SLData t*, Pointer to real average array SLData t*, Pointer to imaginary average array const SLArrayIndex t) FFT Size

DESCRIPTION

This function initializes the order analysis function SDA_OrderAnalysis.

Order analysis is implemented by re-sampling the input data using a sin(x)/x resampling algorithm. It then windows the data and performs an FFT. For further information, please refer to the documentation for the following functions:

SDA_ResampleSinc SDA_Window SDA_Rfft

NOTES ON USE

CROSS REFERENCE

SDA_ExtractOrder, SDA_SumLevel, SDA_SumLevelWholeSpectrum, SDA_OrderAnalysis.

```
SLData t SDA OrderAnalysis (const SLData t *, Pointer to source array
       SLData t*,
                                           Pointer to local processing array
       SLData t*,
                                           Pointer to destination array
       const SLData t*,
                                           Pointer to LUT array
                                           Look up table phase gain
       const SLData t,
       const SLData t,
                                           First order frequency
                                           Speed - revolutions per second
       const SLData t,
                                           Number of adjacent samples for
       const SLArrayIndex t,
interpolation
                                           Pointer to window coefficients
       SLData t*,
       const SLData t,
                                           Window inverse coherent gain
       SLData t*,
                                           Pointer to FFT coefficients
       SLArrayIndex t*,
                                           Pointer to bit reverse address table
       SLData t*,
                                           Pointer to real average array
       SLData t*,
                                           Pointer to imaginary average array
                                           Log magnitude flag
       const SLArrayIndex t,
                                           Pointer to order array
       SLData t*,
       const SLArrayIndex t,
                                           Base order
       const SLArrayIndex t,
                                           Number of orders to extract
       const SLArrayIndex t,
                                           Number of adjacent samples
       const SLData t,
                                           Sample period
       const enum SLSignalCoherenceType t,
                                                  Signal coherence type for
summing orders
       const SLData t,
                                           dB scaling value
       const SLArrayIndex t,
                                           Number of orders to sum
       const SLArrayIndex t,
                                           Source array length
       const SLArrayIndex t,
                                           FFT length
       const SLArrayIndex t)
                                           log2 FFT length
```

DESCRIPTION

This function performs order analysis on the input data. The signal coherence type specifies whether the signal is of type:

```
SIGLIB_SIGNAL_COHERENT SIGLIB_SIGNAL_INCOHERENT
```

The "Log magnitude flag" specifies whether the input data is in linear or dB format. The dB scaling value specifies a scaling for the dB output.

The "First order frequency" parameter specifies the frequency of the first order. The "Base order" parameter specifies the first order to extract and the "Number of orders to extract" specifies how many orders. For example, if the "Base order" is 10 and the "Number of orders to extract" is 5 then the orders extracted are 10, 20, 30, 40 and 50.

NOTES ON USE

The function SIF_OrderAnalysis must be called prior to calling this function.

CROSS REFERENCE

 $SDA_ExtractOrder, SDA_SumLevel, SDA_SumLevelWholeSpectrum, SIF_OrderAnalysis.$

STATISTICS FUNCTIONS (stats.c)

 SDA_Sum

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Sum (const SLData_t *, Source array pointer const SLArrayIndex t) Array length

DESCRIPTION

This function sums all the points in the array.

NOTES ON USE

CROSS REFERENCE

SDA_SumOfSquares, SDA_AbsSum, SDA_Mean, SDA_SampleSd, SDA_PopulationSd, SDA_UnbiasedVariance, SDA_Median.

SLData_t SDA_AbsSum (const SLData_t *, Source array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function sums all the absolute values of all the points in the array.

NOTES ON USE

CROSS REFERENCE

 $SDA_Sum, SDA_SumOfSquares, SDA_Mean, SDA_SampleSd, SDA_PopulationSd, SDA_UnbiasedVariance, SDA_Median.$

SLData_t SDA_SumOfSquares (const SLData_t *, Source array Pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function sums the squares of all the points in the array. This function is often used to calculate the energy of a signal.

NOTES ON USE

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_Mean, SDA_SampleSd, SDA_PopulationSd, SDA_UnbiasedVariance, SDA_Median.

SDA_Mean

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function calculates the arithmetic mean (also known as the average value) of all the points in the array, using the following equation:

$$\bar{x} = \frac{\sum (x)}{N}$$

NOTES ON USE

The "inverse of array length" parameter is used to avoid having to perform a divide operation within the function. This improves run-time performance.

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_AbsMean, SDA_SubtractMean, SDA_SampleSd, SDA_PopulationSd, SDA_UnbiasedVariance, SDA_Median.

SDA_AbsMean

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_AbsMean (const SLData_t *, Pointer to source array const SLData_t, Inverse of array length const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the arithmetic mean (also known as the average value) of the absolute values of all the points in the array, using the following equation:

$$\overline{x} = \frac{\sum (|x|)}{N}$$

NOTES ON USE

The "inverse of array length" parameter is used to avoid having to perform a divide operation within the function. This improves run-time performance.

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_Mean, SDA_SubtractMean, SDA_SampleSd, SDA_PopulationSd, SDA_UnbiasedVariance, SDA_Median.

SLData_t SDA_SubtractMean (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLData_t, Inverse of array length

const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the arithmetic mean (also known as the average value) of all the points in the array, using the following equation:

$$\bar{x} = \frac{\sum (x)}{n}$$

Then subtract this value from all of the points in the array.

NOTES ON USE

The "inverse of array length" parameter is used to avoid having to perform a divide operation within the function. This improves run-time performance.

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_Mean, SDA_SampleSd, SDA PopulationSd, SDA UnbiasedVariance, SDA Median, SDA SubtractMax.

SLData_t SDA_SubtractMax (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the arithmetic maximum value of all the points in the source array then subtract this value from all of the points in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_Mean, SDA_SampleSd, SDA PopulationSd, SDA UnbiasedVariance, SDA Median, SDA SubtractMean.

DESCRIPTION

This function calculates the sample standard deviation of all the points in the array, using the following equation:

$$SD(n-1) = \sqrt{\frac{\sum x^2 - \frac{\left(\sum x\right)^2}{n}}{n-1}}$$

NOTES ON USE

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_Mean, SDA_PopulationSd, SDA UnbiasedVariance, SDA Median.

DESCRIPTION

This function calculates the population standard deviation of all the points in the array, using the following equation:

$$SD(n) = \sqrt{\frac{\sum x^2 - \frac{\left(\sum x\right)^2}{n}}{n}}$$

NOTES ON USE

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_Mean, SDA_SampleSd, SDA_UnbiasedVariance, SDA_Median.

SLData_t SDA_UnbiasedVariance (const SLData_t *, Source array Pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the unbiased variance of all the points in the array, by squaring the sample standard deviation.

NOTES ON USE

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_Mean, SDA_SampleSd, SDA_PopulationSd, SDA_Median.

SDA_Median

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Median (const SLData_t *, Source array pointer SLData_t *, Working array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the median value of all the points in the array.

NOTES ON USE

The working array must be the same length as the input array.

CROSS REFERENCE

SDA_Sum, SDA_AbsSum, SDA_Mean, SDA_SampleSd, SDA PopulationSd.

REGRESSION ANALYSIS FUNCTIONS (regress.c)

SDA_LinraConstantCoeff

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_LinraConstantCoeff (const SLData_t *, X array pointer const SLData_t *, Y array pointer const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the constant coefficient for a linear regression series.

Assuming the data can be modelled according to:

$$y = Mx + C$$

Gives:

$$C = \frac{sum(y) - M*sum(x)}{n}$$

NOTES ON USE

CROSS REFERENCE

SDA_LinraRegressionCoeff, SDA_LinraCorrelationCoeff, SDA_LinraEstimateX, SDA_LinraEstimateY.

DESCRIPTION

This function calculates the regression coefficient for a linear regression series.

Assuming the data can be modelled according to:

$$y = Mx + C$$

Gives:

$$M = \frac{n*sum(x.y) - sum(x)*sum(y)}{n*sum(x^2) - (sum(x))^2}$$

NOTES ON USE

CROSS REFERENCE

SDA_LinraConstantCoeff, SDA_LinraCorrelationCoeff, SDA_LinraEstimateX, SDA_LinraEstimateY.

DESCRIPTION

This function calculates the correlation coefficient for a linear regression series.

Assuming the data can be modelled according to:

$$y = Mx + C$$

Gives:

$$r = \frac{n * sum(x.y) - sum(x) * sum(y)}{\sqrt{n * sum(\chi^2) - \left(sum(\chi)\right)^2 * n * sum(y^2) - \left(sum(y)\right)^2}}$$

NOTES ON USE

CROSS REFERENCE

SDA_LinraConstantCoeff, SDA_LinraRegressionCoeff, SDA_LinraEstimateX, SDA_LinraEstimateY.

SLData_t SDA_LinraEstimateX (const SLData_t *, X array pointer const SLData_t *, Y array pointer const SLData_t, Y value

const SLData_t, Y value const SLArrayIndex_t) Array length

DESCRIPTION

This function estimates the X value for a given Y for a linear regression series.

Assuming the data can be modelled according to:

$$y = Mx + C$$

Gives:

$$x = \frac{y - C}{M}$$

NOTES ON USE

CROSS REFERENCE

SDA_LinraConstantCoeff, SDA_LinraRegressionCoeff, SDA_LinraCorrelationCoeff, SDA_LinraEstimateY.

SLData_t SDA_LinraEstimateY (const SLData_t *, X array pointer const SLData_t *, Y array pointer const SLData_t, X value

const SLData_t, X value const SLArrayIndex_t) Array length

DESCRIPTION

This function estimates the Y value for a given X for a linear regression series.

Assuming the data can be modelled according to:

$$v = Mx + C$$

NOTES ON USE

CROSS REFERENCE

SDA_LinraConstantCoeff, SDA_LinraRegressionCoeff, SDA_LinraCorrelationCoeff, SDA_LinraEstimateX.

DESCRIPTION

This function calculates the constant coefficient for a logarithmic regression series.

Assuming the data can be modelled according to:

$$y = M.\ln(x) + C$$

Gives:

$$C = \frac{sum(y) - M*sum(\ln(x))}{n}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_LograRegressionCoeff, SDA_LograCorrelationCoeff, SDA_LograEstimate X, SDA_LograEstimate Y. \\$

DESCRIPTION

This function calculates the regression coefficient for a logarithmic regression series.

Assuming the data can be modelled according to:

$$y = M.\ln(x) + C$$

Gives:

$$M = \frac{n * sum(\ln(x).y) - sum(\ln(x)) * sum(y)}{n * sum(\ln(x)^2) - (sum(\ln(x)))^2}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_LograConstantCoeff, SDA_LograCorrelationCoeff, SDA_LograEstimateX, SDA_LograEstimateY.$

DESCRIPTION

This function calculates the correlation coefficient for a logarithmic regression series.

Assuming the data can be modelled according to:

$$y = M.\ln(x) + C$$

Gives:

$$r = \frac{n*sum(\ln(x).y) - sum(\ln(x))*sum(y)}{\sqrt{n*sum(\ln(x)^2) - (sum(\ln(x)))^2*n*sum(y^2) - (sum(y))^2}}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_LograConstantCoeff, SDA_LograRegressionCoeff, SDA_LograEstimateX, SDA_LograEstimateY.$

SLData_t SDA_LograEstimateX (const SLData_t *, X array pointer const SLData_t *, Y array pointer const SLData_t, Y value

const SLData_t, Y value const SLArrayIndex_t) Array length

DESCRIPTION

This function estimates the X value for a given Y for a logarithmic regression series.

Assuming the data can be modelled according to:

$$y = M.\ln(x) + C$$

Gives:

$$x = e^{\left(\frac{y-C}{M}\right)}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_LograConstantCoeff, SDA_LograRegressionCoeff, SDA_LograCorrelationCoeff, SDA_LograEstimateY.$

SLData_t SDA_LograEstimateY (const SLData_t *, X array pointer

const SLData_t *, Y array pointer

const SLData_t, X value const SLArrayIndex_t) Array length

DESCRIPTION

This function estimates the Y value for a given X for a logarithmic regression series.

Assuming the data can be modelled according to:

$$v = M.\ln(x) + C$$

NOTES ON USE

CROSS REFERENCE

SDA_LograConstantCoeff, SDA_LograRegressionCoeff, SDA_LograCorrelationCoeff, SDA_LograEstimateX.

DESCRIPTION

This function calculates the constant coefficient for an exponential regression series.

Assuming the data can be modelled according to:

$$y = C * e^{M*x}$$

Gives:

$$C = \frac{sum(\ln(y)) - M * sum(x)}{n}$$

NOTES ON USE

CROSS REFERENCE

SDA_ExpraRegressionCoeff, SDA_ExpraCorrelationCoeff, SDA_ExpraEstimateX, SDA_ExpraEstimateY.

DESCRIPTION

This function calculates the regression coefficient for an exponential regression series.

Assuming the data can be modelled according to:

$$y = C * e^{M^*x}$$

Gives:

$$M = \frac{n*sum(x.\ln(y)) - sum(x)*sum(\ln(y))}{n*sum(x) - (sum(x))^2}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_ExpraConstantCoeff, SDA_ExpraCorrelationCoeff, SDA_ExpraEstimate Y. \\$

DESCRIPTION

This function calculates the correlation coefficient for an exponential regression series.

Assuming the data can be modelled according to:

$$y = C * e^{M*x}$$

Gives:

$$r = \frac{n * sum(x.\ln(y)) - sum(x) * sum(\ln(y))}{\sqrt{n * sum(\chi^2) - \left(sum(x)\right)^2 * n * sum\left(\ln(y)^2\right) - \left(sum(\ln(y))\right)^2}}$$

NOTES ON USE

CROSS REFERENCE

SDA_ExpraConstantCoeff, SDA_ExpraRegressionCoeff, SDA ExpraEstimateX, SDA ExpraEstimateY.

SLData_t SDA_ExpraEstimateX (const SLData_t *, X array pointer const SLData_t *, Y array pointer

const SLData_t, Y value
const SLArrayIndex_t) Array length

DESCRIPTION

This function estimates the X value for a given Y for an exponential regression series.

Assuming the data can be modelled according to:

$$y = C * e^{M^*x}$$

Gives:

$$x = \frac{\ln(x) - C}{M}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_ExpraConstantCoeff, SDA_ExpraRegressionCoeff, SDA_ExpraCorrelationCoeff, SDA_ExpraEstimateY.$

SLData_t SDA_ExpraEstimateY (const SLData_t *, X array pointer

const SLData t*, Y array pointer

const SLData_t, X value const SLArrayIndex_t) Array length

DESCRIPTION

This function estimates the Y value for a given X for an exponential regression series.

Assuming the data can be modelled according to:

$$y = C * e^{M^*x}$$

NOTES ON USE

CROSS REFERENCE

SDA_ExpraConstantCoeff, SDA_ExpraRegressionCoeff, SDA_ExpraCorrelationCoeff, SDA_ExpraEstimateX.

DESCRIPTION

This function calculates the constant coefficient for a power regression series.

Assuming the data can be modelled according to:

$$y = Cx^{M}$$

Gives:

$$C = \frac{sum(\ln(y)) - M * sum(\ln(x))}{n}$$

NOTES ON USE

CROSS REFERENCE

SDA_PowraRegressionCoeff, SDA_PowraCorrelationCoeff, SDA_PowraEstimateX, SDA_PowraEstimateY.

DESCRIPTION

This function calculates the regression coefficient for a power regression series.

Assuming the data can be modelled according to:

$$y = Cx^{M}$$

Gives:

$$M = \frac{n * sum(\ln(x). \ln(y)) - sum(\ln(x)) * sum(\ln(y))}{n * sum(\ln(x)) - \left(sum(\ln(x))\right)^2}$$

NOTES ON USE

CROSS REFERENCE

 $SDA_PowraConstantCoeff, SDA_PowraCorrelationCoeff, SDA_PowraEstimateX, SDA_PowraEstimateY.$

DESCRIPTION

This function calculates the correlation coefficient for a power regression series.

Assuming the data can be modelled according to:

$$y = Cx^{M}$$

Gives:

$$r = \frac{n*sum(\ln(x).\ln(y)) - sum(\ln(x))*sum(\ln(y))}{\sqrt{n*sum(\ln(x))^2} - \left(sum(\ln(x))\right)^2*n*sum(\ln(y)^2) - \left(sum(\ln(y))\right)^2}$$

NOTES ON USE

CROSS REFERENCE

SDA_PowraConstantCoeff, SDA_PowraRegressionCoeff, SDA_PowraEstimateX, SDA_PowraEstimateY.

SLData_t SDA_PowraEstimateX (const SLData_t *, X array pointer

const SLData_t *, Y array pointer

const SLData_t, Y value const SLArrayIndex_t) Array length

DESCRIPTION

This function estimates the X value for a given Y for a power regression series.

Assuming the data can be modelled according to:

$$y = Cx^{M}$$

Gives:

$$x = \left(\frac{\ln(y) - C}{M}\right)$$

NOTES ON USE

CROSS REFERENCE

SDA_PowraConstantCoeff, SDA_PowraRegressionCoeff, SDA_PowraCorrelationCoeff, SDA_PowraEstimateY.

SLData_t SDA_PowraEstimateY (const SLData_t *, X array pointer

const SLData t*, Y array pointer

const SLData_t, X value const SLArrayIndex_t) Array length

DESCRIPTION

This function estimates the Y value for a given X for a power regression series.

Assuming the data can be modelled according to:

$$y = Cx^{M}$$

NOTES ON USE

CROSS REFERENCE

SDA_PowraConstantCoeff, SDA_PowraRegressionCoeff, SDA_PowraCorrelationCoeff, SDA_PowraEstimateX.

SDA_Detrend

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Detrend (const SLData_t *, Source array pointer
SLData_t *, Destination array pointer
SLData_t *, Ramp array pointer
const SLArrayIndex_t) Source / destination array lengths

DESCRIPTION

This function uses the equation y = M.x + C to generate the best straight-line fit to the data in the source array, this is then removed from the data before writing the results to the destination array.

NOTES ON USE

The Ramp array is used internally and is the same length as the source / destination arrays.

CROSS REFERENCE

SDA ExtractTrend.

void SDA_ExtractTrend (const SLData_t *, Source array pointer SLData_t *, Destination array pointer SLData_t *, Ramp array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function uses the equation y = M.x + C to generate the best straight-line fit to the data in the source array, this is then written to the destination array.

NOTES ON USE

The first iteration of this function and any where the vector length increases will take longer than subsequent iterations because a reference vector needs to be allocated memory and initialised. If execution time is important then this function can be called during the application initialisation process to initialise the largest array possible.

CROSS REFERENCE

SDA Detrend.

TRIGONOMETRIC FUNCTIONS (trig.c)

SDA_Sin

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Sin (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the sine of all the values in the array.

NOTES ON USE

CROSS REFERENCE

SDA_Cos, SDA_Tan, SIF_FastSin, SIF_FastCos, SIF_FastSinCos, SIF_FastTan.

SLData_t SDA_Cos (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the cosine of all the values in the array.

NOTES ON USE

CROSS REFERENCE

 $SDA_Sin, SDA_Tan, SIF_FastSin, SIF_FastCos, SIF_FastSinCos, SIF_FastTan.$

SDA_Tan

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDA_Tan (const SLData_t *, Source array pointer SLData_t *, Destination array pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns the tangent of all the values in the array.

NOTES ON USE

CROSS REFERENCE

 $SDA_Sin, SDA_Cos, SIF_FastSin, SIF_FastCos, SIF_FastSinCos, SIF_FastTan.$

SIF_FastSin

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SIF_FastSin (SLData_t *, Fast sine look up table array pointer const SLArrayIndex_t)

Fast sine look up table array pointer Table length

DESCRIPTION

This function initializes the fast sine look up table.

NOTES ON USE

The array contains one complete cycle of a sine wave (0 to 2π), with N samples.

CROSS REFERENCE

SDA_FastSin, SDS_FastSin, SIF_FastCos, SDA_FastCos, SDS_FastCos, SIF_FastSinCos, SDA_FastSinCos, SDS_FastSinCos, SIF_FastTan.

void SDA_FastSin (const SLData_t *, Sine table pointer
SLData_t *, Sine wave destination pointer
SLData_t *, Sine table phase
const SLData_t, Sine wave frequency
const SLArrayIndex_t, Sine wave look up table length
const SLArrayIndex_t) Sample array size

DESCRIPTION

This function uses the fast sine look up table to generate a sine wave. This function is used to generate continuous sinusoidal waveforms, for example in modulation and demodulation functions. If you wish to use a look up table to calculate a quick approximation to sine (θ) then you should use the SDA QuickSin function.

NOTES ON USE

The function SIF FastSin must be called prior to calling this function.

This function operates on an array oriented basis.

CROSS REFERENCE

SIF_FastSin, SDS_FastSin, SIF_FastCos, SDA_FastCos, SDS_FastCos, SIF_FastSinCos, SDA_FastSinCos, SDS_FastSinCos, SIF_FastTan.

SDS_FastSin

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_FastSin (const SLData_t *, Sine table pointer
SLData_t *, Sine table phase
const SLData_t, Sine wave frequency
const SLArrayIndex t) Sine wave look up table length

DESCRIPTION

This function uses the fast sine look up table to generate a sine wave. This function is used to generate continuous sinusoidal waveforms, for example in modulation and demodulation functions. If you wish to use a look up table to calculate a quick approximation to sine (θ) then you should use the SDS_QuickSin function.

NOTES ON USE

The function SIF FastSin must be called prior to calling this function.

This function operates on a per-sample oriented basis.

CROSS REFERENCE

SIF_FastSin, SDA_FastSin, SIF_FastCos, SDA_FastCos, SDS_FastCos, SIF_FastSinCos, SDA_FastSinCos, SDS_FastSinCos, SIF_FastTan.

SIF_FastCos

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SIF_FastCos (SLData_t *, Fast cosine look up table array pointer const SLArrayIndex_t)

Fast cosine look up table array pointer Table length

DESCRIPTION

This function initializes the fast cosine look up table.

NOTES ON USE

The array contains one complete cycle of a cosine wave (0 to 2π), with N samples.

CROSS REFERENCE

SIF_FastSin, SDA_FastSin, SDS_FastSin, SDA_FastCos, SDS_FastCos, SIF_FastSinCos, SDA_FastSinCos, SDS_FastSinCos, SIF_FastTan.

```
void SDA_FastCos (const SLData_t *, Cosine table pointer
SLData_t *, Cosine wave destination pointer
SLData_t *, Cosine table phase
const SLData_t, Cosine wave frequency
const SLArrayIndex_t, Cosine wave look up table length
const SLArrayIndex_t) Sample array size
```

DESCRIPTION

This function uses the fast cosine look up table to generate a cosine wave. This function is used to generate continuous co-sinusoidal waveforms, for example in modulation and demodulation functions. If you wish to use a look up table to calculate a quick approximation to cosine (θ) then you should use the SDA_QuickCos function.

NOTES ON USE

The function SIF FastCos must be called prior to calling this function.

This function operates on an array oriented basis.

CROSS REFERENCE

```
SIF_FastSin, SDA_FastSin, SDS_FastSin, SIF_FastCos, SDS_FastCos, SIF_FastSinCos, SDA_FastSinCos, SDS_FastSinCos, SIF_FastTan.
```

SLData_t SDS_FastCos (const SLData_t *, Cosine table pointer
SLData_t *, Cosine table phase
const SLData_t, Cosine wave frequency

const SLArrayIndex t) Cosine wave look up table length

DESCRIPTION

This function uses the fast cosine look up table to generate a cosine wave. This function is used to generate continuous co-sinusoidal waveforms, for example in modulation and demodulation functions. If you wish to use a look up table to calculate a quick approximation to cosine (θ) then you should use the SDS QuickCos function.

NOTES ON USE

The function SIF FastCos must be called prior to calling this function.

This function operates on a per-sample oriented basis.

CROSS REFERENCE

SIF_FastSin, SDA_FastSin, SDS_FastSin, SIF_FastCos, SDA_FastCos, SIF_FastSinCos, SDA_FastSinCos, SDS_FastSinCos, SIF_FastTan.

SLData_t SIF_FastSinCos (SLData_t *, Fast sine look up table array pointer const SLArrayIndex_t) Fast sine look up table array pointer Sinusoid period

DESCRIPTION

This function initializes the fast overlapped sine and cosine look up table.

NOTES ON USE

The array contains one and a quarter complete cycle of a sine wave (0 to $(5*\pi)/2$), with 5*N/4 samples. You are advised to use the macro: SUF_FastSinCosArrayAllocate () to allocate the look up table to use with this function.

CROSS REFERENCE

SIF_FastSin, SDA_FastSin, SDS_FastSin, SIF_FastCos, SDA_FastCos, SDS FastCos, SDA FastSinCos, SDS FastSinCos, SIF FastTan.

```
void SDA_FastSinCos (const SLData_t *, Sine table pointer
SLData_t *, Sine wave destination pointer
SLData_t *, Cosine wave destination pointer
SLData_t *, Sine table phase
const SLData_t, Sine wave frequency
const SLArrayIndex_t, Sine wave period
const SLArrayIndex_t) Sample array size
```

DESCRIPTION

This function uses the fast sine/cosine look up table to generate a sine and a cosine wave. This function is used to generate continuous sinusoidal and co-sinusoidal waveforms, for example in modulation and demodulation functions. If you wish to use a look up table to calculate a quick approximation to sine (θ) and cosine (θ) then you should use the SDA QuickSinCos function.

NOTES ON USE

The function SIF_FastSinCos must be called prior to calling this function.

This function operates on an array oriented basis.

CROSS REFERENCE

```
SIF_FastSin, SDA_FastSin, SDS_FastSin, SIF_FastCos, SDA_FastCos, SDS FastCos, SIF FastSinCos, SDS FastSinCos, SIF FastTan.
```

```
void SDS_FastSinCos (const SLData_t *, Sine table pointer
SLData_t *, Sine wave destination pointer
SLData_t *, Cosine wave destination pointer
SLData_t *, Sine table phase
const SLData_t, Sine wave frequency
const SLArrayIndex_t) Sine wave period
```

DESCRIPTION

This function uses the fast sine/cosine look up table to generate a sine and a cosine wave. This function is used to generate continuous sinusoidal and co-sinusoidal waveforms, for example in modulation and demodulation functions. If you wish to use a look up table to calculate a quick approximation to sine (θ) and cosine (θ) then you should use the SDS_QuickSinCos function.

NOTES ON USE

The function SIF FastSinCos must be called prior to calling this function.

This function operates on a per-sample oriented basis.

CROSS REFERENCE

```
SIF_FastSin, SDA_FastSin, SDS_FastSin, SIF_FastCos, SDA_FastCos, SDS_FastCos, SIF_FastSinCos, SDA_FastSinCos, SIF_FastTan.
```

SIF_QuickSin

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SIF_QuickSin (SLData_t *, Quick sine look up table array pointer SLData_t *, Pointer to phase gain Table length

DESCRIPTION

This function initializes the quick sine look up table.

NOTES ON USE

The array contains one complete cycle of a sine wave (0 to 2π), with N samples.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SDS_QuickSin, SIF_QuickCos, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan, SDA_QuickTan, SDS_QuickTan.

```
      void SDA_QuickSin (const SLData_t *,
      Pointer to source array (θ)

      const SLData_t *,
      Sine table pointer

      SLData_t *,
      Destination pointer

      SLData_t *,
      Pointer to phase gain

      const SLArrayIndex_t)
      Sample array size
```

DESCRIPTION

This function uses the quick sine look up table to calculate sine (θ) for all of the values passed in the source array where θ is in radians and can be any positive or negative real number. If you wish to use a look up table to calculate a continuous sinusoidal function, for example for a modulator or a demodulator, then you should use the SDA_FastSin function.

NOTES ON USE

The function SIF_QuickSin must be called prior to calling this function. The phase gain parameter is used to locate the correct phase in the look up table, the value is set in the initialization function and should not be modified. This function operates on an array oriented basis.

CROSS REFERENCE

SIF_QuickSin, SDS_QuickSin, SIF_QuickCos, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan.

DESCRIPTION

This function uses the quick sine look up table to calculate sine (θ) for the input value where θ is in radians and can be any positive or negative real number. If you wish to use a look up table to calculate a continuous sinusoidal function, for example for a modulator or a demodulator, then you should use the SDS FastSin function.

NOTES ON USE

The function SIF_QuickSin must be called prior to calling this function. The phase gain parameter is used to locate the correct phase in the look up table, the value is set in the initialization function and should not be modified. This function operates on a per-sample oriented basis.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SIF_QuickCos, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan.

SLData_t SIF_QuickCos (SLData_t *, Quick cosine look up table array pointer SLData_t *, Pointer to phase gain Table length

DESCRIPTION

This function initializes the quick cosine look up table.

NOTES ON USE

The array contains one complete cycle of a cosine wave (0 to 2π), with N samples.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SDS_QuickSin, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan.

```
      void SDA_QuickCos (const SLData_t *,
      Pointer to source array (θ)

      const SLData_t *,
      Cosine table pointer

      SLData_t *,
      Destination pointer

      SLData_t *,
      Pointer to phase gain

      const SLArrayIndex_t)
      Sample array size
```

DESCRIPTION

This function uses the quick cosine look up table to calculate cosine (θ) for all of the values passed in the source array where θ is in radians and can be any positive or negative real number. If you wish to use a look up table to calculate a continuous cosinusoidal function, for example for a modulator or a demodulator, then you should use the SDA_FastCos function.

NOTES ON USE

The function SIF_QuickCos must be called prior to calling this function. The phase gain parameter is used to locate the correct phase in the look up table, the value is set in the initialization function and should not be modified. This function operates on an array oriented basis.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SDS_QuickSin, SIF_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan.

DESCRIPTION

This function uses the quick cosine look up table to calculate cosine (θ) for the input value where θ is in radians and can be any positive or negative real number. If you wish to use a look up table to calculate a continuous co-sinusoidal function, for example for a modulator or a demodulator, then you should use the SDS_FastCos function.

NOTES ON USE

The function SIF_QuickCos must be called prior to calling this function. The phase gain parameter is used to locate the correct phase in the look up table, the value is set in the initialization function and should not be modified. This function operates on a per-sample oriented basis.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SDS_QuickSin, SIF_QuickCos, SDA_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan.

SLData_t SIF_QuickSinCos (SLData_t *, Quick sine look up table array pointer SLData_t *, Pointer to phase gain Sinusoid period

DESCRIPTION

This function initializes the quick overlapped sine and cosine look up table.

NOTES ON USE

The array contains one and a quarter complete cycle of a sine wave (0 to $(5*\pi)/2$), with 5*N/4 samples. You are advised to use the macro: SUF_QuickSinCosArrayAllocate () to allocate the look up table to use with this function.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SDS_QuickSin, SIF_QuickCos, SDA_QuickCos, SDA_QuickSinCos, SDA_QuickSinCos, SIF_QuickTan.

void SDA_QuickSinCos (const SLData_t *, Pointer to source array (θ)

const SLData_t *, Sine table pointer

SLData_t *, Sine destination array pointer SLData_t *, Cosine destination array pointer

SLData t*, Pointer to phase gain

const SLArrayIndex_t, Sine wave look up table period

const SLArrayIndex t) Sample array size

DESCRIPTION

This function uses the quick sine/cosine look up table to calculate sine (θ) and cosine (θ) for the input value where θ is in radians and can be any positive or negative real number. If you wish to use a look up table to calculate a continuous sinusoidal and cosinusoidal function, for example for a modulator or a demodulator, then you should use the SDA FastSinCos function.

NOTES ON USE

The function SIF_QuickSinCos must be called prior to calling this function. The phase gain parameter is used to locate the correct phase in the look up table, the value is set in the initialization function and should not be modified. This function operates on an array oriented basis.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SDS_QuickSin, SIF_QuickCos, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan.

```
    void SDS_QuickSinCos (const SLData_t, const SLData_t *, Sine table pointer
    SLData_t *, Sine destination sample pointer
    SLData_t *, Cosine destination sample pointer
    SLData_t *, Pointer to phase gain
    const SLArrayIndex_t) Sine wave look up table period
```

DESCRIPTION

This function uses the quick sine/cosine look up table to calculate sine (θ) and cosine (θ) for the input value where θ is in radians and can be any positive or negative real number. If you wish to use a look up table to calculate a continuous sinusoidal and cosinusoidal function, for example for a modulator or a demodulator, then you should use the SDS_FastSinCos function.

NOTES ON USE

The function SIF_QuickSinCos must be called prior to calling this function. The phase gain parameter is used to locate the correct phase in the look up table, the value is set in the initialization function and should not be modified. This function operates on a per-sample oriented basis.

CROSS REFERENCE

```
SIF_QuickSin, SDA_QuickSin, SDS_QuickSin, SIF_QuickCos, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SIF_QuickTan.
```

SLData_t SIF_QuickTan (SLData_t *, Quick tangent look up table array pointer SLData_t *, Pointer to phase gain Table length

DESCRIPTION

This function initializes the quick tangent look up table.

NOTES ON USE

The array contains one complete cycle of a tangent wave (0 to 2π), with N samples.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SDS_QuickSin, SIF_QuickCos, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos.

```
      void SDA_QuickTan (const SLData_t *,
      Pointer to source array (θ)

      const SLData_t *,
      Tangent table pointer

      SLData_t *,
      Destination pointer

      SLData_t *,
      Pointer to phase gain

      const SLArrayIndex_t)
      Sample array size
```

DESCRIPTION

This function uses the quick tangent look up table to calculate tangent (θ) for all of the values passed in the source array where θ is in radians and can be any positive or negative real number.

NOTES ON USE

The function SIF_QuickTan must be called prior to calling this function. The phase gain parameter is used to locate the correct phase in the look up table, the value is set in the initialization function and should not be modified. This function operates on an array oriented basis.

CROSS REFERENCE

```
SIF_QuickSin, SDS_QuickSin, SIF_QuickCos, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan.
```

SDS_QuickTan

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function uses the quick tangent look up table to calculate tangent (θ) for the input value where θ is in radians and can be any positive or negative real number.

NOTES ON USE

The function SIF_QuickTan must be called prior to calling this function. The phase gain parameter is used to locate the correct phase in the look up table, the value is set in the initialization function and should not be modified. This function operates on a per-sample oriented basis.

CROSS REFERENCE

SIF_QuickSin, SDA_QuickSin, SIF_QuickCos, SDA_QuickCos, SDS_QuickCos, SIF_QuickSinCos, SDA_QuickSinCos, SDS_QuickSinCos, SIF_QuickTan.

SDA_Sinc

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_Sinc (const SLData_t *, Pointer to source array SLData_t *, Destination pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function returns sin(x)/x for all the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDS_Sinc, SIF_QuickSinc, SDA_QuickSinc and SDS_QuickSinc.

SLData_t SDS_Sinc (const SLData_t) x

DESCRIPTION

This function returns sin(x)/x of the input value.

NOTES ON USE

CROSS REFERENCE

SDA_Sinc, SIF_QuickSinc, SDA_QuickSinc and SDS_QuickSinc.

void SIF_QuickSinc (SLData_t *, Pointer to sinc look up table SLData_t *, Pointer to phase gain const SLData_t, Maximum input 'x' value const SLArrayIndex_t) Look up table length

DESCRIPTION

This function initializes the quick sinc calculation functions (SDA_QuickSinc and SDS_QuickSinc, which returns sin(x)/x of the input value using a look up table approach.

NOTES ON USE

The accuracy of this function is directly related to the array length.

The phase gain parameter is calculated in this function and used in both SDA QuickSinc and SDS QuickSinc. It is not necessary to modify this value.

The maximum input 'x' value is specified as a parameter to this function and it is important to ensure that no 'x' values greater than this are used in SDA_QuickSinc and SDS_QuickSinc. The QuickSinc functions calculate the look up table values over an array of index from 0 to ArrayLength-1 so the function will not return the sinc of the maximum value specified. The maximum value must therefore be over-specified; for example, if the application requires that the sinc value must be calculated for all inputs within the range -10.0 to +10.0 then a suitable magnitude for the maximum 'x' input value would be 11.0.

CROSS REFERENCE

SDA Sinc, SDS Sinc, SDA QuickSinc and SDS QuickSinc.

```
void SDA_QuickSinc (const SLData_t *, Pointer to source array const SLData_t *, Pointer to sinc look up table SLData_t *, Pointer to destination array const SLData_t, Phase gain Source array length
```

DESCRIPTION

This function calculates the sinc (sin(x)/x) values for all of the entries in the source array.

NOTES ON USE

The function SIF_QuickSinc must be called prior to using this function. Please read the description of SIF_QuickSinc, particularly the notes on the maximum input 'x' value.

For reasons of run-time performance, this function does not check that the magnitude of the 'x' input values are less than that specified in SIF_QuickSinc.

CROSS REFERENCE

SDA Sinc, SDS Sinc, SIF QuickSinc and SDS QuickSinc.

SDS_QuickSinc

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SDS_QuickSinc (const SLData_t, Source 'x' value const SLData_t *, Pointer to sinc look up table const SLData_t) Phase gain

DESCRIPTION

This function calculates the sinc (sin(x)/x) for the source 'x' value.

NOTES ON USE

The function SIF_QuickSinc must be called prior to using this function. Please read the description of SIF_QuickSinc, particularly the notes on the maximum input 'x' value.

For reasons of run-time performance, this function does not check that the magnitude of the 'x' input values are less than that specified in SIF QuickSinc.

CROSS REFERENCE

SDA_Sinc, SDS_Sinc, SIF_QuickSinc and SDA_QuickSinc.

COMPLEX VECTOR FUNCTIONS (complex.c)

SCV_Polar

PROTOTYPE AND PARAMETER DESCRIPTION

SLComplexPolar_s SCV_Polar (const SLData_t, Magnitude component const SLData_t) Angle component

DESCRIPTION

This function converts separate magnitude and angle data components to a single polar complex value.

NOTES ON USE

CROSS REFERENCE

SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLComplexRect_s SCV_Rectangular (const SLData_t, Real component const SLData_t) Imaginary component

DESCRIPTION

This function converts separate real and imaginary data components to a single rectangular complex value.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLComplexRect_s SCV_PolarToRectangular (const SLComplexPolar_s) Polar source data

DESCRIPTION

This function converts the polar data to rectangular.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLComplexPolar_s SCV_RectangularToPolar (const SLComplexRect_s)

Complex rectangular source data

DESCRIPTION

This function converts the rectangular data to polar.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SCV_Sqrt

PROTOTYPE AND PARAMETER DESCRIPTION

SLComplexRect_s SCV_Sqrt (const SLComplexRect_s) Source data

DESCRIPTION

This function calculates the square root of the vector, using the DeMoivre's algorithm.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLComplexRect_s SCV_Inverse (const SLComplexRect_s) Source data

DESCRIPTION

This function calculates the inverse of the complex rectangular vector using:

$$1/(a+jb) = (a-jb)/(a^2+b^2).$$

NOTES ON USE

If the input value equals 0.0 + j0.0 then this function returns 1.0 + j0.0.

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLComplexRect_s SCV_Conjugate (const SLComplexRect_s) Source data

DESCRIPTION

This function returns the complex conjugate of the vector.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLData_t SCV_Magnitude (const SLComplexRect_s) Source data

DESCRIPTION

This function returns the real absolute magnitude of the complex vector.

$$Magnitude = \sqrt{Real^2 + Imaginary^2}$$

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Multiply, SCV_Phase, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLData_t SCV_MagnitudeSquared (const SLComplexRect_s) Source data

DESCRIPTION

This function returns the real absolute magnitude squared of the complex vector.

Absolute Squared Magnitude =
$$Real^2 + Imaginary^2$$

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Multiply, SCV_Phase, SCV_Magnitude, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SCV_Phase

PROTOTYPE AND PARAMETER DESCRIPTION

SLData_t SCV_Phase (const SLComplexRect_s) Source data

DESCRIPTION

This function returns the phase of the complex vector, using the following equation:

$$Angle = a \tan 2(imag, real) = \tan^{-1} \left(\frac{imag}{real}\right)$$

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLComplexRect_s SCV_Multiply (const SLComplexRect_s, complex multiplicand

const SLComplexRect_s) Complex multiplier

DESCRIPTION

This function returns the multiplication of the complex vectors.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SCV_Divide

PROTOTYPE AND PARAMETER DESCRIPTION

SLComplexRect_s SCV_Divide (const SLComplexRect_s, Complex source const SLComplexRect_s)

Complex divisor

DESCRIPTION

This function divides one complex rectangular number by another using: $1/(a + jb) = (a - jb) / (a^2 + b^2)$.

NOTES ON USE

If the divisor equals 0.0 + j0.0 then this function returns 1.0 + j0.0.

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SCV_Add

PROTOTYPE AND PARAMETER DESCRIPTION

SLComplexRect_s SCV_Add (const SLComplexRect_s, Complex source const SLComplexRect_s) Complex source

DESCRIPTION

This function returns the addition of the complex vectors.

NOTES ON USE

If the divisor equals 0.0 + j0.0 then this function returns 1.0 + j0.0.

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SLComplexRect_s SCV_Subtract (const SLComplexRect_s, Complex Source 1 const SLComplexRect_s) Complex source 2

DESCRIPTION

This function returns the difference between the complex vectors.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Log, SCV_Exp, SCV_Pow.

SLComplexRect_s SCV_Log (const SLComplexRect_s) Complex source

DESCRIPTION

This function returns the logarithm of the complex vector.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Exp, SCV_Pow.

SCV_Exp

PROTOTYPE AND PARAMETER DESCRIPTION

SLComplexRect_s SCV_Exp (const SLComplexRect_s) Complex source

DESCRIPTION

This function returns the exponentiation of the complex vector.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Expj, SCV_Pow.

SCV_Expj

PROTOTYPE AND PARAMETER DESCRIPTION

SLComplexRect_s SCV_Expj (const SLData_t) Theta

DESCRIPTION

This function returns the exponentiation of the real input $e^{j\theta} = \cos(\theta) + j\sin(\theta)$.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp, SCV_Pow.

SCV_Pow

PROTOTYPE AND PARAMETER DESCRIPTION

SLComplexRect_s SCV_Pow (const SLComplexRect_s, Complex source const SLData_t) Real power to raise complex data

DESCRIPTION

This function raises the complex vector to a real power.

NOTES ON USE

CROSS REFERENCE

SCV_Polar, SCV_Rectangular, SCV_PolarToRectangular, SCV_RectangularToPolar, SCV_Sqrt, SCV_Inverse, SCV_Conjugate, SCV_Magnitude, SCV_Multiply, SCV_Divide, SCV_Add, SCV_Subtract, SCV_Log, SCV_Exp.

 $SLComplexRect_s \ SCV_VectorAddScalar \ (const \ SLComplexRect_s, \\ source \\$

const SLData_t)

Scalar source

DESCRIPTION

This function adds the scalar value to the complex value and return the complex result.

NOTES ON USE

CROSS REFERENCE

SCV_VectorSubtractScalar, SCV_VectorMultiplyScalar, SCV_VectorDivideScalar, SCV_ScalarSubtractVector.

 $SLComplexRect_s\ SCV_VectorSubtractScalar\ (const\ SLComplexRect_s,\ Complex\ source$

const SLData_t)

Scalar source

DESCRIPTION

This function subtracts the scalar value from the complex value and return the complex result.

NOTES ON USE

CROSS REFERENCE

SCV_VectorAddScalar, SCV_VectorMultiplyScalar, SCV VectorDivideScalar, SCV ScalarSubtractVector.

SLComplexRect_s SCV_VectorMultiplyScalar (const SLComplexRect_s, Complex source

const SLData_t)

Scalar source

DESCRIPTION

This function multiplies the complex value by the scalar value and return the complex result.

NOTES ON USE

CROSS REFERENCE

SCV_VectorAddScalar, SCV_VectorSubtractScalar, SCV VectorDivideScalar, SCV ScalarSubtractVector.

 $SLComplexRect_s\ SCV_VectorDivideScalar\ (const\ SLComplexRect_s, \quad Complex\ source$

const SLData_t)

Scalar source

DESCRIPTION

This function divides the complex value by the scalar value and return the complex result.

NOTES ON USE

CROSS REFERENCE

SCV_VectorAddScalar, SCV_VectorSubtractScalar, SCV VectorMultiplyScalar, SCV ScalarSubtractVector.

SLComplexRect_s SCV_ScalarSubtractVector (const SLData_t, Scalar source const SLComplexRect_s) Complex source

DESCRIPTION

This function subtracts the complex value from the scalar value and return the complex result.

NOTES ON USE

CROSS REFERENCE

SCV_VectorAddScalar, SCV_VectorSubtractScalar, SCV_VectorMultiplyScalar, SCV_VectorDivideScalar.

SCV Roots

PROTOTYPE AND PARAMETER DESCRIPTION

void SCV_Roots (const SLComplexRect_s a, a value

const SLComplexRect_s b,

SLComplexRect_s *Root1,

SLComplexRect_s *Root2)

a, a value

b value

c value

Pointer to root # 1

Pointer to root # 1

DESCRIPTION

This function returns the real roots of the bi-quadratic equation:

$$ax^2 + bx + c = 0$$

The polynomial factors are given by the equation:

$$Roots = \frac{-b \pm \sqrt{b^2 - 4ac}}{2a}$$

NOTES ON USE

CROSS REFERENCE SDS_Roots

SCV_Copy

PROTOTYPE AND PARAMETER DESCRIPTION

DESCRIPTION

This function returns the input vector and copies it to the output.

NOTES ON USE

CROSS REFERENCE

SCV_Compare

PROTOTYPE AND PARAMETER DESCRIPTION

SLCompareType_t SCV_Compare (const SLComplexRect_s, Input vector #1 const SLComplexRect_s IVect2) Input vector #2

DESCRIPTION

This function compares the contents of the two source vectors and returns:

NOTES ON USE

CROSS REFERENCE

COMPLEX ARRAY FUNCTIONS (complexa.c)

These functions are used to create arrays of complex variables and also to extract them to separate arrays of real and complex vectors.

SDA_CreateComplexRect

PROTOTYPE AND PARAMETER DESCRIPTION

void SDA_CreateComplexRect (const SLData_t *, Input real data pointer const SLData_t *, Input imaginary data pointer SLComplexRect_s *, Output complex data pointer const SLArrayIndex_t) Array Length

DESCRIPTION

This function creates an array of interleaved complex rectangular values from two separate arrays, each representing the real and imaginary data sets. The output array is actually an array of interleaved values of type SLData t.

NOTES ON USE

CROSS REFERENCE

 $SDA_CreateComplexPolar, SDA_ExtractComplexRect, \\SDA_ExtractComplexPolar.$

void SDA_CreateComplexPolar (const SLData_t *, Input magnitude data pointer

const SLData_t *, Input phase data pointer SLComplexRect_s *, Output complex data pointer

const SLArrayIndex_t) Array Length

DESCRIPTION

This function creates an array of interleaved complex polar values from two separate arrays, each representing the magnitude and phase data sets. The output array is actually an array of interleaved values of type SLData_t.

NOTES ON USE

CROSS REFERENCE

 $SDA_CreateComplexRect, SDA_ExtractComplexRect, SDA_ExtractComplexPolar.$

void SDA_ExtractComplexRect (const SLData_t *, Input complex data pointer

const SLData t*, Output real data pointer

SLComplexRect s *, Output imaginary data pointer

const SLArrayIndex_t) Array Length

DESCRIPTION

This function extracts two separate arrays, each representing the real and imaginary data sets, from a single array of interleaved complex rectangular values. The input array is actually an array of interleaved values of type SLData t.

NOTES ON USE

CROSS REFERENCE

 $SDA_CreateComplexRect, SDA_CreateComplexPolar, SDA_ExtractComplexPolar.$

void SDA_ExtractComplexPolar (const SLData_t *,Input complex data pointer const SLData_t *,

SLComplexRect_s *,

const SLArrayIndex_t)

Output phase data pointer

Array Length

DESCRIPTION

This function extracts two separate arrays, each representing the magnitude and phase data sets, from a single array of interleaved complex rectangular values. The input array is actually an array of interleaved values of type SLData t.

NOTES ON USE

CROSS REFERENCE

 $SDA_CreateComplexRect, SDA_CreateComplexPolar, \\SDA_ExtractComplexRect.$

void SDA_ClearComplexRect (SLComplexRect_s *, Output complex data pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function clears the contents of the complex rectangular array.

NOTES ON USE

CROSS REFERENCE

 $SDA_ClearComplexPolar, SDA_FillComplexRect, SDA_FillComplexPolar.$

void SDA_ClearComplexPolar (SLComplexPolar_s *, Output complex data pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function clears the contents of the complex polar array.

NOTES ON USE

CROSS REFERENCE

SDA_ClearComplexRect, SDA_FillComplexRect, SDA_FillComplexPolar.

void SDA_FillComplexRect (SLComplexRect_s *, Output complex data pointer const SLComplexRect_s, Fill value const SLArrayIndex_t) Array length

DESCRIPTION

This function fills the contents of the complex rectangular array with the constant fill value.

NOTES ON USE

CROSS REFERENCE

SDA_ClearComplexPolar, SDA_FillComplexPolar.

DESCRIPTION

This function fills the contents of the complex polar array with the constant fill value.

NOTES ON USE

CROSS REFERENCE

 $SDA_ClearComplexRect, SDA_ClearComplexPolar, SDA_FillComplexRect.$

SLComplexPolar_s *, Output complex data pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function converts the complex (rectangular co-ordinate) data in the source arrays to polar data, in the destination arrays, according the following equations:

$$magnitude = \sqrt{real^2 + imag^2}$$

$$Angle = tan^{-1} \left(\frac{imag}{real} \right)$$

NOTES ON USE

CROSS REFERENCE

SDA ComplexPolarToRectangular

void SDA_ComplexPolarToRectangular (const SLComplexPolar_s *, Input complex data pointer

SLComplexRect_s *, Output complex data pointer

const SLArrayIndex_t) Array length

DESCRIPTION

This function converts the polar co-ordinate data in the source arrays to rectangular data, in the destination arrays, according to the following equations:

Real = Magnitude * cos (Angle)

Imaginary = Magnitude * sin (Angle)

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectangularToPolar

void SDA_RectangularToPolar (const SLData_t *, Real source pointer const SLData_t *, Imaginary source array pointer SLData_t *, Destination magnitude array pointer SLData_t *, Destination phase array pointer const SLArrayIndex t)

Array length

DESCRIPTION

This function converts the complex (rectangular co-ordinate) data in the source arrays to polar data, in the destination arrays, according the following equations:

$$magnitude = \sqrt{real^2 + imag^2}$$

$$Angle = tan^{-1} \left(\frac{imag}{real} \right)$$

NOTES ON USE

CROSS REFERENCE

SDA PolarToRectangular

void SDA_PolarToRectangular (const SLData_t *, Real source pointer
const SLData_t *, Imaginary source array pointer
SLData_t *, Destination magnitude array pointer
SLData_t *, Destination phase array pointer
const SLArrayIndex t) Array length

DESCRIPTION

This function converts the polar co-ordinate data in the source arrays to rectangular data, in the destination arrays, according to the following equations:

Real = Magnitude * cos (Angle)

Imaginary = Magnitude * sin (Angle)

NOTES ON USE

CROSS REFERENCE

SDA_RectangularToPolar

void SDA_ComplexRectSqrt (const SLComplexRect_s *, Pointer to source array SLComplexRect_s *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the complex square root for each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectInverse, SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude, SDA_ComplexRectMagnitudeSquared, SDA_ComplexRectPhase, SDA_ComplexRectMultiply, SDA_ComplexRectDivide,

SDA_ComplexRectAdd, SDA_ComplexRectSubtract, SDA_ComplexRectLog,

SDA ComplexRectExp, SDA ComplexRectExpj, SDA ComplexRectPow,

SDA ComplexRectAddScalar, SDA ComplexRectSubtractScalar,

SDA_ComplexRectMultiplyScalar, SDA_ComplexRectDivideScalar,

void SDA_ComplexRectInverse (const SLComplexRect_s *, Pointer to source array

SLComplexRect_s *, Pointer to destination array

const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the inverse of each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectSqrt, SDA ComplexRectConjugate,

SDA_ComplexRectMagnitude, SDA_ComplexRectMagnitudeSquared,

SDA ComplexRectPhase, SDA ComplexRectMultiply, SDA ComplexRectDivide,

SDA ComplexRectAdd, SDA ComplexRectSubtract, SDA ComplexRectLog,

SDA ComplexRectExp, SDA ComplexRectExpj, SDA ComplexRectPow,

SDA ComplexRectAddScalar, SDA ComplexRectSubtractScalar,

SDA ComplexRectMultiplyScalar, SDA ComplexRectDivideScalar,

void SDA_ComplexRectConjugate (const SLComplexRect_s *, Pointer to source array

SLComplexRect_s *, Pointer to destination array

const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the complex conjugate of each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectSqrt, SDA ComplexRectInverse,

 $SDA_ComplexRectMagnitude, SDA_ComplexRectMagnitudeSquared,$

SDA_ComplexRectPhase, SDA_ComplexRectMultiply, SDA_ComplexRectDivide,

SDA ComplexRectAdd, SDA ComplexRectSubtract, SDA ComplexRectLog,

SDA ComplexRectExp, SDA ComplexRectExpj, SDA ComplexRectPow,

 $SDA_ComplexRectAddScalar, SDA_ComplexRectSubtractScalar,$

SDA_ComplexRectMultiplyScalar, SDA_ComplexRectDivideScalar,

void SDA_ComplexRectMagnitude (const SLComplexRect_s *, Pointer to source array

SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the magnitude of each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectInverse,

SDA_ComplexRectConjugate, SDA_ComplexRectMagnitudeSquared,

SDA ComplexRectPhase, SDA ComplexRectMultiply, SDA ComplexRectDivide,

SDA ComplexRectAdd, SDA ComplexRectSubtract, SDA ComplexRectLog,

SDA ComplexRectExp, SDA ComplexRectExpj, SDA ComplexRectPow,

SDA ComplexRectAddScalar, SDA ComplexRectSubtractScalar,

SDA_ComplexRectMultiplyScalar, SDA_ComplexRectDivideScalar,

void SDA_ComplexRectMagnitudeSquared (const SLComplexRect_s *, Pointer to source array

SLData_t *, Pointer to destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the magnitude squared for each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectSqrt, SDA_ComplexRectInverse,

SDA ComplexRectConjugate, SDA ComplexRectMagnitude,

SDA ComplexRectPhase, SDA ComplexRectMultiply, SDA ComplexRectDivide,

SDA ComplexRectAdd, SDA ComplexRectSubtract, SDA ComplexRectLog,

SDA ComplexRectExp, SDA ComplexRectExpj, SDA ComplexRectPow,

SDA ComplexRectAddScalar, SDA ComplexRectSubtractScalar,

SDA ComplexRectMultiplyScalar, SDA ComplexRectDivideScalar,

void SDA_ComplexRectPhase (const SLComplexRect_s *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the complex phase for each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectSqrt, SDA_ComplexRectInverse, SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude, SDA_ComplexRectMagnitudeSquared, SDA_ComplexRectMultiply,

SDA ComplexRectDivide, SDA ComplexRectAdd, SDA ComplexRectSubtract,

SDA ComplexRectLog, SDA ComplexRectExp, SDA ComplexRectExpj,

SDA ComplexRectPow, SDA ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

void SDA_ComplexRectMultiply (const SLComplexRect_s *, Pointer to source array 1

const SLComplexRect_s *, Pointer to source array 2
SLComplexRect_s *, Pointer to destination array
const SLArrayIndex t) Array length

DESCRIPTION

This function multiplies the complex values in source array 1 by the complex values in source array 2.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectInverse,

SDA ComplexRectConjugate, SDA ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectDivide, SDA ComplexRectAdd, SDA ComplexRectSubtract,

SDA_ComplexRectLog, SDA_ComplexRectExp, SDA_ComplexRectExpj,

SDA ComplexRectPow, SDA ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

void SDA_ComplexRectDivide (const SLComplexRect_s *, Pointer to source array 1

const SLComplexRect_s *, Pointer to source array 2
SLComplexRect_s *, Pointer to destination array
const SLArrayIndex t) Array length

DESCRIPTION

This function divides the complex values in one source array by the complex values in the second source array.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectSqrt, SDA ComplexRectInverse,

SDA ComplexRectConjugate, SDA ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectAdd, SDA ComplexRectSubtract,

SDA_ComplexRectLog, SDA_ComplexRectExp, SDA_ComplexRectExpj,

SDA ComplexRectPow, SDA ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

void SDA_ComplexRectAdd (const SLComplexRect_s *, Pointer to source array 1

const SLComplexRect_s *, Pointer to source array 2 SLComplexRect_s *, Pointer to destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function adds the complex values in the two source arrays.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectInverse,

SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExp,

SDA_ComplexRectExpj, SDA_ComplexRectPow, SDA_ComplexRectAddScalar,

 $SDA_ComplexRectSubtractScalar, SDA_ComplexRectMultiplyScalar,$

void SDA_ComplexRectSubtract (const SLComplexRect_s *, Pointer to source array 1

const SLComplexRect_s *, Pointer to source array 2
SLComplexRect_s *, Pointer to destination array
const SLArrayIndex t) Array length

DESCRIPTION

This function subtracts the complex samples in source array 2 from those values in source array 1.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectInverse,

SDA ComplexRectConjugate, SDA ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA_ComplexRectLog, SDA_ComplexRectExp, SDA_ComplexRectExpj,

SDA ComplexRectPow, SDA ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

void SDA_ComplexRectLog (const SLComplexRect_s *, Pointer to source array SLComplexRect_s *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the complex log for each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectSqrt, SDA ComplexRectInverse,

SDA ComplexRectConjugate, SDA ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA_ComplexRectMultiply, SDA_ComplexRectDivide, SDA_ComplexRectAdd,

SDA_ComplexRectSubtract, SDA_ComplexRectExp, SDA_ComplexRectExpj,

SDA ComplexRectPow, SDA ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

void SDA_ComplexRectExp (const SLComplexRect_s *, Pointer to source array SLComplexRect_s *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function calculates the complex exponential for each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

 $SDA_ComplexRectSqrt, SDA_ComplexRectInverse,$

SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude,

 $SDA_ComplexRectMagnitudeSquared, SDA_ComplexRectPhase,$

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExpj,

SDA ComplexRectPow, SDA ComplexRectAddScalar,

SDA_ComplexRectSubtractScalar, SDA_ComplexRectMultiplyScalar,

void SDA_ComplexRectExpj (const SLData_t *, Pointer to source array SLComplexRect_s *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function calculates the complex exponential $(cos(\theta) + jsin(\theta))$ for each of the values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectInverse,

SDA ComplexRectConjugate, SDA ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExp,

SDA_ComplexRectPow, SDA_ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

void SDA_ComplexRectPow (const SLComplexRect_s *, Pointer to source array

SLComplexRect s*, Pointer to destination array

const SLData t, Power

const SLArrayIndex_t) Array length

DESCRIPTION

This function raises the complex values in the source array to the given power.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectInverse,

SDA ComplexRectConjugate, SDA ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExp,

 $SDA_ComplexRectExpj, SDA_ComplexRectAddScalar,$

SDA_ComplexRectSubtractScalar, SDA_ComplexRectMultiplyScalar,

void SDA_ComplexRectAddScalar (const SLComplexRect_s *, Pointer to source array

const SLData t, Scalar

SLComplexRect s*, Pointer to destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function adds the scalar value to the complex values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectSqrt, SDA_ComplexRectInverse,

SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude,

SDA_ComplexRectMagnitudeSquared, SDA_ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExp,

SDA_ComplexRectExpj, SDA_ComplexRectPow,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

void SDA_ComplexRectSubtractScalar (const SLComplexRect_s *, Pointer to source array

const SLData t, Scalar

SLComplexRect s*, Pointer to destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function subtracts the scalar value from the complex values in the source array.

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectSqrt, SDA_ComplexRectInverse,

SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude,

SDA_ComplexRectMagnitudeSquared, SDA_ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExp,

SDA_ComplexRectExpj, SDA_ComplexRectPow, SDA_ComplexRectAddScalar,

SDA ComplexRectMultiplyScalar, SDA ComplexRectDivideScalar,

void SDA_ComplexRectMultiplyScalar (const SLComplexRect_s *, Pointer to source array

const SLData t, Scalar

SLComplexRect s *, Pointer to destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function multiplies the complex values in the source array by the scalar value.

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectSqrt, SDA_ComplexRectInverse,

SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExp,

SDA_ComplexRectExpj, SDA_ComplexRectPow, SDA_ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectDivideScalar,

void SDA_ComplexRectDivideScalar (const SLComplexRect_s *, Pointer to source array

const SLData t, Scalar

SLComplexRect s *, Pointer to destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function divides the complex values in the source array by the scalar value.

NOTES ON USE

CROSS REFERENCE

SDA_ComplexRectSqrt, SDA_ComplexRectInverse,

SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExp,

SDA_ComplexRectExpj, SDA_ComplexRectPow, SDA_ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

void SDA_ComplexScalarSubtractRect (const SLData_t, Scalar

const SLComplexRect_s *, Pointer to source array SLComplexRect_s *, Pointer to destination array

const SLArrayIndex t) Array length

DESCRIPTION

This function subtract the complex values in the source array from the scalar value.

NOTES ON USE

CROSS REFERENCE

SDA ComplexRectInverse,

SDA_ComplexRectConjugate, SDA_ComplexRectMagnitude,

SDA ComplexRectMagnitudeSquared, SDA ComplexRectPhase,

SDA ComplexRectMultiply, SDA ComplexRectDivide, SDA ComplexRectAdd,

SDA ComplexRectSubtract, SDA ComplexRectLog, SDA ComplexRectExp,

SDA_ComplexRectExpj, SDA_ComplexRectPow, SDA_ComplexRectAddScalar,

SDA ComplexRectSubtractScalar, SDA ComplexRectMultiplyScalar,

SDA ComplexRectDivideScalar.

void SDA_ComplexRectLinearInterpolate (const SLComplexRect s,

Interpolation start point

const SLComplexRect_s, Interpolation end point

SLComplexRect_s *, Destination array

const SLArrayIndex t) Number of interpolated points

DESCRIPTION

This function performs rectangular linear interpolation of the samples between the two source complex numbers.

NOTES ON USE

The output array length = the number of interpolated points +2.

CROSS REFERENCE

SDA_ComplexPolarLinearInterpolate, SDA_Interpolate, SDA InterpolateAndFilter, SDA InterpolateLinear1, SDA InterpolateLinear2.

void SDA_ComplexPolarLinearInterpolate (const SLComplexPolar_s,

Interpolation start point

const SLComplexPolar_s, Interpolation end point

SLComplexPolar_s *, Destination array

const SLArrayIndex t) Number of interpolated points

DESCRIPTION

This function performs polar linear interpolation of the samples between the two source complex numbers.

NOTES ON USE

The output array length = the number of interpolated points +2.

CROSS REFERENCE

SDA_ComplexRectLinearInterpolate, SDA_Interpolate, SDA InterpolateAndFilter, SDA InterpolateLinear1, SDA InterpolateLinear2.

MATRIX VECTOR FUNCTIONS (matrix.c)

The matrix functions operate on 2 dimensional real matrices. A matrix of n ROWS by m COLUMNS is denoted:

Each element in row i and column j of A is denoted by A(i,j), with the full matrix being shown below:

All SigLib matrices are real so to implement complex operations the real and imaginary components are handled separately. For example a complex array A can be represented by the separate arrays A_real and A_imag. Now we can perform a complex operation (e.g. Hermitian Transpose) by using the following SigLib functions:

```
SMX_Transpose (A_real...) // Transpose the real array
SMX_Transpose (A_imag...) // Transpose the imaginary array
SDA_Negate (A_imag...) //Conjugate the result by
// negating the imaginary array
```

void SMX_Transpose (const SLData_t *, Source matrix pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t, Source matrix # of rows const SLArrayIndex_t) Source matrix # columns

DESCRIPTION

This function transposes a two dimensional matrix. This operation is also referred to as a 'corner turn'.

NOTES ON USE

This function can only work in-place if the matrix is square. If the matrix is not square then the function requires separate source and destination arrays.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn

```
void SMX_Multiply (const SLData_t *, Source matrix 1 pointer const SLData_t *, Source matrix 2 pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t, Source matrix 1 # of rows const SLArrayIndex_t, Source matrix 1 # of columns const SLArrayIndex_t) Source matrix 2 # of columns
```

DESCRIPTION

This function multiplies two, two dimensional matrices.

NOTES ON USE

The number of columns in the first must equal the number of rows in the second. The output matrix has order: [# rows 1, # columns 2]

CROSS REFERENCE

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_CreateIdentity,
SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose,
SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise,
SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow,
SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows,
SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows,
SMX_ExtractCategoricalColumn
```

Destination matrix pointer Source matrix # of rows and columns

DESCRIPTION

This function creates a square identity matrix:

NOTES ON USE

CROSS REFERENCE

SMX Transpose, SMX Copy, SMX Add, SMX Subtract,

SMX MultiplyPiecewise, SMX ScalarMultiply, SMX Multiply, SMX Inverse2x2,

SMX ComplexInverse2x2, SMX Inverse, SMX LuDecompose, SMX LuSolve,

SMX Determinant, SMX LuDeterminant, SMX RotateClockwise,

SMX RotateAntiClockwise, SMX Reflect, SMX Flip, SMX InsertRow,

SMX ExtractRow, SMX InsertColumn, SMX ExtractColumn,

SMX InsertNewRow, SMX DeleteOldRow, SMX InsertNewColumn,

SMX DeleteOldColumn, SMX InsertRegion, SMX ExtractRegion,

SMX InsertDiagonal, SMX ExtractDiagonal, SMX SwapRows,

SMX SwapColumns, SMX Sum, SDA ShuffleColumns, SMX ShuffleRows,

SMX ExtractCategoricalColumn

SLError_t SMX_Inverse2x2 (const SLData_t *, Pointer to source matrix SLData_t *) Pointer to destination matrix

DESCRIPTION

This functions inverts a square 2x2 matrix using the following equation:

if
$$A = |a \ b|$$
 then $A^{-1} = 1 \ / \ (ad - bc)$. $|d - b|$ $|c \ d|$

NOTES ON USE

This function will return the error code SIGLIB ERROR if the matrix is singular.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,

SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,

SMX CreateIdentity, SMX ComplexInverse2x2, SMX Inverse,

SMX LuDecompose, SMX LuSolve, SMX Determinant, SMX LuDeterminant,

SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,

SMX InsertRow, SMX ExtractRow, SMX InsertColumn, SMX ExtractColumn,

SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,

SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,

SMX InsertDiagonal, SMX ExtractDiagonal, SMX SwapRows,

SMX SwapColumns, SMX Sum, SDA ShuffleColumns, SMX ShuffleRows,

SMX ExtractCategoricalColumn

SLError_t SMX_ComplexInverse2x2 (const SLComplexRect_s *, Pointer to complex source matrix

SLComplexRect s *)

Pointer to complex destination matrix

DESCRIPTION

This functions inverts a complex square 2x2 matrix using the following equation:

if A =
$$|a \ b|$$
 then $A^{-1} = 1 \ / \ (ad - bc)$. $|d - b|$ $|c \ d|$

NOTES ON USE

This function will return the error code SIGLIB ERROR if the matrix is singular.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,

SMX MultiplyPiecewise, SMX ScalarMultiply, SMX Multiply,

SMX_CreateIdentity, SMX_Inverse2x2, SMX_Inverse, SMX_LuDecompose,

SMX LuSolve, SMX Determinant, SMX LuDeterminant, SMX RotateClockwise,

SMX RotateAntiClockwise, SMX Reflect, SMX Flip, SMX InsertRow,

SMX_ExtractRow, SMX InsertColumn, SMX ExtractColumn,

SMX InsertNewRow, SMX DeleteOldRow, SMX InsertNewColumn,

SMX DeleteOldColumn, SMX InsertRegion, SMX ExtractRegion,

SMX InsertDiagonal, SMX ExtractDiagonal, SMX SwapRows,

SMX SwapColumns, SMX Sum, SDA ShuffleColumns, SMX ShuffleRows,

SMX ExtractCategoricalColumn

SLError_t SMX_Inverse (const SLData_t *, Source matrix pointer

SLData_t *, Destination matrix pointer

SLData_t *, Temporary array for source

SLData_t *, Index substitution array

SLArrayIndex_t *, Row interchange indices

SLData_t *, Scaling factor array

const SLArrayIndex_t) Number of rows and columns in matrix

DESCRIPTION

This functions inverts a square matrix.

NOTES ON USE

This function uses the LU decomposition algorithm via the function SMX_LuDecompose and then uses forward and backward substitution to solve the equation $A \cdot x = b$ (where A = LU), using the SigLib function SMX_LuSolve.

This function will return the error code SIGLIB ERROR if the matrix is singular.

The *LU* decomposed array is stored temporarily within this function. If multiple linear equations need to be solved then the decomposition and solution functions can be called separately from the user's programs. In this case, it is only necessary to perform the *LU* decomposition once for each matrix *A*, followed by multiple calls to the function SMX LuSolve.

CROSS REFERENCE

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

SLError_t SMX_LuDecompose (SLData_t *, Source and destination pointer SLArrayIndex_t *, Index matrix pointer SLData_t *, Scaling factor array const SLArrayIndex_t) Number of rows and columns in matrix

DESCRIPTION

This functions performs an *LU* decomposition on a square matrix, using Crout's method.

NOTES ON USE

The data in the source matrix will be destroyed.

This function will return the error code SIGLIB ERROR if the matrix is singular.

Scaled partial pivoting is used I.E. only rows are interchanged. A record of the row interchanges are stored in the row interchange matrix and these are used in the functions that can accept the output from SMX LuDecompose.

If multiple linear equations need to be solved then the decomposition and solution functions can be called separately from the user's programs. In this case, it is only necessary to perform the LU decomposition once for each matrix A, followed by multiple calls to the function $SMX_LuSolve$.

CROSS REFERENCE

SMX Transpose, SMX Copy, SMX Add, SMX Subtract, SMX MultiplyPiecewise,

SMX ScalarMultiply, SMX Multiply, SMX CreateIdentity, SMX Inverse2x2,

SMX ComplexInverse2x2, SMX Inverse, SMX LuSolve, SMX Determinant,

SMX LuDeterminant, SMX RotateClockwise, SMX RotateAntiClockwise,

SMX Reflect, SMX Flip, SMX InsertRow, SMX ExtractRow, SMX InsertColumn,

SMX ExtractColumn, SMX InsertNewRow, SMX DeleteOldRow,

SMX InsertNewColumn, SMX DeleteOldColumn, SMX InsertRegion,

SMX ExtractRegion, SMX InsertDiagonal, SMX ExtractDiagonal,

SMX SwapRows, SMX SwapColumns, SMX Sum, SDA ShuffleColumns,

SMX ShuffleRows, SMX ExtractCategoricalColumn

void SMX_LuSolve (const SLData_t *, SLData_t *, Source and inverse matrix pointer const SLArrayIndex_t *, Const SLArrayIndex_t *, Source matrix # of rows and columns

DESCRIPTION

This function uses forward and backward substitution on a square matrix, to solve the equation A. x = b (where A = LU), using the SigLib function SMX_LuSolve. It accepts as its primary inputs an interchanged LU decomposed matrix and row interchange matrix.

NOTES ON USE

If multiple linear equations need to be solved then the decomposition and solution functions can be called separately from the user's programs. In this case, it is only necessary to perform the *LU* decomposition once for each matrix *A*, followed by multiple calls to the function SMX_LuSolve.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows,
SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows,
SMX_ExtractCategoricalColumn

SLData_t SMX_Determinant (const SLData_t *, Source matrix pointer SLData_t *, Temporary array for source SLArrayIndex_t *, Row interchange indices SLData_t *, Scaling factor array const SLArrayIndex_t) Number of rows and columns in matrix

DESCRIPTION

This function returns the determinant of a square matrix.

NOTES ON USE

This function will NOT return an error code if the matrix is non-invertible (I.E. singular) or if there is a memory allocation error.

This function allocates temporary arrays whenever the array length increases because the $\boldsymbol{L}\boldsymbol{U}$ decomposition algorithm is destructive and these arrays avoid the source array from being destroyed.

This function uses the LU decomposition algorithm via the function SMX_LuDecompose.

If the matrix has already been decomposed into the LU form then it is only necessary to call the function SMX LuDeterminant.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_LuDeterminant, SMX_RotateClockwise,
SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow,
SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows,
SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows,
SMX_ExtractCategoricalColumn
```

SLData_t SMX_LuDeterminant (const SLData_t *, Source matrix pointer const SLArrayIndex_t * Row interchange matrix pointer const SLArrayIndex_t) Source matrix # of rows and columns

DESCRIPTION

This function returns the determinant of a square matrix.

NOTES ON USE

This function accepts an *LU* array with interchanged rows, as indicated in the row interchange index array.

If the matrix has already been decomposed into the LU form then it is only necessary to call the function SMX LuDeterminant and not SMX Determinant.

The determinant of a matrix is the product of diagonal elements of $\boldsymbol{L}\boldsymbol{U}$ decomposition and The sign of the determinant changes for each row swap that occurred in the $\boldsymbol{L}\boldsymbol{U}$ decomposition process.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,

SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,

SMX CreateIdentity, SMX Inverse2x2, SMX ComplexInverse2x2, SMX Inverse,

SMX LuDecompose, SMX LuSolve, SMX Determinant, SMX RotateClockwise,

SMX RotateAntiClockwise, SMX Reflect, SMX Flip, SMX InsertRow,

SMX ExtractRow, SMX InsertColumn, SMX ExtractColumn,

SMX InsertNewRow, SMX DeleteOldRow, SMX InsertNewColumn,

SMX DeleteOldColumn, SMX InsertRegion, SMX ExtractRegion,

SMX InsertDiagonal, SMX ExtractDiagonal, SMX SwapRows,

SMX SwapColumns, SMX Sum, SDA ShuffleColumns, SMX ShuffleRows,

SMX ExtractCategoricalColumn

void SMX_RotateClockwise (const SLData_t *, Source matrix pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex t) Number of columns in matrix

DESCRIPTION

This function rotates the matrix clockwise.

NOTES ON USE

This function does not work in-place.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow,
SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows,
SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows,
SMX_ExtractCategoricalColumn

void SMX RotateAntiClockwise (const SLData t*, Source matrix pointer

SLData_t *, Destination matrix pointer const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix

DESCRIPTION

This function rotates the matrix anti-clockwise.

NOTES ON USE

This function does not work in-place.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,

SMX MultiplyPiecewise, SMX ScalarMultiply, SMX Multiply,

SMX CreateIdentity, SMX Inverse2x2, SMX ComplexInverse2x2, SMX Inverse,

SMX LuDecompose, SMX LuSolve, SMX Determinant, SMX LuDeterminant,

SMX RotateClockwise, SMX Reflect, SMX Flip, SMX InsertRow,

SMX ExtractRow, SMX InsertColumn, SMX ExtractColumn,

SMX InsertNewRow, SMX DeleteOldRow, SMX InsertNewColumn,

SMX DeleteOldColumn, SMX InsertRegion, SMX ExtractRegion,

SMX InsertDiagonal, SMX ExtractDiagonal, SMX SwapRows,

SMX SwapColumns, SMX Sum, SDA ShuffleColumns, SMX ShuffleRows,

SMX ExtractCategoricalColumn

void SMX_Reflect (const SLData_t *,
SLData_t *,
const SLArrayIndex_t,
const SLArrayIndex_t)Source matrix pointer
Destination matrix pointer
Number of rows in matrix
Number of columns in matrix

DESCRIPTION

This function reflects the matrix about the central vertical axis.

NOTES ON USE

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Flip, SMX_InsertRow,
SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows,
SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows,
SMX_ExtractCategoricalColumn

void SMX_Flip (const SLData_t *, Source matrix pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix

DESCRIPTION

This function flips the matrix about the central horizontal axis.

NOTES ON USE

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn

```
void SMX_InsertRow (const SLData_t *, Source matrix pointer const SLData_t *, Input data for row SLData_t *, Destination matrix pointer const SLArrayIndex_t, Row number to insert data const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix
```

DESCRIPTION

This function inserts the new data into the selected row.

NOTES ON USE

This function overwrites the data in the selected row in the matrix.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows,
SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows,
SMX_ExtractCategoricalColumn
```

void SMX_ExtractRow (const SLData_t *, Source matrix pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t, Row number to extract data const SLArrayIndex_t) Number of columns in matrix

DESCRIPTION

This function extracts the data from the selected row.

NOTES ON USE

This function copies the data to the destination array. If you want to delete the row afterwards you should use the function SMX DeleteOldRow().

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow,
SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn,
SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal,
SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum,
SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn

DESCRIPTION

This function inserts the new data into the selected column.

NOTES ON USE

This function overwrites the data in the selected column in the matrix.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

void SMX_ExtractColumn (const SLData	_t *, Source matrix pointer
SLData_t *,	Destination matrix pointer
<pre>const SLArrayIndex_t,</pre>	Column number to extract data
const SLArrayIndex_t,	Number of rows in matrix
const SLArrayIndex_t)	Number of columns in matrix

DESCRIPTION

This function extracts the data from the selected column.

NOTES ON USE

This function copies the data to the destination array. If you want to delete the column afterwards you should use the function SMX DeleteOldColumn().

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_InsertNewRow,
SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn,
SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal,
SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum,
SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

```
void SMX_InsertRow (const SLData_t *, Source matrix pointer const SLData_t *, Input data for row SLData_t *, Destination matrix pointer const SLArrayIndex_t, Row number to insert data const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix
```

DESCRIPTION

This function creates a new row and inserts the new data into this row.

NOTES ON USE

The number of rows specified in the parameter list is the number of rows in the source matrix.

This function does not work in-place.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

<pre>void SMX_DeleteOldRow (const SLData</pre>	_t *, Source matrix pointer
SLData_t *,	Destination matrix pointer
<pre>const SLArrayIndex_t,</pre>	Row number to insert data
const SLArrayIndex_t,	Number of rows in matrix
const SLArrayIndex_t)	Number of columns in matrix

DESCRIPTION

This function deletes the complete row from the matrix.

NOTES ON USE

The number of rows specified in the parameter list is the number of rows in the source matrix.

This function works in-place.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

void SMX_InsertNewColumn (const SLData_t *, Source matrix pointer const SLData_t *, Input data for column SLData_t *, Destination matrix pointer const SLArrayIndex_t, Row number to insert data const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix

DESCRIPTION

This function creates a new column and inserts the new data into this column.

NOTES ON USE

The number of columns specified in the parameter list is the number of columns in the source matrix.

This function does not work in-place.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

void SMX_DeleteOldColumn (const	SLData_t *, Source matrix pointer
SLData_t *,	Destination matrix pointer
<pre>const SLArrayIndex_t,</pre>	Column number to insert data
const SLArrayIndex_t,	Number of rows in matrix
const SLArrayIndex_t)	Number of columns in matrix

DESCRIPTION

This function deletes the complete column from the matrix.

NOTES ON USE

The number of columns specified in the parameter list is the number of columns in the source matrix.

This function works in-place.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractRegion, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

void SMX InsertRegion (const SLData t*, Source matrix pointer const SLData t*, Pointer to new region data SLData t*, Destination matrix pointer const SLArrayIndex t, Starting row to insert data const SLArrayIndex t, Starting column to insert data const SLArrayIndex t, Number of rows in new data matrix const SLArrayIndex t, Number of columns in new data matrix const SLArrayIndex t, Number of rows in matrix Number of columns in matrix const SLArrayIndex_t)

DESCRIPTION

This function inserts the new matrix data into the source matrix.

NOTES ON USE

This function overwrites the data in the original matrix.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_ExtractRegion, SMX_InsertDiagonal,
SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum,
SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

<pre>void SMX_ExtractRegion (const SLData_</pre>	t *, Source matrix pointer
SLData_t *,	Destination matrix pointer
<pre>const SLArrayIndex_t,</pre>	Starting row to extract data
<pre>const SLArrayIndex_t,</pre>	Starting column to extract data
<pre>const SLArrayIndex_t,</pre>	Number of rows in region to extract
<pre>const SLArrayIndex_t,</pre>	Number of columns in region to extract
<pre>const SLArrayIndex_t)</pre>	Number of columns in matrix

DESCRIPTION

This function extracts the specified matrix from the source matrix.

NOTES ON USE

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_InsertDiagonal,
SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum,
SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

```
void SMX_InsertDiagonal (const SLData_t *, Source matrix pointer const SLData_t *, New data to place on diagonal SLData_t *, Destination matrix pointer const SLArrayIndex_t)

Dimension of square matrix
```

DESCRIPTION

This function inserts the new data into the diagonal of the matrix.

NOTES ON USE

This function overwrites the data in the original matrix. The matrix must be square.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum,
SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

void SMX_ExtractDiagonal (const SLData_t *, Source matrix pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t) Dimension of square matrix

DESCRIPTION

This function extracts the diagonal from the source matrix.

NOTES ON USE

The matrix must be square.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn

void SMX_SwapRows (const SLData_t *, Source matrix pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t, Row number 1 to swap const SLArrayIndex_t, Row number 2 to swap const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix

DESCRIPTION

This function swaps the data in the two rows.

NOTES ON USE

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn
```

void SMX_SwapColumns (const SLData_t *, Source matrix pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t, Column number 1 to swap const SLArrayIndex_t, Column number 2 to swap const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix

DESCRIPTION

This function swaps the data in the two columns.

NOTES ON USE

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_Sum,
SDA_ShuffleColumns, SMX_ShuffleRows, SMX_ExtractCategoricalColumn

SMX Sum

PROTOTYPE AND PARAMETER DESCRIPTION

<pre>void SMX_Sum (const SLData_t *,</pre>	Source matrix pointer
SLData_t *,	Destination matrix pointer
<pre>const SLArrayIndex_t,</pre>	Number of rows in matrix
const SLArrayIndex t)	Number of columns in matrix

DESCRIPTION

This function sums all values in each column so the number of results equals the number of columns.

NOTES ON USE

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows,
SMX_SwapColumns SDA_ShuffleColumns, SMX_ShuffleRows,
SMX_ExtractCategoricalColumn
```

```
void SMX_ShuffleColumns (const SLData_t *, Pointer to source matrix SLData_t *, Pointer to destination matrix SLData_t *, Pointer to temporary array #1 SLData_t *, Pointer to temporary array #2 const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix
```

DESCRIPTION

This function shuffles the order of the columns in the matrix.

NOTES ON USE

As the number of columns approaches RAND_MAX, the result becomes less random. The solution is to use a better random number generator or call the function multiple times.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract,
SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply,
SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse,
SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant,
SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip,
SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn,
SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn,
SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion,
SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows,
SMX_SwapColumns, SMX_Sum, SMX_ShuffleRows,
SMX_ExtractCategoricalColumn
```

<pre>void SMX_ShuffleRows (const SLData_t *,</pre>	Pointer to source matrix
SLData_t *,	Pointer to destination matrix
SLData_t *,	Pointer to temporary array
const SLArrayIndex_t,	Number of rows in matrix
const SLArrayIndex t)	Number of columns in matrix

DESCRIPTION

This function shuffles the order of the rows in the matrix.

NOTES ON USE

As the number of rows approaches RAND_MAX, the result becomes less random. The solution is to use a better random number generator or call the function multiple times.

```
SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum SDA_ShuffleColumns, SMX_ExtractCategoricalColumn
```

void SMX_ExtractCategoricalColumn (const SLData_t *, Pointer to source matrix

SLArrayIndex_t *, Pointer to destination matrix const SLArrayIndex_t, Number of rows in matrix const SLArrayIndex_t) Number of columns in matrix

DESCRIPTION

This function extracts the categorical column from the matrix. The categories are stored as integers (SLArrayIndex t).

NOTES ON USE

The categorical column is the last column in the matrix.

CROSS REFERENCE

SMX_Transpose, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_Multiply, SMX_CreateIdentity, SMX_Inverse2x2, SMX_ComplexInverse2x2, SMX_Inverse, SMX_LuDecompose, SMX_LuSolve, SMX_Determinant, SMX_LuDeterminant, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum, SDA_ShuffleColumns, SMX_ShuffleRows

<pre>void SMX_Copy (const SLData_t *,</pre>	Source matrix pointer
SLData_t *,	Destination matrix pointer
<pre>const SLArrayIndex_t,</pre>	Source matrix # of rows
const SLArrayIndex t)	Source matrix # of columns

DESCRIPTION

This function copies a two dimensional matrix.

NOTES ON USE

This functionality is implemented as a macro and id defined in the file siglib.h.

```
SMX_Transpose, SMX_Multiply, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum
```

<pre>void SMX_Add (const SLData_t *,</pre>	Source matrix 1 pointer
const SLData_t *,	Source matrix 2 pointer
SLData_t *,	Destination matrix pointer
const SLArrayIndex_t,	Source matrices # of rows
const SLArrayIndex t)	Source matrices # of columns

DESCRIPTION

This function adds two, two dimensional matrices.

NOTES ON USE

This functionality is implemented as a macro and id defined in the file siglib.h.

```
SMX_Transpose, SMX_Multiply, SMX_Copy, SMX_Subtract, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum.
```

void SMX_Subtract (const SLData_t *, Source matrix 1 pointer const SLData_t *, Source matrix 2 pointer SLData_t *, Destination matrix pointer const SLArrayIndex_t, Source matrices # of rows const SLArrayIndex t) Source matrices # of columns

DESCRIPTION

This function subtracts one two dimensional matrix from another.

NOTES ON USE

This functionality is implemented as a macro and id defined in the file siglib.h.

CROSS REFERENCE

SMX_Transpose, SMX_Multiply, SMX_Copy, SMX_Add, SMX_MultiplyPiecewise, SMX_ScalarMultiply, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum.

void SMX_MultiplyPiecewise (const SLData_t *, Source matrix 1 pointer

const SLData_t *, Source matrix 2 pointer
SLData_t *, Destination matrix pointer
const SLArrayIndex_t, Source matrices # of rows
const SLArrayIndex_t) Source matrices # of columns

DESCRIPTION

This function performs piece-wise multiplication between two, two dimensional matrices.

NOTES ON USE

This functionality is implemented as a macro and id defined in the file *siglib.h.*

CROSS REFERENCE

SMX_Transpose, SMX_Multiply, SMX_Copy, SMX_Add, SMX_Subtract, SMX_ScalarMultiply, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum.

DESCRIPTION

This function multiplies a two dimensional matrix by a scalar value.

NOTES ON USE

This functionality is implemented as a macro and id defined in the file siglib.h.

```
SMX_Transpose, SMX_Multiply, SMX_Copy, SMX_Add, SMX_Subtract, SMX_MultiplyPiecewise, SMX_RotateClockwise, SMX_RotateAntiClockwise, SMX_Reflect, SMX_Flip, SMX_InsertRow, SMX_ExtractRow, SMX_InsertColumn, SMX_ExtractColumn, SMX_InsertNewRow, SMX_DeleteOldRow, SMX_InsertNewColumn, SMX_DeleteOldColumn, SMX_InsertRegion, SMX_ExtractRegion, SMX_InsertDiagonal, SMX_ExtractDiagonal, SMX_SwapRows, SMX_SwapColumns, SMX_Sum
```

Machine Learning Functions

These functions implement a selection of two layer convolutional neural networks. The number of nodes in each layer are selectable as are the number of output nodes.

For detecting two different categories only one output node is required. For detecting more than two categories, one node per category is required.

The two layers are:

Layer 1: Hidden layer Layer 2: Output layer

The available activation types are:

Activation Enumerated Type	Activation Type
SIGLIB_ACTIVATION_TYPE_RELU	Rectified Linear Unit
SIGLIB_ACTIVATION_TYPE_LEAKY_RELU	Leaky Rectified Linear Unit
SIGLIB_ACTIVATION_TYPE_LOGISTIC	Logistic (aka Sigmoid)
SIGLIB_ACTIVATION_TYPE_TANH	Hyperbolic Tangent

void SDA_TwoLayer2CategoryNetworkFit (const SLData_t *, Pointer to training data

const SLArrayIndex t*, Pointer to categorical data Pointer to layer 1 weights SLData t*, SLData t*, Pointer to layer 2 weights SLData t*, Pointer to layer 1 pre activation SLData t*, Pointer to layer 1 post activation const enum SLActivationType t, Layer 1 activation type Layer 1 activation alpha const SLData t, const enum SLActivationType t, Layer 2 activation type Layer 2 activation alpha const SLData t, const SLData t, Learning rate Number of training sequences const SLArrayIndex t, const SLArrayIndex t, Input array length const SLArrayIndex t) Number of layer 1 nodes

DESCRIPTION

This function trains a two layer, two category neural network using the provided data.

NOTES ON USE

The training data array is actually a matrix of number of columns = sample length and the number of rows = number of training sequences. Each row represents a category and the categories are indicated in the categorical data array.

The categorical data array includes one entry for each row of the training sequence matrix.

```
SDA_TwoLayer2CategoryNetworkPredict,
SDA_TwoLayerNCategoryNetworkFit, SDA_TwoLayerNCategoryNetworkPredict,
SDS_ActivationReLU, SDA_ActivationReLU, SDS_ActivationReLUDerivative,
SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,
SDA_ActivationLeakyReLU, SDS_ActivationLeakyReLUDerivative,
SDA_ActivationLeakyReLUDerivative, SDS_ActivationLogistic,
SDA_ActivationLogistic, SDS_ActivationLogisticDerivative,
SDA_ActivationLogisticDerivative, SDS_ActivationTanH, SDA_ActivationTanHDerivative,
SDA_ActivationTanHDerivative, SDA_ActivationTanHDerivative,
SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile,
SUF_WriteWeightsBinaryFile, SUF_ReadWeightsBinaryFile
```

SLArrayIndex_t SDA_TwoLayer2CategoryNetworkPredict (const SLData_t *, Pointer to data to classify

const SLData t*, Pointer to layer 1 weights Pointer to layer 2 weights const SLData t*, Pointer to layer 1 post activation SLData t*, SLData t*, Pointer to output activation const enum SLActivationType t, Layer 1 activation type const SLData t, Layer 1 activation alpha const enum SLActivationType t, Layer 2 activation type const SLData t, Layer 2 activation alpha Classification threshold const SLData t, const SLArrayIndex t, Input array length const SLArrayIndex t) Number of layer 1 nodes

DESCRIPTION

This function uses the neural network to predict the category using the provided data. The source data array to classify is a single dimensional array that will be classified by the trained neural network.

NOTES ON USE

```
SDA_TwoLayer2CategoryNetworkFit,
SDA_TwoLayerNCategoryNetworkPredict, SDS_ActivationReLU,
SDA_ActivationReLU, SDS_ActivationReLUDerivative,
SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,
SDA_ActivationLeakyReLU, SDS_ActivationLeakyReLUDerivative,
SDA_ActivationLeakyReLUDerivative, SDS_ActivationLogistic,
SDA_ActivationLogistic, SDS_ActivationLogisticDerivative,
SDA_ActivationLogisticDerivative, SDS_ActivationTanH, SDA_ActivationTanH,
SDS_ActivationTanHDerivative, SDA_ActivationTanHDerivative,
SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile,
SUF_WriteWeightsBinaryFile, SUF_ReadWeightsBinaryFile
```

void SDA_TwoLayerNCategoryNetworkFit (const SLData_t *, Pointer to training data

const SLArrayIndex t*, Pointer to categorical data Pointer to layer 1 weights SLData t*, SLData t*, Pointer to layer 2 weights SLData t*, Pointer to layer 1 pre activation Pointer to layer 1 post activation SLData t*. Pointer to layer 2 post activation SLData t*. const enum SLActivationType t, Layer 1 activation type Layer 1 activation alpha const SLData t, Layer 2 activation type const enum SLActivationType t, const SLData t, Layer 2 activation alpha const SLData t, Learning rate const SLArrayIndex t, Number of training sequences const SLArrayIndex t, Input array length Number of layer 1 nodes const SLArrayIndex t, Number of categories const SLArrayIndex t)

DESCRIPTION

This function trains a two layer neural network that supports an arbitrary number of output categories, using the provided data.

NOTES ON USE

The training data array is actually a matrix of number of columns = sample length and the number of rows = number of training sequences. Each row represents a category and the categories are indicated in the categorical data array.

The categorical data array includes one entry for each row of the training sequence matrix.

```
SDA_TwoLayer2CategoryNetworkPredict,
SDA_TwoLayerNCategoryNetworkPredict,
SDA_ActivationReLU, SDS_ActivationReLUDerivative,
SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,
SDA_ActivationLeakyReLU, SDS_ActivationLeakyReLUDerivative,
SDA_ActivationLeakyReLUDerivative, SDS_ActivationLogistic,
SDA_ActivationLeakyReLUDerivative, SDS_ActivationLogistic,
SDA_ActivationLogistic, SDS_ActivationLogisticDerivative,
SDA_ActivationLogisticDerivative, SDS_ActivationTanH, SDA_ActivationTanH,
SDS_ActivationTanHDerivative, SDA_ActivationTanHDerivative,
SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile,
SUF_WriteWeightsBinaryFile, SUF_ReadWeightsBinaryFile
```

SLArrayIndex_t SDA_TwoLayerNCategoryNetworkPredict (const SLData_t *, Pointer to data to classify

const SLData t*, Pointer to layer 1 weights Pointer to layer 2 weights const SLData t*, Pointer to layer 1 post activation SLData t*, SLData t*, Pointer to layer 2 post activation const enum SLActivationType t, Layer 1 activation type const SLData t, Layer 1 activation alpha const enum SLActivationType t, Layer 2 activation type const SLData t, Layer 2 activation alpha const SLArrayIndex t, Input array length const SLArrayIndex t, Number of layer 1 nodes Number of categories const SLArrayIndex t)

DESCRIPTION

This function uses the neural network to predict the category using the provided data. The source data array to classify is a single dimensional array that will be classified by the trained neural network.

NOTES ON USE

```
SDA_TwoLayerNCategoryNetworkFit, SDS_ActivationReLU, SDA_ActivationReLU, SDS_ActivationReLUDerivative, SDA_ActivationReLUDerivative, SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU, SDA_ActivationLeakyReLU, SDS_ActivationLeakyReLUDerivative, SDA_ActivationLeakyReLUDerivative, SDA_ActivationLeakyReLUDerivative, SDS_ActivationLogistic, SDA_ActivationLogistic, SDS_ActivationLogisticDerivative, SDA_ActivationLogisticDerivative, SDA_ActivationTanH, SDA_ActivationTanHDerivative, SDA_ActivationTanHDerivative, SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile, SUF_WriteWeightsBinaryFile
```

void SDA_TwoLayer2CategoryWithBiasesNetworkFit (const SLData_t *, Pointer to training data

const SLArrayIndex t*, Pointer to categorical data Pointer to layer 1 weights SLData t*, Pointer to layer 1 biases SLData t*, SLData t*, Pointer to layer 2 weights Pointer to layer 2 biases SLData t*. Pointer to layer 1 pre activation SLData t*. Pointer to layer 1 post activation SLData t*, const enum SLActivationType t, Layer 1 activation type Layer 1 activation alpha const SLData t, const enum SLActivationType t, Layer 2 activation type Layer 2 activation alpha const SLData t, const SLData t, Learning rate const SLArrayIndex t, Number of training sequences Input array length const SLArrayIndex t, Number of layer 1 nodes const SLArrayIndex t)

DESCRIPTION

This function trains a two layer, two category neural network using the provided data.

NOTES ON USE

The training data array is actually a matrix of number of columns = sample length and the number of rows = number of training sequences. Each row represents a category and the categories are indicated in the categorical data array.

The categorical data array includes one entry for each row of the training sequence matrix.

CROSS REFERENCE

```
SDA_TwoLayerNCategoryNetworkFit, SDA_TwoLayerNCategoryNetworkPredict, SDS_ActivationReLU, SDA_ActivationReLU, SDS_ActivationReLUDerivative, SDA_ActivationReLUDerivative, SDA_ActivationLeakyReLU, SDS_ActivationLeakyReLU, SDA_ActivationLeakyReLUDerivative, SDA_ActivationLeakyReLUDerivative, SDA_ActivationLeakyReLUDerivative, SDA_ActivationLogistic, SDS_ActivationLogisticDerivative, SDA_ActivationLogisticDerivative, SDA_ActivationLogisticDerivative, SDA_ActivationTanH, SDA_ActivationTanHDerivative, SDA_ActivationTanHDerivative, SUF_WriteWeightsWithBiasesIntegerCFile, SUF_WriteWeightsWithBiasesFloatCFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_ReadWeightsWithBiasesBinaryFile
```

SLArrayIndex_t SDA_TwoLayer2CategoryWithBiasesNetworkPredict (const SLData t*, Pointer to data to classify

SLData t*, Pointer to layer 1 weights Pointer to layer 1 biases SLData t*. Pointer to layer 2 weights SLData t*, SLData t*, Pointer to layer 2 biases Pointer to layer 1 post activation SLData t*. Pointer to output activation SLData t*. const enum SLActivationType t, Layer 1 activation type Layer 1 activation alpha const SLData t, const enum SLActivationType t, Layer 2 activation type const SLData t, Layer 2 activation alpha Classification threshold const SLData t, const SLArrayIndex t, Input array length const SLArrayIndex t) Number of layer 1 nodes

DESCRIPTION

This function uses the neural network to predict the category using the provided data. The source data array to classify is a single dimensional array that will be classified by the trained neural network.

NOTES ON USE

CROSS REFERENCE

```
SDA_TwoLayer2CategoryNetworkFit,
SDA_TwoLayerNCategoryNetworkPredict, SDS_ActivationReLU,
SDA_ActivationReLU, SDS_ActivationReLUDerivative,
SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,
SDA_ActivationLeakyReLU, SDS_ActivationLeakyReLUDerivative,
SDA_ActivationLeakyReLUDerivative, SDS_ActivationLogistic,
SDA_ActivationLogistic, SDS_ActivationLogisticDerivative,
SDA_ActivationLogisticDerivative, SDS_ActivationTanH, SDA_ActivationTanHH,
SDS_ActivationTanHDerivative, SDA_ActivationTanHDerivative,
SUF_WriteWeightsWithBiasesIntegerCFile,
SUF_WriteWeightsWithBiasesFloatCFile, SUF_WriteWeightsWithBiasesBinaryFile,
SUF_ReadWeightsWithBiasesBinaryFile
```

void SDA_TwoLayerNCategoryWithBiasesNetworkFit (const SLData_t *, Pointer to training data

const SLArrayIndex t*, Pointer to categorical data Pointer to layer 1 weights SLData t*, SLData t*, Pointer to layer 1 biases SLData t*, Pointer to layer 2 weights Pointer to layer 2 biases SLData t*. Pointer to layer 1 pre activation SLData t*. Pointer to layer 1 post activation SLData t*, Pointer to layer 2 post activation SLData t*, const enum SLActivationType t, Layer 1 activation type const SLData t, Layer 1 activation alpha const enum SLActivationType t, Layer 2 activation type const SLData t, Layer 2 activation alpha const SLData t, Learning rate const SLArrayIndex t, Number of training sequences const SLArrayIndex t, Input array length const SLArrayIndex t, Number of layer 1 nodes Number of categories const SLArrayIndex t)

DESCRIPTION

This function trains a two layer neural network that supports an arbitrary number of output categories, using the provided data.

NOTES ON USE

The training data array is actually a matrix of number of columns = sample length and the number of rows = number of training sequences. Each row represents a category and the categories are indicated in the categorical data array.

The categorical data array includes one entry for each row of the training sequence matrix.

CROSS REFERENCE

SDA TwoLayer2CategoryNetworkFit,

SDA TwoLayer2CategoryNetworkPredict,

SDA TwoLayerNCategoryNetworkPredict, SDS ActivationReLU,

SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA_ActivationLeakyReLUDerivative, SDS_ActivationLogistic,

SDA ActivationLogistic, SDS ActivationLogisticDerivative,

SDA ActivationLogisticDerivative, SDS ActivationTanH, SDA ActivationTanH,

SDS ActivationTanHDerivative, SDA ActivationTanHDerivative,

SUF WriteWeightsWithBiasesIntegerCFile,

SUF_WriteWeightsWithBiasesFloatCFile, SUF_WriteWeightsWithBiasesBinaryFile,

SUF ReadWeightsWithBiasesBinaryFile

SLArrayIndex_t SDA_TwoLayerNCategoryWithBiasesNetworkPredict (const SLData t*, Pointer to data to classify

SLData t*, Pointer to layer 1 weights Pointer to layer 1 biases SLData t*. Pointer to layer 2 weights SLData t*, SLData t*, Pointer to layer 2 biases Pointer to layer 1 post activation SLData t*. Pointer to layer 2 post activation SLData t*. const enum SLActivationType t, Layer 1 activation type Layer 1 activation alpha const SLData t, const enum SLActivationType t, Layer 2 activation type const SLData t, Layer 2 activation alpha Input array length const SLArrayIndex t, const SLArrayIndex t, Number of layer 1 nodes const SLArrayIndex t) Number of categories

DESCRIPTION

This function uses the neural network to predict the category using the provided data. The source data array to classify is a single dimensional array that will be classified by the trained neural network.

NOTES ON USE

CROSS REFERENCE

```
SDA_TwoLayerNCategoryNetworkFit, SDS_ActivationReLU, SDA_ActivationReLU, SDS_ActivationReLUDerivative, SDA_ActivationReLUDerivative, SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU, SDA_ActivationLeakyReLU, SDS_ActivationLeakyReLUDerivative, SDA_ActivationLeakyReLUDerivative, SDA_ActivationLeakyReLUDerivative, SDA_ActivationLogistic, SDS_ActivationLogisticDerivative, SDA_ActivationLogisticDerivative, SDA_ActivationLogisticDerivative, SDA_ActivationTanH, SDA_ActivationTanHDerivative, SDA_ActivationTanHDerivative, SUF_WriteWeightsWithBiasesIntegerCFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_ReadWeightsWithBiasesBinaryFile
```

SLData_t SDS_ActivationReLU (const SLData_t) Source sample

DESCRIPTION

This function implements the rectified linear (ReLU) activation function on the input sample.

NOTES ON USE

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDA ActivationLogistic, SDS ActivationLogisticDerivative,

SDA ActivationLogisticDerivative, SDS ActivationTanH, SDA ActivationTanH,

SDS ActivationTanHDerivative, SDA ActivationTanHDerivative,

SUF WavWriteFileScaled, SUF WriteWeightsIntegerCFile,

SUF WriteWeightsFloatCFile, SUF WriteWeightsBinaryFile,

SUF ReadWeightsBinaryFile

void SDA_ActivationReLU (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function implements the rectified linear (ReLU) activation function on all the samples in the array.

NOTES ON USE

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDS ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDA ActivationLogistic, SDS ActivationLogisticDerivative,

SDA ActivationLogisticDerivative, SDS ActivationTanH, SDA ActivationTanH,

SDS ActivationTanHDerivative, SDA ActivationTanHDerivative,

SUF WavWriteFileScaled, SUF WriteWeightsIntegerCFile,

SUF WriteWeightsFloatCFile, SUF WriteWeightsBinaryFile,

SUF ReadWeightsBinaryFile

SLData t SDS ActivationReLUDerivative (const SLData t) Source sample

DESCRIPTION

This function implements the derivative of the rectified linear (ReLU) activation function on the input sample.

NOTES ON USE

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

- SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,
- SDS ActivationReLU, SDA ActivationReLUDerivative,
- SDS ActivationLeakyReLU, SDA ActivationLeakyReLU,
- SDS ActivationLeakyReLUDerivative, SDA ActivationLeakyReLUDerivative,
- SDS_ActivationLogistic, SDA_ActivationLogistic,
- SDS ActivationLogisticDerivative, SDA ActivationLogisticDerivative,
- SDS ActivationTanH, SDA ActivationTanH, SDS ActivationTanHDerivative,
- SDA_ActivationTanHDerivative, SUF_WavWriteFileScaled,
- SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,
- SUF WriteWeightsBinaryFile, SUF ReadWeightsBinaryFile

void SDA_ActivationReLUDerivative (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function implements the derivative of the rectified linear (ReLU) activation function on all the samples in the array.

NOTES ON USE

CROSS REFERENCE

SDA TwoLayer2CategoryNetworkFit,

 $SDA_TwoLayerNCategoryNetworkFit, SDA_TwoLayerNCategoryNetworkPredict,$

SDS_ActivationReLU, SDA_ActivationReLU, SDS ActivationReLUDerivative,

SDS ActivationLeakyReLU, SDA ActivationLeakyReLU,

SDS ActivationLeakyReLUDerivative, SDA ActivationLeakyReLUDerivative,

SDS ActivationLogistic, SDA ActivationLogistic,

SDS ActivationLogisticDerivative, SDA ActivationLogisticDerivative,

SDS ActivationTanH, SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA ActivationTanHDerivative, SUF WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

SLData_t SDS_ActivationLeakyReLU (const SLData_t, Source sample const SLData_t)

Activation function alpha value

DESCRIPTION

This function implements the leaky rectified linear (ReLU) activation function on the input sample.

NOTES ON USE

The alpha parameter specifies the decay.

CROSS REFERENCE

SDA TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDA ActivationLeakyReLU,

SDS ActivationLeakyReLUDerivative, SDA ActivationLeakyReLUDerivative,

SDS ActivationLogistic, SDA ActivationLogistic,

SDS ActivationLogisticDerivative, SDA ActivationLogisticDerivative,

SDS ActivationTanH, SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA ActivationTanHDerivative, SUF WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

void SDA_ActivationLeakyReLU (const SLData_t *, Pointer to source array const SLData_t, Activation function alpha value SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function implements the leaky rectified linear (ReLU) activation function on all the samples in the array.

NOTES ON USE

The alpha parameter specifies the decay.

CROSS REFERENCE

SDA TwoLayer2CategoryNetworkFit,

SDA_TwoLayerNCategoryNetworkFit, SDA_TwoLayerNCategoryNetworkPredict,

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDS ActivationLeakyReLUDerivative, SDA ActivationLeakyReLUDerivative,

SDS ActivationLogistic, SDA ActivationLogistic,

SDS ActivationLogisticDerivative, SDA ActivationLogisticDerivative,

SDS ActivationTanH, SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA ActivationTanHDerivative, SUF WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

SLData_t SDS_ActivationLeakyReLUDerivative (const SLData_t, Source sample const SLData_t)

Activation function alpha value

DESCRIPTION

This function implements the derivative of the leaky rectified linear (ReLU) activation function on the input sample.

NOTES ON USE

The alpha parameter specifies the decay.

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDS_ActivationReLU, SDA_ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDA ActivationLeakyReLUDerivative,

SDS ActivationLogistic, SDA ActivationLogistic,

SDS ActivationLogisticDerivative, SDA ActivationLogisticDerivative,

SDS ActivationTanH, SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA ActivationTanHDerivative, SUF WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

void SDA_ActivationLeakyReLUDerivative (const SLData_t *, Pointer to source array

const SLData_t, Activation function alpha value SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function implements the derivative of the leaky rectified linear (ReLU) activation function on all the samples in the array.

NOTES ON USE

The alpha parameter specifies the decay.

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDS_ActivationLogistic, SDA_ActivationLogistic,

SDS ActivationLogisticDerivative, SDA ActivationLogisticDerivative,

SDS ActivationTanH, SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA ActivationTanHDerivative, SUF WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

SLData t SDS ActivationLogistic (const SLData t) Source sample

DESCRIPTION

This function implements the logistic (aka sigmoid) activation function on the input sample.

NOTES ON USE

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDA ActivationLogistic,

SDS ActivationLogisticDerivative, SDA ActivationLogisticDerivative,

SDS ActivationTanH, SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA_ActivationTanHDerivative, SUF_WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

void SDA_ActivationLogistic (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function implements the logistic (aka sigmoid) activation function on all the samples in the array.

NOTES ON USE

CROSS REFERENCE

SDA TwoLayer2CategoryNetworkFit,

 $SDA_TwoLayerNCategoryNetworkFit, SDA_TwoLayerNCategoryNetworkPredict,$

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDS_ActivationLogisticDerivative, SDA_ActivationLogisticDerivative,

SDS ActivationTanH, SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA ActivationTanHDerivative, SUF WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

SLData t SDS ActivationLogisticDerivative (const SLData t) Source sample

DESCRIPTION

This function implements the derivative of the logistic (aka sigmoid) activation function on the input sample.

NOTES ON USE

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDA ActivationLogistic, SDA ActivationLogisticDerivative, SDS ActivationTanH,

SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA_ActivationTanHDerivative, SUF_WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

void SDA_ActivationLogisticDerivative (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function implements the derivative of the logistic (aka sigmoid) activation function on all the samples in the array.

NOTES ON USE

CROSS REFERENCE

SDA TwoLayer2CategoryNetworkFit,

 $SDA_TwoLayerNCategoryNetworkFit, SDA_TwoLayerNCategoryNetworkPredict,$

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDA ActivationLogistic, SDS ActivationLogisticDerivative, SDS ActivationTanH,

SDA ActivationTanH, SDS ActivationTanHDerivative,

SDA ActivationTanHDerivative, SUF WavWriteFileScaled,

SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile,

SLData t SDS ActivationTanH (const SLData t) Source sample

DESCRIPTION

This function implements the hyperbolic tangent (TanH) activation function on the input sample.

NOTES ON USE

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDA ActivationLogistic, SDS ActivationLogisticDerivative,

SDA ActivationLogisticDerivative, SDA ActivationTanH,

 $SDS_Activation Tan HDerivative, SDA_Activation Tan HDerivative, \\$

SUF WavWriteFileScaled, SUF WriteWeightsIntegerCFile,

SUF WriteWeightsFloatCFile, SUF WriteWeightsBinaryFile,

SUF ReadWeightsBinaryFile

void SDA_ActivationTanH (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex t) Array length

DESCRIPTION

This function implements the hyperbolic tangent (TanH) activation function on all the samples in the array.

NOTES ON USE

CROSS REFERENCE

SDA TwoLayer2CategoryNetworkFit,

 $SDA_TwoLayerNCategoryNetworkFit, SDA_TwoLayerNCategoryNetworkPredict,$

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDA ActivationLogistic, SDS ActivationLogisticDerivative,

SDA ActivationLogisticDerivative, SDS ActivationTanH,

SDS ActivationTanHDerivative, SDA ActivationTanHDerivative,

SUF WavWriteFileScaled, SUF WriteWeightsIntegerCFile,

SUF WriteWeightsFloatCFile, SUF WriteWeightsBinaryFile,

SUF ReadWeightsBinaryFile

SLData_t SDS_ActivationTanHDerivative (const SLData_t) Source sample

DESCRIPTION

This function implements the derivative of the hyperbolic tangent (TanH) activation function on the input sample.

NOTES ON USE

CROSS REFERENCE

SDA_TwoLayer2CategoryNetworkFit,

SDA TwoLayerNCategoryNetworkFit, SDA TwoLayerNCategoryNetworkPredict,

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA_ActivationReLUDerivative, SDS_ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDA ActivationLogistic, SDS ActivationLogisticDerivative,

SDA ActivationLogisticDerivative, SDS ActivationTanH, SDA ActivationTanH,

SDA_ActivationTanHDerivative, SUF_WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

void SDA_ActivationTanHDerivative (const SLData_t *, Pointer to source array SLData_t *, Pointer to destination array const SLArrayIndex_t) Array length

DESCRIPTION

This function implements the derivative of the hyperbolic tangent (TanH) activation function on all the samples in the array.

NOTES ON USE

CROSS REFERENCE

SDA TwoLayer2CategoryNetworkFit,

 $SDA_TwoLayerNCategoryNetworkFit, SDA_TwoLayerNCategoryNetworkPredict,$

SDS ActivationReLU, SDA ActivationReLU, SDS ActivationReLUDerivative,

SDA ActivationReLUDerivative, SDS ActivationLeakyReLU,

SDA ActivationLeakyReLU, SDS ActivationLeakyReLUDerivative,

SDA ActivationLeakyReLUDerivative, SDS ActivationLogistic,

SDA ActivationLogistic, SDS ActivationLogisticDerivative,

SDA ActivationLogisticDerivative, SDS ActivationTanH, SDA ActivationTanH,

SDS ActivationTanHDerivative, SUF WavWriteFileScaled,

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

UTILITY FUNCTIONS (siglib.c)

OTIT	A 101	T 7	•
	Similar	• • •	rcian
יוטכי	_Siglil	, v c	i Sivii

PROTOTYPE AND PARAMETER DESCRIPTION

SLData t SUF SiglibVersion (void) Void

DESCRIPTION

This function returns the SigLib version number.

If SigLib is using floating point data then this function will return the version number as a floating point value. If SigLib is using fixed point data then this function will return the version number as a floating point value multiplied by 100.

NOTES ON USE

CROSS REFERENCE

SLError_t SUF_PrintArray (const SLData_t *, Pointer to source array const SLArrayIndex t) Array length

DESCRIPTION

This function prints the contents of the array to the console.

NOTES ON USE

To use this function the #define SIGLIB_CONSOLE_IO_SUPPORTED must be defined as a non-zero value in the file *siglib processors.h*.

CROSS REFERENCE

SUF_PrintComplexArray, SUF_PrintFixedPointArray, SUF_PrintMatrix, SUF_PrintPolar, SUF_PrintRectangular, SUF_PrintIIRCoefficients, SUF_PrintCount, SUF_PrintHigher, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

SLError_t SUF_PrintFixedPointArray (const SLArrayIndex_t *, Pointer to source array

const SLArrayIndex t)

Array length

DESCRIPTION

This function prints the contents of the array to the console.

NOTES ON USE

To use this function the #define SIGLIB_CONSOLE_IO_SUPPORTED must be defined as a non-zero value in the file *siglib_processors.h*.

CROSS REFERENCE

SUF_PrintComplexArray, SUF_PrintMatrix, SUF_PrintPolar, SUF_PrintRectangular, SUF_PrintIIRCoefficients, SUF_PrintCount, SUF_PrintHigher, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

SLError_t SUF_PrintComplexArray (const SLData_t *, Pointer to real source array

const SLData_t *, Pointer to imaginary source array const SLArrayIndex t) Array length

DESCRIPTION

This function prints the contents of the complex arrays to the console.

NOTES ON USE

To use this function the #define SIGLIB_CONSOLE_IO_SUPPORTED must be defined as a non-zero value in the file *siglib_processors.h*.

CROSS REFERENCE

SUF_PrintArray, SUF_PrintFixedPointArray, SUF_PrintMatrix, SUF_PrintPolar, SUF_PrintRectangular, SUF_PrintIIRCoefficients, SUF_PrintCount, SUF_PrintHigher, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

SLError_t SUF_PrintMatrix (const SLData_t *, Pointer to source matrix const SLArrayIndex_t, Number of rows const SLArrayIndex_t) Number of columns

DESCRIPTION

This function prints the contents of the matrix to the console.

NOTES ON USE

To use this function the #define SIGLIB_CONSOLE_IO_SUPPORTED must be defined as a non-zero value in the file *siglib processors.h*.

CROSS REFERENCE

SUF_PrintArray, SUF_PrintFixedPointArray, SUF_PrintComplexArray, SUF_PrintPolar, SUF_PrintRectangular, SUF_PrintIIRCoefficients, SUF_PrintCount, SUF_PrintHigher, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

SLError_t SUF_PrintPolar (const SLComplexPolar_s)

DESCRIPTION

This function prints the polar value, in polar and rectangular format, to the console. The polar angle is printed in radians and degrees.

NOTES ON USE

To use this function the #define SIGLIB_CONSOLE_IO_SUPPORTED must be defined as a non-zero value in the file *siglib processors.h*.

CROSS REFERENCE

SUF_PrintArray, SUF_PrintFixedPointArray, SUF_PrintComplexArray, SUF_PrintMatrix, SUF_PrintRectangular, SUF_PrintIIRCoefficients, SUF_PrintCount, SUF_PrintHigher, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

SLError_t SUF_PrintRectangular (const SLComplexRect_s)

DESCRIPTION

This function prints the rectangular value, in rectangular and polar format, to the console. The polar angle is printed in radians and degrees.

NOTES ON USE

To use this function the #define SIGLIB_CONSOLE_IO_SUPPORTED must be defined as a non-zero value in the file *siglib processors.h*.

CROSS REFERENCE

SUF_PrintArray, SUF_PrintFixedPointArray, SUF_PrintComplexArray, SUF_PrintMatrix, SUF_PrintPolar, SUF_PrintIIRCoefficients, SUF_PrintCount, SUF_PrintHigher, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

SLError_t SUF_PrintIIRCoefficients (const SLData_t *, Ptr. to filter coeffs. SLArrayIndex_t) Number of biquads

DESCRIPTION

This function prints the IIR filter coefficients to the console.

NOTES ON USE

To use this function the #define SIGLIB_CONSOLE_IO_SUPPORTED must be defined as a non-zero value in the file *siglib processors.h*.

CROSS REFERENCE

SUF_PrintArray, SUF_PrintFixedPointArray, SUF_PrintComplexArray, SUF_PrintMatrix, SUF_PrintPolar, SUF_PrintRectangular, SUF_PrintCount, SUF_PrintHigher, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

void SUF_PrintCount (const char *String)

DESCRIPTION

This function prints the string followed by an incrementing counter. This function is useful for counting how many instances of an event occur.

NOTES ON USE

CROSS REFERENCE

SUF_PrintArray, SUF_PrintFixedPointArray, SUF_PrintComplexArray, SUF_PrintMatrix, SUF_PrintPolar, SUF_PrintRectangular, SUF_PrintIIRCoefficients, SUF_PrintHigher, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

void SUF_PrintHigher (const SLData_t, Source value const SLData_t, Threshold const char *)

Source value Threshold String

DESCRIPTION

If the source is larger than the threshold then print the string. This function is useful for detecting data anomolies.

NOTES ON USE

CROSS REFERENCE

SUF_PrintArray, SUF_PrintFixedPointArray, SUF_PrintComplexArray, SUF_PrintMatrix, SUF_PrintPolar, SUF_PrintRectangular, SUF_PrintIIRCoefficients, SUF_PrintLower, SUF_PrintRectangular, SUF_PrintPolar

void SUF_PrintLower (const SLData_t, const SLData_t, const char *)

Source value
Threshold
String

DESCRIPTION

If the source is less than the threshold then print the string. This function is useful for detecting data anomolies.

NOTES ON USE

CROSS REFERENCE

SUF_PrintArray, SUF_PrintFixedPointArray, SUF_PrintComplexArray, SUF_PrintMatrix, SUF_PrintPolar, SUF_PrintRectangular, SUF_PrintIIRCoefficients, SUF_PrintHigher, SUF_PrintRectangular, SUF_PrintPolar

SLError t SUF ClearDebugfprintf (void) Void

DESCRIPTION

This function deletes the contents of the *siglib debug.log* file.

NOTES ON USE

The Debugfprintf functions are the only SigLib functions that includes any file I/O functionality. If you wish to use this function on an embedded DSP then you should ensure that your debug system supports file I/O before building the library. If your compiler or target system does not support file I/O then you will need to remove this function from the library. This can be achieved by setting the constant SIGLIB_FILE_IO_SUPPORTED to '0' in the appropriate section of the siglib processors.h file.

This function returns SIGLIB_FILE_ERROR if the debug file can not be opened and SIGLIB NO ERROR if the file open succeeds.

CROSS REFERENCE

SUF_DebugPrintf, SUF_DebugVfprintf, SUF_DebugPrintArray, SUF_DebugPrintFixedPointArray, SUF_DebugPrintMatrix, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_Debugfprintf (const char *ArgumentType, ...) Variable argument list

DESCRIPTION

This function appends debug information to the file *siglib_debug.log*. The arguments are entirely consistent with the stdio fprintf function.

NOTES ON USE

The parameter list is treated in the same way as the stdio printf function.

The Debugfprintf functions are the only SigLib functions that includes any file I/O functionality. If you wish to use this function on an embedded DSP then you should ensure that your debug system supports file I/O before building the library. If your compiler or target system does not support file I/O then you will need to remove this function from the library. This can be achieved by setting the constant SIGLIB_FILE_IO_SUPPORTED to '0' in the appropriate section of the siglib processors.h file.

This function returns SIGLIB_FILE_ERROR if the debug file can not be opened and SIGLIB NO ERROR if the file open succeeds.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintFixedPointArray, SUF_DebugPrintMatrix, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_Debugvfprintf (char *format, String format va_list) Pointer to a list of arguments

DESCRIPTION

This function appends debug information to the file *siglib_debug.log*. This function operates in the same way as SUF_Debugfprintf but accepts a pointer to a list of arguments rather than an argument list.

NOTES ON USE

The format parameter is the same as for the stdio printf function.

The Debugfprintf functions are the only SigLib functions that includes any file I/O functionality. If you wish to use this function on an embedded DSP then you should ensure that your debug system supports file I/O before building the library. If your compiler or target system does not support file I/O then you will need to remove this function from the library. This can be achieved by setting the constant <code>SIGLIB_FILE_IO_SUPPORTED</code> to '0' in the appropriate section of the <code>siglib_processors.h</code> file.

This function returns SIGLIB_FILE_ERROR if the debug file can not be opened and SIGLIB_NO_ERROR if the file open succeeds.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_DebugPrintArray, SUF_DebugPrintMatrix, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintArray (const SLData_t *, Pointer to source array const SLArrayIndex_t) Array length

DESCRIPTION

This function prints the contents of the array to the debug file *siglib debug.log*.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintFixedPointArray, SUF_DebugPrintComplexArray, SUF_DebugPrintMatrix, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintFixedPointArray (const SLArrayIndex_t *, Pointer to source array

const SLArrayIndex t)

Array length

DESCRIPTION

This function prints the contents of the array to the debug file *siglib debug.log*.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintMatrix, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintComplexArray (const SLData_t *, Pointer to real source array

const SLData_t *, Pointer to imaginary source array

const SLArrayIndex t) Array length

DESCRIPTION

This function prints the contents of the complex arrays to the debug file *siglib debug.log*.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintFixedPointArray, SUF_DebugPrintMatrix, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintComplex, SUF_DebugPrintComplex, SUF_DebugPrintComplex, SUF_DebugPrintComplex, SUF_DebugPrintComplex, SUF_DebugPrintComplexPolar

SLError_t SUF_DebugPrintComplex (const SLData_t real, const SLData_t imag)

DESCRIPTION

This function prints the rectangular value, with separate real and imaginary components, to the debug file *siglib debug.log*.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintComplexRect, SUF_DebugPrintComplexPolar

SLError t SUF DebugPrintComplexRect (const SLComplexRect s Rect)

DESCRIPTION

This function prints the rectangular value to the debug file siglib debug.log.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_DebugVfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintComplex, SUF_DebugPrintComplexPolar

SLError_t SUF_DebugPrintComplexPolar (const SLComplexPolar_s)

DESCRIPTION

This function prints the polar value to the debug file siglib debug.log.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintRectangular, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar, SUF_DebugPrintComplex, SUF_DebugPrintComplexRect

SLError_t SUF_DebugPrintMatrix (const SLData_t *, Pointer to source matrix const SLArrayIndex_t, Number of rows

const SLArrayIndex t) Number of columns

DESCRIPTION

This function prints the contents of the matrix to the debug file siglib debug.log.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintPolar (const SLComplexPolar_s)

DESCRIPTION

This function prints the polar value, in polar and rectangular format, to the debug file *siglib debug.log*. The polar angle is printed in radians and degrees.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintRectangular, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar, SUF_DebugPrintComplex, SUF_DebugPrintComplexRect, SUF_DebugPrintComplexPolar

SLError_t SUF_DebugPrintRectangular (const SLComplexRect_s)

DESCRIPTION

This function prints the rectangular value, in rectangular and polar format, to the debug file *siglib debug.log*. The polar angle is printed in radians and degrees.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintComplex, SUF_DebugPrintComplexRect, SUF_DebugPrintComplexPolar

SLError_t SUF_DebugPrintIIRCoefficients (const SLData_t *, Ptr. to filter coeffs. SLArrayIndex_t) Number of biquads

DESCRIPTION

This function prints the IIR filter coefficients to the debug file siglib debug.log.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintCount (const char *String)

DESCRIPTION

This function prints the string followed by an incrementing counter to the debug file *siglib debug.log*.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

void SUF_DebugPrintHigher (const SLData_t, Source value const SLData_t, Threshold const char *) String

DESCRIPTION

If the source is larger than the threshold then print the string. This function is useful for detecting data anomolies.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintLower, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

void SUF_DebugPrintLower (const SLData_t, Source value const SLData_t, Threshold const char *)

String

DESCRIPTION

If the source is less than the threshold then print the string. This function is useful for detecting data anomolies.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintInfo (void)

DESCRIPTION

This function prints the SigLib version information to the debug file *siglib debug.log*.

NOTES ON USE

This function is implemented as a macro and calls the function SUF Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintLine, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintLine (void)

DESCRIPTION

This function prints the source file name and line number to the debug file *siglib debug.log*.

NOTES ON USE

This function is implemented as a macro and calls the function SUF_Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintTime (void)

DESCRIPTION

This function prints the current time to the debug file siglib debug.log.

NOTES ON USE

This function is implemented as a macro and calls the function SUF Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SUF_PrintRectangular(V)

DESCRIPTION

This function prints the rectangular vector to the console.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SUF_PrintPolar(V)

DESCRIPTION

This function prints the polar vector to the console.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SUF_DebugPrintRectangular(V)

DESCRIPTION

This function prints the rectangular vector to the file siglib debug.log.

NOTES ON USE

This function is implemented as a macro and calls the function SUF Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintPolar

SUF_DebugPrintPolar(V)

DESCRIPTION

This function prints the polar vector to the file siglib debug.log.

NOTES ON USE

This function is implemented as a macro and calls the function SUF Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular

void SUF_MSDelay (const SLFixData_t Delay)

DESCRIPTION

This function delays the processing for the given number of ms.

NOTES ON USE

This function uses the ANSI C "time.h" functions. If your compiler does not provide this functionality then this function will not be compiled into the library.

The accuracy of the delay that this function generates is entirely dependent on the accuracy of the clock functionality provided by the underlying compiler / operating system.

CROSS REFERENCE

const char * SUF_StrError (const SLError_t ErrNo)

DESCRIPTION

This function delays returns a pointer to the error message associated with the error code provided to the function.

NOTES ON USE

CROSS REFERENCE

SLError_t SUF_DebugPrintMatrix (const SLData_t *, Pointer to source matrix

const SLArrayIndex_t, Number of rows const SLArrayIndex_t) Number of columns

DESCRIPTION

This function prints the contents of the matrix to the debug file siglib debug.log.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintPolar (const SLComplexPolar_s)

DESCRIPTION

This function prints the polar value, in polar and rectangular format, to the debug file *siglib debug.log*. The polar angle is printed in radians and degrees.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintRectangular, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintRectangular (const SLComplexRect_s)

DESCRIPTION

This function prints the rectangular value, in rectangular and polar format, to the debug file *siglib debug.log*. The polar angle is printed in radians and degrees.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_DebugVfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintIIRCoefficients (const SLData_t *, Ptr. to filter coeffs. SLArrayIndex_t) Number of biquads

DESCRIPTION

This function prints the IIR filter coefficients to the debug file siglib debug.log.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintCount (const char *String)

DESCRIPTION

This function prints the string followed by an incrementing counter to the debug file *siglib debug.log*.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintHigher, SUF_DebugPrintLower, SUF_Log, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

void SUF_DebugPrintHigher (const SLData_t, Source value const SLData_t, Threshold const char *) String

DESCRIPTION

If the source is larger than the threshold then print the string. This function is useful for detecting data anomolies.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintLower, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

void SUF_DebugPrintLower (const SLData_t, Source value const SLData_t, Threshold const char *) String

DESCRIPTION

If the source is less than the threshold then print the string. This function is useful for detecting data anomolies.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintIIRCoefficients, SUF_DebugPrintCount, SUF_DebugPrintHigher, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintInfo (void)

DESCRIPTION

This function prints the SigLib version information to the debug file *siglib debug.log*.

NOTES ON USE

This function is implemented as a macro and calls the function SUF Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintLine, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintLine (void)

DESCRIPTION

This function prints the source file name and line number to the debug file *siglib debug.log*.

NOTES ON USE

This function is implemented as a macro and calls the function SUF_Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SLError_t SUF_DebugPrintTime (void)

DESCRIPTION

This function prints the current time to the debug file *siglib_debug.log*.

NOTES ON USE

This function is implemented as a macro and calls the function SUF Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SUF_PrintRectangular(V)

DESCRIPTION

This function prints the rectangular vector to the console.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintPolar, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SUF_PrintPolar(V)

DESCRIPTION

This function prints the polar vector to the console.

NOTES ON USE

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_DebugPrintRectangular, SUF_DebugPrintPolar

SUF DebugPrintRectangular(V)

DESCRIPTION

This function prints the rectangular vector to the file *siglib debug.log*.

NOTES ON USE

This function is implemented as a macro and calls the function SUF Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintPolar

SUF DebugPrintPolar(V)

DESCRIPTION

This function prints the polar vector to the file siglib debug.log.

NOTES ON USE

This function is implemented as a macro and calls the function SUF Debugfprintf.

CROSS REFERENCE

SUF_ClearDebugfprintf, SUF_Debugfprintf, SUF_Debugvfprintf, SUF_DebugPrintArray, SUF_DebugPrintComplexArray, SUF_DebugPrintPolar, SUF_DebugPrintRectangular, SUF_Log, SUF_DebugPrintInfo, SUF_DebugPrintTime, SUF_PrintRectangular, SUF_PrintPolar, SUF_DebugPrintRectangular

void SUF_MSDelay (const SLFixData_t Delay)

DESCRIPTION

This function delays the processing for the given number of ms.

NOTES ON USE

This function uses the ANSI C "time.h" functions. If your compiler does not provide this functionality then this function will not be compiled into the library.

The accuracy of the delay that this function generates is entirely dependent on the accuracy of the clock functionality provided by the underlying compiler / operating system.

CROSS REFERENCE

const char * SUF_StrError (const SLError_t ErrNo)

DESCRIPTION

This function delays returns a pointer to the error message associated with the error code provided to the function.

NOTES ON USE

CROSS REFERENCE

File Input/Output Functions (file io.c)

These functions are intended to be used on systems that support file I/O.

SigLib includes a range of functions for storing data, in floating point format, to a file. The functions treat the data in blocks and there are functions for reading and writing the data. The file read functions will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

Data File Formats

The library supports single channel file I/O in the following formats:

File Extension	Description
.bin	Contiguous 16 bit binary data
.csv	Comma Separated Variable format for importing into a spreadsheet
.dat	Two column format, with header. Column 1 : sample timestamp Column 2 : data sample This format is compatible with gnuplot
.pcm	Raw PCM format data with the following options: big or little endian 8, 16, 24 or 32 bit word length
.sig	A single column of floating point numbers that represent the data sequence
.wav	16 bit multi-channel .wav file
.xmt	Xmt file format is often used by development environments for storing log data.

SLArrayIndex_t SUF_BinReadData (SLData_t *, Data array pointer FILE *, File pointer

const enum SLEndianType_t, Endian mode const SLArrayIndex t) Array length

DESCRIPTION

This function reads a block of data from a binary data file.

NOTES ON USE

This function operates in a stream oriented mode and will read successive blocks of data from the file until the end of the file is reached.

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The file must be opened prior to using this function.

The function returns the number of samples read from the file.

The endian mode options are either SIGLIB LITTLE ENDIAN OR SIGLIB BIG ENDIAN.

CROSS REFERENCE

SUF BinWriteData, SUF BinReadFile, SUF BinWriteFile,

SUF PCMReadData, SUF PCMWriteData, SUF PCMReadFile,

SUF PCMWriteFile, SUF CsvReadData, SUF CsvWriteData, SUF CsvReadFile,

SUF CsvWriteFile, SUF CsvReadMatrix, SUF CsvWriteMatrix,

SUF DatReadData, SUF DatWriteData, SUF DatReadHeader,

SUF DatWriteHeader, SUF SigReadData, SUF SigWriteData, SUF SigReadFile,

SUF SigWriteFile, SUF SigCountSamplesInFile, SUF XmtReadData,

SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,

SUF WavWriteWord, SUF WavWriteInt, SUF WavReadHeader,

SUF WavWriteHeader, SUF WavDisplayInfo, SUF WavSetInfo,

SUF WavFileLength, SUF WavReadFile, SUF WavWriteFile,

SUF WavWriteFileScaled

SLArrayIndex_t SUF_BinWriteData (const SLData_t *, Data array pointer FILE *, File pointer

const enum SLEndianType_t, Endian mode const SLArrayIndex t) Endian mode Array length

DESCRIPTION

This function writes a block of data to a binary data file.

NOTES ON USE

This function operates in a stream oriented mode and will append successive blocks of to the end of the file.

The file must be opened prior to using this function.

The function returns the number of samples written to the file.

The endian mode options are either SIGLIB LITTLE ENDIAN OR SIGLIB BIG ENDIAN.

CROSS REFERENCE

SUF BinReadData, SUF BinReadFile, SUF BinWriteFile,

SUF PCMReadData, SUF PCMWriteData, SUF PCMReadFile,

SUF PCMWriteFile, SUF CsvReadData, SUF CsvWriteData, SUF CsvReadFile,

SUF CsvWriteFile, SUF CsvReadMatrix, SUF CsvWriteMatrix,

SUF DatReadData, SUF DatWriteData, SUF DatReadHeader,

SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile,

SUF SigWriteFile, SUF SigCountSamplesInFile, SUF XmtReadData,

SUF WavReadData, SUF WavWriteData, SUF WavReadWord, SUF WavReadInt,

SUF WavWriteWord, SUF WavWriteInt, SUF WavReadHeader,

SUF WavWriteHeader, SUF WavDisplayInfo, SUF WavSetInfo,

SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,

SUF WavWriteFileScaled

SLArrayIndex_t SUF_BinReadFile (SLData_t *, Data array pointer const char *, File name const enum SLEndianType_t, Endian mode const SLArrayIndex t) Array length

DESCRIPTION

This function reads an entire file of data from a binary data file.

NOTES ON USE

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The function returns the number of samples read from the file.

The endian mode options are either SIGLIB LITTLE ENDIAN OR SIGLIB BIG ENDIAN.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex_t SUF_BinWriteFile (const SLData_t *, Data array pointer const char *, File name const enum SLEndianType_t, Endian mode const SLArrayIndex_t) Array length

DESCRIPTION

This function writes an entire array of data to a binary data file.

NOTES ON USE

The function returns the number of samples written to the file.

The endian mode options are either SIGLIB LITTLE ENDIAN OR SIGLIB BIG ENDIAN.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_CsvReadData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadData, SUF_CsvReadData, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavReadInt, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex_t SUF_BinReadData (SLData_t *, Data array pointer

FILE *, File pointer
const enum SLEndianType_t, Endian mode
const SLArrayIndex_t, Word length,
const SLArrayIndex_t) Array length

DESCRIPTION

This function reads a block of data from a raw PCM data file.

NOTES ON USE

This function operates in a stream oriented mode and will read successive blocks of data from the file until the end of the file is reached.

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The file must be opened prior to using this function.

The function returns the number of samples read from the file.

The endian mode options are either SIGLIB LITTLE ENDIAN OR SIGLIB BIG ENDIAN.

The word lengths supported are 8, 16, 24 and 32 bits.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile,
SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile,
SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData,
SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader,
SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile,
SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData,
SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,
SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader,
SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo,
SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,
SUF_WavWriteFileScaled

SLArrayIndex_t SUF_BinWriteData (const SLData_t *, Data array pointer

FILE *, File pointer
const enum SLEndianType_t, Endian mode
const SLArrayIndex_t, Word length,
const SLArrayIndex_t) Array length

DESCRIPTION

This function writes a block of data to a raw PCM data file.

NOTES ON USE

This function operates in a stream oriented mode and will append successive blocks of to the end of the file.

The file must be opened prior to using this function.

The function returns the number of samples written to the file.

The endian mode options are either SIGLIB LITTLE ENDIAN OR SIGLIB BIG ENDIAN.

The word lengths supported are 8, 16, 24 and 32 bits.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMReadFile, SUF_PCMWriteFile,
SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile,
SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData,
SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader,
SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile,
SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData,
SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,
SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader,
SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo,
SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,
SUF_WavWriteFileScaled

SLArrayIndex_t SUF_BinReadFile (SLData_t *, Data array pointer

const char *, File name
const enum SLEndianType_t, Endian mode
const SLArrayIndex_t, Word length,
const SLArrayIndex_t) Array length

DESCRIPTION

This function reads an entire file of data from a raw PCM data file.

NOTES ON USE

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The function returns the number of samples read from the file.

The endian mode options are either SIGLIB LITTLE ENDIAN OR SIGLIB BIG ENDIAN.

The word lengths supported are 8, 16, 24 and 32 bits.

CROSS REFERENCE

```
SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMWriteFile, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled
```

SLArrayIndex_t SUF_BinWriteFile (const SLData_t *, Data array pointer

const char *, File name
const enum SLEndianType_t, Endian mode
const SLArrayIndex_t, Word length,
const SLArrayIndex_t) Array length

DESCRIPTION

This function writes an entire array of data to a raw PCM data file.

NOTES ON USE

The function returns the number of samples written to the file.

The endian mode options are either SIGLIB LITTLE ENDIAN OR SIGLIB BIG ENDIAN.

The word lengths supported are 8, 16, 24 and 32 bits.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_CsvReadData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

```
SLArrayIndex_t SUF_CsvReadData (SLData_t *, Data array pointer FILE *, File pointer const SLData_t, Sample rate (Hz) const SLData_t, Number of columns (1 or 2) const SLArrayIndex t) Array length
```

DESCRIPTION

This function reads a block of data from a csv data file.

NOTES ON USE

This function operates in a stream oriented mode and will read successive blocks of data from the file until the end of the file is reached.

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The file must be opened prior to using this function.

The function returns the number of samples read from the file.

This function supports one or two column format. One column format stores the array samples in a single column. In two column format the Data is stored in time, value pairs. Column 1 is time and column 2 is value.

CROSS REFERENCE

```
SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled
```

SLArrayIndex_t SUF_CsvWriteData (const SLData_t *, Data array pointer FILE *, File pointer

const SLData_t, Sample rate (Hz)
const SLArrayIndex_t, Sample index

const SLData t, Number of columns (1 or 2)

const SLArrayIndex t) Array length

DESCRIPTION

This function writes a block of data to a csv data file.

NOTES ON USE

This function operates in a stream oriented mode and will append successive blocks of to the end of the file.

The file must be opened prior to using this function.

The function returns the number of samples written to the file.

This function supports one or two column format. One column format stores the array samples in a single column. In two column format the Data is stored in time, value pairs. Column 1 is time and column 2 is value.

The Sample index is used as an offset for the incrementing time column.

CROSS REFERENCE

SUF BinReadData, SUF BinWriteData, SUF BinReadFile,

SUF BinWriteFile, SUF PCMReadData, SUF PCMWriteData, SUF PCMReadFile,

SUF PCMWriteFile, SUF CsvReadData, SUF CsvReadFile, SUF CsvWriteFile,

SUF CsvReadMatrix, SUF CsvWriteMatrix, SUF DatReadData,

SUF DatWriteData, SUF DatReadHeader, SUF DatWriteHeader,

SUF SigReadData, SUF SigWriteData, SUF SigReadFile, SUF SigWriteFile,

SUF SigCountSamplesInFile, SUF XmtReadData, SUF WavReadData,

SUF WavWriteData, SUF WavReadWord, SUF WavReadInt,

SUF WavWriteWord, SUF WavWriteInt, SUF WavReadHeader,

SUF WavWriteHeader, SUF WavDisplayInfo, SUF WavSetInfo,

SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,

SUF WavWriteFileScaled

```
SLArrayIndex_t SUF_CsvReadFile (SLData_t *, Data array pointer const char *, File name const SLData_t, Sample rate (Hz) const SLData_t, Number of columns (1 or 2) const SLArrayIndex t) Array length
```

DESCRIPTION

This function reads an entire file of data from a csv data file.

NOTES ON USE

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The function returns the number of samples read from the file.

This function supports one or two column format. One column format stores the array samples in a single column. In two column format the Data is stored in time, value pairs. Column 1 is time and column 2 is value.

The function SUF_SigCountSamplesInFile() can be used to count the number of samples in the file before reading from the file, to allow the appropriate amount of memory to be allocated using the function SUF_VectorArrayAllocate().

CROSS REFERENCE

```
SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvWriteData, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFile, SUF_WavWriteFileScaled
```

SLArrayIndex_t SUF_CsvWriteFile (const SLData_t *, Data array pointer const char *, File name const SLData_t, Sample rate (Hz) const SLArrayIndex t, Sample index

const SLData t, Number of columns (1 or 2)

const SLArrayIndex t) Array length

DESCRIPTION

This function writes an entire array of data to a csv data file.

NOTES ON USE

The function returns the number of samples written to the file.

This function supports one or two column format. One column format stores the array samples in a single column. In two column format the Data is stored in time, value pairs. Column 1 is time and column 2 is value.

The Sample index is used as an offset for the incrementing time column.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile,
SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvReadFile, SUF_CsvReadMatrix,
SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData,
SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData,
SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile,
SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData,
SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,
SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader,
SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo,
SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,
SUF_WavWriteFileScaled

```
SLArrayIndex_t SUF_CsvReadMatrix (SLData_t **, Data array pointer const char *, File name const enum SLFileReadFirstRowFlag_t, First row flag SLArrayIndex_t *, Pointer to the number of rows read SLArrayIndex t *)

Pointer to the number of columns read
```

DESCRIPTION

This function reads a matrix from a .csv file, with option to keep or ignore the first row.

The function calculates the geometry for the array and returns the number of rows and columns using the pointers.

The .csv file is opened and this function allocates the memory for the array and returns a valid pointer through the data array pointer function parameter.

The function includes an option to keep or ignore the first row in the .csv file, using the following options:

```
SIGLIB_FIRST_ROW_IGNORE
SIGLIB_FIRST_ROW_KEEP
```

This ignore first row mode is compatible with pandas .csv file format, in which the first row is the column titles.

NOTES ON USE

The function returns the number of samples read from the file.

CROSS REFERENCE

```
SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvWriteData, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled
```

SLArrayIndex_t SUF_CsvWriteMatrix (SLData_t **, Data array pointer const char *, File name SLArrayIndex_t, Number of rows to write

SLArrayIndex_t, Number of rows to write SLArrayIndex_t) Number of columns to write

DESCRIPTION

This function writes a matrix to a .csv file.

NOTES ON USE

The function returns the number of samples written to the file.

CROSS REFERENCE

SUF WavWriteFileScaled

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvWriteData, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,

SLArrayIndex_t SUF_DatReadData (SLData_t *, Data array pointer FILE *, File pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function reads an array of floating-point data from the file.

NOTES ON USE

This function operates in a stream oriented mode and will read successive blocks of data from the file until the end of the file is reached.

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The file must be opened prior to using this function.

The function returns the number of samples read from the file.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile,
SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile,
SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_DatWriteData,
SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData,
SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile,
SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData,
SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,
SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader,
SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo,
SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,
SUF_WavWriteFileScaled

SLArrayIndex_t SUF_DatWriteData (const SLData_t *, Data array pointer

FILE *, File pointer
const SLData_t, Sample rate (Hz)
const SLArrayIndex_t, Sample index
const SLArrayIndex_t) Array length

DESCRIPTION

This function writes an array of floating-point data to the file.

NOTES ON USE

This function operates in a stream oriented mode and will append successive blocks of to the end of the file.

The sample index parameter is used to maintain the index across successive writes.

The file must be opened prior to using this function.

The function returns the number of samples written to the file.

CROSS REFERENCE

```
SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile,
SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile,
SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix,
SUF_DatReadData, SUF_DatReadHeader, SUF_DatWriteHeader,
SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile,
SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData,
SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,
SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader,
SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo,
SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,
SUF_WavWriteFileScaled
```

SLData t SUF DatReadHeader (FILE *) File pointer

DESCRIPTION

This function reads the header information from a dat file and returns the sample rate (Hz).

NOTES ON USE

The file must be opened prior to using this function.

CROSS REFERENCE

SUF WavWriteFileScaled

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,

SLArrayIndex_t SUF_DatWriteHeader (FILE *, File pointer const SLData t) Sample rate (Hz)

DESCRIPTION

This function writes the sample rate to the dat file header.

NOTES ON USE

The file must be opened prior to using this function.

The function returns the number of characters written to the file, a negative number on file error.

CROSS REFERENCE

SUF WavWriteFileScaled

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,

SLArrayIndex_t SUF_SigReadData (SLData_t *, Data array pointer FILE *, File pointer const SLArrayIndex t) Array length

DESCRIPTION

This function reads an array of floating-point data from the file.

NOTES ON USE

This function operates in a stream oriented mode and will read successive blocks of data from the file until the end of the file is reached.

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The file must be opened prior to using this function.

The function returns the number of samples read from the file.

The data is formatted in a single column.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile,
SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile,
SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix,
SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader,
SUF_DatWriteHeader, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile,
SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData,
SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,
SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader,
SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo,
SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,
SUF_WavWriteFileScaled

SLArrayIndex_t SUF_SigWriteData (const SLData_t *, File pointer const SLArrayIndex_t)

Data array pointer File pointer Array length

DESCRIPTION

This function writes an array of floating-point data to the file.

NOTES ON USE

This function writes an array of floating-point data to the file.

NOTES ON USE

This function operates in a stream oriented mode and will append successive blocks of to the end of the file.

The file must be opened prior to using this function.

The function returns the number of samples written to the file.

The data is formatted in a single column.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile,
SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile,
SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix,
SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader,
SUF_DatWriteHeader, SUF_SigReadData, SUF_SigReadFile, SUF_SigWriteFile,
SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData,
SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,
SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader,
SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo,
SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,
SUF_WavWriteFileScaled

SLArrayIndex_t SUF_SigReadFile (SLData_t *, Data array pointer const char *) File name

DESCRIPTION

This function reads an entire file of floating-point data from the file into an array.

NOTES ON USE

It is important to ensure that the array is long enough to read all of the data.

The function returns the number of samples read from the file or -1 for file error.

The data is formatted in a single column.

The function SUF_SigCountSamplesInFile() can be used to count the number of samples in the file before reading from the file, to allow the appropriate amount of memory to be allocated using the function SUF VectorArrayAllocate().

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile,
SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile,
SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix,
SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader,
SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigWriteFile,
SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData,
SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt,
SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader,
SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo,
SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile,
SUF_WavWriteFileScaled

SLArrayIndex_t SUF_SigWriteFile (const SLData_t *, Data array pointer const char *, File name const SLArrayIndex_t) Array length

DESCRIPTION

This function writes an array of floating-point data to the file.

NOTES ON USE

The data is formatted in a single column.

This function returns the number of samples written to the file or -1 for file error.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex_t SUF_SigCountSamplesInFile (const char *) File name

DESCRIPTION

This function counts the number of samples in the .sig the file.

NOTES ON USE

The function counts the number of newline characters, which will equal the number of samples because the last line of the file will always be blank.

This function can be used to count the number fo samples in SigLib .csv files, which store arrays in columns.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex_t SUF_XmtReadData (SLData_t *, Data array pointer FILE *, File pointer const SLArrayIndex_t) Array length

DESCRIPTION

This function reads an array of floating-point data from the an xmt file.

NOTES ON USE

This function operates in a stream oriented mode and will read successive blocks of data from the file until the end of the file is reached.

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The file must be opened prior to using this function.

The function returns the number of samples read from the file or -1 for file error.

CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_PCMReadData, SUF_PCMWriteData, SUF_PCMReadFile, SUF_PCMWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex_t SUF_WriteWeightsIntegerCFile (const char *, File name

const SLData_t*, Stage 1 weights const SLData_t*, Stage 2 weights

const SLArrayIndex_t, Length of stage 1 weights const SLArrayIndex_t, Length of stage 2 weights

const SLArrayIndex_t) Number of stages

DESCRIPTION

This function writes neural network weights to a C header file, as 8 bit words.

NOTES ON USE

The function returns the number of weights written to the file or zero on error.

CROSS REFERENCE

SUF_WriteWeightsFloatCFile, SUF_WriteWeightsBinaryFile, SUF_ReadWeightsBinaryFile, SUF_WriteWeightsWithBiasesIntegerCFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_ReadWeightsWithBiasesBinaryFile.

SLArrayIndex_t SUF_WriteWeightsFloatCFile (const char *, File name

const SLData_t*, Stage 1 weights const SLData_t*, Stage 2 weights

const SLArrayIndex_t, Length of stage 1 weights const SLArrayIndex_t, Length of stage 2 weights

const SLArrayIndex t) Number of stages

DESCRIPTION

This function writes neural network weights to a C header file, as floating point values.

NOTES ON USE

The function returns the number of weights written to the file or zero on error.

CROSS REFERENCE

SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsBinaryFile, SUF_ReadWeightsBinaryFile, SUF_WriteWeightsWithBiasesIntegerCFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_ReadWeightsWithBiasesBinaryFile.

SLArrayIndex_t SUF_WriteWeightsBinaryFile (const char *, File name const SLData_t*, Stage 1 weights const SLData_t *, Stage 2 weights const SLArrayIndex_t, Length of stage 1 weights const SLArrayIndex_t, Length of stage 2 weights const SLArrayIndex_t, Length of stages const SLArrayIndex_t, Number of stages const SLArrayIndex_t) Number of quantization bits

DESCRIPTION

This function writes neural network weights to a binary file, as 8 bit words.


The weights can be quantized from 1 to 32 bits before being written to the weights file. The word length saved will vary on the number of quantization bits according to the following table.

Number of Bits	Word Length Saved
1 to 8	8
9 to 16	16
17 to 32	32

NOTES ON USE

The function returns the number of weights written to the file or <= zero on error.

The binary file has the following format:



CROSS REFERENCE

SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile, SUF_ReadWeightsBinaryFile, SUF_WriteWeightsWithBiasesIntegerCFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_ReadWeightsWithBiasesBinaryFile.

DESCRIPTION

This function reads neural network weights from a binary file, reading the header to understand the exact format of the data in the file.

NOTES ON USE

The function returns the number of weights read from the file or zero on error.

The binary file has the following format:

Numb	per Numbe Of ers Q Bit	er Max Of Layer 1 s Weights	Max Lay Bia	of . yer 1 . ases .	. Mā . Lā . We	ax Of ayer N eights	Max Of Layer N Biases	
	Layer 1 Weights	Layer 1 Biases		Layer N	· -	Layer N Biases	: 	

CROSS REFERENCE

SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile, SUF_WriteWeightsBinaryFile, SUF_WriteWeightsWithBiasesIntegerCFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_ReadWeightsWithBiasesBinaryFile.

SLArrayIndex_t SUF_WriteWeightsWithBiasesIntegerCFile (const char *, File name

const SLData_t*, Stage 1 weights const SLData_t*, Stage 1 biases const SLData_t *, Stage 2 weights const SLData_t *, Stage 2 biases

const SLArrayIndex_t, Number of input nodes

const SLArrayIndex_t, Number of hidden layer nodes const SLArrayIndex_t) Number of output categories

DESCRIPTION

This function writes neural network weights and biases to a C header file, as 8 bit words.

NOTES ON USE

The function returns the number of weights and biases written to the file or zero on error.

CROSS REFERENCE

SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile, SUF_WriteWeightsBinaryFile, SUF_ReadWeightsBinaryFile, SUF_WriteWeightsWithBiasesFloatCFile, SUF_WriteWeightsWithBiasesBinaryFile, SUF_ReadWeightsWithBiasesBinaryFile.

SLArrayIndex_t SUF_WriteWeightsWithBiasesFloatCFile (const char *, File name

const SLData_t*, Stage 1 weights const SLData_t*, Stage 1 biases const SLData_t *, Stage 2 weights const SLData_t *, Stage 2 biases

const SLArrayIndex_t, Number of input nodes

const SLArrayIndex_t, Number of hidden layer nodes const SLArrayIndex_t) Number of output categories

DESCRIPTION

This function writes neural network weights and biases to a C header file, as floating point values.

NOTES ON USE

The function returns the number of weights and biases written to the file or zero on error.

CROSS REFERENCE

SUF WriteWeightsIntegerCFile, SUF WriteWeightsFloatCFile,

SUF WriteWeightsBinaryFile, SUF ReadWeightsBinaryFile,

SUF WriteWeightsWithBiasesIntegerCFile,

SUF WriteWeightsWithBiasesBinaryFile, SUF ReadWeightsWithBiasesBinaryFile.

SLArrayIndex_t SUF_WriteWeightsWithBiasesBinaryFile (const char *, File name

const SLData_t*,	Stage 1 weights
const SLData_t*,	Stage 1 biases
const SLData_t *,	Stage 2 weights
const SLData_t *,	Stage 2 biases
4 CT A T 1	NI 1 C' 4

const SLArrayIndex_t, Number of input nodes

const SLArrayIndex_t, Number of hidden layer nodes const SLArrayIndex_t, Number of output categories const SLArrayIndex_t) Number of quantization bits

DESCRIPTION

This function writes neural network weights and biases to a binary file, as 8 bit words.

The weights and biases can be quantized from 1 to 32 bits before being written to the file. The word length saved will vary on the number of quantization bits according to the following table.

Number of Bits	Word Length Saved
1 to 8	8
9 to 16	16
17 to 32	32

NOTES ON USE

The function returns the number of weights and biases written to the file or <= zero on error.

The binary file has the following format:

+		+		+		+	-	 +-		+		-+-	 -+		-+
	Number	1	Number	1	Max Of				Max Of	1	Layer		1	Layer	
	Of		Of		Layer 1	_			Layer N		1			N	
-	Layers		Q Bits	1	Weights	3			Weights		Weights		-	Weights	
		1				4		 					 		_+

CROSS REFERENCE

SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile, SUF_WriteWeightsBinaryFile, SUF_ReadWeightsBinaryFile, SUF_WriteWeightsWithBiasesIntegerCFile, SUF WriteWeightsWithBiasesFloatCFile, SUF ReadWeightsWithBiasesBinaryFile.

SLArrayIndex_t SUF_ReadWeightsWithBiasesBinaryFile (const char *, File name const SLData_t*, Stage 1 weights const SLData_t*, Stage 1 biases const SLData_t *, Stage 2 weights const SLData_t *) Stage 2 biases

DESCRIPTION

This function reads neural network weights and biases from a binary file, reading the header to understand the exact format of the data in the file.

NOTES ON USE

The function returns the number of weights and biases read from the file or zero on error.

The binary file has the following format:

Number Number Max Of . Max Of Layer . Layer Of Of Layer 1 . Layer N 1 . N	+
Of Of Laver 1 Laver N 1 . N	
Layers Q Bits Weights . Weights Weights . Weights	- 1

CROSS REFERENCE

```
SUF_WriteWeightsIntegerCFile, SUF_WriteWeightsFloatCFile, SUF_WriteWeightsBinaryFile, SUF_ReadWeightsBinaryFile, SUF_WriteWeightsWithBiasesIntegerCFile, SUF_WriteWeightsWithBiasesFloatCFile, SUF_WriteWeightsWithBiasesBinaryFile.
```

WAV File Functions

The following functions are used to read and write .wav files. These functions require a structure of type SLWavFileInfo s, which is defined as :

This structure can be accessed directly from any program however functions are supplied for reading and writing to it.

Note: when writing a stream to a .wav file it is first necessary to write the header using the function wav_write_header() then the data can be written to the file. Once all of the data has been written and the exact number of samples is known then the number of samples can be re-written to the header and the function wav_write_header should be called again.

For multi-channel wav files, the data is returned with the channels multiplexed into a single array so the array length must equal the

NumberOfSamples*NumberOfChannels. The SigLib DSP library includes functions for multiplexing and de-multiplexing data streams.

SLArrayIndex_t SUF_WavReadData (SLData_t *, Destination data pointer FILE *, File pointer const SLWavFileInfo_s, Wave file information structure const SLArrayIndex t) Array length

FUNCTION DESCRIPTION

This function reads an array of wave file data from the file.

NOTES ON USE

This function operates in a stream oriented mode and will read successive blocks of data from the file until the end of the file is reached.

This function will zero pad any buffers if there is not sufficient data in the remainder of the file to fill the buffer.

The function returns the number of samples read from the file.

The file must be opened prior to using this function.

Returns wavInfo.NumberOfSamples = 0 on error.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

void SUF_WavWriteData (const SLData_t *, Source data pointer FILE *, File pointer const SLWavFileInfo_s, Wave file information structure const SLArrayIndex_t) Array length

FUNCTION DESCRIPTION

This function writes an array of wave file data to the file.

NOTES ON USE

This function operates in a stream oriented mode and will append successive blocks of to the end of the file.

The file must be opened prior to using this function.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile,
SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile,
SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix,
SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader,
SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile,
SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData,
SUF_WavReadData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord,
SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader,
SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile,
SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex_t SUF_WavReadWord (FILE *)

File pointer

FUNCTION DESCRIPTION

This function reads a word of data from a wave file.

The file must be opened prior to using this function.

NOTES ON USE

The function returns the word read from the file.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex_t SUF_WavReadInt (FILE *) File pointer

FUNCTION DESCRIPTION

This function reads an integer word of data from a wave file.

NOTES ON USE

The function returns the integer word read from the file.

The file must be opened prior to using this function.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

void SUF_WavWriteWord (const SLArrayIndex_t, Data word to write FILE *)

File pointer

FUNCTION DESCRIPTION

This function writes a word of data to the file.

NOTES ON USE

The file must be opened prior to using this function.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

void SUF_WavWriteInt (const SLArrayIndex_t, Long data word to write FILE *)

File pointer

FUNCTION DESCRIPTION

This function writes a SLArrayIndex t word of data to the file.

NOTES ON USE

The file must be opened prior to using this function.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLWavFileInfo s SUF WavReadHeader (FILE *) File pointer

FUNCTION DESCRIPTION

This function reads the header information from a wave file and returns it in the SLWavFileInfo s structure.

NOTES ON USE

The file must be opened prior to using this function.

Returns wavInfo.NumberOfSamples = 0 on error.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

void SUF_WavWriteHeader (FILE *, const SLWavFileInfo s)

File pointer

Wave file information structure

FUNCTION DESCRIPTION

This function writes the header information to a wave file from the SLWavFileInfo_s structure.

NOTES ON USE

The file must be opened prior to using this function.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

void SUF WavDisplayInfo (const SLWavFileInfo s) Wave file information structure

FUNCTION DESCRIPTION

This function prints out the header information stored in the SLWavFileInfo_s structure.

NOTES ON USE

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLWavFileInfo_s SUF_WavSetInfo (const SLArrayIndex_t, Sample rate (Hz)

const SLArrayIndex_t, Number of samples const SLArrayIndex_t, Number of channels const SLArrayIndex_t, Word length const SLArrayIndex_t, Bytes per sample const SLArrayIndex_t) Data format

FUNCTION DESCRIPTION

This function generates a SLWavFileInfo s structure from the supplied data.

NOTES ON USE

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavFileLength, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex_t SUF_WavFileLength (const char *) Filename

FUNCTION DESCRIPTION

This function returns the number of samples in the .wav file.

NOTES ON USE

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavReadFile, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLWavFileInfo_s SUF_WavReadFile (SLData_t *, Destination data pointer const char *) Filename

FUNCTION DESCRIPTION

This function reads the contents of the .wav file data from the file.

NOTES ON USE

It is important to ensure that the destination array is long enough to receive the data.

Returns the SLWavFileInfo_s structure for the data read, with the number of samples read set to -1 on file read error.

FUNCTION CROSS REFERENCE

SUF_BinReadData, SUF_BinWriteData, SUF_BinReadFile, SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile, SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix, SUF_DatReadData, SUF_DatWriteData, SUF_DatReadHeader, SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile, SUF_SigWriteFile, SUF_SigCountSamplesInFile, SUF_XmtReadData, SUF_WavReadData, SUF_WavWriteData, SUF_WavReadWord, SUF_WavReadInt, SUF_WavWriteWord, SUF_WavWriteInt, SUF_WavReadHeader, SUF_WavWriteHeader, SUF_WavDisplayInfo, SUF_WavSetInfo, SUF_WavFileLength, SUF_WavWriteFile, SUF_WavWriteFileScaled

SLArrayIndex t SUF WavWriteFile (SLData t*, Data pointer

const char *, Filename

const SLWavFileInfo s, Wave file information structure

const SLArrayIndex t) Array length

FUNCTION DESCRIPTION

This function writes the contents of the array to the .wav file.

NOTES ON USE

Returns the number of samples written, -1 for file open error.

FUNCTION CROSS REFERENCE

SUF BinReadData, SUF BinWriteData, SUF BinReadFile,

SUF BinWriteFile, SUF CsvReadData, SUF CsvWriteData, SUF CsvReadFile,

SUF_CsvWriteFile, SUF_CsvReadMatrix, SUF_CsvWriteMatrix,

SUF DatReadData, SUF DatWriteData, SUF DatReadHeader,

SUF_DatWriteHeader, SUF_SigReadData, SUF_SigWriteData, SUF_SigReadFile,

SUF SigWriteFile, SUF SigCountSamplesInFile, SUF XmtReadData,

SUF WavReadData, SUF WavWriteData, SUF WavReadWord, SUF WavReadInt,

SUF WavWriteWord, SUF WavWriteInt, SUF WavReadHeader,

SUF WavWriteHeader, SUF WavDisplayInfo, SUF WavSetInfo,

SUF WavFileLength, SUF WavReadFile, SUF WavWriteFileScaled

SLArrayIndex t SUF WavWriteFileScaled (SLData t*, Data pointer

const char *, Filename

const SLWavFileInfo s, Wave file information structure

const SLArrayIndex t) Array length

FUNCTION DESCRIPTION

This function writes the contents of the array to the .wav file. The output is scaled to a magnitude of 32767.0

NOTES ON USE

Returns the number of samples written, -1 for file open error.

FUNCTION CROSS REFERENCE

SUF BinReadData, SUF BinWriteData, SUF BinReadFile,

SUF_BinWriteFile, SUF_CsvReadData, SUF_CsvWriteData, SUF_CsvReadFile,

SUF CsvWriteFile, SUF CsvReadMatrix, SUF CsvWriteMatrix,

SUF DatReadData, SUF DatWriteData, SUF DatReadHeader,

SUF DatWriteHeader, SUF SigReadData, SUF SigWriteData, SUF SigReadFile,

SUF SigWriteFile, SUF SigCountSamplesInFile, SUF XmtReadData,

SUF WavReadData, SUF WavWriteData, SUF WavReadWord, SUF WavReadInt,

SUF WavWriteWord, SUF WavWriteInt, SUF WavReadHeader,

SUF WavWriteHeader, SUF WavDisplayInfo, SUF WavSetInfo,

SUF WavFileLength, SUF WavReadFile, SUF WavWriteFile

UTILITY MACROS (siglib macros.h)

The following section details the SigLib utility macros located in the file *siglib macros.h.* These macros are only available in applications written in C/C++.

Macros to handle the fact that ANSI C rounds floating point numbers down to fixed point equivalents. These macros also allow for floating point not quantizing to perfect integer values

Macros that return type SLData t

SDS_RoundDown(a) Round down to fixed point number SDS_RoundUp(a) Round up to fixed point number SDS_RoundToNearest(a) Round to nearest fixed point number

Macros that return type SLArrayIndex t

SAI_RoundDown(a)

SAI_RoundUp(a)

SAI RoundToNearest(a)

Round down to fixed point number
Round up to fixed point number
Round to nearest fixed point number

Macros that output type SLFixData t

SDS_Odd(a) Returns 1 if a is odd, 0 otherwise SDS_Even(a) Returns 1 if a is even, 0 otherwise

SDS PowerOfTwo(a) Returns 1 if a is a power of 2, 0 otherwise

SDS_Abs(a) Returns the absolute value of a, using C function fabs()
SDS_Absolute(a) Returns the absolute value of a, using macro function
SDS_Sign(a) Returns the sign of 'a' - either SIGLIB_POSITIVE or

SIGLIB NEGATIVE

Macros that output type SLArrayIndex_t

SAI_Odd(a) Returns 1 if a is odd, 0 otherwise SAI Even(a) Returns 1 if a is even, 0 otherwise

SAI PowerOfTwo(a) Returns 1 if a is a power of 2, 0 otherwise

SAI_Absolute(a) Returns the absolute value of a, using macro function SAI_Sign(a) Returns the sign of 'a' - either SIGLIB_POSITIVE or

SIGLIB_NEGATIVE

SAI_Log2(a) Returns the log₂ of a. This macro is very useful for

calculating log₂ of a radix-2 FFT length

SAI Log3(a) Returns the log4 of a. This macro is very useful for

calculating log4 of a radix-4 FFT length

SAI NumberOfElements(a) Returns the number of elements in the array

SAI_FftLength(a)

SAI_FftLength4(a)

SAI_FftLengthLog2(a)

SAI_FftLengthLog2(a)

SAI_FftLengthLog4(a)

Returns the FFT length for a given log2(FFT length)

Returns the log2(FFT length) for a given FFT length

Returns the log4(FFT length) for a given FFT length

SDS_BitTest(a,Mask) Returns 1 if all bits in mask equal '1', returns 0

otherwise

SDS BitMask(a) Sets 'a' LSBs to 1 and the remainder to 0

Macros that output type SLData t

SDA_Average(a,b) Another name for the SDA_Mean function

SDA Subtract(a,b,c,d) Subtract a constant value from the data using the

SDA Add function

SDS_SumAndDifference(a,b,sum,diff) Returns the sum and difference of the

two values

 a^2 SDS Square(a) Inverse hyperbolic sine SDS Asinh(a) Swap two floating point data values SDS Swap(a,b) SDS Swap2(a,b) Swap two fixed point data values SDS Sort2(a,b) Sort 2 values, places max. result in a, uses SDS Swap2 SDS Sort3(a,b,c) Sort 3 values, places max. result in a, uses SDS Sort2 Sort 4 values, places max. result in a, uses SDS Sort2 SDS Sort4(a,b,c,d)SDS Sort5(a,b,c,d,e) Sort 5 values, places max. result in a, uses SDS Sort2 SDS Sort6(a,b,c,d,e,f) Sort 6 values, max. result in a, uses SDS Sort2

SDA_SignalGenerateRamp (Address, Peak, Offset, PhasePointer, ArrayLength)
Generate a ramp signal with values from -signal amplitude to +signal
amplitude and given offset. For further information, please refer to the
function SDA_SignalGenerate.

To generate a positive ramp from 0 to Max level use:

To generate a positive ramp from 0 to -Max level use: SDA_SigGenRamp (p_Dst, -Max/2, SIGLIB_FILL, -Max/2, SIGLIB_ZERO, ArrayLength)

- SDA_SignalGenerateImpulse(Address, Peak, ArrayLength)

 Generate a single impulse at location 0 and "Peak" amplitude. For further information, please refer to the function SDA_SignalGenerate.
- SDA_SignalGenerateKronekerDeltaFunction (Address, Peak, Delay, ArrayLength)
 Generate a single impulse at the location specified by the Delay parameter and "Peak" amplitude. For further information, please refer to the function SDA SignalGenerate.
- SDA_SignalGenerateWhiteNoise(Address, Peak, Fill_Add, ArrayLength)
 Generate a bi-polar normally distributed random white noise signal with
 "Peak" amplitude.
- SDS_SignalGenerateWhiteNoise(Address, Peak, Fill_Add)
 Generate a single sample of a bi-polar normally distributed random white noise signal with "Peak" amplitude.
- SDA_SignalGenerateGaussianNoise(Address, Fill_Add, Variance, pPhase, pValue, ArrayLength)

Generate a bi-polar Gaussian distributed random white noise signal with "Peak" amplitude.

- SDS_SignalGenerateGaussianNoise(Address, Fill_Add, Variance, pPhase, pValue)
 Generate a single sample of a bi-polar Gaussian distributed random white noise signal with "Peak" amplitude.
- SDA_Ones(Address, ArrayLength) Fill array with 1.0.
- SDA_Zeros(Address, ArrayLength)
 Fill array with zeros.
- SDA_Operate(IPointer1, IPointer2, OPointer, Operation, ArrayLength)

Perform a standard mathematical operation (+, -, *, /) between the source array elements in piece wise mode. If the input pointers reference matrices then the array length should be the product of the two dimensions.

SCV_Real(r) Return the real component of a complex number SCV_Imaginary(i) Return the imaginary component of a complex number

SCV_CopyMacro(IVect, OVect) Copy the complex vector from IVect to OVect.

SUF_Halt () Halts execution of the application at the current location.

SUF_Log (*pStr*) This function will print the string pointed to by *pStr* to the *siglib_debug.log* file provided that the C constant <code>SIGLIB_ENABLE_LOG</code> has been <code>#defined</code>. <code>SIGLIB_ENABLE_LOG</code> can be defined either in the source file you wish to debug or on the compilation command line.

Some of the SigLib functions call the standard library functions, for example sin, cos, log, malloc, free etc. All of these stdio functions are accessed through SigLib macros and this allows ease of portability between platforms, processors and between different word lengths on a particular processor (e.g. between sin() or sinf()). The required stdio function can be chosen, for a particular application, by changing the appropriate definition in *siglib.h*. The complete list of SigLib stdio macros is:

SDS_Sin	Sine	SDS_Log	Natura	ıl logarithm
SDS_Cos	Cosine	SDS_Log10	Logari	ithm base 10
SDS_Tan	Tangent	SDS_10Log10	10 * L	og_{10}
SDS_Asin	Arc-sine	SDS_20Log10	20 * L	\log_{10}
SDS_Acos	Arc-cosine	SDS_Log2Macro	Log2	without error
SDS_Atan	Arc-tangent	detection		
SDS_Atan2	Arc-tangent 2	SDS_VoltageTodBmM	lacro	Linear voltage
SDS_Sinh	Hyperbolic Sine	to dBm		
SDS_Cosh	Hyperbolic Cosine	SDS_dBmToVoltageM	lacro	dBm to linear
SDS_Tanh	Hyperbolic Tangent	voltage		
SDS_Sqrt	Square root	SDS_VoltageTodBMa	cro	Linear voltage
SDS_Abs	Absolute number	gain to dBm		
SDS_Exp	Exponential	SDS_dBToVoltageMa	cro	dB gain to
SDS_Pow	Raise to power	linear voltage		
SDS_Floor	Floor function	SDS_PowerTodBMacr	0	Linear power
SDS_Ceil	Ceiling function	gain to dBm		
SDS_Fmod	Floating point	SDS_dBToPowerMacr	0	dB gain to
modulo function		linear power		
SDS Nearest	Round to nearest			

SigLib also includes C/C++ macro functions for the allocation and de-allocation of memory arrays. The macros are described below.

The parameter 'N' defines the number of elements in the array.

The parameter 'M' defines the period of the sinusoid being generated.

<pre>SUF_VectorArrayAllocate (N) SUF_FftCoefficientAllocate (N)</pre>	Allocate an array of SLData_t type Allocate a radix-2 FFT coefficient array of SLData t
<pre>SUF_FftCoefficientAllocate4 (N)</pre>	Allocate a radix-4 FFT coefficient array of SLData t
SUF_FftCoefficientAllocate (N)	Allocate an FIR extended filter state array of SLData t
SUF_FirExtendedArrayAllocate (N)	Allocate an IIR filter state array of SLData_t
SUF_IirStateArrayAllocate (N)	Allocate an IIR coefficient array of SLData_t
SUF_IirCoefficientAllocate (N)	Allocate a carrier look up table of SLData_t type for the given carrier
<pre>SUF_AmCarrierArrayAllocate (CarrierFreq, SampleRate)</pre>	frequency and sample rate (Hz) Allocate a fast sin/cos look up table of SLData_t type
<pre>SUF_FastSinCosArrayAllocate (M)</pre>	Allocate a quick sin/cos look up table of SLData_t type
<pre>SUF_QuickSinCosArrayAllocate (M)</pre>	Allocate a QAM carrier array of SLData t type
SUF_QamCarrierArrayAllocate	Allocate a QPSK carrier array of

```
(M)
                                      SLData t type
SUF QpskCarrierArrayAllocate
                                      Allocate an array of
(M)
                                      SLComplexRect stypes
SUF ComplexRectArrayAllocate
                                      Allocate an array of
(N)
                                      SLComplexPolar stypes
SUF ComplexPolarArrayAllocate
                                      Allocate an array of type
(N)
                                      SLMicrohone t types
SUF MicrophoneArrayAllocate
(N)
                                      Allocate an array of type
                                      SLArrayIndex t types
                                      Allocate an array of type
SUF IndexArrayAllocate (N)
                                      SLFixData ttypes
SUF FixDataArrayAllocate (N)
SUF DifferentialEncoderArrayAl
                                      Differential encoder/decoder look-up-
locate[wordLength]
                                      tables
SUF MemoryFree (SLData t *)
                                      Free the memory array
```

SigLib defines the following macros to translate frequencies to bin numbers and vice versa:

SUF_BinNumberToFrequency(Bin, FFTLength, SampleRate) Convert the FFT bin number to the appropriate frequency. The frequency is returned as type SLData t.

SUF_BinNumberToFrequency2 (Bin, InvFFTLength, SampleRate) Convert the FFT bin number to the appropriate frequency. The frequency is returned as type SLData_t. Note this macro takes the inverse of the FFT length as a parameter and hence avoids the division operation.

SUF_FrequencyToBinNumber (Freq, FFTLength, SampleRate) Convert the frequency to the appropriate FFT bin number. The FFT bin number is returned as type SLArrayIndex t.

SUF_FrequencyToBinNumber2 (Freq, FFTLength, InvSampleRate) Convert the frequency to the appropriate FFT bin number. The FFT bin number is returned as type <code>SLArrayIndex_t</code>. Note this macro takes the inverse of the sample rate (Hz) as a parameter and hence avoids the division operation.

SigLib defines the following macros to provide the width of the data elements:

```
SIGLIB_DATA_WORD_LENGTH
SIGLIB_ARRAY_INDEX_WORD_LENGTH
SIGLIB_FIX_WORD_LENGTH
SIGLIB_FIX_WORD_LENGTH

Returns the length of an SLArrayIndex_t word
Returns the length of an SLFixData_t word
```

SigLib defines the following null pointers, these should be used when a parameter is not required because of the selected mode of operation:

SIGLIB_NULL_FLOAT_PTR SIGLIB_NULL_FIX_PTR	Null pointer to SLData_t Null pointer to SLArrayIndex_t
SIGLIB_NULL_COMPLEX_RECT_PTR SIGLIB_NULL_COMPLEX_POLAR_PTR	Null pointer to SLComplexRect_s Null pointer to SLComplexPolar_s

SigLib, Numerix-DSP and Digital Filter Plus are trademarks of Delta Numerix all other trademarks acknowledged.

Delta Numerix are continuously increasing the functionality of SigLib and reserve the right to alter the product at any time.