ModusToolbox™ Software Training Level 3 – Wi-Fi



Chapter 1: Introduction

After completing this chapter, you will understand what this class is, what topics are covered, the overall class objectives, and you will understand what is contained in the ModusToolbox™ for Connectivity and ModusToolbox™ for Wi-Fi run-time software.

Table of contents

1.1	What is this class?	. 2
1.2	Prerequisites	. 2
1.3	Required software	. 7
1.4	Development kits	. :
1.4.1	PSoC™ 6 kit	
1.4.2	Arduino compatible shield	
1.5	Introduction to ModusToolbox™ for Connectivity and ModusToolbox™ for Wi-Fi run-time software	. !
1.6	ModusToolbox™ for Connectivity and ModusToolbox™ for Wi-Fi run-time software library descriptions	. (
1.6.1	Wi-Fi Core FreeRTOS lwIP MbedTLS	
1.6.2	HTTP	
1.6.3	MQTT	-
1.6.4	Over-The-Air (OTA) Bootloading	
1.6.5	Bluetooth®/Bluetooth® LE Hosted Stack (BTSTACK and FreeRTOS Wrapper)	8
1.6.6	Low Power Assistant (LPA)	8
1.7	Path Lengths	. 8
1.8	Documentation	. 9
1.9	Code examples	1(
1.10	Exercises	12
Exercise	1: Download Class Material	

Document conventions

Convention	Usage	Example		
Courier New	Displays code and text commands	<pre>CY_ISR_PROTO(MyISR); make build</pre>		
Italics	Displays file names and paths	sourcefile.hex		
[bracketed, bold]	Displays keyboard commands in procedures	[Enter] or [Ctrl] [C]		
Menu > Selection	Represents menu paths	File > New Project > Clone		
Bold	Displays GUI commands, menu paths and selections, and icon names in procedures	Click the Debugger icon, and then click Next .		



1.1 What is this class?

This is a class to teach how to use Wi-Fi in ModusToolbox™ applications. The descriptions and exercises use a PSoC™ 6 MCU as a host to a CYW43012 device.

After completing this class, you should be able to create and debug Wi-Fi applications using ModusToolbox™ tools. This class will introduce you to several concepts including: the network stack, sockets, TLS, HTTP, MQTT, and interacting with Amazon Web Services (AWS).

1.2 Prerequisites

This class assumes that you know the basics of using the ModusToolbox™ ecosystem, how to interact with PSoC™ 6 MCUs including using peripherals, and how to program a PSoC™ 6 device. If you are unfamiliar with these topics, the following classes should be reviewed first:

- ModusToolbox[™] Software Training Level 1 Getting Started
- ModusToolbox™ Software Training Level 2 PSoC™ MCUs

1.3 Required software

ModusToolbox[™] tools

You should already have ModusToolbox[™] tools installed on your system. If not, refer to the ModusToolbox[™] Software Training Level 1 Getting Started class or visit the ModusToolbox[™] Software website for instructions.



1.4 Development kits


For this class we will use the following development kits:

1.4.1 **PSoC™** 6 kit

CY8CKIT-062S2-43012 - A PSoC™ 6-2M MCU and a CYW43012 Wi-Fi + Bluetooth® Combo

Note:

If you are taking this course on your own, you will need two of these kits to complete some of the exercises in later chapters. If you are taking this course in a classroom setting, you will only need one of these kits.




- 1. Power LED (LED1)
- 2. KitProg3 USB connector (J6)
- 3. PSoC[™] 6 MCU VDD power selection jumper (J14)
- 4. KitProg3 programming mode selection button (SW3)
- 5. PSoC™ 6 MCU VDD current measurement jumper (J15)
- PSoC™ 6 MCU VDDIO2 and CYW43012 VDDIO power selection jumper (J16)
- 7. PSoC™ 6 MCU VDDIO0 current measurement jumper (J19)
- 8. External power supply VIN connector (J5)
- 9. PSoC™ 6 MCU user buttons (SW2 and SW4)
- 10. Potentiometer connection jumper (J25)
- 11. Potentiometer (R1)
- 12. Arduino-compatible power header (J1)
- 13. PSoC[™] 6 MCU reset button (SW1)
- 14. PSoC™ 6 MCU debug and trace header (J12)
- 15. PSoC[™] 6 MCU program and debug header (J11)
- 16. Arduino Uno R3-compatible I/O headers (J2, J3, and J4)
- 17. CAPSENSE™ slider (SLIDER) and buttons (N0 and BTN1)
- 18. PSoC™ 6 MCU VDDIO2 current measurement jumper (J18)


- 19. CYW43012 VDDIO current measurement jumper(J17)
- 20. Infineon serial NOR flash memory (S25FL512S, U3)
- 21. Infineon PSoC™ 6 (2M) MCU with CYW43012 Carrier Module (CY8CMOD-062S2-43012, MOD1)
- 22. CYW43012 based Murata Type 1LV module
- 23. Wi-Fi/Bluetooth® antenna
- 24. PSoC™ 6 MCU
- 25. Infineon serial Ferroelectric RAM (CY15B104QSN, U4)
- 26. CYW43012 VBAT current measurement jumper (J8)
- 27. CYW43012 VBAT power selection jumper (J9):
- 28. PSoC™ 6 MCU user LEDs (LED8 and LED9)
- 29. PSoC™ 6 I/O header (J21, J22, J24)
- 30. RGB LED (LED5)
- 31. Wi-Fi/Bluetooth® GPIO header (J23)
- 32. PSoC™ 6 USB device connector (J7)
- 33. Optional USB Host power supply header (J10)
- 34. KitProg3 status LED (LED2)
- 35. KitProg3 (PSoC™ 5LP MCU) programmer and debugger (CY8C5868LTI-LP039, U2)
- 36. MicroSD Card holder (J20) (on back of board)



1.4.2 Arduino compatible shield

CY8CKIT-028-TFT





- 1. 2.4-inch TFT display
- 2. Motion Sensor (U1)
- 3. Ambient Light Sensor (Q1)
- 4. PDM microphone (U2)
- 5. Arduino compatible I/O headers (J2, J3, J4)
- 6. Arduino compatible power header (J1)

- 7. TFT display power control load switch (U4)
- 8. TFT display connector (J5)
- 9. Audio CODEC (U3)
- 10. Audio Jack (J6)
- 11. Audio Jack Selection (OMTP/AHJ) Switch (SW1)



1.5 Introduction to ModusToolbox™ for Connectivity and ModusToolbox™ for Wi-Fi run-time software

In addition to the PSoC[™] 6, the development kit used in this course has a CYW43012 connectivity device that supports both Wi-Fi and Bluetooth[®]. Let's face it, most electronic devices these days have some sort of wireless connectivity. In this chapter we will focus on the Wi-Fi piece of the puzzle. The connection between the PSoC[™] 6 and the connectivity device is done using SDIO for Wi-Fi (or SPI on some devices) and an HCI UART interface for Bluetooth[®]. Furthermore, wireless co-existence between Wi-Fi and Bluetooth[®] is supported so both functions can operate simultaneously.

Infineon has several cloud solutions depending on how you decide to manage your connected devices. The ModusToolbox™ for Connectivity solution was built for customers with their own cloud device management back end, whether hosted on AWS, Google, Azure, AliCloud, or any other cloud infrastructure.

If you are using Amazon Web Services IoT Core for your device management, then you may prefer to use our more customized AWS IoT Core solution. Likewise, if you are using Arm Pelion for your device management, you may prefer our customized Arm Pelion solution. Note that if you are using Amazon's cloud services for storage but not their IoT Core device management, ModusToolbox™ for Connectivity is a great solution for you, as you will see in some of the upcoming exercises.

ModusToolbox™ for Wi-Fi provides the low-level features such as the Wi-Fi Connection Manager and Wi-Fi Host Driver while ModusToolbox™ for Connectivity provides a Secure Socket layer and support for application layer cloud protocols such as MQTT and HTTP.


While ModusToolbox™ for Wi-Fi and ModusToolbox™ for Connectivity provide core functionality including connectivity, security, firmware upgrade support, and application layer protocols like MQTT, they are also flexible so you can modify or extend them to match your needs.



1.6 ModusToolbox™ for Connectivity and ModusToolbox™ for Wi-Fi run-time software library descriptions

The run-time software is distributed as a collection of libraries that work together to help you easily get your IoT device up and running on the Cloud. Some of the libraries were written by Infineon, while others are industry standard open source libraries. As you have seen, these can be pulled into a ModusToolbox[™] application easily by using the Library Manager.

The complete set of run-time software libraries fit together with the core PSoC™ 6 libraries as shown below. The Connectivity and Wi-Fi libraries are shown in orange and yellow, respectively.



Most libraries are available as GitHub repositories. These "repos" contain source files, readme files, and documentation such as an API reference.

The following subsections describe the ModusToolbox™ for Connectivity and ModusToolbox™ for Wi-Fi libraries.

1.6.1 Wi-Fi Core FreeRTOS lwIP MbedTLS

This library is a collection of the libraries that any Wi-Fi application will need. By adding this library to an application, you get:

- <u>Wi-Fi Host Driver (WHD)</u> Embedded Wi-Fi Host Driver that provides a set of APIs to interact with Cypress WLAN chips.
- WHD BSP Integration Functions to simplify connecting the WHD library to a BSP containing a WLAN chip.



- <u>Wi-Fi Connection Manager</u> Makes Wi-Fi connections easier and more reliable by implementing Wi-Fi Protected Setup (WPS) to simplify the secure connection to a Wi-Fi access point (AP) and by providing a monitoring service to detect problems and keep connections alive.
- <u>FreeRTOS</u> FreeRTOS kernel, distributed as standard C source files with configuration header file, for use with the PSoC™ 6 MCU.
- <u>CLib Support</u> This is a support library that provides the necessary hooks to make C library functions such as malloc and free thread safe. This implementation is specific to FreeRTOS.
- <u>Connectivity Utilities</u> A collection of general-purpose middleware utilities including JSON parser, linked list functions, string functions, network helper functions, logging functions, and error code utilities. Header files are provided in the library to include the required set of functions. For example, the network helper functions are included via the header file nw_helper.h while JSON parsing is included via the header file cy json parser.h.
- <u>lwIP</u> A Lightweight open-source TCP/IP stack. lwIP stands for "lightweight IP".
- <u>lwIP FreeRTOS Integration</u> Contains FreeRTOS dependencies needed by the Lightweight opensource TCP/IP stack
- <u>lwIP Network Interface Integration</u> An integration layer that links the lwIP network stack with the underlying Wi-Fi host driver (WHD) and Ethernet driver. This functionality is included via the header file cy network mw core.h.
- <u>MbedTLS</u> An open source, portable, easy to use, readable and flexible SSL library, that has cryptographic capabilities.
- <u>MbedTLS Acceleration</u> Contains MbedTLS hardware accelerated basic cryptography functions.
- <u>RTOS Abstraction Layer</u> Minimalistic RTOS-agnostic kernel interface allowing middleware to be used in multiple ecosystems, such as Arm's Mbed OS and Amazon's FreeRTOS. It is not recommended for use by the end application the user should write code for their RTOS of choice such as FreeRTOS.
- <u>Secure Sockets</u> Network abstraction APIs for underlying lwIP network stack and MbedTLS security library. The secure sockets library eases application development by exposing a socket like interface for both secure and non-secure socket communication.
- WPA3 External Supplicant Supports WPA3 SAE authentication using HnP (Hunting and Pecking Method) and H2E (Hash to Element Method) using RFC.
- Predefined configuration files for FreeRTOS, lwIP and MbedTLS for typical embedded IoT use-cases.

The Library Manager name for the Wi-Fi Middleware Core library is *wifi-core-freertos-lwip-mbedtls*. It includes the other libraries listed above automatically.

1.6.2 HTTP

This is actually two separate libraries – one for HTTP servers and one for HTTP clients. The libraries enable both secure (https) and non-secure (http) modes of connection. They support RESTful HTTP methods: HEAD, GET, PUT, and POST.

The Library Manager names for these libraries are http-client and http-server.

1.6.3 MQTT

This library includes the open source <u>AWS IoT device SDK embedded C</u> library plus some glue to get it to work seamlessly in ModusToolbox[™] for Connectivity. It is based on MQTT client v3.1.1 and supports QoS levels 0 and 1. Both secure and non-secure TCP connections can be used.

The Library Manager name for this library is *mgtt*.



1.6.4 Over-The-Air (OTA) Bootloading

The OTA toolkit library is an extensible solution based on MCUBoot that can be modified to work with any third-party or custom IoT device management software. With it you can rapidly create efficient and reliable OTA schemes. It currently supports OTA over MQTT and HTTP.

The Library Manager name for this library is OTA.

1.6.5 Bluetooth®/Bluetooth® LE Hosted Stack (BTSTACK and FreeRTOS Wrapper)

In addition to the great Wi-Fi support in ModusToolbox[™] for Wi-Fi, you can use the ModusToolbox[™] for Bluetooth[®] functionality in the 43xxx combo device to enable Bluetooth[®] LE for your device. For example, it can easily be used to enable Wi-Fi onboarding so that you can safely and quickly connect your device to a Wi-Fi network using Bluetooth[®] LE to select the network and enter the password. One of the ModusToolbox[™] code examples will show you that exact thing.

In the Library Manager, you can include the *bluetooth-freertos* library which will include the BTSTACK library automatically.

1.6.6 Low Power Assistant (LPA)

The LPA is a library and associated settings in the Device Configurator that allow you to configure a PSoC[™] 6 Host and WLAN (Wi-Fi / Bluetooth® Radio) device for optimized low-power operation. With LPA you can achieve the most aggressive power budgets by placing the host device into sleep or deep sleep modes while networks are quiet or when there is traffic that can be handled by the connectivity device.

The Library Manager name for this library is LPA.

1.7 Path Lengths

Windows has a path length limitation of 260 characters. This isn't usually a problem, but some of the libraries used for IoT functionality have very long paths. Therefore, you may run into a build error if the path to your application is too long. For example, the HTTP client and MQTT libraries include the aws-iot-device-sdk-embedded-C library as a dependency. When that library is included in an application, the build directory will have a file in this location:

 $\label{lem:continuous} $$\operatorname{container_checked.d}$ CY8CKIT-062S2-43012\Debug\ext\mtb_shared\aws-iot-device-sdk-embedded-C\20 2103.00\libraries\aws\ota-for-aws-iot-embedded-sdk\source\dependency\3rdparty\tinycbor\src\cborencoder_close_container_checked.d$

That's 209 characters, so only 51 characters are left for the path to the application (which by default is C:\Users\<user_name>\mtw\<application_name>.

If you see build errors indicating that file cannot be found in the build directory, it is likely due to the path length. You can shorten the name of the application or move your workspace to a location with fewer characters in the path (e.g. *C*:\mtw).



1.8 Documentation

The best place to find documentation for ModusToolbox™ for Connectivity and ModusToolbox™ for Wi-Fi is inside the individual libraries themselves. You can look on GitHub directly, you can open the documentation from a library that you have downloaded, or you can open the documentation for a downloaded library from inside the Eclipse IDE for ModusToolbox.

For example, here is the *README.md* for the Wi-Fi Host Driver library as seen on GitHub:

∃ README.md

Wi-Fi Host Driver (WHD)

Overview

The WHD is an independent, embedded Wi-Fi Host Driver that provides a set of APIs to interact with Infineon WLAN chips. The WHD is an independent firmware product that is easily portable to any embedded software environment, including popular IoT frameworks such as Mbed OS and Amazon FreeRTOS. Therefore, the WHD includes hooks for RTOS and TCP/IP network abstraction layers.

The release notes detail the current release. You can also find information about previous versions.

Supported bus interface

Interface	4343W	43438	4373	43012	43439	43907
SDIO	0	0	0	0	0	
SPI	0	0			О	
M2M						0

WPA3 AP mode support


Security	4343W	43438	4373	43012	43439	43907
WPA3			0		0	

More information

- · Wi-Fi Host Driver API Reference Manual and Porting Guide
- · Wi-Fi Host Driver Release Notes
- Infineon Technologies



Once you have downloaded a library, you can go to the *docs* directory or you can open it from the Quick Panel inside Eclipse. In either case, you will typically find an *api_reference_manual.html* file with full descriptions of the API.



1.9 Code examples

It is always easier to start with an existing application rather than starting with a blank slate. Infineon provides a wealth of code examples for just that reason.

All Infineon code examples are hosted on GitHub so ultimately that's where you will find them, but there are a few ways to get there:

- 1. Inside the project creator tool look under the Wi-Fi category.
- 2. Directly from the Infineon GitHub website
- 3. From the Infineon website

The first method is recommended if you want to create an application from the code example since it handles all of the BSP and library downloads automatically.

Of course, you can learn a ton by looking at the source code and reading the comments from the examples. On top of that, every Infineon code example has a README.md file that explains the example, tells you which kits it will run on, shows how to set it up, explains how to use it, and explains the design. The README.md is always a good starting point.



You will need a markdown reader to get the most out of the README.md documents. There are plugins for most web browsers as well as an extension for VS Code. Markdown will also show inside the Eclipse IDE, but some things may be formatted strangely since Eclipse doesn't support everything that Markdown can do.

WLAN low power

This code example demonstrates the low-power operation of a host MCU and a WLAN device using the network activity handlers provided by the low power assistant (LPA) middleware.

The code example connects to a configured network. After connecting to the network successfully, the example configures the WLAN device in a power-save mode, suspends the network stack, and puts the host MCU in a wait state. During this wait state, the host MCU enters a low-power state and wakes up on any network activity detected on the MAC interface.

View this README on GitHub.

Provide feedback on this code example.

Requirements

- ModusToolbox™ software v3.0 or later (tested with v3.0)
- Board support package (BSP) minimum required version: 4.0.0
- Programming language: C
- Associated parts: All PSoC™ 6 MCU parts, AIROC™ CYW43012 Wi-Fi & Bluetooth® combo chip, AIROC™
 CYW4343W Wi-Fi & Bluetooth® combo chip

Supported toolchains (make variable 'TOOLCHAIN')

- GNU Arm® embedded compiler v10.3.1 (GCC_ARM) Default value of TOOLCHAIN
- Arm® compiler v6.16 (ARM)
- IAR C/C++ compiler v9.30.1 (IAR)

Supported kits (make variable 'TARGET')

PSoC™ 6 Wi-Fi Bluetooth® prototyping kit (CY8CPROTO-062-4343W) - Default value of TARGET




1.10 Exercises

Exercise 1: Download Class Material

In this exercise, you will download the class material from GitHub. This will give you local access to the manuals and projects.

1.	Use a Web browser to go to the class GitHub site at: https://github.com/Infineon/training-modustoolbox-level3-wifi
2.	Click the Code button.



3. Click the Download ZIP button to download the repo to your local disk to a convenient location and then unzip it.

Note: If you are familiar with Git operations, you can clone the repository to your local disk using the URL instead of downloading a ZIP fie if you prefer.

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Published by Infineon Technologies AG 81726 Munich, Germany

© 2022 Infineon Technologies AG. All Rights Reserved.

IMPORTANT NOTICE

The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics ("Beschaffenheitsgarantie").

With respect to any examples, hints or any typical values stated herein and/or any information regarding the application of the product, Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights of any third party.

In addition, any information given in this document is subject to customer's compliance with its obligations stated in this document and any applicable legal requirements, norms and standards concerning customer's products and any use of the product of Infineon Technologies in customer's applications.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

For further information on the product, technology, delivery terms and conditions and prices please contact your nearest Infineon Technologies office (www.infineon.com).

WARNINGS

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.