General

Action	Description
	Close the radio complete, save all settings and favorits.
	Lock and Power-Save mode. There is near no CPU usage and the backlight is turn off. Also all buttons are holded so that you can't push them accidentally when you have the GCW in your bag or else.
+	Run radio in background. Restart the program to close the radio.
L	Roll the menu to the left.
R	Roll the menu to the right.

0 Main

Action	Description
	Tune 0.1 MHz down.
+	Tune 0.1 MHz up.
+	Volume up. This means the fm volume control.
+	Volume down. This means the fm volume control, to.
A +	Tune 1 MHz down.
A +	Tune 1 MHz up.
₿⊹■	Tune 0.01 MHz down.
₿₊■	Tune 0.01 MHz up.
•	Grow frequenz analysing bar. If the bar diagramm is calculate before.

GCW-Radio Controls

&	Shrink frequenz analysing bar.
SELECT	Add current frequenz to favorit list.
START	Switch between speaker and headphone output.

1 Favorits

Action	Description
+	Select list entry.
A	Tune to the selected favorit frequenzy.
8	Edit selected favorit station name. Use D-Pad to select characters and A button to enter the input. Press B to chancel.
•	Move the selectet station up in the list.
₿	Move the selectet station down in the list.
SELECT	Delete selectet entry from the list.

2 Scan

Action	Description
-	Select scanning mode. (Scan next station or scan all stations)
-	Select scan config values.
A	Increase value by 1 (0.1) / run action
₿	Decrease value by 1 (0.1)
•	Increase value by 10 (1.0)
X	Decrease value by 10 (1.0)
START	Start the scanning process