

ALIAS SHALL NOT BE LIABLE FOR TECHNICAL OR EDITORIAL ERRORS OR OMISSIONS CONTAINED HEREIN NOR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE FURNISHING, PERFORMANCE OR USE OF THIS MATERIAL.

It is the policy of Alias Limited to enforce any and all rights relating to protection of this information. The information contained in this document is proprietary in nature and may not be reproduced, copied or divulged in whole or in part without the prior written consent of Alias Limited. This document has been provided pursuant to the terms of a contract or confidentiality agreement. Unauthorised distribution or disclosure of its contents is a violation of that contract or agreement and persons doing so may be liable for penalties as provided by law.

COPYRIGHT

Copyright © 1991-2002 Alias Limited.

1 Stuart Road, Manor Park, Runcorn, Cheshire, WA7 1TS, United Kingdom.

Telephone: +44 (0) 1928 579311

Fax: +44 (0) 1928 579389 E-mail: info@alias.ltd.uk Web: www.alias.ltd.uk

TRADEMARKS

I-Sketch, I-Sketch Classic, I-Sketch Field, I-Convert, I-Export, I-Run, I-View, I-View CAD, I-Tools, I-Data Integrator, PLANTGEN, SPOOLGEN and ISOGEN are registered trademarks of Alias Limited.

All other trademarks are the property of their respective owners.



	Negative Text Records -1 to -199 records marked with an asterisk can be used with the 'Frame Text Positioning' facility	
Isogen Record	<u>Description</u>	PCF Equivalent
-1	Overflow Text record	
-2	Spare	
-3	Text input for drawing Title Block	Data in TITLE-BLOCK file
-4	Special SKEY input	Data in SPECIAL-INSTRUMENTS file
-5	Used by CADC for PDMS Version Number	
-6 *	Pipeline Name	PIPELINE-REFERENCE
-7 *	Spool Prefix Identifier	SPOOL-PREFIX
-8 *	Revision Identifier	REVISION
-9 *	Project Name	PROJECT-IDENTIFIER
-10 *	Batch Reference / Plant Area Name	BATCH or AREA
-11 *	Piping Specification Name	PIPING-SPEC
-12 *	Pipeline Nominal Pressure Class / Rating	NOMINAL-CLASS or
		NOMINAL-RATING
-13 *	Line Type Identifier	PIPELINE-TYPE
-14 *	IDF creation Date(or system Date – see option switch6)	DATE-DMY
-15 *	Insulation Specification Name	INSULATION-SPEC
-16 *	Tracing Specification Name	TRACING-SPEC
-17 *	Painting Specification Name	PAINTING-SPEC
-18 *	Specific Gravity of Pipeline contents	SPECIFIC-GRAVITY
-19 *	Pipeline Temperature	PIPELINE-TEMP
-20	Component Material Item Code	ITEM-CODE
-21	Component Material Description	DESCRIPTION
-22	Component Tag / Name	TAG or NAME
-23 *	Standard Bend Radius for Pipeline	BEND-RADIUS in Pipe Header Data
-24	Bend Radius for individual bend	BEND-RADIUS in Component Data
-25 *	System Isometric Name	SYSTEM-ISOMETRIC-REFERENCE



-26	Change of Piping Specification	PIPING-SPEC
-27	BOP (Bottom of Pipe) Elevation value	BOP-ELEVATION
-28 *	User Defined Spool Name	SPOOL-IDENTIFIER
-29 *	Equipment / Vessel Trim Name	EQUIPMENT-TRIM-REFERENCE
-30	Pipeline Connection to another Pipeline (CONT ON)	END-CONNECTION-PIPELINE
-31	Pipeline Connection to Equipment Item (CONN TO)	END-CONNECTION-EQUIPMENT
-32	Pipeline termination at Open End (OPEN)	END-POSITION-OPEN
-33	Pipeline termination at Closed End (CLOSED)	END-POSITION-CLOSED
-34	Pipeline termination at Vent location (VENT)	END-POSITION-VENT
-35	Pipeline termination at Drain location (DRAIN)	END-POSITION-DRAIN
-36	Undefined termination - Only Co-ordinates output	END-POSITION-NULL
-37	User defined Message on a component	MESSAGE
-38	Pipeline Split Point indicator (-38 ++++)	ISO-SPLIT-POINT
-39	Unique Component Identifier	UNIQUE-COMPONENT-IDENTIFIER
-40	Compound Direction message on a component	DIRECTION
-41 *	User Defined Miscellaneous Specification Name	MISC-SPEC1
-42 *	User Defined Miscellaneous Specification Name	MISC-SPEC2
-43 *	User Defined Miscellaneous Specification Name	MISC-SPEC3
-44 *	User Defined Miscellaneous Specification Name	MISC-SPEC4
-45 *	User Defined Miscellaneous Specification Name	MISC-SPEC5
-46	Gearbox Orientation Direction Message	GEARBOX
-47	Break In Point Identification Name	BIP-IDENTIFIER
-48	1) System Isometric Drawing Split Point Indicator	SYSTEM-SPLIT
	2) Equipment Trim Isometric Split Point Indicator	EQUIPMENT-TRIM-SPLIT
-49	Induction Bend Start indicator + Identifier	INDUCTION-START
-50	Induction Bend End indicator	INDUCTION-END
-51	Used for Isogen internal processing	
-52	Used for Isogen internal processing	
-53	Used for Isogen internal processing	
-54	Used for Isogen internal processing	



-55	1) FFI use	
	-55 ++++ FFI Split Point - No Weld	
	-55 ++++ 1 WS FFI Split Point - with Site Weld	
	-55 ++++ 1 WF FFI Split Point - with Field Fit Weld	
	-55 ++++ 1 WO FFI Split Point - with Offshore Weld	
	-55 SS28901 FFI Identifier (System Name + Program	m generated suffix)
-55	2) STORK Division I.D. and Sequence No. system	
	-55 12345 Sequence Number (Limited to five digits)	
	-55 **A Division Identifier	
-55	3) General Use	
	Bypass Closure (-55 ++++B)	BYPASS-CLOSURE-POINT
	-55 ++++E Open End marker	
	-55 B01 BIT Identifier	
-55	4) Pipeline Start (-55 ++++START)	START-CO-ORDS
-56	Used for Isogen internal processing	
-57	Used for Isogen internal processing	
-58	Used for Isogen internal processing	
-59	Used for Isogen internal processing	
-60	Used for Isogen internal processing	
-61 *	COMPIPE Area Identification record (Redundant)	COMPIPE-AREA
-62 *	COMPIPE Drawing Number record (Redundant)	COMPIPE-DRAWING-NO
-63 *	COMPIPE Description record (Redundant)	COMPIPE-DESCRIPTION
-64	Weight	WEIGHT
-65	Spare	
-66	Isometric Drawing Output Plotfile Name	OUTPUT-FILE-NAME
-67	Weld Number - User Defined or Repeat	REPEAT-WELD-IDENTIFIER
-68	Weld Specification Name	WELD-SPEC
-69	Repeat Part Number (V8.5.0+)	REPEAT-PART-NUMBER



-70	User Defined Message (Output in Square Ended	MESSAGE-SQUARE
	Box)	
-71	User Defined Message (Output in Diamond Ended	MESSAGE-POINTED
	Box)	
-72	User Defined Message (Output in Round Ended	MESSAGE-ROUND
	Box)	
-73	User Defined Message (Output in Triangular Box)	MESSAGE-TRI ANGLE
-74	User Defined Message (Output in Diamond shaped	MESSAGE-DIAMOND
	Box)	
-75	User Defined Message (Output in a Circle)	MESSAGE-CIRCLE
-76	Port Reference for Multi-port component	PORT-POINT?
-77	Spare	
-78	Detailed Sketch Filename	DETAIL-SKETCH-IDENTIFIER
	Information Note Filename	
-79	Remark Identification Number	1) WELD-REMARK-NUMBER
	N.B. Remarks may be attached to either a WELD	2) COMPONENT-REMARK-NUMBER
	or a COMPONENT	
-80	Component - Optional Material Description record	Any User Defined Word
-81	Component - Optional Material Description record	Any User Defined Word
-82	Component - Optional Material Description record	Any User Defined Word
-83	Component - Optional Material Description record	Any User Defined Word
-84	Component - Optional Material Description record	Any User Defined Word
-85	Component - Optional Material Description record	Any User Defined Word
-86	Component - Optional Material Description record	Any User Defined Word
-87	Component - Optional Material Description record	Any User Defined Word
-88	Component - Optional Material Description record	Any User Defined Word
-89	Component - Optional Material Description record	Any User Defined Word
-90 *	Pipeline Isometric Drawing sequence Number	PIPELINE-DRAWING-SEQUENCE- NUMBER
-91 *	Spool Sheet Isometric Drawing sequence Number	SPOOL-DRAWING-SEQUENCE- NUMBER
-92 *	Client Drawing Name	CLIENT-DRAWING-IDENTIFIER
-93	Highest Site Assembly Identification Number	HIGHEST-ASSEMBLY-NUMBER



	(Repeatability function)	
-94	Highest Spool Number (Repeatability function)	HIGHEST-SPOOL-NUMBER
-95	Highest Unique Identifier (Repeatability function)	HIGHEST-UNIQUE-IDENTIFIER
-96	Highest Pipe Support Weld Number used (Repeatability function)	HIGHEST-SUPPORT-WELD-NUMBER
-97	Highest Weld Number used (Repeatability function)	HIGHEST-WELD-NUMBER
-98	Highest Part Number used (Repeatability function)	HIGHEST-PART-NUMBER
-99	Pipeline Isometric or Spool Isometric Re-plotting indicator	REPLOT
-100	IDF or PCF Input filename	
-101	Drawing Frame (Backing Sheet) Input filename	DRAWING-FRAME
-102	Isometric Output Plotfile Name Prefix characters	PLOTFILE-PREFIX
-103	User Defined Symbols Input filename	BINARY-SYMBOLS
-104	Material Control Output filename	MATERIAL-CONTROL
-105	Messages Output filename	MESSAGE
-106	PDMS Error Message file	
	(CADC only - not used by Alias)	
-107	PDMS 'Resume' identifier	
	(CADC only - not used by Alias)	
-108	Printed Material List Output filename	PRINTED-MATERIAL-LIST
-109	Centreline Length Summary Output filename	CENTRELI NE-LENGTH
-110	Centreline Length / Insulation Output filename	CENTRELINE/INSULATION-LENGTH
-111	Stressing Interface Output filename	
-112	Pipe Support Summary Output filename (Overwrite) (alternative to -114 file)	SUPPORT-SUMMARY
-113	Pipe Support Data Output filename - Binary	
-114	Pipe Support Information Output filename (alternative to -112 file)	SUPPORT-INFORMATION-FILE
-115	Materials - Sheet Output filename (Overwrite)	MATERIAL/SHEET-IDENTIFICATION
-116	Cut Pipe List Summary Output filename (Overwrite) (alternative to -129 file)	CUT-LIST-SUMMARY
-117	Repeatability Return Output filename	REPEATABILITY-RETURN



-118	COMPIPE - LINE and MTO filenames (Redundant)	
-119	Font Input filename (CADC only - not used by Alias)	
-120	Welding Definition File Input filename	WELDING-DEFINITION
-121	Material List Remarks Input filename	REMARKS
-122	Materials Definition File Input filename	MATERIAL-LIST-DEFINITION
-123	Data Definition File Input filename	DRAWING-DEFINITION
-124	Detail Sketch directory Input name	DETAIL-SKETCH-DIRECTORY
-125	Weld Summary Output filename (Append) (alternative to -126 file)	WELD-SUMMARY-APPEND
-126	Weld Summary Output filename (Overwrite) (Is alternative to -125 file)	WELD-SUMMARY-OVERWRITE
-127	Bending Information Output filename (Append) (Is alternative to -128 file)	BENDING-FILE-APPEND
-128	Bending Information Output filename (Overwrite) (Is alternative to -127 file)	BENDING-FILE-OVERWRITE
-129	Cut List Summary Output filename (Append) (Is alternative to -116 file)	CUT-LIST-SUMMARY-APPEND
-130 *	General Weld Prefix	WELD-PREFIX-GENERAL
-131 *	Fabrication Weld Prefix	WELD-PREFIX-FABRICATION
-132 *	Erection (Site / Field) Weld Prefix	WELD-PREFIX-ERECTION
-133 *	Offshore Weld Prefix	WELD-PREFIX-OFFSHORE
-134 *	Fabrication Support Weld Prefix	SUPPORT-WELD-PREFIX-
		FABRICATION
-135 *	Erection Support Weld Prefix	SUPPORT-WELD-PREFIX-ERECTION
-136 *	Offshore Support Weld Prefix	SUPPORT-WELD-PREFIX-OFFSHORE
-137	Spare	
-138	Spare	
-139	Spare	
-140	Function Definition Input filename	FUNCTION-DEFINITION
-141	Component Information Input filename	COMPONENT-INFORMATION
-142	Insulation Weights Input filename	INSULATION-WEIGHT
-143	Specific Gravity Input filename	SPECIFIC-GRAVITY
-144	C of G Output filename	WEIGHT/COFG-SUMMARY-APPEND



-145	C of G Output filename	WEIGHT/COFG-SUMMARY- OVERWRITE
-146	Bolting Information Input filename	BOLT-INFORMATION-FILE
-147	STORK - Data Output Transfer file to	REGISTRATION-INFORMATION-FILE
	ACCESS system	
-148	STORK - Data Output Transfer file to	FABRICATION-INFORMATION-FILE
	ACCESS system	
-149	STORK - Data Output Transfer file to	ERECTION-INFORMATION-FILE
	ACCESS system	
-150	Traceability Output filename	TRACEABILITY-FILE
-151	STORK - Attribute storage file	ATTRIBUTE-FILE
-152	Text Font Definition Input filename	FONT-INFORMATION-FILE
-153	Bulk Materials Output filename	BULK-MATERIAL-LIST
-154	Spool Information Output filename	SPOOL-INFORMATION-FILE
-155	Site Weld Information Output filename	SITE-WELD-INFORMATION-FILE
-156	Pipeline Attributes Input filename	PIPELINE-ATTRIBUTES-FILE
-157	Heat Treatment/NDE Input filename	HEATTREATMENT/NDE-FILE
-158	Drawing Information Cross Reference Output	DRAWING-CROSS-REF-FILE
	filename	
-159	Bending database file	BENDING-DATABASE_FILE
-160	Bending report file	BENDING-REPORT-FILE
-161	Ascii symbols file	ASCII-SYMBOLS
-162	Drawing report file	DRAWING-REPORT-FILE
-163	Site assembly file (append type)	SITE-ASSEMBLY-FILE-APPEND
-164	Site assembly file (overwrite type)	SITE-ASSEMBLY-FILE-OVERWRITE
-165	Pipe Cutting file	PIPE-CUTTING-FILE
-170	Spool Attribute 1	SPOOL-ATTRIBUTE1
-171	Spool Attribute 2	SPOOL-ATTRIBUTE2
-172	Spool Attribute 3	SPOOL-ATTRIBUTE3
-173	Spool Attribute 4	SPOOL-ATTRIBUTE4
-174	Spool Attribute 5	SPOOL-ATTRIBUTE5



-175	Spool Attribute 6	SPOOL-ATTRIBUTE6
-176	Spool Attribute 7	SPOOL-ATTRIBUTE7
-177	Spool Attribute 8	SPOOL-ATTRIBUTE8
-178	Spool Attribute 9	SPOOL-ATTRIBUTE9
-179	Spool Attribute 10	SPOOL-ATTRIBUTE10
-180	Weld Attribute 1	WELD-ATTRIBUTE1
-181	Weld Attribute 2	WELD -ATTRIBUTE2
-182	Weld Attribute 3	WELD -ATTRIBUTE3
-183	Weld Attribute 4	WELD -ATTRIBUTE4
-184	Weld Attribute 5	WELD -ATTRIBUTE5
-185	Weld Attribute 6	WELD -ATTRIBUTE6
-186	Weld Attribute 7	WELD -ATTRIBUTE7
-187	Weld Attribute 8	WELD -ATTRIBUTE8
-188	Weld Attribute 9	WELD -ATTRIBUTE9
-189	Weld Attribute 10	WELD -ATTRIBUTE10
-190	Component Attribute 1	COMPONENT-ATTRIBUTE1
-191	Component Attribute 2	COMPONENT -ATTRIBUTE2
-192	Component Attribute 3	COMPONENT -ATTRIBUTE3
-193	Component Attribute 4	COMPONENT -ATTRIBUTE4
-194	Component Attribute 5	COMPONENT -ATTRIBUTE5
-195	Component Attribute 6	COMPONENT -ATTRIBUTE6
-196	Component Attribute 7	COMPONENT -ATTRIBUTE7
-197	Component Attribute 8	COMPONENT -ATTRIBUTE8
-198	Component Attribute 9	COMPONENT -ATTRIBUTE9
-199	Component Attribute 10	COMPONENT -ATTRIBUTE10



	AText Records
-201	E
-202	N
-203	W
-204	S
-205	EL +
-206	EL -
-207	NS (set to ? to automatically determine the format used for outputting the nominal size message)
-208	CONN. TO
-209	CONT. ON
-210	F
-211	G
-212	В
-213	SPINDLE
-214	MM
-215	REDUCING FLANGE
-216	OFFSET
-217	MITRE
-218	LOBSTER
-219	REINFORCED
-220	LEFT LOOSE
-221	FFW
-222	FALL
-223	DEGREES (left blank)
-224	:
-225	% (left blank)
-226	GRAD
-227	PER M
-228	PER FT



-229	SCREWED END
-230	VENT (used in conjunction with -34 record)
-231	BEND
-232	SPEC
-233	C
-234	START
-235	COMMENCE
-236	S
-237	п
-238	·
-239	DRAIN (used in conjunction with -35 record)
-240	(used in conjunction with -32 record)
-241	(used in conjunction with -33 record)
-242	(used in conjunction with -36 record)
-243	(used with reducers IE - FLAT)
-244	UP
-245	DOWN
-246	NORTH
-247	SOUTH
-248	EAST
-249	WEST
-250	DATE
-251	PROJECT NO.
-252	BATCH REF
-253	PIPING SPEC
-254	ISS
-255	DRG
-256	OF
-257	SPL
-258	JAN
-259	FEB
-260	MAR



-261	APR
-262	MAY
-263	JUN
-263 -264	JUL
-264 -265	AUG
	SEP SEP
-266	
-267	OCT
-268	NOV
-269	DEC
-270	THERMAL INSULATION SPEC
-271	TRACING SPEC
-272	PAINTING SPEC
-273	LG
-274	default is blank - used as delimeter for spool i.d.
-275	SWEPT TEE
-276	CONT. FROM
-277	ORIFICE FLANGE
-278	DIAL FACE
-279	L
-280	TAPPING
-281	TAIL
-282	WINDOW
-283	FLAT (used when reducer flat in skew)
-284	TEE BEND
-285	RATING FLANGE
-286	Default is blank - used for screwed end message on erection fittings)
-287	ORIENTATION DIRECTION
-288	PIPE
-289	MATL
-290	INSUL
-291	TRACE
-292	PAINT



-293		
-295 null - used for spec change -43 record -296 null - used for spec change -44 record -297 null - used for spec change -45 record -298 TEE ELBOW -299 COMDACE ITEM CODE DELIMETER -300 FABRICATION MATERIALS -301 PT -302 NO -303 COMPONENT DESCRIPTION -304 N.S. -305 ITEM CODE -306 OTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-293	null - used for spec change -41 record
-296	-294	null - used for spec change -42 record
-297 null - used for spec change -45 record -298 TEE ELBOW -299 COMDACE ITEM CODE DELIMETER -300 FABRICATION MATERIALS -301 PT -302 NO -303 COMPONENT DESCRIPTION -304 N.S305 ITEM CODE -306 QTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-295	null - used for spec change -43 record
-298 TEE ELBOW -299 COMDACE ITEM CODE DELIMETER -300 FABRICATION MATERIALS -301 PT -302 NO -303 COMPONENT DESCRIPTION -304 N.S305 ITEM CODE -306 OTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-296	null - used for spec change -44 record
-299 COMDACE ITEM CODE DELIMETER -300 FABRICATION MATERIALS -301 PT -302 NO -303 COMPONENT DESCRIPTION -304 N.S305 ITEM CODE -306 OTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-297	null - used for spec change -45 record
-300 FABRICATION MATERIALS -301 PT -302 NO -303 COMPONENT DESCRIPTION -304 N.S305 ITEM CODE -306 OTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-298	TEE ELBOW
-301 PT -302 NO -303 COMPONENT DESCRIPTION -304 N.S305 ITEM CODE -306 QTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-299	COMDACE ITEM CODE DELIMETER
-302 NO -303 COMPONENT DESCRIPTION -304 N.S305 ITEM CODE -306 OTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-300	FABRICATION MATERIALS
-303 COMPONENT DESCRIPTION -304 N.S305 ITEM CODE -306 OTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-301	PT
-304 N.S305 ITEM CODE -306 QTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-302	NO
-305 ITEM CODE -306 OTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-303	COMPONENT DESCRIPTION
-306 QTY -307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-304	N.S.
-307 PIPE -308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-305	ITEM CODE
-308 FITTINGS -309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-306	QTY
-309 FLANGES -310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-307	PIPE
-310 ERECTION MATERIALS -311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-308	FITTINGS
-311 GASKETS -312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-309	FLANGES
-312 BOLTS -313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-310	ERECTION MATERIALS
-313 VALVES / IN-LINE ITEMS -314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-311	GASKETS
-314 INSTRUMENTS -315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-312	BOLTS
-315 SUPPORTS -316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-313	VALVES / IN-LINE ITEMS
-316 PIPE SPOOLS -317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-314	INSTRUMENTS
-317 PIPE NS -318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-315	SUPPORTS
-318 CL LENGTH -319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-316	PIPE SPOOLS
-319 CUT PIPE LENGTHS -320 PIECE -321 NO -322 CUT -323 LENGTH	-317	PIPE NS
-320 PIECE -321 NO -322 CUT -323 LENGTH	-318	CL LENGTH
-321 NO -322 CUT -323 LENGTH	-319	CUT PIPE LENGTHS
-322 CUT -323 LENGTH	-320	PIECE
-323 LENGTH	-321	NO
	-322	CUT
-324 REMARKS	-323	LENGTH
	-324	REMARKS



-325	default is blank - used for spool separators
-326	PLD BEND
-327	LOOSE FLG
-328	FF WELD
-329	M
-330	INS
-331	MM
-332	PAGE
-333	PIPELINE REF
-334	S (used to signify special end flange)
-335	WITH SPECIAL RATING FLANGE(S) (SEE ISO)
-336	SYSTEM REF
-337	D BEND RADIUS
-338	BEND RADIUS
-339	MISCELLANEOUS COMPONENTS
-340	INDUCTION BEND ID -
-341	EQUIPMENT TRIM MATERIALS
-342	NOZZLE REF -
-343	CONTINUED
-344	END CONNECTOR
-345	AND
-346	GEARBOX ORIENTATION
-347	used for continuations on - material list
-348	used for continuations from - material list
-349	PP
-350	REDUCING ELBOW
-351	FABRICATED (PULLED) BEND
-352	WEIGHT
-353	KGS
-354	LBS
-355	TOTAL WEIGHT - THIS DRG
-356	U



-357	В
-358	W
-359	default is blank - used for bolt units
-360	FT
-361	FT-INS
-362	END\$ONE
-363	END\$TWO
-364	ITEM\$CODE
-365	default is blank - used for part\$no on cut list
-366	SQ.CUT
-367	BEVEL
-368	SCREWED
-369	SHAPED
-370	MITRED
-371	OFFSHORE MATERIALS
-372	REMARKS
-373	REM
-374	ANGLE
-375	WELDS
-376	FAB
-377	EREC
-378	OFF
-379	TOTAL FABRICATION WEIGHT
-380	TOTAL ERECTION WEIGHT
-381	TOTAL OFFSHORE WEIGHT
-382	TOTAL WEIGHT UNLISTED ITEMS
-383	* (missing weight character)
-384	TANGENT+
-385	CUT/WELD
-386	default is blank (used for insulation length)
-387	default is blank (used for heat tracing length)
-388	TANGENTIAL CONNECTION



-389	OFFSET CONNECTION
-390	FROM ? ORIGIN
-391	default is blank - used to show Weld/Connections that have not been adjusted to incorporate Gap/Shrinkage
-400	TRACED PIPE
-401	LAGGED PIPE
-402	PIPE SUPPORT
-403	COMPN JOINT
-404	SCREWED JOINT
-405	SOCKET WELD
-406	FIELD WELD
-407	SHOP WELD
-408	used for box at bottom of drawing eg. (pulled bend radius is 3x nominal pipe bore)
-409	used for box at bottom drawing eg. (all flanges 150p rating unless stated otherwise)
-410	[1] DENOTES PIPE SPOOL NO 1 DENOTES PARTS LIST NO
-411	SITE CONNECTION
-412	WELD SHOP WELD WELDER VISUAL NDT HARD S.R FAB.QA
-413	NO /FLD PROC ID ACCEPT NO NO ACCEPT
-414	S
-415	F
-416	0
-417	BW
-418	SW
-419	MW
-420	LUG
-421	SOF
-422	SOB
-423	LET
-450	B.O.P.
-451	TAPPING CONNECTION
-452	UNACCEPTABLE SPLIT



-453	MM-
-454	CONNECTION ORIENTATION
-455	(elevations at flange face IE ?\$FLANGE FACE)
-456	SEE DETAIL?
-457	MITRE ?
-458	Default is blank - used for metric bore units
-459	? THK
-460	BEAM\$?
-461	COLUMN\$?
-462	?\$BUILDING CL
-463	CL EQUIPMENT\$?
-464	CL PIPELINE\$?
-465	?\$FLOOR LEVEL
-466	?\$WALL
-467	GRID LINE\$?
-468	default is blank - used for user defined reference description
-469	REFERENCE POINT
-470	SUPPORT LOCATION
-471	LOCATION-POINT?
-472	NO.?
-473	OF
-474	ABOVE
-475	default is blank - used to trigger drawing identifiers in Spoolgen
-476	default is blank - used for drawing identifiers in Spoolgen
-477	CUT OUT ?
-478	J
-481	E
-482	N
-483	W
-484	S
-485	U
-486	D



-487 *** REFERENCE FLAT *** -488 *** REFERENCE SPINDLE *** -489 *** REFERENCE SUPPORT *** -490 *** REFERENCE BUPPORT *** -491 *** REFERENCE WINDOW *** -492 FLAT DIRECTION -493 SPINDLE DIRECTION -494 SUPPORT DIRECTION -495 BRANCH DIRECTION -496 WINDOW DIRECTION -497 FLANGE ROTATION? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 I (used to indicate manual weld) -519 EB (used in weld box)	_	
-489 *** REFERENCE SUPPORT *** -490 *** REFERENCE BRANCH *** -491 *** REFERENCE WINDOW *** -492 FLAT DIRECTION -493 SPINDLE DIRECTION -494 SUPPORT DIRECTION -495 BRANCH DIRECTION -496 WINDOW DIRECTION -497 FLANGE ROTATION? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-487	*** REFERENCE FLAT ***
-490 *** REFERENCE BRANCH *** -491 *** REFERENCE WINDOW *** -492 FLAT DIRECTION -493 SPINDLE DIRECTION -494 SUPPORT DIRECTION -495 BRANCH DIRECTION -496 WINDOW DIRECTION -497 FLANGE ROTATION ? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-488	*** REFERENCE SPINDLE ***
-491 *** REFERENCE WINDOW *** -492 FLAT DIRECTION -493 SPINDLE DIRECTION -494 SUPPORT DIRECTION -495 BRANCH DIRECTION -496 WINDOW DIRECTION -497 FLANGE ROTATION ? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFORCEMENT PAD FOR@ -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate manual weld)	-489	*** REFERENCE SUPPORT ***
-492 FLAT DIRECTION -493 SPINDLE DIRECTION -494 SUPPORT DIRECTION -495 BRANCH DIRECTION -496 WINDOW DIRECTION -497 FLANGE ROTATION? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate manual weld)	-490	*** REFERENCE BRANCH ***
-493 SPINDLE DIRECTION -494 SUPPORT DIRECTION -495 BRANCH DIRECTION -496 WINDOW DIRECTION -497 FLANGE ROTATION? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-491	*** REFERENCE WINDOW ***
-494 SUPPORT DIRECTION -495 BRANCH DIRECTION -496 WINDOW DIRECTION -497 FLANGE ROTATION? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-492	FLAT DIRECTION
-495 BRANCH DIRECTION -496 WINDOW DIRECTION -497 FLANGE ROTATION? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-493	SPINDLE DIRECTION
-496 WINDOW DIRECTION -497 FLANGE ROTATION? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-494	SUPPORT DIRECTION
-497 FLANGE ROTATION? -498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-495	BRANCH DIRECTION
-498 Default is blank - SITE WELD -499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-496	WINDOW DIRECTION
-499 SHOP TEST WELD -500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-497	FLANGE ROTATION ?
-500 SHOP TEST -501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-498	Default is blank - SITE WELD
-501 Default is blank - OFFSHORE WELD -502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-499	SHOP TEST WELD
-502 SUPPORT -503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-500	SHOP TEST
-503 SPOOL ID -504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-501	Default is blank - OFFSHORE WELD
-504 default is blank - used for ffw weld category -507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-502	SUPPORT
-507 RPD -508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-503	SPOOL ID
-508 LF -509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-504	default is blank - used for ffw weld category
-509 L4 -510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-507	RPD
-510 default is blank - used for part no / weld delimeter -511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-508	LF
-511 PAD -512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-509	L4
-512 TACK WELD -513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-510	default is blank - used for part no / weld delimeter
-513 TW -514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-511	PAD
-514 REINFPAD -515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-512	TACK WELD
-515 REINFORCEMENT PAD FOR@ -516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-513	TW
-516 TRN -517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-514	REINFPAD
-517 5 (used to indicate manual weld) -518 1 (used to indicate automatic weld)	-515	REINFORCEMENT PAD FOR@
-518 1 (used to indicate automatic weld)	-516	TRN
	-517	5 (used to indicate manual weld)
-519 EB (used in weld box)	-518	1 (used to indicate automatic weld)
	-519	EB (used in weld box)
-520 RL (used in weld box)	-520	RL (used in weld box)



-521	FW
-521	Default is blank (reinforced set-on tee)
-523	
	Default is blank (reinforced angled set-on tee)
-524	Default is blank (angled seton tee)
-525	default is blank (half coupling weld)
-526	default is blank (reinforced tee / pad to main)
-527	Default is blank (reinforced tee / pad to branch)
-528	Defaul is blank (trunnion d2 type weld)
-529	default is blank (trunnion d4 type weld)
-530	default is blank (trunnion d5 type weld)
-531	default is blank (trunnion d6 type weld)
-532	default is blank (trunnion d7 type weld)
-533	FI
-534	RL
-535	SU
-536	VL
-537	default is blank (used for style 3/4 pipe quan units)
-538	default is blank (used for bolting data)
-539	
-540	default is blank (used for alternative bolting ns)
-541	_N
-542	_S
-543	default is blank (used for special information note)
-544	default is blank (used for showing additional material)
-545	/ (used for additional material delimeter)



	User Defined Attribute Block	
<u>Isogen</u> <u>Record</u>	<u>Description</u>	PCF Equivalent
-600 *	Attributes -600 to -699 are for User Defined	ATTRIBUTE0 to
to -699 *	attributes in Isogen	ATTRIBUTE99

	Minus 700 Series – TextPos	
<u>Isogen</u> <u>Record</u>	<u>Description</u>	PCF Equivalent
-700 *	North Arrow X-Y Position on isometric	Use a -700 record in the POSITIONED-TEXT file
-701	Spare	
-702 *	Drawing (Sheet) Number	Use a -702 record in the POSITIONED-TEXT file
-703 *	Number of Drawings (Sheets)	Use a -703 record in the POSITIONED-TEXT file
-704 *	Total Weight for a Drawing	
-705 *	Total Fabrication Weight	
-706 *	Total Erection Weight	
-707 *	Total Offshore Weight	
-708 *	Flange Part Number (Flat Spools)	
-709 *	Flange Rotation Angle (Flat Spools)	
-710 *	Total Weight Unlisted Items	
-711 *	Total Weight of Pipeline	
-712 *	Total Wet (Full) Weight of Pipeline	
-713 *	Total Insulation Weight for Pipeline	
-714 *	C of G Position of Dry (Empty) Pipeline	
-715 *	C of G Position of Dry Pipeline + Insulation	



C of G Position of Wet (Full) Pipeline	
C of G Position of Wet Pipeline + Insulation	
Total Pipeline Fabrication Weight	
Total Pipeline Erection Weight	
Total Pipeline Offshore Weight	
Zone 1 Identifier STORK	
Zone 2 Identifier STORK	
Zone 3 Identifier STORK	
STORK Sequence Number	
Spool Weight (Style 4 Material List)	
Spool C of G Position (Style 4 Material List)	
Weld Diameter Inches (Spools)	
Spool C.L. Length	
Spool Erection Factor	
Pipeline Erection Factor	
Weld Diameter Inches (Pipeline)	
Location Point - to nearest Steelwork Stanchion	
Location Point - above nearest Floor Level	
	C of G Position of Wet Pipeline + Insulation Total Pipeline Fabrication Weight Total Pipeline Erection Weight Total Pipeline Offshore Weight Zone 1 Identifier STORK Zone 2 Identifier STORK Zone 3 Identifier STORK STORK Sequence Number Spool Weight (Style 4 Material List) Spool C of G Position (Style 4 Material List) Weld Diameter Inches (Spools) Spool C.L. Length Spool Erection Factor Weld Diameter Inches (Pipeline) Location Point - to nearest Steelwork Stanchion



	AText's -800 to -899	
	Used in Spoolgen Probing and FFI	
-800	BEND	
-801	ELBOW	
-802	OLET	
-803	TEE	
-804	CROSS	
-805	REDUCER	
-806	TEE REDUCER	
-807	REDUCING FLANGE	
-808	TEE BEND/ELBOW	
-809	ANGLE VALVE	
-810	3 WAY VALVE	
-811	4 WAY VALVE	
-812	INSTRUMENT	
-813	MISC COMPONENT	
-814	PIPE (TUBE	
-815	FIXED PIPE	
-816	PIPE BLOCK	
-817	FLANGE	
-818	LJSE FLANGE	
-819	BLIND FLANGE	
-820	CONNECTOR	
-821	BACKING NUT	
-822	CLAMP	
-823	MISC HYGENIC COMPONENT	
-824	CAP	
-825	COUPLING	
-826	UNION	



-827	VALVE	
-828	TRAP	
-829	VENT	
-830	FILTER	
-831	SUPPORT	
-832	INSTRUMENT TEE	
-833	WELD	
-834	NONE	
-835	Unused	
-836	Unused	
-837	Unused	
-838	Unused	
-839	Unused	
-840	Changed to Bend	
-841	Flange set to Loose	
-842	Detail Sketch ?	
-843	Support changed to Fabrication	
-844	Support changed to Erection	
-845	Support changed to Offshore	
-846	Tack Weld	
-847	Support Weld(s added	
-848	Automatic Weld	
-849	Shop Test	
-850	REDUCING-CONCENTRIC	
-851	REDUCING-ECCENTRIC	
-852	STUB/BACKING PAIR	
-853	SCREWED	
-854	SLIP-ON J TYPE	
-855	SLIP-ON	
-856	SOCKET-WELD	
-857	WELD-NECK	
-858	SLIP-ON ORIFICE	
-859	WELD-NECK ORIFICE	
-860	LAP-JOINT RING	



-862 UNKNOWN -863 Material added -864 General Information Note - ? -865 Specific Information Note - ? -866 Weld deleted -867 Support Weld(s deleted -868 Spool Name deleted -869 Flow Arrow deleted -870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	004	LAD IOINT CTUD END	
-863 Material added -864 General Information Note - ? -865 Specific Information Note - ? -866 Weld deleted -867 Support Weld(s deleted -868 Spool Name deleted -869 Flow Arrow deleted -870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOORWALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	-861	LAP-JOINT STUB END	
-864 General Information Note - ? -865 Specific Information Note - ? -866 Weld deleted -867 Support Weld(s deleted -868 Spool Name deleted -869 Flow Arrow deleted -870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOORWALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added			
-865 Specific Information Note - ? -866 Weld deleted -867 Support Weld(s deleted -868 Spool Name deleted -869 Flow Arrow deleted -870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added			
-866 Weld deleted -867 Support Weld(s deleted -868 Spool Name deleted -869 Flow Arrow deleted -870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added			
-867 Support Weld(s deleted -868 Spool Name deleted -869 Flow Arrow deleted -870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added		•	
-868 Spool Name deleted -869 Flow Arrow deleted -870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added			
-869 Flow Arrow deleted -870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOORWALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	-867	Support Weld(s deleted	
-870 Message deleted -871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	-868	Spool Name deleted	
-871 Detail Sketch deleted -872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	-869	Flow Arrow deleted	
-872 Information Note deleted -873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	-870	Message deleted	
-873 Additional Material deleted -874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·871	Detail Sketch deleted	
-874 Loose Flange un-set -875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·872	Information Note deleted	
-875 Location point added -876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·873	Additional Material deleted	
-876 Location point deleted -877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·874	Loose Flange un-set	
-877 FLOOR/WALL PENETRATION -878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·875	Location point added	
-878 FLOW ARROW -879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·876	Location point deleted	
-879 INSULATION SYMBOL -880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·877	FLOOR/WALL PENETRATION	
-880 MESSAGE -881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·878	FLOW ARROW	
-881 Drawing Identifier deleted -882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	.879	INSULATION SYMBOL	
-882 Default Start -883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	-880	MESSAGE	
-883 Pipeline Start -884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·881	Drawing Identifier deleted	
-884 Default Bypass Closure -885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	-882	Default Start	
-885 Used as delimiter in FFISYS -886 Bypass Closure -887 Pipe Support Added	·883	Pipeline Start	
-886 Bypass Closure -887 Pipe Support Added	-884	Default Bypass Closure	
-887 Pipe Support Added	-885	Used as delimiter in FFISYS	
	-886	Bypass Closure	
	-887		
-000 It the authorit peteren	-888	Pipe Support Deleted	
-890 Coupling Added	-890	Coupling Added	
-891 Coupling Deleted	·891		
-899 Properties Changed	-899	; •	



	Alternative User Defined Attribute Block		
Isogen Description Record		PCF Equivalent	
-900 *	Records -900 to -999 are normally used for ATTRIBUTE100 to Fabricator defined Pipeline Attributes in Spoolgen ATTRIBUTE199		
to -999 *	and for Pipeline Attributes and Heat / NDE attributes	extracted from -156 and -157 files	
	Component Records		
<u>Isogen</u> Record	<u>Description</u>	PCF Equivalent	
30/31	Bend or U Bend	BEND	
35/36	1) Elbow	ELBOW	
	2) Reducing Elbow	ELBOW-REDUCING	
40/41/42	1) Olet	OLET	
	2) Instrument Tee	INSTRUMENT-TEE	
45/46/47	1) Tee TEE		
	2) Tee Set On branch	TEE-SET-ON	
	3) Tee Stun In branch	TEE-STUB	
50/51/52/53	1) Cross	CROSS	
	2) Cross Set On branch	CROSS-SET-ON	
	3) Cross Stub In branch	CROSS-STUB	
55	1) Concentric Reducer	REDUCER-CONCENTRIC	
	2) Eccentric Reducer	REDUCER-ECCENTRIC	
60/61/62	1) Concentric Teed Reducer	REDUCER-CONCENTRIC-TEED	
	2) Eccentric Teed Reducer	REDUCER-ECCENTRIC-TEED	
65	1) Reducing Flange Concentric	FLANGE-REDUCING-CONCENTRIC	
	2) Reducing Flange Eccentric	FLANGE-REDUCING-ECCENTRIC	



70/71/72	1) Tee Bend	BEND-TEED
	2) Tee Elbow	ELBOW-TEED
75/76	Angle Valve	VALVE-ANGLE
80/81/82	3 Way Valve	VALVE-3WAY
85/86/87/88	4 Way Valve	VALVE-4WAY
90	Instrument Dial	INSTRUMENT-DIAL
90/93	1) Instrument Straight through	INSTRUMENT
	2) Instrument Angled	INSTRUMENT-ANGLE
	3) Instrument Offset	INSTRUMENT-OFFSET
	4) Instrument Return	INSTRUMENT-RETURN
90/91/93	3 Way Instrument	INSTRUMENT-3WAY
90/91/92/93	4 Way Instrument	INSTRUMENT-4WAY
95/96	1) Misc Component Straight through	MISC-COMPONENT
	2) Misc Component Angled	MISC-COMPONENT-ANGLE
	3) Misc Component Offset	MISC-COMPONENT-OFFSET
	4) Misc Component Return	MISC-COMPONENT-RETURN
		MULTI-PORT-COMPONENT
100	Pipe	PIPE
101	Fixed Length Pipe	PIPE-FIXED
102	Fixed Length Pipe Block	PIPE-BLOCK-FIXED
103	Variable Length Pipe Block	PIPE-BLOCK-VARIABLE
104	Gap component	GAP
105	Flange	FLANGE
106	1) Lap Joint Stub End	LAPJOINT-STUBEND
	2) Lap Joint Stub Ring	LAPJOINT-RING
107	Blind Flange	FLANGE-BLIND
110	Gasket	GASKET
111	Hygenic Connector	CONNECTOR
112	Hygenic Backing Nut	NUT
113	Hygenic Clamp	CLAMP
114	Hygenic Misc. Component	MISC-HYGIENIC
115	Bolt	BOLT
120	Weld	WELD
125	Сар	CAP



126	1) Coupling	COUPLING
	2) Elbolet	ELBOLET
127	Union	UNION
130	Valve - Straight or Reducing	VALVE
132/133	1) Trap - Straight through	TRAP
	2) Trap Angled	TRAP-ANGLE
	3) Trap Offset	TRAP-OFFSET
	4) Trap Return	TRAP-RETURN
134	Safety Disc / Vent	SAFETY-DISC
136/137	1) Filter Straight through	FILTER
	2) Filter Angled	FILTER-ANGLE
	3) Filter Offset	FILTER-OFFSET
	4) Filter Return	FILTER-RETURN
140	Instrument Balloon	INSTRUMENT-BALLOON
150	Pipe Support	SUPPORT



	Special Type Records	
Isogen Description Record		PCF Equivalent
0	Additional Bore	
3	Text Positioning (TextPos) record	Data in POSITIONED-TEXT file
148	1) Drawing Split Point (148 record used together with a -38 record)	ISO-SPLIT-POINT CO-ORDS data
	2) Spool Identifier positioning record (148 record used together with a -28 record)	SPOOL-IDENTIFIER CO-ORDS data TEXT
149	Location records 1) Positioned Comment (148 record used together with a -37 record) N.B. Where a 149 record appears with an associated -70 to -75 type record then the following types of PCF commands are generated	MESSAGE CO-ORDS data
	149 & -70	MESSAGE-SQUARE CO-ORDS data TEXT data
	149 & -71	MESSAGE-SQUARE CO-ORDS data TEXT data
	149 & -72	MESSAGE-ROUND CO-ORDS data TEXT data
	149 & -73	MESSAGE-TRIANGLE CO-ORDS data TEXT data



	149 & -74	MESSAGE-DIAMOND
		CO-ORDS data
		TEXT data
	149 & -75	MESSAGE-CIRCLE
		CO-ORDS data
		TEXT data
	2) Location Point	LOCATION-POINT
		CO-ORDS data
		SKEY LOPT
	3) Floor Symbol	FLOOR-SYMBOL
		CO-ORDS data
		SKEY data
	4) Flow Arrow	FLOW-ARROW
		CO-ORDS data
		FLOW data
		SKEY data
	5) Insulation Symbol	INSULATION-SYMBOL
		CO-ORDS data
		SKEY data
	6) Reference Dimension	REFERENCE-DIMENSION
		REFERENCE-POINT-LOCATION
		CO-ORDS data
		DIMENSIONED
151	Reference Dimension - Primary (Record structure is	REFERENCE-DIMENSION-PRIME
	149 151 153)	CO-ORDS data
152	Reference Dimension - Skewed (Record structure is	REFERENCE-DIMENSION-SKEWED
	149 152 153)	CO-ORDS data
153	Reference Dimension - Referenced Item Centre	REFERENCED-ITEM
	Line orientation	CO-ORDS data
		CO-ORDS data
		ITEM-DIRECTION data
160	Additional Material Item - Associated with a	ADDITIONAL-ITEM (This entry
	Pipeline component	must appear starting in column position 5 under a main component item)



161	Additional Material Item - Independent	ADDITIONAL-ITEM (This entry
		appears as a stand alone item)
200	Tapped Branch (Tapping Point) Start	TAP-CONNECTION
201	Tapped Branch (Tapping Point) End	
300	Large Co-ordinate offset - Metric Units	OFFSET-METRIC
301	Large Co-ordinate offset - Imperial Units OFFSET-IMPERIAL	
501	Alternative Fitting Symbol - Symbol parameters	Skipped
502	Alternative Fitting Symbol - Symbol definition	Skipped
	(Points and Lines)	
	Always handled as an Additional Item	LUGG
	Listed in a -31 connection record	NOZZLE
	Used on Fabricated Tees and Crosses	REINFORCEMENT-PAD
999	End of File Marker	



	IDF Component Structure	
Word No.	<u>Field Use</u>	
1	Component Type Identifier - e.g. 100 for PIPE	See Component Records section for details
2	Start Point Co-Ordinate - East / West	Value is in 100 th MM integer numbers
3	Start Point Co-Ordinate - North / South	Value is in 100 th MM integer numbers
4	Start Point Co-Ordinate - Elevation +/-	Value is in 100 th MM integer numbers
5	End Point Co-Ordinate - East / West	Value is in 100 th MM integer numbers
6	End Point Co-Ordinate - North / South	Value is in 100 th MM integer numbers
7	End Point Co-Ordinate - Elevation +/-	Value is in 100 th MM integer numbers
8	Pipe Bore	Value is in 1/16 th 's Inch for Inch bores or in MM's for Metric bores –
		e.g. 3" bore = 48 25 MM bore = 25
9	 1) Item Code / Description Pointer 2) Reinforcement Pad Item Code on Reinforced Tees 	1) Item Codes are held in a series of vertically arranged –20 records at the bottom of the IDF. The value here is a pointer to that section. The Material Description of an Item Code is held in the –21 record that immediately follows the –20 record.
		2) The 4 th 5 th and 6 th digit positions of this record, if present, are used for a pointer to the Reinforcement Pad Item Code on a Reinforced Tee component.
		3) The 7 th 8 th and 9 th digit positions of this record, if present, are used for a pointer to the Repeat Part Number of a component.
10	Component Weight	Value is held as a real or integer number and may be in LBS or KGS - depending on the setting in O.S. 41 (Held to the nearest 1/10 th LB or KG)
		Tons or Tonnes can be represented by use of a decimal point (eg. 1.67)



		43 11 11 11 11 11 11 11 11 11 11 11 11 11
11	Carries up to 5 items of information	1) Units position - Only used for Pipe to indicate the Pipe End condition.
		1= Screwed end at start of pipe
		2= Screwed end at end of pipe
		3= Screwed end at both ends of pipe
		2) Tens, Hundredth's and Thousands position - Only used for Pipe to calculate the Pipe Wastage amount. Values held here are 1/10 th's percentage Wastage amounts. e.g. 4%=40 12.5%=125
		3) In the Ten Thousands position - Plant Area Identification Number in the range 1 to 9.
		4) One Hundred Thousands position. – Used to indicate the pipework style.
		0= Standard Pipework
		1= Dotted Pipework, Undimensioned
		2= Dotted Pipework, Dimensioned
		5) In the Millions position – Used to control whether or not the component is to appear in the BOM and isometric, and if so, how.
		0= Component Item Code to appear on the BOM with a Part Number on the isometric
		1 = Component not to appear on the BOM nor on the isometric
		2= The Component Item Code to appear both on the BOM and on the isometric underneath the Part Number.
12	SKEY (Symbol Key)	Normally 2 or 4 characters, but can be blank.



13	Carries up to 4 items of mutually exclusive information for a component	1) ANGLE. Holds the Angle value of certain type of component – e.g. Bend, Elbow or Tee. The value held is in 1/100 th /s Degree. e.g. 45 degrees = 4500, 90 degrees = 9000 2) BOLT LENGTH. In 115 Bolt records - holds the Bolt Length either in whole MM's or 1/16 th /s Inch depending on the units in use e.g. 115 MM or 48 for 3" 3) FLANGE PROTRUSION LENGTH. Only set on certain types of 105 Flange records that have special welding on requirements. That is, those types where the Pipe protrudes through the Flange prior to welding. The value held must only be in whole MM's. 4) INDIVIDUAL TAPPING CO-ORDINATES ON /OFF. Applies only to 200 type Tapping Co-Ordinate records. Values may be –
		0 = Output Tapping Co-Ordinates 1 = Suppress Tapping Co-Ordinates



14	Carries up to 5 items of information	1) Units position – Fab / Erect / Offshore classification
		0= No classification
		1= Fabrication Item
		2= Erection Item
		3= Offshore Item
		2) Tens position – Fluid Flow
		0 or blank = Fluid Flow in direction built
		1= Fluid Flow opposite to direction built
		3) Hundreds position – Primary Direction for the following – Valve Spindle, Flat Side on Eccentric Reducer, Instrument Dial Face, Sight Glass Window, Orifice Plate Tapping, Spectacle Plate Tail, Slip Plate Tail and Support
		0 or blank = No Direction
		1= North
		2= South
		3= East
		4= West
		5= Up
		6= Down
		4) Thousands position – Insulation / Tracing indication
		0 or blank= No Tracing or Insulation
		1= Insulated
		2= Heat Traced
		3= Insulated and Heat Traced
		5) Ten Thousands position – Direction of the Offline Branch Leg on Flanged Tee Bends and Flanged Tee Elbows
		0 or blank= No Direction set
		1= Branch Leg in line with Main Line 'In' leg
		2= Branch Leg in line with Main Line 'Out' leg

TS Rowe

21 November 2002