CTU firmware for integration test in Padova

As CTU_v0 has some design issue with the mini-WR interface, the VIO is used to control the CTU_v0 in this firmware.

Registers and their function are show in table 1. See below for detailed specification.

Name	Width	Function
ch_mask_in	14	mask the channels that you don't want to take in to account
		when calculate nhit
threshold_i	16	trigger threshold for physics trigger
trig_mask	7	trigger source mask
ext_trig_i	1	manual trigger input
ch_sel	5	select channel to be shown in the ILA
period_i	32	period setting for the periodic trigger
sma_sel	1	select source of SMA[1]
window_i	5	trigger window

- ch_mask_in: '1' to mask the corresponding channel. During the test, most of the channels will be empty. To avoid un-wanted noise from un-connected/noisy channels, set '1' to corresponding bit. ch_mask is actually 168 bits wide, cover all 168 BEC channels. As we only plan to use 2 BEC, the high 154 bits are constant '1' in the firmware.
- threshold_i: physics trigger is generated by comparing the nhit and threshold. If the calculated nhit is larger (>) than the threshold, a trigger will be generated. This register has default value 0 and should be set after power up.
- trig_mask: 7 trigger sources are provided by the firmware. If 1 or more sources are not needed, set its trig_mask to '0'. For external trigger source, DIO channel 3 and 4 are recommended.
 - trig_mask[6]: external trigger from DIO channel 4
 - trig_mask[5]: external trigger from DIO channel 3
 - trig_mask[4]: manual trigger from VIO
 - trig_mask[3]: external trigger from SMA[4]. Be careful when use this, should use LVCMOS18 standard!
 - trig_mask[2]: external trigger from SMA[3]. Be careful when use this, should use LVCMOS18 standard!
 - trig_mask[1]: periodic trigger mask
 - trig_mask[0]: physics trigger mask
- ext_trig_i: rising edge of this register will generate a manual trigger.
- ch_sel: select RMU channel to be shown in the ILA. Range from 0 to 23.
- period_i: period setting for the periodic trigger. The default value is x" 3B9ACA0", generates 1Hz trigger.
- sma_sel: source for SMA[1], when '0', the SMA[1] output the original PPS from mini-WR, otherwise output the re-generated PPS.
- window_i: set the trigger window for physics trigger. The default value is 0, range from 0 to 31.

An example setting is show below:

- "locked" shows the clock generator status;
- "rx_aligned" shows the status of the link with RMU. Here only channel 0 is connected so rx_aligned[0] is on;
- "ch_mask_in" masked all channels except the first two;
- "threshold_i" sets as x"FE", hit sum larger than this value will cause a physics trigger;
- "period_i" is the default value which is 1Hz;
- "trig_mask" is 1, only physics (nhit) trigger is enabled;
- "window_i" is 3, the trigger logic will add the hit number in the last 3 clock cycles to make trigger decision, to compensate the TOF and link un-even.

