PO Box 518 620 Applegate St. Philomath, OR 97370



(541) 929-5650 Fax (541) 929-5277 www.wetlabs.com

Date 2/25/2016 Customer NOAA / David Straausz

S/N# FLS-107 Technician SML

Diagnosis

Evaluated instrument and found sleep current to be too high otherwise no problems.

Repairs

Standard Service performed. Replaced application board due to high sleep current. This does not affect the tuning. Verified tuning, tested, and characterized instrument. Replaced shutter, shutter shaft, shaft seal, faceplate, and case seal.

ECO Standard Service Definition

The bulkhead connector, pressure housing and window on the instrument are first inspected for possible damage.

The instrument then is powered on and the current data is checked to determine if the instrument is working properly.

The instrument pre-service characterization is perfromed

The head is next inspected for cracks in the LED, the detector and the motor bores.

The digital and analog operations are checked.

The instruments scaling is checked with dye or scatter proxy as determined by the instrument type.

The firmware version on the instrument is updated as necessary.

The case seals, desiccant, shaft seal, faceplate, and shaft are replaced as the instrument is reassembled.

The instrument is rescaled if needed after reassembly.

Standard testing is performed on the instrument and characterized before being returned to the customer.

ECO Standard Testing Definition

- Performed noise test: 1 sample/sec for 60 sec
- Performed stability test: 1 sample/sec for 12 hrs as needed
- Performed thermistor calibration if installed
- Performed live 6hr pressure test: 5 samples every 4 minutes as needed
- Pressure-tested unit
- Completed instrument characterization
- Updated unit's characterization sheet and included on CD
- Updated unit's device file and included on CD

FLS-107 Revision L 6/9/09