



Embedded Systems

Master 's Degree in Informatics Engineering




ESP-01 & NodeMCU Platform






LoRa – Long Range Radio

- LoRa (Long Range) is a low-power wide-area network (LPWAN) technology (more than 10 km in rural areas)
- The LoRa Alliance is an association created in 2015 to support LoRaWAN (~ 500 members)
- The LoRa physical layer protocol is proprietary





LoRa – Long Range Radio



LoRa uses unlicensed frequencies that are available worldwide. These are the most widely used frequencies:

- 868 MHz for Europe
- 915 MHz for North America
- 433 MHz band for Asia



Key Feature of LoRa



Long Range

Connects devices up to 30 miles apart in rural areas and penetrates dense urban or deep indoor environments



Low Power

Requires minimal energy, with prolonged battery lifetime of up to 10 years, minimizing battery replacement costs



Secure

Features end-to-end AES128 encryption, mutual authentication, integrity protection, and confidentiality



Standardized

Offers device interoperability and global availability of LoRaWAN networks for speedy deployment of IoT applications anywhere



Geolocation

Enables GPS-free tracking applications, offering unique low power benefits untouched by other technologies



Mobile

Maintains communication with devices in motion without strain on power consumption



High Capacity

Supports millions of messages per base station, meeting the needs of public network operators serving large markets




Low Cost

Reduces infrastructure investment, battery replacement expense, and ultimately operating expenses



LoRa – Applications




LoRa long range and low power features, makes it perfect for battery-operated sensors and low-power applications in:


- Internet of Things (IoT)
- Smart home
- Machine-to-machine communication
- Etc.




LoRa - Topologies



Point to Point Communication: two LoRa enabled devices talk with each other using RF signals.




Network or LoRa WAN: It allows accessing to gateways






LoRa vs ZigBee

Network Architecture



Gateway, servers and end devices.
Wide Area Network

- 2-5 Km (urban areas)
- 15 Km (suburban areas)





Coordinator, routers and end devices.
Low rate wireless personal area network

- 10 to 100 meters




LoRa vs ZigBee

Protocol Stack





ESP family



Ai-Thinker series based around ESP8266 and , referred as ESP-xx modules ranges from 01 to 14.



Wemos D1 mini -- 2017 versions

US / UK Prices -- includes shipping to US / UK

mini V3.0.0
ESP8266 4MB
\$4.21 / £ 3.23



mini Lite V1.0.0
ESP8285 1MB
\$3.71 / £ 2.84



MicroPython based boards

mini Pro V1.1.0
ESP8266 16MB
ceramic antenna
\$6.81 / £ 5.41






NodeMCU family



NodeMCU v0.9 / V1



NodeMCU v1.0 / V2




NodeMCU v1.0 / V3

NodeMCU development board has a total 30 pins in which 14 pins are active, uses ESP-12 module, onboard reset and flash button, 3.3 voltage regulator, Micro USB, USB to UART Bridge and some other components.



ESP8266-12E Block Diagram





ESP8266-12E pinout

ESP8266 Modul

ESP12E

RESET	RESET	RES	1
ADC	ADC	ADC	2
CH	PD	EN	3
WAKE	GPIO16	D0	4
PWM	SCK	GPIO14	D5
PWM	MISO	GPIO12	D6
Rx0	MOSI	GPIO13	D7
	VCC	VCC	8

Hilfreiche Übersicht, bei der Programmierung über die Arduino IDE

A close-up photograph of an ESP8266 WiFi module. The module is a square PCB with a central chip labeled "AT-THINKER". A large blue "WIFI" logo is printed on the right side. On the left, there is a large "FC" logo. At the top, there is a gold-colored spiral antenna. The text "MODEL VENDOR" is visible above the central chip.

9	SDCMD	GPIO11	CS0
10	SDDO	GPIO7	MISO
11	D11	GPIO9	SPIHD
12	D12	GPIO10	SPIWP
13	SDDI	GPIO8	MOSI
14	SDCLK	GPIO6	CLK

Mikrocontroller - Elektronik.de

Der Elektronik Blog für Bastler und Tüftler

Creative Commons (CC) Lizenz

 Namensnennung - Nicht-Kommerziell
 Weitergabe unter gleichen Bedingungen
 Alle Angaben ohne Gewähr

LED an GPIO2 (D4)

22	D10	GPIO1	TXD0	
21	D9	GPIO3	RXD0	
20	D1	GPIO5	SCL	
19	D2	GPIO4	SDA	PWM
18	D3	GPIO0	FLASH	
17	D4	GPIO2	TX1	
16	D8	GPIO15	MTD0	PWM SS
15	GND	GND	GND	

Hinweise:

Bei der Programmierung muss GPIO0 (Flash) beim Bootvorgang auf LOW gezogen werden.

GPIO15 muss beim Start immer auf LOW liegen
GPIO2 beim Start High oder unbeschaltet

EN / CH_PD muss zum aktivieren es Moduls auf High liegen

Die Arduino-IDE programmiert das Modul über den eingebauten Bootloader per TXD0 und RXD0

Maximale Belastbarkeit pro Pin 6 mA (max. 12mA)
Betriebsspannung 3,3V



ESP-01

- Low cost, compact and powerful Wi-Fi Module
- Power Supply: +3.3V only
- Built-in low power 32-bit MCU @ 80MHz
- 512kB Flash Memory
- Can be used as Station or Access Point or both combined
- Supports Deep sleep (<10uA)
- Supports serial communication hence compatible with many development platform like Arduino
- Can be programmed using Arduino IDE or AT-commands or Lua Script





What is NodeMCU?

- Open-source
- WI-FI enabled
- Based on the ESP8266-12
- Arduino-like hardware IO (**3.3V**)
- Nodejs style network API
- MicroPython/LUA programming*
- Extremelly low cost <5€ !!



* <https://nodemcu.readthedocs.io/en/master/> > LUA

** https://www.nodemcu.com/index_en.html




ESP-01 vs NodeMCU?

	ESP-01	NodeMCU v1.0
CPU	32-bit Tensilica Xtensa LX106	
CPU Clock	80MHz/160MHz	
Instruction SRAM	64KBytes (<36KB Station Mode)	
Data SRAM	96KBytes	
Flash Memory	1MByte	4MBytes
GPIO Pins	2	11
ADC	-	1
USB-to-Serial	-	CH340G
UART/SPI/I2C	1/1/1	
WiFi Built-In	802.11 b/g/n	




ESP-01



ESP-01 PINOUT


NOTES:

- ▲ Typ. pin current 6mA (Max. 12mA)
- ▲ For sleep mode, connect GPIO16 and EXT_RSTB. On wakeup, GPIO16 will output LOW for system reset.
- ▲ On boot/reset/wakeup, keep GPIO15 LOW and GPIO2 HIGH.






ESP-01





ESP-01

Control



ESP-01 PINOUT

NOTES:


- ▲ Typ. pin current 6mA (Max. 12mA)
- ▲ For sleep mode, connect GPIO16 and EXT_RSTB. On wakeup, GPIO16 will output LOW for system reset.
- ▲ On boot/reset/wakeup, keep GPIO15 LOW and GPIO2 HIGH.

■	SP. FUNCTION(S)
■	COMM. INTERFACE
■	PIN NUMBER
■	N/C
~	PWM




ESP-01

4 GPIO available







ESP-01






ESP-01 – Programming module



Not Accessible – ESP-01


ESP8266 Boot Options

	GPIO0	GPIO2	Mode	Comments
L	H	H	Flash	Boot from SPI Flash (Normal running)
L	L	H	UART	Program via UART (TX/RX)
H	x (not care)	x (not care)	SDIO	Boot from SD-card






NodeMCU 12E






NodeMCU 12E






NodeMCU 12E





NodeMCU 12E




Booting/Flash ping
Don't use it

Flash pin




NodeMCU 12E





NodeMCU 12E





Programming ESP8266

Native Expressig SDK

[ESP8266 - SDK-Getting_started_guide_en.pdf](#)

1.5. ESP8266 Toolkit

1.5.1. Compiler

Linux OS is required to compile the ESP8266 SDK. When using Windows OS, we recommend VirtualBox as the virtual machine for ESP8266. In order to simplify the compilation procedure, we have installed the compiling tools on the virtual machine. Users can directly compile the ESP8266 SDK by importing the ESP8266 compiler (OVA image) into the virtual machine. http://downloads.espressif.com/FB/ESP8266_GCC.zip

1.5.2. Firmware Download Tool

The ESP8266 DOWNLOAD TOOL is the official firmware download tool developed by Espressif. Users can download multiple binaries to the SPI Flash of the ESP8266 mother board (ESP-LAUNCHER or ESP-WROOM-02) at the same time according to the actual compilation mode and flash size.

1.5.3. Serial Port Debug Tool

The serial port debug tool can be used to directly communicate with the ESP8266 module over a standard RS-232 port. For PCs that do not have a physical serial port, a virtual com port (USB-to-serial converter) can be used.



Programming ESP8266

Native Expressig SDK

ESP8266 - SDK-Getting_started_guide_en.pdf

Xtensa-lx106-elf


Toolchain



ESP8266 IoT SDK
Espressif Systems



Standard GNU
development tools





Programming ESP8266

Native Expressig SDK

<https://github.com/pfalcon/esp-open-sdk>

Xtensa-lx106-elf


Toolchain



ESP8266 IoT SDK
Espressif Systems




Standard GNU
development tools





Arduino IDE – ESP8266

Arduino - Preferences




http://arduino.esp8266.com/stable/package_esp8266com_index.json



Arduino IDE - NodeMCU

Arduino – Tools > Boards > Boards Manager




In some cases latest version has problems with older boards!



Arduino IDE - NodeMCU

Arduino – Select Board and Serial Port



Debugging feature is controllable over the IDE menu. The new menu points manage the real-time Debug messages.

The Serial port must be initialized by the user at the highest baudrate > `Serial.begin(115200)` and selected in the Debug Port menu

Debugging level is user selected

<https://arduino-esp8266.readthedocs.io/en/latest/>




ESP8266 - WiFi

Station Mode (WIFI_STA) → It can connect to the Wi-Fi network as any other device

Access Point (WIFI_AP) → It establishes its own Wi-Fi network, then any other device can connect to the ESP8266

Both Station and Access Point (WIFI_AP_STA) → It operates as both a station and a soft access point mode. This provides the possibility of building e.g. mesh networks.





ESP8266 – WiFi Station

`WiFi.begin(ssid, password, channel, bssid, connect)` / `WiFi.begin(ssid, password)` / `WiFi.begin()`

- **ssid** - a character string containing the SSID of Access Point we would like to connect to, may have up to 32 characters
- **password** to the access point, a character string that should be minimum 8 characters long and not longer than 64 characters
- **channel** of AP, if we like to operate using specific channel, otherwise this parameter may be omitted
- **bssid** - mac address of AP, this parameter is also optional
- **connect** - a boolean parameter that if set to **false**, will instruct module just to save the other parameters without actually establishing connection to the access point

`WiFi.config(local_ip, gateway, subnet, [dns1], [dns2])`

> Disable DHCP client and set the IP configuration of station interface to user defined arbitrary values.

- **local_ip** - enter here IP address you would like to assign the ESP station's interface
- **gateway** - should contain IP address of gateway (a router) to access external networks
- **subnet** - this is a mask that defines the range of IP addresses of the local network
- **dns1, dns2** - optional parameters that define IP addresses of Domain Name Servers (DNS) that maintain a directory of domain names (like e.g. www.google.co.uk) and translate them for us to IP addresses

> It is possible to configure multiple Access Points using the *ESP8266WiFiMulti* library.



ESP8266 – WiFi Station

```
#include <ESP8266WiFi.h>

const char* ssid = "*****";
const char* password = "*****";

IPAddress staticIP(192,168,1,22);
IPAddress gateway(192,168,1,9);
IPAddress subnet(255,255,255,0);

void setup(void)
{
    Serial.begin(115200);
    Serial.println();

    Serial.printf("Connecting to %s\n", ssid);
    WiFi.config(staticIP, gateway, subnet);
    WiFi.begin(ssid, password);
    while (WiFi.status() != WL_CONNECTED)
    {
        delay(500);
        Serial.print(".");
    }
    Serial.println();
    Serial.print("Connected, IP address: ");
    Serial.println(WiFi.localIP());
}
```



ESP8266 – WiFi Access Point

WiFi.softAP(ssid) / WiFi.softAP(ssid, psk, channel, hidden, [max_connection])

- **ssid** - character string containing network SSID (max. 32 characters)
- **psk** - optional character string with a pre-shared key. For WPA2-PSK network it should be minimum 8 characters long and not longer than 64 characters. If not specified, the access point will be open for anybody to connect.
- **channel** - optional parameter to set Wi-Fi channel, from 1 to 13. Default channel = 1.
- **hidden** - optional parameter, if set to true will hide SSID.
- **max_connection** - optional parameter to set max simultaneous connected stations, from 0 to 8. Defaults to 4. Once the max number has been reached, any other station that wants to connect will be forced to wait until an already connected station disconnects.

*There are other overloaded methods

WiFi. softAPConfig (local_ip, gateway, subnet)

- **local_ip** - enter here IP address you would like to assign the ESP station's interface
- **gateway** - should contain IP address of gateway (a router) to access external networks
- **subnet** - this is a mask that defines the range of IP addresses of the local network

>Not using this method the network established by softAP will have default IP address of 192.168.4.1



ESP8266 – WiFi Access Point

```
#include <ESP8266WiFi.h>
#include <Ticker.h>

Ticker tickerFunction;

void clientsConnected() {
    Serial.printf("Stations connected = %d\n", WiFi.softAPgetStationNum());
}

IPAddress local_IP(192,168,100,1);
IPAddress gateway(192,168,100,255);
IPAddress subnet(255,255,255,0);

void setup()
{
    Serial.begin(115200);
    Serial.println();

    Serial.print("Setting soft-AP configuration ... ");
    Serial.println(WiFi.softAPConfig(local_IP, gateway, subnet) ? "Ready" : "Failed!");

    Serial.print("Setting soft-AP ... ");
    Serial.println(WiFi.softAP("ESPsoftAP_01") ? "Ready" : "Failed!");

    Serial.print("Soft-AP IP address = ");
    Serial.println(WiFi.softAPIP());

    tickerFunction.attach(3, clientsConnected); // 3 seconds
}

void loop()
{
```



ESP8266 – WiFi Server & Client

It provides functionality to other programs or devices, called clients

Methods come directly from the Arduino library

WiFiServer server(port) → Creates a new server **port**

- **port** - the port to listen on (int)

WiFiClient client → Creates a client able to be connected to any server