

### Binairy format:

<SOF-SID10...SID0-RTR-IDE-r0-DLC3...0-DATABYTE1...DATABYTEn-CRC15...CRC1-CRCDEL-ACK-ACKDEL-EOF7...EOF1-IFS3...IFS1>

bits	Description
SOF	Start Of Frame (always 0)
SID10 & SID9	Priority (00: highest 11: lowest priority)
SID8SID1	Address
SID0	Always 0
RTR	Remote Transmit Request
IDE	Identifier Extension (always 0)
r0	reserved (always 0)
DLC3DLC0	Data Length Code (08)
Databyte1	Command
Databyte2	Parameter
Databyte3	Parameter
Databyte4	Parameter
Databyte5	Parameter
Databyte6	Parameter
Databyte7	Parameter
Databyte8	Parameter
CRC15CRC1	Cyclic Redundancy Checksum
CRCDEL	CRC Delimiter (always 1)
ACK	Acknowledge slot (transmit 1 readback 0 if received correctly)
ACKDEL	Acknowledge Delimiter (always 1)
EOF7EOF1	End Of Frame (always 1111111)
IFS3IFS1	InterFrame Space (always 111)

### The module can transmit the following messages:

- Channel status
- Module status
- Module type and subtype
- Bus error counter status
- First, second and third part of the channel names
- Memory data
- Memory data block (4 bytes)
- Real-time clock status
- Date status
- Daylight savings status
- Real-time clock status request
- Clear linked push button led
- Set linked push button led
- Slow blink linked push button led
- Fast blink linked push button led

### The module can receive the following commands:

- Linked push button status
- Module type request
- Module status request
- Channel name request
- Clear channel led
- Set channel led
- Slow blink channel led
- Fast blink channel led
- Very fast channel led
- Update channel leds
- Read memory data
- Read memory data block (4 bytes)
- Memory dump request
- Write memory data
- Write memory data block (4 bytes)

- Bus error counter status request
- Real-time clock status request
- Set real-time clock
- Set date
- Set daylight savings
- Enable/disable global sunrise/sunset related actions
  Enable/disable local sunrise/sunset related actions
- Set local alarm clock
- Set global alarm clock
- Lock channel
- Unlock channel
- Disable channel program
- Enable channel program
- Select program

#### Transmits power up message:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 2 databyte to send

DATABYTE1 = COMMAND\_POWER\_UP (H'AB')

DATABYTE2 = module address

### Transmits real time clock status request:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 1 databyte to send

DATABYTE1 = COMMAND\_REALTIME\_CLOCK\_STATUS\_REQUEST (H'D7')

#### Transmits the real time clock status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 databytes to send

DATABYTE1 = COMMAND REALTIME CLOCK STATUS (H'D8')

DATABYTE2 = Day

Contents	Day
0	Monday
1	Tuesday
2	Wednesday
3	Thursday
4	Friday
5	Saturday
6	Sunday

 $DATABYTE3 = \overline{Hour(0...23)}$ 

DATABYTE4 = Minute (0...59)

#### Transmits the date status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 5 databytes to send

DATABYTE1 = COMMAND DATE STATUS (H'B7')

DATABYTE2 = Day (1...31)

DATABYTE3 = Month (1...12)

DATABYTE4 = High byte of Year

DATABYTE5 = Low byte of Year

### Transmits the daylight savings status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND\_DAYLIGHT\_SAVING\_STATUS (H'AF')

DATABYTE2 = 0 =disabled / 1 = enabled

#### Transmits the channel switch status:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 databytes to send

DATABYTE1 = COMMAND PUSH BUTTON STATUS (H'00')

DATABYTE2 = Channel just pressed

DATABYTE3 = Channel just released

DATABYTE4 = Channel long pressed

#### Transmits the sensor output switch status:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Subaddress

RTR = 0

DLC3...DLC0 = 4 databytes to send

DATABYTE1 = COMMAND OUTPUT STATUS (H'00')

DATABYTE2 = Output channel just activated (1 = just activated)

Contents	Output channel
xxxxxxx1	Heater just activated
xxxxxx1x	Boost heater/cooler just activated
xxxxx1xx	Pump just activated
xxxx1xxx	Cooler just activated
xxx1xxxx	Temperature alarm 1 just activated
xx1xxxxx	Temperature alarm 2 alarm activated
x1xxxxxx	Temperature alarm 3 just activated
1xxxxxxx	Temperature alarm 4 alarm activated

DATABYTE3 = Outputs just deactivated (1 = just deactivated)

``	Outputs just deactivated (1 = just deactivated)	
	Contents	Output channel
	xxxxxxx1	Heater just deactivated
	xxxxxx1x	Boost heater/cooler just deactivated
	xxxxx1xx	Pump just deactivated
	xxxx1xxx	Cooler just deactivated
	xxx1xxxx	Temperature alarm 1 just deactivated
	xx1xxxxx	Temperature alarm 2 alarm deactivated
	x1xxxxxx	Temperature alarm 3 just deactivated
	1xxxxxxx	Temperature alarm 4 alarm deactivated

DATABYTE4 = always zero

### Transmits the module type

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_MODULE\_TYPE (H'FF')

DATABYTE2 = VMBGP1-2 type (H'3A') VMBGP2-2 type (H'3B') VMBGP4-2 type (H'3C')

DATABYTE3 = High byte of serial number DATABYTE4 = Low byte of serial number

 $DATABYTE5 = Memorymap\ version$ 

DATABYTE6 = Build year DATABYTE7 = Build week

DATABYTE8 = Version + CAN Termination

Contents	Output channel
xxxxxxx1	1 = TERM closed, 0 = TERM open
xxxx111x	Version number. $(0 = old touch / 1 = new touch PCB)$

### Transmits the module subtype:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND SUBTYPE (H'B0')

DATABYTE2 = VMBGP1-2 type (H'3A') VMBGP2-2 type (H'3B') VMBGP4-2 type (H'3C')

DATABYTE3 = High byte of serial number

DATABYTE4 = Low byte of serial number

DATABYTE5 = Subaddress1 (H'FF' subaddress disabled)

DATABYTE6 = Subaddress2 (H'FF' subaddress disabled)

DATABYTE7 = Subaddress3 (H'FF' subaddress disabled)

DATABYTE8 = Subaddress4 (H'FF' subaddress disabled)

```
Transmit: Bus error counter status
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 4 databytes to send
   DATABYTE1 = COMMAND BUSERROR COUNTER STATUS (H'DA')
   DATABYTE2 = Transmit error counter
   DATABYTE3 = Receive error counter
   DATABYTE4 = Bus off counter
Transmits the memory data:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 4 databytes to send
   DATABYTE1 = COMMAND MEMORY DATA (H'FE')
   DATABYTE2 = High memory address
   DATABYTE3 = LOW memory address
   DATABYTE4 = memory data
   Remark: address range: H'0000' to H'03FF'
Transmits memory data block (4 bytes):
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 7 databytes to send
   DATABYTE1 = COMMAND_MEMORY_DATA_BLOCK (H'CC')
   DATABYTE2 = High start address of memory block
   DATABYTE3 = LOW start address of memory block
   DATABYTE4 = memory data1
   DATABYTE5 = memory data2
    DATABYTE6 = memory data3
    DATABYTE7 = memory data4
   Remark:
              address range: H'0000' to H'03FC'
              H'0400' to H'07FC' = eeprom data
Transmits the first part of channel name:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 8 databytes to send
   DATABYTE1 = COMMAND CHANNEL NAME PART1 (H'F0')
   DATABYTE2 = channel number 1...9 (channel 9 = temperature sensor name)
   DATABYTE3 = Character 1 of the channel name
   DATABYTE4 = Character 2 of the channel name
   DATABYTE5 = Character 3 of the channel name
   DATABYTE6 = Character 4 of the channel name
   DATABYTE7 = Character 5 of the channel name
   DATABYTE8 = Character 6 of the channel name
Transmits the second part of the channel name:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 8 databytes to send
   DATABYTE1 = COMMAND_CHANNEL_NAME_PART2 (H'F1')
   DATABYTE2 = Channel number 1...9 (channel 9 = temperature sensor name)
   DATABYTE3 = Character 7 of the channel name
   DATABYTE4 = Character 8 of the channel name
   DATABYTE5 = Character 9 of the channel name
   DATABYTE6 = Character 10 of the channel name
   DATABYTE7 = Character 11 of the channel name
```

DATABYTE8 = Character 12 of the channel name

#### Transmits the third part of the channel name:

SID10-SID9 = 11 (lowest priority) SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 6 databytes to send

DATABYTE1 = COMMAND\_CHANNEL\_NAME\_PART3 (H'F2')

DATABYTE2 = channel number 1...9 (channel 9 = temperature sensor name)

DATABYTE3 = Character 13 of the channel name

DATABYTE4 = Character 14 of the channel name

DATABYTE5 = Character 15 of the channel name

DATABYTE6 = Character 16 of the channel name

#### Remarks:

Unused characters contain H'FF'.

#### Transmits the module status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 7 databytes to send

DATABYTE1 = COMMAND MODULE STATUS (H'ED')

DATABYTE2 = channel 1 to 8 status (1 = pressed / 0 = released)

DATABYTE3 = enabled/disable channel status (1 = enabled / 0 = disabled)

DATABYTE4 = normal/inverted channel status (1 = normal / 0 = inverted)

DATABYTE5 = locked channel status (0 = unlocked / 1 = locked)

DATABYTE6 = disabled channel program status (0 = program enabled / 1 = program disabled)

DATABYTE7 = alarm & program selection

Contents	Selected program
B'xxxxxx00'	None
B'xxxxxx01'	Program group 1 (Summer)
B'xxxxxx10'	Program group 2 (Winter)
B'xxxxxx11'	Program group 3 (Holiday)
B'xxxxx0xx'	Clock alarm 1 off
B'xxxxx1xx'	Clock alarm 1 on
B'xxxx0xxx'	Local clock alarm 1
B'xxxx1xxx'	Global clock alarm 1
B'xxx0xxxx'	Clock alarm 2 off
B'xxx1xxxx'	Clock alarm 2 on
B'xx0xxxxx'	Local clock alarm 2
B'xx1xxxxx'	Global clock alarm 2
B'x0xxxxxx'	Sunrise disabled
B'x1xxxxxx'	Sunrise enabled
B'0xxxxxxx'	Sunset disabled
B'1xxxxxxx'	Sunset enabled

### Transmit the sensor status:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND TEMP SENSOR STATUS (H'EA')

DATABYTE2 = Operating mode

Contents	Operating mode
xxxxxxx1	Mode push button locked
xxxxxxx0	Mode push button unlocked
Xxxxx11x	Disable mode
xxxxx01x	Manual mode
xxxxx10x	Sleep timer mode
xxxxx00x	Run mode
xxxx1xxx	Auto send sensor temperature enabled
xxxx0xxx	Auto send sensor temperature disabled
x100xxxx	Comfort mode
x010xxxx	Day mode

x001xxxx	Night mode
x000xxxx	Safe temp mode (anti frost)
1xxxxxxx	Cooler mode
0xxxxxxx	Heater mode

DATABYTE3 = Program step mode

Contents	Program step mode
xxxxx0xx	No sensor program group 1
xxxxx1xx	Sensor program group 1 available
xxxx0xxx	No sensor program group 2
xxxx1xxx	Sensor program group 2 available
0xxxxxxx	No sensor program group 3
1xxxxxxx	Sensor program group 3 available
x100xxxx	Comfort program step received
x010xxxx	Day program step received
x001xxxx	Night program step received
X000xxxx	Safe temperature program step received
xxxxxx1x	Enable unjamming heater valve
xxxxxx0x	Disable unjamming heater valve
xxxxxxx1	Enable unjamming pump
xxxxxxx0	Disable unjamming pump

DATABYTE4 =  $\overline{\text{Output status } (1 = \text{activated})}$ 

Contents	Output channel
xxxxxxx0	Heater off
xxxxxxx1	Heater on
xxxxxx0x	Boost heater/cooler off
xxxxxx1x	Boost heater/cooler on
xxxxx0xx	Pump off
xxxxx1xx	Pump on
xxxx0xxx	Cooler off
xxxx1xxx	Cooler on
xxx0xxxx	Temperature alarm 1 off
xxx1xxxx	Temperature alarm 1 on
xx0xxxxx	Temperature alarm 2 off
xx1xxxxxx	Temperature alarm 2 on
x0xxxxxx	Temperature alarm 3 off
x1xxxxxx	Temperature alarm 3 on
0xxxxxxx	Temperature alarm 4 off
1xxxxxxx	Temperature alarm 4 on

DATABYTE5 = Current sensor temperature into two's complement format (resolution 0.5°)

Contents	Current sensor temperature
01111111	63.5°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
10010010	-55°C

DATABYTE6 = Current temperature set (resolution  $0.5^{\circ}$ )

Contents	Current temperature set
01101100	54°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
11000000	-32°C

DATABYTE7 = High byte of the sleep timer
DATABYTE8 = Low byte of the sleep timer into minutes

#### Remark:

[DATABYTE7][DATABYTE8] contains a 16-bit sleep timer into minutes (1 to 65.279min).

If the sleep timer contains H'0000', the sleep timer is deactivated.

If the sleep timer contains a value between H'0001' and H'FEFF' (1 to 65.279min), the sleep timer is running for that time.

If the sleep timer contains H'FFFF', the sensor is in manual mode.

#### Transmit the sensor temperature:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 7 databytes to send

DATABYTE1 = COMMAND\_SENSOR\_TEMPERATURE (H'E6')

DATABYTE2 = High byte current sensor temperature

DATABYTE3 = Low byte current sensor temperature into two's complement format (resolution 0.0625°)

DATABYTE4 = High byte minimum sensor temperature

DATABYTE5 = Low byte minimum sensor temperature into two's complement format (resolution 0.0625°)

DATABYTE6 = High byte maximum sensor temperature

DATABYTE7 = Low byte maximum sensor temperature into two's complement format (resolution 0.0625°)

High byte	Low byte	Current sensor temperature
01111111	11100000	63.5°C
00000001	00000000	0.5°C
00000000	10000000	0.25°C
00000000	01000000	0.125°C
00000000	00100000	0.0625°C
00000000	00000000	0°C
11111111	11111111	-0.0625°C
11111111	11011111	-0.125°C
11111111	10011111	-0.25°C
11111110	00011111	-0.5°C
10010010	00011111	-55°C

#### Remark:

The 5 least significant bits of the low byte are always zero.

The low order bytes are not sending with the data length of 4 bytes (resolution 0.5°C)

#### Transmit time statistics

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND TIME STATISTICS (H'C8')

DATABYTE2 = statistics mode index

Contents	Time statistics
10000001	Heating antifreeze mode time statistics
10000010	Heating night mode time statistics
10000100	Heating day mode time statistics
10001000	Heating comfort mode time statistics
10010000	Heating global time statistics
01000001	Cooling standby mode time statistics
01000010	Cooling night mode time statistics
01000100	Cooling day mode time statistics
01001000	Cooling comfort mode time statistics
01010000	Cooling global time statistics

DATABYTE3 = 'ON' time (hours bcd digits 4 & 3)

DATABYTE4 = 'ON' time (hours bcd digits 2 & 1)

DATABYTE5 = 'ON' time (minutes bcd digits 2 & 1)

DATABYTE6 = Mode time (hours bcd digits 4 & 3) DATABYTE7 = Mode time (hours bcd digits 2 & 1)

DATABYTE8 = Mode time (minutes bcd digits 2 & 1)

Remark:

The time is bcd formatted.

Databytes 3, 4 & 5 gives the total 'ON' time of the heater or cooler in the corresponding mode.

Databytes 6, 7 & 8 gives the total time of selected mode.

### Transmit the first part of the sensor settings:

SID10-SID9 = 11 (lowest priority) SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND TEMP SENSOR SETTINGS PART1 (H'E8')

DATABYTE2 = Current temperature set (resolution  $0.5^{\circ}$ )

DATABYTE3 = Comfort temperature set for heating mode (resolution  $0.5^{\circ}$ )

DATABYTE4 = Day temperature set for heating mode (resolution  $0.5^{\circ}$ )

DATABYTE5 = Night temperature set for heating mode (resolution 0.5°)

DATABYTE6 = Anti frost temperature set for heating mode (resolution 0.5°)

DATABYTE7 = Boost temperature difference set (resolution  $0.5^{\circ}$ )

DATABYTE8 = Hysteresis temperature set

Contents	Hysteresis
xxx11111	15.5°C
Xxx00001	0.5°C
Xxx00000	0°C

#### Transmit the second part of the sensor settings:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART2 (H'E9')

DATABYTE2 = Comfort temperature set for cooling mode (resolution 0.5°)

DATABYTE3 = Day temperature set for cooling mode (resolution 0.5°)

DATABYTE4 = Night temperature set for cooling mode (resolution 0.5°)

DATABYTE5 = Safe temperature set for cooling mode (resolution  $0.5^{\circ}$ )

DATABYTE6 = High byte of the default sleep timer

DATABYTE7 = Low byte of the default sleep timer into minutes (1 to 65.279min)

DATABYTE8 = Default auto send temperature time interval into seconds

(Valid range: 10...255s)

(5...9 = auto send on temperature change with min interval 5...9s)

(<4 = auto send disabled)

### Transmit the third part of the sensor settings:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_TEMP SENSOR SETTINGS PART3 (H'C6')

DATABYTE2 = Temperature alarm 1 setting (resolution 0.5°)

DATABYTE3 = Temperature alarm 4 setting (resolution  $0.5^{\circ}$ )

DATABYTE4 = Lower temperature range cool mode (resolution  $0.5^{\circ}$ )

DATABYTE5 = Upper temperature range heat mode (resolution 0.5°)

DATABYTE6 = Calibration offset factor (resolution  $0.5^{\circ}$ )

Contents	Calibration factor
00001111	Calibration factor +7.5°C
00000001	Calibration factor +0.5°C
00000000	Calibration factor +0°C
11111111	Calibration factor -0.5°C
11110000	Calibration factor -8°C

 $DATABYTE7 = \overline{Zone number}$ 

DATABYTE8 = Calibration gain factor

#### Transmit the fourth part of the sensor settings:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_TEMP\_SENSOR\_SETTINGS\_PART4 (H'B9')

DATABYTE2 = Minimum switching time (0...255s)

DATABYTE3 = Pump delayed on time (0...255s)

DATABYTE4 = Pump delayed off time (0...255s)

DATABYTE5 = Temperature alarm 2 setting (resolution 0.5°)

DATABYTE6 = Temperature alarm 3 setting (resolution 0.5°)

DATABYTE7 = Lower temperature range heat mode (resolution  $0.5^{\circ}$ )

DATABYTE8 = Upper temperature range cool mode (resolution 0.5°)

#### Transmit: Clears LEDs on a linked push button module:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the linked push button module for clearing LEDs

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND\_CLEAR LED (H'F5')

DATABYTE2 = LED bit numbers (1 = clear LED)

#### Transmit: Sets LEDs on a linked push button module:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the linked push button module for setting LEDs on

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND\_SET\_LED (H'F6')

DATABYTE2 = LED bit numbers (1 = set LED)

### Transmit: Blinks LEDs slowly on a linked push button module:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the linked push button module for slowly blinking LEDs

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND SLOW BLINKING LED (H'F7')

DATABYTE2 = LED bit numbers (1 = slow blink LED)

### Transmit: Blinks LEDs fast on a linked push button module:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Address of the linked push button module for fast blinking LEDs

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND\_FAST\_BLINKING\_LED (H'F8')

DATABYTE2 = LED bit numbers (1 = fast blink LED)

### Transmits program step info:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND PROGRAM STEP INFO (H'C1')

DATABYTE2 = Program step number (1...85 / 255 step not found)

DATABYTE3 = Program reference

Contents	Description
000xxxxx	Disable program step
001xxxxx	Absolute time
010xxxxx	Wake up time 1 + relative time
011xxxxx	Go to bed time 1 + relative time
100xxxxx	Wake up time 2 + relative time
101xxxxx	Go to bed time 2 + relative time
110xxxxx	Sunrise + relative time
111xxxxx	Sunset + relative time
xxx01111	Rel. time = 3h45min

xxx00001	Rel. time = 15min
xxx00000	Rel. time = 0
xxx11111	Rel. time = -15min
xxx10000	Rel. time = -4h

DATABYTE4 = Program step month & four least significant bits of day

Contents	Description
xxxx0000	Weekly program
xxxx0001	January
xxxx0010	February
xxxx0011	March
xxxx0100	April
xxxx0101	May
xxxx0110	June
xxxx0111	July
xxxx1000	August
xxxx1001	September
xxxx1010	October
xxxx1011	November
xxxx1100	December
xxxx1101	Monthly program
xxxx1110	Monthly program
xxxx1111	Monthly program

Contents byte6	Contents byte4	Description
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1of the month
00xxxxxx	0010xxxx	Day 2of the month
•••	•••	
01xxxxxx	1111xxxx	Day 31of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mofr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
11xxxxxx	1111xxxx	Never

DATABYTE5 = Program step hour & group number

Contents	Description
xxx00000	0h
xxx00001	1h
xxx10111	23h
xx1xxxxx	Program group 1 (Summer program)
x1xxxxxx	Program group 2 (Winter program)
1xxxxxxx	Program group 3 (Holiday program)

DATABYTE6 = Program step minute & every flag & msb of day

-8 ·· · · · · · · · · · · · · · · · · ·	
Contents	Description
xx000000	0min
xx000001	1min
xx111011	59min

Contents byte6	Contents byte4	Description
00xxxxxx	0000xxxx	Never
00xxxxxx	0001xxxx	Day 1of the month
00xxxxxx	0010xxxx	Day 2of the month
•••	•••	
01xxxxxx	1111xxxx	Day 31of the month
10xxxxxx	0000xxxx	Never
10xxxxxx	0001xxxx	Every Monday
10xxxxxx	0010xxxx	Every Tuesday
•••	•••	
10xxxxxx	0111xxxx	Every Sunday
10xxxxxx	1000xxxx	Every weekend (sa & su)
10xxxxxx	1001xxxx	Every working day (mofr)
10xxxxxx	1010xxxx	Every day except Sunday
10xxxxxx	1011xxxx	Every day
10xxxxxx	1100xxxx	Never
•••	•••	
11xxxxxx	1111xxxx	Never

DATABYTE7 = Program step action

Contents	Action
0	0s25 Pulse
1	1s Pulse
2	2s Pulse
119	1min59s Pulse
120	2min Pulse
121	2min15s Pulse
131	4min45s Pulse
132	5min Pulse
133	5min30s Pulse
181	29min30s Pulse
182	30min Pulse
183	31min Pulse
•••	
211	59min Pulse
212	1h Pulse
213	1h15min Pulse
227	4h45min Pulse
228	5h Pulse
229	5h30min Pulse
•••	
237	9h30min Pulse
238	10h Pulse
239	11h Pulse
•••	
246	18h Pulse
247	Press
248	Long Press
249	Release
250	Lock
251	Unlock
252	Sensor: Safe mode
253	Sensor: Night mode
254	Sensor: Day mode
255	Sensor: Comfort mode

## DATABYTE8 = Channel

Contents	Channel	
1	Channel 1 or temperature sensor	
2	Channel 2	
7	Channel 7	
8	Channel 8	

#### 'Linked push button status' received:

SID10-SID9 = 00 (highest priority)

SID8...SID1 = Address of the linked push button module

RTR = 0

DLC3...DLC0 = 4 databytes received

DATABYTE1 = COMMAND PUSH BUTTON STATUS (H'00')

DATABYTE2 = Linked push buttons just pressed (1 = just pressed)

DATABYTE3 = Linked push buttons just released (1 = just released)

DATABYTE4 = linked push buttons long pressed (1 = longer than 0.85s pressed)

#### Power up message' received

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 2 databyte to send

DATABYTE1 = COMMAND POWER UP (H'AB')

DATABYTE2 = module address

### 'Real time clock status request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 1 databyte to send

DATABYTE1 = COMMAND REALTIME CLOCK STATUS REQUEST (H'D7')

Remark: The real time clock status will only be send if master clock is on

#### 'Set real time clock' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 4 databytes to send

DATABYTE1 = COMMAND SET\_REALTIME\_CLOCK (H'D8')

DATABYTE2 = Day of week

Contents day of week'	Description
H'00'	Monday
H'01'	Tuesday
H'02'	Wednesday
H'03'	Thursday
H'04'	Friday
H'05'	Saterday
H'06'	Sunday

DATABYTE3 = Hours (0...23)

DATABYTE4 = Minutes (0...59)

### 'Set date' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 5 databytes to send

DATABYTE1 = COMMAND\_SET\_REALTIME\_DATE (H'B7')

DATABYTE2 = Day (1...31)

DATABYTE3 = Month (1...12)

DATABYTE4 = High byte of Year

DATABYTE5 = Low byte of Year

### 'Set daylight savings' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND SET DAYLIGHT SAVING (H'AF')

DATABYTE2 = 0 = disabled / 1 = enabled

#### 'Enable/disable global sunrise/sunset related actions' command received:

```
SID10-SID9 = 11 (lowest priority)
```

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 3 databytes to send

DATABYTE1 = COMMAND\_ENA\_DIS\_SUNRISE\_SUNSET (H'AE')

DATABYTE2 = Channel (FF)

DATABYTE3 = enable/disable flags

Contents	Description
B'xxxxxxx0'	Disable sunrise related actions
B'xxxxxx1'	Enable sunrise related actions
B'xxxxxx0x'	Disable sunset related actions
B'xxxxxx1x'	Enable sunset related actions

#### 'Enable/disable local sunrise/sunset related actions' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes to send

DATABYTE1 = COMMAND\_ENA\_DIS\_SUNRISE\_SUNSET (H'AE')

DATABYTE2 = Channel (FF)

DATABYTE3 = enable/disable flags

Contents	Description
B'xxxxxxx0'	Disable sunrise related actions
B'xxxxxxx1'	Enable sunrise related actions
B'xxxxxx0x'	Disable sunset related actions
B'xxxxxx1x'	Enable sunset related actions

#### 'Set global clock alarm' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = H'00'

RTR = 0

DLC3...DLC0 = 7 databytes to send

DATABYTE1 = COMMAND SET ALARM CLOCK (H'C3')

DATABYTE2 = Alarm number (1 or 2)

DATABYTE3 = Wake up hour (0...23)

DATABYTE4 = Wake up minute (0...59)

DATABYTE5 = Go to bed hour (0...23)

DATABYTE6 = Go to bed minute (0...59)

DATABYTE7 = Clock alarm enable flag (0 = disabled / 1 = enabled)

#### 'Set local clock alarm' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 7 databytes to send

DATABYTE1 = COMMAND\_SET\_ALARM\_CLOCK (H'C3')

DATABYTE2 = Alarm number (1 or 2)

DATABYTE3 = Wake up hour (0...23)

DATABYTE4 = Wake up minute (0...59)

DATABYTE5 = Go to bed hour (0...23)

DATABYTE6 = Go to bed minute (0...59)

DATABYTE7 = Clock alarm enable flag (0 = disabled / 1 = enabled)

### 'Module type request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 1

DLC3...DLC0 = 0 databytes received

```
'Module status request' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 databytes received
   DATABYTE1 = COMMAND MODULE STATUS REQUEST (H'FA')
   DATABYTE2 = don't care
'Channel name request' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 databytes received
   DATABYTE1 = COMMAND CHANNEL NAME REQUEST (H'EF')
   DATABYTE2 = channel number 1...9 (9 for temperature sensor name)
   Remark: channel = H'FF' for all 8 channel names & temperature sensor name
'Clear channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 databytes received
   DATABYTE1 = COMMAND CLEAR LED (H'F5')
   DATABYTE2 = LEDs to clear (a one clears the corresponding LED of channel 1 to 8)
'Set channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 databytes received
   DATABYTE1 = COMMAND SET LED (H'F6')
   DATABYTE2 = LEDs to set (a one sets the corresponding LED of channel 1 to 8)
'Slow blink channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 databytes received
   DATABYTE1 = COMMAND SLOW BLINK LED (H'F7')
   DATABYTE2 = LEDs to blink slow (a one blinks slow the corresponding LED of channel 1 to 8)
'Fast blink channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 databytes received
   DATABYTE1 = COMMAND_FAST_BLINK_LED (H'F8')
   DATABYTE2 = LEDs to blink fast (a one blinks fast the corresponding LED of channel 1 to 8)
'Very fast blink channel LED' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 2 databytes received
   DATABYTE1 = COMMAND VERY FAST BLINK LED (H'F9')
```

DATABYTE2 = LEDs to blink very fast (a one blinks very fast the corresponding LED of channel 1 to 8)

```
'Update channel LEDs' command received:
```

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 databytes received

DATABYTE1 = COMMAND UPDATE LED STATUS (H'F4')

DATABYTE2 = LEDs to set (a one sets the corresponding LED of channel 1 to 8)

DATABYTE3 = LEDs to blink slow (a one blinks slow the corresponding LED of channel 1 to 8)

DATABYTE4 = LEDs to blink fast (a one blinks very fast the corresponding LED of channel 1 to 8)

#### Remark:

The 'LEDs to set' status overrides the blinking modes.

Very fast blinking if slow & fast blinking are set.

#### 'Read data from memory' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes received

DATABYTE1 = COMMAND\_READ\_DATA\_FROM\_MEMORY (H'FD')

DATABYTE2 = High memory address

DATABYTE3 = LOW memory address

Remark: address range: H'0000' to H'03FF'

### 'Read data block from memory' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes received

DATABYTE1 = COMMAND READ MEMORY BLOCK (H'C9')

DATABYTE2 = High memory address

DATABYTE3 = LOW memory address

Remark: address range: H'0000' to H'03FC'

#### 'Memory dump request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 1 databytes received

DATABYTE1 = COMMAND\_MEMORY\_DUMP\_REQUEST (H'CB')

### 'Write data to memory' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 4 databytes received

DATABYTE1 = COMMAND\_WRITE\_DATA\_TO\_MEMORY (H'FC')

DATABYTE2 = High memory address

DATABYTE3 = LOW memory address

DATABYTE4 = memory data to write

#### Remark:

Wait at least 10ms for sending a next command on the velbus.

Address range: H'0000' to H'03FF'

Terminate always with a write command at the last memory location.

```
'Write memory block' command received:
   SID10-SID9 = 11 (lowest priority)
   SID8...SID1 = Module address
   RTR = 0
   DLC3...DLC0 = 7 databytes received
   DATABYTE1 = COMMAND_WRITE_MEMORY BLOCK (H'CA')
   DATABYTE2 = High memory address
   DATABYTE3 = LOW memory address
   DATABYTE4 = memory databyte1 to write
   DATABYTE5 = memory databyte2 to write
   DATABYTE6 = memory databyte3 to write
   DATABYTE7 = memory databyte4 to write
   Remark:
   Wait for 'memory data block' feedback before sending a next command on the velbus.
   Terminate always with a write command at the last memory location.
   Address range: H'0000' to H'03FC'
'Bus error counter status request' command received:
   SID10-SID9 = 11 (lowest priority)
```

SID8...SID1 = Module address RTR = 0DLC3...DLC0 = 1 databytes to send DATABYTE1 = COMMAND\_BUS\_ERROR\_COUNTER STATUS REQUEST (H'D9')

#### 'Unlock channel' command received:

SID10-SID9 = 00 (highest priority) SID8...SID1 = Module address RTR = 0DLC3...DLC0 = 2 databytes received DATABYTE1 = COMMAND CANCEL FORCED OFF (H'13') DATABYTE2 = Channel number (1...9) (9 for enable temperature sensor)

Remark: channel number = H'FF' for all 8 channels

#### 'Lock channel' command received:

SID10-SID9 = 00 (highest priority) SID8...SID1 = Module address RTR = 0DLC3...DLC0 = 5 databytes received DATABYTE1 = COMMAND FORCED OFF (H'12') DATABYTE2 = Channel number (1...9) (9 for disable temperature sensor) DATABYTE3 = high byte of delay time DATABYTE4 = mid byte of delay time DATABYTE5 = low byte of delay time

# Remark:

Channel number = H'FF' for all 8 channels

[DATABYTE3][DATABYTE4][DATABYTE5] contain a 24-bit time in seconds

The command will be skipped when the time parameter contains zero.

When the time parameter contains H'FFFFFF' then the channel will be permanently locked.

### 'Enable Channel Program' command received:

SID10-SID9 = 11 (lowest priority) SID8...SID1 = Module address RTR = 0DLC3...DLC0 = 2 databytes received DATABYTE1 = COMMAND ENABLE PROGRAM (H'B2') DATABYTE2 = Channel number (1...8)

Remark: channel number = H'FF' for all 8 channels

#### 'Disable Channel Program' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 5 databytes received

DATABYTE1 = COMMAND\_DISABLE\_PROGRAM (H'B1')

DATABYTE2 = Channel number (1...8)DATABYTE3 = high byte of delay time

DATABYTE4 = mid byte of delay time

DATABYTE5 = low byte of delay time

#### Remark:

Channel number = H'FF' for all 8 channels

[DATABYTE3][DATABYTE4][DATABYTE5] contain a 24-bit time in seconds

The command will be skipped when the time parameter contains zero.

When the time parameter contains H'FFFFFF' then the channel program will be permanently disabled.

### 'Select Program' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 databytes received

DATABYTE1 = COMMAND SELECT PROGRAM (H'B3')

DATABYTE2 = Program mode

Contents	Selected programl
0	None
1	Program group 1 (Summer)
2	Program group 2 (Winter)
3	Program group 3 (Holiday)

#### 'Sensor temperature request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND SENSOR TEMP REQUEST (H'E5')

DATABYTE2 = Autosend time interval into seconds

(valid range: 10...255s)

(5...9 = auto send on temperature change)

(1...4 = auto send disabled)

(0 = no change on auto send interval)

### 'Sensor settings request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND TEMP SENSOR SETTINGS REQUEST (H'E7')

DATABYTE2 = don't care

### 'Set heating mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 databytes received

DATABYTE1 = COMMAND SET HEATING MODE (H'E0')

DATABYTE2 = don't care

#### 'Set cooling mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 databytes received

DATABYTE1 = COMMAND\_SET\_COOLING\_MODE (H'DF')

DATABYTE2 = don't care

### 'Set sensor zone number' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND\_SET\_SENSOR\_ZONE\_NUMBER (H'C5')

DATABYTE2 = Zone number (0= no zone / 1...7 = valid zone)

Remark: The module answers with his type

### 'Set default sleep time' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes received

DATABYTE1 = COMMAND\_SET\_DEFAULT\_SLEEP\_TIME (H'E3')

DATABYTE2 = High byte of the default sleep time

DATABYTE3 = Low byte of the default sleep time into minutes

(valid range H'0001' to H'FEFF' or 1min to 65.279min)

Remark: Wait at least 20ms for sending a next command on the velbus

#### 'Set temperature' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes received

DATABYTE1 = COMMAND SET TEMP (H'E4')

DATABYTE2 = Pointer to temperature variable (0...20)

Contents	Temperature variable
0	Current temperature set
1	Comfort temperature set for heating
2	Day temperature set for heating
3	Night temperature set for heating
4	Safe temperature set for heating
5	Temperature difference for turbo output
6	Hysteresis (0°15.5°C)
7	Comfort temperature set for cooling
8	Day temperature set for cooling
9	Night temperature set for cooling
10	Safe temperature set for cooling
11	Calibration offset factor (-8°+7.5°C)
12	Reset minimum/maximum temperature
13	Reset time statistics
14	enable/disable anti-block valve/pump
15	Temperature alarm 1 set
16	Temperature alarm 4 set
17	Lower temperature range cool mode
18	Upper temperature range heat mode
19	Differential sensor address (H'FF' = no diff. sensor)
20	Target temperature set for the differential sensor
21	Minimum switching time
22	Pump delayed on time
23	Pump delayed off time
24	Temperature alarm 2 set
25	Temperature alarm 3 set

26	Lower temperature range heat mode
27	Upper temperature range cool mode
28	Calibration gain factor

DATABYTE3 = Temperature set (resolution  $0.5^{\circ}$ )

Contents	Temperature set
01111111	63.5°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
10010010	-55°C

DATABYTE3 = Reset minimum/maximum temperature

Contents	Reset temperature
00000001	Reset minimum temperature
00000010	Reset maximum temperature

DATABYTE3 = Reset time statistics mode index

Contents	Reset time statistics
10000001	Reset heating antifreeze mode time statistics
10000010	Reset heating night mode time statistics
10000100	Reset heating day mode time statistics
10001000	Reset heating comfort mode time statistics
10010000	Reset heating global time statistics
01000001	Reset cooling standby mode time statistics
01000010	Reset cooling night mode time statistics
01000100	Reset cooling day mode time statistics
01001000	Reset cooling comfort mode time statistics
01010000	Reset cooling global time statistics

DATABYTE3 = Enable/disable unjamming heater valve & pump

-	Zinacie, disacie diffamining neater varie de pump		
	Contents	Enable/disable unjamming valve and pump	
	00000000	Disable unjamming heater valve & pump	
	00000001	Disable unjamming heater valve & enable unjamming pump	
	00000010	Enable unjamming heater valve & disable unjamming pump	
	00000011	Enable unjamming heater valve & pump	

DATABYTE3 = Minimum switching time:

Contents	Operating mode
00000000	No switching time protection
00000001	1 minute switching time protection
00000010	2 minute switching time protection
11111110	254 minute switching time protection
11111111	Default 1 minute switching time protection

### Remark:

Valid hysteresis range =  $0 \dots 15.5$ °C

Valid calibration factor range =  $-8 \dots 7.5$ °C

Wait at least 10ms for sending a next command on the velbus.

#### 'Switch to comfort mode' command received:

SID10-SID9 = 11 (lowest priority) SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes received

DATABYTE1 = COMMAND SWITCH TO COMFORT MODE (H'DB')

DATABYTE2 = High byte of the sleep time

DATABYTE3 = Low byte of the sleep time into minutes

#### Remark:

If the sleep time contains H'FF00', the command is a program step.

A sleep time between H'0001' and H'FEFF' (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of H'FFFF' puts the sensor into manual mode. Program steps will not be executed any more and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

### 'Switch to day mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes received

DATABYTE1 = COMMAND SWITCH TO DAY MODE (H'DC')

DATABYTE2 = High byte of the sleep time

DATABYTE3 = Low byte of the sleep time into minutes

#### Remark:

If the sleep time contains H'FF00', the command is a program step.

A sleep time between H'0001' and H'FEFF' (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of H'FFFF' puts the sensor into manual mode. Program steps will not be executed any more and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

### 'Switch to night mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes received

DATABYTE1 = COMMAND SWITCH TO NIGHT MODE (H'DD')

DATABYTE2 = High byte of the sleep time

DATABYTE3 = Low byte of the sleep time into minutes

#### Remark:

If the sleep time contains H'FF00', the command is a program step.

A sleep time between H'0001' and H'FEFF' (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of H'FFFF' puts the sensor into manual mode. Program steps will not be executed anymore and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

#### 'Switch to safe temperature mode' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 3 databytes received

DATABYTE1 = COMMAND\_SWITCH\_TO\_SAFE\_MODE (H'DE')

DATABYTE7 = High byte of the sleep time

DATABYTE8 = Low byte of the sleep time into minutes

#### Remark:

If the sleep time contains H'FF00', the command is a program step.

A sleep time between H'0001' and H'FEFF' (1 to 65.279min) starts the sleep timer for that time and program steps will not be executed during that time.

A sleep time of H'FFFF' puts the sensor into manual mode. Program steps will not be executed anymore and local control is disabled.

A value of zero for the sleep time cancels the manual mode or sleep timer.

### 'Time statistics request' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 2 databytes to send

DATABYTE1 = COMMAND TIME STATISTICS REQUEST (H'C7')

DATABYTE2 = statistics mode index

Contents	Time statistics request	
10000001	Heating antifreeze mode time statistics	
10000010	Heating night mode time statistics	
10000100	Heating day mode time statistics	
10001000	Heating comfort mode time statistics	
10010000	Heating global time statistics	
01000001	Cooling standby mode time statistics	
01000010	Cooling night mode time statistics	
01000100	Cooling day mode time statistics	
01001000	Cooling comfort mode time statistics	
01010000	Cooling global time statistics	

### 'Read program step' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 5 databytes to send

DATABYTE1 = COMMAND READ PROGRAM STEP (H'C0')

DATABYTE2 = Start program step number (1...85)

DATABYTE3 = Program group number (1...3)

DATABYTE4 = Channel (1...8 for buttons or 128 for temperature channel)

DATABYTE5 = Search direction (1 = search for next matched step / 0 = search for previous matched program step)

### 'Write program step' command received:

SID10-SID9 = 11 (lowest priority)

SID8...SID1 = Module address

RTR = 0

DLC3...DLC0 = 8 databytes to send

DATABYTE1 = COMMAND\_WRITE\_PROGRAM STEP (H'C2')

DATABYTE2 = Program step number (1...85)

DATABYTE3 = Program reference

Contents	Description	
000xxxxx	Disable program step	
001xxxxx	Absolute time	
010xxxxx	Wake up time 1 + relative time	
011xxxxx	Go to bed time 1 + relative time	
100xxxxx	Wake up time 2 + relative time	
101xxxxx	Go to bed time 2 + relative time	
110xxxxx	Sunrise + relative time	
111xxxxx	Sunset + relative time	

xxx01111	Rel. time = 3h45min
xxx00001	Rel. time = 15min
xxx00000	Rel. time = $0$
xxx11111	Rel. time = -15min
xxx10000	Rel. time = -4h

DATABYTE4 = Program step month & four least significant bits of day

Contents	Description
xxxx0000	Weekly program
xxxx0001	January
xxxx0010	February
xxxx0011	March
xxxx0100	April
xxxx0101	May
xxxx0110	June
xxxx0111	July
xxxx1000	August
xxxx1001	September
xxxx1010	October
xxxx1011	November
xxxx1100	December
xxxx1101	Monthly program
xxxx1110	Monthly program
xxxx1111	Monthly program

Contents byte6	Contents byte4	Description	
00xxxxxx	0000xxxx	Never	
00xxxxxx	0001xxxx	Day 1of the month	
00xxxxxx	0010xxxx	Day 2of the month	
	•••		
01xxxxxx	1111xxxx	Day 31of the month	
10xxxxxx	0000xxxx	Never	
10xxxxxx	0001xxxx	Every Monday	
10xxxxxx	0010xxxx	Every Tuesday	
••	•••		
10xxxxxx	0111xxxx	Every Sunday	
10xxxxxx	1000xxxx	Every weekend (sa & su)	
10xxxxxx	1001xxxx	Every working day (mofr)	
10xxxxxx	1010xxxx	Every day except Sunday	
10xxxxxx	1011xxxx	Every day	
10xxxxxx	1100xxxx	Never	
11xxxxxx	1111xxxx	Never	

DATABYTE5 = Program step hour & group number

Contents	Description	
xxx00000	Oh	
xxx00001	1h	
xxx10111	23h	
xx1xxxxx	Program group 1 (Summer program)	
x1xxxxxx	Program group 2 (Winter program)	
1xxxxxxx	Program group 3 (Holiday program)	

DATABYTE6 = Program step minute & msb of day & every flag

Contents	Description
xx000000	0min
xx000001	1min

xx111011	59min

Contents byte6	Contents byte4	Description	
00xxxxxx	0000xxxx	Never	
00xxxxxx	0001xxxx	Day 1of the month	
00xxxxxx	0010xxxx	Day 2of the month	
•••			
01xxxxxx	1111xxxx	Day 31of the month	
10xxxxxx	0000xxxx	Never	
10xxxxxx	0001xxxx	Every Monday	
10xxxxxx	0010xxxx	Every Tuesday	
	•••		
10xxxxxx	0111xxxx	Every Sunday	
10xxxxxx	1000xxxx	Every weekend (sa & su)	
10xxxxxx	1001xxxx	Every working day (mofr)	
10xxxxxx	1010xxxx	Every day except Sunday	
10xxxxxx	1011xxxx	Every day	
10xxxxxx	1100xxxx	Never	
	•••		
11xxxxxx	1111xxxx	Never	

DATABYTE7 = Program step action

Contents	Action	
0	0s25 Pulse	
1	1s Pulse	
2	2s Pulse	
119	1min59s Pulse	
120	2min Pulse	
121	2min15s Pulse	
131	4min45s Pulse	
132	5min Pulse	
133	5min30s Pulse	
181	29min30s Pulse	
182	30min Pulse	
183	31min Pulse	
211	59min Pulse	
212	1h Pulse	
213	1h15min Pulse	
•••		
227	4h45min Pulse	
228	5h Pulse	
229	5h30min Pulse	
237	9h30min Pulse	
238	10h Pulse	
239	11h Pulse	
•••		
246	18h Pulse	
247	Press	
248	Long Press	
249	Release	
250	Lock	
251	Unlock	
252	Sensor: Safe mode	
253	Sensor: Night mode	
254	Sensor: Day mode	
255	Sensor: Comfort mode	

## DATABYTE8 = Channel

<del></del>		
Contents	Channel	
1	Channel 1 or temperature sensor	
2	Channel 2	
7	Channel 7	
8	Channel 8	

# Memory map version 2 for build 1803 or higher: (PCB With New Touch Controller CAP1188)

Address	Contents	Address	Contents
H'0000'	Channel 1 name character 1	H'0001'	Channel 1 name character 2
H'000E'	Channel 1 name character 15	H'000F'	Channel 1 name character 16
H'0010'	Channel 1 reaction time	H'0011'	Channel 1 start function
H'0012'	Channel 1 end function	H'0013'	Channel 1 mode
H'0014'	Channel 2 name character 1	H'0015'	Channel 2 name character 2
H'0022'	Channel 2 name character 15	H'0023'	Channel 2 name character 16
H'0024'	Channel 2 reaction time	H'0025'	Channel 2 start function
H'0026'	Channel 2 end function	H'0027'	Channel 2 mode
H'008C'	Channel 8 name character 1	H'0089'	Channel 8 name character 2
	Channel 9 manus abanceton 15	 Н'009В'	Channel 9 mama abancatan 16
H'009A' H'009C'	Channel 8 name character 15 Channel 8 reaction time	H'009B	Channel 8 name character 16 Channel 8 start function
H'009E'	Channel 8 end function	H'009D'	Channel 8 mode
H'00A0'	Long pressed delay	H'00A1'	Dual function long pressed time
H'00A2'	Led backlight intensity	H'00A3'	Led intensity
H'00A4'	Alarm clock configuration	H'00A5'	Wake up 1 hour (023)
H'00A6'	Wake up 1 minutes (059)	H'00A7'	Go to bed 1 hour (023)
H'00A8'	Go to bed 1 minutes (059)	H'00A9'	Wake up 2 hour (023)
H'00AA'	Wake up 2 minutes (059)	H'00AB'	Go to bed 2 hour (023)
H'00AC'	Go to bed 2 minutes (059)	H'00AD'	Sunrise hour at 21 December (023)
H'00AE'	Sunrise minutes at 21 December (059)	H'00AF'	Sunrise 21 January – sunrise 5 January (-128'127')
H'00B0'	Sunrise 5 February – sunrise 21 January (-128'127')	H'00B1'	Sunrise 21 February – sunrise 5 February (-128'127')
H'00B2'	Sunrise 5 March – sunrise 21 February (-128'127')	H'00B3'	Sunrise 21 March – sunrise 5 March (-128'127')
H'00B4'	Sunrise 5 April – sunrise 21 March (-128'127')	H'00B5'	Sunrise 21 April – sunrise 5 April (-128'127')
H'00B6'	Sunrise 5 May – sunrise 21 April (-128'127')	H'00B7'	Sunrise 21 May – sunrise 5 May (-128'127')
H'00B8'	Sunrise 5 June – sunrise 21 May (-128'127')	H'00B9'	Sunrise 21 June – sunrise 5 June (-128'127')
H'00BA'	Sunrise 5 July – sunrise 21 June (-128'127')	H'00BB'	Sunrise 21 July – sunrise 5 July (-128'127')
H'00BC'	Sunrise 5 August – sunrise 21 July (-128'127')	H'00BD'	Sunrise 21 August – sunrise 5 August (-128'127')
H'00BE' H'00C0'	Sunrise 5 September – sunrise 21 August (-128'127') Sunrise 5 October – sunrise 21 September (-128'127')	H'00BF' H'00C1'	Sunrise 21 September – sunrise 5 September (-128127') Sunrise 21 October – sunrise 5 October (-128'127')
H'00C0'	Sunrise 5 October – sunrise 21 September (-128127)  Sunrise 5 November – sunrise 21 October (-128127)	H'00C3'	Sunrise 21 November – sunrise 5 November (-128'127')
H'00C4'	Sunrise 5 December – sunrise 21 November (-128'127')	H'00C5'	Sunrise 21 December – sunrise 5 December (-128'127')
H'00C6'	Sunrise 5 January – sunrise 21 December (-128'127')	H'00C7'	Sunset hour at 21 December (023)
H'00C8'	Sunset minutes at 21 December (059)	H'00C9'	Sunset 21 January – sunset 5 January (-128'127')
H'00CA'	Sunset 5 February – sunset 21 January (-128'127')	H'00CB'	Sunset 21 February – sunset 5 February (-128'127')
H'00CC'	Sunset 5 March – sunset 21 February (-128'127')	H'00CD'	Sunset 21 March – sunset 5 March (-128'127')
H'00CE'	Sunset 5 April – sunset 21 March (-128'127')	H'00CF'	Sunset 21 April – sunset 5 April (-128'127')
H'00D0'	Sunset 5 May – sunset 21 April (-128'127')	H'00D1'	Sunset 21 May – sunset 5 May (-128'127')
H'00D2'	Sunset 5 June – sunset 21 May (-128'127')	H'00D3'	Sunset 21 June – sunset 5 June (-128'127')
H'00D4'	Sunset 5 July – sunset 21 June (-128'127')	H'00D5'	Sunset 21 July – sunset 5 July (-128'127')
H'00D6'	Sunset 5 August – sunset 21 July (-128'127')	H'00D7'	Sunset 21 August – sunset 5 August (-128'127')
H'00D8'	Sunset 5 September – sunset 21 August (-128'127')	H'00D9'	Sunset 21 September – sunset 5 September (-128'127')
H'00DA' H'00DC'	Sunset 5 October – sunset 21 September (-128'127')	H'00DB' H'00DC'	Sunset 21 October – sunset 5 October (-128'127')
H'00DE'	Sunset 5 November – sunset 21 October (-128'127')  Sunset 5 December – sunset 21 November (-128'127')	H'00DC	Sunset 21 November – sunset 5 November (-128'127') Sunset 21 December – sunset 5 December (-128'127')
H'00E0'	Sunset 5 January – sunset 21 November (-128127)  Sunset 5 January – sunset 21 December (-128'127')	H'00E1'	Sensor name character 1
H'00E2'	Sensor name character 2	H'00E3'	Sensor name character 3
H'00F0'	Sensor name character 16	H'00F1'	Temp. sensor: zone
H'00F2'	Temp. sensor: flags	H'00F3'	Temp. sensor: calibration offset
H'00F4'	Temp. sensor: calibration gain	H'00F5'	Temp. sensor: hysteresis
H'00F6'	Temp. sensor: boost difference	H'00F7'	Temp. sensor: Pump delayed on
H'00F8'	Temp. sensor: pump delayed off	H'00F9'	Temp. sensor: min switching time
H'00FA'	Temp. sensor: default sleep time low byte	H'00FB'	Temp. sensor: default sleep time high byte
H'00FC'	Temp. sensor: heater lower temperature range	H'00FD'	Temp. sensor: heater upper temperature range
H'00FE'	Temp. sensor: heater safe temperature set	H'00FF'	Temp. sensor: heater night temperature set
H'0100'	Temp. sensor: heater day temperature set	H'0101'	Temp. sensor: heater comfort temperature set
H'0102'	Temp. sensor: cooler lower temperature range	H'0103'	Temp. sensor: cooler upper temperature range
H'0104'	Temp. sensor: cooler safe temperature set	H'0105'	Temp. sensor: cooler night temperature set
H'0106'	Temp. sensor: cooler day temperature set	H'0107'	Temp. sensor: cooler comfort temperature set

H'0108'	Temp. sensor: alarm 1 temperature set	H'0109'	Temp. sensor: alarm 2 temperature set
H'010A'	Temp. sensor: alarm 3 temperature set	H'010B'	Temp. sensor: alarm 4 temperature set
H'010C'	Temp. sensor alarm1 & 2 modes	H'010D'	Temp. sensor alarm3 & 4 modes
H'010E'	Module settings	H'010F'	Unused field

#### Remark:

Unused locations contain H'FF'

#### Valid reaction times

Contents	Reaction time
H'01'	immediatly (default)
H'4C'	1s
Н'99'	2s
H'E0'	3s
H'FF'	Channel disabled

### Channel x start/end function

Contents	Function
1	Channel 1 (default)
2	Channel 2 (default)
7	Channel 7 (default)
8	Channel 8 (default)

#### Remark:

For a normal one function button, the start and end function channel are the same.

For a multi function button, the start function channel must be less than the end function. At every press the next channel will be send. When the end function channel is reached, the start channel will be send again at the next press.

For a dual function button, the start function channel will be send at a short press or the end function will be send at a long press.

### Channels mode

Contents	Description
B'xxxxxxx0'	Dual function disabled (default)
B'xxxxxxx1'	Dual function enabled
B'xxxxxx0x'	Multi-function auto reset disabled (default)
B'xxxxxx1x'	Multi-function auto reset enabled
B'xxxxx0xx'	Led backlight off
B'xxxxx1xx'	Led backlight on
B'xxxx0xxx'	Led feedback off (default)
B'xxxx1xxx'	Led feedback on (default)
B'xxx0xxxx'	Slow blinking led feedback off
B'xxx1xxxx'	Slow blinking led feedback on (default)
B'xx0xxxxx'	Fast blinking led feedback off
B'xx1xxxxx'	Fast blinking led feedback on (default)
B'x0xxxxxx'	Very fast blinking led feedback off
B'x1xxxxxx'	Very fast blinking led feedback on (default)

### Remark:

When auto reset is enabled, the start function will be loaded again after 3 seconds inactivity of the channel. For a dual function button, the start function channel will be send at a short press or the end function will be send at a long press.

The dual function overwrites the multi-function mode.

#### Valid long pressed delay

Contents	Reaction time
H'40'	0.8s (default)
H'80'	1.6s

Valid dual function long pressed times

Contents	Long pressed time
H'4C'	1s
Н'99'	2s (default)

H'E0'	3s

Led backlight intensity

Contents	Led backlight intensity	
H'01'	Minimum	
•••		
H'05'	default	
H'0F'	Maximum	

Led intensity

Contents	Led intensity	
H'10'	Minimum	
H'29'	Maximum (default)	

Alarm clock configuration

Contents	Channel locked/unlocked
B'xxxxxxx0'	Alarm 1 disabled (default)
B'xxxxxxx1'	Alarm 1 enabled
B'0xxxxx0x'	Local alarm 1 (default)
B'lxxxxxlx'	Global alarm 1
B'xxxxx0xx'	Alarm 2 disabled (default)
B'xxxxx1xx'	Alarm 2 enabled
B'xxxx0xxx'	Local alarm 2 (default)
B'xxxx1xxx'	Global alarm 2
B'xxx0xxxx'	Sunrise disabled
B'xxx1xxxx'	Sunrise enabled (default)
B'xx0xxxxx'	Sunset disabled
B'xx1xxxxx'	Sunset enabled (default)
B'x0xxxxxx'	Day light savings disabled
B'x1xxxxxx'	Day light savings enabled (default)

Module settings

g.		
Contents	Description	
B'x0xxxxxx'	Keybeep off	
B'x1xxxxxx'	Keybeep enabled (default)	

Temp. sensor zone

T. T		
Contents	Zone	
0'	No zone	
1.	Zone 1	
7	Zone 7	

Temp. sensor flags

Contents	Contents Description		
B'xxxxxxx0' Pump unjamming disabled (default)			
B'xxxxxxx1'	Pump unjamming enabled		
B'xxxxxx0x'	Heater valve unjamming disabled (default)		
B'xxxxxx1x'	Heater valve unjamming enabled		
B'xxxxx0xx'	Not used (default)		
B'xxxxx1xx'	Not used		
B'xxxx0xxx'	Not used (default)		
B'xxxx1xxx'	Not used		
B'xxx0xxxx' VMBGP4 local thermostat control starts sleep timer at long press( defa			
B'xxx1xxxx'	VMBGP4 local thermostat control starts sleep timer at short press		
B'xx0xxxxx'	Independent temperature alarms (default)		
B'xx1xxxxx'	Dependent temperature alarms		
B'x0xxxxxx'	Normal Led indication (default)		
B'x1xxxxxx'	Thermostat Led indication for VMBGP4		
B'0xxxxxxx'	Button 4 of VMBGP4 operates normal (default)		
B'lxxxxxxx'	Button 4 of VMBGP4 as local thermostat control		

Temp. sensor calibration offset (resolution  $0.5^{\circ}$ ):

Contents	Calibration offset
00001111	Calibration offset +7.5°C
00000001	Calibration offset +0.5°C
00000000	Calibration offset +0°C (default)
11111111	Calibration offset -0.5°C
11110000	Calibration offset -8°C

Temp. sensor calibration gain:

٠,	emp. sensor canoration gain.		
	Contents	Calibration gain	
	0	Calibration gain	
	128	Calibration gain (default)	
	255	Calibration gain	

Calibrated Temperature = (gain/128) \* sensortemperature + offset

Temp. sensor hysteresis (resolution 0.5°):

Contents	Hysteresis
00011111	15.5°C
00000001	0.5°C
00000000	0°C

Temp. sensor boost difference (resolution 0.5°):

emp. sensor boost afference (resolution 0.5 ).		
Contents	Temperature difference	
00010100	+10°C	
00000001	+0.5°C	
00000000	0°C	
11111111	-0.5°C	
11101100	-10°C	

## Temp. sensor pump delayed on, pump delayed off & valve minimum switching time:

Contents	Time
00000000	0
00000001	1 sec
00000010	2 sec
11111110	254 sec
11111111	255 sec

## Temp. sensor default sleep time into minutes

valid range H'0001' to H'FEFF' or 1min to 65.279min

Temp. sensor lower, upper, safe, night, day, comfort or alarm set (resolution 0.5°):

Contents	Temperature set
01111000	60°C
00101000	20°C
00000010	1°C
00000001	0.5°C
00000000	0°C
11111111	-0.5°C
11000000	-32°C

Temp. sensor Alarm1 & 2 modes

Contents	Description
B'xxxxx000'	Low temperature alarm 1
B'xxxxx001'	High temperature alarm 1 (default)
B'xxxxx010'	Anti-frost mode alarm 1
B'xxxxx011'	Night mode alarm 1
B'xxxxx100'	Day mode alarm 1
B'xxxxx101'	Comfort mode alarm 1
B'xxxxx110'	Night, Day or Comfort mode alarm 1
B'xxxxx111'	Day or Comfort mode alarm 1
B'xxxx0xxx'	Temperature alarms 1 absolute (default)
B'xxxx1xxx'	Temperature alarms 1 relative
B'x000xxxx'	Low temperature alarm 2
B'x001xxxx'	High temperature alarm 2 (default)
B'x010xxxx'	Anti-frost mode alarm 2
B'x011xxxx'	Night mode alarm 2
B'x100xxxx'	Day mode alarm 2
B'x101xxxx'	Comfort mode alarm 2
B'x110xxxx'	Night, Day or Comfort mode alarm 2
B'x111xxxx'	Day or Comfort mode alarm 2
B'0xxxxxxx'	Temperature alarms 2 absolute (default)
B'1xxxxxxx'	Temperature alarms 2 relative

Temp. sensor Alarm3 & 4 modes

Contents Description		
B'xxxxx000'	Low temperature alarm 3	
B'xxxxx001'	High temperature alarm 3 (default)	
B'xxxxx010'	Anti-frost mode alarm 3	
B'xxxxx011'	Night mode alarm 3	
B'xxxxx100'	Day mode alarm 3	
B'xxxxx101'	Comfort mode alarm 3	
B'xxxxx110'	Night, Day or Comfort mode alarm 3	
B'xxxxx111'	Day or Comfort mode alarm 3	
B'xxxx0xxx'	Temperature alarms 3 absolute (default)	
B'xxxx1xxx'	Temperature alarms 3 relative	
B'x000xxxx'	Low temperature alarm 4	

B'x001xxxx'	High temperature alarm 4 (default)	
B'x010xxxx'	Anti-frost mode alarm 4	
B'x011xxxx'	Night mode alarm 4	
B'x100xxxx'	Day mode alarm 4	
B'x101xxxx'	Comfort mode alarm 4	
B'x110xxxx'	Night, Day or Comfort mode alarm 4	
B'x111xxxx'	Day or Comfort mode alarm 4	
B'0xxxxxxx'	Temperature alarms 4 absolute (default)	
B'1xxxxxxx'	Temperature alarms 4 relative	

Address	Contents	Address	Contents
H'0110'	Linked Push button 1 module address	H'0111'	Linked Push button 1 bit number
H'0112'	Linked Push button 1 action	H'0113'	Linked Push button 1 time parameter
H'0114'	Linked Push button 1 channel parameter	H'0115'	Linked Push button 2 module address
H'0116'	Linked Push button 2 bit number	H'0117'	Linked Push button 2 action
H'0118'	Linked Push button 2 time parameter	H'0119'	Linked Push button 2 channel parameter
H'011A'	•••	H'011B'	
		•••	
H'01FA'	•••	H'01F1'	Linked Push button 46 module address
H'01F2'	Linked Push button 46 bit number	H'01F3'	Linked Push button 46 action
H'01F4'	Linked Push button 46 time parameter	H'01F5'	Linked Push button 46 channel parameter

What has changed? Max limit Linked Push Buttons reduced to 46 (Previous 48)

**Remark:** Unused locations contain H'FF'

## Action

0         Switch status led indication         -         Channel number           1         Lock channel at closed switch         -         Channel number           2         Lock channel at opened switch         -         Channel number           3         Lock channel         Timeout         Channel number           4         Lock/unlock channel         Timeout         Channel number           5         Unlock channel         -         Channel number           6         Disable channel program at closed switch         -         Channel number           7         Disable channel program at opened switch         -         Channel number           8         Disable channel program channel         Timeout         Channel number           9         Disable channel program         Timeout         Channel number           10         Enable channel program         -         Channel number           11         Select no programs         -         -         Channel number           12         Select program group 1 (eg. summer programs)         -         -         -           13         Select program group 2 (eg. winter programs)         -         -         -           14         Select program group 3 (eg. holiday programs)	eter
Lock channel at opened switch   Channel number	(18)
Lock channel	(18)
Lock/unlock channel	(18)
5         Unlock channel         -         Channel number           6         Disable channel program at closed switch         -         Channel number           7         Disable channel program at opened switch         -         Channel number           8         Disable channel program at opened switch         -         Channel number           9         Disable channel program         Timeout         Channel number           10         Enable channel program         -         Channel number           11         Select no programs         -         -           12         Select program group 1 (eg. summer programs)         -         -           13         Select program group 2 (eg. winter programs)         -         -           14         Select program group 3 (eg. holiday programs)         -         -           15         Enable Alarm 1 at closed switch         -         -           16         Enable Alarm 1 at closed switch         -         -           17         Disable Alarm 1 at closed switch         -         -           18         Disable Alarm 1         -         -           20         Enable Alarm 1         -         -           21         Disable Alarm 2 at closed switch	
6         Disable channel program at closed switch         -         Channel number           7         Disable channel program at opened switch         -         Channel number           8         Disable channel program channel         Timeout         Channel number           9         Disable/enable channel program         Timeout         Channel number           10         Enable channel program         -         Channel number           11         Select no programs         -         -         Channel number           11         Select program         -         -         Channel number           12         Select program         -         -         -           13         Select program group 1 (eg. summer programs)         -         -         -           13         Select program group 2 (eg. winter programs)         -         -         -           14         Select program group 3 (eg. holiday programs)         -         -         -           15         Enable Alarm 1 at closed switch         -         -         -           16         Enable Alarm 1 at closed switch         -         -         -           18         Disable Alarm 1 at open switch         -         -         -	(18)
Disable channel program at opened switch   Channel number	(18)
Select program group 1 (eg. summer programs)   -	(18)
Disable/enable channel program	(18)
10	
11	(18)
12	(18)
13	
14         Select program group 3 (eg. holiday programs)         -         -           15         Enable Alarm 1 at closed switch         -         -           16         Enable Alarm 1 at open switch         -         -           17         Disable Alarm 1 at open switch         -         -           18         Disable Alarm 1 at open switch         -         -           19         Enable Alarm 1         -         -           20         Enable/Disable Alarm 1         -         -           21         Disable Alarm 1         -         -           21         Disable Alarm 1         -         -           22         Enable Alarm 2         -         -           23         Enable Alarm 2 at closed switch         -         -           24         Disable Alarm 2 at open switch         -         -           25         Disable Alarm 2         -         -           26         Enable/Disable Alarm 2         -         -           27         Enable/Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -	
15	
16	
17         Disable Alarm 1 at closed switch         -         -           18         Disable Alarm 1 at open switch         -         -           19         Enable Alarm 1         -         -           20         Enable Alarm 1         -         -           21         Disable Alarm 1         -         -           21         Disable Alarm 2 at closed switch         -         -           23         Enable Alarm 2 at open switch         -         -           24         Disable Alarm 2 at closed switch         -         -           25         Disable Alarm 2 at open switch         -         -           26         Enable Alarm 2         -         -           27         Enable/Disable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at closed switch         -         -           31         Disable Sunrise at open switch         -         -           32         Disable Sunrise at open switch         -         -           34         Enable/Disable Sunrise         -         - <t< td=""><td></td></t<>	
18         Disable Alarm 1 at open switch         -         -           19         Enable Alarm 1         -         -           20         Enable/Disable Alarm 1         -         -           21         Disable Alarm 1         -         -           22         Enable Alarm 2 at closed switch         -         -           23         Enable Alarm 2 at open switch         -         -           24         Disable Alarm 2 at closed switch         -         -           25         Disable Alarm 2 at open switch         -         -           26         Enable Alarm 2         -         -           27         Enable/Disable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at open switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable/Disable Sunrise         -         -           34         Enable/Disable Sunrise         -         -	
19	
Disable Alarm 1	
21         Disable Alarm 1         -         -           22         Enable Alarm 2 at closed switch         -         -           23         Enable Alarm 2 at open switch         -         -           24         Disable Alarm 2 at closed switch         -         -           25         Disable Alarm 2 at open switch         -         -           26         Enable Alarm 2         -         -           27         Enable/Disable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at open switch         -         -           32         Disable Sunrise at open switch         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
22         Enable Alarm 2 at closed switch         -         -           23         Enable Alarm 2 at open switch         -         -           24         Disable Alarm 2 at closed switch         -         -           25         Disable Alarm 2 at open switch         -         -           26         Enable Alarm 2         -         -           27         Enable/Disable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at open switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
23         Enable Alarm 2 at open switch         -         -           24         Disable Alarm 2 at closed switch         -         -           25         Disable Alarm 2 at open switch         -         -           26         Enable Alarm 2         -         -           27         Enable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at closed switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
23         Enable Alarm 2 at open switch         -         -           24         Disable Alarm 2 at closed switch         -         -           25         Disable Alarm 2 at open switch         -         -           26         Enable Alarm 2         -         -           27         Enable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at closed switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
25         Disable Alarm 2 at open switch         -         -           26         Enable Alarm 2         -         -           27         Enable/Disable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at closed switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
26         Enable Alarm 2         -         -           27         Enable/Disable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at closed switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
27         Enable/Disable Alarm 2         -         -           28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at open switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
28         Disable Alarm 2         -         -           29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at closed switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
29         Enable Sunrise at closed switch         -         -           30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at closed switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
30         Enable Sunrise at open switch         -         -           31         Disable Sunrise at closed switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
31         Disable Sunrise at closed switch         -         -           32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
32         Disable Sunrise at open switch         -         -           33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
33         Enable Sunrise         -         -           34         Enable/Disable Sunrise         -         -           35         Disable Sunrise         -         -           36         Enable Sunset at closed switch         -         -           37         Enable Sunset at open switch         -         -	
35Disable Sunrise36Enable Sunset at closed switch37Enable Sunset at open switch	
36 Enable Sunset at closed switch	
36 Enable Sunset at closed switch	
37 Enable Sunset at open switch	
	-
39 Disable Sunset at open switch	-
40 Enable Sunset	
41 Enable/Disable Sunset	
42 Disable Sunset	
43 Sensor: Comfort mode Short press sleep time Long press sleep	time
44 Sensor: Day mode Short press sleep time Short press sleep	
45 Sensor: Night mode Short press sleep time Short press sleep  Short press sleep time Shor	
46 Sensor: Safe mode Short press sleep time Short press sleep  Short press sleep time Short	
47 Sensor: Heating mode	

48	Sensor: Cooling mode	-	-
49	Sensor: Forced Safe mode at open switch	-	0xFF
50	Sensor: Forced Safe mode at closed switch	-	0xFF
51	Sensor: Forced Safe mode	Timeout	-
52	Sensor: Forced or Cancel Forced Safe mode	Timeout	-
53	Sensor: Cancel Forced Safe mode	-	-
54	Toggle program group 1 (eg. summer programs)	-	-
55	Toggle program group 2 (eg. winter programs)	-	-
56	Toggle program group 3 (eg. holiday programs)	-	-

Time parameter

ime parameter	
Time	Timeout
parameter	
0	0s (no timer)
1	1s
2	2s
3	3s
119	1min59s
120	2min
121	2min15s
131	4min45s
132	5min
133	5min30s
181	29min30s
182	30min
183	31min
211	59min
212	1h
213	1h15min
227	4h45min
228	5h
229	5h30min
237	9h30min
238	10h
239	11h
251	23h
252	1d
253	2d
254	3d
255	Infinite

Sleep time	action
parameter	
0	No action
1	Select until next program step execution
2	Select for default sleep time (see sensor config.)
3	Select for 15 min (auto return to program)
4	Select for 30 min (auto return to program)
17	Select for 3h45 min (auto return to program)
18	Select for 4h min (auto return to program)
19	Select for 4h30 min (auto return to program)
•••	
33	Select for 11h30 min (auto return to program)
34	Select for 12h (auto return to program)
35	Select for 13h (auto return to program)
45	Select for 23h (auto return to program)
46	Select for 1 day (auto return to program)
47	Select for 1 day 12h (auto return to program)
57	Select for 6 days 12h (auto return to program)
58	Select for 7 days (auto return to program)
59	Select for 8 days (auto return to program)
96	Select for 45 days (auto return to program)
97	Select and ignore all program steps

Action	Action	Time parameter	Channel parameter
number			
0	Switch status led indication	•	Channel number (18)
1	Lock channel at closed switch	•	Channel number (18)
2	Lock channel at opened switch	•	Channel number (18)
3	Lock channel	Timeout	Channel number (18)
4	Lock/unlock channel	Timeout	Channel number (18)
5	Unlock channel	-	Channel number (18)

Address	Contents	Address	Contents
H'01F6'	Button Treshold TP1	H'01F7'	Button Treshold TP2
H'01F8'	Button Treshold TP3	H'01F9'	Button Treshold TP4
H'01FA'	Button Treshold TP5	H'01FB'	Button Treshold TP6
H'01FC'	Button Treshold TP7	H'01FD'	Touch Controller Param 1
H'01FE'	Touch Controller Param 2	H'01FF'	Touch Controller Param 3

Remark: A lot of these parameters can be found -with extra information- in the CAP1188 datasheet.

### Version 0

### $\underline{Button\ Treshold\ TP1-TP7}$

Writes a byte that adjusts the threshold when a touch is detected. (7bit number!)

#11del VMBG /*	SP4	#ifdef /*	VMBGP1		#ifde: /*	E VMB	GP2		
4 button g	glass panel		ton glass	_				panel (	ed3
   6	4		5	4		1		1	
 +	I	1	2	l I	   1	1	2	I	
3	1	   3	1	71		- 1		1	
Ι Ι ΓΡ		TP			TP				
*/ ifdef VMBG	DADTD.	*/			*/		TRIDGE	DO (DTC /D	
trager AMPG									
*		/*	VIIDGEZ_E	CD_ED4	/ /	e Lidei	VPIDGI	PO(PTC/D	<i>'</i> )
/* 4 button g	glass panel	/* 2 but	ton glass	panel	/	k			el (with flat OLED)
		/* 2 but	_	panel	/	k			
	glass panel 	/* 2 but   6	ton glass	panel	ed4 7	butt butt	ton gl	lass pan  2  	
	glass panel 	/* 2 but	ton glass	panel	ed4 7	butt butt		lass pan  2  	
	glass panel 	/* 2 but   6   3   5	ton glass	panel	ed4 7	7 butt 1 6	con gl	lass pan 2	

### Version 1

### Button Treshold TP1 – TP7

Writes a byte that adjusts the threshold when a touch is detected. (7bit number!)

### Touch Controller Param1/2/3

Writes a byte that contains settings for detecting touches on the glass panel.

	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	length
Param 1	GAIN		D	ELTA SEN	S	DIS_DIG_NOISE	DIS_ANA_NOISE	MAX_DUR_EN	= 8bit
Param 2	DIS_RF_NOISE		MAX_DUR		CS_B	N_TH	unused	= 8bit	
Param 3	MULT_BLK_EN		AVERAGE	AVERAGE S.		AMP_TIME	CYCLE	TIME	= 8bit

### a) GAIN:

Table 5.3 GAIN Bit Decode

GAI		
1	0	CAPACITIVE TOUCH SENSOR GAIN
0	0	1
0	1	2
1	0	4
1	1	8

#### b) DELTA\_SENS:

Table 5.8 DELTA\_SENSE Bit Decode

2	1	0	SENSITIVITY MULTIPLIER
0	0	0	128x (most sensitive)
0	0	1	64x
0	1	0	32x (default)
0	1	1	16x
1	0	0	8x
1	0	1	4x
1	1	0	2x
1	1	1	1x - (least sensitive)

### c) DIS\_DIG\_NOISE

DIS\_DIG\_NOISE - Determines whether the digital noise threshold (see Section 5.19, "Sensor Input Noise Threshold Register") is used by the device. Setting this bit disables the feature.

- '0' The digital noise threshold is used. If a delta count value exceeds the noise threshold but does not exceed the touch threshold, the sample is discarded and not used for the automatic recalibration routine.
- '1' (default) The noise threshold is disabled. Any delta count that is less than the touch threshold is used for the automatic re-calibration routine.

#### d) DIS\_ANA\_NOISE

DIS\_ANA\_NOISE - Determines whether the analog noise filter is enabled. Setting this bit disables the feature.

- '0' (default) If low frequency noise is detected by the analog block, the delta count on the corresponding channel is set to 0. Note that this does not require that Noise Status bits be set.
- '1' A touch is not blocked even if low frequency noise is detected.

#### e) MAX\_DUR\_EN

MAX\_DUR\_EN - Determines whether the maximum duration recalibration is enabled.

- '0' (default) The maximum duration recalibration functionality is disabled. A touch may be held indefinitely and no re-calibration will be performed on any sensor input.
- '1' The maximum duration recalibration functionality is enabled. If a touch is held for longer than the MAX\_DUR bit settings, then the re-calibration routine will be restarted (see Section 5.8).

### f) DIS\_RF\_NOISE

DIS\_RF\_NOISE - Determines whether the RF noise filter is enabled. Setting this bit disables the feature.

- '0' (default) If RF noise is detected by the analog block, the delta count on the corresponding channel is set to 0. Note that this does not require that Noise Status bits be set.
- '1' A touch is not blocked even if RF noise is detected.

#### g) MAX\_DUR

 $\label{eq:MAX_DUR[3:0]} \textbf{-} (default 1010b) \textbf{-} Determines the maximum time that a sensor pad is allowed to be touched until the capacitive touch sensor input is recalibrated, as shown in Table 5.13.$ 

Table 5.13 MAX\_DUR Bit Decode

	MA	X_DUR[3:0]		
3	2	1	0	TIME BEFORE RECALIBRATION
0	0	0	0	560ms
0	0	0	1	840ms
0	0	1	0	1120ms
0	0	1	1	1400ms
0	1	0	0	1680ms
0	1	0	1	2240ms
0	1	1	0	2800ms
	1	1	1	3360ms
1	0	0	0	3920ms
1	0	0	1	4480ms
1	0	1	0	5600ms (default)
1	0	1	1	6720ms
1	1	0	0	7840ms
1	1	0	1	8906ms
1	1	1	0	10080ms
1	1	1	1	11200ms

CS1\_BN\_TH[1:0] - Controls the noise threshold for all capacitive touch sensor inputs, as shown in Table 5.34. The threshold is proportional to the threshold setting.

Table 5.34 CSx\_BN\_TH Bit Decode

CS_BN_		
1	0	PERCENT THRESHOLD SETTING
0	0	25%
0	1	37.5% (default)
1	0	50%
1	1	62.5%

#### i) MULT BLK EN

MULT\_BLK\_EN - Enables the multiple button blocking circuitry.

- '0' The multiple touch circuitry is disabled. The device will not block multiple touches.
- '1' (default) The multiple touch circuitry is enabled. The device will flag the number of touches equal to programmed multiple touch threshold and block all others. It will remember which sensor inputs are valid and block all others until that sensor pad has been released. Once a sensor pad has been released, the N detected touches (determined via the cycle order of CS1 CS8) will be flagged and all others blocked.

### h) AVERAGE

Determines the number of samples that are taken for all active channels during the sensor cycle as shown in Table 5.18. All samples are taken consecutively on the same channel before the next channel is sampled and the result is averaged over the number of samples measured before updating the measured results.

Table 5.18 AVG Bit Decode

	AVG[2:0]		
2	1	0	NUMBER OF SAMPLES TAKEN PER MEASUREMENT
0	0	0	1
0	0	1	2
0	1	0	4
0	1	1	8 (default)
1	0	0	16
1	0	1	32
1	1	0	64
1	1	1	128

### h) SAMP\_TIME

SAMP\_TIME[1:0] - Determines the time to take a single sample as shown in Table 5.19.

Table 5.19 SAMP\_TIME Bit Decode

SAMP_TIME[1:0]		
1	0	SAMPLE TIME
0	0	320us
0	1	640us
1	0	1.28ms (default)
1	1	2.56ms

### h) CYCLE\_TIME

CYCLE\_TIME[1:0] - Determines the overall cycle time for all measured channels during normal operation as shown in Table 5.20. All measured channels are sampled at the beginning of the cycle time. If additional time is remaining, then the device is placed into a lower power state for the remaining duration of the cycle.

Table 5.20 CYCLE\_TIME Bit Decode

CYCLE_TIME[1:0]		
1	0	OVERALL CYCLE TIME
0	0	35ms
0	1	70ms (default)
1	0	105ms
1	1	140ms

Address	Contents	Address	Contents
H'0200'	Program step 1 byte1	H'0201'	Program step 1 byte2
H'0202'	Program step 1 byte3	H'0203'	Program step 1 byte4
H'0204'	Program step 1 byte5	H'0205'	Program step 1 byte6
•••			
H'03B6'	Program step 74 byte1	H'03B7'	Program step 74 byte2
H'03B8'	Program step 74 byte3	H'03B9'	Program step 74 byte4
H'03BA'	Program step 74 byte5	H'03BB'	Program step 74 byte6

Contents program byte1	Description	
B'000xxxxx'	Disable program step	
B'001xxxxx'	Absolute time	
B'010xxxxx'	Wake up time 1 + relative time	
B'011xxxxx'	Go to bed time 1 + relative time	
B'100xxxxx'	Wake up time 2 + relative time	
B'101xxxxx'	Go to bed time 2 + relative time	
B'110xxxxx'	Sunrise + relative time	
B'111xxxxx'	Sunset + relative time	
B'xxx01111'	Rel. time = 3h45min	
B'xxx00001'	Rel. time = 15min	
B'xxx00000'	Rel. time = $0$	
B'xxx11111'	Rel. time = -15min	
•••		
B'xxx10000'	Rel. time = -4h	

Remark: Wake up, Go to bed, sunrise & sunset time are only allowed for weekly programs

Contents program byte2	Description
B'xxxx0000'	Weekly program
B'xxxx0001'	January
B'xxxx0010'	February
B'xxxx0011'	March
B'xxxx0100'	April
B'xxxx0101'	May
B'xxxx0110'	June
B'xxxx0111'	July
B'xxxx1000'	August
B'xxxx1001'	September
B'xxxx1010'	October
B'xxxx1011'	November
B'xxxx1100'	December
B'xxxx1101'	Monthly program
B'xxxx1110'	Monthly program
B'xxxx1111'	Monthly program

Contents program byte3	Description
B'xxx00000'	0h
B'xxx00001'	1h
B'xxx10111'	23h
B'xx1xxxxx'	Program group 1 (Summer program)
B'x1xxxxxx'	Program group 2 (Winter program)
B'1xxxxxxx'	Program group 3 (Holiday program)

Contents program byte4	Description
B'xx000000'	0min
B'xx000001'	1min
B'xx111011'	59min

Contents program byte4	Contents program byte2	Description
B'00xxxxxx'	B'0000xxxx'	Never
B'00xxxxxx'	B'0001xxxx'	Day 1of the month
B'00xxxxxx'	B'0010xxxx'	Day 2of the month
B'01xxxxxx'	B'1111xxxx'	Day 31of the month
B'10xxxxxx'	B'0000xxxx'	Never
B'10xxxxxx'	B'0001xxxx'	Every Monday
B'10xxxxxx'	B'0010xxxx'	Every Tuesday
B'10xxxxxx'	B'0111xxxx'	Every Sunday
B'10xxxxxx'	B'1000xxxx'	Every weekend (sa & su)
B'10xxxxxx'	B'1001xxxx'	Every working day (mofr)
B'10xxxxxx'	B'1010xxxx'	Every day except Sunday
B'10xxxxxx'	B'1011xxxx'	Every day
B'10xxxxxx'	B'1100xxxx'	Never
B'11xxxxxx'	B'1111xxxx'	Never

Contents program byte5	Action	
0	0s25 Pulse	
1	1s Pulse	
2	2s Pulse	
119	1min59s Pulse	
120	2min Pulse	
121	2min15s Pulse	
131	4min45s Pulse	
132	5min Pulse	
133	5min30s Pulse	
181	29min30s Pulse	
182	30min Pulse	
183	31min Pulse	
211	59min Pulse	
212	1h Pulse	
213	1h15min Pulse	
227	4h45min Pulse	
228	5h Pulse	
229	5h30min Pulse	
237	9h30min Pulse	
238	10h Pulse	
239	11h Pulse	
246	18h Pulse	
247	Press	
248	Long Press	
249	Release	
250	Lock	
251	Unlock	
252	Sensor: Safe mode	
253	Sensor: Night mode	
254	Sensor: Day mode	
255	Sensor: Comfort mode	
255	Standar Common mode	

Contents program byte6	Channel
1	Channel 1
2	Channel 2
7	Channel 7
8	Channel 8
128	Temperature sensor

Address	Contents	Address	Contents
H'03BC'	Location id low byte	H'03BD'	Location id high byte
H'03BE'	Group id low byte	H'03BF'	Group id high byte
H'03C0'	Module name character 1	H'03C1'	Module name character 2
H'03FE'	Module name character 63	H'03FF'	Module name character 64

# **EEprom memory map:**

Address	Contents	Address	Contents
H0400'	Bank 1: Day of week	H'0401'	Bank 1: Day of month
H'0402'	Bank 1: Month	H'0403'	Bank 1: Year low byte
H'0404'	Bank 1: Year high byte	H'0405'	Bank 1: Program group number
H'0406'	Bank 1: Locked flags ch18	H'0407'	Bank 1: Program disabled flags ch18
H'0408'	Bank 1: Sensor current mode low byte	H'0409'	Bank 1: Sensor current mode high byte
H'040A'	Bank 1: Sensor current program mode	H'040B'	Bank 1: Sensor target temperature low byte
H'040C'	Bank 1: Sensor target temperature high byte	H'040D'	Bank 1: Auto send sensor temperature
H'040E'	Bank 1: reserved	H'040F'	Bank 1: current bank number
H07F0'	Bank 64: Day of week	H'07F1'	Bank 64: Day of month
H'07F2'	Bank 64: Month	H'07F3'	Bank 64: Year low byte
H'07F4'	Bank 64: Year high byte	H'07F5'	Bank 64: Program group number
H'07F6'	Bank 64: Locked flags ch18	H'07F7'	Bank 64: Program disabled flags ch18
H'07F8'	Bank 64: Sensor current mode low byte	H'07F9'	Bank 64: Sensor current mode high byte
H'07FA'	Bank 64: Sensor current program mode	H'07FB'	Bank 64: Sensor target temperature low byte
H'07FC'	Bank 64: Sensor target temperature high byte	H'07FD'	Bank 64: Auto send sensor temperature
H'07FE'	Bank 64: reserved	H'07FF'	Bank 64: current bank number