CONNECTING YOUR RPI TO UNH-SECURE.

These steps should get your Raspberry Pi connected to the UNH secure network. To get started, you do need a monitor, keyboard and mouse connected to your RPi. If all goes well, after this initial setup you can use your RPi in "headless" mode, i.e. without a monitor, keyboard or mouse.

INITIAL STEPS:

- 1. Boot the Raspberry pi, and log in as "pi"
- 2. You will get a command prompt. To get to graphical mode, type: "startx"
- 3. Wait a little. You get to a pretty picture, and a "Welcome to Raspberry Pi" screen. Follow the directions on this screen carefully:
 - a. "Next", then make sure the Language is correct, and set timezone to "New York". Clock "Next".
 - b. Here you can change the password. I recommend you don't, just click "Next".
 - c. The Set Up Screen can be skipped, just click "Next".
 - d. At "Select Wifi Network" select "UNH-Public" and click "Next".
 - e. At "Update Software", click "Skip" to save time.
 - f. Click "Done"
- 4. Once you see the screen, click on the top right blue "Wifi" symbol, if should say "UNH-Public". We want to do some steps so that this changes to "UNH-Secure"
 - a. If the symbol, which is the 3rd one from the right, is either two red x with grey bars, two blue arrows, or the ball with bars symbol:
 - b. If you see the red x symbol, first select "Turn Wifi On", then select "UNH-Public"
 - c. The blue icon will blink a few times, and then become solid.
- 5. Follow the Easy steps below.

EASY SETUP USING A SCRIPT.

- 6. Open a terminal by clicking on the black box icon with the > symbol in it.
- 7. Go to the Phys605 directory: cd Phys605
- 8. Update the directory: git pull
- 9. Go to the UNH Wifi directory: cd UNH Wifi
- 10. Execute the update scripts: ./UNH Secure setup.sh
 - a. If you are user "pi" then you will not require a password.
 - b. When asked, supply the number of your RPi (on the sticker) only the number.

- 11. The Wifi icon will go to "red" state, and then after a little connect to UNH_Secure.
- 12. The name of your system on the network will be phys605pi##.aw4.unh.edu (i.e. phys605pi7.aw4.unh.edu). It will take a little for this new name to be registered, so be a little patient.
- 13. Once your system is configured, you can log into it from your own computer with ssh, using the new network name: ssh pi@phys605pi##.aw4.unh.edu

MANUAL SETUP.

- 1. Open the web-browser (chromium), by clicking on the blue "world" ball on the left side of the screen.
 - a. You will get a page with a certificate error.
 - b. Type "cloudpath.unh.edu" in the address bar.
 - c. Click the "agree" box and then "next".
 - d. Click on "Faculty, Staff & Students".
 - e. Use your UNH username and password to log in.
- 2. Select the (small) "Show all operating systems" at the bottom, and then select "Raspberry Pi"
- 3. Click on each of the steps: 1, 2, 3 and 4

CONFIGURING YOUR WIFI:

- 1. You now want to start up a terminal: Click on the black box icon with the >_ symbol in it at the top of your screen.
- 2. Go into your Downloads directory: cd Downloads
- 3. With the "ls" command, you can see the 4 certificate files you downloaded, "CA-27#####.cer", "CA-47#####.cer", "username@cpuserunhedu.cer" and "username@cpuserunhedu.key".
 - Here "username" is replaces with your UNH username.
- 4. We now need to change the password on the "username@cpuserunhedu.key" file:
 - a. openssl rsa -des3 -in username@cpuserunhedu.key -our cpuserunhedu.key And supply when prompted first your UNH username password and then the new password. Write down (or remember) this new password, you will need it below.
 - b. cp username@cpuserunhedu.cer cpuserunhedu.cer
- 5. Copy the certificates to the directory: /etc/ssl/certs with the command: sudo cp CA-* cpuserunhedu* /etc/ssl/certs
- 6. Next, some tricky business to patch a bug in the RPi setup:
 - a. edit /lib/dhcpcd/dhcpcd-hooks/10-wpa_supplicant with the command: sudo nano /lib/dhcpcd/dhcpcd-hooks/10-wpa_supplicant
 - b. Navigate your cursor down to the line that reads:"wpa_supplicant_driver="\${wpa_supplicant_driver:-nl80211,wext}"Now edit that line so that it reads instead:

"wpa_supplicant_driver="\${wpa_supplicant_driver:-wext,nl80211}" So you just swapped the wornds "nl80211" and "wext".

- c. Save the file with control-o and then exit with control-x
- 7. Now, a final editing session. You need add the relevant information into the /etc/wpa supplicant/wpa supplicant.conf file:
 - a. Use the command: sudo nano /etc/wpa_supplicant/wpa_supplicant.conf Below what is already there add the following lines: network={

```
ssid="UNH-Secure"
proto=RSN
key_mgmt=WPA-EAP
eap=TLS
identity="<username>@cpuser.unh.edu"
ca_cert="/etc/ssl/certs/CA-47BEABC922EAE80E78783462A79F45C254FDE68B.cer"
client_cert="/etc/ssl/certs/cpuserunhedu.cer"
private_key="/etc/ssl/certs/cpuserunhedu.key"
private_key="/etc/ssl/certs/cpuserunhedu.key"
private_key_passwd="<password you set before>"
priority=77
}
```