




# Instruction Manual

## CORDLESS MINI CUTTER

MT-MC3.6V/BMC

**3.6V**  
Lithium-ion

Li-ion



### IMPORTANT:

Read carefully before use  
Keep for future reference

[contact@vloxo.net](mailto:contact@vloxo.net)

||||| Professional



- *This device may not be used for any purpose other than intended. Not suitable for commercial or industrial use.*
- *This device may be interest of children, but as you know it is not a toy. In this reason, device being where children can't reach place.*
- *Other information in this guide to see the section "**Safety Instructions**".*
- *Please read the manual, you can start using the product after that.*

## GENERAL SAFETY WARNINGS FOR POWER TOOLS

The cordless mini cutter (here in after referred to as the "appliance") is designed for cutting materials such as fabric, PVC, carpet or the like. The appliance is intended for use by adults. Young people under 16 years of age may only use the appliance under supervision. Any other usage of or modification to the appliance is deemed to be improper and carries the risk of serious personal injury. Not for commercial use.

### **WARNING!**

- Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery operated (cordless) power tool.

### 1. Work area safety

- Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

### 2. Electrical safety

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
- If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

### 3. Personal safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating a power tool may result in serious personal injury.
- Use personal protective equipment. Always wear eye protection. Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.
- Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.
- Do not allow yourself to get lulled into a false sense of security, and do not ignore the safety rules for power tools, even if you are familiar with the power tool after repeated use. A careless action can cause severe injury within a fraction of a second.

## SAFETY INSTRUCTIONS FOR DEVICE


- Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- Use the power tool, accessories and accessory tools, etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
- Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

## PARTS DESCRIPTION

- ① On/off Switch
- ② Lock-off Button
- ③ Blade Guard
- ④ Blade
- ⑤ Blade Screw
- ⑥ Charger Socket
- ⑦ Charging Indicator Light
- ⑧ Charge

### Technical Data

Battery: 3.6V 2000mAh  
Speed: 240 rpm  
Max cutting size: 6mm  
Charging time: 3-5 hours



## BEFORE THE FIRST USE

### Charging the battery

Charge the battery fully before using the screwdriver for the first time. Plug the USB cord provided into power source and insert the charging connector into the charging socket on the screwdriver. A full charge takes 3-5 hours. Unplug the adapter from the mains socket after charging. Never charge for more than 5 hours at a time.

## USE

### WARNING!

- Make sure that the clamping screw is firmly tightened before putting the appliance into operation.

### Fitting/changing the cutting disc

### WARNING!

- The cutting disc can become very hot during use. Allow it to cool before changing.
- Wear protective gloves to avoid injury.
- Don't turn on the switch before changing the cutting disc !.
- Remove the clamping screw and the clamping flange .
- Remove the cutting disc. Push the cutting disc carefully.
- Proceed in reverse order to fit a new cutting disc. Make sure that the ground side of the cutting disc is facing outwards.

### WARNING! RISK OF INJURY

- Note that the cutting disc runs on for a little while.
- Switching on and off:
- Press the safety lock-off and plug the On/Off switch .
- Release the On/Off switch.
- Handling the appliance
- Move the appliance forward slowly and without exerting too much pressure.
- Make sure that the cutting disc does not come to a standstill.
- Keep thin materials, such as fabric, under tension while working them.

## CLEANING AND MAINTENANCE

### WARNING! RISK OF INJURY!

The appliance is maintenance-free.

- The appliance must always be kept clean, dry and free from oil or grease.
- Never allow liquids to get into the appliance.
- Use a dry cloth to clean the housing. Never use petrol, solvents or cleansers which can damage plastic.
- Always keep the area around the blade guard clean. Remove dust and chips by blowing them out with compressed air or with a brush.
- The optimum storage environment is cool and dry.

## GUIDELINES FOR PROTECTION OF THE ENVIRONMENT

This appliance should not be put into the domestic garbage at the end of its durability, but must be taken to a central point for the recycling of electric and electronic domestic appliances. This symbol on the appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycled. By recycling used domestic appliances you contribute to foment the protection of our environment. Ask your local authorities for information regarding the point of recollection.

