

# AIM-Edge ncox/ncon Image Refresh over Ethernet

User Manual

19 March 2024 Version 1.1



#### Content

1.	Introduction				
2.	I/O Port Overview				
3.	Getting	Started	. 2		
	3.1.	Hardware Requirement	. 2		
	3.2.	Download OTA Image Package & Tool	. 2		
	3.3.	Start OTA update	. 2		
4.	Appendix				
	4.1.	Login to AIM-Edge ncox/ncon by ssh	. 5		
	4.2.	AlMobile Container Usage	. 5		



# **Revision History**


Date	Version	Modification
2024/02/26	1.0	Creation
2024/03/19	1.1	Improve user experience of downloading process
	4	



#### 1. Introduction

This document is to describe how to download Jetpack 5.1.2 system image to AIM-Edge ncox/ncon device over Ethernet, including hardware requirement, download image package and image refreshing procedures.

## 2. I/O Port Overview





# 3. Getting Started

#### 3.1. Hardware Requirement

To refresh the image over Ethernet, it needs a Linux Host PC/Notebook with Ubuntu Linux X64 20.04 or 18.04, and the Host PC/NB should be able to connect to AIM-Edge ncox/ncon through LAN.

#### 3.2. Download OTA Image Package & Tool

Check the OneDrive URL provided by AIMobile for OTA image refresh package folder (O1\_dev\_5.1.2\_V07\_OTA in the example below), there will be OTA image file (ota\_payload\_package.tar.gz), OTA tool (ota\_tools\_V3.tar.bz2) & script (ota.sh). Download the three files to Host PC/NB.



## 3.3. Start OTA update

Run the OTA script from Host PC/NB as below, check the table below for parameters may need change, and user can check section 4.1 about how to get target device IP address.

./ota.sh -i 192.168.55.1 -p ota\_payload\_package.tar.gz -t ota\_tools\_V3.tar.bz2 --port 22

Option	Parameter description
-i	Target device IP
-p	OTA package file name
-t	OTA tool file name
port	Target device SSH port number (default:22)



1. Input target device account and password, the OTA tool & image file will be uploaded to the target device.

2. After the file uploading is completed, the files will be decompressed on the target device.

```
Linux_for_Tegra/tools/ota_tools/version_upgrade/Image_based_OTA_Examples.txt
Linux_for_Tegra/tools/ota_tools/version_upgrade/nv_ota_update.sh
Linux_for_Tegra/tools/ota_tools/version_upgrade/pv_1.6.6-1_arm64.deb
Linux_for_Tegra/tools/ota_tools/version_upgrade/ota_validate_params.sh
Linux_for_Tegra/tools/ota_tools/version_upgrade/l4t_generate_ota_package.sh
Linux_for_Tegra/tools/ota_tools/version_upgrade/nv_ota_validate.sh
Linux_for_Tegra/tools/ota_tools/version_upgrade/nv_ota_update_without_layout_change.sh
Linux_for_Tegra/tools/ota_tools/version_upgrade/nv_ota_customer.conf
Linux_for_Tegra/tools/ota_tools/version_upgrade/ota_multi_board_specs.sh
Linux_for_Tegra/tools/ota_tools/version_upgrade/kernel_bootctrl.bin.reset
Linux_for_Tegra/tools/ota_tools/version_upgrade/nv_ota_decompress_package.sh
Linux_for_Tegra/p2822-0000+p2888-0004-R32x-R35i.conf
tar: Linux_for_Tegra/tools/ota_tools/version_upgrade: time stamp 2024-03-14 12:01:00 is 136939.707366304 s in the future
Linux_for_Tegra/p2822-0000+p2888-0008-R35A-R35i.conf
Linux_for_Tegra/p2822-0000+p2888-0004-R35A-R35i.conf
Linux_for_Tegra/jetson-agx-xavier-devkit-R32x-R35i.conf
Linux_for_Tegra/jetson-agx-xavier-devkit-R35A-R35i.conf
Linux_for_Tegra/p2822-0000+p2888-0008-R32x-R35i.conf
Linux_for_Tegra/jetson-xnx-devkit-emmc-R35A-R35i.conf
Linux_for_Tegra/jetson-xnx-devkit-emmc-R32i.conf
Linux_for_Tegra/jaxi-R35A-R35i.conf
Linux_for_Tegra/p3509-0000+p3668-0001-qspi-emmc-R35A-R35i.conf
Linux_for_Tegra/jaxi-R32x-R35i.conf
Linux_for_Tegra/Tegra_Software_License_Agreement-Tegra-Linux.txt
Linux_for_Tegra/p3509-0000+p3668-0001-qspi-emmc-R32i.conf
Linux_for_Tegra/bootloader/
Linux_for_Tegra/bootloader/t186ref/
Linux_for_Tegra/bootloader/t186ref/BCT/
Linux_for_Tegra/bootloader/t186ref/BCT/tegra186-mb1-bct-misc-si-l4t-r32i.cfg
Linux_for_Tegra/bootloader/t186ref/cfg/
Linux_for_Tegra/bootloader/t186ref/cfg/flash_t194_sdmmc_rootfs_ab_R35A_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_p3668_rootfs_ab_R35A_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_t194_sdmmc_R32x_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_t194_sdmmc_rootfs_ab_R32x_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_jaxi_rootfs_ab_R32x_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_jaxi_R35A_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_t194_sdmmc_R35A_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_p3668_R35A_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_p3668_rootfs_ab_R32i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_jaxi_R32x_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_p3668_R32i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_jaxi_rootfs_ab_R35A_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_p3668_R32x_R35i.xml
Linux_for_Tegra/bootloader/t186ref/cfg/flash_l4t_t194_spi_emmc_p3668_rootfs_ab_R32x_R35i.xml
[sudo] password for aim: Selecting previously unselected package pv.
(Reading database ... 145653 files and directories currently installed.)
Preparing to unpack pv_1.6.6-1_arm64.deb ...
Unpacking pv (1.6.6-1) ...
Setting up pv (1.6.6-1) ...
Processing triggers for man-db (2.9.1-1) ...
Command: /tmp/Linux_for_Tegra/tools/ota_tools/version_upgrade/nv_ota_start.sh /tmp/ota_payload_package.tar.gz
Current rootfs is on /dev/nvme0n1
init_ota_log /ota_log
Creating log dir at /ota_log
Create log file at /ota_log/ota_20240312-215841.log
OTA_LOG_FILE=/ota_log/ota_20240312-215841.log
Extract /tmp/ota_payload_package.tar.gz
6.88GiB 0:01:30 [85.7MiB/s] [=
                                                                  7 60% ETA 0:00:59
```



3. After the files are decompressed, it will check the OTA package file integrity.

```
Info. Active boot storage: nvme0n1
Info. Legacy mode: false
TNSPEC 3767-300-0000-L.2-1-0-p3509-a02+p3767-0000-
COMPATIBLE_SPEC 3767-000-0000--1--p3509-a02+p3767-0000-
TEGRA_LEGACY_UPDATE false
TEGRA_BOOT_STORAGE nvme@n1
TEGRA_EMMC_ONLY false
TEGRA_CHIPID 0x23
TEGRA_OTA_BOOT_DEVICE /dev/mtdblock0
TEGRA_OTA_GPT_DEVICE /dev/mtdblock0
Info: Write TegraPlatformCompatSpec with 3767-000-0000--1--p3509-a02+p3767-0000-.
Info. Uninstalling mtdblock.
check_prerequisites
decompress_ota_package ota_package.tar /ota_work
decompress_ota_package: start at Mon 11 Mar 2024 05:59:44 PM CST
11.6GiB 0:00:35 [ 335MiB/s] [===
                                                             =>] 100%
Sha1 checksum for /ota_work/ota_package.tar (4169b4b774280e73a3b199bc09d5d19ebea7ed1c) matches
                                                               ] 16% ETA 0:01:11
1.90GiB 0:00:14 [ 395KiB/s] [==
```

4. After file integrity checking is done, the target device will start image updating automatically.

```
install_partition_with_alt /ota_work/external_device/images-R35-ToT
prerequisite_check esp
The /ota_work/external_device/images-R35-ToT/esp.img for partition esp is not found
Skip updating esp partition as no valid image is found
update_rootfs /ota_work
update_rootfs_with_a_b_disabled /ota_work
force_booting_to_recovery p3509-a02+p3767-0000
1+0 records in
1+0 records out
8 bytes copied, 0.00706323 s, 1.1 kB/s
Rootfs is to be updated in recovery kernel once device is rebooted. check_bootloader_version /ota_work
update_bootloader /ota_work
Bootloader on non-current slot(B) is to be updated once device is rebooted
OTA start at Tue Mar 19 15:58:05 CST 2024.
                                              # [54%] [-]
Bootloader on non-current slot(B) is to be updated once device is rebooted
OTA start at Tue Mar 19 15:58:05 CST 2024.
```

5. The image updating will take around 15~20 minutes, and the Host PC/NB will monitor the target device status continuously, after the Host PC/NB detect the target device is reconnected to network, the OTA process is completed.

6. If Host PC/NB waits for longer than 30 minutes, it will abort the OTA script and show warning message "OTA status: Timeout please check device power" to remind user to check target device status.



# 4. Appendix

#### 4.1. Login to AIM-Edge ncox/ncon by ssh

- 1. AIM-Edge ncox/ncon Gigabit Ethernet port is set to DHCP mode on default, it will try to get IP address from router in LAN directly after power on.
- 2. Please check the LAN router/access point Web control interface to know the IP assigned to ncox/ncon, the ncox/ncon device name should be "AIM-dev-xxxx" as the screenshot below.



- 3. Connect to AIM-Edge ncox/ncon from Host NB/PC with ssh (Username: aim /Password: aim12345).
- 4. Because of security concern, user will be asked to change the password on the first login.

```
WARNING: Your password has expired.
You must change your password now and login again!
Changing password for aim.
Current password: |
```

#### 4.2. AlMobile Container Usage

Please check readme.txt on Ubuntu desktop about pre-installed AIMobile container usage including how to relocate the container image.

The AIMobile container image is pre-installed to root file system, it takes around 13GB, and it can be removed with "docker system prune -af" command.

```
aim@AIM-dev-4737:~$ docker images
REPOSITORY TAG IMAGE ID CREATED SIZE
aimobile/l4t-jetpack r35.4.1 353b9824dd21 2 weeks ago 12.9GB
```