CC3100 HTTP Client

CC3100 HTTP Client

Overview & Application details

Return to CC31xx & CC32xx Home Page

HTTP client library can be used to communicate and exchange data with the HTTP web server.

HTTP client library support two modes

- Minimum mode: HTTP client library in minimum mode supports synchronous mode, redirection handling, chunked transfer encoding, proxy and TLS. HTTPCli_LIBTYPE_MIN flag should be used to build the library in minimum mode.
- Full Mode: HTTP Client library in full mode supports all the features of the minimal mode along with
 asynchronous mode and content handling and requires RTOS support. HTTPCli_LIBTYPE_FULL flag should
 be used to build the library in full mode.

This sample application demonstrates the HTTP Client library API for HTTP based application development in minimum mode. This application explain user to how to:

- Connect to an access point
- · Connect to a HTTP Server with and without proxy
- · Do POST, GET, PUT and DELETE
- Parse JSON data using "Jasmine JSON Parser"

To enable the secure connection (in example) user need to add the follow code snippet

```
SlDateTime_t dt;
struct HTTPCli_SecureParams sparams;
/* Set current Date to validate certificate */
dt.sl_tm_day = DATE;
dt.sl_tm_mon = MONTH;
dt.sl_tm_year = YEAR;
dt.sl_tm_hour = HOUR;
dt.sl_tm_min = MINUTE;
dt.sl_tm_sec = SECOND;
sl_DevSet(SL_DEVICE_GENERAL_CONFIGURATION,
                            SL_DEVICE_GENERAL_CONFIGURATION_DATE_TIME,
                            sizeof(SlDateTime_t), (unsigned char *)(&dt));
/* Security parameters */
sparams.method.secureMethod = SL_SO_SEC_METHOD_TLSV1_2;
sparams.mask.secureMask = SL_SEC_MASK_TLS_RSA_WITH_AES_256_CBC_SHA;
strncpy(sparams.cafile, SL_SSL_CA_CERT, sizeof(SL_SSL_CA_CERT));
sparams.privkey[0] = 0;
sparams.cert[0] = 0;
sparams.dhkey[0] = 0;
HTTPCli_setSecureParams(&sparams);
```

And HTTPCli_connect function should be called with HTTPCli_TYPE_TLS option.

```
HTTPCli_connect(&cli, (struct sockaddr *)&addr, HTTPCli_TYPE_TLS, NULL);
```

CC3100 HTTP Client

User can change the proxy by changing the MACRO 'PROXY_IP', 'PROXY_PORT'. To enable proxy user need to define USE_PROXY macro in project properties.

HTTP Client library API details are provided in SDK under docs folder.

Usage

Prerequisite: This application requires an access-point with internet connectivity

- Connect the board to a Windows-PC and configure the terminal-program for seeing the logs CC3100 & CC3200
 Terminal Setting has detailed instructions for configuring the terminal-program
- Open sl_common.h and and change SSID_NAME, SEC_TYPE and PASSKEY as per your access-point's
 properties. SimpleLink device will connect to this AP when the application is executed
- Open main.c and change HOST_NAME and HOST_PORT as per your server properties. Other HTTP request parameters may also change depending upon the server. This example is tested with httpbin.org host and 80 port.
- Build and launch the project, the application tries to connect to AP.
- Upon connection application tries to connect to the http host.
- Upon successful connection application will send POST, DELETE, PUT and GET request and check and parse the response.
- See the self explanatory logs on the terminal-program's console. On success, below message will be displayed on the terminal

CC3100 HTTP Client

Limitations/Known Issues

- HTTP connection timeout is not supported.
- Only IPV4 is supported
- HTTP client library supports ANSI C99 standards.

Article Sources and Contributors

CC3100 HTTP Client Source: http://processors.wiki.ti.com/index.php?oldid=229442 Contributors: A0131875, A0132173, Jitgupta, Raghshenoy, SarahP

Image Sources, Licenses and Contributors

File: Cc31xx_cc32xx_return_home.png Source: http://processors.wiki.ti.com/index.php?title=File: Cc31xx_cc32xx_return_home.png License: unknown Contributors: A0221015 Image: HTTP Client.png Source: http://processors.wiki.ti.com/index.php?title=File: HTTP_Client.png License: unknown Contributors: Jitgupta