

# CONFIGURATION REFERENCE

This document is under construction.

## Main speakers' settings

### Front speakers

- Ch 2 Level at **9 o'clock**
- DSP D-contour **OFF**
- DSP HPF **OFF**
- Gray button **NOT** pressed in



### Fill speakers

- Level at 9 o'clock
- High at 0
- Low at 0




# Coffee shop speakers

- Volume at 9 o'clock
- DSP preset button NOT pressed in



# Rhode link settings

- The receiver (the one on the wall) should be on 0db gain.
- The transmitter (the one with the mic) should be on 10db gain.



# Streaming

## OBS

Todo... \* Disable taskbar peeking in windows, as it messes with the live projectors.

## OSCBridge

Todo... ## Live Todo...

# **Hardware**

## **Camera**

Todo... ## Baby-room TV Todo...