



INTRODUCTION TO FORCE SENSOR

BY ARVIND SESHAN

LESSON OBJECTIVES

- Learn how to use the Force Sensor
- Learn how to use the Wait Functions
- Note: Force Sensor is not available in Robot Inventor



WHAT IS A FORCE SENSOR?

- The Force Sensor does two main types of sensing:
 - Touch sensing
 - Force sensing
- You can measure the Force in percent or Newtons



```
is_pressed()
get_force_newton()
get_force_percentage()
```

HOW DO YOU PROGRAM WITH A FORCE SENSOR

Just like with motors, the force sensor must be initialized before use

- There are two modes of the force sensor
- The two modes are
 - Pressed even a gentle tap is detected
 - Released hold the sensor in and release it any amount

```
force.wait_until_pressed()
force.wait_until_released()
```

CHALLENGE I: MOVE UNTIL PRESSED

- Program your robot to move straight until you press the sensor with your hand
- You will use the wait_until_pressed() function for this challenge

```
force.wait until pressed()
```

Basic steps:

- Set the **movement motors** for your robot (A and E for Droid Bot IV and ADB robot)
- Set the stop action to brake
- Set the % speed for your robot
- **Initialize** the force sensor
- Start moving straight
- Use the wait_until_pressed() function to detect when the Force Sensor is pressed
- Stop moving

CHALLENGE I: SOLUTION

In previous lessons, you learnt how to configure your robot. The first 3 lines set the movement motors, the stop action, and the default speed. (See Configuring Your Robot Lesson)

```
motor_pair = MotorPair('A', 'E')
motor_pair.set_stop_action('brake')
motor_pair.set_default_speed(30)
force = ForceSensor('F')
motor_pair.start() Start moving
force.wait_until_pressed() Wait until the Force Sensor is pressed
motor_pair.stop() Stop moving
```

CREDITS

- This lesson was created by Arvind Seshan for SPIKE Prime Lessons
- More lessons are available at www.primelessons.org



This work is licensed under a <u>Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International</u> License.