

# Morfeas WEB User Guide MDAQ-if/Portal

#### 1 License

Copyright (C) 12022 Sam Harry Tzavaras.

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included at the LICENSE file.

## 2 Change History

Feb 14,12022: Sam Harry Tzavaras – Initial Work.

Contents		
1	License	2
2	Change History	2
3	Introduction	4
4	Installation	4
5	Morfeas WEB MDAQ-if/Portal UI	4

Example of Morfeas WEB MDAQ-if UI  $\ \ldots \ \ldots \ \ldots \ \ 4$ 

Reference Guides

Morfeas WEB-UI

List of Figures

Page 3

#### 3 Introduction

The "Morfeas WEB MDAQ if/Portal" is the web user interface of the Morfeas WEB for MDAQ devices. MDAQs are acquisition devices with 8 differential or 16 single ended analog inputs and MODBus-TCP output. The "Morfeas WEB MDAQ if/Portal" works in conjunction with the "Morfeas MDAQ if" which is part of the "Morfeas core".

The "Morfeas WEB MDAQ if/Portal" is published under the AGPLv3 or later.

#### 4 Installation

The installation of the MDAQs start by configuring the Morfeas System, by adding a Morfeas\_MDAQ\_if component to the IPv4 address of the MDAQ, together with an identification name for the component. This done from the Morfeas "System Configuration" WEB utility.

### 5 Morfeas WEB MDAQ-if/Portal UI




Figure 1: Example of Morfeas WEB MDAQ-if UI