

# Morfeas WEB User Guide Configuration

### 1 License

Copyright (C) 12022 Sam Harry Tzavaras.

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included in the section entitled "GNU Free Documentation License".

### 2 Change History

 $\rm Jan~20,12022:~Sam~Harry~Tzavaras-Initial~Work.$ 

# Contents

1	License	2
2	Change History	2
3	Introduction	4
4	Network configuration	4
5	Morfeas System configuration	4
${f L}$	List of Figures	
	1 Morfeas WEB Utility for Network Configuration	4

### 3 Introduction

This reference guide will introduce utilities of the Morfeas WEB related to configuration of the Morfeas system and the network of host computer.

The "Morfeas WEB" is published under the AGPLv3 or later.

### 4 Network configuration

The network configuration utility is accessed by the front page of the Morfeas WEB from the button with this ''s symbol. At figure 1 shown an example of the network configuration utility.




Figure 1: Morfeas WEB Utility for Network Configuration

## 5 Morfeas System configuration