# LibOpenCIF

April 7, 2014

User manual 1.0

## 1 Introduction

This section shows to the user the information needed to understand the idea and concept behind this library and the reasons to use it.

#### 1.1 What is a CIF file?

A **CIF** file (*Caltech Intermediate Form*) is a special format designed to be used in **IC** (*Integrated Circuit*) design. Such format stores the physical layout of a design using basic figures (squares, metal stripes, polygons, circles). This format is used by various professional **CAD** (*Computer Aided Design*) tools, both open source and private, like **Alliance VLSI** (open source) and **Tanner Tools** (private).

One characteristic to keep in mind is that, in *IC* designs, one important aspect is precision. All the values managed (positions and sizes, for example), must have an incredible precision, since all the components must be precisely positioned and defined. To avoid problems relative to precision loss using floating point values, the values are defined as integers in the file. Also, the format doesn't limit the length of the values, so, the format of the values supported are defined by the applications that manipulate those values, not by the format itself (an application can support only 32 bit integers, but, others, can provide support for 64 bit values). That is the purpose of the AB fractions found in the definition start commands. Since there is still needed to use floating point values, the use of such special fractions help to translate the integer values to the exact floating values they are meant to be, and so, leaving the possible precision loss to the hands of the applications.

Such file format stores all the information of the design in plain text using commands. There are different kinds of commands that define and control different components of the design.

#### Box commands

Such commands define boxes (or rectangles) to be placed in the design. Such commands has three properties: position, size and an optional rotation vector, represented by a point.

#### Roundflash commands

Such commands define circles. The circles, however, normally are used as a piece component for the wire figures. The roundflash command has two properties: position and diameter.

#### Wire commands

Such commands define continuous stripes of material. The command is defined by a specific width and a list of points on which the stripe cross.

#### Polygon commands

Such commands represent arbitrary figures formed by a list of points.

## Definition start commands

These commands represent the start of special groups of commands, named definitions. Those definitions can represent anything, from a small cell of a design, to a whole design. Such commands specify an identification ID (a number), and, also, an optional AB fraction that can be used to transform all the values of the commands contained in the definition itself, from integers to floating point values.

#### Layer commands

The layer commands specify the material used by the commands that follow them.

#### Definition end commands

These commands help to set the end boundaries of the definitions.

#### Definition delete commands

The definitions already specified can be used as needed, all the times needed. If, for some reason, is needed to use an identification ID already used, is possible to use this command to delete from memory a used definition.

#### Call commands

The format itself defines that nothing in the file does something for the design until there is a call to a definition (that means that there can be things defined but never used). The call commands specifies the usage of a specific definition. The calls support the specification of some transformations to be applied to such definitions, like rotation, displacement and mirroring. Also, the calls can be put inside of the definitions, so, a big cell in a design can be split into smaller pieces, called as needed.

#### End command

The end command defines the end of the file.

## 1.2 What is LibOpenCIF?

LibOpenCIF is an open source library intended to aid the programmers to be able to load a CIF file into memory. The library provides basic validation of the contents. All the validations are performed using a special designed finite state machine.

The CIF file format, even defining a syntax of how to write a correct file, an input file can be hard to read, since the white spaces can be a lot of things, from real white spaces (spaces, tabs, enter) to lower case chars (all the lower case letters, from 'a' to 'z'). That means that there is possible to found a command like this one:

```
"B100xjnjzncjjajnja,,,as,c,cac,,,ac,csc,100,,,ca,ca,cas,s,,,gh,h50,-50,,,as-1,-1;
```

That, surprisingly, is a completely valid command. So, all the applications that need to load a CIF file, needs a way to load the contents and extract the real information from the commands. LibOpenCIF provides the ways to easily validate and load the contents of the input files. In this example, the library will provide the user with two basic things: A cleaned and easy to manage string, containing the same command and a class instance that provides direct and instant access to the values of the command. So, as an example, the previous command can be loaded with the library in the following form:

```
"B 100 100 50 -50 -1 -1;"
```

So, the library gives to the user two different mechanisms to work with the information of a CIF file.

#### 1.3 Why use LibOpenCIF?

LibOpenCIF can be used by everyone. From small programs, to big ones. These are some of the advantages of using LibOpenCIF on your system:

- Pure and standard C++ code: The library is self contained. That means that, from the compilation process, to the usage, there is no dependence in any other library or special tool. All of the capabilities of the library are provided using only C++ code and none system-call.
- Input file validations: The contents of a CIF file must be validated to ensure that the contents are complete and correct commands. Such validations are performed by the library using a special finite state machine, designed to validate and support various command formats found in use in professional tools (like layer names with more than 4 characters, digits and underscores). All of this ensures that the load process is performed according to the CIF specifications, but being compatible with industrial applications.
- Contents formatted for the user: After validating the input file contents, the library perform a buffering of the commands. This means that all the commands found in the input file can be accessed as a vector of strings. Also, the commands are not just copied from the input file. The string commands buffered are cleaned. That means, that all the separation chars are replaced by single white spaces. This formatting helps to have all the components of the command separated by a white space, allowing the user to use, for example, the strings as input streams.

- Contents ready to use: The library also offers to the user a ready-to-use vector of pointers. Such pointers, of a basic class, are instances of specialized classes that represent the commands of the file.
- Output and input operators: The classes used by the library provide the mechanisms to let the user send and read the commands from wherever he wants<sup>1</sup>.

 $<sup>^{1}</sup>$ Read the section 3.2 for more about such topics.

## 2 Using LibOpenCIF

The following sections shows the user how to use the library, from installing and uninstalling, to the common usage of the loaded results from the CIF files.

## 2.1 Installing

The installation is very straight forward. First, you need to get the library package, a compressed file containing all the sources and other specific files needed to install it. You need a file named *libopencif-X.Y.tar.gz*, where X and Y goes for the mayor and minor release number of the package.

Once you get the package, extract it in a new folder with full permissions of the actual user (like a folder in your home folder or any extra partition with write permissions, but, preferably not in a removable device like a USB stick or an external hard disk).

After extracting the package, open a terminal and change it's active working directory to the folder where the contents of the package are (so, that when you execute the ls command, you can see listed the contents).

On the extracted folder, with a terminal window opened, run the following commands, one by one, as a normal user (not as root nor using sudo, except for the last one). Don't forget to check the output of the commands to find any problem:

- \$ ./configure
- \$ make
- \$ sudo make install

Remember, the "\$" simbol is not part of the command. After running the commands, the library should be correctly installed in your system.

## 2.2 Uninstalling

If the library needs to be uninstalled, you can do it using the library package itself. To uninstall, get the package file, extract it's contents (as done in the installation procedure) and run these commands:

- \$ ./configure
- \$ sudo make uninstall

The following sections demonstrate the usage of the library. All of the relevant components of the library, from a user point of view, are covered. If you need more information, refer to the Technical Manual.

## 2.3 Compiling a program with the library

The first important point to learn how to do is the compilation of a program using the library. The compilation is very simple.

Let's assume you have only one source file, named program.cc, a C++ program source code. So, the compilation can be done with this command:

```
$ g++ program.cc -o binary_name -lopencif
```

Such command calls the compiler, named g++, followed by the source program file program.cc. After that, the -o binary\_name option specifies the name of the final binary file. Finally, there can be found the option that will add the library itself to the compilation process: -lopencif.

After running such command, the program will be compiled and ready to run. Please, refer to the documentation of your compiler or IDE to be able to add the needed option (-lopencif) to the compilation process.

## 2.4 Opening a CIF file

After learning how to compile your program, the first important task to perform, when using the library, is how to open a CIF file. For this example, we will assume that your application source file is named main.cc and your design file is named design.cif. Also, there is the assumption that both files are located in the same folder.

First, lets introduce the basic C++ program code that will help to demonstrate the usage of the library on the algorithm 1.

#### Algorithm 1 Initial test program source.

```
1  # include <iostream>
2
3  using namespace std;
4
5  int main ()
6  {
7     cout << "Test program" << endl;
8     return ( 0 );
9  }</pre>
```

Such code is a standard C++ program. The program, by itself, does nothing but print a simple message on the terminal. To use the library, the first step is to include the library itself. To do it, add this include instruction:

#### # include <opencif/opencif>

After including such line, all the components of the library are now available to use in the program. All the components of the library can be found within a namespace named OpenCIF. To open our design, you need to create an instance of the class File.

```
OpenCIF::File design;
```

The instance can also be created using dynamic memory allocation (using new and pointers).

After such instance is ready, we need to set the actual path to the file to open. The path can be relative or full. To set the path, the File class have a member function named setPath, which takes as argument a C++ string class instance or a direct string.

```
design.setPath ( "design.cif" );
```

After that, the instance is ready to be used. The next step is loading the file.

#### 2.5 Loading the whole file

After setting the file path, we can now order the File class instance to load the contents of the file.

The library uses, by default, an automated process of loading. Such process performs the following tasks in order:

- 1. Open the file.
- 2. Using a finite state machine, start validating the contents of the file, char by char. At the same time, the library is buffering the commands found and validated in a string form.
- 3. After loading the file into memory, the library performs a cleaning process to the commands loaded, replacing the separation chars with single white spaces.
- 4. Finally, the library converts the commands buffered into class instances.

Those 4 steps are performed automatically with a single member function call, named loadFile. The loadFile member function calls the needed member functions of the File class to perform the previous four tasks<sup>2</sup>. Of course, the tasks one and two can fail by some reasons. So, the library has implemented a special value type that is returned when calling the loadFile member function and helps the user to know if there is any kind of problem with the process.

The possible values of the return value are constants that can be found within the File class. The type of such constants is LoadStatus. So, to ask the File instance to load the file and store the result of the operation, you need to create a variable of type LoadStatus and call the loadFile member function from your instance:

 $<sup>^2</sup>$ To learn more about a manual load process, please, refer to the section 2.8 on this document.

```
OpenCIF::File::LoadStatus end_status;
end_status = design.loadFile ();
```

The possible values of the LoadStatus type are four constants found in the File class definition. The following piece of code checks the result of the operation. Take in mind that this is only an example, so, you can use a different approach to perform a validation of the result:

```
switch ( end_status )
{
   case OpenCIF::File::AllOk:
      cout << "None error detected" << endl;
      break;
   case OpenCIF::File::CantOpenInputFile:
      cout << "Error opening file" << endl;
      break;
   case OpenCIF::File::IncompleteInputFile:
      cout << "Incomplete file, no End Command found" << endl;
      break;
   case OpenCIF::File::IncorrectInputFile:
      cout << "Incorrect file" << endl;
      break;
}</pre>
```

These are the four possible values of the LoadStatus type:

AllOk This value is returned if all the operations where performed correctly. That means: The file can be opened, the contents of the file are correct and the end command was found.

CantOpenInputFile This value is returned if there was a problem opening the input file. Such problem can be related to the file path (the path can be incorrect, the file was removed before opening, etc).

IncompleteInputFile This value is returned if the input file is *correct*, but there was not found the end command. Even when this command is returned, all the validated and cleaned commands (in string form) are still stored and accessible for the user. If the user needs, he can manually call the member function related to transform the loaded string commands into class instances. The user must be aware that the contents, being incomplete, can be not useful at all.

IncorrectInputFile This value is returned if the validation process has reached an unexpected character in the file. In this case, in a similar way that the previous return value, the validated commands are still buffered and accessible to the user. Of course, there is a way to force the complete loading of a file, even when incorrect commands can be found. Such option will be explained in the section 2.8 found in this document.

## 2.6 Using the strings loaded

If you have a file already loaded, that means that you have received either an AllOk value (a complete loaded file) or any other value (a partial load, at best) from the loadFile member function, then you can make use of the loaded commands as you need. The commands are stored by the library in a C++ vector class that stores string class instances. Each string instance contains a full and valid CIF command. For every command in the CIF file, there is a string counterpart on the vector, in the same order.

To gather access to such commands, you must use the member function getRawCommands.

```
vector< string > commands;
commands = design.getRawCommands ();
```

After getting the commands, you can use them as needed. The format of the commands is very clear and easy to understand<sup>3</sup>. All the commands have it's components separated by single white spaces, so, all the separation characters are replaced. The next are two valid commands in CIF format (the first one is an exaggeration, but yet correct, the second one is as can be found in some professional tools):

<sup>&</sup>lt;sup>3</sup>Refer to the section 3.3, or in the Technical Manual, to learn more about the cleaning process of the commands.

```
Pthis,is,an,example100,-100,,,200,100more,text,100,0,,,;
P100,100 200,100 100,0;
```

So, the library transform such command to this:

```
P 100 -100 200 200 100 0 ;
```

All the components (included the identification character, the 'P' char and the semicolon) are separated with single white spaces. This format is intended to let the user use any process he wants to extract the information. The white spaces are used since they can be easily identified and can be used in common algorithms for splitting strings. Also, this command format is useful if the user wants to read the values of the command using a C++ input stream, like a istringstream class instance.

## 2.7 Using the instances created

If the file is correctly loaded or the partial loaded contents are manually ordered to be converted into instances (see section 2.8), the user can have access to a C++ vector class instance that stores class pointers. Those pointers are of the Command class, a special common base class used in most of the hierarchy of the classes defined in the library, so, using polymorphism, the user can ask, pointer by pointer, which command type is (a Box, Wire, Polygon, etc) and cast the pointer as needed (only the member function that returns the type of the command is polymorphic). The next example code shows how to get access to the vector of pointers from the File class instance using the getCommands member function.

```
vector< OpenCIF::Command* > commands;
commands = design.getCommands ();
```

After getting the commands, you can use the polymorphic member function type to get a constant value that represent the command type. The next example code, shows a simple process where the commands are already stored in a vector named commands. The code uses a for cycle to check all the commands stored and ask them their types using a switch structure. In every case, the pointer is casted to a derived class pointer and then printed to the console.

```
vector< OpenCIF::Command* > commands;
commands = design.getCommands ();
for ( int i = 0; i < commands.size (); i++ )</pre>
   OpenCIF::BoxCommand* box;
   /*... More class pointers of every type ...*/
   OpenCIF::Command* cmd;
   cmd = commands[ i ];
   switch ( cmd->type () )
      case OpenCIF::Command::Box:
         box = dynamic_cast< OpenCIF::BoxCommand* > ( cmd );
         cout << box << endl;</pre>
         break;
      /*... More Switch cases ...*/
      default:
         break;
   }
}
```

In this little example, a for cycle traverse over all the commands loaded from the file. For every command, it's pointer is copied into a Command class pointer (only to reduce the name from "commands[ i ]" to "cmd"). After that, a switch is used to check the command type.

To access the command type, there is possible to use the polymorphic member function type. Such call will return a constant value of an enumeration type. Since, in C++, if a switch structure is used to check the value of a enumeration type, all the possible values of such enumeration should be used. That is the reason to use the

empty default statement, to avoid the need to include unnecessary cases (there are various class types defined in the library that are not intended to be used by the user).

In this case, there only appears to be used one value of such enumeration (see section 2.8.6 to learn more about the classes intended to be used by a user), the Box value (all the values that represent the type of a command are stored in the Command class within the OpenCIF namespace).

In this case, the cmd pointer is dynamically casted into a BoxCommand class pointer. With such casted pointer, the command can be printed<sup>4</sup>.

Sadly, the member functions of the classes are not available using the base pointer beyond the type member function (they are not polymorphic). That means that there is needed to perform the casting to derived pointer in order to use the needed member functions.

## 2.8 Manual loading process

There is possible that you need or want to load a CIF file until some specific step and/or want to force the load of the file even when facing errors in the contents. The LibOpenCIF library provides such facilities to the user.

#### 2.8.1 Opening the input file

The first process to review is the manual loading. To manually load a file, the first step, as in the automatic method, is to set the file path using the setPath member function:

```
OpenCIF::File design;
design.setPath ( "design.cif" );
```

After that, the first manual operation to do is opening the input file. To manually open the file, use the openFile member function.

```
design.openFile ();
```

Such call can return two different results:

AllOk The file was opened correctly.

**CantOpenInputFile** The file can't be opened. In this case, the user must perform some kind of validation of the file path, from checking that it is correct, to validate the existence and permissions of the file itself.

The user must be aware that this step is needed for the rest of the steps.

## 2.8.2 Validating/buffering file

The next step, once the input file is opened, is to validate the file. The user must remember that, while validating, the library performs a buffering of the commands found, storing them as strings. This process is performed by the call to the validateSyntax member function.

```
design.validateSyntax ();
```

Such call can return three possible values:

**AllOk** The input file is correct and complete.

**IncompleteInputFile** The input file is correct, but there was not found the End command. This may result in an incomplete and useless design file<sup>5</sup>.

IncorrectInputFile The input file has errors. Normally, after detecting an unexpected character, the validation/bufferin process stops.

In all the three cases, the commands buffered and validated are accessible through the call to the getRawCommands member function. Such call will return a vector of strings. Such strings are the commands found in the input file, but they are still not cleaned, so, you will find them exactly as you can see them in the file. If you need exactly that, this is the point when you can retrieve the commands.

<sup>&</sup>lt;sup>4</sup>The commands are designed to be printable from 3 states: base pointer (as Command class pointers), class pointers (as in this example) and as regular class instances (not pointers).

<sup>&</sup>lt;sup>5</sup>There must be pointed that some professional applications support such lack of command, but that doesn't mean that a valid CIF file must not have an End Command.

#### 2.8.3 Cleaning the commands

After loading the input file, a call to the cleanCommands member function is recommended, since it performs the cleaning of all the commands loaded (no matter if the file was correct nor complete).

```
design.cleanCommands ();
```

All the buffered commands are replaced with their cleaned counterparts (to reduce memory usage). If there is needed to keep a copy of the original commands of the file, is recommended to perform a call to the getRawCommands member function and storing them in a string vector before calling the member function to clean the commands.

This member function doesn't return any value and can't fail (since it only works with the commands loaded, if there is none, will do nothing).

#### 2.8.4 Converting the commands into instances

The last step of the load process. If there are commands loaded and cleaned, the member function convertCommands can be called to convert them into class instances.

```
design.convertCommands ();
```

After calling it, the command class pointers can be accessed using the getCommands member function.

The convertCommands member function doesn't return anything, but the user must be aware that this member function is the most prone to errors, since it's design and work flow depends on the string commands stored. The commands must be already cleaned. If the commands are not cleaned, the call to this member function can lead to logical or even critical errors (program crashes). Remember: The member function assumes that the commands are clean, so it can work a little bit more faster and prevent bottlenecks.

If the user is totally sure about the nature of the input files and their formats, the cleaning operation can be skipped to increase the overall speed of the load process.

## 2.8.5 Forcing load of file

There is possible to force the process of validation of a file, so it skips the incorrect commands and load as much as possible of a file. The user must be aware that doing this may result in an incorrect design that may not be useful at all.

The process is simple, and can be used when automatically or manually loading a file.

When using the automatic process, calling the loadFile member function of the File class, you can pass a constant value to it to specify what to do when encountering an error. By default, a call to such member function in this way:

```
design.loadFile ();
```

Will automatically pass the constant value StopOnError that specify the behavior of the process when confronting an incorrect or incomplete file. Such value is located within the File class. So, to explicitly order the automatic load process to stop when facing errors, you can use this call:

```
design.loadFile ( OpenCIF::File::StopOnError );
```

Also, you can force the automatic process to continue loading and processing the commands found even when facing an incomplete or incorrect command. To do it, you can use the constant value ContinueOnError that is also found within the File class. To use it when automatically loading a file, you can use a call like this one:

```
design.loadFile ( OpenCIF::File::ContinueOnError );
```

Doing this, the process will ignore the fact that a file is incomplete and will try to skip incorrect commands and read as many as possible<sup>6</sup>.

Even using this two constants, the loadFile member function will still return the correspondent value after loading, either AllOk, IncompleteInputFile or IncorrectInputFile.

Those constants (StopOnError and ContinueOnError) can also be used when manually loading a file. From all the member functions that can be used, the only one that accept such values is the validateSyntax member

<sup>&</sup>lt;sup>6</sup>There must be noted that the error CantOpenInputFile will still stop all the process, since is a critical error that can't be ignored.

function. All the other member functions don't need such control, since they operate on previous results or are truly critical processes (like the openFile member function), so, the validateSyntax member function, by default, uses the StopOnError constant, but you can use the specific constant that you need. You can specify an instruction like this one:

```
design.validateSyntax ( OpenCIF::File::StopOnError );
```

So, the call to such member function will behave normally. After finding an unexpected input char, the process will stop. But, you can specify other constant to force the validation of the file, even when facing errors in the input file:

```
design.validateSyntax ( OpenCIF::File::ContinueOnError );
```

In this case, the member function will continue and skip as many errors as possible.

### 2.8.6 Classes intended to be used by the user

When loading a CIF file, you can use the OpenCIF library to automatically convert the CIF string commands into OpenCIF class instances. As explained before, you can do it when loading a file in automatic mode, or when manually loading it's contents.

Remember that all of this classes can be found within the OpenCIF namespace. The most important and useful classes for the user are the next ones.

#### Command

This is the base for most of the class hierarchy in the library. The next list shows all the relevant member functions, constructors and destructors that the user might need.

- Command: Constructor of the class. Takes no arguments and initialize the instance type as a Command.
- type: Public member function that is polymorphic. Takes no arguments and returns a value of type CommandType. In the case of this class, the value returned is PlainCommand.

The class has, also, defined two operator functions that let the class be written and read to and from an input and output stream, respectively<sup>7</sup>. Those operators expect a class pointer, not a normal instance. This is due that this class is intended to be used only to store to other classes (base-class-pointer to derived-class mechanism). These two operators are not polymorphic for themselves, but they call internal private member functions that are polymorphic. So, sending a class instance using a Command pointer to an output stream, will call the needed function to convert the instance into a string and write it to the stream, or, if extracting from a stream, the operator will call the relevant polymorphic function to read an instance.

#### Point

This class represents a CIF point in the file and is used in various classes in the library. The next list shows all the relevant member functions, constructors and destructors that the user might need.

- Point: Constructor of the class. It is overloaded, so you can call it with or without arguments. Calling without arguments will use the default constructor. The default constructor initialize the instance with values 0 in X and Y (the origin). The other constructor takes as argument two long int integers representing X and Y, in that order (first X, then Y).
- set: Public member function that helps to set the coordinates of the point in a single call. Takes as argument two long int integers, representing X and Y, in that order. Has no return value.
- setX: Public member function that sets the X component of the point. Takes as argument a long int integer value.
- setY: Public member function that sets the Y component of the point. Takes as argument a long int integer value.

<sup>&</sup>lt;sup>7</sup>The user must be aware that the reading process depends heavily on the format of the input stream. The input stream must have a clean format as defined in the section 3.3.

- getX: Public member function that returns the X component of the point. Returns a long int integer value.
- getY: Public member function that returns the Y component of the point. Returns a long int integer value.

The class has, also, defined two operator functions that let the class be written and read to and from an input and output stream, respectively<sup>8</sup>. Those operators expect a normal instance, not a pointer. The next code lines represent the calls presented.

```
// Normal instance, default constructor (point initialized to 0,0)
OpenCIF::Point point;
// Normal instance, overloaded constructor (point initialized to 100,100)
OpenCIF::Point point ( 100 , 100 );
// Manually setting the point values
point.set ( -100 , 200 );
point.setX ( -100 );
point.setY ( 200 );
// Manually getting the point values
long int x , y;
x = point.getX ();
y = point.getY ();
// Reading a point from an input file
ifstream file;
/*... Opens file ...*/
file >> point;
// Writing a point to an output file
ofstream file;
/*... Opens file ...*/
file << point;</pre>
```

#### Size

This class represents a CIF size in the file and is used in various classes in the library. The next list shows all the relevant member functions, constructors and destructors that the user might need.

- Size: Constructor of the class. Initialize the size to 1,1 by default.
- set: Public member function that helps to set the component size in a single call. Takes as argument two unsigned long int integers, representing width and height, in that order. Has no return value.
- setWidth: Public member function that sets the width component of the size. Takes as argument an unsigned long int integer value.
- setHeight: Public member function that sets the height component of the size. Takes as argument an unsigned long int integer value.
- getWidth: Public member function that returns the width component of the size. Returns an unsigned long int integer value.
- getHeight: Public member function that returns the height component of the point. Returns an unsigned long int integer value.

<sup>&</sup>lt;sup>8</sup>The user must be aware that the reading process depends heavily on the format of the input stream. The input stream must have a clean format as defined in the section 3.3.

The class has, also, defined two operator functions that let the class be written and read to and from an input and output stream, respectively<sup>9</sup>. Those operators expect a normal instance, not a pointer. The next code lines represent the calls presented.

```
// Normal instance, default constructor (size initialized to 1,1)
OpenCIF::Size size;
// Manually setting the size values
size.set ( 100 , 200 );
size.setWidth ( 100 );
size.setHeight ( 200 );
// Manually getting the size values
unsigned long int x , y;
x = size.getWidth ();
y = size.getHeight ();
// Reading a size from an input file
ifstream file;
/*... Opens file ...*/
file >> size;
// Writing a size to an output file
ofstream file;
/*... Opens file ...*/
file << size;
```

#### PolygonCommand

This class represents the Polygon Command. The next list shows all the relevant member functions, constructors and destructors that the user might need.

- PolygonCommand: Constructor of the class. It is overloaded, so you can call it with without arguments. Calling without arguments will use the default constructor. The default constructor initialize the instance without points. The other constructor takes as argument a C++ string. Such string must represent a complete CIF command with a format as defined in section 3.3. Such constructor will initialize the instance with the points defined in the string command. Both constructors set the command type as Polygon.
- type: Public member function that is polymorphic. Takes no arguments and returns a value of type CommandType. In the case of this class, the value returned is Polygon.
- setPoints: Public member function that helps the user to manually set a C++ vector of Point class instances. Such vector represent the points of the polygon. The call to this member function replace the previously stored polygon points.
- getPoints: Public member function that helps the user to retrieve the points used by the polygon. The return value is a C++ vector containing Point class instances.

The class has, also, defined four operator functions that let the class be written and read to and from an input and output stream, respectively<sup>10</sup>. Two operators works to read and write PolygonCommand class pointers. The other two works to read and write PolygonCommand class instances. The next code lines represent the calls presented.

```
// Normal instance, default constructor (no points set)
OpenCIF::PolygonCommand normal_instance;
```

<sup>&</sup>lt;sup>9</sup>The user must be aware that the reading process depends heavily on the format of the input stream. The input stream must have a clean format as defined in the section 3.3.

<sup>&</sup>lt;sup>10</sup>The user must be aware that the reading process depends heavily on the format of the input stream. The input stream must have a clean format as defined in the section 3.3.

```
// Pointer instance, default constructor (no points set)
OpenCIF::PolygonCommand* pointer_instance = new OpenCIF::PolygonCommand ();
// Normal instance, initializing using string
OpenCIF::PolygonCommand normal_points ( "P 0 0 100 0 100 100;" );
// Pointer instance, initializing using string
OpenCIF::PolygonCommand* pointer_points;
pointer_points = new OpenCIF::PolygonCommand ( "P 0 0 100 0 100 100 ;" );
// Setting points manually
vector< Point > points;
points.push_back ( Point ( 0 , 0 ) );
points.push_back ( Point ( 100 , 0 ) );
points.push_back ( Point ( 100 , 100 ) );
normal_instance.setPoints ( points );
pointer_instance->setPoints ( points );
// Getting points
vector< Point > retrieved_points;
retrieved_points = normal_points.getPoints ();
retrieved_points = pointer_points->getPoints ();
// Loading instances from a file
ifstream file;
/*... Opens file ...*/
file >> normal_points;
file >> pointer_points;
// Writing instances to a file
ofstream file;
/*... Opens file ...*/
file << normal_points;</pre>
file << pointer_points;
```

#### WireCommand

This class represents a CIF Wire command. The next list shows all the relevant member functions, constructors and destructors that the user might need.

- WireCommand: Constructor of the class. It is overloaded, so you can call it with or without arguments. Calling without arguments will use the default constructor. The default constructor initialize the instance without points and a width of 0. The other constructor takes as argument a C++ string class instance. The string must represent an valid and clean CIF wire command.
- setWidth: Public member function that helps to set the width of the wire. Takes as argument an unsigned long int integer value.
- getWidth: Public member function that returns the width of the wire. Returns an unsigned long int integer value.
- setPoints: Public member function that helps the user to manually set a C++ vector of Point class instances. Such vector represent the points of the wire. The call to this member function replace the previously stored wire points.
- getPoints: Public member function that helps the user to retrieve the points used by the wire. The return value is a C++ vector containing Point class instances.

The class has, also, defined four operator functions that let the class be written and read to and from an input and output stream, respectively<sup>11</sup>. Two operators works to read and write WireCommand class pointers. The other two works to read and write WireCommand class instances. The next code lines represent the calls presented.

```
// Normal instance, default constructor (no points set)
OpenCIF::WireCommand normal_instance;
// Pointer instance, default constructor (no points set)
OpenCIF::WireCommand* pointer_instance = new OpenCIF::WireCommand ();
// Normal instance, initializing using string
OpenCIF::WireCommand normal_points ( "W 100 0 0 100 0 100 ;" );
// Pointer instance, initializing using string
OpenCIF::WireCommand* pointer_points;
pointer_points = new OpenCIF::WireCommand ( "W 100 0 0 100 0 100 100 ;" );
// Setting values manually
vector< Point > points;
points.push_back ( Point ( 0 , 0 ) );
points.push_back ( Point ( 100 , 0 ) );
points.push_back ( Point ( 100 , 100 ) );
normal_instance.setPoints ( points );
normal_instance.setWidth ( 100 );
pointer_instance->setPoints ( points );
pointer_instance->setWidth ( 100 );
// Getting values
vector< Point > retrieved_points;
unsigned long int width;
retrieved_points = normal_points.getPoints ();
width = normal_points.getWidth ();
retrieved_points = pointer_points->getPoints ();
width = pointer_points->getWidth ();
// Loading instances from a file
ifstream file;
/*... Opens file ...*/
file >> normal_points;
file >> pointer_points;
// Writing instances to a file
ofstream file;
/*... Opens file ...*/
file << normal_points;</pre>
file << pointer_points;</pre>
```

#### BoxCommand

This class represents a CIF Wire command. The next list shows all the relevant member functions, constructors and destructors that the user might need.

<sup>&</sup>lt;sup>11</sup>The user must be aware that the reading process depends heavily on the format of the input stream. The input stream must have a clean format as defined in the section 3.3.

- WireCommand: Constructor of the class. It is overloaded, so you can call it with or without arguments. Calling without arguments will use the default constructor. The default constructor initialize the instance without points and a width of 0. The other constructor takes as argument a C++ string class instance. The string must represent an valid and clean CIF wire command.
- setWidth: Public member function that helps to set the width of the wire. Takes as argument an unsigned long int integer value.
- getWidth: Public member function that returns the width of the wire. Returns an unsigned long int integer value.
- setPoints: Public member function that helps the user to manually set a C++ vector of Point class instances. Such vector represent the points of the wire. The call to this member function replace the previously stored wire points.
- getPoints: Public member function that helps the user to retrieve the points used by the wire. The return value is a C++ vector containing Point class instances.

The class has, also, defined four operator functions that let the class be written and read to and from an input and output stream, respectively<sup>12</sup>. Two operators works to read and write WireCommand class pointers. The other two works to read and write WireCommand class instances. The next code lines represent the calls presented.

```
// Normal instance, default constructor (no points set)
OpenCIF::WireCommand normal_instance;
// Pointer instance, default constructor (no points set)
OpenCIF::WireCommand* pointer_instance = new OpenCIF::WireCommand ();
// Normal instance, initializing using string
OpenCIF::WireCommand normal_points ( "W 100 0 0 100 0 100 ;" );
// Pointer instance, initializing using string
OpenCIF::WireCommand* pointer_points;
pointer_points = new OpenCIF::WireCommand ("W 100 0 0 100 0 100 100;");
// Setting values manually
vector< Point > points;
points.push_back ( Point ( 0 , 0 ) );
points.push_back ( Point ( 100 , 0 ) );
points.push_back ( Point ( 100 , 100 ) );
normal_instance.setPoints ( points );
normal_instance.setWidth ( 100 );
pointer_instance->setPoints ( points );
pointer_instance->setWidth ( 100 );
// Getting values
vector< Point > retrieved_points;
unsigned long int width;
retrieved_points = normal_points.getPoints ();
width = normal_points.getWidth ();
retrieved_points = pointer_points->getPoints ();
width = pointer_points->getWidth ();
```

<sup>&</sup>lt;sup>12</sup>The user must be aware that the reading process depends heavily on the format of the input stream. The input stream must have a clean format as defined in the section 3.3.

```
// Loading instances from a file
ifstream file;
/*... Opens file ...*/
file >> normal_points;
file >> pointer_points;

// Writing instances to a file
ofstream file;
/*... Opens file ...*/
file << normal_points;
file << pointer_points;</pre>
```

- 3 About LibOpenCIF
- 3.1 Using LibOpenCIF in different operating systems
- 3.2 Usage of the overloaded operators on the classes
- 3.3 Cleaning process of the string commands