

Custom / Local `.bin` — Bring-Your-Own-Firmware Guide

Profile: Custom / local `.bin` · **Upstream:** none — *you* supply the binary (a firmware not yet in Cyber Controller, or one you built yourself) **Chips:** any ESP32-family part — ESP32, ESP32-S2, ESP32-S3, ESP32-C2, ESP32-C3, ESP32-C6, ESP32-C5, ESP32-H2 · **Cyber Controller profile:** `custom` (esptool backend, chip **auto-detect**, lone-image merged@0x0 default, optional explicit multi-file offsets, **no** suicide/erase-on-flash) **This guide:** obtain or build a `.bin` → understand merged-vs-multi-file and offsets → flash it via Cyber Controller → verify it boots → troubleshoot. **You are responsible for whatever firmware you flash.**

1. Overview

This is the **meta profile**. Every other profile in Cyber Controller targets one specific firmware with a pinned download, a known board list, and a protocol parser. The `custom` profile targets *nothing* and *everything*: it lets you flash **any precompiled ESP32 `.bin` you already have on disk** — a firmware Cyber Controller doesn't ship a profile for yet, a pre-release build from a project's CI, or your own PlatformIO / Arduino / ESP-IDF output.

It exists because the flashing machinery (chip auto-detection, correct per-chip bootloader offsets, the `--flash_size detect` safety flag, child-process cleanup) is identical no matter whose firmware you write. The `custom` profile reuses all of that and simply points the flasher at **your** file instead of a downloaded release. Its description in the profile JSON sums it up:

"Flash ANY local `.bin(s)` you provide, with chip-appropriate default offsets. A lone merged image flashes at 0x0; pass an explicit support map (offset→path) for a full multi-file flash."

What `custom` does **not** do: there is no upstream repo (`repo: null, firmware_urls: {}`), no release resolver (`resolver: local` — `latest_release()` returns `("local", [])`), and no protocol-aware command palette (`protocol: custom`). Cyber Controller can't parse the output of a firmware it doesn't know, so after flashing you drive the device through the **raw serial terminal**, not a per-firmware command set. Think of `custom` as "esptool with a nice UI, integrated into the same Flash/Devices workflow as everything else."

2. Legal & Safety

You are responsible for whatever firmware you flash. Because this profile flashes *arbitrary* code, the legal and safety picture depends entirely on the binary you choose — Cyber Controller is just the writer.

- **Only flash firmware you trust.** A `.bin` is opaque machine code. Prefer binaries you compiled yourself from source you've read, or official signed/hash-verified releases from a project you trust. A malicious or tampered image can brick the board, exfiltrate over Wi-Fi/BLE, or turn the device into something you

didn't intend. **Verify a download's checksum/signature against the project's published value before flashing** (verify: the project's release notes for a SHA-256 / GPG signature).

- **Authorized use only.** If the firmware you flash performs Wi-Fi/BLE/RF actions (deauth, beacon spam, evil-AP, jamming, scanning), the same laws that govern those actions on any device apply here — in most jurisdictions transmitting against networks or people you don't own or have **written permission** to test is illegal (US: CFAA/FCC; elsewhere equivalents). **RF jamming firmware is illegal to operate almost everywhere** regardless of the board it runs on. Flashing is not operating, but you are still responsible for what you then do with the device.
- **Know your hardware limits.** Flashing an image built for the wrong chip, wrong flash size, or wrong board can leave the device non-booting (recoverable — see §8) but writing to the wrong external SPI device or forcing a board outside its electrical limits is on you.
- **No safety net from the profile.** `custom` sets `danger: ""` (no built-in danger label) and `supports_suicide: false` — it ships **no** confirmation gating for whatever the firmware later does and **no** Dead Man's Switch wipe. The judgment is yours.

This guide is for flashing firmware you're authorized to run on hardware you own, in a lawful research/engineering context.

3. "Hardware" — any ESP32-family board + a data cable

There is no purchase list here, because the whole point is that you bring your own board and binary. The only requirements:

Need	Detail
An ESP32-family board	Any chip <code>esptool</code> /Cyber Controller supports: <code>esp32</code> , <code>esp32s2</code> , <code>esp32s3</code> , <code>esp32c2</code> , <code>esp32c3</code> , <code>esp32c6</code> , <code>esp32c5</code> , <code>esp32h2</code> . The board can be a bare DevKit, a CYD, an M5 device, a Flipper dev board — anything, as long as your <code>.bin</code> was built for that exact chip (see §8). <code>boards: []</code> in the profile means it imposes no board list.
A real USB data cable	Not a charge-only cable. Without data lines no COM/tty port appears.
The USB-serial driver	CP210x (most DevKits / official boards), CH340/CH341 (cheap clones), or native USB-CDC (S2/S3/C-series). No driver → no port.
A matching <code>.bin</code>	The firmware image(s) for your chip — covered in §4.
A supported <code>esptool</code>	Cyber Controller calls <code>esptool</code> under the hood and needs <code>esptool>=4.7, <6</code> . v6 removed the <code>write_flash / --flash_size / chip_id</code> aliases this tool relies on; <4.7 predates newer chips (e.g. C5). If yours is out of range, <code>pip install 'esptool>=4.7, <6'</code> .

Flash size matters. Many `.bin` images encode a flash-size header. Cyber Controller passes `--flash_size` detect so a 16 MB-header image won't boot-loop a 4 MB board, but if you build your own firmware, build it for the board's actual flash size (verify: your board is ≥ 4 MB if the firmware expects it).

4. Preparing your .bin

This is the heart of bring-your-own-firmware. Get this right and flashing is trivial.

4.1 Where .bin files come from

- **A project's GitHub Release / CI artifacts.** Look for assets ending in `.bin` (or a `.zip` containing them). Projects ship one of two shapes:
 - a single **merged** image (often named `*merged*.bin`, `*.merged-flash.bin`, `firmware-full.bin`, or the asset a web-flasher uses), **or**
 - **separate** `bootloader.bin`, `partitions.bin` (a.k.a. `partition-table.bin`), sometimes `boot_app0.bin`, and the **app** (`firmware.bin` / `*.ino.bin`).
- **Your own PlatformIO build.** Output lands in `.pio/build/<env>/:`
 - app: `firmware.bin` · bootloader: `bootloader.bin` · partitions: `partitions.bin`.
 - `pio run -v` prints the exact `esptool write_flash` line **with the offsets** PlatformIO would use.
- **Your own Arduino IDE build.** *Sketch* → *Export Compiled Binary* writes next to the sketch:
 - `Sketch.ino.bin` (app), `Sketch.ino.bootloader.bin`, `Sketch.ino.partitions.bin`.
 - Standard ESP32 Arduino offsets: bootloader `0x1000`, partitions `0x8000`, `boot_app0` `0xE000`, app `0x10000`.
- **Your own ESP-IDF build.** `idf.py build` produces `build/<project>.bin` (app), `build/bootloader/bootloader.bin`, `build/partition_table/partition-table.bin`. **idf.py flash prints every offset**, and `build/flasher_args.json` lists them in its `flash_files` map.
- **Web-flasher manifests (ESP Web Tools).** A `manifest.json` lists parts as `{path, offset}` — usually a single merged image at `0x0`.

4.2 Merged single-.bin vs multi-file

This distinction determines the offset you flash at — get it wrong and the board won't boot.

Image model	What it is	How to flash
Merged single .bin (merged-single-bin)	One file that already contains bootloader + partition table + (<code>boot_app0</code>) + app, each pre-placed at its correct internal address.	Flash the whole file at 0x0 . Simplest path — and the default for custom.
Multi-file (offsets) (multi-file-offsets)	The app .bin plus <i>separate</i> bootloader/partitions/(<code>boot_app0</code>) files. The app alone is not bootable on a blank chip.	Write each file at its own offset (table below). The app goes at its app offset (typically <code>0x10000</code>).

Cyber Controller's custom profile defaults to the merged model (`image_model: merged-single-bin`, `app_offset: 0x0`). When you hand it a lone `.bin`, it writes that one file at `0x0` — correct for a merged image. If all you have are *separate* `bootloader/partition/app` files, you have two options:

1. **Merge them first** with `esptool`, then flash the merged result at `0x0` (recommended — turns a multi-file image into the easy case):
`esptool --chip esp32 merge_bin -o merged.bin \ 0x1000
bootloader.bin 0x8000 partitions.bin 0xe000 boot_app0.bin 0x10000 app.bin` (Use your chip and your project's real offsets; for S3/C3/C6/H2 the bootloader is `0x0`, for C5 it's `0x2000`.)

2. **Provide an explicit multi-file flash** via the `flash_local()` "support map" — see §5.3 and §6.

4.3 Standard offsets (and how to find a project's)

The "always" offsets (partition table, `boot_app0`, `app`) are constant across chips; only the **bootloader** offset varies by chip family:

Region	Offset	Notes
Merged single image	0x0	The merged blob always starts at zero — this is the custom default.
Bootloader — classic ESP32 / S2	0x1000	
Bootloader — S3 / C2 / C3 / C6 / H2	0x0	RISC-V parts + S3 place the 2nd-stage bootloader at zero.

Bootloader — ESP32-C5	0x2000	The C5 ROM expects it here — <i>not</i> 0x0, <i>not</i> 0x1000. Flashing a C5 bootloader at 0x0 yields a board that never boots.
Partition table	0x8000	Same on every chip.
boot_app0	0xE000	Only present in some build flows (e.g. Arduino). Omit if your project omits it.
App	0x10000	The default app-only offset for multi-file images.

How to find a specific project's offsets (don't guess if it's non-standard): - **ESP-IDF:** open `build/flasher_args.json` — the `flash_files` object maps offset → file exactly. `idf.py flash` also echoes them. - **Arduino:** run an upload with verbose output on (*File* → *Preferences* → *Show verbose output during upload*, or `arduino-cli upload -v`); the printed `esptool write_flash` command lists every offset. - **PlatformIO:** `pio run -v` (or `pio run -t upload -v`) prints the `write_flash` command with offsets. - **ESP Web Tools project:** read the `manifest.json` `parts[].offset` values. - **A project's README / `flash.sh` / `RUN_THIS.bat` / `flash.bat`:** these almost always hard-code the offsets the maintainer uses — the source of truth when in doubt.

If a project ships a **merged** image, you can ignore all of this and flash at `0x0`.

5. Flashing a local `.bin` via Cyber Controller

Cyber Controller's Flash tab loads firmware via a small **profile JSON**, and the custom profile's job is to carry a pointer to your local file. The cleanest way to flash an arbitrary `.bin` is to write a tiny local profile JSON and load it.

5.1 Write a one-off local profile (recommended, most explicit)

Create a small JSON file (e.g. `my-firmware.json`) pointing at your `.bin`:

```
{
  "id": "custom",
  "name": "My Firmware (local)",
  "local_path": "C:/path/to/your/merged.bin",
  "chip": "auto",
  "flash_baud": 921600
}
```

- `id: "custom"` selects this profile's machinery.
- `local_path` is your `.bin` (a **merged** image — it will be written at `0x0`).
- `chip: "auto"` lets Cyber Controller detect the chip; set it explicitly (`"esp32s3"`, `"esp32c5"`, ...) if you want to force it.
- `flash_baud` is optional (default 921600).

5.2 Flash it

1. **Install the USB-serial driver** for your board (CP210x / CH340 / native), then connect the board by USB.
2. Open Cyber Controller → **Flash** tab.
3. **Port:** pick the board's COM/tty in the *Port* card (click **Refresh** if it's missing → driver/cable issue).
4. **Firmware Profile:** click **Browse...** (next to the profile dropdown) and select your `my-firmware.json`. It loads into the dropdown and becomes the active profile. (*The picker's file filter is JSON profiles. verify: whether your build also lets Browse target a `.bin` directly; the documented, reliable path is the local-profile JSON above.*)
5. **Chip:** leave **Board / variant** on *Auto* — for custom the chip is resolved as **explicit profile chip** → **board chip** → **auto-detect via esptool chip_id**. The flash log prints `[chip] detecting...` then `[chip] using <chip>`.

6. Click **Flash**. Cyber Controller writes your `local_path .bin` at `0x0` (merged default), with `--flash_size` detect for safety, at the chosen baud. Watch the **Flash Log** and progress bar; "Flash complete" means esptool returned success.

5.3 Multi-file via the support map

The Flash-tab local-profile flow writes **one** file at `0x0` (the merged case). For a genuine **multi-file** flash — separate bootloader/partitions/app each at its own offset — the underlying `flash_local()` surface accepts a support map (offset → path) plus an `app_offset`; supplying it switches the flash to "full" mode. If your build doesn't expose this in the UI, the robust workaround is [§4.2 option 1: esptool merge_bin](#) your separate files into one image and flash that at `0x0`. (*verify: whether your Cyber Controller build surfaces the support-map / per-offset picker in the Flash tab.*)

6. Integration (the `custom` profile)

- **Profile facts** (`src/config/profiles/custom.json`): `id: custom, backend: esptool, protocol: custom, boards: [], default_baud: 921600, repo: null, firmware_urls: {}, danger: "", supports_suicide: false, image_model: merged-single-bin, resolver: local, app_offset: 0x0, variants_for_chip: all, default_variant: first.`
- **No remote anything.** `latest_release()` returns `("local", [])` and `support_files()` returns `None` — there's nothing to download. As the profile note says: *"No GitHub repo — the user points at local files via the bespoke `flash_local()` / `local_asset()` surface ... the engine has a dedicated custom branch."*
- **The flash path.** In the engine (`flash_engine._flash_esptool`): it first resolves the chip (**explicit** → **board** → **esptool chip_id auto-detect**, falling back to `esp32`), then — because the profile carries a `local_path` — routes to the dedicated custom branch: `custom = flash_core.get_profile("custom")`
`custom.flash_local(port, chip, profile.local_path, on_line, baud=profile.baud)`
`flash_local(...)` flashes the app at `app_offset` (`0x0` default = merged blob) unless a support map is passed, in which case it does a full multi-file write (`mode = "full" if support else "app"`).
- `local_asset(path, chip=None, offset="0x0", merged=True)` is the helper that builds the asset descriptor for a local file — useful if you script the flash rather than using a profile JSON.
- **Chip auto-detect** is firmware-agnostic and shared by every profile: `esptool chip_id` output is matched against `ESP32-S3/S2/C6/C5/C3/C2/H2` tokens, else plain `ESP32`. This is why `chip: "auto"` "just works" for most boards — but set it explicitly if detection is flaky or the board reports oddly.
- **No protocol parser, no command palette, no Cross-Comm routing, no Dead Man's Switch** for `custom` — `protocol: custom` and `supports_suicide: false`. After flashing you interact through the raw serial terminal ([§7](#)).
- **Backup before overwriting.** The Flash tab's **Backup** button dumps the current flash to a `.bin` first — do this if you might want to restore the board's prior firmware.

7. Usage

Because Cyber Controller doesn't know your firmware's protocol, "usage" is **verify it boots, then talk to it raw**.

1. **Confirm a clean flash.** The Flash Log should end with esptool's success/verify lines and "Flash complete." A "Hash of data verified" line (when present) means the written image matches.

2. **Verify it boots.** Go to the **Devices** tab → select the same port → **Connect**. Open the serial terminal and watch the **boot banner**: - A normal ESP32 boot prints a `rst:0x1 (POWERON_RESET) / boot:0x...` ROM banner followed by your firmware's own startup output. **Set the terminal baud to the firmware's monitor baud** (commonly 115200; some firmwares use 921600 or other — verify: against the project). - A blank screen on a display board, or only the ROM banner with no app output, suggests a wrong offset / wrong chip / wrong board image — see [§8](#).
3. **Interact raw.** Type the firmware's own commands into the serial terminal (e.g. a CLI prompt, help, etc., per *that* firmware's docs). Cyber Controller relays bytes faithfully but won't colorize or parse them, and won't populate the Targets pool — that's expected for custom.
4. **Re-flash / iterate.** For your own builds, rebuild → update `local_path` (or overwrite the same path) → Flash again. No need to erase between compatible builds, though a full erase resolves layout changes (see below).

8. Troubleshooting

- **No COM/tty port:** install the CP210x/CH340 driver; swap to a **data** cable; on Linux add your user to `dialout` and replug.
- **"A fatal error occurred: Failed to connect to ESP32 / Wrong boot mode":** hold **BOOT** (GPIO0) while plugging in or during connect, then release; lower the flash baud in your profile (`flash_baud`); close any other serial monitor holding the port.
- **Flashes "successfully" but won't boot — wrong offset (merged vs multi-file mistake):**
 - You flashed a **merged** image somewhere other than `0x0` → re-flash at `0x0` (the `custom` default).
 - You flashed only the **app** `.bin` to a blank chip (no bootloader/partitions) → boot-loop with `invalid header: 0xffffffff` or `rst:0x10 (RTCWDT_RTC_RESET)`. Fix: flash the **full** set (`bootloader@chip offset + partitions@0x8000 + app@0x10000`), or `esptool merge_bin` them and flash at `0x0` ([§4.2](#)).
- **C5 specifically:** bootloader must be at `0x2000`, not `0x0/0x1000` — a C5 image with the bootloader at the wrong offset never boots.
- **Won't boot — wrong chip:** an image built for a *different* chip (e.g. S3 binary on a classic ESP32) won't run. Confirm the detected chip in the Flash Log (`[chip] using ...`) matches what your `.bin` was built for; set `chip` explicitly if auto-detect guessed wrong. Independently confirm the silicon with `esptool --port <port> chip_id`.
- **Flash-size / 16 MB-header boot-loop:** Cyber Controller passes `--flash_size` detect to avoid this, but if you built the firmware, build it for the board's actual flash size.
- **esptool errors about unknown commands/options:** your esptool is out of range — install `esptool>=4.7, <6` (v6 removed the aliases this tool uses; very old versions don't know newer chips).
- **Brick recovery (board unresponsive / boot-loops after a bad flash):** click **Erase Flash** in the Flash tab to fully erase the chip, then re-flash with a **known-good merged image at 0x0** for the correct chip. A full erase clears stale partition tables and NVS that can survive a partial flash. (`custom` has `supports_suicide: false`, so Erase Flash is a plain chip erase, not a secure-wipe bundle.)
- **Verify failed:** re-flash with verify on; the usual causes are a flaky cable, a clone flash chip, or too-high baud — lower `flash_baud` and retry.
- **Booted but the serial terminal shows garbage:** wrong terminal baud — match the firmware's monitor baud (often 115200).

9. Sources

- **esptool** (the backend Cyber Controller drives): `write_flash`, `merge_bin`, `chip_id`, flash offsets and memory layout — <https://docs.espressif.com/projects/esptool/> (verify: your installed version is `>=4.7, <6`).
- **Espressif build/flash flows for finding offsets**: ESP-IDF `idf.py flash` output and `build/flasher_args.json`; Arduino *Export Compiled Binary* + verbose upload; PlatformIO `pio run -v`; ESP Web Tools `manifest.json` `parts[].offset`.
- **Cyber Controller profile & engine**: `src/config/profiles/custom.json` (`backend: esptool`, `resolver: local`, `image_model: merged-single-bin`, `app_offset: 0x0`, `supports_suicide: false`); `flash_core.CustomLocalProfile` (`flash_local()`, `local_asset()`, `latest_release()` → `("local", [])`); `flash_engine._flash_esptool` (`chip resolve` → `local_path` custom branch); per-chip bootloader offsets in `flash_core._bootloader_offset / _BOOTLOADER_OFFSET` (C5 → `0x2000`).
- **Offsets used above** come from the profile JSON + Cyber Controller's flash core (`merged@0x0`; `bootloader 0x1000 classic/S2`, `0x0 S3+RISC-V`, `0x2000 C5`; `partitions 0x8000`; `boot_app0 0xE000`; `app 0x10000`). For a **specific** project always confirm against that project's own flash script / `flasher_args.json` — *if a value isn't in the JSON or your project's docs, verify it before flashing.*