## **Technical description of Carnivore2**

This is the detailed technical description and documentation for the multi-functional Carnivore2 cartridge that was created by RBSC.

**NOTE:** The hexadecimal numbers are shown as #90, 90h or 0x90

#### The main components and features:

- External storage: CF card (CompactFlash)
  - Nextor is used as DOS (built-in support for FAT12/16, maximum partition size: 4 GB)
  - High read and write speeds
  - Supports SD and MicroSD card adapters
  - Nextor supports floppy disk emulation with DSK files
  - Utilities compatible with MSX-DOS versions 1 and 2
  - The cartridge can be configured as a RAM extension, IDE disk, FMPAC and SCC/SCC+ sound cards, or a combination of these devices
- RAM: 2048 Kb (2 Mb)
  - o Includes:
    - 1024 Kb main RAM with mapper
    - 256 Kb for ROM shadowing
    - 720 Kb additional RAM with a mapper, similar to MegaRAM
    - 4 Kb (in the last 64 Kb-block) for the FMPAC SRAM (a backup battery is needed to save data after turning off the power)
- Flash memory (FlashROM): 8 Mb capacity, 64 Mb/s
  - The first 256 Kb are used for service information and ROM BIOSes
  - Mapper emulation:
    - Linear 64 Kb mode
    - ASCII8
    - ASCII16
    - Konami4
    - Konami5 (SCC/SCC+)
    - Custom mapper
- Sound
  - PPI and PSG emulation
  - Konami SCC and SCC+ emulation
  - OPLL emulation (YM2413, MSX Music), BIOS IU translated to English
  - Volume setting for all emulated audio devices
  - PSG and PPI can be enabled and disabled in the user interface
- Additional 128 byte configuration EEPROM (M93C46MN1), works in 8-bit mode
- User-adjustable volume for SCC and FMPAC (8 steps), saved in 93C46 EEPROM
- User-adjustable volume for PSG and Clicker (8 steps), saved in 93C46 EEPROM
- User-controlled PSG and Clicker device on/off switch
- User-adjustable VDP frequency (50/60Hz), saved in the 93C46 EEPROM

#### **On-board BIOSes and modules:**

File	Subslot	Description
BOOTCMFC.ROM	0	Boot Menu
BIDECMFC.ROM	1	IDE BIOS

File	Subslot	Description
	2	1Mb RAM
FMPCCMFC.ROM	3	FMPAC BIOS

The location of the Boot Menu, directory and BIOSes in the FlashROM chip is described below. There are logical and physical blocks and they have different numbering.

## The location of blocks in FlashROM

The FlashROM chip that is used in Carnivore2 has 8 logical blocks in the first physical 64kb block and then go the rest of 64kb physical blocks. In the logical blocks there are Boot Menu and directory. The next few blocks are allocated for the BIOSes of the embedded devices.

### 8kb blocks

The first 8 logical 8kb blocks are grouped into the first physical block that is addressed by the AddrFr register. Logical blocks 0 and 1 contain the Boot Menu code. The next 2 blocks the directory entries and auto-start info. Then go 2 blocks that contain data for the Boot Menu. The last block is currently unused.

Address range	Block number	Description	
000000h-001FFFh	0	after power on (AddrFR=#00, R1Mult=«10000101» B1AdrD = #4000) is visible in subslot 0 at address #4000-#5FFF and contains the first 8kb of boot menu (ROM «AB» header + start addresses)	
002000h-003FFFh	1	after power on is visible in subslot 0 at addresses #6000-#7FFF (bits 2-0 of R1Mult = «101» are the size of the shown block (16kb)) and contain the second 8kb of boot menu	
004000h-005FFFh	2	directory entries	
006000h-007FFFh	3	directory entries	
008000h-009FFFh	4	this block holds the auto-start table; the auto-start variable is stored at different addresses — it is «floating» within this block	
00A000h-00BFFFh	5	used for the data of the Boot Menu	
00C000h-00DFFFh	6	used for the data of the Boot Menu	
00E000h-00FFFFh	7	not used	

### 64kb blocks

After the first 8 logical 8kb blocks that form the first physical block, there go the physical 64kb blocks of the FlashROM.

Address range	Physical block number	Logical block number	Description
010000h-01FFFFh	8	1, AddrFR=#01	contain the IDE BIOS
020000h-02FFFh	9	2, AddrFR=#02	contain the IDE BIOS

Address range	Physical block number	Logical block number	Description
030000h-03FFFFh	10	3, AddrFR=#03	contains FMPAC BIOS
040000h-04FFFh	11	4, AddrFR=#03	
050000h-05FFFFh	12	5, AddrFR=#03	Data blocks — these blocks are used
			for saving the ROM images (games,
			etc.)
7F0000h-7FFFFh	134	127, AddrFR=#7F	

# FlashROM chip

Model: Numonix M29W640GB TSOP48

Datasheet

### Block layout:

#00000	8K
#02000	8K
#04000	8K
#06000	8K
#08000	8K
#0A000	8K
#0C000	8K
#0E000	8K
#10000	64K x 127

Command addresses: #4555 and #5AAA

### Commands:

AUTOSELECT	#90
WRITE	#A0
CHIP_ERASE	#10
BLOCK_ERASE	#30
RESET	#F0

FlashROM ID: #7E

- Block 0 is reserved for the directory and the boot menu: B00TCMFC.R0M
- Blocks 1-2 are reserved for the IDE BIOS: BIDECMFC.ROM
- Block 3 is reserved for the FMPAC BIOS: FMPCCMFC.ROM

# **OPLL** emulation (FMPAC)

The OPLL emulation (FMPAC) that is supported by the cartridge is mapped to ports #7C-7D.

The FMPAC SRAM is emulated by using the 8kb of the upper area of the 1st megabyte of RAM (shadow RAM) that is not shared with the memory mapper. The physical address of the 8kb area for SRAM in the shadow RAM is 0FE000h-0FFFFFh.

NOTE: The settings of SRAM will be lost after powering down unless the cartridge has the backup battery installed.

FMPAC's own control registers:

- 7FF4h: write YM-2413 register port (write only)
- 7FF5h: write YM-2413 data port (write only)
- 7FF6h: activate OPLL I/O ports (read/write)
- 7FF7h: ROM page (read/write)

To enable 8kb of SRAM at address 4000h-5FFFh, set 4Dh to 5FFEh and 69h to 5FFFh.

# Additional configuration EEPROM

Model: M93C46MN1 (128 bytes/1 kbit)

**Datasheet** 

IMPORTANT! The chip is operated only in 8-bit mode!

This EEPROM is used to store additional configuration settings. Using the EEPROM prevents the important configuration settings from being lost after power goes down. The location of the settings in the EEPROM and their description can be found i the table blow.

Address	Description		
01	FMPAC and SCC volume, 3 bits per value, max volume is 8, first 2 bits are used as flags		
02	50 or 60 Hz VDP frequency flag, bit 1 from this byte is used — if this bit is zero then 60 Hz is used		
03	PSG and clicker enable/disable flags and volumes, 3 bits per volume, max volume is 8, first 2 bits are used as enable/disable flags		
04	Entry sorting (0=disabled)		
05	Fade in/out effects (0=disabled)		
06	Keyboard/joystick speed (this is an increment for default value)		
07	Many faut valatta		
08	Menu font palette		
09	Menu background palette		
0A			
0B	Help font palette		
0C			
0D	Holp hackground palette		
0E	Help background palette		
0F	Volume font polette		
10	Volume font palette		

Address	Description	
11	Volume background palette	
12	volume background palette	
13	DSC/DDI font polatto	
14	PSG/PPI font palette	
15	PSG/PPI background palette	
16		
17	Custom settings in use flag (must be #42)	
18	Double reset on «cold boot» (1=enabled)	
19	MPAC mono (1=enabled)	

Writing to EEPROM is done via the configuration register CardMDR+#23. The commands for EEPROM are saved into this register in a sequence that is described in the chip's datasheet. Only write-enable, read and write commands are used.

# **Configuration registers**

The configuration registers are located at addresses #0F80 or #4F80 or #8F80 or #CF80h. Their visibility and location is controlled by the main control register's first byte — at address #4F80. The main control register is called CardMDR. After power on, the registers are located at address #4F80. All registers are write-only except the pseudo-register for sending/receiving the data when accessing the FlashROM and the register for the configuration EEPROM.

Below you can find the description of configuration registers.

Register number, name	Bit number	Value	Description
00 CardMDR	main cartridge's configuration register		

Register number, name	Bit number	Value	Description
	7	1	don't show registers
	7	0	show registers
	6 5	0/1/2/3	registers are located at addresses 0F80h/4F80h/8F80h/CF80h
	4	1	SCC enabled
	4	0	SCC disabled
		1	delayed configuration
	3	0	configuration is changed immediately after updating the registers
		0	delayed configuration is enabled after CPU executes at address 0000h
	2	1	configuration is enabled after reading from address 4000h The delayed configuration works only for AddrFR and bank control registers
		source for BIOS o	f embedded devices
		0	BIOS data (boot menu, IDE controller, FMPAC) is read from FlashROM chip
	1	1	BIOS data (boot menu, IDE controller, FMPAC) is read from RAM Warning! The data must be copied into DAM before setting this bit!
		configuration reg	isters visibility control
	0	0	all configuration registers are visible at addresses 0F80h/4F80h/8F80h/CF80h depending on the values of bits 5 and 6
		1	configuration registers are not visible, 1 byte of data from the corresponding block in the FlashROM is available at those addresses
01 AddrM0	lower address re	egister (bits 7-0) f	or accessing the FlashROM
02 AddrM1	middle address	register (bits 15-8	3) for accessing the FlashROM
03 AddrM2	higher address	register (bits 22-1	.6) for accessing the FlashROM
04 DatM0	pseudo-register	for sending/recei	ving data from/to FlashROM
05 AddrFR	register controlling the number of FlashROM's 64kb block for ROM emulation The default value of this register is 00h		
First bank conf			
06 R1Mask	bitmask for bank's register address This value is normally mirrored into several addresses, for example for Konami 5 cartridges those addresses for the first bank are 5000h-57FFh. Here we use only the high byte's address — F8h (11111000b) The default value of this register is F8h		
07 R1Addr	high byte of the bank's address register (example: 50h for address 5000h) The default value of this register is 50h		
08 R1Reg	initial value for bank's number (usually 00h) The default value of this register is 00h		
09 R1Mult	bank's mode and size register		

Register number, name	Bit number	Value	Description	
	7	1	bank's register is enabled	
	7	0	bank's control is disabled	
		1	mirroring is disabled	
	6	0	mirroring is enabled	
		media type selection		
	5	0	FlashROM	
		1	RAM	
	4	1	writing to bank is enabled	
	4	0	writing to bank is disabled	
	3	0	bank is enabled	
	3	1	bank is disabled	
	2, 1, 0	bank's size 111b = 64 kb, 110b = 32 kb, 101b = 16 kb, 100b = 8 kb, 011b = 4 kb other value — ba The default value	ink is disabled e of this register is 85h	
0A B1MaskR	bitmask for bank's addressing mode into the FlashROM This is the ROM's emulated size and the number of pages. For example for a 128kb ROM we will need 16 pages of 8kb, so we set the 0Fh (00001111b) mask. The default value of this register is 03h			
	high byte of the bank's address (example: 40h for address 4000h) The default value of this register is 40h			
Second bank co	onfiguration re	gisters		
0C R2Mask	similar to R1Mask			
0D R2Addr	similar to R1Addr			
0E R2Reg	similar to R1Reg			
0F R2Mult	similar to R1Mult, the default value is 00h (bank is disabled)			
10 B2MaskR	similar to B1MaskR			
11 B2AdrD	similar to B1AdrD			
Third bank con	figuration regi	sters		
12 R3Mask	similar to R1Ma	sk		
13 R3Addr	similar to R1Ado	dr		
14 R3Reg	similar to R1Reg	9		
15 R3Mult	similar to R1Mu	lt, the default valu	ue is 00h (bank is disabled)	
16 B3MaskR	similar to B1MaskR			
17 B3AdrD	similar to B1AdrD			
Fourth bank co	nfiguration re	gisters		
	similar to R1Mask			
19 R4Addr	similar to R1Addr			
	similar to R1Reg			
	similar to R1Mult, the default value is 00h (bank is disabled)			
	similar to B1MaskR			
	similar to B1AdrD			

Register number, name	Bit number	Value	Description				
1E Mconf	expanded slot c	onfiguration regis	ter				
	7	1	slot is expanded				
	7	0	slot is not expanded				
	6	1	MMM mapper ports FC,FD,FE,FF reading is enabled				
	5	1	control YM2413 (FM Pack Synt. 7Ch,7Dh)				
	4	1	control 3C порта (МММ mapper)				
	3	1	control -3 Subslot FM Pack bios ROM				
	2	1	control -2 Subslot MMM mapper with 1mb of RAM is enabled				
	1	1	control -1 Subslot CF card interface				
	0	1	control -0 Subslot MSCC (and this register)				
1F CMDRCpy	copy of the Card	dMDR+#00 regist	er (to be used with LDIR command)				
20 ConfFl FlashROM chip's configuration The default value of this register is — 010b							
	2	0	8 bit bus				
		1	16 bit bus				
	1	Reset/protect flag					
	0	1	enable 12V for boosted writing into FlashROM				
	0	0	зdisable 12V for boosted writing into FlashROМ				
21 NSReg	Non standart Re The default valu	•	is #00, please don't change it!				
22 SndLVL	volume level re The default valu	-	is 1Bh (00011011b)				
	7, 10 = FMPAC mono, 6 00 = FMPAC stereo						
	5, 4, 3	FMPAC audio level (0-7)					
	2, 1, 0	SCC/SCC+ audio level (0-7)					
23 CfgEEPR	register for cont	rolling additional	configuration EEPROM (93C46)				
	7, 6, 5, 4	not used					
	3	EECS signal Chip	Select EEPROM				
	2	EECK signal CLK					
	1		Input (data sent to EEPROM)				
	0		a Output (data received from EEPROM); read-only				
24 PSGCtrl	PSG control reg The default valu	·					

Register number, name	Bit number	Value	Description					
	7	enable/disable PS	G					
	6	enable/disable PPI Clicker						
	5,							
	4,	PSG audio level (	0–7)					
	3							
	2,	DDI Clialcan accdia	lovel (0, 7)					
	1, 0	PPI Clicker audio level (0-7)						
25 V_AR_L	lower 8 bits of t	he interceptor cod	le					
26 V_AR_H	chigher 8 bits of	f the interceptor c	ode					
27 aV_hunt	interceptor's fla	g for delayed conf	iguration					
	0	activation flag for interceptor code on system restart or read fro #4000						
		1	enabled					
		interceptor code's	s location					
	1	0	boot menu in FlashROM					
		1	first shadow RAM block					
28 SLM_cfg	per-device subs	bslot assignment (master slot)						
	7 FMDAC subslet number							
	6	FMPAC subslot number						
	5	DAM (Manager MMM) and alab manager						
	4	RAM (Mapper MMM) subslot number						
	3	IDE (CE) and alat of						
	2	IDE (CF) subslot number						
	1							
	0	FlashROM/SCC su	ibsiot number					
29 SCART_cfg	slave slot contro	ol register						
		1	slave slot enabled					
	7	0	slave slot disabled					
	_	1	slave slot's location assigned by user					
	6	0	slave slot assigned as subslot of master slot					
	F	1	slave slot expanded (if not used as a subslot of master slot)					
	5	0	slave slot non-expanded (if not used as a subslot of master slot)					
	4	1	master slot's location is assigned by user					
	4	0	master slot located at the physical slot					
	_	1						
	3	0	not used					
2A SCART_SLT	slot/subslot con	figuration on powe	er-on					

Register number, name	Bit number	Value	Description				
	7, 6	00 = mini ROM up to 32kb without mapper, 01 = K4 mapper, 10 = K5+SCC mapper, 11 = K5 mapper without SCC					
	5, 4	master slot number					
	3, 2	expanded slave slot number					
	1, 0	slave slot number					
2B SCART_StBI	slave slot's 64kl	kb block assignment in FlashROM					
2C, 2D, 2E FPGA_ver	FPGA firmware	re version (3 ASCII bytes)					
2F	$MROM_offs = m$	ini ROM offset in 6	4kb block (in 8kb steps)				

# **Directory entry format**

There are 253 user-controlled directory entries available in the cartridge. The first directory entry can't be edited or deleted because it sets the default cartridge's configuration — all enabled. The directory is 8kb in size and is located in the 2 and 3 logical blocks of the FlashROM chip at addresses 004000h-005FFFh (block 2) and 006000h-007FFFh (block 3). The physical block number (controlled by the AddrFr register) is zero.

Each directory entry occupies 40h (64 bytes) and has the following format:

Register number	Name	Bit number	Value/description						
#00	NUM	Record number (last one — #FF is ignored)							
#01	ACT	Active/empty record's flag (#FF — active record)							
#02	STB	Starting 64kb block for data							
#03	LNB	Data size in 6	54kb blocks						
#04	MAP	Mapper type	symbol						
#05	NAM	Name of the	record starts (30 bytes)						
#22	NAM	Name of the	Name of the record ends						
#23	R1Mask								
#24	R1Addr	6 bytes of first bank's configuration							
#25	R1Reg								
#26	R1Mult								
#27	B1MaskR								
#28	B1AdrD								
#29	R2Mask								
#2A	R2Addr								
#2B	R2Reg	Chalan Canadhadha alla an Canadha							
#2C	R2Mult	bytes of second bank's configuration							
#2D	B2MaskR								
#2E	B2AdrD								

Name	Bit number	Value/description							
R3Mask									
R3Addr									
R3Reg	6 bytes of third bank's configuration								
R3Mult									
B3MaskR									
B3AdrD									
R4Mask									
R4Addr									
R4Reg	6 hytes of forth bank's configuration								
R4Mult	6 bytes of forth bank's configuration								
B4MaskR									
B4AdrD									
Mconf	expanded slo	t configuration register							
CardMDR	main configu	ration register							
PosSiz	size and posi	tion in 64kb block for mini ROMs							
	7	reserved							
		offset of mini ROM in 64kb block based							
		on ROM's size:							
		8 kb 16 kb 32 kb							
	6,	000b 0 kb 0 kb 0 kb							
		001b 8 kb 16 kb 32 kb							
		010b 16 kb 32 kb							
	4	011b 24 kb 48 kb							
		100b 32 kb 101b 40 kb							
		110b 48 kb							
		111b 56 kb							
	3	non-standard ROM size: 1 — 49 kb							
	J	0 — standard ROM size							
		mini ROM's size:							
	) ,	110b = 32 kb							
		101b = 16 kb							
	o o	100b = 8 kb 011b = 4 kb							
		000b = not mini ROM							
RstRun	reset and sta								
		ROM's start address:							
	3	0 — use bit 2 from this register							
		1 — use start address at 0002h							
		ROM's start address:							
	2	0 — use start address at 4002h 1 — use start address at 8002h							
		execution control:							
	1	0 — don't start ROM							
	_	1 — start using ROMini address (bits 3,2)							
	R3Mask R3Addr R3Reg R3Mult B3MaskR B3AdrD R4Mask R4Addr B4MaskR B4AdrD Mconf CardMDR PosSiz	R3Mask R3Addr R3Reg R3Mult B3MaskR B3AdrD R4Mask R4Addr R4Reg R4Mult B4MaskR B4AdrD Mconf expanded slo CardMDR main configu PosSiz for							

Register number	Name	Bit number	Value/description
		0	reset flag: 0 — do not reset MSX 1 — reset MSX
#3F	Resrv	Reserved	

# **Mappers**

The cartridge supports a few common mappers and the linear mode that allows first 64kb of the MiniROM to be visible in the address space. The physical addresses allocated for the mappers' operation lie in the range of 100000h–1FFFFFh. This means that only the second megabyte of RAM is used.

### **ASCII8**

The cartridge supports the ASCII8 mapper.

Default configuration values:

#F8	#60	#00	#84	#FF	#40	bank 0
#F8	#68	#01	#84	#FF	#60	bank 1
#F8	#70	#02	#84	#FF	#80	bank 2
#F8	#78	#03	#84	#FF	#A0	bank 3
#FF	#AC	#00	#02	#FF		configuration registers

## **ASCII16**

The cartridge supports the ASCII16 mapper.

Default configuration values:

#F8	#60	#00	#85	#FF	#40	bank 0
#F8	#70	#01	#85	#FF	#80	bank 1
#F8	#70	#02	#08	#3F	#80	bank 2
#F8	#78	#03	#08	#3F	#A0	bank 3
#FF	#8C	#00	#01	#FF		configuration registers

## Konami4

The cartridge supports the Konami4 mapper.

Default configuration values:

#E8 #50 #00 #04 #FF	#40 <b>bank 0</b>
---------------------	-------------------

#E8	#60	#01	#84	#FF	#60	bank 1
#E8	#80	#02	#84	#FF	#80	bank 2
#E8	#A0	#03	#84	#FF	#A0	bank 3
#FF	#AC	#00	#02	#FF		configuration registers

## Konami5

The cartridge supports the Konami5 (SCC) mapper.

Default configuration values:

#F8	#50	#00	#84	#FF	#40	bank 0
#F8	#70	#01	#84	#FF	#60	bank 1
#F8	#90	#02	#84	#FF	#80	bank 2
#F8	#B0	#03	#84	#FF	#A0	bank 3
#FF	#BC	#00	#02	#FF		configuration registers

## **MiniROM**

The cartridge supports MiniROM (ROM images up to 49kb) without mapper.

Default configuration values:

#F8	#60	#00	#06	#7F	#40	bank 0
#F8	#70	#01	#08	#7F	#80	bank 1
#F8	#70	#02	#08	#3F	#C0	bank 2
#F8	#78	#03	#08	#3F	#A0	bank 3
#FF	#8C	#07	#01	#FF		configuration registers

## Linear 64kb mode

The cartridge supports the linear 64kb mode, when the first 64kb of the ROM are visible in the address space.

The default configuration values for MiniROMs are:

5 #7F #40 <b>bank 0</b>	bank	#40	#7F	#06	#00	#60	#F8
8 #7F #80 <b>bank 1</b>	bank	#80	#7F	#08	#01	#70	#F8
3 #3F #C0 <b>bank 2</b>	bank	#C0	#3F	#08	#02	#70	#F8
8 #3F #A0 <b>bank 3</b>	bank	#A0	#3F	#08	#03	#78	#F8
#FF configuration registers	confi		#FF	#01	#07	#8C	#FF

Bank addresses in linear mode:

#0000-#3FFF	bank	0
#4000-#7FFF	bank	1

#8000-#BFFF	bank	2
#C000-#FFFF	bank	3

# **Default register values**

Below you can find the default values for several configuration registers.

CardMDR	CardMDR+#00	20h (but may vary because of 2 last bits)
AddrFR	CardMDR+#05	00h
R1Mult	CardMDR+#09	85h
R2Mult	CardMDR+#0F	00h
R3Mult	CardMDR+#15	00h
R4Mult	CardMDR+#1B	00h
CMDRCpy	CardMDR+#1F	20h
ConfFl	CardMDR+#20	02h

## Links

Carnivore2 User Guide

From:

https://sysadminmosaic.ru/ - Мозаика системного администрирования

Permanent link:

https://sysadminmosaic.ru/msx/carnivore2/specification-en

Last update: **2020-03-21 21:52** 

