

THICKNESS/SEAL CHECKER TSC-RS SERIES OPERATION MANUAL



WARNING

- Do not carry out installation, operation, service, or maintenance until thoroughly understanding the contents of this manual.
- Keep this manual available at all times for installation, operation, service, and maintenance.

ISHIDA CO.,LTD.

You can help improve this manual by calling attention to errors and by recommending improvements.
Please convey your comments to the nearest Ishida Company regional representative.

Thank you!

Copyright (c) 2009 by Ishida Co.,Ltd. All Rights Reserved.

No part of this manual may be reproduced in any form, by photocopy or any other means,
without permission in writing from the publisher.

IMPORTANT CONSIDERATIONS



It is imperative to read and understand the contents of this manual thoroughly when operating the machine or performing any service, maintenance, or inspection procedures. Please be aware of the hazards involved which may not be obvious, and follow the instructions detailed in this manual.

1. It is impossible to enumerate or predict all of the possible dangers of using this equipment and fully list all of them in an instruction manual. When operating the equipment or performing production in any way not specifically described in this manual, please contact your local Ishida Service representative before proceeding.
Safety countermeasures not specifically described in this manual or indicated on the machine itself should be carefully considered and implemented before performing any operation, service, or maintenance procedures.
2. The copyright for the material in this document is held by Ishida Co., Ltd., and all information contained herein is protected by the Copyright Law. Any disclosure to third parties or unauthorized copying of the information contained herein is not permitted without prior written approval from Ishida Co., Ltd.
3. Although this manual has been carefully edited, if there are any mistakes, or if you have any questions, please contact your local Ishida Service representative or its local distributor/representative.
The model number and machine number are printed on the equipment plate attached to the equipment.
4. The information contained herein may be changed without prior notice.

 ISHIDA			
MODEL _____			
PRODUCT _____			
WEIGHING RANGE		g~	g
JOB NUMBER _____			
NUMBER _____			
MFG DATE _____			
POWER SINGLE	AC	V	A
3-PHASE	AC	V	A
FREQUENCY		Hz	
ISHIDA CO.,LTD. MADE IN JAPAN			

Equipment Plate

WARRANTY CONDITIONS

1. Ishida Co., Ltd. only assumes responsibility for repairing or replacing components which are deemed to be defective due to improper design or manufacturing.
The measures to be taken for defects whose origin is unclear shall be decided by mutual consultation between both parties.
2. Ishida assumes no responsibility for loss, injury or damage which are the result of unauthorized or unforeseen operational procedures.
3. The warranty period is stated in the Certificate.

The definition for each intended reader described in the table below

- | | |
|-----------------------------------|--|
| 1. Operator: | Personnel who perform basic operations during daily production with the production line (i.e. Operator Level). |
| 2. System manager: | Personnel who set weighing parameters or tune the equipment (i.e. Site Engineer Level). |
| 3. Maintenance personnel: | Personnel who have specialized knowledge about the equipment and perform maintenance or inspection of the equipment (i.e. Installation Engineer Level) of the equipment. |
| 4. Ishida Service representative: | Personnel who perform tuning when installing the equipment. |

MANUAL OBJECTIVES AND STRUCTURE

This manual is designed to provide users with information on operation, maintenance and inspection procedures of the Ishida seal tester.

The following information is contained in this manual.

1 Safety Considerations

Be sure to read and understand all information related to safety contained in this manual before attempting to operate, inspect or service this equipment.

This information is included to instruct persons who own, install, operate, service or inspect this equipment on the warning symbols, precautions which must be observed, and the meanings of warning etc. labels attached to the machine.

2 Introduction

This chapter describes special terminology used in this manual, main components, and operation outlines.

3 Installation

This chapter describes the correct methods of installing the seal tester.

4 Names and Functions of the Remote Control Unit

This chapter describes the names and functions of the components of the remote control unit.

5 Functions and Operations of the Remote Control Unit

This chapter describes the procedures for entering machine settings and operating the unit.

6 Production

This chapter describes emergency stop procedures, an outline of operations, pre-operation preparation, production procedures, and the end production procedures.

7 Cleanup Procedures

This chapter describes procedures for cleaning the seal tester components.

8 Periodic Maintenance

This chapter describes the maintenance and inspection procedures required to maintain the seal tester in optimum operation condition.

9 Troubleshooting

This chapter describes how to determine the causes of seal tester malfunction and to restore proper function.

Index

GENERAL TABLE OF CONTENTS

1 SAFETY CONSIDERATION AND SANITARY

1.1	Summary.....	1-1
1.2	Warning Indications: Types and Definitions	1-2
1.3	General Precautions to be Observed	1-3
1.4	Special Safety Precautions	1-5
1.5	Warning Labels	1-6
1.5.1	Warning Label Handling.....	1-6
1.5.2	Warning Label Location.....	1-6
1.6	Electrical Power Shutdown and Indication	1-7

2 INTRODUCTION

2.1	Summary.....	2-1
2.2	Terminology.....	2-2
2.3	Specifications	2-3
2.4	Configuration of the System	2-5
2.5	Operation Outline	2-7

3 INSTALLATION

3.1	Summary.....	3-1
3.2	Installation Location & Power Source Connection	3-2
3.2.1	Installation Location & Environment.....	3-2
3.2.2	Power Source Connection	3-2
3.3	Adjustment of Jack Bolt.....	3-3
3.4	Slant Adjustment of Infeed Conveyor Belt.....	3-3
3.4.1	Height Adjustment of Brush Conditioner	3-5
3.4.2	Nozzle Adjustment of Pre-rejecter	3-6

4 NAMES AND FUNCTIONS OF RCU

4.1	Summary.	4-1
4.2	Components and Functions of the Remote Control Unit (RCU)	4-2
4.3	Operation Panel and Data Entry	4-2
4.3.1	Operation panel view	4-3
4.3.2	Data entry	4-5
4.3.2.1	Entering a numeral value	4-6
4.3.2.2	Entering an alphabet, number, or symbol.	4-7
4.3.3	Correction after Data Entry and Setting.	4-8

5 FUNCTIONS AND OPERATIONS OF RCU

5.1	Summary.	5-1
5.2	Screen Configuration Chart	5-1
5.3	Upper Setting Bar	5-4
5.3.1	Message Board Screen	5-5
5.3.2	Selecting a Language	5-9
5.3.3	Selecting an Operation Level.	5-10
5.3.3.1	Switching to the Operator Level	5-11
5.3.3.2	Switching to the Site Engineer Level	5-11
5.3.3.3	Switching to the Installation Level	5-12
5.3.4	Control Panel.	5-14
5.3.4.1	Screen Control	5-15
5.3.4.2	Password Set	5-16
5.3.4.3	Destination ID.	5-17
5.3.5	Setting the Date & Time.	5-20
5.3.6	Help function	5-22
5.4	MAIN MENU Screen.	5-23
5.4.1	ZOOM CHANGEOVER	5-25
5.4.2	Left Tab	5-26
5.4.2.1	Result	5-26
5.4.2.2	Tune1	5-27
5.4.2.3	Tune2	5-27
5.4.3	H COMPE.	5-28
5.5	PRESET LIST Screen.	5-29
5.5.1	Photo Display.	5-29
5.5.2	List Display	5-30
5.6	PRESET Copy	5-31
5.6.1	Copying selected preset	5-32

5.6.2	Copy all	5-34
5.6.3	Selection and Initialization of Preset	5-36
5.6.4	Initialization of all	5-37
5.7	Output Selection	5-39
5.8	Preset Parameter	5-41
5.8.1	Preset Parameter Screen	5-42
5.8.1.1	Taking photos of product	5-43
5.8.2	Basic Setting Screen	5-45
5.8.2.1	CRITERIA.	5-46
5.8.2.2	MODE/SPEED SETTING.	5-47
5.8.2.3	GENERAL SETTING	5-48
5.8.2.4	Timing Auto Calculation	5-50
5.8.3	Advanced Setting.	5-51
5.9	MACHINE PARAMETER	5-52
5.9.1	Reject Setting.	5-54
5.9.2	Output Signal Setting.	5-54
5.9.3	System Config.. . . .	5-56
5.9.4	Program Number	5-57
5.10	Information Screen	5-58
5.10.1	STATISTICS Screen	5-59
5.10.2	ERROR LOG Screen.	5-61
5.10.3	WORST ERROR 10 Screen	5-62
5.10.4	Measurement Result Log Screen	5-63
5.10.5	Measurement Result Graph Screen	5-64
5.11	Production Screen.	5-66
5.12	Automated Adjustment Unit.	5-68
5.12.1	Normal Operation.	5-68
5.13	ATA Sampling (Optional)	5-69
5.13.1	ATA Procedure	5-69
5.13.2	Attention.	5-70

6 PRODUCTION

6.1	Summany	6-1
6.2	Emergency Stop and Restart	6-2
6.2.1	Emergency stop method by power switch	6-2
6.2.2	Emergency stop method by EMERGENCY STOP button	6-3
6.3	Outline of Production Sequence	6-4

6.4	Pre-Production Procedure	6-5
6.4.1	Production Procedure	6-5
6.5	End Production	6-8

7 CLEANUP PROCEDURES

7.1	CLEANUP PROCEDURES	7-1
7.2	Cleaning and Sterilization	7-2
7.3	Cleaning and Sterilization Methods	7-3
7.4	Cleaning and Sterilization of Each Part	7-4
7.4.1	RCU Cleaning	7-4
7.4.2	Cleaning of Conveyor Belt	7-5
7.4.3	Photo Sensor	7-7
7.4.4	Cleaning of Cleaning Brush	7-7
7.4.4.1	Infeed Conveyor (For the specification of all-in-one height-adjustable conveyor)	7-7
7.4.4.2	Seal Check Conveyor	7-8
7.4.5	Cleaning of Conditioning Brush	7-9
7.4.6	Stabilizer Unit (option)	7-9

8 PERIODIC MAINTENANCE

8.1	Overview	8-1
8.2	Daily Inspection	8-2
8.2.1	Pre-Startup Inspection	8-2
8.2.2	Inspection during Production	8-2
8.3	Maintenance and Inspection Procedures	8-3
8.3.1	Printer Paper Replacement	8-3
8.3.2	Operation check of photoelectric sensor	8-5
8.3.3	Timing belt tension adjustment and visual check for scratch	8-5
8.3.4	Height Compensation of Seal Check Conveyor	8-7
8.3.5	Timing belt tension adjustment	8-9
8.3.6	Inspection / adjustment of conveyor belt	8-11

9 TROUBLESHOOTING

9.1	Summany	9-1
9.2	Error Message Handling	9-2
9.3	System Error / Failure	9-5

9.4 Warning Messages 9-6

