HeliOS

0.3.5

Generated by Doxygen 1.9.1

1 Data Structure Index 1

1 Data Structure Index	1
1.1 Data Structures	1
2 File Index	2
2.1 File List	2
3 Data Structure Documentation	2
3.1 MemoryRegionStats_s Struct Reference	2
3.1.1 Detailed Description	3
3.2 QueueMessage_s Struct Reference	3
3.2.1 Detailed Description	3
3.2.2 Field Documentation	3
3.3 SystemInfo_s Struct Reference	4
3.3.1 Detailed Description	4
3.3.2 Field Documentation	4
3.4 TaskInfo_s Struct Reference	5
3.4.1 Detailed Description	6
3.4.2 Field Documentation	6
3.5 TaskNotification_s Struct Reference	7
3.5.1 Detailed Description	7
3.5.2 Field Documentation	7
3.6 TaskRunTimeStats_s Struct Reference	8
3.6.1 Detailed Description	8
3.6.2 Field Documentation	8
4 File Documentation	9
4.1 config.h File Reference	9
4.1.1 Detailed Description	9
4.1.2 Macro Definition Documentation	10
	12
	17
	17
	18
**	
200 - 100	27
4.2.5 Function Documentation	28
Index	53

1 Data Structure Index

1.1 Data Structures

Here are the data structures with brief descriptions:

	MemoryRegionStats_s Data structure for statistics on a memory region	2
	QueueMessage_s Data structure for a message queue message	3
	SystemInfo_s	
	Data structure for system information	4
	TaskInfo_s	
	Data structure for information about a task	5
	TaskNotification_s	
	Data structure for direct to task notifications	7
	TaskRunTimeStats_s	
	Data structure for task runtime statistics	8
2	File Index	
~	I IIG IIIGGA	

2.1 File List

Here is a list of all documented files with brief descriptions:

```
config.h
Kernel header file for user definable settings

9
HeliOS.h
Header file for end-user application code

12
```

3 Data Structure Documentation

3.1 MemoryRegionStats_s Struct Reference

Data structure for statistics on a memory region.

```
#include <HeliOS.h>
```

Data Fields

- Word_t largestFreeEntryInBytes
- Word_t smallestFreeEntryInBytes
- Word t numberOfFreeBlocks
- Word_t availableSpaceInBytes
- Word_t successful Allocations
- Word_t successfulFrees
- Word_t minimumEverFreeBytesRemaining

3.1.1 Detailed Description

The MemoryRegionStats_t data structure is used to store statistics about a HeliOS memory region. Statistics can be obtained for the heap and kernel memory regions.

See also

```
xMemGetHeapStats()
xMemGetKernelStats()
xMemoryRegionStats
```

The documentation for this struct was generated from the following file:

· HeliOS.h

3.2 QueueMessage_s Struct Reference

Data structure for a message queue message.

```
#include <HeliOS.h>
```

Data Fields

- · Base_t messageBytes
- char messageValue [CONFIG_MESSAGE_VALUE_BYTES]

3.2.1 Detailed Description

The QueueMessage_t data structure contains the message queue message returned by xQueuePeek() and xQueueReceive(). The QueueMessage_t type should be declared as xQueueMessage.

See also

```
xQueueMessage
xQueuePeek()
xQueueReceive()
xMemFree()
CONFIG_MESSAGE_VALUE_BYTES
```

Warning

The memory allocated for an instance of xQueueMessage must be freed using xMemFree().

3.2.2 Field Documentation

3.2.2.1 messageBytes Base_t QueueMessage_s::messageBytes

The number of bytes in the message Value member that makes up the message value. This cannot exceed CONFIG_MESSAGE_VALUE_BYTES.

```
3.2.2.2 messageValue char QueueMessage_s::messageValue[CONFIG_MESSAGE_VALUE_BYTES]
```

the char array that contains the actual message value. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

· HeliOS.h

3.3 SystemInfo_s Struct Reference

Data structure for system information.

```
#include <HeliOS.h>
```

Data Fields

- char productName [OS PRODUCT NAME SIZE]
- · Base_t majorVersion
- · Base_t minorVersion
- · Base_t patchVersion
- Base_t numberOfTasks

3.3.1 Detailed Description

The SystemInfo_t data structure contains information about the HeliOS system and is returned by xSystemGetSystemInfo(). The SystemInfo_t type should be declared as xSystemInfo.

See also

```
xSystemInfo
xSystemGetSystemInfo()
xMemFree()
```

Warning

The memory allocated for an instance of xSystemInfo must be freed using xMemFree().

3.3.2 Field Documentation

3.3.2.1 majorVersion Base_t SystemInfo_s::majorVersion

The major version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

3.3.2.2 minorVersion Base_t SystemInfo_s::minorVersion

The minor version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

3.3.2.3 numberOfTasks Base_t SystemInfo_s::numberOfTasks

The number of tasks presently in a suspended, running or waiting state.

```
3.3.2.4 patchVersion Base_t SystemInfo_s::patchVersion
```

The patch version number of HeliOS and is Symantec Versioning Specification (SemVer) compliant.

```
3.3.2.5 productName char SystemInfo_s::productName[OS_PRODUCT_NAME_SIZE]
```

The name of the operating system or product. Its length is defined by OS_PRODUCT_NAME_SIZE. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

· HeliOS.h

3.4 TaskInfo_s Struct Reference

Data structure for information about a task.

```
#include <HeliOS.h>
```

Data Fields

- Base_t id
- char name [CONFIG_TASK_NAME_BYTES]
- TaskState_t state
- Ticks_t lastRunTime
- Ticks_t totalRunTime

3.4.1 Detailed Description

The TaskInfo_t structure is similar to xTaskRuntimeStats_t in that it contains runtime statistics for a task. However, TaskInfo_t also contains additional details about a task such as its identifier, ASCII name and state. The TaskInfo_t structure is returned by xTaskGetTaskInfo(). If only runtime statistics are needed, TaskRunTimeStats_t should be used because of its lower memory footprint. The TaskInfo_t type should be declared as xTaskInfo.

See also

```
xTaskInfo
xTaskGetTaskInfo()
xMemFree()
CONFIG_TASK_NAME_BYTES
```

Warning

The memory allocated for an instance of xTaskInfo must be freed using xMemFree().

3.4.2 Field Documentation

```
3.4.2.1 id Base_t TaskInfo_s::id
```

The task identifier which is used by xTaskGetHandleByld() to return the task handle.

```
\textbf{3.4.2.2} \quad \textbf{lastRunTime} \quad \texttt{Ticks\_t} \quad \texttt{TaskInfo\_s::} \\ \texttt{lastRunTime}
```

The runtime duration in ticks the last time the task was executed by the scheduler.

```
3.4.2.3 name char TaskInfo_s::name[CONFIG_TASK_NAME_BYTES]
```

The name of the task which is used by xTaskGetHandleByName() to return the task handle. This is NOT a null terminated string.

```
3.4.2.4 state TaskState_t TaskInfo_s::state
```

The state the task is in which is one of four states specified in the TaskState_t enumerated data type.

```
3.4.2.5 totalRunTime Ticks_t TaskInfo_s::totalRunTime
```

The total runtime duration in ticks the task has been executed by the scheduler.

The documentation for this struct was generated from the following file:

· HeliOS.h

3.5 TaskNotification_s Struct Reference

Data structure for direct to task notifications.

```
#include <HeliOS.h>
```

Data Fields

- Base t notificationBytes
- char notificationValue [CONFIG_NOTIFICATION_VALUE_BYTES]

3.5.1 Detailed Description

The TaskNotification_t data structure contains the direct to task notification returned by xTaskNotifyTake(). The TaskNotification_t type should be declared as xTaskNotification.

See also

```
xTaskNotification
xTaskNotifyTake()
xMemFree()
CONFIG_NOTIFICATION_VALUE_BYTES
```

Warning

The memory allocated for an instance of xTaskNotification must be freed using xMemFree().

3.5.2 Field Documentation

3.5.2.1 notificationBytes Base_t TaskNotification_s::notificationBytes

The number of bytes in the notification value member that makes up the notification value. This cannot exceed CONFIG_NOTIFICATION_VALUE_BYTES.

3.5.2.2 notificationValue char TaskNotification_s::notificationValue[CONFIG_NOTIFICATION_VALUE_BYTES]

The char array that contains the actual notification value. This is NOT a null terminated string.

The documentation for this struct was generated from the following file:

• HeliOS.h

3.6 TaskRunTimeStats_s Struct Reference

Data structure for task runtime statistics.

```
#include <HeliOS.h>
```

Data Fields

- · Base tid
- · Ticks t lastRunTime
- Ticks_t totalRunTime

3.6.1 Detailed Description

The TaskRunTimeStats_t structure contains task runtime statistics and is returned by xTaskGetAllRunTimeStats() and xTaskGetTaskRunTimeStats(). The TaskRunTimeStats_t type should be declared as xTaskRunTimeStats.

See also

```
xTaskRunTimeStats
xTaskGetTaskRunTimeStats()
xTaskGetAllRunTimeStats()
xMemFree()
```

Warning

The memory allocated for an instance of xTaskRunTimeStats must be freed using xMemFree().

3.6.2 Field Documentation

```
3.6.2.1 id Base_t TaskRunTimeStats_s::id
```

The task identifier which is used by xTaskGetHandleById() to return the task handle.

```
3.6.2.2 lastRunTime Ticks_t TaskRunTimeStats_s::lastRunTime
```

The runtime duration in ticks the last time the task was executed by the scheduler.

```
3.6.2.3 totalRunTime Ticks_t TaskRunTimeStats_s::totalRunTime
```

The total runtime duration in ticks the task has been executed by the scheduler.

The documentation for this struct was generated from the following file:

· HeliOS.h

4 File Documentation 9

4 File Documentation

4.1 config.h File Reference

Kernel header file for user definable settings.

Macros

• #define CONFIG_MESSAGE_VALUE_BYTES 0x8u /* 8 */

Define to enable the Arduino API C++ interface.

• #define CONFIG NOTIFICATION VALUE BYTES 0x8u /* 8 */

Define the size in bytes of the direct to task notification value.

#define CONFIG_TASK_NAME_BYTES 0x8u /* 8 */

Define the size in bytes of the ASCII task name.

#define CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS 0x18u /* 24 */

Define the number of memory blocks available in all memory regions.

#define CONFIG_MEMORY_REGION_BLOCK_SIZE 0x20u /* 32 */

Define the memory block size in bytes for all memory regions.

#define CONFIG_QUEUE_MINIMUM_LIMIT 0x5u /* 5 */

Define the minimum value for a message queue limit.

4.1.1 Detailed Description

Author

Manny Peterson (mannymsp@gmail.com)

Version

0.3.5

Date

2022-01-31

Copyright

HeliOS Embedded Operating System Copyright (C) 2020-2022 Manny Peterson mannymsp@gmail.com

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see https://www.gnu.org/licenses/.

4.1.2 Macro Definition Documentation

4.1.2.1 CONFIG_MEMORY_REGION_BLOCK_SIZE #define CONFIG_MEMORY_REGION_BLOCK_SIZE 0x20u /* 32 */

Setting CONFIG_MEMORY_REGION_BLOCK_SIZE allows the end-user to define the size of a memory region block in bytes. The memory region block size should be set to achieve the best possible utilization of the available memory. The CONFIG_MEMORY_REGION_BLOCK_SIZE setting effects both the heap and kernel memory regions. The default value is 32 bytes. The literal must be appended with a "u" to maintain MISRA C:2012 compliance.

See also

```
xMemAlloc()
xMemFree()
CONFIG MEMORY REGION SIZE IN BLOCKS
```

4.1.2.2 CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS #define CONFIG_MEMORY_REGION_SIZE_IN_← BLOCKS 0x18u /* 24 */

The heap memory region is used by tasks. Whereas the kernel memory region is used solely by the kernel for kernel objects. The CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS setting allows the end-user to define the size, in blocks, of all memory regions thus effecting both the heap and kernel memory regions. The size of a memory block is defined by the CONFIG_MEMORY_REGION_BLOCK_SIZE setting. The size of all memory regions needs to be adjusted to fit the memory requirements of the end-user's application. By default the CONFIG_MEMORY_\top REGION_SIZE_IN_BLOCKS is defined on a per platform and/or tool-chain basis therefor it is not defined here by default. The literal must be appended with a "u" to maintain MISRA C:2012 compliance.

4.1.2.3 CONFIG_MESSAGE_VALUE_BYTES #define CONFIG_MESSAGE_VALUE_BYTES 0x8u /* 8 */

Because HeliOS kernel is written in C, the Arduino API cannot be called directly from the kernel. For example, assertions are unable to be written to the serial bus in applications using the Arduino platform/tool-chain. The CONFIG_ENABLE_ARDUINO_CPP_INTERFACE builds the included arduino.cpp file to allow the kernel to call the Arduino API through wrapper functions such as *ArduinoAssert*(). The arduino.cpp file can be found in the /extras directory. It must be copied into the /src directory to be built.

Note

On some MCU's like the 8-bit AVRs, it is necessary to undefine the DISABLE_INTERRUPTS() macro because interrupts must be enabled to write to the serial bus.

Define to enable system assertions.

The CONFIG_ENABLE_SYSTEM_ASSERT setting allows the end-user to enable system assertions in HeliOS. Once enabled, the end-user must define CONFIG_SYSTEM_ASSERT_BEHAVIOR for there to be an effect. By default the CONFIG_ENABLE_SYSTEM_ASSERT setting is not defined.

See also

CONFIG_SYSTEM_ASSERT_BEHAVIOR

Define the system assertion behavior.

The CONFIG_SYSTEM_ASSERT_BEHAVIOR setting allows the end-user to specify the behavior (code) of the assertion which is called when CONFIG_ENABLE_SYSTEM_ASSERT is defined. Typically some sort of output is generated over a serial or other interface. By default the CONFIG_SYSTEM_ASSERT_BEHAVIOR is not defined.

Note

In order to use the *ArduinoAssert*() functionality, the CONFIG_ENABLE_ARDUINO_CPP_INTERFACE setting must be enabled.

See also

```
CONFIG_ENABLE_SYSTEM_ASSERT
CONFIG_ENABLE_ARDUINO_CPP_INTERFACE
```

```
#define CONFIG_SYSTEM_ASSERT_BEHAVIOR(f, 1) _ArduinoAssert_( f , 1 )
```

Define the size in bytes of the message queue message value.

Setting the CONFIG_MESSAGE_VALUE_BYTES allows the end-user to define the size of the message queue message value. The larger the size of the message value, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xQueueMessage

```
4.1.2.4 CONFIG_NOTIFICATION_VALUE_BYTES #define CONFIG_NOTIFICATION_VALUE_BYTES 0x8u /* 8 */
```

Setting the CONFIG_NOTIFICATION_VALUE_BYTES allows the end-user to define the size of the direct to task notification value. The larger the size of the notification value, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xTaskNotification

4.1.2.5 CONFIG_QUEUE_MINIMUM_LIMIT #define CONFIG_QUEUE_MINIMUM_LIMIT 0x5u /* 5 */

Setting the CONFIG_QUEUE_MINIMUM_LIMIT allows the end-user to define the MINIMUM length limit a message queue can be created with xQueueCreate(). When a message queue length equals its limit, the message queue will be considered full and return true when xQueueIsQueueFull() is called. A full queue will also not accept messages from xQueueSend(). The default value is 5. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

```
xQueuelsQueueFull()
xQueueSend()
xQueueCreate()
```

```
4.1.2.6 CONFIG_TASK_NAME_BYTES #define CONFIG_TASK_NAME_BYTES 0x8u /* 8 */
```

Setting the CONFIG_TASK_NAME_BYTES allows the end-user to define the size of the ASCII task name. The larger the size of the task name, the greater impact there will be on system performance. The default size is 8 bytes. The literal must be appended with "u" to maintain MISRA C:2012 compliance.

See also

xTaskInfo

4.2 HeliOS.h File Reference

Header file for end-user application code.

```
#include "posix.h"
#include <stdint.h>
#include "config.h"
#include "defines.h"
```

Data Structures

struct TaskRunTimeStats_s

Data structure for task runtime statistics.

struct TaskInfo s

Data structure for information about a task.

struct TaskNotification_s

Data structure for direct to task notifications.

• struct QueueMessage s

Data structure for a message queue message.

struct SystemInfo_s

Data structure for system informaiton.

struct MemoryRegionStats_s

Data structure for statistics on a memory region.

Macros

#define DEREF_TASKPARM(t, p) *((t*) p)

A C macro to simplify casting and dereferencing a task paramater.

Typedefs

• typedef uint8 t Base t

Type definition for the base data type.

• typedef uint32_t Word_t

Type defintion for the word data type.

typedef uint32_t Ticks_t

The type definition for time expressed in ticks.

typedef size_t Size_t

The type defintion for storing the size of some object in memory.

typedef Size_t xSize

The type defintion for storing the size of some object in memory.

typedef struct TaskRunTimeStats_s TaskRunTimeStats_t

Data structure for task runtime statistics.

• typedef struct TaskInfo_s TaskInfo_t

Data structure for information about a task.

typedef struct TaskNotification_s TaskNotification_t

Data structure for direct to task notifications.

typedef struct QueueMessage_s QueueMessage_t

Data structure for a message queue message.

typedef struct SystemInfo_s SystemInfo_t

Data structure for system informaiton.

typedef struct MemoryRegionStats_s MemoryRegionStats_t

Data structure for statistics on a memory region.

· typedef void Task_t

Stub type definition for the task type.

typedef void TaskParm_t

Type definition for the task parameter.

• typedef void Queue_t

Stub type definition for the message queue type.

typedef void Timer_t

Stub type definition for the timer type.

typedef void Addr_t

Type defintion for the memory address data type.

typedef Addr_t * xAddr

Type defintion for the memory address data type.

typedef Base_t xBase

Type definition for the base data type.

typedef Word_t xWord

Type defintion for the word data type.

typedef Timer_t * xTimer

Stub type definition for the timer type.

• typedef Queue t * xQueue

Stub type definition for the message queue type.

typedef QueueMessage_t * xQueueMessage

Data structure for a message queue message.

typedef TaskNotification_t * xTaskNotification

Data structure for direct to task notifications.

typedef TaskInfo t * xTaskInfo

Data structure for information about a task.

typedef TaskRunTimeStats t * xTaskRunTimeStats

Data structure for task runtime statistics.

typedef MemoryRegionStats_t * xMemoryRegionStats

Data structure for statistics on a memory region.

typedef Task_t * xTask

Stub type definition for the task type.

typedef TaskParm_t * xTaskParm

Type definition for the task parameter.

typedef Ticks_t xTicks

The type definition for time expressed in ticks.

typedef TaskState t xTaskState

Enumerated type for task states.

typedef SchedulerState_t xSchedulerState

Enumerated type for scheduler states.

typedef SystemInfo_t * xSystemInfo

Data structure for system informaiton.

Enumerations

- enum TaskState_t { TaskStateError , TaskStateSuspended , TaskStateRunning , TaskStateWaiting }
 Enumerated type for task states.
- enum SchedulerState_t { SchedulerStateError , SchedulerStateSuspended , SchedulerStateRunning }
 Enumerated type for scheduler states.

Functions

void xSystemInit (void)

System call to initialize the system.

• void _SystemAssert_ (const char *file_, int line_)

System call to handle assertions.

xAddr xMemAlloc (const xSize size_)

System call to allocate memory from the heap.

void xMemFree (const xAddr addr_)

System call to free memory allocated from the heap.

xSize xMemGetUsed (void)

System call to return the amount of allocated heap memory.

xSize xMemGetSize (const xAddr addr_)

System call to return the amount of heap memory allcoated for a given address.

xMemoryRegionStats xMemGetHeapStats (void)

System call to obtain statistics on the heap.

xMemoryRegionStats xMemGetKernelStats (void)

System call to obtain statistics on the kernel memory region.

xQueue xQueueCreate (xBase limit)

System call to create a new message queue.

• void xQueueDelete (xQueue queue_)

System call to delete a message queue.

xBase xQueueGetLength (xQueue queue_)

System call to get the length of the message queue.

xBase xQueuelsQueueEmpty (xQueue queue_)

System call to check if the message queue is empty.

xBase xQueueIsQueueFull (xQueue queue_)

System call to check if the message queue is full.

xBase xQueueMessagesWaiting (xQueue queue)

System call to check if there are message queue messages waiting.

xBase xQueueSend (xQueue queue_, xBase messageBytes_, const char *messageValue_)

System call to send a message using a message queue.

xQueueMessage xQueuePeek (xQueue queue)

System call to peek at the next message in a message queue.

void xQueueDropMessage (xQueue queue_)

System call to drop the next message in a message queue.

xQueueMessage xQueueReceive (xQueue queue_)

System call to receive the next message in the message queue.

void xQueueLockQueue (xQueue queue)

System call to LOCK the message queue.

void xQueueUnLockQueue (xQueue queue_)

System call to UNLOCk the message queue.

void xTaskStartScheduler (void)

System call to pass control to the HeliOS scheduler.

void xTaskResumeAll (void)

System call to set scheduler state to running.

void xTaskSuspendAll (void)

System call to set the scheduler state to suspended.

xSystemInfo xSystemGetSystemInfo (void)

The xSystemGetSystemInfo() system call will return the type xSystemInfo containing information about the system including the OS (product) name, its version and how many tasks are currently in the running, suspended or waiting states.

• xTask xTaskCreate (const char *name_, void(*callback_)(xTask, xTaskParm), xTaskParm taskParameter_)

System call to create a new task.

void xTaskDelete (xTask task_)

System call to delete a task.

xTask xTaskGetHandleByName (const char *name_)

System call to get a task's handle by its ASCII name.

xTask xTaskGetHandleById (xBase id_)

System call to get a task's handle by its task identifier.

xTaskRunTimeStats xTaskGetAllRunTimeStats (xBase *tasks)

System call to return task runtime statistics for all tasks.

xTaskRunTimeStats xTaskGetTaskRunTimeStats (xTask task_)

System call to return task runtime statistics for the specified task.

xBase xTaskGetNumberOfTasks (void)

System call to return the number of tasks regardless of their state.

xTaskInfo xTaskGetTaskInfo (xTask task_)

System call to return the details of a task.

xTaskInfo xTaskGetAllTaskInfo (xBase *tasks)

System call to return the details of all tasks.

xTaskState xTaskGetTaskState (xTask task)

System call to return the state of a task.

char * xTaskGetName (xTask task_)

System call to return the ASCII name of a task.

xBase xTaskGetId (xTask task_)

System call to return the task identifier for a task.

void xTaskNotifyStateClear (xTask task_)

System call to clear a waiting direct to task notification.

xBase xTaskNotificationIsWaiting (xTask task_)

System call to check if a direct to task notification is waiting.

Base_t xTaskNotifyGive (xTask task_, xBase notificationBytes_, const char *notificationValue_)

System call to give another task a direct to task notification.

xTaskNotification xTaskNotifyTake (xTask task_)

System call to take a direct to task notification from another task.

void xTaskResume (xTask task_)

System call to resume a task.

void xTaskSuspend (xTask task)

System call to suspend a task.

void xTaskWait (xTask task_)

System call to place a task in a waiting state.

void xTaskChangePeriod (xTask task , xTicks timerPeriod)

System call to set the task timer period.

xTicks xTaskGetPeriod (xTask task)

System call to get the task timer period.

void xTaskResetTimer (xTask task_)

System call to reset the task timer.

xSchedulerState xTaskGetSchedulerState (void)

System call to get the state of the scheduler.

xTimer xTimerCreate (xTicks timerPeriod_)

System call to create a new timer.

• void xTimerDelete (xTimer timer)

System call will delete a timer.

void xTimerChangePeriod (xTimer timer_, xTicks timerPeriod_)

System call to change the period of a timer.

xTicks xTimerGetPeriod (xTimer timer_)

System call to get the period of a timer.

xBase xTimerIsTimerActive (xTimer timer_)

System call to check if a timer is active.

xBase xTimerHasTimerExpired (xTimer timer_)

System call to check if a timer has expired.

void xTimerReset (xTimer timer_)

System call to reset a timer.

void xTimerStart (xTimer timer_)

System call to start a timer.

void xTimerStop (xTimer timer_)

The xTimerStop() system call will place the timer in the stopped state. Neither xTimerStart() nor xTimerStop() will reset the timer. Timers can only be reset with xTimerReset().

void xSystemHalt (void)

The xSystemHalt() system call will halt HeliOS.

4.2.1 Detailed Description

Author

Manny Peterson (mannymsp@gmail.com)

Version

0.3.5

Date

2022-01-31

Copyright

HeliOS Embedded Operating System Copyright (C) 2020-2022 Manny Peterson mannymsp@gmail.com

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see https://www.gnu.org/licenses/.

4.2.2 Macro Definition Documentation

4.2.2.1 DEREF_TASKPARM #define DEREF_TASKPARM(t, p) *((t*) p)

When a task paramater is passed to a task, it is passed as a pointer of type void. To use the paramater, it must first be cast to the correct type and dereferenced. The following is an example of how the DEREF_TASKPARM() C macro simplifies that process.

```
void myTask_main(xTask task_, xTaskParm parm_) {
  int i;
  i = DEREF_TASKPARM(int, parm_);
  i++;
  DEREF_TASKPARM(int, parm_) = i;
  return;
}
```

Parameters

t	The data type to cast the task paramater to (e.g., int).
р	The task pointer, typically named parm

4.2.3 Typedef Documentation

4.2.3.1 Addr_t typedef void Addr_t

The xAddr type is used to store a memory address and is used to pass memory addresses back and forth between system calls and the end-user application. It is not necessary to use the xAddr type within the end-user application as long as the type is not used to interact with the HeliOS kernel through system calls.

```
4.2.3.2 Base_t typedef uint8_t Base_t
```

A simple data type is often needed as an argument for a system call or a return type. The Base_t type is used in such a case where there are no other structural data requirements and is typically an unsigned 8-bit integer. The Base_t type should be declared as xBase.

See also

xBase

4.2.3.3 MemoryRegionStats_t typedef struct MemoryRegionStats_s MemoryRegionStats_t

The MemoryRegionStats_t data structure is used to store statistics about a HeliOS memory region. Statistics can be obtained for the heap and kernel memory regions.

See also

xMemGetHeapStats() xMemGetKernelStats() xMemoryRegionStats

4.2.3.4 Queue_t typedef void Queue_t

The Queue_t type is a stub type definition for the internal message queue structure and is treated as a message queue handle by most of the message queue related system calls. The members of the data structure are not accessible. The Queue_t type should be declared as xQueue.

See also

xQueue xQueueDelete()

Warning

The memory allocated for an instance of xQueue must be freed using xQueueDelete().

4.2.3.5 QueueMessage_t typedef struct QueueMessage_s QueueMessage_t

The QueueMessage_t data structure contains the message queue message returned by xQueuePeek() and xQueueReceive(). The QueueMessage_t type should be declared as xQueueMessage.

See also

```
xQueueMessage
xQueuePeek()
xQueueReceive()
xMemFree()
CONFIG_MESSAGE_VALUE_BYTES
```

Warning

The memory allocated for an instance of xQueueMessage must be freed using xMemFree().

4.2.3.6 Size_t typedef size_t Size_t

The Size_t type is used to store the size of an object in memory and is always represented in bytes. Size_t should always be declared as xSize.

See also

xSize

4.2.3.7 SystemInfo_t typedef struct SystemInfo_s SystemInfo_t

The SystemInfo_t data structure contains information about the HeliOS system and is returned by xSystemGetSystemInfo(). The SystemInfo_t type should be declared as xSystemInfo.

See also

```
xSystemInfo
xSystemGetSystemInfo()
xMemFree()
```

Warning

The memory allocated for an instance of xSystemInfo must be freed using xMemFree().

4.2.3.8 Task_t typedef void Task_t

The Task_t type is a stub type definition for the internal task data structure and is treated as a task handle by most of the task related system calls. The members of the data structure are not accessible. The Task_t type should be declared as xTask.

See also

```
xTask
xTaskDelete()
```

Warning

The memory allocated for an instance of xTask must be freed by xTaskDelete()

4.2.3.9 TaskInfo_t typedef struct TaskInfo_s TaskInfo_t

The TaskInfo_t structure is similar to xTaskRuntimeStats_t in that it contains runtime statistics for a task. However, TaskInfo_t also contains additional details about a task such as its identifier, ASCII name and state. The TaskInfo_t structure is returned by xTaskGetTaskInfo(). If only runtime statistics are needed, TaskRunTimeStats_t should be used because of its lower memory footprint. The TaskInfo_t type should be declared as xTaskInfo.

See also

```
xTaskInfo
xTaskGetTaskInfo()
xMemFree()
CONFIG_TASK_NAME_BYTES
```

Warning

The memory allocated for an instance of xTaskInfo must be freed using xMemFree().

4.2.3.10 TaskNotification_t typedef struct TaskNotification_s TaskNotification_t

The TaskNotification_t data structure contains the direct to task notification returned by xTaskNotifyTake(). The TaskNotification_t type should be declared as xTaskNotification.

See also

```
xTaskNotification
xTaskNotifyTake()
xMemFree()
CONFIG_NOTIFICATION_VALUE_BYTES
```

Warning

The memory allocated for an instance of xTaskNotification must be freed using xMemFree().

4.2.3.11 TaskParm_t typedef void TaskParm_t

The TaskParm_t type is used to pass a parameter to a task at the time of creation using xTaskCreate(). A task parameter is a pointer of type void and can point to any number of intrinsic types, arrays and/or user defined structures which can be passed to a task. It is up the the end-user to manage, allocate and free the memory related to these objects using xMemAlloc() and xMemFree(). The TaskParm_t should be declared as xTaskParm.

See also

```
xTaskParm
xMemAlloc()
xMemFree()
```

Warning

The memory allocated for an instance of xTaskParm must be freed using xMemFree().

4.2.3.12 TaskRunTimeStats_t typedef struct TaskRunTimeStats_s TaskRunTimeStats_t

The TaskRunTimeStats_t structure contains task runtime statistics and is returned by xTaskGetAllRunTimeStats() and xTaskGetTaskRunTimeStats(). The TaskRunTimeStats_t type should be declared as xTaskRunTimeStats.

See also

```
xTaskRunTimeStats
xTaskGetTaskRunTimeStats()
xTaskGetAllRunTimeStats()
xMemFree()
```

Warning

The memory allocated for an instance of xTaskRunTimeStats must be freed using xMemFree().

4.2.3.13 Ticks_t typedef uint32_t Ticks_t

The xTicks type is used by several of the task and timer related system calls to express time. The unit of measure for time is always ticks.

See also

xTicks

4.2.3.14 Timer_t typedef void Timer_t

The Timer_t type is a stub type definition for the internal timer data structure and is treated as a timer handle by most of the timer related system calls. The members of the data structure are not accessible. The Timer_t type should be declared as xTimer.

See also

```
xTimer xTimerDelete()
```

Warning

The memory allocated for an instance of xTimer must be freed using xTimerDelete().

```
4.2.3.15 Word_t typedef uint32_t Word_t
```

A word is a 32-bit data type in HeliOS.

See also

xWord

```
4.2.3.16 xAddr typedef Addr_t* xAddr
```

The xAddr type is used to store a memory address and is used to pass memory addresses back and forth between system calls and the end-user application. It is not necessary to use the xAddr type within the end-user application as long as the type is not used to interact with the HeliOS kernel through system calls.

```
4.2.3.17 xBase typedef Base_t xBase
```

A simple data type is often needed as an argument for a system call or a return type. The xBase type is used in such a case where there are no other structural data requirements is typically an unsigned 8-bit integer.

See also

Base_t

4.2.3.18 xMemoryRegionStats typedef MemoryRegionStats_t* xMemoryRegionStats

The xMemoryRegionStats data structure is used to store statistics about a HeliOS memory region. Statistics can be obtained for the heap and kernel memory regions.

See also

```
xMemGetHeapStats()
xMemGetKernelStats()
MemoryRegionStats_t
```

4.2.3.19 xQueue typedef Queue_t* xQueue

The xQueue type is a stub type definition for the internal message queue structure and is treated as a message queue handle by most of the message queue related system calls. The members of the data structure are not accessible.

See also

```
Queue_t
xQueueDelete()
```

Warning

The memory allocated for an instance of xQueue must be freed using xQueueDelete().

4.2.3.20 **xQueueMessage** typedef QueueMessage_t* xQueueMessage

The xQueueMessage data structure contains the message queue message returned by xQueuePeek() and xQueueReceive(). See QueueMessage_t for information about the data structure's members.

See also

```
QueueMessage_t
xQueuePeek()
xQueueReceive()
xMemFree()
CONFIG_MESSAGE_VALUE_BYTES
```

Warning

The memory allocated for an instance of xQueueMessage must be freed using xMemFree().

4.2.3.21 xSchedulerState typedef SchedulerState_t xSchedulerState

The scheduler can be in one of four possible states defined in the SchedulerState_t enumerated type. The state of the scheduler is changed by calling xTaskSuspendAll() and xTaskResumeAll(). The state can be obtained by calling xTaskGetSchedulerState().

See also

```
xSchedulerState
xTaskSuspendAll()
xTaskResumeAll()
xTaskGetSchedulerState()
```

4.2.3.22 xSize typedef Size_t xSize

The xSize type is used to store the size of an object in memory and is always represented in bytes.

4.2.3.23 xSystemInfo typedef SystemInfo_t* xSystemInfo

The xSystemInfo data structure contains information about the HeliOS system and is returned by xSystemGetSystemInfo(). See xSystemInfo_t for information about the data structure's members.

See also

```
SystemInfo_t
xSystemGetSystemInfo()
xMemFree()
```

Warning

The memory allocated for an instance of xSystemInfo must be freed using xMemFree().

4.2.3.24 xTask typedef Task_t* xTask

The xTask type is a stub type definition for the internal task data structure and is treated as a task handle by most of the task related system calls. The members of the data structure are not accessible.

See also

```
Task_t
xTaskCreate()
xTaskDelete()
```

Warning

The memory allocated for an instance of xTask must be freed by xTaskDelete()

4.2.3.25 xTaskInfo typedef TaskInfo_t* xTaskInfo

The xTaskInfo structure is similar to xTaskRunTimeStats in that it contains runtime statistics for a task. However, xTaskInfo also contains additional details about a task such as its identifier, ASCII name and state. The xTaskInfo structure is returned by xTaskGetTaskInfo(). If only runtime statistics are needed, xTaskRunTimeStats should be used because of its lower memory footprint. See TaskInfo_t for information about the data structure's members.

See also

```
TaskInfo_t
xTaskGetTaskInfo()
xMemFree()
CONFIG TASK NAME BYTES
```

Warning

The memory allocated for an instance of xTaskInfo must be freed using xMemFree().

4.2.3.26 xTaskNotification typedef TaskNotification_t* xTaskNotification

The xTaskNotification data structure contains the direct to task notification returned by xTaskNotifyTake(). See TaskNotification_t for information about the data structure's members.

See also

```
TaskNotification_t
xTaskNotifyTake()
xMemFree()
CONFIG_NOTIFICATION_VALUE_BYTES
```

Warning

The memory allocated for an instance of xTaskNotification must be freed using xMemFree().

4.2.3.27 xTaskParm typedef TaskParm_t* xTaskParm

The xTaskParm type is used to pass a parameter to a task at the time of creation using xTaskCreate(). A task parameter is a pointer of type void and can point to any number of intrinsic types, arrays and/or user defined structures which can be passed to a task. It is up the the end-user to manage allocate and free the memory related to these objects using xMemAlloc() and xMemFree().

See also

```
TaskParm_t
xMemAlloc()
xMemFree()
```

Warning

The memory allocated for an instance of xTaskParm must be freed using xMemFree().

4.2.3.28 xTaskRunTimeStats typedef TaskRunTimeStats_t* xTaskRunTimeStats

The xTaskRunTimeStats structure contains task runtime statistics and is returned by xTaskGetAllRunTimeStats() and xTaskGetTaskRunTimeStats(). See TaskRunTimeStats_t for information about the data structure's members.

See also

```
TaskRunTimeStats_t
xTaskGetTaskRunTimeStats()
xTaskGetAllRunTimeStats()
xMemFree()
```

Warning

The memory allocated for an instance of xTaskRunTimeStats must be freed using xMemFree().

4.2.3.29 xTaskState typedef TaskState_t xTaskState

A task can be in one of the four possible states defined in the TaskState_t enumerated type. The state of a task is changed by calling xTaskResume(), xTaskSuspend() or xTaskWait().

See also

```
TaskState_t
xTaskResume()
xTaskSuspend()
xTaskWait()
```

4.2.3.30 xTicks typedef Ticks_t xTicks

The xTicks type is used by several of the task and timer related system calls to express time. The unit of measure for time is always ticks.

See also

Ticks_t

4.2.3.31 xTimer typedef Timer_t* xTimer

The xTimer type is a stub type definition for the internal timer data structure and is treated as a timer handle by most of the timer related system calls. The members of the data structure are not accessible.

See also

```
Timer_t
xTimerDelete()
```

Warning

The memory allocated for an instance of xTimer must be freed using xTimerDelete().

4.2.3.32 xWord typedef Word_t xWord

A word is a 32-bit data type in HeliOS.

See also

Word t

4.2.4 Enumeration Type Documentation

$\textbf{4.2.4.1} \quad \textbf{SchedulerState_t} \quad \texttt{enum SchedulerState_t}$

The scheduler can be in one of four possible states defined in the SchedulerState_t enumerated type. The state of the scheduler is changed by calling xTaskSuspendAll() and xTaskResumeAll(). The state can be obtained by calling xTaskGetSchedulerState().

See also

```
xSchedulerState
xTaskSuspendAll()
xTaskResumeAll()
```

Enumerator

SchedulerStateError	Not used.
SchedulerStateSuspended	State the scheduler is in after xTaskSuspendAll() is called.
SchedulerStateRunning	State the scheduler is in after xTaskResumeAll() is called.

4.2.4.2 TaskState_t enum TaskState_t

A task can be in one of the four possible states defined in the TaskState_t enumerated type. The state of a task is changed by calling xTaskResume(), xTaskSuspend() or xTaskWait(). The TaskState_t enumerated type should be declared as xTaskState.

See also

```
xTaskState
xTaskResume()
xTaskSuspend()
xTaskWait()
```

Enumerator

TaskStateError	Returned by xTaskGetTaskState() when task cannot be found.
TaskStateSuspended	State a task is in when it is first created by xTaskCreate() or suspended by
	xTaskSuspend().
TaskStateRunning	State a task is in after xTaskResume() is called.
TaskStateWaiting	State a task is in after xTaskWait() is called.

4.2.5 Function Documentation

The <code>SystemAssert()</code> system call handles assertions. The <code>SystemAssert()</code> system call should not be called directly. Instead, the <code>SYSASSERT()</code> macro should be used. The system assertion functionality will only work when the <code>CONFIG_ENABLE_SYSTEM_ASSERT</code> and <code>CONFIG_SYSTEM_ASSERT_BEHAVIOR</code> settings are defined.

See also

```
SYSASSERT

CONFIG_ENABLE_SYSTEM_ASSERT

CONFIG_SYSTEM_ASSERT_BEHAVIOR
```

Parameters

file←	This is automatically defined by the compiler's definition of FILE
_ line←	This is automatically defined by the compiler's definition of <i>LINE</i>
_	,

```
4.2.5.2 xMemAlloc() xAddr xMemAlloc (
const xSize size_)
```

The xMemAlloc() system call allocates memory from the heap for HeliOS system calls and end-user tasks. The size of the heap, in bytes, is dependent on the CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS and CONFIG_← MEMORY_REGION_BLOCK_SIZE settings. xMemAlloc() functions similarly to calloc() in that it clears the memory it allocates.

See also

```
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS
CONFIG_MEMORY_REGION_BLOCK_SIZE
xMemFree()
```

Parameters

size⊷	The amount (size) of the memory to be allocated from the heap in bytes.

Returns

xAddr If successful, xMemAlloc() returns the address of the newly allocated memory. If unsuccessful, the system call will return null.

Note

HeliOS technically does not allocate memory from what is traditionally heap memory. HeliOS uses a private "heap" which is actually static memory allocated at compile time. This is done to maintain MISRA C:2012 compliance since standard library functions like malloc(), calloc() and free() are not permitted.

```
4.2.5.3 xMemFree() void xMemFree ( const xAddr addr_)
```

The xMemFree() system call will free heap memory allocated by xMemAlloc() and other HeliOS system calls such as xSystemGetSystemInfo().

See also

xMemAlloc()

Parameters

addr⊷	The address of the allocated heap memory to be freed.
_	

Warning

xMemFree() cannot be used to free memory allocated for kernel objects. Memory allocated by xTaskCreate(), xTimerCreate() or xQueueCreate() must be freed by their respective delete system calls (i.e., xTaskDelete()).

```
4.2.5.4 xMemGetHeapStats() xMemoryRegionStats xMemGetHeapStats ( void )
```

The xMemGetHeapStats() system call will return statistics about the heap so the end-user can better understand the state of the heap.

See also

xMemoryRegionStats

Returns

xMemoryRegionStats Returns the xMemoryRegionStats structure or null if unsuccesful.

Warning

The memory allocated by xMemGetHeapStats() must be freed by xMemFree().

4.2.5.5 xMemGetKernelStats() xMemoryRegionStats xMemGetKernelStats (void)

The xMemGetKernelStats() system call will return statistics about the kernel memory region so the end-user can better understand the state of kernel memory.

See also

xMemoryRegionStats

Returns

xMemoryRegionStats Returns the xMemoryRegionStats structure or null if unsuccesful.

Warning

The memory allocated by xMemGetKernelStats() must be freed by xMemFree().

```
4.2.5.6 xMemGetSize() xSize xMemGetSize ( const xAddr addr_)
```

The xMemGetSize() system call returns the amount of heap memory in bytes that is currently allocated to a specific address. If the address is null or invalid, xMemGetSize() will return zero bytes.

Parameters

addr⊷	The address of the allocated heap memory to obtain the size of the memory, in bytes, that is allocated.

Returns

Size_t The amount of memory currently allocated to the specific address in bytes. If the address is invalid or null, xMemGetSize() will return zero.

Note

If the address addr_points to a structure that, for example, is 48 bytes in size base on sizeof(), xMemGetSize() will return the number of bytes allocated by the block(s) that contain the structure. Assuming the default block size of 32, a 48 byte structure would require TWO blocks so xMemGetSize() would return 64 - not 48. xMemGetSize() also checks the health of the heap and will return zero if it detects a consistency issue with the heap. Thus, xMemGetSize() can be used to validate addresses before the objects they reference are accessed.

```
4.2.5.7 xMemGetUsed() xSize xMemGetUsed (void)
```

The xMemGetUsed() system call returns the amount of heap memory, in bytes, that is currently allocated. Calls to xMemAlloc() increases and xMemFree() decreases the amount of memory in use.

Returns

Size_t The amount of memory currently allocated in bytes. If no heap memory is currently allocated, xMemGetUsed() will return zero.

Note

xMemGetUsed() returns the amount of heap memory that is currently allocated to end-user objects AND kernel objects. However, only end-user objects may be freed using xMemFree(). Kernel objects must be freed using their respective delete system call (e.g., xTaskDelete()).

```
4.2.5.8 xQueueCreate() xQueue xQueueCreate() xBase limit_)
```

The xQueueCreate() system call creates a message queue for inter-task communication.

See also

xQueue

xQueueDelete()

CONFIG_QUEUE_MINIMUM_LIMIT

Parameters

limit←	The message limit for the queue. When this number is reach, the queue is considered full and
_	xQueueSend() will fail. The minimum limit for queues is dependent on the setting
	CONFIG_QUEUE_MINIMUM_LIMIT.

Returns

xQueue A queue is returned if successful, otherwise null is returned if unsuccessful.

Warning

The message queue memory can only be freed by xQueueDelete().

The xQueueDelete() system call will delete a message queue created by xQueueCreate(). xQueueDelete() will delete a queue regardless of how many messages the queue contains at the time xQueueDelete() is called. Any messages the message queue contains will be deleted in the process of deleting the message queue.

See also

xQueueCreate()

Parameters

queue↔	The queue to be deleted.
_	

4.2.5.10 xQueueDropMessage() void xQueueDropMessage ($xQueue \ queue _$)

The xQueueDropMessage() system call will drop the next message from the message queue without returning the message.

Parameters

queue⊷	The queue to drop the next message from.

```
4.2.5.11 xQueueGetLength() xBase xQueueGetLength ( xQueue \ queue \_ )
```

The xQueueGetLength() system call returns the length of the queue (the number of messages the queue currently contains).

Parameters

queue⊷	The queue to return the length of.
_	

Returns

xBase The number of messages in the queue. If unsuccessful or if the queue is empty, xQueueGetLength() returns zero.

4.2.5.12 xQueuelsQueueEmpty() xBase xQueueIsQueueEmpty ($xQueue \ queue \)$

The xQueuelsEmpty() system call will return a true or false dependent on whether the queue is empty (message queue length is zero) or contains one or more messages.

Parameters

queue⊷	The queue to determine whether it is empty.
_	

Returns

xBase True if the queue is empty. False if the queue has one or more messages. xQueuelsQueueEmpty() will also return false if the queue parameter is invalid.

```
4.2.5.13 xQueuelsQueueFull() xBase xQueueIsQueueFull ( xQueue \ queue\_ )
```

The xQueuelsFull() system call will return a true or false dependent on whether the queue is full or contains zero messages. A queue is considered full if the number of messages in the queue is equal to the queue's length limit.

Parameters

queue⊷	The queue to determine whether it is full.
_	

Returns

xBase True if the queue is full. False if the queue has zero. xQueuelsQueueFull() will also return false if the queue parameter is invalid.

```
4.2.5.14 xQueueLockQueue() void xQueueLockQueue ( xQueue queue_ )
```

The xQueueLockQueue() system call will lock the message queue. Locking a message queue will prevent xQueueSend() from sending messages to the queue.

Parameters

queue⊷	The queue to lock.
_	

4.2.5.15 xQueueMessagesWaiting() xBase xQueueMessagesWaiting ($xQueue \ queue_$)

The xQueueMessageWaiting() system call returns true or false dependent on whether there is at least one message waiting. The message queue does not have to be full to return true.

Parameters

queue⊷	The queue to determine whether one or more messages are waiting.

Returns

xBase True if one or more messages are waiting. False if there are no messages waiting of the queue parameter is invalid.

```
4.2.5.16 xQueuePeek() xQueueMessage xQueuePeek ( xQueue \ queue  )
```

The xQueuePeek() system call will return the next message in the specified message queue without dropping the message.

See also

```
xQueueMessage
xMemFree()
```

Parameters

queue⊷	The queue to return the next message from.

Returns

xQueueMessage The next message in the queue. If the queue is empty or the queue parameter is invalid, xQueuePeek() will return null.

Warning

The memory allocated by xQueuePeek() must be freed by xMemFree().

```
4.2.5.17 xQueueReceive() xQueueMessage xQueueReceive ( <math>xQueue \ queue\_)
```

The xQueueReceive() system call will return the next message in the message queue and drop it from the message queue.

See also

```
xQueueMessage
xMemFree()
```

Parameters

Ī	queue⊷	The queue to return the next message from.
	_	

Returns

xQueueMessage The message returned from the queue. If the queue is empty of the queue parameter is invalid, xQueueReceive() will return null.

Warning

The memory allocated by xQueueReceive() must be freed by xMemFree().

The xQueueSend() system call will send a message using the specified message queue. The size of the message value is passed in the message bytes parameter. The maximum message value size in bytes is dependent on the CONFIG_MESSAGE_VALUE_BYTES setting.

See also

```
CONFIG_MESSAGE_VALUE_BYTES
xQueuePeek()
xQueueReceive()
```

queue_	The queue to send the message to.
message⊷ Bytes	The number of bytes contained in the message value. The number of bytes must be greater than zero and less than or equal to the setting CONFIG MESSAGE VALUE BYTES.
message↔ Value_	The message value. If the message value is greater than defined in CONFIG_MESSAGE_VALUE_BYTES, only the number of bytes defined in CONFIG_MESSAGE_VALUE_BYTES will be copied into the message value. The message value is NOT a null terminated string.

Returns

xBase xQueueSend() returns RETURN_SUCCESS if the message was sent to the queue successfully. Otherwise RETURN_FAILURE if unsuccessful.

4.2.5.19 xQueueUnLockQueue() void xQueueUnLockQueue ($xQueue queue_$)

The xQueueUnLockQueue() system call will unlock the message queue. Unlocking a message queue will allow xQueueSend() to send messages to the queue.

Parameters

queue⊷	The queue to unlock.
_	

4.2.5.20 xSystemGetSystemInfo() xSystemInfo xSystemGetSystemInfo (void)

Returns

xSystemInfo The system info is returned if successful, otherwise null is returned if unsuccessful.

See also

xSystemInfo xMemFree()

Warning

The memory allocated by the xSystemGetSystemInfo() must be freed with xMemFree()

```
4.2.5.21 xSystemHalt() void xSystemHalt ( void )
```

The xSystemHalt() system call will halt HeliOS. Once xSystemHalt() is called, the system must be reset.

```
4.2.5.22 xSystemInit() void xSystemInit ( void )
```

The xSystemInit() system call initializes the required interrupt handlers and memory and must be called prior to calling any other system call.

The xTaskChangePeriod() system call will change the period (ticks) on the task timer for the specified task. The timer period must be greater than zero. To have any effect, the task must be in the waiting state set by calling xTaskWait() on the task. Once the timer period is set and the task is in the waiting state, the task will be executed every timerPeriod_ ticks. Changing the period to zero will prevent the task from being executed even if it is in the waiting state unless it were to receive a direct to task notification.

See also

```
xTaskWait()
xTaskGetPeriod()
xTaskResetTimer()
```

Parameters

task_	The task to change the timer period for.
timer←	The timer period in ticks.
Period_	

The xTaskCreate() system call will create a new task. The task will be created with its state set to suspended. The xTaskCreate() and xTaskDelete() system calls cannot be called within a task. They MUST be called outside of the scope of the HeliOS scheduler.

Parameters

name_	The ASCII name of the task which can be used by xTaskGetHandleByName() to obtain the task handle. The length of the name is depended on the CONFIG_TASK_NAME_BYTES. The task name is NOT a null terminated char string.
callback_	The address of the task main function. This is the function that will be invoked by the scheduler when a task is scheduled for execution.
task⇔ Parameter_	A pointer to any type or structure that the end-user wants to pass into the task as a parameter. The task parameter is not required and may simply be set to null.

Generated by Doxygen

Returns

xTask A handle to the newly created task.

See also

```
xTask
xTaskParm
xTaskDelete()
xTaskState
CONFIG_TASK_NAME_BYTES
```

Warning

xTaskCreate() MUST be called outside the scope of the HeliOS scheduler (i.e., not from a task's main). The task memory can only be freed by xTaskDelete().

The xTaskDelete() system call will delete a task. The xTaskCreate() and xTaskDelete() system calls cannot be called within a task. They MUST be called outside of the scope of the HeliOS scheduler.

Parameters

task↩	The handle of the task to be deleted.
_	

Warning

xTaskDelete() MUST be called outside the scope of the HeliOS scheduler (i.e., not from a task's main).

```
4.2.5.26 xTaskGetAllRunTimeStats() xTaskRunTimeStats xTaskGetAllRunTimeStats ( xBase * tasks_ )
```

The xTaskGetAllRunTimeStats() system call will return the runtime statistics for all of the tasks regardless of their state. The xTaskGetAllRunTimeStats() system call returns the xTaskRunTimeStats type. An xBase variable must be passed by reference to xTaskGetAllRunTimeStats() which will be updated by xTaskGetAllRunTimeStats() to contain the number of tasks so the end-user can iterate through the tasks. The xTaskRunTimeStats memory must be freed by xMemFree() after it is no longer needed.

See also

```
xTaskRunTimeStats
xMemFree()
```

tasks⊷	A variable of type xBase passed by reference which will contain the number of tasks upon return. If no	
_	tasks currently exist, this variable will not be modified.	

Returns

xTaskRunTimeStats The runtime stats returned by xTaskGetAllRunTimeStats(). If there are currently no tasks then this will be null. This memory must be freed by xMemFree().

Warning

The memory allocated by xTaskGetAllRunTimeStats() must be freed by xMemFree().

4.2.5.27 xTaskGetAllTaskInfo() xTaskInfo xTaskGetAllTaskInfo (xBase * tasks_)

The xTaskGetAllTaskInfo() system call returns the xTaskInfo structure containing the details of ALL tasks including their identifier, name, state and runtime statistics.

See also

xTaskInfo

Parameters

tasks⇔	A variable of type xBase passed by reference which will contain the number of tasks upon return. If no	Ī
_	tasks currently exist, this variable will not be modified.	

Returns

xTaskInfo The xTaskInfo structure containing the tasks details. xTaskGetAllTaskInfo() returns null if there no tasks or if a consistency issue is detected.

Warning

The memory allocated by xTaskGetAllTaskInfo() must be freed by xMemFree().

4.2.5.28 xTaskGetHandleById() xTask xTaskGetHandleById (xBase *id_*)

The xTaskGetHandleById() system call will return the task handle of the task specified by identifier identifier.

See also

xBase

Returns

xTask The task handle. xTaskGetHandleById() returns null if the the task identifier cannot be found.

```
4.2.5.29 xTaskGetHandleByName() xTask xTaskGetHandleByName ( const char * name_ )
```

The xTaskGetHandleByName() system call will return the task handle of the task specified by its ASCII name. The length of the task name is dependent on the CONFIG_TASK_NAME_BYTES setting. The name is compared byte-for-byte so the name is case sensitive.

See also

CONFIG_TASK_NAME_BYTES

Parameters

name⇔	The ASCII name of the task to return the handle of. The task name is NOT a null terminated string.	
_		

Returns

xTask The task handle. xTaskGetHandleByName() returns null if the name cannot be found.

```
4.2.5.30 xTaskGetId() xBase xTaskGetId ( xTask task_{-} )
```

The xTaskGetId() system call returns the task identifier for the task.

Parameters

task⊷	The task to return the identifier of.

Returns

xBase The identifier of the task. If the task cannot be found, xTaskGetId() returns zero (all tasks identifiers are 1 or greater).

```
4.2.5.31 xTaskGetName() char* xTaskGetName ( xTask task_ )
```

The xTaskGetName() system call returns the ASCII name of the task. The size of the task is dependent on the setting CONFIG_TASK_NAME_BYTES. The task name is NOT a null terminated char string. The memory allocated for the char array must be freed by xMemFree() when no longer needed.

See also

```
CONFIG_TASK_NAME_BYTES xMemFree()
```

Parameters

task↩	The task to return the name of.
_	

Returns

char* A pointer to the char array containing the ASCII name of the task. The task name is NOT a null terminated char string. xTaskGetName() will return null if the task cannot be found.

Warning

The memory allocated by xTaskGetName() must be free by xMemFree().

```
4.2.5.32 xTaskGetNumberOfTasks() xBase xTaskGetNumberOfTasks (
```

The xTaskGetNumberOfTasks() system call returns the current number of tasks regardless of their state.

Returns

xBase The number of tasks.

```
4.2.5.33 xTaskGetPeriod() xTicks xTaskGetPeriod ( xTask task_{-})
```

The xTaskGetPeriod() will return the period for the timer for the specified task. See xTaskChangePeriod() for more information on how the task timer works.

See also

```
xTaskWait()
xTaskChangePeriod()
xTaskResetTimer()
```

task⊷	The task to return the timer period for.
_	

Returns

xTicks The timer period in ticks. xTaskGetPeriod() will return zero if the timer period is zero or if the task could not be found.

```
      \textbf{4.2.5.34} \quad \textbf{xTaskGetSchedulerState()} \quad \textbf{xSchedulerState} \quad \textbf{xTaskGetSchedulerState()}
```

The xTaskGetSchedulerState() system call will return the state of the scheduler. The state of the scheduler can only be changed using xTaskSuspendAll() and xTaskResumeAll().

See also

```
xSchedulerState
xTaskSuspendAll()
xTaskResumeAll()
```

Returns

xSchedulerState The state of the scheduler.

```
4.2.5.35 xTaskGetTaskInfo() xTaskInfo xTaskGetTaskInfo ( xTask task_{-})
```

The xTaskGetTaskInfo() system call returns the xTaskInfo structure containing the details of the task including its identifier, name, state and runtime statistics.

See also

xTaskInfo

Parameters

task⇔	The task to return the details of.
lasn←	The task to return the details of.

Returns

xTaskInfo The xTaskInfo structure containing the task details. xTaskGetTaskInfo() returns null if the task cannot be found.

Warning

The memory allocated by xTaskGetTaskInfo() must be freed by xMemFree().

```
4.2.5.36 xTaskGetTaskRunTimeStats() xTaskRunTimeStats xTaskGetTaskRunTimeStats ( xTask task_)
```

The xTaskGetTaskRunTimeStats() system call returns the task runtime statistics for one task. The xTaskGetTaskRunTimeStats() system call returns the xTaskRunTimeStats type. The memory must be freed by calling xMemFree() after it is no longer needed.

See also

```
xTaskRunTimeStats
xMemFree()
```

Parameters

task⇔	The task to get the runtime statistics for.

Returns

xTaskRunTimeStats The runtime stats returned by xTaskGetTaskRunTimeStats(). xTaskGetTaskRunTimeStats() will return null of the task cannot be found.

Warning

The memory allocated by xTaskGetTaskRunTimeStats() must be freed by xMemFree().

```
4.2.5.37 xTaskGetTaskState() xTaskState xTaskGetTaskState ( xTask task_)
```

The xTaskGetTaskState() system call will return the state of the task.

See also

xTaskState

Parameters

task⇔	The task to return the state of.

Returns

xTaskState The xTaskState of the task. If the task cannot be found, xTaskGetTaskState() will return null.

```
4.2.5.38 xTaskNotificationIsWaiting() xBase xTaskNotificationIsWaiting ( xTask \ task )
```

The xTaskNotificationIsWaiting() system call will return true or false depending on whether there is a direct to task notification waiting for the task.

Parameters

task⊷	The task to check for a waiting task notification.

Returns

xBase Returns true if there is a task notification. False if there is no notification or if the task could not be found.

The xTaskNotifyGive() system call will give a direct to task notification to the specified task. The task notification bytes is the number of bytes contained in the notification value. The number of notification bytes must be between one and the CONFIG_NOTIFICATION_VALUE_BYTES setting. The notification value must contain a pointer to a char array containing the notification value. If the task already has a waiting task notification, xTaskNotifyGive() will NOT overwrite the waiting task notification. xTaskNotifyGive() will return true if the direct to task notification was successfully given.

See also

```
CONFIG_NOTIFICATION_VALUE_BYTES 
xTaskNotifyTake()
```

Parameters

task_	The task to send the task notification to.
notification⊷ Bytes_	The number of bytes contained in the notification value. The number must be between one and the CONFIG_NOTIFICATION_VALUE_BYTES setting.
notification <i>⊷</i> Value_	A char array containing the notification value. The notification value is NOT a null terminated string.

Returns

xBase RETURN_SUCCESS if the direct to task notification was successfully given, RETURN_FAILURE if not.

The xTaskNotifyStateClear() system call will clear a waiting direct to task notification if one exists without returning the notification.

Parameters

task⊷	The task to clear the notification for.

```
4.2.5.41 xTaskNotifyTake() xTaskNotification xTaskNotifyTake ( xTask \ task )
```

The xTaskNotifyTake() system call will return the waiting direct to task notification if there is one. The xTaskNotifyTake() system call will return an xTaskNotification structure containing the notification bytes and its value. The memory allocated by xTaskNotifyTake() must be freed by xMemFree().

See also

```
xTaskNotification
xTaskNotifyGive()
xMemFree()
CONFIG NOTIFICATION VALUE BYTES
```

Parameters

task⇔	The task to return a waiting task notification.
_	

Returns

xTaskNotification The xTaskNotification structure containing the notification bytes and value. xTaskNotifyTake() will return null if no waiting task notification exists or if the task cannot be found.

Warning

The memory allocated by xTaskNotifyTake() must be freed by xMemFree().

The xTaskResetTimer() system call will reset the task timer. xTaskResetTimer() does not change the timer period or the task state when called. See xTaskChangePeriod() for more details on task timers.

See also

```
xTaskWait()
xTaskChangePeriod()
xTaskGetPeriod()
```

Parameters

task⊷	The task to reset the task timer for.
_	

4.2.5.43 xTaskResume() void xTaskResume (xTask task_)

The xTaskResume() system call will resume a suspended task. Tasks are suspended on creation so either xTaskResume() or xTaskWait() must be called to place the task in a state that the scheduler will execute.

See also

```
xTaskState
xTaskSuspend()
xTaskWait()
```

Parameters

task⇔	The task to set its state to running.
_	

```
4.2.5.44 xTaskResumeAll() void xTaskResumeAll ( void )
```

The xTaskResumeAll() system call will set the scheduler state to running so the next call to xTaskStartScheduler() will resume execute of all tasks. The state of each task is not altered by xTaskSuspendAll() or xTaskResumeAll().

See also

xTaskSuspendAll()

```
4.2.5.45 xTaskStartScheduler() void xTaskStartScheduler ( void )
```

The xTaskStartScheduler() system call passes control to the HeliOS scheduler. This system call will not return until xTaskSuspendAll() is called. If xTaskSuspendAll() is called, xTaskResumeAll() must be called before xTaskStartScheduler() can be called again to continue executing tasks.

```
4.2.5.46 xTaskSuspend() void xTaskSuspend ( xTask task_ )
```

The xTaskSuspend() system call will suspend a task. A task that has been suspended will not be executed by the scheduler until xTaskResume() or xTaskWait() is called.

See also

xTaskState

xTaskResume()

xTaskWait()

Parameters

task⇔	The task to suspend.

```
4.2.5.47 xTaskSuspendAll() void xTaskSuspendAll ( void )
```

The xTaskSuspendAll() system call will set the scheduler state to suspended so the scheduler will stop and return. The state of each task is not altered by xTaskSuspendAll() or xTaskResumeAll().

See also

xTaskResumeAll()

The xTaskWait() system call will place a task in the waiting state. A task must be in the waiting state for event driven multitasking with either direct to task notifications OR setting the period on the task timer with xTaskChangePeriod(). A task in the waiting state will not be executed by the scheduler until an event has occurred.

See also

xTaskState xTaskResume() xTaskSuspend()

task⇔	The task to place in the waiting state.

The xTimerChangePeriod() system call will change the period of the specified timer. The timer period is measured in ticks. If the timer period is zero, the xTimerHasTimerExpired() system call will always return false.

See also

xTimerHasTimerExpired()

Parameters

timer_	The timer to change the period for.
timer←	The timer period in is ticks. Timer period must be zero or greater.
Period_	

4.2.5.50 xTimerCreate() xTimer xTimerCreate (xTicks *timerPeriod*_)

The xTimerCreate() system call will create a new timer. Timers differ from task timers in that they do not create events that effect the scheduling of a task. Timers can be used by tasks to initiate various task activities based on a specified time period represented in ticks. The memory allocated by xTimerCreate() must be freed by xTimerDelete(). Unlike tasks, timers may be created and deleted within tasks.

See also

xTimer

xTimerDelete()

Parameters

timer←	The number of ticks before the timer expires.
Period_	

Returns

xTimer The newly created timer. If the timer period parameter is less than zero or xTimerCreate() was unable to allocate the required memory, xTimerCreate() will return null.

Warning

The timer memory can only be freed by xTimerDelete().

The xTimerDelete() system call will delete a timer. For more information on timers see the xTaskTimerCreate() system call.

See also

xTimerCreate()

Parameters

timer⇔	The timer to be deleted.

4.2.5.52 xTimerGetPeriod() xTicks **x**TimerGetPeriod (**x**Timer *timer_*)

The xTimerGetPeriod() system call will return the current timer period for the specified timer.

Parameters

timer←	The timer to get the timer period for.

Returns

xTicks The timer period. If the timer cannot be found, xTimerGetPeriod() will return zero.

```
4.2.5.53 xTimerHasTimerExpired() xBase xTimerHasTimerExpired ( xTimer\ timer\_)
```

The xTimerHasTimerExpired() system call will return true or false dependent on whether the timer period for the specified timer has elapsed. xTimerHasTimerExpired() will NOT reset the timer. Timers will not automatically reset. Timers MUST be reset with xTimerReset().

See also

xTimerReset()

timer⇔	The timer to determine if the period has expired.
_	

Returns

xBase True if the timer has expired, false if the timer has not expired or could not be found.

```
4.2.5.54 xTimerIsTimerActive() xBase xTimerIsTimerActive ( xTimer\ timer\_)
```

The xTimerlsTimerActive() system call will return true of the timer has been started with xTimerStart().

See also

xTimerStart()

Parameters

timer⊷	The timer to check if active.
_	

Returns

xBase True if active, false if not active or if the timer could not be found.

```
4.2.5.55 xTimerReset() void xTimerReset ( xTimer\ timer_)
```

The xTimerReset() system call will reset the start time of the timer to zero.

Parameters

timer←	The timer to be reset.
_	

The xTimerStart() system call will place the timer in the running (active) state. Neither xTimerStart() nor xTimerStop() will reset the timer. Timers can only be reset with xTimerReset().

See also

```
xTimerStop()
xTimerReset()
```

Parameters

timer←	The timer to be started.
_	

```
4.2.5.57 xTimerStop() void xTimerStop ( xTimer timer_ )
```

See also

```
xTimerStart()
xTimerReset()
```

Parameters

timer⇔	The timer to be stopped.

Index

SystemAssert	TaskStateWaiting, 28
HeliOS.h, 28	Ticks_t, 21
	Timer_t, 21
Addr_t	Word_t, 22
HeliOS.h, 18	xAddr, 22
	xBase, 22
Base_t	xMemAlloc, 28
HeliOS.h, 18	xMemFree, 29
	xMemGetHeapStats, 30
config.h, 9	xMemGetKernelStats, 30
CONFIG_MEMORY_REGION_BLOCK_SIZE, 10	xMemGetSize, 30
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS,	xMemGetUsed, 31
10	xMemoryRegionStats, 22
CONFIG_MESSAGE_VALUE_BYTES, 10	
CONFIG_NOTIFICATION_VALUE_BYTES, 11	xQueue, 23
CONFIG_QUEUE_MINIMUM_LIMIT, 11	xQueueCreate, 31
CONFIG_TASK_NAME_BYTES, 12	xQueueDelete, 32
CONFIG_MEMORY_REGION_BLOCK_SIZE	xQueueDropMessage, 32
config.h, 10	xQueueGetLength, 32
CONFIG_MEMORY_REGION_SIZE_IN_BLOCKS	xQueuelsQueueEmpty, 33
config.h, 10	xQueuelsQueueFull, 33
CONFIG_MESSAGE_VALUE_BYTES	xQueueLockQueue, 33
config.h, 10	xQueueMessage, 23
CONFIG NOTIFICATION VALUE BYTES	xQueueMessagesWaiting, 34
config.h, 11	xQueuePeek, 34
CONFIG_QUEUE_MINIMUM_LIMIT	xQueueReceive, 35
config.h, 11	xQueueSend, 35
CONFIG_TASK_NAME_BYTES	xQueueUnLockQueue, 36
	xSchedulerState, 23
config.h, 12	xSize, 24
DEREF TASKPARM	xSystemGetSystemInfo, 36
HeliOS.h, 17	xSystemHalt, 36
1101100.11, 17	xSystemInfo, 24
HeliOS.h, 12	xSystemInit, 37
SystemAssert, 28	xTask, 24
	xTaskChangePeriod, 37
Base_t, 18	xTaskCreate, 37
DEREF_TASKPARM, 17	xTaskDelete, 38
MemoryRegionStats_t, 18	xTaskGetAllRunTimeStats, 38
	xTaskGetAllTaskInfo, 39
Queue_t, 18 QueueMessage_t, 18	xTaskGetHandleById, 39
	xTaskGetHandleByName, 40
SchedulerState_t, 27	xTaskGetId, 40
SchedulerStateError, 27	xTaskGetName, 40
SchedulerStateRunning, 27	
SchedulerStateSuspended, 27	xTaskGetNumberOfTasks, 41
Size_t, 19	xTaskGetPeriod, 41
SystemInfo_t, 19	xTaskGetSchedulerState, 42
Task_t, 19	xTaskGetTaskInfo, 42
TaskInfo_t, 20	xTaskGetTaskRunTimeStats, 43
TaskNotification_t, 20	xTaskGetTaskState, 43
TaskParm_t, 20	xTaskInfo, 24
TaskRunTimeStats_t, 21	xTaskNotification, 25
TaskState_t, 27	xTaskNotificationIsWaiting, 44
TaskStateError, 28	xTaskNotifyGive, 44
TaskStateRunning, 28	xTaskNotifyStateClear, 45
TaskStateSuspended, 28	xTaskNotifyTake, 45

54 INDEX

xTaskParm, 25	messageBytes, 3
xTaskResetTimer, 45	messageValue, 4
xTaskResume, 46	QueueMessage_t
xTaskResumeAll, 46	HeliOS.h, 18
xTaskRunTimeStats, 25	
xTaskStartScheduler, 46	SchedulerState_t
xTaskState, 26	HeliOS.h, 27
xTaskSuspend, 47	SchedulerStateError
xTaskSuspendAll, 47	HeliOS.h, 27
xTaskWait, 47	SchedulerStateRunning
xTicks, 26	HeliOS.h, 27
xTimer, 26	SchedulerStateSuspended
xTimerChangePeriod, 48	HeliOS.h, 27
xTimerGreate, 48	Size_t
xTimer Greate, 40 xTimer Delete, 49	HeliOS.h, 19
	state
xTimerGetPeriod, 49	TaskInfo_s, 6
xTimerHasTimerExpired, 49	SystemInfo_s, 4
xTimerIsTimerActive, 50	majorVersion, 4
xTimerReset, 50	minorVersion, 5
xTimerStart, 50	
xTimerStop, 51	numberOfTasks, 5
xWord, 27	patchVersion, 5
tul	productName, 5
id T. I. ()	SystemInfo_t
TaskInfo_s, 6	HeliOS.h, 19
TaskRunTimeStats_s, 8	Table 4
lastRunTime	Task_t
	HeliOS.h, 19
TaskInfo_s, 6	TaskInfo_s, 5
TaskRunTimeStats_s, 8	id, 6
major//arajan	lastRunTime, 6
majorVersion	name, 6
SystemInfo_s, 4	state, 6
MemoryRegionStats_s, 2	totalRunTime, 6
MemoryRegionStats_t	TaskInfo_t
HeliOS.h, 18	HeliOS.h, 20
messageBytes	TaskNotification_s, 7
QueueMessage_s, 3	notificationBytes, 7
messageValue	notificationValue, 7
QueueMessage_s, 4	TaskNotification t
minorVersion	HeliOS.h, 20
SystemInfo_s, 5	TaskParm t
	HeliOS.h, 20
name	TaskRunTimeStats_s, 8
TaskInfo_s, 6	id, 8
notificationBytes	lastRunTime, 8
TaskNotification_s, 7	totalRunTime, 8
notificationValue	TaskRunTimeStats t
TaskNotification_s, 7	HeliOS.h, 21
numberOfTasks	
SystemInfo_s, 5	TaskState_t
	HeliOS.h, 27
patchVersion	TaskStateError
SystemInfo_s, 5	HeliOS.h, 28
productName	TaskStateRunning
SystemInfo_s, 5	HeliOS.h, 28
	TaskStateSuspended
Queue_t	HeliOS.h, 28
HeliOS.h, 18	TaskStateWaiting
QueueMessage_s, 3	HeliOS.h, 28

INDEX 55

Ticks_t	xSize
HeliOS.h, 21	HeliOS.h, 24
Timer_t	xSystemGetSystemInfo
HeliOS.h, 21	HeliOS.h, 36
totalRunTime	xSystemHalt
TaskInfo_s, 6	HeliOS.h, 36
TaskRunTimeStats_s, 8	xSystemInfo
radik tarrimootato_d, o	HeliOS.h, 24
Word_t	xSystemInit
HeliOS.h, 22	-
1101100.11, 22	HeliOS.h, 37
xAddr	xTask
HeliOS.h, 22	HeliOS.h, 24
xBase	xTaskChangePeriod
	HeliOS.h, 37
HeliOS.h, 22 xMemAlloc	xTaskCreate
	HeliOS.h, 37
HeliOS.h, 28	xTaskDelete
xMemFree	HeliOS.h, 38
HeliOS.h, 29	xTaskGetAllRunTimeStats
xMemGetHeapStats	HeliOS.h, 38
HeliOS.h, 30	xTaskGetAllTaskInfo
xMemGetKernelStats	HeliOS.h, 39
HeliOS.h, 30	xTaskGetHandleById
xMemGetSize	HeliOS.h, 39
HeliOS.h, 30	
xMemGetUsed	xTaskGetHandleByName
HeliOS.h, 31	HeliOS.h, 40
xMemoryRegionStats	xTaskGetId
HeliOS.h, 22	HeliOS.h, 40
xQueue	xTaskGetName
	HeliOS.h, 40
HeliOS.h, 23	xTaskGetNumberOfTasks
xQueueCreate	HeliOS.h, 41
HeliOS.h, 31	xTaskGetPeriod
xQueueDelete	HeliOS.h, 41
HeliOS.h, 32	xTaskGetSchedulerState
xQueueDropMessage	HeliOS.h, 42
HeliOS.h, 32	xTaskGetTaskInfo
xQueueGetLength	HeliOS.h, 42
HeliOS.h, 32	xTaskGetTaskRunTimeStats
xQueuelsQueueEmpty	HeliOS.h, 43
HeliOS.h, 33	xTaskGetTaskState
xQueuelsQueueFull	HeliOS.h, 43
HeliOS.h, 33	xTaskInfo
xQueueLockQueue	
HeliOS.h, 33	HeliOS.h, 24
xQueueMessage	xTaskNotification
HeliOS.h, 23	HeliOS.h, 25
xQueueMessagesWaiting	xTaskNotificationIsWaiting
HeliOS.h, 34	HeliOS.h, 44
xQueuePeek	xTaskNotifyGive
	HeliOS.h, 44
HeliOS.h, 34	xTaskNotifyStateClear
xQueueReceive	HeliOS.h, 45
HeliOS.h, 35	xTaskNotifyTake
xQueueSend	HeliOS.h, 45
HeliOS.h, 35	
	xTaskParm
xQueueUnLockQueue	xTaskParm HeliOS.h, 25
HeliOS.h, 36	HeliOS.h, 25
	HeliOS.h, 25 xTaskResetTimer
HeliOS.h, 36	HeliOS.h, 25

56 INDEX

xTaskResume HeliOS.h, 46 xTaskResumeAll HeliOS.h, 46 xTaskRunTimeStatsHeliOS.h, 25 xTaskStartScheduler HeliOS.h, 46 xTaskState HeliOS.h, 26 xTaskSuspend HeliOS.h, 47 xTaskSuspendAll HeliOS.h, 47 xTaskWait HeliOS.h, 47 xTicks HeliOS.h, 26 xTimer HeliOS.h, 26 xTimerChangePeriod HeliOS.h, 48 xTimerCreate HeliOS.h, 48 xTimerDelete HeliOS.h, 49 xTimerGetPeriod HeliOS.h, 49 xTimerHasTimerExpired HeliOS.h, 49 xTimerIsTimerActive HeliOS.h, 50 xTimerReset HeliOS.h, 50 xTimerStartHeliOS.h, 50 xTimerStop HeliOS.h, 51 xWord

HeliOS.h, 27