

MTU_ValueService **Technical Documentation**

Diesel engine
12 V 4000 G21R
12 V 4000 G41R

Operating Instructions
MS150065/01E



Printed in Germany

© 2011 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Commissioning Note

Important

Please complete and return the “Commissioning Note” card below to MTU Friedrichshafen GmbH.

The Commissioning Note information serves as a basis for the contractually agreed logistic support (warranty, spare parts, etc.).



Postcard
MTU Friedrichshafen GmbH
Technical Information Management
Dept. VOT
88040 Friedrichshafen
GERMANY

Commissioning Note

Please use block capitals!



Engine No.:	MTU works order no.:
Engine model:	Date put into operation:
Application : * ☐ Marine ☐ Rail ☐ Genset ☐	Type : Manufacturer:
End user`s address:	
Remarks:	

**Commissioning
Note**

Tick appropriate box

1	Safety	9
1.1	General regulations	9
1.2	Personnel and organizational requirements	10
1.3	Transport.....	11
1.4	Crankshaft transport locking device	12
1.5	Safety precautions when working on the engine.....	15
1.6	Fluids and lubricants, fire prevention and environmental protection.....	17
1.7	Standards for safety notices in the publication.....	19
2	Product Summary.....	21
2.1	Engine Layout.....	21
2.1.1	Engine layout.....	21
2.2	Engine Side and Cylinder Designations.....	23
2.2.1	Engine side and cylinder designations.....	23
2.3	Main Engine Dimensions.....	24
2.3.1	Main engine dimensions	24
2.4	Firing Sequence.....	25
2.4.1	Firing order	25
2.5	Final Compression Pressure.....	26
2.5.1	Final compression pressure	26
2.6	Technical Data.....	27
2.6.1	12V 4000 engine data, short-time operation, 3D, optimized fuel consumption.....	27
2.6.2	12V 4000 engine data, short-time operation, 3D, emissions optimized w/o certificate	30
3	Operation.....	33
3.1	Putting the engine into operation after extended out-of-service periods (>3 months).....	33
3.2	Putting the engine into operation after scheduled out-of-service-period	34
3.3	Start engine in manual mode (testing mode).....	35
3.4	Starting the engine in emergency situations (override mode).....	36
3.5	Operational checks.....	37
3.6	Stop engine in manual mode (testing mode).....	38
3.7	Emergency stop.....	39
3.8	After stopping the engine – Engine remains ready for operation.....	40
3.9	After stopping the engine – putting the engine out of service	41
3.10	Plant – Cleaning.....	42
4	Maintenance.....	43
4.1	Maintenance task reference table [QL1]	43

5	Troubleshooting	45
5.1	Troubleshooting	45
5.2	Fault messages on engine governor	48
6	Task Description	59
6.1	Engine	59
6.1.1	Engine – Barring manually	59
6.1.2	Engine – Barring with starting system	60
6.1.3	Engine – Test run	61
6.2	Cylinder Liner	62
6.2.1	Cylinder liner – Endoscopic examination	62
6.2.2	Instructions and comments on endoscopic and visual examination of cylinder liners	64
6.3	Crankcase Breather	65
6.3.1	Crankcase breather – Oil separator replacement, diaphragm check and replacement	65
6.4	Valve Drive	67
6.4.1	Valve gear – Lubrication	67
6.4.2	Valve clearance – Check and adjustment	68
6.4.3	Cylinder head cover – Removal and installation	71
6.5	Injection Pump / HP Pump	72
6.5.1	HP pump – Relief bore check	72
6.6	Injection Valve / Injector	73
6.6.1	Injector – Replacement	73
6.6.2	Injector – Removal and installation	74
6.7	Fuel System	80
6.7.1	Fuel system – Venting	80
6.8	Fuel Filter	81
6.8.1	Fuel filter – Replacement	81
6.8.2	Fuel prefilter cleaning	82
6.8.3	Fuel prefilter – Differential pressure gauge check and adjustment	83
6.8.4	Fuel prefilter – Draining	84
6.8.5	Fuel prefilter – Flushing	86
6.8.6	Fuel prefilter – Filter element replacement	88
6.9	Charge-Air Cooling	90
6.9.1	Intercooler – Check drain for coolant leakage and obstruction	90
6.10	Air Filter	91
6.10.1	Air filter – Replacement	91
6.10.2	Air filter – Removal and installation	92
6.11	Air Intake	93
6.11.1	Service indicator - Signal ring position check	93
6.12	Starting Equipment	94
6.12.1	Air starter – Manual operation	94

6.12.2	Starter – Condition check.....	95
6.13	Lube Oil System, Lube Oil Circuit.....	96
6.13.1	Engine oil – Level check.....	96
6.13.2	Engine oil – Change.....	97
6.13.3	Engine oil – Sample extraction and analysis.....	99
6.14	Oil Filtration / Cooling.....	100
6.14.1	Engine oil filter – Replacement.....	100
6.14.2	Centrifugal oil filter – Cleaning and filter sleeve replacement.....	101
6.15	Coolant Circuit, General, High-Temperature Circuit.....	103
6.15.1	Coolant – Level check.....	103
6.15.2	Engine coolant – Change.....	104
6.15.3	Engine coolant – Draining.....	105
6.15.4	Engine coolant – Filling.....	106
6.15.5	Engine coolant pump – Relief bore check.....	109
6.15.6	Coolant – Sample extraction and analysis.....	110
6.16	Low-Temperature Circuit.....	111
6.16.1	Charge-air coolant – Level check.....	111
6.16.2	Charge-air coolant – Change.....	112
6.16.3	Charge-air coolant – Draining.....	113
6.16.4	Charge-air coolant – Filling.....	114
6.16.5	Charge-air coolant – Sample extraction and analysis.....	118
6.16.6	Charge-air coolant pump – Relief bore check.....	119
6.17	Belt Drive.....	120
6.17.1	Drive belt – Condition check.....	120
6.18	Battery-Charging Generator.....	121
6.18.1	Battery-charging generator drive – Drive belt tension adjustment.....	121
6.18.2	Battery-charging generator drive – Drive belt tension check.....	122
6.18.3	Battery-charging generator drive – Drive belt replacement.....	123
6.19	Engine Mounting / Support.....	124
6.19.1	Engine/generator mounting security check.....	124
6.20	Wiring (General) for Engine/Gearbox/Unit.....	125
6.20.1	Engine wiring – Check.....	125
6.21	Accessories for (Electronic) Engine Governor / Control System.....	126
6.21.1	Engine control unit and connectors – Cleaning.....	126
6.21.2	Engine governor plug-in connections – Check.....	128
7	Appendix A.....	129
7.1	MTU contacts/service partners.....	129
7.2	Abbreviations.....	130
8	Appendix B.....	133
8.1	Special Tools.....	133
8.2	Consumables.....	135
8.3	Spare Parts.....	136

8.4	Index.....	137
-----	------------	-----

1 Safety

1.1 General regulations

General

In addition to the instructions in this publication, the applicable country-specific legislation and other compulsory regulations regarding accident prevention must be observed. This MTU engine is a state-of-the-art product and conforms with all the applicable specifications and regulations. Nevertheless, persons and property may be at risk in the event of:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the Safety Instructions

Correct use

The engine is intended exclusively for the application specified in the contract or defined at the time of delivery. Any other use is considered improper use. The engine manufacturer accepts no liability whatsoever for resultant damage or injury in such case. The responsibility is borne by the user alone.

Correct use also includes observation of and compliance with the maintenance specifications.

Modifications or conversions

Unauthorized engine modifications compromise safety.

MTU will accept no liability or warranty claims for any damage caused by unauthorized modifications or conversions.

Spare parts

Only genuine MTU spare parts must be used to replace components or assemblies. The engine manufacturer accepts no liability whatsoever for damage or injury resulting from the use of other spare parts and the warranty shall be voided in such case.

Reworking components

Repair or engine overhaul must be carried out in workshops authorized by MTU.

1.2 Personnel and organizational requirements

Personnel requirements

Work on the engine must only be carried out by appropriately qualified and instructed personnel.

Observe the minimum legal age.

Responsibilities of the operating, maintenance and repair personnel must be specified by the operating company.

Organizational measures

This publication must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep it handy in the vicinity of the engine such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Use the manual as a basis for instructing personnel on engine operation and repair. In particular, personnel must have read and understood the safety-relevant instructions.

This is especially important for personnel who work on the engine only on an occasional basis. These persons shall receive repeated instruction.

Use the Spare Parts Catalog to identify spare parts during maintenance and repair work.

Working clothes and protective equipment

Wear proper protective clothing for all work.

Depending on the kind of work, use the necessary personal protective equipment.