

Title: Nautilus_Mainboard

Sheet: /STM/

Rev: 0

Author: Evan


Date: 2025-11-19

Size: A4

Id: 2/20

File: STM.kicad_sch

1 2 3 4 5 6



1 2 3 4 5 6

A

A

B

B

C

C

D

D

A

A

B

B


C

C

D

D

Not in the PCB yet as we dont know if we actually need it.



Title: Nautilus_Mainboard

Sheet: /Piezzo/
Rev: 0

Author: Evan


Date: 2025-11-19


Size: A4


Id: 4/20

File: Piezzo.kicad_sch

1 2 3 4 5 6







Title: Nautilus_Mainboard

Sheet: /IMU/

Rev: 0


Author: Davide


Date: 2025-11-19


Size: A4

Id: 18/20

File: IMU.kicad_sch







Title: Nautilus_Mainboard

Sheet: /STM/CAN_Interface/

Rev: 1




Author: Evan & Davide

Date: 2025-11-19

Id: 7/20

File: PowerSTM.kicad_sch

A



WIP, nRPI_BOOT? power only to certain parts? -> Diode (later) indication? (YES! LED)



Title: Nautilus_Mainboard

Sheet: /CM4/CM4_Module1B/

Rev: 0

Author: Davide



Date: 2025-11-19

Size: A4

Id: 11/20

File: CM4_Module1B.kicad_sch

212x



if the USB-only cold start "disconnects" we can try to bump SS to 470nF instead of 330nF.

Pins	MIN	MAX	UNIT
V _{IN1} , V _{IN2} , V _{OUT}	-0.3	24	V
V _{OV1} , V _{OV2}	-0.3	6	V
V _{PRI} , V _{SEL}	-0.3	6	V
V _{ST}	-0.3	6	V
I _{OUT}			Internally Limited
T _{J, MAX}			Internally Limited
T _{STG}	-65	150	°C

Figure 6-2. TPS2121 (RUX) Package 12-Pin VQFN-HR Bottom View

Pin Functions			
NAME	TPS2120	TPS2121	IO
IN1	B1, B2, C1	7	I Power Input for Source 1
IN2	B3, B4, C2	2	I Power Input for Source 2
OUT	C2, C3, D1, 1, 8	I	I Power Output
ST	E1, E2	9	O Status output indicating which channel is selected. Connect to GND if not required.
ILIM	E2	10	I Output Current Limiting for both channels.
SS	E3	11	O Adjusts Input Setting Delay Time and Output Soft Start Time.
GND	E4	12	— Device Ground
PR1	A1	6	I Enables Comparator Operation. Connect to IN1 to set switchover voltage. Connect to GND if not required.
OV1	A2	5	I Active Low Enable Supervisor for IN1 Overvoltage Protection. Connect to GND if not required.
OV2	A3	4	I Active Low Enable Supervisor for IN2 Overvoltage Protection. Connect to GND if not required.
SEL	A4	—	I Allows GPO to override priority operation and manually select IN2. TPS2120 only.

CP2 — 3 I Enables Comparator Operation and is compared to PR1 to set switchover voltage. Connect to GND if not required. TPS2120 only.



Title: Nautilus_Mainboard

Sheet: /Power_logic/5V_Logic/

Rev: 0


Author: Davide


Date: 2025-11-19

Size: A4

Id: 12/20

File: 5V_Logic.kicad_sch





1 2 3 4 5 6

A

A

B



B

C

C

D

D



1 2 3 4 5 6

A

A

B


B

C

C

D

D



Title: Nautilus_Mainboard

Sheet: /IMU/IMU1/

Rev: 0

Author: Davide

Date: 2025-11-19

Size: A4

Id: 19/20

File: IMU1.kicad_sch

1 2 3 4 5 6

A

A

B


B

C

C

D

D



Title: Nautilus_Mainboard

Sheet: /IMU/IMU2/

Rev: 0

Author: Davide

Date: 2025-11-19


Size: A4

Id: 20/20

File: IMU2.kicad_sch


A

A



A

A



B

B

C

C

D

D

**Title: Nautilus_Mainboard**

Sheet: /CM4/CM4_Module1A/CM4_LED2/

Rev: 0

Author: Davide

Date: 2025-11-19


Size: A4

Id: 9/20

File: CM4_LED2.kicad_sch

A

A



B

B

C

C

D

D



Title: Nautilus_Mainboard

Sheet: /CM4/CM4_Module1A/CM4_Ethernet/

Rev: 0

Author: Davide

Date: 2025-11-19

Size: A4

Id: 10/20

File: CM4_Ethernet.kicad_sch