

Manage AWS KMS

ONTAP 9.12.1 REST API reference

NetApp February 13, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9121/ontap/security_aws-kms_endpoint_overview.html on February 13, 2024. Always check docs.netapp.com for the latest.

Table of Contents

Ma	anage AWS KMS	1
	Security aws-kms endpoint overview	1
	Retrieve all AWS KMS instances configured for all clusters and SVMs	7
	Configure the AWS KMS configuration for an SVM	. 18
	Re-key or re-version an AWS KMS key encryption key for AWS KMS	32
	Re-key SVM KEK for an AWS KMS	. 37
	Restore keys for an SVM from a configured AWS KMS	40
	Delete an AWS KMS configuration	43
	Retrieve an AWS KMS configuration	46
	Update an AWS KMS configuration	. 54

Manage AWS KMS

Security aws-kms endpoint overview

Overview

Amazon Web Services Key Management Services (AWS KMS) is a cloud key management service (KMS) that provides a secure store for secrets. This feature allows ONTAP to securely store its encryption keys using AWS KMS. In order to use AWS KMS with ONTAP, you must first create a Customer Master Key (CMK) in AWS KMS and provide an Access Key ID and Secret Access Key for a user that has appropriate access to the newly created CMK in the AWS KMS."

Examples

Enabling AWS KMS for an SVM

The following example shows how to enable AWS KMS at the SVM-scope. Note the *return_records=true* query parameter is used to obtain the newly created key manager configuration.

```
# The API:
POST /api/security/aws-kms
# The call:
curl -X POST 'https://<mgmt-ip>/api/security/aws-kms?return records=true'
-H 'accept: application/hal+json' -d '{"svm":{"uuid":"f36ff553-e713-11ea-
bd56-005056bb4222" }, "region": "us-east-1", "key id": "kmip-aws",
"access key id": "AK7ATC35ZXU6GKUDQURT", "secret access key": "Ahrut-
#ghty5-881Ht"}'
# The response:
"num records": 1,
"records": [
    "uuid": "f72098a2-e908-11ea-bd56-005056bb4222",
    "svm": {
        "uuid": "f36ff553-e713-11ea-bd56-005056bb4222",
        "name": "vs0"
    },
    "region": "us-east-1",
    "key id": "kmip-aws",
    "access key id": "AK7ATC35ZXU6GKUDQURT",
    " links": {
        "self": {
        "href": "/api/security/aws-kms/f72098a2-e908-11ea-bd56-
005056bb4222"
        }
    }
]
}
```

Retrieving all AWS KMS configurations

The following example shows how to retrieve all AWS KMS configurations.

```
# The API:
GET /api/security/aws-kms
# The call:
curl -X GET 'https://<mgmt-ip>/api/security/aws-kms?fields=*'
# The response:
"records": [
    "uuid": "f72098a2-e908-11ea-bd56-005056bb4222",
    "scope": "svm",
    "svm": {
        "uuid": "f36ff553-e713-11ea-bd56-005056bb4222",
        "name": "vs0"
    },
    "region": "us-east-1",
    "key id": "kmip-aws",
    "access key id": "AK7ATC35ZXU6GKUDQURT",
    "service": "KMS",
    "default domain": "amazonaws.com",
    "polling period": 60,
    "timeout": 10,
    " links": {
        "self": {
        "href": "/api/security/aws-kms/f72098a2-e908-11ea-bd56-
005056bb4222"
        }
    }
],
"num records": 1,
" links": {
    "self": {
    "href": "/api/security/aws-kms?fields=*"
}
}
```

Retrieving a specific AWS KMS configuration

The following example shows how to retrieve information for a specific AWS KMS configuration.

```
# The API:
GET /api/security/aws-kms/{uuid}
# The call:
curl -X GET 'https://<mgmt-ip>/api/security/aws-kms/f72098a2-e908-11ea-
bd56-005056bb4222?fields=*'
# The response:
{
"uuid": "f72098a2-e908-11ea-bd56-005056bb4222",
"scope": "svm",
"svm": {
    "uuid": "f36ff553-e713-11ea-bd56-005056bb4222",
    "name": "vs0"
},
"region": "us-east-1",
"key id": "kmip-aws",
"access key id": "AK7ATC35ZXU6GKUDQURT",
"service": "KMS",
"default domain": "amazonaws.com",
"polling period": 60,
"timeout": 10,
" links": {
    "self": {
    "href": "/api/security/aws-kms/f72098a2-e908-11ea-bd56-005056bb4222"
}
}
```

Retrieving the advanced properties of an AWS configured for a specific SVM

These values are not retrieved by default with the 'fields=*' option. The following example retrieves the advanced properties of a configured AWS for a specific SVM; there is an added computational cost in retrieving their values. The properties are not populated for either a collection GET or an instance GET unless they are explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

```
# The API:
GET /api/security/aws-kms

# The call:
curl -X GET 'https://<mgmt-ip>/api/security/aws-kms/7052c6c0-a503-11ec-a68f-005056ac75a0/?fields=state,amazon_reachability,ekmip_reachability'

# The response:
```

```
"uuid": "d70efc34-aa13-11ec-a059-005056ac7c32",
"state": {
  "cluster state": true,
  "message": "",
 "code": "0"
},
"amazon reachability": {
  "reachable": true,
 "message": "",
 "code": "0"
} ,
"ekmip reachability": [
    "reachable": true,
    "message": "",
    "code": "0",
    "node": {
      "uuid": "817f544f-a98d-11ec-ae20-005056ac7c32",
      "name": "node1",
      " links": {
          "href": "/api/cluster/nodes/817f544f-a98d-11ec-ae20-
005056ac7c32"
   }
  },
    "reachable": true,
    "message": "",
    "code": "0",
    "node": {
      "uuid": "84b3f5f3-a98d-11ec-9ff4-005056acfbfe",
      "name": "node2",
      " links": {
        "self": {
          "href": "/api/cluster/nodes/84b3f5f3-a98d-11ec-9ff4-
005056acfbfe"
        }
      }
   }
  }
],
" links": {
 "self": {
```

```
"href": "/api/security/aws-kms/d70efc34-aa13-11ec-a059-005056ac7c32"
}
}
}
```

Updating the "access_key_id" of a specific AWS KMS configuration

The following example shows how to update the "access key id" for a specific AWS KMS configuration.

Updating a specific AWS KMS configuration to allow it to use a proxy.

The following example shows how to update a specific AWS KMS configuration to allow the AWS KMS instance to use a proxy.

```
# The API:
PATCH /api/security/aws-kms/{uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/security/aws-kms/f72098a2-e908-11ea-bd56-005056bb4222/' -d '{"default_domain": "216.9", "host":
"172.20.216.9", "port": 8000, "service": "10", "verify_host": false,
"verify_ip": false}'
```

Deleting a specific AWS KMS configuration

The following example shows how to delete a specific AWS KMS configuration.

```
# The API:
DELETE /api/security/aws-kms/{uuid}

# The call;
curl -X DELETE 'https://<mgmt-ip>/api/security/aws-kms/f72098a2-e908-11ea-bd56-005056bb4222'
```

Restoring keys from a KMIP server

The following example shows how to restore keys for a AWS KMS configuration.

```
# The API:
POST /api/security/aws-kms/{uuid}/restore

# The call:
curl -X POST 'https://<mgmt-ip>/api/security/aws-kms/33820b57-ec90-11ea-
875e-005056bbf3f0/restore'
```

Retrieve all AWS KMS instances configured for all clusters and SVMs

GET /security/aws-kms

Introduced In: 9.12

Retrieves all AWS KMS instances configured for all clusters and SVMs.

Related ONTAP commands

- security key-manager external aws show
- ullet security key-manager external aws check

Parameters

Name	Туре	In	Required	Description
timeout	integer	query	False	Filter by timeout
ekmip_reachability. message	string	query	False	Filter by ekmip_reachability. message

Name	Туре	In	Required	Description
ekmip_reachability.c ode	string	query	False	Filter by ekmip_reachability.c ode
ekmip_reachability.r eachable	boolean	query	False	Filter by ekmip_reachability.r eachable
ekmip_reachability.n ode.uuid	string	query	False	Filter by ekmip_reachability.n ode.uuid
ekmip_reachability.n ode.name	string	query	False	Filter by ekmip_reachability.n ode.name
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
proxy_username	string	query	False	Filter by proxy_username
proxy_type	string	query	False	Filter by proxy_type
scope	string	query	False	Filter by scope
region	string	query	False	Filter by region
verify_host	boolean	query	False	Filter by verify_host
access_key_id	string	query	False	Filter by access_key_id
service	string	query	False	Filter by service
uuid	string	query	False	Filter by uuid
encryption_context	string	query	False	Filter by encryption_context
amazon_reachability .code	string	query	False	Filter by amazon_reachability .code

Name	Туре	In	Required	Description
amazon_reachability .message	string	query	False	Filter by amazon_reachability .message
amazon_reachability .reachable	boolean	query	False	Filter by amazon_reachability .reachable
verify_ip	boolean	query	False	Filter by verify_ip
proxy_port	integer	query	False	Filter by proxy_port
state.cluster_state	boolean	query	False	Filter by state.cluster_state
state.message	string	query	False	Filter by state.message
state.code	string	query	False	Filter by state.code
key_id	string	query	False	Filter by key_id
proxy_host	string	query	False	Filter by proxy_host
polling_period	integer	query	False	Filter by polling_period
host	string	query	False	Filter by host
default_domain	string	query	False	Filter by default_domain
skip_verify	boolean	query	False	Filter by skip_verify
port	integer	query	False	Filter by port
verify	boolean	query	False	Filter by verify
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 1 • Max value: 120 • Min value: 0
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	Number of records
records	array[aws_kms]	

```
" links": {
    "next": {
      "href": "/api/resourcelink"
    },
    "self": {
     "href": "/api/resourcelink"
    }
  },
  "num records": 1,
  "records": {
    " links": {
      "self": {
        "href": "/api/resourcelink"
      }
    "access key id": "<id value>",
    "amazon reachability": {
      "code": "346758",
      "message": "Amazon KMS is not reachable from all nodes -
<reason>."
    },
    "default domain": "domainName",
    "ekmip reachability": {
      "code": "346758",
      "message": "embedded KMIP server status unavailable on node.",
      "node": {
        " links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    },
    "encryption context": "aws:fsx:fs-id=fs-0785c8beceb895999",
    "host": "aws-host.host.com",
    "key id": "kmip-aws",
    "polling period": 55,
    "port": 443,
    "proxy host": "proxy.eng.com",
    "proxy password": "awskze-Jwjje2-WJJPer",
    "proxy port": 1234,
```

```
"proxy type": "http",
    "proxy username": "proxyuser",
    "region": "us-east-1",
    "scope": "svm",
    "secret access key": "<id value>",
    "service": "dynamodb.*.amazonaws.com",
    "skip verify": "",
    "state": {
     "code": "346758",
      "message": "AWS KMS key protection is unavailable on the
following nodes: node1, node2."
    },
    "svm": {
      " links": {
       "self": {
          "href": "/api/resourcelink"
       }
      },
     "name": "svm1",
     "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "timeout": 20,
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
    "verify": "",
    "verify host": 1,
    "verify ip": ""
 }
}
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
65537551	Top-level internal key protection key (KEK) unavailable on one or more nodes.
65537552	Embedded KMIP server status not available.
65537915	The Amazon Web Service Key Management Service is unreachable from one or more nodes.

Name	Туре	Description
error	error	

Example error

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
next	href	
self	href	

_links

Name	Туре	Description
self	href	

amazon reachability

Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

Name	Туре	Description
code	string	Code corresponding to the error message. Returns a 0 if Amazon KMS is reachable from all nodes in the cluster.
message	string	Error message returned when 'reachable' is false.
reachable	boolean	Set to true if the Amazon KMS is reachable from all nodes of the cluster.

node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

ekmip_reachability

Provides the connectivity status for the given SVM on the given node to all EKMIP servers configured on all nodes of the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

Name	Туре	Description
code	string	Code corresponding to the error message. Returns a 0 if a given SVM is able to communicate to the EKMIP servers of all of the nodes in the cluster.
message	string	Error message set when cluster- wide EKMIP server availability from the given SVM and node is false.
node	node	
reachable	boolean	Set to true if the given SVM on the given node is able to communicate to all EKMIP servers configured on all nodes in the cluster.

state

Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster-wide.

Name	Туре	Description
cluster_state	boolean	Set to true when AWS KMS key protection is available on all nodes of the cluster.
code	string	Code corresponding to the message. Returns a 0 if AWS KMS key protection is available on all nodes of the cluster.
message	string	Error message set when cluster_state is false.

svm

Name	Туре	Description
_links	_links	

Name	Туре	Description
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

aws_kms

Name	Туре	Description
_links	_links	
access_key_id	string	AWS Access Key ID of the user that has appropriate access to AWS KMS.
amazon_reachability	amazon_reachability	Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.
default_domain	string	AWS KMS default domain.
ekmip_reachability	array[ekmip_reachability]	
encryption_context	string	Additional layer of authentication and logging.
host	string	AWS KMS host's hostname.
key_id	string	AWS Key ID.
polling_period	integer	Polling period in minutes.
port	integer	AWS KMS port.
proxy_host	string	Proxy host.
proxy_password	string	Proxy password. Password is not audited.

Name	Туре	Description
proxy_port	integer	Proxy port.
proxy_type	string	Proxy type.
proxy_username	string	Proxy username.
region	string	AWS region of the AWS KMS.
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
secret_access_key	string	AWS Secret Access Key for the provided access key ID.
service	string	AWS service type.
skip_verify	boolean	Set to true to bypass verfication of updated user credentials when updating credentials.
state	state	Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster-wide.
svm	svm	
timeout	integer	AWS Connection timeout, in seconds.
uuid	string	A unique identifier for the AWS KMS.
verify	boolean	Set to true to verify the AWS KMS host.
verify_host	boolean	Set to true to verify the AWS KMS host's hostname.
verify_ip	boolean	Set to true to verify the AWS KMS host's IP address.

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Configure the AWS KMS configuration for an SVM

POST /security/aws-kms

Introduced In: 9.12

Configures the AWS KMS configuration for the specified SVM.

Required properties

- svm.uuid or svm.name Existing SVM in which to create an AWS KMS.
- region AWS region of the AWS KMS.
- key id AWS Key ID

Optional properties

- access key id AWS access key ID of the user who has the appropriate access to AWS KMS.
- secret access key AWS secret access key for the access key ID provided.
- service AWS service type.
- default domain AWS KMS default domain.
- port AWS KMS port.
- proxy type Type of proxy (http, https, etc.), if proxy configuration is used.
- proxy host Proxy hostname if proxy configuration is used.
- proxy_port Proxy port number if proxy configuration is used.

- proxy_username Proxy username if proxy configuration is used.
- proxy_password Proxy password if proxy configuration is used.
- polling_period Polling period in minutes.
- encryption context Additional layer of authentication and logging.

Related ONTAP commands

• security key-manager external aws enable

Parameters

Name	Туре	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Туре	Description
_links	_links	
access_key_id	string	AWS Access Key ID of the user that has appropriate access to AWS KMS.
amazon_reachability	amazon_reachability	Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.
default_domain	string	AWS KMS default domain.
ekmip_reachability	array[ekmip_reachability]	
encryption_context	string	Additional layer of authentication and logging.

Name	Туре	Description
host	string	AWS KMS host's hostname.
key_id	string	AWS Key ID.
polling_period	integer	Polling period in minutes.
port	integer	AWS KMS port.
proxy_host	string	Proxy host.
proxy_password	string	Proxy password. Password is not audited.
proxy_port	integer	Proxy port.
proxy_type	string	Proxy type.
proxy_username	string	Proxy username.
region	string	AWS region of the AWS KMS.
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
secret_access_key	string	AWS Secret Access Key for the provided access key ID.
service	string	AWS service type.
skip_verify	boolean	Set to true to bypass verfication of updated user credentials when updating credentials.
state	state	Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster- wide.
svm	svm	
timeout	integer	AWS Connection timeout, in seconds.

Name	Туре	Description
uuid	string	A unique identifier for the AWS KMS.
verify	boolean	Set to true to verify the AWS KMS host.
verify_host	boolean	Set to true to verify the AWS KMS host's hostname.
verify_ip	boolean	Set to true to verify the AWS KMS host's IP address.

```
" links": {
   "self": {
     "href": "/api/resourcelink"
   }
 },
 "access key id": "<id value>",
 "amazon reachability": {
   "code": "346758",
   "message": "Amazon KMS is not reachable from all nodes - <reason>."
 },
 "default domain": "domainName",
 "ekmip reachability": {
    "code": "346758",
    "message": "embedded KMIP server status unavailable on node.",
    "node": {
     " links": {
        "self": {
          "href": "/api/resourcelink"
       }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
 "encryption context": "aws:fsx:fs-id=fs-0785c8beceb895999",
 "host": "aws-host.host.com",
 "key id": "kmip-aws",
 "polling period": 55,
 "port": 443,
 "proxy host": "proxy.eng.com",
 "proxy password": "awskze-Jwjje2-WJJPer",
 "proxy port": 1234,
 "proxy type": "http",
 "proxy username": "proxyuser",
 "region": "us-east-1",
 "scope": "svm",
 "secret access key": "<id value>",
 "service": "dynamodb.*.amazonaws.com",
 "skip verify": "",
 "state": {
   "code": "346758",
    "message": "AWS KMS key protection is unavailable on the following
nodes: node1, node2."
```

Response

```
Status: 201, Created
```

Name	Туре	Description
_links	_links	
num_records	integer	Number of records
records	array[aws_kms]	

```
" links": {
    "next": {
     "href": "/api/resourcelink"
    },
    "self": {
     "href": "/api/resourcelink"
    }
  },
  "num records": 1,
  "records": {
    " links": {
      "self": {
        "href": "/api/resourcelink"
      }
    "access key id": "<id value>",
    "amazon reachability": {
      "code": "346758",
      "message": "Amazon KMS is not reachable from all nodes -
<reason>."
    },
    "default domain": "domainName",
    "ekmip reachability": {
      "code": "346758",
      "message": "embedded KMIP server status unavailable on node.",
      "node": {
        " links": {
          "self": {
            "href": "/api/resourcelink"
          }
        },
        "name": "node1",
        "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
      }
    },
    "encryption context": "aws:fsx:fs-id=fs-0785c8beceb895999",
    "host": "aws-host.host.com",
    "key id": "kmip-aws",
    "polling period": 55,
    "port": 443,
    "proxy host": "proxy.eng.com",
    "proxy password": "awskze-Jwjje2-WJJPer",
    "proxy port": 1234,
```

```
"proxy type": "http",
    "proxy username": "proxyuser",
    "region": "us-east-1",
    "scope": "svm",
    "secret access key": "<id value>",
    "service": "dynamodb.*.amazonaws.com",
    "skip verify": "",
    "state": {
     "code": "346758",
      "message": "AWS KMS key protection is unavailable on the
following nodes: node1, node2."
    },
    "svm": {
      " links": {
       "self": {
          "href": "/api/resourcelink"
       }
      },
     "name": "svm1",
     "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "timeout": 20,
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
    "verify": "",
    "verify host": 1,
    "verify ip": ""
 }
}
```

Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
3735622	Certificate type not supported for create operation.

Error Code	Description
3735645	You cannot specify a value for serial as it is generated automatically.
3735657	Specifying \"-subtype\" when creating a certificate is not supported.
3735664	Specified key size is not supported in FIPS mode.
3735665	Specified hash function is not supported in FIPS mode.
3735700	Specified key size is not supported.
65536600	Nodes are out of quorum.
65537518	Failed to find a LIF with Cluster role on node. One or more nodes may be out of quorum.
65537900	Failed to enable the Amazon Web Service Key Management Service for an SVM due to an invalid secret access key.
65537901	The Amazon Web Service Key Management Service (AWSKMS) cannot be enabled because all nodes in the cluster are not running a version that supports the AWSKMS feature.
65537906	Failed to store the secret access key.
65537907	The Amazon Web Service Key Management Service is disabled on the cluster. For further assistance, contact technical support.
65537908	The Amazon Web Service Key Management Service is not supported for the admin SVM.
65537910	Failed to configure Amazon Web Service Key Management Service for an SVM because a key manager has already been configured for the SVM.
65537911	The Amazon Web Service Key Management Service is not supported in MetroCluster configurations.
65537912	The Amazon Web Service Key Management Service cannot be configured for an SVM because one or more volume encryption keys of the SVM are stored on the admin SVM.
65537926	The Amazon Web Service Key Management Service is not configured for this SVM.

Name	Туре	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
self	href	

amazon reachability

Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

Name	Туре	Description
code	string	Code corresponding to the error message. Returns a 0 if Amazon KMS is reachable from all nodes in the cluster.
message	string	Error message returned when 'reachable' is false.
reachable	boolean	Set to true if the Amazon KMS is reachable from all nodes of the cluster.

node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

ekmip reachability

Provides the connectivity status for the given SVM on the given node to all EKMIP servers configured on all nodes of the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

Name	Туре	Description
code	string	Code corresponding to the error message. Returns a 0 if a given SVM is able to communicate to the EKMIP servers of all of the nodes in the cluster.
message	string	Error message set when cluster- wide EKMIP server availability from the given SVM and node is false.
node	node	
reachable	boolean	Set to true if the given SVM on the given node is able to communicate to all EKMIP servers configured on all nodes in the cluster.

state

Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster-wide.

Name	Туре	Description
cluster_state	boolean	Set to true when AWS KMS key protection is available on all nodes of the cluster.
code	string	Code corresponding to the message. Returns a 0 if AWS KMS key protection is available on all nodes of the cluster.
message	string	Error message set when cluster_state is false.

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

aws_kms

Name	Туре	Description
_links	_links	
access_key_id	string	AWS Access Key ID of the user that has appropriate access to AWS KMS.
amazon_reachability	amazon_reachability	Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.
default_domain	string	AWS KMS default domain.
ekmip_reachability	array[ekmip_reachability]	
encryption_context	string	Additional layer of authentication and logging.
host	string	AWS KMS host's hostname.
key_id	string	AWS Key ID.
polling_period	integer	Polling period in minutes.
port	integer	AWS KMS port.
proxy_host	string	Proxy host.
proxy_password	string	Proxy password. Password is not audited.
proxy_port	integer	Proxy port.
proxy_type	string	Proxy type.
proxy_username	string	Proxy username.
region	string	AWS region of the AWS KMS.

Name	Туре	Description
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
secret_access_key	string	AWS Secret Access Key for the provided access key ID.
service	string	AWS service type.
skip_verify	boolean	Set to true to bypass verfication of updated user credentials when updating credentials.
state	state	Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster-wide.
svm	svm	
timeout	integer	AWS Connection timeout, in seconds.
uuid	string	A unique identifier for the AWS KMS.
verify	boolean	Set to true to verify the AWS KMS host.
verify_host	boolean	Set to true to verify the AWS KMS host's hostname.
verify_ip	boolean	Set to true to verify the AWS KMS host's IP address.

_links

Name	Туре	Description
next	href	
self	href	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Re-key or re-version an AWS KMS key encryption key for AWS KMS

POST /security/aws-kms/{aws kms.uuid}/rekey-external

Introduced In: 9.12

Rekeys or re-versions the AWS KMS Key Encryption Key (KEK) for the given AWS KMS.

Related ONTAP commands

• security key-manager external aws rekey-external

Parameters

Name	Туре	In	Required	Description
aws_kms.uuid	string	path	True	UUID of the existing AWS KMS configuration.

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 1 • Max value: 120 • Min value: 0
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Туре	Description
key_id	_	Key identifier of the AWS KMS key encryption key.

Name	Туре	Description
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
svm	svm	

Example request

Response

```
Status: 202, Accepted
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
65537538	Internal error. Failed to get unwrapped key for a given key ID.
65537543	Internal Error. Missing top-level internal key protection key (KEK) on a node.

Error Code	Description
65537547	One or more volume encryption keys for encrypted volumes of this data SVM are stored in the key manager configured for the admin SVM. Use the REST API POST method to migrate this data SVM's keys from the admin SVM's key manager before running the rekey operation.
65537919	External rekey failed on one or more nodes.
65537926	AWS KMS is not configured for the given SVM.

Name	Туре	Description
error	error	

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

_links

Name	Туре	Description
self	href	

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

aws_kms_key

Name	Туре	Description
key_id	string	Key identifier of the AWS KMS key encryption key.
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
svm	svm	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments

Name	Туре	Description
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Re-key SVM KEK for an AWS KMS

POST /security/aws-kms/{aws_kms.uuid}/rekey-internal

Introduced In: 9.12

Rekeys SVM KEK for the given AWS KMS.

Related ONTAP commands

• security key-manager external aws rekey-internal

Parameters

Name	Туре	In	Required	Description
aws_kms.uuid	string	path	True	UUID of the existing AWS KMS configuration.

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 1 • Max value: 120 • Min value: 0
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Response

Status: 202, Accepted

Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

Error

Status: Default

Error Code	Description
65537547	One or more volume encryption keys for encrypted volumes of this data SVM are stored in the key manager configured for the admin SVM. Use the REST API POST method to migrate this data SVM's keys from the admin SVM's key manager to this data SVM's key manager before running the rekey operation.
65537556	Unable to successfully encrypt or decrypt because the configured external key manager for the given SVM is in a blocked state.
65537559	There are no existing internal keys for the SVM. A rekey operation is allowed for an SVM with one or more encryption keys.
65537566	Internal error. All nodes in the cluster are not currently online.
65537926	AWS KMS is not configured for the given SVM.

Name	Туре	Description
error	error	

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

Definitions

See Definitions

error_arguments

Name	Type Description	
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Restore keys for an SVM from a configured AWS KMS

POST /security/aws-kms/{aws_kms.uuid}/restore

Introduced In: 9.12

Restores the keys for an SVM from a configured AWS KMS.

Related ONTAP commands

• security key-manager external AWS restore

Parameters

Name	Туре	In	Required	Description
aws_kms.uuid	string	path	True	UUID of the existing AWS KMS configuration.
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 1 • Max value: 120 • Min value: 0

Name	Туре	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Response

Status: 202, Accepted

Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

Error

Status: Default

Error Code	Description
65536082	Unable to restore all keys.
65537544	Missing wrapped top-level internal key protection key (KEK) from internal database.
65537926	The Amazon Web Service Key Management Service is not configured for the given SVM.

Name	Туре	Description
error	error	

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Definitions

See Definitions

error arguments

Name	Type Description	
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete an AWS KMS configuration

DELETE /security/aws-kms/{uuid}

Introduced In: 9.12

Deletes an AWS KMS configuration.

Related ONTAP commands

• security key-manager external aws disable

Parameters

Name	Туре	In	Required	Description
uuid	string	path	True	AWS KMS UUID

Response

Status: 200, Ok

Error

Status: Default

Error Code	Description
65536817	Internal error. Failed to determine if it is safe to disable key manager.
65536827	Internal error. Failed to determine if the given SVM has any encrypted volumes.
65536834	Internal error. Failed to get existing key-server details for the given SVM.
65536883	Internal error. Volume encryption key is missing for a volume.
65536884	Internal error. Volume encryption key is invalid for a volume.
65537103	Cannot remove key manager that still contains one or more authentication keys for self-encrypting drives.
65537104	One or more self-encrypting drives are assigned an authentication key.
65537106	Volume encryption keys (VEK) for one or more encrypted volumes are stored on the key manager configured for the given SVM.
65537121	Cannot determine authentication key presence on one or more self-encrypting drives.

Error Code	Description
65537926	Amazon Web Service Key Management Service is not configured for SVM.
196608080	One or more nodes in the cluster have the root volume encrypted using NVE (NetApp Volume Encryption).
196608301	Internal error. Failed to get encryption type.
196608332	NAE aggregates found in the cluster.
196608351	NetApp Aggregate Encryption (NAE) aggregates are found in the cluster.

Name	Туре	Description
error	error	

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Definitions

See Definitions

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve an AWS KMS configuration

GET /security/aws-kms/{uuid}

Introduced In: 9.12

Retrieves the AWS KMS configuration for the SVM specified by the UUID.

Related ONTAP commands

- security key-manager external aws show
- security key-manager external aws check

Parameters

Name	Туре	In	Required	Description
uuid	string	path	True	AWS KMS UUID
fields	array[string]	query	False	Specify the fields to return.

Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
access_key_id	string	AWS Access Key ID of the user that has appropriate access to AWS KMS.
amazon_reachability	amazon_reachability	Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.
default_domain	string	AWS KMS default domain.
ekmip_reachability	array[ekmip_reachability]	
encryption_context	string	Additional layer of authentication and logging.
host	string	AWS KMS host's hostname.
key_id	string	AWS Key ID.
polling_period	integer	Polling period in minutes.
port	integer	AWS KMS port.
proxy_host	string	Proxy host.
proxy_password	string	Proxy password. Password is not audited.
proxy_port	integer	Proxy port.
proxy_type	string	Proxy type.

Name	Туре	Description
proxy_username	string	Proxy username.
region	string	AWS region of the AWS KMS.
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
secret_access_key	string	AWS Secret Access Key for the provided access key ID.
service	string	AWS service type.
skip_verify	boolean	Set to true to bypass verfication of updated user credentials when updating credentials.
state	state	Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster- wide.
svm	svm	
timeout	integer	AWS Connection timeout, in seconds.
uuid	string	A unique identifier for the AWS KMS.
verify	boolean	Set to true to verify the AWS KMS host.
verify_host	boolean	Set to true to verify the AWS KMS host's hostname.
verify_ip	boolean	Set to true to verify the AWS KMS host's IP address.

```
" links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "access key id": "<id value>",
 "amazon reachability": {
   "code": "346758",
   "message": "Amazon KMS is not reachable from all nodes - <reason>."
  },
  "default domain": "domainName",
  "ekmip reachability": {
    "code": "346758",
    "message": "embedded KMIP server status unavailable on node.",
    "node": {
     " links": {
        "self": {
          "href": "/api/resourcelink"
       }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "encryption context": "aws:fsx:fs-id=fs-0785c8beceb895999",
 "host": "aws-host.host.com",
 "key id": "kmip-aws",
 "polling period": 55,
 "port": 443,
 "proxy host": "proxy.eng.com",
 "proxy password": "awskze-Jwjje2-WJJPer",
 "proxy port": 1234,
 "proxy type": "http",
 "proxy username": "proxyuser",
 "region": "us-east-1",
 "scope": "svm",
 "secret access key": "<id value>",
  "service": "dynamodb.*.amazonaws.com",
 "skip verify": "",
 "state": {
    "code": "346758",
    "message": "AWS KMS key protection is unavailable on the following
nodes: node1, node2."
```

Error

```
Status: Default
```

Error Code	Description
65537551	Top-level internal key protection key (KEK) unavailable on one or more nodes.
65537552	Embedded KMIP server status not available.
65537915	The Amazon Web Service Key Management Service is unreachable from one or more nodes.

Name	Туре	Description
error	error	

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
self	href	

amazon_reachability

Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

Name	Туре	Description
code	string	Code corresponding to the error message. Returns a 0 if Amazon KMS is reachable from all nodes in the cluster.
message	string	Error message returned when 'reachable' is false.
reachable	boolean	Set to true if the Amazon KMS is reachable from all nodes of the cluster.

node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

ekmip reachability

Provides the connectivity status for the given SVM on the given node to all EKMIP servers configured on all nodes of the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

Name	Туре	Description
code	string	Code corresponding to the error message. Returns a 0 if a given SVM is able to communicate to the EKMIP servers of all of the nodes in the cluster.
message	string	Error message set when cluster- wide EKMIP server availability from the given SVM and node is false.
node	node	
reachable	boolean	Set to true if the given SVM on the given node is able to communicate to all EKMIP servers configured on all nodes in the cluster.

state

Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster-wide.

Name	Туре	Description
cluster_state	boolean	Set to true when AWS KMS key protection is available on all nodes of the cluster.
code	string	Code corresponding to the message. Returns a 0 if AWS KMS key protection is available on all nodes of the cluster.
message	string	Error message set when cluster_state is false.

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update an AWS KMS configuration

PATCH /security/aws-kms/{uuid}

Introduced In: 9.12

Updates the AWS KMS configuration.

Optional properties

- region AWS region of the AWS KMS.
- service AWS service type.
- default domain AWS KMS default domain.
- port AWS KMS port.
- proxy type Type of proxy (http, https, etc.), if proxy configuration is used.
- proxy host Proxy hostname if proxy configuration is used.
- proxy port Proxy port number if proxy configuration is used.
- proxy username Proxy username if proxy configuration is used.
- proxy password Proxy password if proxy configuration is used.
- polling period Polling period in minutes.
- timeout AWS Connection timeout, in seconds.
- verify Set to true to verify the AWS KMS host.

- verify_host Set to true to verify the AWS KMS host's hostname.
- verify ip Set to true to verify the AWS KMS host's IP address.
- host AWS KMS host's hostname.
- secret access key AWS secret access key for the access key ID provided.
- access-key-id AWS access key ID of the user with the appropriate access to AWS KMS.
- skip verify Set to true to bypass verfication of updated user credentials when updating credentials.
- encryption_context Additional layer of authentication and logging.

Related ONTAP commands

- security key-manager external aws update-config
- security key-manager external aws update-credentials

Parameters

Name	Туре	In	Required	Description
uuid	string	path	True	AWS KMS UUID

Request Body

Name	Туре	Description
_links	_links	
access_key_id	string	AWS Access Key ID of the user that has appropriate access to AWS KMS.
amazon_reachability	amazon_reachability	Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.
default_domain	string	AWS KMS default domain.
ekmip_reachability	array[ekmip_reachability]	

Name	Туре	Description
encryption_context	string	Additional layer of authentication and logging.
host	string	AWS KMS host's hostname.
key_id	string	AWS Key ID.
polling_period	integer	Polling period in minutes.
port	integer	AWS KMS port.
proxy_host	string	Proxy host.
proxy_password	string	Proxy password. Password is not audited.
proxy_port	integer	Proxy port.
proxy_type	string	Proxy type.
proxy_username	string	Proxy username.
region	string	AWS region of the AWS KMS.
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
secret_access_key	string	AWS Secret Access Key for the provided access key ID.
service	string	AWS service type.
skip_verify	boolean	Set to true to bypass verfication of updated user credentials when updating credentials.
state	state	Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster- wide.
svm	svm	

Name	Туре	Description
timeout	integer	AWS Connection timeout, in seconds.
uuid	string	A unique identifier for the AWS KMS.
verify	boolean	Set to true to verify the AWS KMS host.
verify_host	boolean	Set to true to verify the AWS KMS host's hostname.
verify_ip	boolean	Set to true to verify the AWS KMS host's IP address.

```
" links": {
   "self": {
     "href": "/api/resourcelink"
   }
 },
 "access key id": "<id value>",
 "amazon reachability": {
   "code": "346758",
   "message": "Amazon KMS is not reachable from all nodes - <reason>."
 },
 "default domain": "domainName",
 "ekmip reachability": {
    "code": "346758",
    "message": "embedded KMIP server status unavailable on node.",
    "node": {
     " links": {
        "self": {
          "href": "/api/resourcelink"
       }
      },
      "name": "node1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
 "encryption context": "aws:fsx:fs-id=fs-0785c8beceb895999",
 "host": "aws-host.host.com",
 "key id": "kmip-aws",
 "polling period": 55,
 "port": 443,
 "proxy host": "proxy.eng.com",
 "proxy password": "awskze-Jwjje2-WJJPer",
 "proxy port": 1234,
 "proxy_type": "http",
 "proxy username": "proxyuser",
 "region": "us-east-1",
 "scope": "svm",
 "secret access key": "<id value>",
 "service": "dynamodb.*.amazonaws.com",
 "skip verify": "",
 "state": {
   "code": "346758",
    "message": "AWS KMS key protection is unavailable on the following
nodes: node1, node2."
```

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

Error Code	Description
65537541	No inputs provided for the REST API PATCH request.
65537906	Failed to store the secret access key.
65537920	Secret access key cannot be empty.
65537921	Unable to connect to the Amazon Web Service Key Management Service (AWSKMS) using these credentials.
65537924	Access key ID cannot be empty.
65537926	Amazon Web Service Key Management Service is not configured for SVM.

Name	Туре	Description
error	error	

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
self	href	

amazon reachability

Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

Name	Туре	Description
code	string	Code corresponding to the error message. Returns a 0 if Amazon KMS is reachable from all nodes in the cluster.
message	string	Error message returned when 'reachable' is false.
reachable	boolean	Set to true if the Amazon KMS is reachable from all nodes of the cluster.

node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

ekmip reachability

Provides the connectivity status for the given SVM on the given node to all EKMIP servers configured on all nodes of the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.

Name	Туре	Description
code	string	Code corresponding to the error message. Returns a 0 if a given SVM is able to communicate to the EKMIP servers of all of the nodes in the cluster.
message	string	Error message set when cluster- wide EKMIP server availability from the given SVM and node is false.
node	node	
reachable	boolean	Set to true if the given SVM on the given node is able to communicate to all EKMIP servers configured on all nodes in the cluster.

state

Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster-wide.

Name	Туре	Description
cluster_state	boolean	Set to true when AWS KMS key protection is available on all nodes of the cluster.
code	string	Code corresponding to the message. Returns a 0 if AWS KMS key protection is available on all nodes of the cluster.
message	string	Error message set when cluster_state is false.

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

aws_kms

Name	Туре	Description
_links	_links	
access_key_id	string	AWS Access Key ID of the user that has appropriate access to AWS KMS.
amazon_reachability	amazon_reachability	Indicates whether or not the Amazon KMS is reachable from all nodes in the cluster. This is an advanced property; there is an added computational cost to retrieving its value. The property is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter or GET for all advanced properties is enabled.
default_domain	string	AWS KMS default domain.
ekmip_reachability	array[ekmip_reachability]	
encryption_context	string	Additional layer of authentication and logging.
host	string	AWS KMS host's hostname.
key_id	string	AWS Key ID.
polling_period	integer	Polling period in minutes.
port	integer	AWS KMS port.
proxy_host	string	Proxy host.
proxy_password	string	Proxy password. Password is not audited.
proxy_port	integer	Proxy port.
proxy_type	string	Proxy type.
proxy_username	string	Proxy username.
region	string	AWS region of the AWS KMS.

Name	Туре	Description
scope	string	Set to "svm" for interfaces owned by an SVM. Otherwise, set to "cluster".
secret_access_key	string	AWS Secret Access Key for the provided access key ID.
service	string	AWS service type.
skip_verify	boolean	Set to true to bypass verfication of updated user credentials when updating credentials.
state	state	Indicates whether or not the Amazon Web Services Key Management Service (AWS KMS) key protection is available cluster-wide.
svm	svm	
timeout	integer	AWS Connection timeout, in seconds.
uuid	string	A unique identifier for the AWS KMS.
verify	boolean	Set to true to verify the AWS KMS host.
verify_host	boolean	Set to true to verify the AWS KMS host's hostname.
verify_ip	boolean	Set to true to verify the AWS KMS host's IP address.

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.