FOR FI-A F1-A V1.1 WIFL SETTING

Computer and 3D printer connected via WiFi BY <u>CURA</u> . Need TF card plug into the motherboard the all times. Otherwise, will report an error.



WIFI connection support Ultimaker_Cura-4.2.0-BETA




Download and install < CURA> sectioning software


Download cura4.2 https://github.com/Ultimaker/Cura/releases/tag/4.2-beta

2

Download < MKS plugin > Copy the file to the CURA installation directory plugins directory. https://github.com/my3dltd/F1-MSK-V1.1-WIFI




• Modify: WiFi username password--connection



Open the <u>lite_cfg</u> file with Notepad

<u>Download the latest firmware</u> https://github.com/my3dltd/F1-MKS-V1.1-Firmware



7)

WIFI SETTING username and password






Copy the modified **lite_cfg** file and **mkslite.bin** to the TF card, insert the 3D printer, and then turn on the

power switch again.


Will update automatically.

After the update, the files in the TF card are automatically invalidated (can be deleted) and can only be updated once. If you need to update again. Need to re-copy the file into the TF card.

Setting up CURA



Work with a printer using a CRUA wireless connection



Congratulations
Set up successfully



