CSE435 – Robotics

Lab 1 - Introduction to RobotBasic Simulator

General Notes

- Commands in RobotBASIC are not case-sensitive.
- The simulator "run screen" is **800 × 600 pixels** (width × height).
- Parameters in square brackets [] are optional. If omitted, RobotBASIC uses defaults.
- The screen origin (0,0) is **top-left**. Increasing x moves right, increasing y moves down.

1. Initializing a Robot

rLocate x, y, [heading, size, color]

Parameter	Meaning / Default	Notes
х, у	Coordinates in the screen	x,y are coordinates of the center of the robot
heading	Direction in degrees	Default = 0 (facing upward). Positive values clockwise
size	Diameter in pixels	Default = 20 (range $5 \rightarrow 50$)
color	Color of the robot	Default = blue

Examples:

```
rLocate 400, 300
rLocate 100, 100, 45, 30, red
```

To print x and y values

print(rGpsY())
print(rGpsY())

2. Animating the Robot

Moving Forward / Backward

rForward value

- value in pixels.
- Positive → move forward.
- Negative → move backward.

Turning


- dvalue in degrees.
- Positive → clockwise.
- Negative → counterclockwise.

3. Controlling Robot Speed

rSpeed value

- Larger value = **slower movement** (easier to observe).
- Smaller value = **faster movement**.

Example



4. Drawing Obstacles / Shapes

Circle

circle x1, y1, x2, y2, [outlineColor, fillColor]

- (x1, y1) and (x2, y2) define the **bounding rectangle** of the circle/ellipse.
- Optional: outline color and fill color.

Rectangle

rectangle x1, y1, x2, y2, [outlineColor, fillColor]

- (x1, y1) = upper-left corner.
- (x2, y2) = lower-right corner.
- Optional: outline color and fill color.