## ADCSRB - ADC Control and status registers B

| ADCSRB - ADC Control and status registers B   |                                    |                |  |       |       |      |                   |     |     |  |  |
|---|------------------------------------|----------------|--|-------|-------|------|-------------------|-----|-----|--|--|
| address: 0x7B Defaults: 0x00  |                                    |                |  |       |       |      |                   |     |     |  |  |
| Bit   |                                    | 7              | 6  | 5     | 4     | 3    | 2                 | 1   | 0   |  |  |
| Name  |                                    | CME01          | CME00  | CME11 | CME10 | ACTS | ADTS2 ADTS1 ADTS0 |     |     |  |  |
| R/W   |                                    | R/W            | R/W  | R/W   | R/W   | R/WR | w                 | R/W | R/W |  |  |
| Bit   | Name                               | ne description |  |       |       |      |                   |     |     |  |  |
| 7   | СМЕ                                | 01 AC0 Neg     | Negative input selection, CME0 = {CME01, CME00}        |       |       |      |                   |     |     |  |  |
| 6   | СМЕ                                | 00 00          | 00: External ports ACXN As a AC0 Negative input        |       |       |      |                   |     |     |  |  |
| 01: ADC As a multiplexed output AC0 Negative input  |                                    |                |  |       |       |      |                   |     |     |  |  |
| 10: As the output of the differential amplifier AC0 Negative input  |                                    |                |  |       |       |      |                   |     |     |  |  |
|   |                                    | 11:            | 11: shut down AC0 The negative input source            |       |       |      |                   |     |     |  |  |
| 5   | СМЕ                                | 11 AC1 Neg     | C1 Negative input selection, CME1 = {CME11, CME10}     |       |       |      |                   |     |     |  |  |
| 4   | 4 CME10                            |                | 00: External ports ACXN As a AC1 Negative input        |       |       |      |                   |     |     |  |  |
| 01: External ports AC1N As a AC1 Negative input   |                                    |                |  |       |       |      |                   |     |     |  |  |
| 10: ADC internal 1/5 As the partial pressure AC1 Negative input   |                                    |                |  |       |       |      |                   |     |     |  |  |
|   |                                    | 11:            | 11: Differential op amp's output as AC1 Negative input |       |       |      |                   |     |     |  |  |
| 3 ACHS AC Trigger source channel selection  |                                    |                |  |       |       |      |                   |     |     |  |  |
| 0 - AC0 Output as ADC The automatic conversion trigger 1 - AC1 Output as ADC The automatic conversion trigger |                                    |                |  |       |       |      |                   |     |     |  |  |
|   |                                    |                |  |       |       |      |                   |     |     |  |  |
| 2: 0  | ADTS see ADC Register description. |                |  |       |       |      |                   |     |     |  |  |

## C0XR - AC0 Auxiliary Control Register

| COXR - ACO Auxiliary Control Register            |  |                 |  |      |        |                               |      |   |       |                |  |
|--|--|-----------------|--|------|--------|-------------------------------|------|---|-------|----------------|--|
| address: 0                                       | )x51   |                 | Defaults: 0x00   |      |        |                               |      |   |       |                |  |
| Bit  |  | 7               |  | 6    | 5      | 4                             | 3    | 2 | 1     | 0              |  |
| Name   |  | -               |  | C0OE | C0HYSE | COPSO COWKE COFEN COFS1 COFS0 |      |   |       |                |  |
| R/W  |  | -               |  | R/W  | R/W    | R/W                           | R/WR | w | R/WR/ | w              |  |
| Bit  | Name   | ;               | description  |      |        |                               |      |   |       |                |  |
| 7  | -  |                 | Retention  |      |        |                               |      |   |       |                |  |
| 6  | COOE   |                 | AC0 The comparator output to an external enable control port                   |      |        |                               |      |   |       |                |  |
|  |  |                 | COOE = 1, AC0 The comparator output to an external port PD2 COOE = 0, Prohibit |      |        |                               |      |   |       |                |  |
|  |  |                 | comparator output to an external port  |      |        |                               |      |   |       |                |  |
| 5  | 5 C0HYSE AC0 Output enable control hysteresis function.  |                 |  |      |        |                               |      |   |       |                |  |
|  |  |                 | 1 = Enable output hysteresis   |      |        |                               |      |   |       |                |  |
| 0 = Disable output hysteresis                    |  |                 |  |      |        |                               |      |   |       |                |  |
| 4 C0PS0 AC0 The positive terminal of the input s |  | source selected | low.   |      |        |                               |      |   |       |                |  |
|  | C0PS0 versus C0BG Joint control AC0 The positive terminal of the input source, refer to C0SR Register Definition |                 |  |      |        |                               |      |   |       | ter Definition |  |
|  |  |                 | _  |      |        |                               |      |   |       |                |  |
| 3  | 3 COWKE ACO For the wake-up can be controlled.   |                 |  |      |        |                               |      |   |       |                |  |
|  | 1 = Enables the comparator output wake-up function   |                 |  |      |        |                               |      |   |       |                |  |