

OVP Guide to Using Processor Models

Model specific information for ARM_Cortex-M3

Imperas Software Limited Imperas Buildings, North Weston Thame, Oxfordshire, OX9 2HA, U.K. docs@imperas.com



Author	Imperas Software Limited
Version	20240902.0
Filename	OVP_Model_Specific_Information_armm_Cortex-M3.pdf
Created	2 September 2024
Status	OVP Standard Release

Copyright Notice

Copyright (c) 2024 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the readers responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED, AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit OVPworld.org.

Contents

1	Ove	erview	1
	1.1	Description	1
	1.2	Licensing	1
	1.3	Limitations	2
	1.4	Verification	2
	1.5	Features	2
	1.6	Unpredictable Behavior	3
		1.6.1 Equal Target Registers	3
		1.6.2 Floating Point Load/Store Multiple Lists	3
		1.6.3 If-Then (IT) Block Constraints	3
		1.6.4 Use of R13	3
		1.6.5 Use of R15	3
	1.7	Integration Support	4
		1.7.1 Memory Transaction Query	4
		1.7.2 Halt Reason Introspection	4
2	Cor	nfiguration	5
	2.1	Location	5
	2.2	GDB Path	5
	2.3	Semi-Host Library	5
	2.4	Processor Endian-ness	5
	2.5	QuantumLeap Support	5
	2.6	Processor ELF code	5
3	All	Variants in this model	6
4	Bus	s Master Ports	7
5	Bus	s Slave Ports	8
6	Net	t Ports	9
7	FIF	FO Ports	10
8	For	mal Parameters	11
	8.1	Parameter values and limits	12
a	Eve	ocution Modes	1 /

${\bf Imperas~OVP~Fast~Processor~Model~Documentation~for~ARM_Cortex-M3}$

10 Exceptions	15
11 Hierarchy of the model	16
11.1 Level 1	 16
12 Model Commands	17
12.1 Level 1	 17
12.1.1 debugflags	 17
12.1.2 isync	 17
12.1.3 itrace	
13 Registers	19
13.1 Level 1	 19
13.1.1 Core	
13.1.2 Control	 19
13.1.3 System	
13 1 4 Integration support	

Overview

This document provides the details of an OVP Fast Processor Model variant.

OVP Fast Processor Models are written in C and provide a C API for use in C based platforms. The models also provide a native interface for use in SystemC TLM2 platforms.

The models are written using the OVP VMI API that provides a Virtual Machine Interface that defines the behavior of the processor. The VMI API makes a clear line between model and simulator allowing very good optimization and world class high speed performance. Most models are provided as a binary shared object and also as source. This allows the download and use of the model binary or the use of the source to explore and modify the model.

The models are run through an extensive QA and regression testing process and most model families are validated using technology provided by the processor IP owners. There is a companion document (OVP Guide to Using Processor Models) which explains the general concepts of OVP Fast Processor Models and their use. It is downloadable from the OVPworld website documentation pages.

1.1 Description

ARMM Processor Model

1.2 Licensing

Usage of binary model under license governing simulator usage.

Note that for models of ARM CPUs the license includes the following terms:

Licensee is granted a non-exclusive, worldwide, non-transferable, revocable licence to:

If no source is being provided to the Licensee: use and copy only (no modifications rights are granted) the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used

to emulate an ARM based system to run application software in a production or live environment.

If source code is being provided to the Licensee: use, copy and modify the model for the sole purpose of designing, developing, analyzing, debugging, testing, verifying, validating and optimizing software which: (a) (i) is for ARM based systems; and (ii) does not incorporate the ARM Models or any part thereof; and (b) such ARM Models may not be used to emulate an ARM based system to run application software in a production or live environment.

In the case of any Licensee who is either or both an academic or educational institution the purposes shall be limited to internal use.

Except to the extent that such activity is permitted by applicable law, Licensee shall not reverse engineer, decompile, or disassemble this model. If this model was provided to Licensee in Europe, Licensee shall not reverse engineer, decompile or disassemble the Model for the purposes of error correction.

The License agreement does not entitle Licensee to manufacture in silicon any product based on this model.

The License agreement does not entitle Licensee to use this model for evaluating the validity of any ARM patent.

The License agreement does not entitle Licensee to use the model to emulate an ARM based system to run application software in a production or live environment.

Source of model available under separate Imperas Software License Agreement.

1.3 Limitations

Performance Monitors are not implemented.

Debug Extension and related blocks are not implemented.

1.4 Verification

Models have been extensively tested by Imperas. ARM Cortex-M models have been successfully used by customers to simulate the Micrium uC/OS-II kernel and FreeRTOS.

1.5 Features

The model is configured with 16 interrupts and 3 priority bits (use override_numInterrupts and override_priorityBits parameters to change these).

Thumb-2 instructions are supported.

MPU is present. Use parameter override_MPU_TYPE to disable it or change the number of MPU regions if required.

SysTick timer is present. Use parameter SysTickPresent to disable it if required.

FPU extension is not present. Use parameter override_MVFR0 to enable it if required.

DSP extension is not present. Use parameter override_InstructionAttributes3 to enable it if required.

Bit-band region is present. Use parameter BitBandPresent to disable it if required.

A 20-bit PPB bus port can be connected. If it is, then any loads or stores to address range 0xE0040000:0xE00FFFFF will be visible on this bus at address range 0x00040000:0x000FFFFF.

1.6 Unpredictable Behavior

Many instruction behaviors are described in the ARM ARM as CONSTRAINED UNPRE-DICTABLE. This section describes how such situations are handled by this model.

1.6.1 Equal Target Registers

Some instructions allow the specification of two target registers (for example, double-width SMULL, or some VMOV variants), and such instructions are CONSTRAINED UNPREDICTABLE if the same target register is specified in both positions. In this model, such instructions are treated as UNDEFINED.

1.6.2 Floating Point Load/Store Multiple Lists

Instructions that load or store a list of floating point registers (e.g. VSTM, VLDM, VPUSH, VPOP) are CONSTRAINED UNPREDICTABLE if either the uppermost register in the specified range is greater than 32 or (for 64-bit registers) if more than 16 registers are specified. In this model, such instructions are treated as UNDEFINED.

1.6.3 If-Then (IT) Block Constraints

Where the behavior of an instruction in an if-then (IT) block is described as CONSTRAINED UNPREDICTABLE, this model treats that instruction as UNDEFINED.

1.6.4 Use of R13

Use of R13 is described as CONSTRAINED UNPREDICTABLE in many circumstances. This model allows R13 to be used like any other GPR.

1.6.5 Use of R15

Use of R15 is described as CONSTRAINED UNPREDICTABLE in many circumstances. This model allows such use to be configured using the parameter "unpredictableR15" as follows:

Value "undefined": any reference to R15 in such a situation is treated as UNDEFINED;

Value "nop": any reference to R15 in such a situation causes the instruction to be treated as a NOP;

Value "raz_wi": any reference to R15 in such a situation causes the instruction to be treated as a RAZ/WI (that is, R15 is read as zero and write-ignored);

Value "execute": any reference to R15 in such a situation is executed using the current value of R15 on read, and writes to R15 are allowed.

Value "assert": any reference to R15 in such a situation causes the simulation to halt with an assertion message (allowing any such unpredictable uses to be easily identified).

In this variant, the default value of "unpredictable R15" is "execute".

1.7 Integration Support

This model implements a number of non-architectural pseudo-registers and other features to facilitate integration.

1.7.1 Memory Transaction Query

Two registers are intended for use within memory callback functions to provide additional information about the current memory access. Register executionPri indicates the current processor execution priority. Register atomicType indicates whether the current instruction has any special atomic constraints (0 indicates no constraint, 1 indicates atomic, 2 indicates exclusive access).

1.7.2 Halt Reason Introspection

An artifact register HaltReason can be read to determine the reason or reasons that a processor is halted. This register is a bitfield, with the following encoding: bit 0 indicates the processor has executed a wait-for-event (WFE) instruction; bit 1 indicates the processor has executed a wait-for-interrupt (WFI) instruction; bit 2 indicates the processor has entered lockup state; and bit 3 indicates the processor is held in reset.

Configuration

2.1 Location

This model's VLNV is arm.ovpworld.org/processor/armm/1.0.

The model source is usually at:

\$IMPERAS_HOME/ImperasLib/source/arm.ovpworld.org/processor/armm/1.0

The model binary is usually at:

\$IMPERAS_HOME/lib/\$IMPERAS_ARCH/ImperasLib/arm.ovpworld.org/processor/armm/1.0

2.2 GDB Path

The default GDB for this model is: \$IMPERAS_HOME/lib/\$IMPERAS_ARCH/gdb/arm-none-eabi-gdb.

2.3 Semi-Host Library

The default semi-host library file is arm.ovpworld.org/semihosting/armNewlib/1.0

2.4 Processor Endian-ness

This is a LITTLE endian model.

2.5 QuantumLeap Support

This processor is qualified to run in a QuantumLeap enabled simulator.

2.6 Processor ELF code

The ELF code supported by this model is: 0x28.

All Variants in this model

This model has these variants

Variant	Description
ARMv6-M	
ARMv7-M	
Cortex-M0	
Cortex-M0plus	
Cortex-M1	
Cortex-M3	(described in this document)
Cortex-M4	
Cortex-M4F	
Cortex-M7	
Cortex-M7F	
Cortex-M23	
Cortex-M33	
Cortex-M33F	

Table 3.1: All Variants in this model

Bus Master Ports

This model has these bus master ports.

Name	min	max	Connect?	Description
INSTRUCTION	32	32	mandatory	
DATA	32	32	optional	
PPB	20	20	optional	PPB interface

Table 4.1: Bus Master Ports

Bus Slave Ports

This model has no bus slave ports.

Net Ports

This model has these net ports.

Name	Type	Connect?	Description		
sysResetReq	output	optional	Indicates that a reset is required		
intISS	output	optional	Indicates that an interrupt service has		
			started		
eventOut	output	optional	EVENTO output signal (SEV)		
lockup	output	optional	Indicates fatal lockup state entered		
haltReason	output	optional	Indicates why core is halted		
int	input	optional	Raise or lower interrupt by index		
reset	input	optional	RESET (active high)		
cpuWait	input	optional	CPUWAIT (active high at reset only)		
nmi	input	optional	NMI (posedge-triggered)		
eventIn	input	optional	EVENTI input (posedge-triggered)		
initvtor	input	optional	VTOR reset configuration		
int0	input	optional	Scalar interrupt input 0		
int1	input	optional	Scalar interrupt input 1		
int2	input	optional	Scalar interrupt input 2		
int3	input	optional	Scalar interrupt input 3		
int4	input	optional	Scalar interrupt input 4		
int5	input	optional	Scalar interrupt input 5		
int6	input	optional	Scalar interrupt input 6		
int7	input	optional	Scalar interrupt input 7		
int8	input	optional	Scalar interrupt input 8		
int9	input	optional	Scalar interrupt input 9		
int10	input	optional	Scalar interrupt input 10		
int11	input	optional	Scalar interrupt input 11		
int12	input	optional	Scalar interrupt input 12		
int13	input	optional	Scalar interrupt input 13		
int14	input	optional	Scalar interrupt input 14		
int15	input	optional	Scalar interrupt input 15		

Table 6.1: Net Ports

FIFO Ports

This model has no FIFO ports.

Formal Parameters

Name	Type	Description		
verbose	Boolean	Specify verbosity of output		
showHiddenRegs	Boolean	Show hidden registers during register tracing		
UAL	Boolean	Disassemble using UAL syntax		
enableVFPAtReset	Boolean	Enable vector floating point (SIMD and VFP) instructions at		
		reset. (Enables cp10/11 in CPACR and sets FPEXC.EN)		
compatibility	Enumeration	Specify compatibility mode		
	ISA			
	gdb			
	nopBKPT			
unpredictableR15	Enumeration	Specify behavior for UNPREDICTABLE uses of R15		
	undefined			
	nop			
	raz_wi			
	execute			
	assert			
override_debugMask	Uns32	Specifies debug mask, enabling debug output for model compo-		
		nents		
instructionEndian Endian		The architecture specifies that instruction fetch is always little		
		endian; this attribute allows the defined instruction endianness		
		to be overridden if required		
resetAtTime0 Boolean		Reset the model at time=0 (default=1)		
SysTickPresent	Uns32	Specify number of SysTick timers present		
BitBandPresent	Boolean	Specify presence of bit-band region		
override_PFR0	Uns32	Override ID_PFR0 register		
override_PFR1	Uns32	Override ID_PFR1 register		
override_DFR0	Uns32	Override ID_DFR0 register		
override_AFR0 Uns32 Override ID_AFR0 r		Override ID_AFR0 register		
override_MMFR0	Uns32	Override ID_MMFR0 register		
override_MMFR1	Uns32	Override ID_MMFR1 register		
override_MMFR2	Uns32	Override ID_MMFR2 register		
$override_MMFR3$	Uns32	Override ID_MMFR3 register		
override_ISAR0	Uns32	Override ID_ISAR0 register		
override_ISAR1	Uns32	Override ID_ISAR1 register		
override_ISAR2	Uns32	Override ID_ISAR2 register		
override_ISAR3	Uns32	Override ID_ISAR3 register		
override_ISAR4	Uns32	Override ID_ISAR4 register		
override_ISAR5	Uns32	Override ID_ISAR5 register		
override_MVFR0	Uns32	Override ID_MVFR0 register		
override_MVFR1	Uns32	Override ID_MVFR1 register		
override_MVFR2	Uns32	Override ID_MVFR2 register		

override_CPUID	Uns32	Override system CPUID register
override_MPU_TYPE	Uns32	Override system MPU_TYPE register
override_VTOR	Uns32	Override VTOR register reset value
override_deviceStrongAligned	Boolean	Force accesses to Device and Strongly Ordered regions to be
		aligned
override_STRoffsetPC12	Uns32	Specifies that STR/STR of PC should do so with 12:byte offset
		from the current instruction (if 1), otherwise an 8:byte offset is
		used
override_ERG	Uns32	Specifies exclusive reservation granule
override_priorityBits	Uns32	Specifies number of priority bits in BASEPRI etc (1-8, default is
		3)
$override_numInterrupts$	Uns32	Specifies number of external interrupt lines
$override_InstructionAttributes0$	Uns32	Override ID_ISAR0 register (deprecated, use override_ISAR0)
override_InstructionAttributes1	Uns32	Override ID_ISAR1 register (deprecated, use override_ISAR1)
$override_InstructionAttributes 2$	Uns32	Override ID_ISAR2 register (deprecated, use override_ISAR2)
override_InstructionAttributes3	Uns32	Override ID_ISAR3 register (deprecated, use override_ISAR3)
override_InstructionAttributes4	Uns32	Override ID_ISAR4 register (deprecated, use override_ISAR4)
override_InstructionAttributes5	Uns32	Override ID_ISAR5 register (deprecated, use override_ISAR5)

Table 8.1: Parameters

8.1 Parameter values and limits

These are the formal parameter limits and actual parameter values

Name	Min	Max	Default	Actual
(Others)				
variant				Cortex-M3
verbose			t	t
showHiddenRegs			f	f
UAL			t	t
enableVFPAtReset			f	f
compatibility			ISA	ISA
unpredictableR15			execute	execute
override_debugMask	0	0xffffffff	0	0
endian			none	none
instructionEndian			none	none
resetAtTime0			t	t
SysTickPresent	0	0	1	1
BitBandPresent			f	f
override_PFR0	0	0xffffffff	48	48
override_PFR1	0	0xffffffff	0x200	0x200
override_DFR0	0	0xffffffff	0	0
override_AFR0	0	0xffffffff	0	0
override_MMFR0	0	0xffffffff	48	48
override_MMFR1	0	0xffffffff	0	0
override_MMFR2	0	0xfffffff	0	0
override_MMFR3	0	0xffffffff	0	0
override_ISAR0	0	0xffffffff	0x1141110	0x1141110
override_ISAR1	0	0xffffffff	0x2111000	0x2111000

override_ISAR2	0	0xffffffff	0x20112231	0x20112231
override_ISAR3	0	0xffffffff	0x1111110	0x1111110
override_ISAR4	0	0xffffffff	0x1310102	0x1310102
override_ISAR5	0	0xffffffff	0	0
override_MVFR0	0	0xffffffff	0	0
override_MVFR1	0	0xffffffff	0	0
override_MVFR2	0	0xffffffff	0	0
override_CPUID	0	0xffffffff	0x412fc230	0x412fc230
override_MPU_TYPE	0	0xffffffff	0x800	0x800
override_VTOR	0	0xffffffff	0	0
$override_deviceStrongAligned$			f	f
override_STRoffsetPC12	0	1	0	0
override_ERG	0	0x400	0	0
override_priorityBits	1	8	3	3
override_numInterrupts	0	0x1f0	16	16
override_InstructionAttributes0	0	0xffffffff	0x1141110	0x1141110
override_InstructionAttributes1	0	0xffffffff	0x2111000	0x2111000
override_InstructionAttributes2	0	0xffffffff	0x20112231	0x20112231
override_InstructionAttributes3	0	0xffffffff	0x1111110	0x1111110
override_InstructionAttributes4	0	0xffffffff	0x1310102	0x1310102
override_InstructionAttributes5	0	0xffffffff	0	0

Table 8.2: Parameter values and limits

Execution Modes

Mode	Code
Thread	0
Handler	1

Table 9.1: Modes implemented in this processor

Exceptions

Exception	Code
None	0
Reset	1
NMI	2
HardFault	3
MemManage	4
BusFault	5
UsageFault	6
SVCall	11
DebugMonitor	12
PendSV	14
SysTick	15
ExternalInt000	16
ExternalInt001	17
ExternalInt002	18
ExternalInt003	19
ExternalInt004	20
ExternalInt005	21
ExternalInt006	22
ExternalInt007	23
ExternalInt008	24
ExternalInt009	25
ExternalInt00a	26
ExternalInt00b	27
ExternalInt00c	28
ExternalInt00d	29
ExternalInt00e	30
ExternalInt00f	31

Table 10.1: Exceptions implemented by this processor

Hierarchy of the model

A CPU core may be configured to instance many processors of a Symmetrical Multi Processor (SMP). A CPU core may also have sub elements within a processor, for example hardware threading blocks.

OVP processor models can be written to include SMP blocks and to have many levels of hierarchy. Some OVP CPU models may have a fixed hierarchy, and some may be configured by settings in a configuration register. Please see the register definitions of this model.

This model documentation shows the settings and hierarchy of the default settings for this model variant.

11.1 Level 1

This level in the model hierarchy has 3 commands.

This level in the model hierarchy has 4 register groups:

Group name	Registers
Core	16
Control	7
System	59
Integration_support	4

Table 11.1: Register groups

This level in the model hierarchy has no children.

Model Commands

A Processor model can implement one or more **Model Commands** available to be invoked from the simulator command line, from the OP API or from the Imperas Multiprocessor Debugger.

12.1 Level 1

12.1.1 debugflags

show or modify the processor debug flags

Argument	Type	Description		
-get	Boolean	print current processor flags value		
-mask	Boolean	print valid debug flag bits		
-set	Int32	new processor flags (only flags 0x0000008c can		
		be modified)		

Table 12.1: debugflags command arguments

12.1.2 isync

specify instruction address range for synchronous execution

Argument	Type	Description			
-addresshi	Uns64	end address of synchronous execution range			
-addresslo	Uns64	start address of synchronous execution range			

Table 12.2: isync command arguments

12.1.3 itrace

enable or disable instruction tracing

Argument	Type	Description
-access	String	show memory accesses by this instruction. Ar-
		gument can be any combination of X (execute),
		A (load or store access) and S (system)
-after	Uns64	apply after this many instructions

-enable	Boolean	enable instruction tracing		
-full	Boolean	ean turn on all trace features		
-instructioncount	Boolean	include the instruction number in each trace		
-memory	String	(Alias for access). show memory accesses by this		
		instruction. Argument can be any combination		
		of X (execute), A (load or store access) and S		
		(system)		
-mode	Boolean	show processor mode changes		
-off	Boolean	disable instruction tracing		
-on	Boolean	enable instruction tracing		
-processorname	Boolean	Include processor name in all trace lines		
-registerchange	Boolean	show registers changed by this instruction		
-registers	Boolean	show registers after each trace		

Table 12.3: itrace command arguments

Registers

13.1 Level 1

13.1.1 Core

Registers at level:1, group:Core

Name	Bits	Initial-Hex	RW	Description
r0	32	0	rw	
r1	32	0	rw	
r2	32	0	rw	
r3	32	0	rw	
r4	32	0	rw	
r5	32	0	rw	
r6	32	0	rw	
r7	32	0	rw	
r8	32	0	rw	
r9	32	0	rw	
r10	32	0	rw	
r11	32	0	rw	frame pointer
r12	32	0	rw	
sp	32	0	rw	stack pointer
lr	32	0	rw	
pc	32	0	rw	program counter

Table 13.1: Registers at level 1, group:Core

13.1.2 Control

Registers at level:1, group:Control

Name	Bits	Initial-Hex	RW	Description
cpsr	32	0	rw	xPSR register. Includes APSR, IPSR and EPSR
control	32	0	rw	
primask	32	0	rw	
faultmask	32	0	rw	
basepri	32	0	rw	
sp_process	32	0	rw	stack pointer
sp_main	32	0	rw	stack pointer

Table 13.2: Registers at level 1, group:Control

13.1.3 System

Registers at level:1, group:System

Name	Bits	Initial-Hex	RW	Description
ICTR	32	0	rw	0xe000e004: Interrupt Controller Type
ACTLR	32	0	rw	0xe000e008: Auxiliary Control
SYST_CSR	32	4	rw	0xe000e010: SysTick Control and Status
SYST_RVR	32	0	rw	0xe000e014: SysTick Reload Value
SYST_CVR	32	0	rw	0xe000e018: SysTick Current Value
SYST_CALIB	32	0	rw	0xe000e01c: SysTick Cultent Value
NVIC_ISER0	32	0	rw	0xe000e010: Interrupt Set Enable 0
NVIC_ICER0	32	0		0xe000e100. Interrupt Set Enable 0 0xe000e180: Interrupt Clear Enable 0
NVICLISPR0	32	0	rw	0xe000e180. Interrupt Clear Enable 0 0xe000e200: Interrupt Set Pending 0
NVICLISF RO NVICLICPRO	32	0	rw	0xe000e200: Interrupt Set Fending 0 0xe000e280: Interrupt Clear Pending 0
NVIC_ICPRO NVIC_IABRO	32	0	rw	0xe000e250: Interrupt Clear Fending 0 0xe000e300: Interrupt Active Bit 0
NVIC_IABRO NVIC_IPRO	32	0	r-	
		-	rw	0xe000e400: Interrupt Priority 0
NVIC IPR1	32	0	rw	0xe000e404: Interrupt Priority 1
NVIC IPR2	32	0	rw	0xe000e408: Interrupt Priority 2
NVIC_IPR3	32	0	rw	0xe000e40c: Interrupt Priority 3
CPUID	32	412fc230	r-	0xe000ed00: CPUID Base
ICSR	32	1000	rw	0xe000ed04: Interrupt Control and State
VTOR	32	0	rw	0xe000ed08: Vector Table Offset
AIRCR	32	fa050000	rw	0xe000ed0c: Application Interrupt and Reset Control
SCR	32	0	rw	0xe000ed10: System Control
CCR	32	200	rw	0xe000ed14: Configuration and Control
SHPR1	32	0	rw	0xe000ed18: System Handler Priority 1
SHPR2	32	0	rw	0xe000ed1c: System Handler Priority 2
SHPR3	32	0	rw	0xe000ed20: System Handler Priority 3
SHCSR	32	0	rw	0xe000ed24: System Handler Control and State
CFSR	32	0	rw	0xe000ed28: Configurable Fault Status
HFSR	32	0	rw	0xe000ed2c: HardFault Status
DFSR	32	0	rw	0xe000ed30: Debug Fault Status Register
MMAR	32	0	rw	0xe000ed34: MemManage Fault Address
BFAR	32	0	rw	0xe000ed38: BusFault Address
AFSR	32	0	rw	0xe000ed3c: Auxiliary Fault Status
ID_PFR0	32	30	rw	0xe000ed40: Processor Feature 0
ID_PFR1	32	200	rw	0xe000ed44: Processor Feature 1
ID_DFR0	32	0	rw	0xe000ed48: Debug Feature 0
ID_AFR0	32	0	rw	0xe000ed4c: Auxiliary Feature 0
ID_MMFR0	32	30	rw	0xe000ed50: Memory Model Feature 0
ID_MMFR1	32	0	rw	0xe000ed54: Memory Model Feature 1
ID_MMFR2	32	0	rw	0xe000ed58: Memory Model Feature 2
ID_MMFR3	32	0	rw	0xe000ed5c: Memory Model Feature 3
ID_ISAR0	32	1141110	rw	0xe000ed60: Instruction Set Attributes 0
ID_ISAR1	32	2111000	rw	0xe000ed64: Instruction Set Attributes 1
ID_ISAR2	32	20112231	rw	0xe000ed68: Instruction Set Attributes 2
ID_ISAR3	32	1111110	rw	0xe000ed6c: Instruction Set Attributes 3
ID_ISAR4	32	1310102	rw	0xe000ed70: Instruction Set Attributes 4
ID_ISAR5	32	0	rw	0xe000ed74: Instruction Set Attributes 5
CPACR	32	0	rw	0xe000ed88: Coprocessor Access Control
MPU_TYPE	32	800	rw	0xe000ed90: MPU Type
MPU_CONTROL	32	0	rw	0xe000ed94: MPU Control
MPU_RNR	32	0	rw	0xe000ed98: MPU Region Number
MPU_RBAR	32	0	rw	0xe000ed9c: MPU Region Base Address
MPU_RASR	32	0	rw	0xe000eda0: MPU Region Attribute and Size
MPU_RBAR_A1	32	0	rw	0xe000eda4: MPU Region Base Address Alias 1
0	J 22		1 11	oncooperate the oriogist base riddress than i

MPU_RASR_A1	32	0	rw	0xe000eda8: MPU Region Attribute and Size Alias 1
MPU_RBAR_A2	32	0	rw	0xe000edac: MPU Region Base Address Alias 2
MPU_RASR_A2	32	0	rw	0xe000edb0: MPU Region Attribute and Size Alias 2
MPU_RBAR_A3	32	0	rw	0xe000edb4: MPU Region Base Address Alias 3
MPU_RASR_A3	32	0	rw	0xe000edb8: MPU Region Attribute and Size Alias 3
DEMCR	32	0	rw	0xe000edfc: Debug Exception and Monitor Control
STIR	32	-	-w	0xe000ef00: Software Triggered Interrupt

Table 13.3: Registers at level 1, group:System

13.1.4 Integration_support

Registers at level:1, group:Integration_support

Name	Bits	Initial-Hex	RW	Description
executionPri	32	7ffffff	r-	current execution priority level
stackDomain	64	7f6f	r-	stack domain for current execution level
		b1c935e0		
HaltReason	8	0	r-	bit field indicating halt reason
atomicType	8	0	r-	current atomic instruction type (1:atomic, 2:exclusive)

Table 13.4: Registers at level 1, group:Integration_support